

SECTION **BL**

BODY, LOCK & SECURITY SYSTEM

CONTENTS

PRECAUTIONS	4	Component Parts and Harness Connector Location..	16	A
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4	System Description	17	B
Precautions for work	4	WITH LEFT FRONT ONLY FRONT POWER WINDOW ANTI-PINCH SYSTEM	17	C
Wiring Diagnosis and Trouble Diagnosis	4	WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM	17	D
PREPARATION	5	OUTLINE	17	E
Special Service Tool	5	KEY-TRAP PREVENTIVE FUNCTION	18	F
Commercial Service Tool	5	Schematic	19	G
SQUEAK AND RATTLE TROUBLE DIAGNOSES	6	Wiring Diagram — D/LOCK —	20	H
Work Flow	6	FIG. 1	20	I
CUSTOMER INTERVIEW	6	FIG. 2	21	BL
DUPLICATE THE NOISE AND TEST DRIVE	7	FIG. 3	22	J
CHECK RELATED SERVICE BULLETINS	7	FIG. 4	23	K
LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE	7	Terminals and Reference Value for BCM	24	L
REPAIR THE CAUSE	7	Work Flow	24	M
CONFIRM THE REPAIR	8	CONSULT-II Function (BCM)	25	
Generic Squeak and Rattle Troubleshooting	8	CONSULT-II BASIC OPERATION PROCEDURE	25	
INSTRUMENT PANEL	8	DATA MONITOR	27	
CENTER CONSOLE	8	ACTIVE TEST	27	
DOORS	8	Symptom Chart	28	
TRUNK	9	BCM Power Supply and Ground Circuit Check	28	
SUNROOF/HEADLINING	9	Door Switch Check	30	
OVERHEAD CONSOLE (FRONT AND REAR).....	9	Key Switch (Insert) Check	32	
SEATS	9	Door Lock/Unlock Switch Check (With left front only power window anti-pinch system)	33	
UNDERHOOD	9	Door Lock/Unlock Switch Check (With left and right front power window anti-pinch system)	36	
Diagnostic Worksheet	10	Front Door Lock Assembly LH (Actuator) Check ...	38	
HOOD	12	Door Lock Actuator Check (Front RH and Rear LH/ RH)	39	
Fitting Adjustment	12	Front Door Lock Assembly LH (Key Cylinder Switch) Check (With left front only power window anti-pinch system)	40	
FRONT END HEIGHT ADJUSTMENT AND LATERAL/ LONGITUDINAL CLEARANCE ADJUSTMENT	12	Door Lock/Unlock Switch Check (With left and right front power window anti-pinch system)	41	
SURFACE HEIGHT ADJUSTMENT	12	Power Window and Door Lock/Unlock Switch RH (With left and right front power window anti-pinch		
Removal and Installation of Hood Assembly	13			
Removal and Installation of Hood Lock Control	14			
REMOVAL	14			
INSTALLATION	14			
Hood Lock Control Inspection	15			
POWER DOOR LOCK SYSTEM	16			

system)	43	Removal and Installation of Door Lock	77
Front Door Lock Assembly LH (Key Cylinder Switch)		REMOVAL	77
Check (With left and right front power window anti-pinch system)	44	Disassembly and Assembly	78
REMOTE KEYLESS ENTRY SYSTEM	46	DISASSEMBLY	78
Component Parts and Harness Connector Location ..	46	ASSEMBLY	78
System Description	47	TRUNK LID	79
INPUTS	47	Fitting Adjustment	79
OPERATED PROCEDURE	47	LONGITUDINAL AND LATERAL CLEARANCE	
CAN Communication System Description	48	ADJUSTMENT	80
Schematic	49	SURFACE HEIGHT ADJUSTMENT	80
Wiring Diagram — KEYLES —	50	Removal and Installation of Trunk Lid Assembly ...	80
FIG. 1	50	Removal and Installation of Trunk Lid Lock	80
FIG. 2	51	LOCK REMOVAL	80
FIG. 3	52	STRIKER REMOVAL	81
FIG. 4	53	LOCK AND STRIKER INSTALLATION	81
Terminals and Reference Value for BCM	54	Removal and Installation of Trunk Lid Weatherstrip..	81
CONSULT-II Function (BCM)	55	TRUNK LID OPENER	82
CONSULT-II Inspection Procedure	55	Wiring Diagram — TLID —	82
“MULTI REMOTE ENT”	55	Terminals and Reference Value for BCM	83
CONSULT-II Application Items	56	VEHICLE SECURITY (THEFT WARNING) SYSTEM..	84
“MULTI REMOTE ENT”	56	Component Parts and Harness Connector Location..	84
Trouble Diagnosis Procedure	58	System Description	86
BCM Power Supply and Ground Circuit Check	58	DESCRIPTION	86
Trouble Diagnoses	59	POWER SUPPLY	86
SYMPTOM CHART	59	INITIAL CONDITION TO ACTIVATE THE SYS-	
Keyfob Battery and Function Check	61	TEM	86
Door Switch Check	62	VEHICLE SECURITY SYSTEM ALARM OPER-	
Key Switch (Insert) Check	64	ATION	86
Trunk Release Solenoid Check	65	VEHICLE SECURITY SYSTEM DEACTIVATION..	87
Check Hazard Function	67	PANIC ALARM OPERATION	87
Check Horn Function	67	CAN Communication System Description	87
Check Headlamp Function	67	Schematic	88
Check Room Lamp, Step Lamp and Ignition Key Illu-		Wiring Diagram — VEHSEC —	89
mination Function	67	FIG. 1	89
ID Code Entry Procedure	68	FIG. 2	90
KEYFOB ID SET UP WITH CONSULT-II	68	FIG. 3	91
KEYFOB ID SET UP WITHOUT CONSULT-II	70	FIG. 4	92
Keyfob Battery Replacement	71	Terminals and Reference Value for BCM	93
DOOR	72	Terminals and Reference Value for IPDM E/R	93
Fitting Adjustment	72	CONSULT-II Function (BCM)	94
FRONT DOOR	72	CONSULT-II INSPECTION PROCEDURE	94
REAR DOOR	72	CONSULT-II APPLICATION ITEM	96
STRIKER ADJUSTMENT	73	Trouble Diagnosis	97
Removal and Installation	73	WORK FLOW	97
Door Weatherstrip	74	Preliminary Check	98
FRONT DOOR LOCK	75	Symptom Chart	99
Component Structure	75	BCM Power Supply and Ground Circuit Check ...	100
Inspection and Adjustment	75	Door Switch Check	101
EXTERIOR HANDLE ROD ADJUSTMENT	75	TRUNK LAMP SWITCH AND TRUNK RELEASE	
Removal and Installation	75	SOLENOID SWITCH CHECK	103
REMOVAL	75	TRUNK KEY CYLINDER SWITCH (UNLOCK	
Disassembly and Assembly	76	SWITCH) SIGNAL	104
DISASSEMBLY	76	SECURITY INDICATOR LAMP CHECK	105
ASSEMBLY	76	FRONT DOOR LOCK ASSEMBLY LH (KEY CYL-	
REAR DOOR LOCK	77	INDER SWITCH) CHECK	106
Components	77	VEHICLE SECURITY HORN ALARM CHECK ...	106
Inspection and Adjustment	77	VEHICLE SECURITY HEADLAMP ALARM	
EXTERIOR HANDLE ROD ADJUSTMENT	77	CHECK	106
		DOOR LOCK/UNLOCK SWITCH CHECK	106

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)	107	ANTI-CORROSIVE WAX	134	
Component Parts and Harness Connector Location	107	UNDERCOATING	135	A
System Description	108	Body Sealing	136	
System Composition	108	DESCRIPTION	136	
ECM Re-communicating Function	109	Body Construction	139	B
Wiring Diagram — NATS —	110	BODY CONSTRUCTION	139	
Terminals and Reference Value for BCM	111	Body Alignment	140	
CONSULT-II	111	BODY CENTER MARKS	140	C
CONSULT-II INSPECTION PROCEDURE	111	PANEL PARTS MATCHING MARKS	141	
CONSULT-II DIAGNOSTIC TEST MODE FUNCTION	112	DESCRIPTION	142	
HOW TO READ SELF-DIAGNOSTIC RESULTS	113	ENGINE COMPARTMENT	143	D
NVIS (NATS) SELF-DIAGNOSTIC RESULTS		UNDERBODY	145	
ITEM CHART	113	PASSENGER COMPARTMENT	147	
Work Flow	114	REAR BODY	149	E
Trouble Diagnoses	115	Handling Precautions for Plastics	151	
SYMPTOM MATRIX CHART 1	115	HANDLING PRECAUTIONS FOR PLASTICS	151	
SYMPTOM MATRIX CHART 2	116	LOCATION OF PLASTIC PARTS	152	F
DIAGNOSTIC SYSTEM DIAGRAM	116	Precautions in Repairing High Strength Steel	154	
Diagnostic Procedure 1	117	HIGH STRENGTH STEEL (HSS) USED IN NISSAN VEHICLES	154	
Diagnostic Procedure 2	118	Foam Repair	156	G
Diagnostic Procedure 3	119	URETHANE FOAM APPLICATIONS	156	
Diagnostic Procedure 4	120	FILL PROCEDURES	156	
Diagnostic Procedure 5	121	Replacement Operations	157	H
Diagnostic Procedure 6	124	DESCRIPTION	157	
How to Replace NVIS (NATS) IMMU	125	HOODLEDGE	160	
HOMELINK UNIVERSAL TRANSCEIVER	126	HOODLEDGE (PARTIAL REPLACEMENT)	161	
Wiring Diagram — TRNSCV —	126	FRONT SIDE MEMBER	162	BL
Trouble Diagnoses	127	FRONT SIDE MEMBER (PARTIAL REPLACEMENT)	164	
DIAGNOSTIC PROCEDURE	127	FRONT PILLAR	165	J
BODY REPAIR	128	CENTER PILLAR	168	
Body Exterior Paint Color	128	OUTER SILL	169	
Body Component Parts	129	REAR FENDER	170	K
UNDERBODY COMPONENT PARTS	129	REAR PANEL	171	
BODY COMPONENT PARTS	131	REAR FLOOR REAR	172	
Corrosion Protection	133	REAR SIDE MEMBER EXTENSION	173	L
DESCRIPTION	133			M

PRECAUTIONS

PRECAUTIONS

PF0:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EIS003H8

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for work

EIS003H9

- After removing and installing the opening/closing parts, be sure to carry out fitting adjustments to check their operation.
- Check the lubrication level, damage, and wear of each part. If necessary, grease or replace it.

Wiring Diagnosis and Trouble Diagnosis

EIS003HA

When you read wiring diagrams, refer to the following:

- [GI-14, "How to Read Wiring Diagrams"](#).
- [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

When you perform trouble diagnosis, refer to the following:

- [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#).
- [GI-26, "How to Perform Efficient Diagnosis for an Electrical Incident"](#).
Check for any Service bulletins before servicing the vehicle.

PREPARATION

PREPARATION



PF0:00002

Special Service Tool

EIS003HB

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.


Tool number (Kent-Moore No.) Tool name	Description
— (J-39570) Chassis ear	Locating the noise
— (J-43980) NISSAN Squeak and Rattle Kit	Repairing the cause of noise
— (J-43241) Remote Keyless Entry Tester	Used to test keyfobs



Commercial Service Tool

EIS003HC

(Kent-Moore No.) Tool name	Description
(J-39565) Engine ear	Locating the noise



A
B
C
D
E
F
G
H
BL
J
K
L
M


SQUEAK AND RATTLE TROUBLE DIAGNOSES

SQUEAK AND RATTLE TROUBLE DIAGNOSES

PF0:0000

Work Flow

EIS00486



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [BL-10, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from. Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise. Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks. Refer to [BL-8, "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-43980) is available through your authorized NISSAN Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

Always check with the Parts Department for the latest parts information.

The following materials are contained in the NISSAN Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100×135 mm (3.94×5.31 in)/76884-71L01: 60×85 mm (2.36×3.35 in)/76884-71L02: 15×25 mm (0.59×0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50×50 mm (1.97×1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50×50 mm (1.97×1.97 in)

INSULATOR (Light foam block)

SQUEAK AND RATTLE TROUBLE DIAGNOSES

80845-71L00: 30 mm (1.18 in) thick, 30×50 mm (1.18×1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15×25 mm (0.59×0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll. The following materials not found in the kit can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used instead of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

EIS00487

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-43980) to repair the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner. In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headliner and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

1. Loose harness or harness connectors.
2. Front console map/reading lamp lense loose.
3. Loose screws at console attachment points.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A

B

C

D

E

F

G

H

BL

J

K

L

M

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Diagnostic Worksheet

EIS00488




SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Nissan Customer:

We are concerned about your satisfaction with your Nissan vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Nissan right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to the back of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

LIWA0276E

SQUEAK AND RATTLE TROUBLE DIAGNOSES

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET- page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (check the boxes that apply)

- | | |
|--|---|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the sun |
| <input type="checkbox"/> 1 st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: _____ |

III. WHEN DRIVING:

- through driveways
- over rough roads
- over speed bumps
- only at about ____ mph
- on acceleration
- coming to a stop
- on turns : left, right or either (circle)
- with passengers or cargo
- other: _____
- after driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE?

- squeak (like tennis shoes on a clean floor)
- creak (like walking on an old wooden floor)
- rattle (like shaking a baby rattle)
- knock (like a knock on a door)
- tick (like a clock second hand)
- thump (heavy, muffled knock noise)
- buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

	<u>YES</u>	<u>NO</u>	<u>Initials of person performing</u>
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____




VIN: _____ Customer Name: _____

W.O. #: _____ Date: _____

SBT844





This form must be attached to Work Order

HOOD Fitting Adjustment



Unit: mm (in)

N·m (kg·m, ft·lb)



LIA1526E

FRONT END HEIGHT ADJUSTMENT AND LATERAL/LONGITUDINAL CLEARANCE ADJUSTMENT

1. Loosen the hood lock and adjust the height by rotating the bumper rubber until the hood becomes 1 to 1.5 mm (0.04 to 0.059 in) higher than the fender.
2. Temporarily tighten the hood lock, and position it by engaging it with the hood striker. Check the lock and striker for looseness, and tighten the bolts to the specified torque.

SURFACE HEIGHT ADJUSTMENT

1. Remove the hood lock, and adjust the surface height difference of the hood and fender according to the fitting standard dimension, by rotating RH and LH bumper rubbers.
2. Install the hood lock temporarily, and align the hood striker and lock so that the centers of striker and lock become vertical viewed from the front, by moving the hood lock laterally.


HOOD

3. Check that the secondary latch is properly engaged with the secondary striker with hood's own weight by dropping it from approx. 200 mm (7.87 in) height or by pressing it lightly approx. 3 kg (29 N).

CAUTION:

Do not drop the hood from 300 mm (11.81 in) height or higher.




4. Move the hood lock up and down so that the striker and lock are engaged firmly with the hood closed.
5. Tighten the bolts to the specified torque.



EIS003HH

Removal and Installation of Hood Assembly

SEC. 650



: Apply body grease.

: N·m (kg-m, ft-lb)

LIIA1527E

1. Remove the nuts on the hood to remove the hood assembly. Installation is in the reverse order of removal.


A
B
C
D
E
F
G
H
BL
J
K
L
M

HOOD

Removal and Installation of Hood Lock Control

EIS003HI

SEC. 656




REMOVAL

1. Disconnect the hood lock cable from the hood lock, and unclip it from the radiator core upper support and hood ledge.
2. Remove the screws and the hood opener.
3. Remove the grommet from the dash lower, and pull the hood lock cable into the passenger compartment.


CAUTION:

While pulling, be careful not to damage (peeling) the outside of the hood lock cable.




INSTALLATION

1. Pull the hood lock cable through the hole in the lower dash and into the engine compartment. Be careful not to bend the cable too much, keeping the radius 100 mm (3.94 in) or more.
2. Check that the cable is not offset from the grommet, and push the grommet into the panel hole securely.
3. Apply the sealant to the grommet (at * mark) properly.



HOOD

4. Install the cable securely to the lock.
5. After installing, check the hood lock adjustment and hood opener operation.




EIS003HJ

Hood Lock Control Inspection


CAUTION:

If the hood lock cable is bent or deformed, replace it.

1. Check that the secondary latch is properly engaged with the secondary striker with hood's own weight by dropping it from approx. 200 mm (7.87 in) height.
2. While operating the hood opener, carefully check that the front end of the hood is raised by approx. 20 mm (0.79 in). Also check that the hood opener returns to the original position.



3. Check the hood lock lubrication condition. If necessary, apply "body grease" to the points shown in the figure.




POWER DOOR LOCK SYSTEM

POWER DOOR LOCK SYSTEM

PFP:24814

Component Parts and Harness Connector Location

EIS003HK



LIA1870E

POWER DOOR LOCK SYSTEM

EIS003HL

System Description

Power is supplied at all time

- to BCM terminal 70
- through 50A fusible link (letter **f**, located in the fuse and fusible link box)
- through 10A fuse [No. 21, located in the fuse block (J/B)]
- to BCM terminal 57
- to key switch and key lock solenoid terminal 3.

With ignition key inserted, power is supplied

- through key switch and key lock solenoid terminal 4
- to BCM terminal 37.

WITH LEFT FRONT ONLY FRONT POWER WINDOW ANTI-PINCH SYSTEM

Ground is supplied to terminal 67 of the BCM through body grounds M57, M61 and F14.

When the door is unlocked with main power window and door lock/unlock switch, ground is supplied

- through terminal 19 of main power window and door lock/unlock switch through body grounds M57, M61 and F14
- to BCM terminal 46
- through main power window and door lock/unlock switch terminal 17.

When the door is locked with main power window and door lock/unlock switch, ground is supplied

- through terminal 19 of main power window and door lock/unlock switch through body grounds M57, M61 and F14
- to BCM terminal 45
- through main power window and door lock/unlock switch terminal 18.

When the door is unlocked with power window and door lock/unlock switch RH, ground is supplied

- through terminal 19 power window and door lock/unlock switch RH through body grounds M57, M61 and F14
- to BCM terminal 46
- through power window and door lock/unlock switch RH terminal 20.

When the door is locked with power window and door lock/unlock switch RH, ground is supplied

- through terminal 19 of power window and door lock/unlock switch RH through body grounds M57, M61 and F14
- to BCM terminal 45
- through power window and door lock/unlock switch RH terminal 18.

When the door is locked with front door lock assembly LH (key cylinder switch), ground is supplied

- to BCM terminal 8
- through body grounds M57, M61 and F14.

When the door is unlocked with front door lock assembly LH (key cylinder switch), ground is supplied

- to BCM terminal 7
- through body grounds M57, M61 and F14.

WITH LEFT AND RIGHT FRONT POWER WINDOW ANTI-PINCH SYSTEM

BCM is connected to main power window and door lock/unlock switch and power window and door lock/unlock switch RH as power window serial link.

Main power window and door lock/unlock switch and power window and door lock/unlock switch RH output to key cylinder lock/unlock switch, central lock/unlock switch and power window UP/DOWN control by key cylinder switch as DATA LINE (power window serial link) to BCM.

OUTLINE

Functions available by operating the central switches on driver's door and passenger's door

- Interlocked with the locking operation of central switch, door lock actuators of all doors are locked.
- Interlocked with the unlocking operation of central switch, door lock actuators of all doors are unlocked.

A
B
C
D
E
F
G
H
BL
J
K
L
M

POWER DOOR LOCK SYSTEM

Functions available by operating the key cylinder switch on driver's door


- Interlocked with the locking operation of door key cylinder, door lock actuators of all doors are locked.
- When door key cylinder is unlocked, front door lock assembly LH (actuator) is unlocked.
- When door key cylinder is unlocked for the second time within 5 seconds after the first operation, door lock actuators on all doors are unlocked.

Key-trap preventive function

When door lock switch LH or RH is operated to lock doors with ignition key put in key cylinder and any door open, all door lock actuators are locked and then unlocked.

KEY-TRAP PREVENTIVE FUNCTION


Time chart



POWER DOOR LOCK SYSTEM

Schematic

EIS003HM



A
B
C
D
E
F
G
H
I
J
K
L
M

BL



WIWA1027E

POWER DOOR LOCK SYSTEM

Wiring Diagram — D/LOCK —
FIG. 1

EIS003HN






BL-D/LOCK-01



WIWA0420E

POWER DOOR LOCK SYSTEM

FIG. 2





WIWA0421E

POWER DOOR LOCK SYSTEM

FIG. 3

BL-D/LOCK-03









WIWA1017E

POWER DOOR LOCK SYSTEM

FIG. 4

(A1) : WITH LEFT FRONT ONLY POWER WINDOW ANTI-PINCH SYSTEM

BL-D/LOCK-04




LIWA0386E

POWER DOOR LOCK SYSTEM

Terminals and Reference Value for BCM

EIS003HO

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
7	W/L	Front door lock assembly LH (key cylinder switch) (unlock)	OFF (neutral) → ON (unlocked)	5V → 0V
8	P/L	Front door lock assembly LH (key cylinder switch) (lock)	OFF (neutral) → ON (locked)	5V → 0V
12	P/L	Front door switch RH	Door open (ON) → Door close (OFF)	0V → Battery voltage
13	R/W	Rear door switch RH	Door open (ON) → Door close (OFF)	0V → Battery voltage
22	Y/G	Power window serial link	—	 <p style="text-align: right; font-size: small;">LIA0166E</p>
37	B/R	Key switch (insert)	Key inserted (ON) → Key removed from IGN key cylinder (OFF)	Battery voltage → 0V
45	BR	Lock switch signal	Door lock and unlock switch (unlocked → locked)	Battery voltage → 0V
46	P	Unlock switch signal	Door lock and unlock switch (locked → unlocked)	Battery voltage → 0V
47	SB	Front door switch LH	Door open (ON) → Door close (OFF)	0V → Battery voltage
48	R/B	Rear door switch LH	Door open (ON) → Door close (OFF)	0V → Battery voltage
57	W	Battery power supply	—	Battery voltage
59	G/W	Front door lock assembly LH (actuator) (unlock)	Driver door lock knob (locked → unlocked)	0V → Battery voltage
65	Y/R	All door lock actuator (lock)	Driver door lock knob (neutral → lock)	0V → Battery voltage
66	G/R	Front door lock actuator RH and Rear door lock actuators LH/RH (unlock)	Door lock and unlock switch (locked → unlocked)	0V → Battery voltage
67	B	Ground	—	—
70	W/B	Battery power supply	—	Battery voltage

Work Flow

EIS003HP

1. Check the symptom and customer's requests.
2. Understand the outline of system. Refer to [BL-17, "System Description"](#) .
3. Perform BCM Power Supply and Ground Circuit Check. Refer to [BL-28, "BCM Power Supply and Ground Circuit Check"](#) .
4. According to the trouble diagnosis chart, repair or replace the cause of the malfunction. Refer to [BL-28, "Symptom Chart"](#) .
5. Does power door lock system operate normally? OK: GO TO 6, NG: GO TO 4.
6. INSPECTION END.

POWER DOOR LOCK SYSTEM

CONSULT-II Function (BCM)

EIS003HQ

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnostic test item	Diagnostic mode	Content
Inspection by part	WORK SUPPORT	Changes setting of each function.
	DATA MONITOR	Displays BCM input/output data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
	SELF-DIAG RESULTS	Displays BCM self-diagnosis results.
	CAN DIAG SUPPORT MNTR	The results of transmit/receive diagnosis of CAN communication can be read.
	ECU PART NUMBER	BCM part number can be read.
	CONFIGURATION	Performs BCM configuration read/write functions.

CONSULT-II BASIC OPERATION PROCEDURE


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communications.


1. With ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to data link connector on vehicle, and turn ON ignition switch.



2. Touch "START (NISSAN BASED VHCL)".



3. Touch "BCM" on "SELECT SYSTEM" screen.



POWER DOOR LOCK SYSTEM

4. Select item to be diagnosed on "SELECT TEST ITEM" screen.

SELECT TEST ITEM
COMB SW
WIPER
BCM C/U
FLASHER
SIGNAL BUFFER
TRUNK

LKIA0099E

POWER DOOR LOCK SYSTEM

DATA MONITOR

Operation procedure

1. Touch "DOOR LOCK" on the "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on the "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on the "DATA MONITOR" screen.

ALL SIGNALS	Monitor all items.
SELECTION FROM MENU	Select and monitor the item.

4. Touch "START".
5. If "SELECTION FROM MENU" is selected, touch the desired monitor item. If "ALL SIGNALS" is selected, all the items are monitored.
6. During monitoring, touching "COPY" can start recording the monitor item status.

Display item list

Monitor item "OPERATION"	Content
IGN ON SW	"ON/OFF" Indicates [ON/OFF] condition of ignition switch.
KEY ON SW	"ON/OFF" Indicates [ON/OFF] condition of key switch.
CDL LOCK SW	"ON/OFF" Indicates [ON/OFF] condition of lock signal from lock/unlock switch LH and RH.
CDL UNLOCK SW	"ON/OFF" Indicates [ON/OFF] condition of unlock signal from lock/unlock switch LH and RH.
KEY CYL LK-SW	"ON/OFF" Indicates [ON/OFF] condition of lock signal from key cylinder.
KEY CYL UN-SW	"ON/OFF" Indicates [ON/OFF] condition of unlock signal from key cylinder.
DOOR SW-DR	"ON/OFF" Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	"ON/OFF" Indicates [ON/OFF] condition of front door switch RH.
DOOR SW-RR	"ON/OFF" Indicates [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	"ON/OFF" Indicates [ON/OFF] condition of rear door switch LH.

ACTIVE TEST

Operation procedure

1. Touch "DOOR LOCK" on the "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on the "SELECT DIAG MODE" screen.
3. Touch the item to be tested, and check the operation.
4. During the operation check, touching "OFF" deactivates the operation.

Display item list

Test item	Content
ALL D/LK MTR	This test is able to check all door lock actuators lock operation. These actuators lock when "ON" on CONSULT-II screen is touched.
DR D/UN MTR	This test is able to check front door lock assembly LH (actuator) unlock operation. These actuators lock when "ON" on CONSULT-II screen is touched.
NON DR D/UN	This test is able to check door lock actuators [except front door lock assembly LH (actuator)] unlock operation. These actuators unlock when "ON" on CONSULT-II screen is touched.

POWER DOOR LOCK SYSTEM

Symptom Chart

EIS003HR

Symptom	Malfunctioning system	Power window system
Key reminder door function does not operate properly.	Door switch check. Refer to BL-30, "Door Switch Check" .	—
	Key switch (Insert) check. Refer to BL-32, "Key Switch (Insert) Check" .	
	If above systems are "OK", replace BCM. Refer to BCS-20, "Removal and Installation of BCM" .	
Power door lock does not operate with door lock and unlock switch on main power window and door lock/unlock switch or power window and door lock/unlock switch RH	Door lock and unlock switch check. Refer to BL-33, "Door Lock/Unlock Switch Check (With left front only power window anti-pinch system)" .	With left front only anti-pinch system.
	Door lock and unlock switch check. Refer to BL-36, "Door Lock/Unlock Switch Check (With left and right front power window anti-pinch system)" .	With left and right front anti-pinch system.
Power door lock does not operate with driver door lock knob switch.	Door lock actuator check –Driver–. Refer to BL-38, "Front Door Lock Assembly LH (Actuator) Check" .	—
Specific door lock acutuator does not operate.	Door lock actuator check (passenger, Rear LH/ RH).Refer to BL-39, "Door Lock Actuator Check (Front RH and Rear LH/RH)" .	—
Power door lock does not operate with front door lock assembly LH (key cylinder switch) operation.	Front door lock assembly LH (key cylinder switch) check. Refer to BL-40, "Front Door Lock Assembly LH (Key Cylinder Switch) Check (With left front only power window anti-pinch system)" .	With left front only anti-pinch system.
	Door lock and unlock switch check. Refer to BL-41, "Door Lock/Unlock Switch Check (With left and right front power window anti-pinch system)" .	With left and right front anti-pinch system.
	Front door lock assembly LH (key cylinder switch) check. Refer to BL-44, "Front Door Lock Assembly LH (Key Cylinder Switch) Check (With left and right front power window anti-pinch system)" .	
	If above systems are "OK", replace BCM. Refer to BCS-20, "Removal and Installation of BCM" .	—

BCM Power Supply and Ground Circuit Check

EIS003HS

1. CHECK FUSE

- Check the following BCM fuses and fusible link.

Component Parts	Terminal No. (SIGNAL)	Ampere	No.	Location
BCM	57 (BAT power supply)	10A	21	Fuse block (J/B)
	70 (BAT power supply)	50A	f	Fuse and fusible link box

NOTE:

Refer to [BL-16, "Component Parts and Harness Connector Location"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

POWER DOOR LOCK SYSTEM


2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check voltage between BCM connector M20 terminals 57, 70 and ground.

Connector	Terminals (Wire color)		Signal name	Ignition switch	Voltage (V) (Approx.)
	(+)	(-)			
M20	57 (W)	Ground	Battery power supply	OFF	Battery voltage
	70 (W/B)		Battery power supply	OFF	Battery voltage

OK or NG

- OK >> GO TO 3.
 NG >> Repair or replace harness.




3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M20 terminal 67 and ground.

Connector	Terminals (Wire color)		Continuity
	(+)	(-)	
M20	67 (B)	Ground	Yes

OK or NG

- OK >> Power supply and ground circuit is OK.
 NG >> Repair or replace harness.



POWER DOOR LOCK SYSTEM

EIS003HT

Door Switch Check

1. CHECK DOOR SWITCHES INPUT SIGNAL

 With CONSULT-II

Check door switches ("DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR") in DATA MONITOR mode with CONSULT-II. Refer to [BL-27, "DATA MONITOR"](#).

- When any doors are open:

DOOR SW-DR : ON
DOOR SW-AS : ON
DOOR SW-RL : ON
DOOR SW-RR : ON

- When any doors are closed:

DOOR SW-DR : OFF
DOOR SW-AS : OFF
DOOR SW-RL : OFF
DOOR SW-RR : OFF


DATA MONITOR	
MONITOR	
DOOR SW - DR	OFF
DOOR SW - AS	OFF
DOOR SW - RR	OFF
DOOR SW - RL	OFF

PIIA6222E

 Without CONSULT-II

Check voltage between BCM connector M18 or M19 terminals 12, 13, 47, 48 and ground.

Connector	Item	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
		(+)	(-)		
M18	Front door switch RH	12 (P/L)	Ground	Open ↓ Closed	0 ↓ Battery voltage
	Rear door switch RH	13 (R/W)			
M19	Front door switch LH	47 (SB)			
	Rear door switch LH	48 (R/B)			



OK or NG

- OK >> System is OK.
 NG >> GO TO 2.

POWER DOOR LOCK SYSTEM


2. CHECK DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door switch and BCM.
3. Check continuity between door switch connector B8 (Front LH) or B108 (Front RH) terminal 2, B18 (Rear LH) or B116 (Rear RH) terminal 1 and BCM connector M18, M19 terminals 12, 13, 47 and 48.

2 (SB) - 47 (SB) : Continuity should exist
2 (P/L) - 12 (P/L) : Continuity should exist
1 (R/B) - 48 (R/B) : Continuity should exist
1 (R/W) - 13 (R/W) : Continuity should exist

4. Check continuity between door switch connector B8 (Front LH) or B108 (Front RH) terminal 2, B18 (Rear LH) or B116 (Rear RH) terminal 1 and ground.

2 (SB or P/L) - Ground : Continuity should not exist
1 (R/B or R/W) - Ground : Continuity should not exist



OK or NG

- OK >> GO TO 3.
 NG >> Repair or replace harness.


3. CHECK DOOR SWITCHES

1. Disconnect door switch harness.
2. Check continuity between door switch connector terminals.

	Terminals (Wire color)	Condition	Continuity
Front door switch LH/RH	2 – Ground	Open	Yes
		Closed	No
Rear door switch LH/RH	1 – Ground	Open	Yes
		Closed	No

OK or NG

- OK >> Check door switch case ground condition.
 NG >> Replace door switch.



POWER DOOR LOCK SYSTEM

EIS003HU


Key Switch (Insert) Check

1. CHECK KEY SWITCH AND KEY LOCK SOLENOID INPUT SIGNAL

 With CONSULT-II

Check key switch "KEY ON SW" in DATA MONITOR mode with CONSULT-II. Refer to [BL-27, "DATA MONITOR"](#).

- When key is inserted to ignition key cylinder :
KEY ON SW : ON
- When key is removed from ignition key cylinder :
KEY ON SW : OFF




 Without CONSULT-II

Check voltage between BCM connector M18 terminal 37 and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M18	37 (B/R)	Ground	Key is inserted.	Battery voltage
			Key is removed.	0

OK or NG

- OK >> System is OK.
- NG >> GO TO 2.




2. CHECK KEY SWITCH (INSERT)

- Turn ignition switch OFF.
- Disconnect key switch and key lock solenoid connector.
- Check continuity between key switch and key lock solenoid connector terminals 3 and 4.

Terminals	Condition	Continuity
3 - 4	Key is inserted.	Yes
	Key is removed.	No

OK or NG

- OK >> GO TO 3.
- NG >> Replace key switch and key lock solenoid. Refer to [PS-9, "STEERING COLUMN"](#).



POWER DOOR LOCK SYSTEM

3. CHECK KEY SWITCH AND KEY LOCK SOLENOID CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between the BCM harness connector M18 terminal 37 and key switch and key lock solenoid harness connector M26 terminal 4.
3. Check continuity between BCM harness connector M18 terminal 37 and ground.


37 (B/R) - 4 (B/R) : Continuity should exist
37 (B/R) - Ground : Continuity should not exist

OK or NG

OK >> Check the following:

- 10A fuse [No. 21, located in fuse block (J/B)]
- Harness for open or short between key switch and key lock solenoid and fuse

NG >> Repair or replace harness.



Door Lock/Unlock Switch Check (With left front only power window anti-pinch system)

EIS003HV

1. CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL


With CONSULT-II

Check door lock/unlock switch ("CDL LOCK SW", "CDL UNLOCK SW") in DATA MONITOR mode in CONSULT-II. Refer to [BL-27, "DATA MONITOR"](#).

- When door lock/unlock switch is turned to LOCK :
- When door lock/unlock switch is turned to UNLOCK :

CDL LOCK SW : ON


CDL UNLOCK SW : ON



Without CONSULT-II

Check voltage between BCM connector M19 terminals 45, 46 and ground.

Connector	Terminal		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M19	46 (P)	Ground	Door lock/unlock switch is neutral.	Battery voltage
			Door lock/unlock switch is turned to UNLOCK.	0
	45 (BR)	Ground	Door lock/unlock switch is neutral.	Battery voltage
			Door lock/unlock switch is turned to LOCK.	0



OK or NG

- OK >> System is OK.
 NG >> GO TO 2.


POWER DOOR LOCK SYSTEM

2. CHECK DOOR LOCK/UNLOCK SWITCH GROUND HARNESS

Check continuity between main power window and door lock/unlock switch connector D6 terminal 19 and power window and door lock/unlock switch RH connector D105 terminal 19 and body ground.


- Main power window and door lock/unlock switch

Connector	Terminals	Continuity
D6	19 (B) – Ground	Yes



- Power window and door lock/unlock switch RH

Connector	Terminals	Continuity
D105	19 (B) – Ground	Yes



OK or NG


- OK >> GO TO 3.
- NG >> Repair or replace harness.

POWER DOOR LOCK SYSTEM

3. CHECK DOOR LOCK/UNLOCK SWITCH


1. Disconnect main power window and door lock/unlock switch or power window and door lock/unlock switch RH.
2. Check continuity between each door lock/unlock switch terminals.
 - Main power window and door lock/unlock switch

Terminals	Condition	Continuity
17 – 19	Neutral	No
	Unlock	Yes
18 – 19	Neutral	No
	Lock	Yes



- Power window and door lock/unlock switch RH

Terminals	Condition	Continuity
18 – 19	Neutral	No
	Lock	Yes
19 – 20	Neutral	No
	Unlock	Yes



OK or NG

- OK >> Repair or replace harness.
- NG >> Replace main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

A
B
C
D
E
F
G
H
J
K
L
M

BL

POWER DOOR LOCK SYSTEM

Door Lock/Unlock Switch Check (With left and right front power window anti-pinch system)

EIS003HW

1. CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

 With CONSULT-II

Check door lock/unlock switch ("CDL LOCK SW", "CDL UNLOCK SW") in DATA MONITOR mode in CONSULT-II. Refer to [BL-27, "DATA MONITOR"](#).


- When door lock/unlock switch is turned to LOCK :
CDL LOCK SW : ON
- When door lock/unlock switch is turned to UNLOCK :
CDL UNLOCK SW : ON


DATA MONITOR	
MONITOR	
CDL LOCK SW	OFF
CDL UNLOCK SW	OFF

PIIA6538E

 Without CONSULT-II

- Remove key from ignition key cylinder.
- Check the signal between BCM connector M18 terminal 22 and ground with oscilloscope when door lock/unlock switch is turned to LOCK or UNLOCK.
- Make sure the signals which are shown in the figure below can be detected during 10 seconds just after the door lock/unlock switch is turned to LOCK or UNLOCK.

Connector	Terminal (Wire color)		Signal (Reference value)
	(+)	(-)	
M18	22 (Y/G)	Ground	 <p style="text-align: right;">LIIA0166E</p>



OK or NG

- OK >> Door lock and unlock switch circuit is OK.
- NG >> GO TO 2.

2. CHECK BCM OUTPUT SIGNAL

Check ("POWER WINDOW DOWN") in ACTIVE TEST mode for "MULTI REMOTE ENT" with CONSULT-II. Refer to [BL-27, "ACTIVE TEST"](#).

When "ACTIVE TEST" is performed, are the front windows lowered?

OK or NG

- OK >> GO TO 3.
- NG >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).

ACTIVE TEST	
POWER WINDOW DOWN	OFF
ON	

PIIA3080E



POWER DOOR LOCK SYSTEM

3. CHECK ANTI-PINCH SERIAL LINK CIRCUIT

Check continuity between BCM harness connector M18 terminal 22 and main power window and door lock/unlock switch connector D7 terminal 14.

Con- nector	Terminal	Con- nector	Terminal	Continuity
M18	22 (Y/G)	D7	14(Y/G)	Yes
		D105	11(Y/G)	Yes

Check continuity between BCM connector M18 terminal 22 and power window and door lock/unlock switch RH connector D105 terminal 11.



OK or NG

- OK >> Replace main power window and door lock/unlock switch or power window and door lock/unlock switch RH.
- NG >> Repair or replace harness.

A
B
C
D
E
F
G
H
BL
J
K
L
M

POWER DOOR LOCK SYSTEM

EIS003HX


Front Door Lock Assembly LH (Actuator) Check

1. CHECK DOOR LOCK ACTUATOR SIGNAL

With CONSULT-II

Check front door lock assembly LH (actuator) "ALL D/LK MTR", "DR D/UN MTR" in ACTIVE TEST mode with CONSULT-II. Refer to [BL-27, "ACTIVE TEST"](#).


ALL D/LK MTR : ON/OFF
DR D/UN MTR : ON/OFF



Without CONSULT-II

Check voltage between BCM connector M20 terminals 59, 65 and ground.

Connector	Terminal		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M20	59 (G/W)	Ground	Driver door lock knob is turned to UNLOCK.	0 → Battery voltage
	65 (Y/R)	Ground	Driver door lock knob is turned to LOCK.	0 → Battery voltage




OK or NG

OK >> System is OK.
 NG >> GO TO 2.

2. CHECK DOOR LOCK ACTUATOR HARNESS

Check continuity between BCM connector M20 terminals 59, 65 and front door lock assembly LH (actuator) connector D51 terminals 1, 3 and body ground.

Connector	Terminal	Connector	Terminal	Continuity
M20	59 (G/W)	D51	3 (G/W)	Yes
	65 (Y/R)		1 (Y/R)	Yes
	59 (G/W), 65 (Y/R)	Ground		No



OK or NG

OK >> Replace front door lock assembly LH (actuator). Refer to [BL-75, "Removal and Installation"](#).
 NG >> Repair or replace harness.

POWER DOOR LOCK SYSTEM

EIS003HY


Door Lock Actuator Check (Front RH and Rear LH/RH)

1. CHECK DOOR LOCK ACTUATOR SIGNAL

With CONSULT-II

Check door lock actuators "ALL D/LK MTR", "NON DR D/UN" in ACTIVE TEST mode with CONSULT-II. Refer to [BL-27, "ACTIVE TEST"](#).


ALL D/LK MTR : ON/OFF
DR D/UN MTR : ON/OFF



Without CONSULT-II

Check voltage between BCM connector M20 terminals 65, 66 and ground.

Connector	Terminal		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M20	65 (Y/R)	Ground	Driver door lock knob is turned to LOCK.	0 → Battery voltage
	66 (G/R)	Ground	Door lock/unlock switch is turned to UNLOCK.	0 → Battery voltage




OK or NG

- OK >> System is OK.
- NG >> GO TO 2.

2. CHECK DOOR LOCK ACTUATOR HARNESS

Check continuity between BCM connector M20 terminals 65, 66 and front door lock actuator RH, rear door lock actuator LH/RH connector D151, D205 and D305 terminals 1, 3 and body ground.

Connector	Terminal	Connector	Terminal	Continuity
M20	65 (Y/R)	D151, D205, D305	1(Y/R)	Yes
	66 (G/R)		3(G/R)	Yes
	65 (Y/R), 66 (G/R)	Ground		No



OK or NG

- OK >> Replace front door lock actuator RH or rear door lock actuator LH/RH. Refer to [BL-75, "Removal and Installation"](#) (front) or [BL-77, "Removal and Installation of Door Lock"](#) (rear).
- NG >> Repair or replace harness.

POWER DOOR LOCK SYSTEM

Front Door Lock Assembly LH (Key Cylinder Switch) Check (With left front only power window anti-pinch system)


EIS003HZ

1. CHECK DOOR KEY CYLINDER SWITCH LH SIGNAL

 With CONSULT-II

Check front door lock assembly LH (key cylinder switch) ("KEY CYL LK-SW", "KEY CYL UN-SW") in DATA MONITOR mode in CONSULT-II. Refer to [BL-27, "DATA MONITOR"](#).


- When key inserted in front key cylinder is turned to LOCK:
KEY CYL LK-SW : ON
- When key inserted in front key cylinder is turned to UNLOCK:
KEY CYL UN-SW : ON



 Without CONSULT-II

Check voltage between BCM connector M18 terminals 7, 8 and ground.

Connector	Terminal		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M18	7 (W/L)	Ground	Front door lock assembly LH (key cylinder switch) is neutral.	5
			Front door lock assembly LH (key cylinder switch) is turned to UNLOCK.	0
	8 (P/L)	Ground	Front door lock assembly LH (key cylinder switch) is neutral.	5
			Front door lock assembly LH (key cylinder switch) is turned to LOCK.	0




OK or NG

- OK >> System is OK.
- NG >> GO TO 2.

2. CHECK FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) GROUND HARNESS

Check continuity between front door lock assembly LH (key cylinder switch) connector D50 terminal 3 and body ground.

Connector	Terminals	Continuity
D50	3 (B) – Ground	Yes



POWER DOOR LOCK SYSTEM


OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace harness.

3. CHECK FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH)

Check continuity between front door lock assembly LH (key cylinder switch) connector terminals.

Terminals	Condition	Continuity
1 - 3	Key is turned to LOCK or neutral.	No
	Key is turned to UNLOCK	Yes
2 - 3	Key is turned to UNLOCK or neutral.	No
	Key is turned to LOCK.	Yes



OK or NG

- OK >> Repair or replace harness.
- NG >> Replace front door lock assembly LH (key cylinder switch). Refer to [BL-75, "Removal and Installation"](#).

Door Lock/Unlock Switch Check (With left and right front power window anti-pinch system)


EIS00310

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

With CONSULT-II

Check main power window and door lock/unlock switch ("LOCK SW DR/AS", "UNLK SW DR/AS") in DATA MONITOR mode in CONSULT-II. Refer to [BL-27, "DATA MONITOR"](#).


- When main power window and door lock/unlock switch is turned to LOCK :
LOCK SW DR/AS : ON
- When main power window and door lock/unlock switch is turned to UNLOCK :
UNLK SW DR/AS : ON



Without CONSULT-II

Check voltage between BCM connector M18 terminal 22 and ground.

Connector	Terminal		Condition	Voltage (V)
	(+)	(-)		
M18	22 (Y/G)	Ground	—	<p>LIA0166E</p>



OK or NG


- OK >> System is OK.
- NG >> GO TO 2.

POWER DOOR LOCK SYSTEM

2. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH GROUND HARNESS

Check continuity between main power window and door lock/unlock switch connector D7 terminal 11 and body ground.

Connector	Terminals	Continuity
D7	11 (B) – Ground	Yes



OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace harness.


3. CHECK POWER WINDOW SERIAL LINK CIRCUIT

Check continuity between BCM connector M18 terminal 22 and main power window and door lock/unlock switch connector D7 terminal 14.

22 (Y/G) — 14 (Y/G) : Continuity should exist

OK or NG

- OK >> GO TO 4.
- NG >> Repair or replace harness.




4. CHECK DOOR LOCK/UNLOCK SWITCH

Check continuity between main power window and door lock/unlock switch terminals.

Terminals	Condition	Continuity
5 – 11	Key is turned to LOCK or neutral.	No
	Key is turned to UNLOCK	Yes
4 – 11	Key is turned to UNLOCK or neutral.	No
	Key is turned to LOCK.	Yes

OK or NG

- OK >> Repair or replace harness.
- NG >> Replace main power window and door lock/unlock switch or power window and door lock/unlock switch RH.



POWER DOOR LOCK SYSTEM

Power Window and Door Lock/Unlock Switch RH (With left and right front power window anti-pinch system)

EIS00311

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

With CONSULT-II


Check main power window and door lock/unlock switch ("LOCK SW DR/AS", "UNLK SW DR/AS") in DATA MONITOR mode in CONSULT-II. Refer to [BL-27, "DATA MONITOR"](#).

- When main power window and door lock/unlock switch is turned to LOCK :

LOCK SW DR/AS : ON

- When main power window and door lock/unlock switch is turned to UNLOCK :


UNLK SW DR/AS : ON



Without CONSULT-II

Check voltage between BCM connector M18 terminal 22 and ground.

Connector	Terminal		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M18	22 (Y/G)	Ground	—	<p>LIA0166E</p>



OK or NG


- OK >> System is OK.
- NG >> GO TO 2.

2. CHECK DOOR LOCK/UNLOCK SWITCH GROUND HARNESS

Check continuity between power window and door lock/unlock switch RH connector D106 terminal 7 and body ground.

- Power window and door lock/unlock switch RH

Connector	Terminals	Continuity
D106	7 (B) – Ground	Yes



OK or NG


- OK >> GO TO 3.
- NG >> Repair or replace harness.

POWER DOOR LOCK SYSTEM

3. CHECK DOOR LOCK/UNLOCK SWITCH

1. Disconnect power window and door lock/unlock switch RH.
 2. Check continuity between switch terminals 7 and 11.
- Power window and door lock/unlock switch RH

Terminals	Condition	Continuity
7 – 11	Neutral	No
	Lock	Yes
	Unlock	Yes



OK or NG

- OK >> Repair or replace harness.
- NG >> Replace power window and door lock/unlock switch RH.

Front Door Lock Assembly LH (Key Cylinder Switch) Check (With left and right front power window anti-pinch system)


EIS00312

1. CHECK DOOR KEY CYLINDER SWITCH LH SIGNAL

With CONSULT-II

Check front door lock assembly LH (key cylinder switch) ("KEY CYL LK-SW", "KEY CYL UN-SW") in DATA MONITOR mode in CONSULT-II. Refer to [BL-27, "DATA MONITOR"](#).

- When key inserted in front key cylinder is turned to LOCK :
 - KEY CYL LK-SW : ON**
- When key inserted in front key cylinder is turned to UNLOCK:
 - KEY CYL UN-SW : ON**




OK or NG

- OK >> System is OK.
- NG >> GO TO 2.

2. CHECK DOOR KEY CYLINDER SWITCH LH GROUND HARNESS

Check continuity between front door lock assembly LH (key cylinder switch) connector D50 terminal 3 and body ground.

Connector	Terminals	Continuity
D50	3 (B) – Ground	Yes



POWER DOOR LOCK SYSTEM


OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace harness.

3. CHECK DOOR KEY CYLINDER SWITCH LH

Check continuity between front door lock assembly LH (key cylinder switch) connector terminals.

Terminals	Condition	Continuity
1 - 3	Key is turned to LOCK or neutral.	No
	Key is turned to UNLOCK.	Yes
2 - 3	Key is turned to UNLOCK or neutral.	No
	Key is turned to LOCK.	Yes




OK or NG

- OK >> GO TO 4.
- NG >> Replace front door lock assembly LH (key cylinder switch). Refer to [BL-75, "Removal and Installation"](#).

4. CHECK DOOR KEY CYLINDER HARNESS

Check continuity between main power window and door lock/unlock switch connector D7 terminals 4, 5 and front door lock assembly LH (key cylinder switch) connector D50 terminals 1, 2 and body ground.

Connector	Terminal	Connector	Terminal	Continuity
D7	4 (P/L)	D50	2 (P/L)	Yes
	5 (W/L)		1 (W/L)	Yes
	4 (P/L), 5 (W/L)	Ground		No



OK or NG

- OK >> Replace main power window and door lock/unlock switch.
- NG >> Repair or replace harness.


REMOTE KEYLESS ENTRY SYSTEM

PF2:28596

REMOTE KEYLESS ENTRY SYSTEM

Component Parts and Harness Connector Location

EIS00313



LIA2219E

REMOTE KEYLESS ENTRY SYSTEM

EIS00314

System Description

INPUTS

Power is supplied at all times

- to BCM terminal 70
- through 50A fusible link (letter f , located in the fuse and fusible link box).

Power is supplied at all times

- to key switch terminal 3 and
- to BCM terminal 57
- through 10A fuse [No. 21, located in the fuse block (J/B)].

When the key switch is ON (ignition key is inserted in key cylinder), power is supplied

- through key switch terminal 4
- to BCM terminal 37.

When the front door switch LH is ON (door is OPEN), ground is supplied

- to BCM terminal 47.
- through front door switch LH terminal 2
- to front door switch LH case ground.

When the front door switch RH is ON (door is OPEN), ground is supplied

- to BCM terminal 12
- through front door switch RH terminal 2
- to front door switch RH case ground.

When the rear door switch RH is ON (door is OPEN), ground is supplied

- to BCM terminal 13
- through rear door switch RH terminal 1
- to rear door switch RH case ground.

When the rear door switch LH is ON (door is OPEN), ground is supplied

- to BCM terminal 48
- through rear door switch LH terminal 1
- to rear door switch LH case ground.

Keyfob signal is inputted to BCM.

The remote keyless entry system controls operation of the

- power door lock
- trunk lid opener
- interior lamp
- panic alarm
- hazard and horn reminder
- keyless power window down (open)

OPERATED PROCEDURE

Power Door Lock Operation

BCM receives a LOCK signal from keyfob. BCM locks all doors with input of LOCK signal from keyfob.

When an UNLOCK signal is sent from keyfob once, driver's door will be unlocked.

Then, if an UNLOCK signal is sent from keyfob again within 5 seconds, all other doors will be unlocked.

Hazard and Horn Reminder

BCM output to IPDM E/R for hazard and horn reminder signal as DATA LINE (CAN H line and CAN L line).

The hazard and horn reminder has C mode (horn chirp mode) and S mode (non-horn chirp mode).

A

B

C

D

E

F

G

H

BL

J

K

L

M

REMOTE KEYLESS ENTRY SYSTEM

Operating function of hazard and horn reminder

	C mode		S mode	
	Lock	Unlock	Lock	Unlock
Remote controller operation	Lock	Unlock	Lock	Unlock
Hazard warning lamp flash	Twice	Once	Twice	—
Horn sound	Once	—	—	—

How to change hazard and horn reminder mode

Ⓜ With CONSULT-II

Hazard and horn reminder can be changed using "WORK SUPPORT" mode in "MULTI ANSWER BACK SET".

ⓧ Without CONSULT-II

Refer to Owner's Manual for instructions.

Interior Lamp Operation

When the following input signals are both supplied:

- door switches OPEN (when all the doors are closed);
- driver's door LOCKED;

Remote keyless entry system turns on interior lamp and ignition illumination (for 30 seconds) with input of UNLOCK signal from keyfob.

For detailed description, refer to [LT-117, "ROOM LAMP TIMER OPERATION"](#) .

Panic Alarm Operation

When key switch is OFF (when ignition key is not inserted in key cylinder), remote keyless entry system turns on and off horn and headlamp intermittently with input of PANIC ALARM signal from keyfob.

The alarm automatically turns off after 25 seconds or when BCM receives any signal from keyfob.

For detailed description, refer to [BL-84, "VEHICLE SECURITY \(THEFT WARNING\) SYSTEM"](#) .

Trunk Lid Opener Operation

When a TRUNK OPEN signal is sent with key OFF (ignition key removed from key cylinder) from keyfob, power is supplied

- through BCM terminal 53
- to trunk lamp switch and trunk release solenoid terminal 3.

When power and ground are supplied, trunk lamp switch and trunk release solenoid opens trunk lid.

Keyless Power Window Down (open) Operation

When keyfob unlock switch is turned ON with ignition switch OFF, and the switch is detected to be on continuously for 3 seconds, the driver's door and passenger's door (with left and right front power window anti-pinch system) power windows are simultaneously opened.

Power window is operated to open and the operation continues as long as the keyfob unlock switch is pressed.

CAN Communication System Description


EIS00315

Refer to [LAN-21, "CAN COMMUNICATION"](#) .

REMOTE KEYLESS ENTRY SYSTEM

Schematic

EIS00316



A
B
C
D
E
F
G
H
I
J
K
L
M

BL




WIWA1029E

REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram — KEYLES —
FIG. 1

EIS00317

BL-KEYLES-01





WIWA0422E

REMOTE KEYLESS ENTRY SYSTEM

FIG. 2

BL-KEYLES-02







WIWA0423E

REMOTE KEYLESS ENTRY SYSTEM

FIG. 3

BL-KEYLES-03





WIWA0424E

REMOTE KEYLESS ENTRY SYSTEM

FIG. 4

BL-KEYLES-04




WIWA1018E

REMOTE KEYLESS ENTRY SYSTEM

Terminals and Reference Value for BCM

EIS00318

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
1	R/Y	Ignition key illumination	When doors are unlocked using keyfob (OFF → Unlock)	Battery voltage → 0V
11	PU	Ignition switch (ACC or ON)	Ignition switch (ACC or ON position)	Battery voltage
12	P/L	Front door switch RH	Door Closed (OFF) → Open (ON)	Battery voltage → 0V
13	R/W	Rear door switch RH	Door Closed (OFF) → Open (ON)	Battery voltage → 0V
22	Y/G	Power window serial link	—	
37	B/R	Ignition key switch (insert)	Key inserted → Key removed from key cylinder	Battery voltage → 0V
38	R	Ignition switch (ON or START)	Ignition switch (ON or START position)	Battery voltage
39	L	CAN-H	—	—
40	P	CAN-L	—	—
47	SB	Front door switch LH	Door Closed (OFF) → Open (ON)	Battery voltage → 0V
48	R/B	Rear door switch LH	Door Closed (OFF) → Open (ON)	Battery voltage → 0V
53	P	Trunk release solenoid	When trunk lid release solenoid is operated using keyfob (OFF → ON)	0V → Battery voltage
56	P/B	Battery saver (Interior lamp)	Battery saver operates → Does not operate (ON → OFF)	Battery voltage → 0V
57	W	Battery power supply	—	Battery voltage
59	G/W	Driver door lock actuator	Door lock & unlock switch (Neutral → Unlock)	0V → Battery voltage
62	R/W	Step lamp LH and RH	When doors are unlocked using keyfob (OFF → Unlock)	Battery voltage → 0V
63	R	Room lamp	When doors are locked using keyfob → Unlocked using keyfob (Lamp switch in "DOOR" position)	Battery voltage → 0V
65	Y/R	Door lock actuators	Door lock & unlock switch (Neutral → Lock)	0V → Battery voltage
66	G/R	Passenger and rear doors lock actuator	Door lock & unlock switch (Neutral → Unlock)	0V → Battery voltage
67	B	Ground	—	—
70	W/B	Battery power supply	—	Battery voltage

REMOTE KEYLESS ENTRY SYSTEM

CONSULT-II Function (BCM)

EIS00319

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.

BCM diagnostic test item	Diagnostic mode	Content
Inspection by part	WORK SUPPORT	Changes setting of each function.
	DATA MONITOR	Displays BCM input/output data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
	SELF-DIAG RESULTS	Displays BCM self-diagnosis results.
	CAN DIAG SUPPORT MNTR	The results of transmit/receive diagnosis of CAN communication can be read.
	ECU PART NUMBER	BCM part number can be read.
	CONFIGURATION	Performs BCM configuration read/write functions.


CONSULT-II Inspection Procedure “MULTI REMOTE ENT”

EIS0031A


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communications.


1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.



3. Turn ignition switch ON.
4. Touch “START (NISSAN BASED VHCL)”.




5. Touch “BCM”.




REMOTE KEYLESS ENTRY SYSTEM

6. Touch "MULTI REMOTE ENT".



7. Select diagnosis mode. "DATA MONITOR", "ACTIVE TEST" and "WORK SUPPORT" are available.



CONSULT-II Application Items "MULTI REMOTE ENT"

EIS0031B

Data Monitor

Monitored Item	Description
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
PANIC BTN	Indicates [ON/OFF] condition of panic signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from keyfob.
KEY CYL LK-SW	Indicates [ON/OFF] condition of lock signal from door key cylinder switch.
KEY CYL UN-SW	Indicates [ON/OFF] condition of unlock signal from door key cylinder switch.
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from lock/unlock switch.
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from lock/unlock switch.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	Indicates [ON/OFF] condition of rear door switch LH.
LK/UN BTN ON	Indicates [ON/OFF] condition of lock/unlock signal at the same time from keyfob.
TRUNK BTN/SIG	Indicates [ON/OFF] condition of trunk open signal from keyfob.
UN BUTTON ON	Indicates [ON/OFF] condition of unlock signal from keyfob.

Active Test

Test Item	Description
INT LAMP	This test is able to check interior lamp illumination operation. The interior lamp illumination is turned on when "ON" on CONSULT-II screen is touched.
IGN ILLUM	This test is able to check ignition illumination operation. The ignition illumination is turned on when "ON" on CONSULT-II screen is touched.

REMOTE KEYLESS ENTRY SYSTEM

Test Item	Description
FLASHER RIGHT(CAN)	This test is able to check right hazard reminder operation. The right hazard lamp turns on when "ON" on CONSULT-II screen is touched.
FLASHER LEFT(CAN)	This test is able to check left hazard reminder operation. The left hazard lamp turns on when "ON" on CONSULT-II screen is touched.
HORN	This test is able to check panic alarm and horn reminder operations. The alarm activate for 0.5 seconds after "ON" on CONSULT-II screen is touched.
HEAD LAMP(HI)	This test is able to check headlamps panic alarm operation. The headlamp illuminates for 0.5 seconds after "ON" on CONSULT-II screen is touched.
TRUNK/BACK DOOR	This test is able to check trunk lid opener actuator operation. The trunk is unlocked when "ON" on CONSULT-II screen is touched.

Work Support

Test Item	Description
REMO CONT ID CONFIR	It can be checked whether keyfob ID code is registered or not in this mode.
REMO CONT ID REGIST	Keyfob ID code can be registered.
REMO CONT ID ERASUR	Keyfob ID code can be erased.
MULTI ANSWER BACK SET	Hazard and horn reminder mode can be changed in this mode. The reminder mode will be changed when "MODE SET" on CONSULT-II screen is touched.
AUTO LOCK SET	Auto locking function mode can be changed in this mode. The function mode will be changed when "MODE SET" on CONSULT-II screen is touched.
PANIC ALRM SET	Panic alarm operation mode can be changed in this mode. The operation mode will be changed when "MODE SET" on CONSULT-II screen is touched.
TRUNK OPEN SET	Trunk lid opener operation mode can be changed in this mode. The operation mode will be changed when "MODE SET" on CONSULT-II screen is touched.
PW DOWN SET	Keyless power window down (open) operation mode can be changed in this mode. The operation mode will be changed when "MODE SET" on CONSULT-II screen is touched.

A
B
C
D
E
F
G
H
J
K
L
M

BL

REMOTE KEYLESS ENTRY SYSTEM

Hazard and horn reminder mode

	MODE 1 (C mode)		MODE 2 (S mode)		MODE 3		MODE 4		MODE 5		MODE 6	
	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock
Keyfob operation	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock	Lock	Unlock
Hazard warning lamp flash	Twice	Once	Twice	—	—	—	Twice	Once	Twice	—	—	Once
Horn sound	Once	—	—	—	—	—	—	—	Once	—	Once	—

Auto locking function mode

	MODE 1	MODE 2	MODE 3
Auto locking function	5 minutes	Nothing	1 minutes

Panic alarm operation mode

	MODE 1	MODE 2	MODE 3
Keyfob operation	0.5 seconds	Nothing	1.5 seconds

Trunk open operation mode

	MODE 1	MODE 2	MODE 3
Keyfob operation	0.5 seconds	Nothing	1.5 seconds

Power window down operation mode

	MODE 1	MODE 2	MODE 3
Keyfob operation	3 seconds	Nothing	5 seconds

Trouble Diagnosis Procedure

EIS0031C

1. Check the symptom and customer's requests.
2. Understand outline of system. Refer to [BL-47, "System Description"](#).
3. Confirm that power door lock system operates normally. Refer to [BL-16, "POWER DOOR LOCK SYSTEM"](#).
4. Perform BCM power supply and ground circuit check. Refer to [BL-58, "BCM Power Supply and Ground Circuit Check"](#).
5. Refer to trouble diagnosis chart by symptom, repair or replace any malfunctioning parts. Refer to [BL-59, "Trouble Diagnoses"](#).
6. Inspection End.

BCM Power Supply and Ground Circuit Check

EIS0031D

1. CHECK FUSE

- Check the following BCM fuses and fusible link.

Component Parts	Terminal No. (SIGNAL)	Ampere	No.	Location
BCM	57 (BAT power supply)	10A	21	Fuse block (J/B)
	70 (BAT power supply)	50A	f	Fuse and fusible link box
	11 (ACC power supply)	10A	6	Fuse block (J/B)
	38 (IGN power supply)	10A	1	Fuse block (J/B)

NOTE:

Refer to [BL-16, "Component Parts and Harness Connector Location"](#).

OK or NG


- OK >> GO TO 2.
 NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).

REMOTE KEYLESS ENTRY SYSTEM

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check voltage between BCM connectors M18, M20 terminals 11, 38, 57, 70 and ground.

Connector	Terminals (Wire color)		Signal name	Ignition switch	Voltage (V) (Approx.)
	(+)	(-)			
M18	11 (PU)	Ground	ACC power supply	ACC	Battery voltage
	38 (R)		IGN power supply	ON	Battery voltage
M20	57 (W)		Battery power supply	OFF	Battery voltage
	70 (W/B)		Battery power supply	OFF	Battery voltage




OK or NG

- OK >> GO TO 3.
NG >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M20 terminal 67 and ground.

Connector	Terminals (Wire color)		Continuity
	(+)	(-)	
M20	67 (B)	Ground	Yes



OK or NG

- OK >> Power supply and ground circuit is OK.
NG >> Repair or replace harness.

Trouble Diagnoses SYMPTOM CHART

NOTE:

- Always check the "Trouble Diagnosis Procedure" before troubleshooting. Refer to [BL-58, "Trouble Diagnosis Procedure"](#).
- Always check keyfob battery before replacing keyfob. Refer to [BL-61, "Keyfob Battery and Function Check"](#).
- The panic alarm operation and trunk lid opener operation of remote keyless entry system do not activate with the ignition key inserted in the ignition key cylinder.
- Use Remote Keyless Entry Tester J-43241 (follow instructions on tester) to check operation of keyfob before replacing keyfob.

Symptom	Diagnoses/service procedure	Reference page
All function of remote keyless entry system do not operate.	1. Keyfob battery and function check (use Remote Keyless Entry Tester J-43241) NOTE: If the result of keyfob function check is OK, keyfob is not malfunctioning.	BL-61
	2. Replace keyfob. Refer to ID Code Entry Procedure.	BL-68

REMOTE KEYLESS ENTRY SYSTEM

Symptom	Diagnoses/service procedure	Reference page
The new ID of keyfob cannot be entered.	1. Keyfob battery and function check (use Remote Keyless Entry Tester J-43241) NOTE: If the result of keyfob function check is OK, keyfob is not malfunctioning.	BL-61
	2. Key switch (insert) check	BL-64
	3. Door switch check	BL-62
	4. Replace keyfob. Refer to ID Code Entry Procedure.	BL-68
Door lock or unlock does not function. (If the power door lock system does not operate manually, check power door lock system. Refer to BL-16, "POWER DOOR LOCK SYSTEM" .)	1. Keyfob battery and function check (use Remote Keyless Entry Tester J-43241) NOTE: If the result of keyfob function check is OK, keyfob is not malfunctioning.	BL-61
	2. Replace keyfob. Refer to ID Code Entry Procedure.	BL-68
Hazard and horn reminder does not activate properly when pressing lock or unlock button of keyfob.	1. Hazard reminder check	BL-67
	2. Horn reminder check	BL-67
	3. Door switch check	BL-62
	4. Replace BCM.	BCS-20
Room lamp, ignition illumination and step lamp operation do not activate properly.	1. Room lamp operation check	BL-67
	2. Ignition illumination operation check	BL-67
	3. Step lamp operation check	BL-67
	4. Door switch check	BL-62
Panic alarm (horn and headlamp) does not activate when panic alarm button is continuously pressed.	1. Keyfob battery and function check (use Remote Keyless Entry Tester J-43241) NOTE: If the result of keyfob function check is OK, keyfob is not malfunctioning.	BL-61
	2. Vehicle security operation check. Refer to Vehicle security system.	BL-84
	3. Key switch (insert) check	BL-64
	4. Replace keyfob. Refer to ID Code Entry Procedure.	BL-68
Trunk lid does not open when trunk opener button is continuously pressed.	1. Keyfob battery and function check (use Remote Keyless Entry Tester J-43241) NOTE: If the result of keyfob function check is OK, keyfob is not malfunctioning.	BL-61
	2. Trunk release solenoid check	BL-65
	3. Key switch (insert) check	BL-64
	4. Replace BCM.	BCS-20

REMOTE KEYLESS ENTRY SYSTEM

E/IS003/F

Keyfob Battery and Function Check

1. CHECK KEYFOB BATTERY

Remove battery and measure voltage across battery positive and negative terminals, (+) and (-).

Voltage : 2.5V - 3.0V


NOTE:

Keyfob does not function if battery is not set correctly.

OK or NG

OK >> GO TO 2.

NG >> Replace battery. Refer to [BL-71, "Keyfob Battery Replacement"](#).



2. CHECK KEYFOB FUNCTION

With CONSULT-II

Check keyfob function in "DATA MONITOR" mode with CONSULT-II.

When pushing each button of keyfob, the corresponding monitor item should be turned as follows.

Condition	Monitor item
Pushing LOCK	LK BUTTON/SIG : ON
Pushing UNLOCK	UN BUTTON/SIG : ON
Pushing TRUNK	TRUNK BTN/SIG : ON
Pushing PANIC	PANIC BTN : ON
Pushing LOCK and UNLOCK at the same time	LK/UN BTN ON : ON

DATA MONITOR	
MONITOR	
PANIC BTN	OFF
UN BUTTON/SIG	OFF
LK BUTTON/SIG	OFF
TRUNK BTN/SIG	OFF
LK/UN BTN ON	OFF

LIA0195E

Without CONSULT-II

Check keyfob function using Remote Keyless Entry Tester J-43241.

OK or NG

OK >> WITH CONSULT-II: Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).

OK >> WITHOUT CONSULT-II: Keyfob is OK. Further inspection is necessary. Refer to [BL-59, "SYMPTOM CHART"](#).

NG >> WITH CONSULT-II: Further inspection is necessary. Refer to [BL-59, "SYMPTOM CHART"](#).

NG >> WITHOUT CONSULT-II: Replace keyfob. Refer to [BL-70, "KEYFOB ID SET UP WITHOUT CONSULT-II"](#).

REMOTE KEYLESS ENTRY SYSTEM

EIS0031G

Door Switch Check

1. CHECK DOOR SWITCHES INPUT SIGNAL

 With CONSULT-II

Check door switches ("DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR") in DATA MONITOR mode with CONSULT-II. Refer to [BL-27, "DATA MONITOR"](#).

- When any doors are open:

DOOR SW-DR : ON
DOOR SW-AS : ON
DOOR SW-RL : ON
DOOR SW-RR : ON

- When any doors are closed:

DOOR SW-DR : OFF
DOOR SW-AS : OFF
DOOR SW-RL : OFF
DOOR SW-RR : OFF


DATA MONITOR	
MONITOR	
DOOR SW - DR	OFF
DOOR SW - AS	OFF
DOOR SW - RR	OFF
DOOR SW - RL	OFF

PIIA6222E

 Without CONSULT-II

Check voltage between BCM connector M18 or M19 terminals 12, 13, 47, 48 and ground.

Connector	Item	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
		(+)	(-)		
M18	Front door switch RH	12 (P/L)	Ground	DOOR Open ↓ Closed	0 ↓ Battery voltage
	Rear door switch RH	13 (R/W)			
M19	Front door switch LH	47 (SB)			
	Rear door switch LH	48 (R/B)			



OK or NG

- OK >> System is OK.
 NG >> GO TO 2.

REMOTE KEYLESS ENTRY SYSTEM


2. CHECK DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door switch and BCM.
3. Check continuity between door switch connector B8 (front LH) or B108 (front RH) terminal 2, B18 (rear LH) or B116 (rear RH) terminal 1 and BCM connector M18, M19 terminals 12, 13, 47 and 48.

- 1 (R/B) - 48 (R/B) : Continuity should exist**
- 1 (R/W) - 13 (R/W) : Continuity should exist**
- 2 (SB) - 47 (SB) : Continuity should exist**
- 2 (P/L) - 12 (P/L) : Continuity should exist**

4. Check continuity between door switch connector B8 (front LH) or B108 (front RH) terminal 2, B18 (rear LH) or B116 (rear RH) terminal 1 and ground.

- 1 (R/B or R/W) - Ground : Continuity should not exist**
- 2 (SB or P/L) - Ground : Continuity should not exist**



OK or NG

- OK >> GO TO 3.
- NG >> Repair or replace harness.


3. CHECK DOOR SWITCHES

1. Disconnect door switch harness.
2. Check continuity between door switch connector terminals.

	Terminals (Wire color)	Condition	Continuity
Front door switch LH/RH	2 – Ground	Door Open	Yes
		Door Closed	No
Rear door switch LH/RH	1 – Ground	Door Open	Yes
		Door Closed	No

OK or NG

- OK >> Check door switch case ground condition.
- NG >> Replace door switch.



REMOTE KEYLESS ENTRY SYSTEM

EIS003IH


Key Switch (Insert) Check

1. CHECK KEY SWITCH AND KEY LOCK SOLENOID INPUT SIGNAL

 With CONSULT-II

Check key switch "KEY ON SW" in DATA MONITOR mode with CONSULT-II. Refer to [BL-27, "DATA MONITOR"](#).

- When key is inserted to ignition key cylinder:
KEY ON SW : ON
- When key is removed from ignition key cylinder:
KEY ON SW : OFF




 Without CONSULT-II

Check voltage between BCM connector M18 terminal 37 and ground.

Connector	Terminal (Wire color)		Condition	Voltage (V) (Approx.)
	(+)	(-)		
M18	37 (B/R)	Ground	Key is inserted.	Battery voltage
			Key is removed.	0

OK or NG

- OK >> System is OK.
- NG >> GO TO 2.




2. CHECK KEY SWITCH (INSERT)

- Turn ignition switch OFF.
- Disconnect key switch and key lock solenoid connector.
- Check continuity between key switch and key lock solenoid connector terminals 3 and 4.

Terminals	Condition	Continuity
3 - 4	Key is inserted.	Yes
	Key is removed.	No

OK or NG

- OK >> GO TO 3.
- NG >> Replace key switch and key lock solenoid.




REMOTE KEYLESS ENTRY SYSTEM

3. CHECK KEY SWITCH AND KEY LOCK SOLENOID CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between the BCM harness connector M18 terminal 37 and key switch and key lock solenoid harness connector M26 terminal 4.
3. Check continuity between BCM harness connector M18 terminal 37 and ground.

37 (B/R) - 4 (B/R) : Continuity should exist
37 (B/R) - Ground : Continuity should not exist



OK or NG

OK >> Check the following:

- 10A fuse [No. 21, located in fuse block (J/B)]
- Harness for open or short between key switch and key lock solenoid and fuse

NG >> Repair or replace harness.

Trunk Release Solenoid Check

EIS003II

1. CHECK TRUNK LID OPENER

Check trunk release operation with trunk lid opener switch.

NOTE:

First check trunk lid opener cancel switch position. Refer to [BL-82. "TRUNK LID OPENER"](#).

Does trunk lid open?

Yes >> GO TO 2.

No >> Check trunk release solenoid and the circuit.

2. CHECK TRUNK LID OPENER ACTUATOR OPERATION

With CONSULT-II

1. Select "ACTIVE TEST" in "MULTI REMOTE ENT" with CONSULT-II.
2. Select "TRUNK/BACK DOOR" and touch "ON".

Trunk release solenoid should operate.


NOTE:

If CONSULT-II is not available, skip this procedure and go to the next step.

OK or NG

OK >> Trunk lid opener actuator circuit is OK.

NG >> Check harness for open or short between BCM and trunk lid opener actuator.



REMOTE KEYLESS ENTRY SYSTEM

3. CHECK TRUNK LID OPENER ACTUATOR CIRCUIT

⊗ Without CONSULT-II

1. Disconnect trunk lamp switch and trunk release solenoid connector.
2. While pressing keyfob release button, check voltage between trunk lamp switch and trunk release solenoid harness connector B32 terminal 3 and ground.


3 (P) - Ground : Battery voltage should exist.

3. Check continuity between trunk lamp switch and trunk release solenoid harness connector B32 terminal 4 and ground.

4 (B) - Ground : Continuity should exist.

OK or NG

- OK >> Replace trunk release solenoid.
NG >> Check the following:
1. Harness for open or short between BCM and trunk release solenoid
 2. Harness for open or short between trunk lamp switch and trunk release solenoid and ground
 3. Replace BCM



LIIA1512E

REMOTE KEYLESS ENTRY SYSTEM

Check Hazard Function

EIS003J

1. CHECK HAZARD WARNING LAMP

Does hazard indicator flash with hazard switch?

Yes or No

Yes >> Hazard warning lamp circuit is OK.

No >> Check "hazard indicator." Refer to [LT-72, "TURN SIGNAL AND HAZARD WARNING LAMPS"](#) .

Check Horn Function

EIS003K

First, perform the "SELF-DIAG RESULTS" in "BCM" with CONSULT-II, then perform the trouble diagnosis of malfunction system indicated in "SELF-DIAG RESULTS" of "BCM".

1. CHECK HORN FUNCTION

Does horn sound with horn switch?

Yes or No

Yes >> Horn circuit is OK.

No >> Check horn circuit. Refer to [WW-36, "HORN"](#) .

Check Headlamp Function

EIS003L

First, perform the "SELF-DIAG RESULTS" in "BCM" with CONSULT-II, then perform the trouble diagnosis of malfunction system indicated in "SELF-DIAG RESULTS" of "BCM".

1. CHECK HEADLAMP OPERATION

Does headlamp come on when turning lighting switch ON?

Yes or No

Yes >> Headlamp operation circuit is OK.

No >> Check headlamp circuit. Refer to [LT-6, "HEADLAMP \(FOR USA\)"](#) or [LT-33, "HEADLAMP \(FOR CANADA\) - DAYTIME LIGHT SYSTEM -"](#) .

Check Room Lamp, Step Lamp and Ignition Key Illumination Function

EIS003M

1. CHECK ROOM LAMP, STEP LAMP AND IGNITION KEY ILLUMINATION FUNCTION

When room lamp switch is in DOOR position, open the front door LH or RH.

Room lamp, Step lamp and ignition key illumination should illuminate.

OK or NG

OK >> System is OK.

NG >> Check interior lamp circuits. Refer to [LT-115, "INTERIOR ROOM LAMP"](#) .

A
B
C
D
E
F
G
H
I
J
K
L
M

BL

REMOTE KEYLESS ENTRY SYSTEM

EIS003IN

ID Code Entry Procedure KEYFOB ID SET UP WITH CONSULT-II


NOTE:

- If a keyfob is lost, the ID code of the lost keyfob must be erased to prevent unauthorized use. A specific ID code can be erased with CONSULT-II. However, when the ID code of a lost keyfob is not known, all controller ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new keyfobs must be re-registered.
- When registering an additional keyfob, the existing ID codes in memory may or may not be erased. If five ID codes are stored in memory when an additional code is registered, only the oldest code is erased. If less than five codes are stored in memory when an additional code is registered, the new ID code is added and no ID codes are erased.
- Entry of a maximum of five ID codes is allowed. When more than five codes are entered, the oldest ID code will be erased.
- Even if the same ID code that is already in memory is input, the same ID code can be entered. The code is counted as an additional code.


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communications.


1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to the data link connector.



3. Turn ignition switch ON.
4. Touch "START (NISSAN BASED VHCL)".




5. Touch "BCM".




REMOTE KEYLESS ENTRY SYSTEM

6. Touch "MULTI REMOTE ENT".



A
B
C
D


7. Touch "WORK SUPPORT".



E
F
G

8. The items shown on the figure can be set up.


- "REMO CONT ID CONFIR"
Use this mode to confirm if a keyfob ID code is registered or not.
 - "REMO CONT ID REGIST"
Use this mode to register a keyfob ID code.
- NOTE:**
Register the ID code when keyfob or BCM is replaced, or when additional keyfob is required.
- "REMO CONT ID ERASUR"
Use this mode to erase a keyfob ID code.



H
BL
J
K
L
M

REMOTE KEYLESS ENTRY SYSTEM

KEYFOB ID SET UP WITHOUT CONSULT-II



LIIA1513E

REMOTE KEYLESS ENTRY SYSTEM

NOTE:


- If a keyfob is lost, the ID code of the lost keyfob must be erased to prevent unauthorized use. A specific ID code can be erased with CONSULT-II. However, when the ID code of a lost keyfob is not known, all controller ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new keyfobs must be re-registered.
To erase all ID codes in memory, register one ID code (keyfob) five times. After all ID codes are erased, the ID codes of all remaining and/or new keyfobs must be re-registered.
- When registering an additional keyfob, the existing ID codes in memory may or may not be erased. If five ID codes are stored in memory, when an additional code is registered, only the oldest code is erased. If less than five ID codes are stored in memory, when an additional ID code is registered, the new ID code is added and no ID codes are erased.
- If you need to activate more than two additional new keyfobs, repeat the procedure "Additional ID code entry" for each new keyfob.
- Entry of maximum five ID codes is allowed. When more than five ID codes are entered, the oldest ID code will be erased.
- Even if same ID code that is already in the memory is input, the same ID code can be entered. The code is counted as an additional code.

Keyfob Battery Replacement

EIS00310

NOTE:

- Be careful not to touch the circuit board or battery terminal.
 - The keyfob is water-resistant. However, if it does get wet, immediately wipe it dry.
1. Open the lid using a coin.
 2. Remove the battery.
 3. Install the new battery, positive side down.
 4. Close the lid securely. Push the keyfob buttons two or three times to check operation.



LIA1514E


DOOR

PFP:80100

EIS003IP

DOOR

Fitting Adjustment



- a. Flush + 0.5, -1.0 mm (+0.02, -0.04 in) b. Flush + 1.0, -0.5 mm (+0.04, -0.02 in) c. 4.5 ± 1.0 mm (0.18 ± 0.04 in)
d. 4.6 ± 1.0 mm (0.18 ± 0.04 in)

FRONT DOOR

Longitudinal clearance and surface height adjustment at front end

1. Remove the front fender. Refer to [EI-20, "FRONT FENDER"](#).
2. Loosen the bolts. Raise the front door at rear end to adjust.

REAR DOOR


Longitudinal clearance and surface height adjustment at front end

1. Remove the center pillar upper and lower garnish. Refer to [EI-32, "Removal and Installation"](#).
2. Accessing from inside the vehicle, loosen the nuts. Open the rear door, and raise the rear door at rear end to adjust.

DOOR

STRIKER ADJUSTMENT

1. Adjust the striker so that it becomes parallel with the lock insertion direction.




Removal and Installation


E/S0031Q

CAUTION:

- When removing and installing the door assembly, support the door with a jack and shop cloth to protect the door and body.
 - When removing and installing door assembly, be sure to carry out the fitting adjustment.
 - Check the hinge rotating part for poor lubrication. If necessary, apply "body grease".
1. Remove the door window and module assembly. Refer to [GW-34, "Removal and Installation"](#).
 2. Remove the door harness.
 3. Remove the check link cover.
 4. Remove the check link bolt from the hinge pillar.



5. Remove the door-side nuts and bolts, and the door assembly. Installation is in the reverse order of removal.




A
B
C
D
E
F
G
H
BL
J
K
L
M

DOOR

Door Weatherstrip

EIS0031R



1. Glued area

2. Clip (Driver side: Yellow, Passenger side: Blue)


3. Weatherstrip

FRONT DOOR LOCK

PFP:80502

FRONT DOOR LOCK Component Structure

EIS003IS



Inspection and Adjustment

EIS003IT


1. Remove the front door window and front door module assembly. Refer to [GW-34, "FRONT DOOR GLASS AND REGULATOR"](#).

EXTERIOR HANDLE ROD ADJUSTMENT

- Rotate the bushing to adjust so that the clearance between the bushing and rod becomes as shown in the figure.

CAUTION:


Be careful not to make the clearance 0 mm (0 in) or the rod will be pressed continuously.



Removal and Installation REMOVAL

EIS003IU

1. Remove the front door window and front door module assembly. Refer to [GW-34, "FRONT DOOR GLASS AND REGULATOR"](#).
2. Separate the key cylinder rod and exterior handle rod connection (on the handle) if equipped.
3. Remove the screws (TORX T30) and the door lock assembly.
4. Disconnect the door lock actuator electrical connector.




FRONT DOOR LOCK

5. Remove the exterior handle bolts, move the exterior handle assembly backward, and then remove it from the panel in front of the exterior handle escutcheon.

Installation is in the reverse order of removal.

CAUTION:

To install each rod, be sure to rotate the rod holder until a click is felt.



EIS003IV


Disassembly and Assembly

DISASSEMBLY

CAUTION:

Be sure to remove or install the actuator with the door lock assembly removed.

1. Remove the screws and actuator from the door lock assembly.
2. Pull the actuator straight downward to separate it from the door lock assembly.



ASSEMBLY

1. Align the actuator pivot with the cutout on the knob lever of the door lock assembly, then assemble the actuator.
2. Move the knob lever and the actuator pivot toward the lock-on direction, and check that it engages securely.


REAR DOOR LOCK

REAR DOOR LOCK

PFP:82502

Components

EIS003W



Inspection and Adjustment

EIS003IX


Remove the rear door finisher. Refer to [EI-30, "DOOR FINISHER"](#).

EXTERIOR HANDLE ROD ADJUSTMENT

Rotate the bushing to adjust so that the clearance between the bushing and rod becomes as shown.

CAUTION:

Be careful not to make the clearance 0 mm (0 in) or the rod will be pressed continuously.



Removal and Installation of Door Lock


REMOVAL

EIS003IY

1. Remove the rear door finisher. Refer to [EI-30, "DOOR FINISHER"](#).

REAR DOOR LOCK

2. Remove the screws (TORX T30) and the door lock assembly.
3. Disconnect the door lock actuator connector.




4. Remove the exterior handle bolts, and move the handle backward to disengage it from the panel in front of the exterior handle escutcheon, then remove the handle.

Installation is in the reverse order of removal.

CAUTION:

To install each rod, be sure to rotate the rod holder until a click is felt.




Disassembly and Assembly

DISASSEMBLY

CAUTION:

Be sure to remove or install the actuator with the door lock assembly removed.

1. Remove the screws and the actuator from the door lock assembly.
2. Pull the actuator straight downward to separate it from the door lock assembly.



ASSEMBLY




1. Align the actuator pivot with the cutout on the knob lever of the door lock assembly, then assemble the actuator.
2. Move the knob lever and the actuator pivot toward the lock-on direction, and check that it engages securely.

TRUNK LID


TRUNK LID Fitting Adjustment

PFPH4300


E/S003J0




A-A




B-B



C-C



D-D



LIIA2207E

A
B
C
D
E
F
G
H
BL
J
K
L
M

TRUNK LID

- | | | |
|---|---|---------------------|
| 1. Trunk lid assembly | 2. Rear window glass | 3. Body side outer |
| 4. Rear combination lamp | 5. Rear bumper fascia | a. 7.3 mm (0.29 in) |
| b. 3.5 ± 1.0 mm (0.14 ± 0.04 in) | c. flush + 0.5/ -1.0 mm (+ 0.02/-0.04 in) | d. 5.4 mm (0.21 in) |
| e. 8.2 ± 1.5 mm (0.3 ± 0.06 in) | | |

LONGITUDINAL AND LATERAL CLEARANCE ADJUSTMENT


1. With the striker released, loosen the trunk lid hinge bolts and close the trunk lid.
2. Make the lateral clearance and the clearance to the rear window glass equal, and open the trunk lid to tighten the bolts to the specified torque.

SURFACE HEIGHT ADJUSTMENT

1. Loosen the striker bolts. Raise the striker to the top position, and temporarily tighten the upper bolt at the position.
2. Close the trunk lid lightly and adjust the surface height, then open the trunk lid to finally tighten the striker bolts.

Removal and Installation of Trunk Lid Assembly

EIS003J1



1. Remove the trunk lid finisher. Refer to [EI-37, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#).
2. Disconnect the connectors in the trunk lid, and remove the harness clamps to pull the harness out of the trunk lid.
3. Remove the bolts and the trunk lid assembly.

Installation is in the reverse order of removal.

CAUTION:


After installing, apply touch-up paint (the body color) onto the head of the hinge mounting bolts.

Removal and Installation of Trunk Lid Lock

EIS003J2

LOCK REMOVAL


1. Remove the trunk lid finisher. Refer to [EI-37, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#).
2. Separate the key cylinder rod.
3. After removing the harness connector, remove the bolts and the trunk lid lock.



TRUNK LID

STRIKER REMOVAL

1. Remove the trunk rear plate and trunk rear finisher. Refer to [EL-37, "TRUNK ROOM TRIM & TRUNK LID FINISHER"](#).
2. Remove the bolts and the trunk lock support from the vehicle.
3. After removing the harness connector, remove the bolts, and the striker from the trunk lock support.




LOCK AND STRIKER INSTALLATION

1. Install the trunk lid lock and striker.
2. After installing, close the trunk lid lightly. Perform the lock and surface height adjustment. Refer to [BL-79, "Fitting Adjustment"](#).
3. After installing, check the operation.

Removal and Installation of Trunk Lid Weatherstrip

E/IS003J3



1. Install the weatherstrip from the front with the vehicle center mark aligned to the weatherstrip mark.
2. At rear side, align the weatherstrip seam to the center of the striker.
3. After installing, pull the weatherstrip lightly to check for looseness.

CAUTION:

The weatherstrip should fit tightly onto the corners and trunk lid rear plate.

TRUNK LID OPENER




PF0:84640

EIS003J4

TRUNK LID OPENER

Wiring Diagram — TLID —

BL-TLID-01



WIWA1019E

TRUNK LID OPENER

Terminals and Reference Value for BCM

E/S003J5

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
30	R/B*1, L/R*2	Trunk lid opener switch	OFF → ON	Battery voltage → 0V
53	P	Trunk opener output	When trunk lamp switch and trunk release solenoid is operated using keyfob trunk release button (OFF → ON)	0V → Battery voltage
70	W/B	Battery power supply	—	Battery voltage

NOTE:

*1: Without trunk lid opener cancel switch.

*2: With trunk lid opener cancel switch.

A
B
C
D
E
F
G
H
J
K
L
M

BL


VEHICLE SECURITY (THEFT WARNING) SYSTEM

VEHICLE SECURITY (THEFT WARNING) SYSTEM

PFP:28491


Component Parts and Harness Connector Location

EIS003J6



LIA1397E

VEHICLE SECURITY (THEFT WARNING) SYSTEM



A
B
C
D
E
F
G
H
I
J
K
L
M

BL

LIA1872E

VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS003J7

System Description

DESCRIPTION

Setting the vehicle security system

Disarmed phase

- When the vehicle is being driven or when doors or trunk lid is open, the vehicle security system is set in the disarmed phase on the assumption that the owner is inside or near the vehicle.

Pre-armed phase and armed phase

- The vehicle security system turns into the "pre-armed" phase when trunk lid and all doors are closed and locked by electronic key. The security indicator lamp illuminates for 30 seconds. Then, the system automatically shifts into the "armed" phase.

Canceling the set vehicle security system

When one of the following operations is performed, the armed phase is canceled.

1. Unlock the doors with the key or the keyfob.
2. Open the trunk lid with the key or the keyfob. When the trunk lid is closed after opening the trunk lid with the keyfob, the system returns to the armed phase.

Activating the alarm operation of the vehicle security system

Make sure the system is in the armed phase.

When one of the following operations is performed, the system sounds the horns and flashes the head-lamps for about 50 seconds.

1. Any door is opened before unlocking door with key or keyfob.
2. Door is unlocked without using key or keyfob.
3. Trunk lid is opened without using key or keyfob.

POWER SUPPLY

Power is supplied at all times

- through 10A fuse [No.19, located in the fuse block (J/B)]
- to security indicator lamp terminal 1
- through 10A fuse [No. 21, located in the fuse block (J/B)]
- to key switch and key lock solenoid terminal 3
- to BCM terminal 57
- through 50A fusible link (letter f , located in the fuse and fusible link box)
- to BCM terminal 70.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 6, located in the fuse block (J/B)]
- to BCM terminal 11.

INITIAL CONDITION TO ACTIVATE THE SYSTEM

The operation of the vehicle security system is controlled by the doors and trunk lid.

To activate the vehicle security system, BCM must receive signals indicating the doors and trunk lid are closed and the doors are locked.

When a door is open, BCM terminal 12, 13, 47 or 48 receives a ground signal from each door switch.

When front door LH is unlocked, BCM terminal 22 receives a signal from terminal 14 of main power window and door lock/unlock switch.

When front door RH is unlocked, BCM terminal 22 receives a signal from terminal 11 of power window and door lock/unlock switch RH.

The IPDM E/R then sends a signal to the BCM through the CAN SYSTEM.

When the trunk lid is open, BCM terminal 42 receives a ground signal

- from terminal 1 of the trunk lamp switch and trunk release solenoid
- through body grounds B7 and B19.

VEHICLE SECURITY SYSTEM ALARM OPERATION

The vehicle security system is triggered by

- opening a door
- opening the trunk lid

VEHICLE SECURITY (THEFT WARNING) SYSTEM

- unlocking door without using the key or keyfob.

The vehicle security system will be triggered once the system is in armed phase

- when BCM receives a ground signal at terminals 12, 13, 47, 48 (door switch), 42 (trunk lamp and trunk release solenoid switch).

Power is supplied at all times

- to horn relay terminal 1
- through 15A fuse (No. 25, located in fuse and fusible link box).

When the vehicle security system is triggered, ground is supplied intermittently

- to headlamp high relay
- from IPDM E/R terminal 51
- to horn relay terminal 2.

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 50 seconds, but will reactivate if the vehicle is tampered with again.

VEHICLE SECURITY SYSTEM DEACTIVATION

To deactivate the vehicle security system, a door or the trunk lid must be unlocked with the key or keyfob.

When the key is used to unlock the driver door, BCM terminal 22 receives signal

- from terminal 14 of the main power window and door lock/unlock switch.

When the key is used to unlock the trunk lid, BCM terminal 41 receives a ground signal from terminal 1 of the trunk key cylinder switch (unlock switch).

When the BCM receives either one of these signals or unlock signal from keyfob, the vehicle security system is deactivated. (Disarmed phase)

PANIC ALARM OPERATION

Remote keyless entry system may or may not operate vehicle security system (horn and headlamps) as required.

When the remote keyless entry system is triggered, ground is supplied intermittently

- to headlamp high relay
- from IPDM E/R terminal 51
- to horn relay terminal 2.

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off after 25 seconds or when BCM receives any signal from keyfob.

CAN Communication System Description


Refer to [LAN-21, "CAN COMMUNICATION"](#)

E/S003J8

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Schematic

EIS003J9





WIWA1020E

VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS003JA






Wiring Diagram — VEHSEC —
FIG. 1



VEHICLE SECURITY (THEFT WARNING) SYSTEM

FIG. 2

BL-VEHSEC-02




WIWA1022E

VEHICLE SECURITY (THEFT WARNING) SYSTEM


FIG. 3

BL-VEHSEC-03

— — — — : DATA LINE



A
B
C
D
E
F
G
H
BL
J
K
L
M





WIWA1023E

VEHICLE SECURITY (THEFT WARNING) SYSTEM

FIG. 4

BL-VEHSEC-04




WIWA0427E

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Terminals and Reference Value for BCM

EIS003JB

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
11	PU	Ignition switch (ACC or ON)	Ignition switch (ACC or ON position)	Battery voltage
12	P/L	Front door switch RH	Door Closed (OFF) → Open (ON)	Battery voltage → 0V
13	R/W	Rear door switch RH	Door Closed (OFF) → Open (ON)	Battery voltage → 0V
22	Y/G	Power window serial link	—	
23	G/OR	Security indicator output	OFF → ON	Battery voltage → 0V
37	B/R	Ignition key switch (insert)	Key inserted → Key removed from key cylinder	Battery voltage → 0V
39	L	CAN-H	—	—
40	P	CAN-L	—	—
41	L/B	Trunk key cylinder	Unlocked → Neutral	0V → 5V
42	PU/W	Trunk switch	Trunk lid closed (OFF) → Trunk lid open (ON)	Battery voltage → 0V
47	SB	Front door switch LH	Door Closed (OFF) → Open (ON)	Battery voltage → 0V
48	R/B	Rear door switch LH	Door Closed (OFF) → Open (ON)	Battery voltage → 0V
57	W	Battery power supply	—	Battery voltage
67	B	Ground	—	0
70	W/B	Battery power supply	—	Battery voltage

Terminals and Reference Value for IPDM E/R

EIS003JC

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
22	R/L	Parking, license, and tail lamps	OFF → ON	0V → Battery voltage
27	L/W	Headlamp high (RH)	OFF → ON	0V → Battery voltage
28	G	Headlamp high (LH)	OFF → ON	0V → Battery voltage
38	B	Ground	—	0
48	L	CAN-H	—	—
49	P	CAN-L	—	—
51	G/W	Horn relay	ON → OFF	0V → Battery voltage
60	B	Ground	—	0

VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS003JD

CONSULT-II Function (BCM)

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnostic test item	Diagnostic mode	Content
Inspection by part	WORK SUPPORT	Changes setting of each function.
	DATA MONITOR	Displays BCM input/output data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
	SELF-DIAG RESULTS	Displays BCM self-diagnosis results.
	CAN DIAG SUPPORT MNTR	The results of transmit/receive diagnosis of CAN communication can be read.
	ECU PART NUMBER	BCM part number can be read.
	CONFIGURATION	Performs BCM configuration read/write functions.

CONSULT-II INSPECTION PROCEDURE


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communications.


1. With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, and turn the ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on the "SELECT SYSTEM" screen.



VEHICLE SECURITY (THEFT WARNING) SYSTEM

4. Touch "THEFT ALM" on the "SELECT TEST ITEM" screen.
- WORK SUPPORT, DATA MONITOR and ACTIVE TEST are available for the vehicle security system.



A

B

C

D

E

F

G

H

BL

J

K

L

M

VEHICLE SECURITY (THEFT WARNING) SYSTEM

CONSULT-II APPLICATION ITEM

Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
KEY CYL LK SW	Indicates [ON/OFF] condition of lock signal from key cylinder switch.
KEY CYL UN SW	Indicates [ON/OFF] condition of unlock signal from key cylinder switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch RH.
DOOR SW-RL	Indicates [ON/OFF] condition of rear door switch LH.
TRNK OPN MTR	Indicates [ON/OFF] condition of trunk opener motor.
TRNK OPNR SW	Indicates [ON/OFF] condition of trunk opener switch.
TRUNK KEY SW	Indicates [ON/OFF] condition of trunk key cylinder switch.
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from door lock/unlock switch LH and RH.
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from door lock/unlock switch LH and RH.
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
TRUNK BTN/SIG	Indicates [ON/OFF] condition of trunk open signal from keyfob.

Active Test

Test Item	Description
THEFT IND	This test is able to check security indicator lamp operation. The lamp will be turned on when "ON" on CONSULT-II screen is touched.
HEADLAMP	This test is able to check vehicle security lamp operation. The headlamps will be activated for 0.5 seconds after "ON" on CONSULT-II screen is touched.
HORN	This test is able to check vehicle security horn operation. The horns will be activated for 0.5 seconds after "ON" on CONSULT-II screen is touched.


Work Support

Test Item	Description
SECURITY ALARM SET	This mode can confirm and change security alarm ON-OFF setting.
THEFT ALM TRG	The switch which triggered vehicle security alarm is recorded. This mode is able to confirm and erase the record of vehicle security alarm. The trigger data can be erased by touching "CLEAR" on CONSULT-II screen.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnosis WORK FLOW

EIS003JE



LIA0123E


- "POWER DOOR LOCK SYSTEM" Diagnosis. Refer to [BL-16, "POWER DOOR LOCK SYSTEM"](#) .
- "REMOTE CONTROL SYSTEM" Diagnosis. Refer to [BL-46, "REMOTE KEYLESS ENTRY SYSTEM"](#) .

VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS003JF

Preliminary Check

The system operation is canceled by turning ignition switch to ACC at any step between START and ARMED in the following flow chart.



LIA1525E

After performing preliminary check, go to symptom chart.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

Symptom Chart

EIS003JG

PROCEDURE		Diagnostic procedure	
SYMPTOM			
1	Vehicle security system cannot be set by	All items Diagnostic Procedure 1 (Door and trunk lamp and trunk release solenoid switch check) Refer to BL-101, "Door Switch Check" . If the above systems are "OK", replace BCM.	
		Lock/unlock switch Diagnostic Procedure 7 (Door lock/unlock switch check) Refer to BL-106, "DOOR LOCK/UNLOCK SWITCH CHECK" . If the above systems are "OK", check main power window and door lock/unlock switch.	
		Driver door outside key Diagnostic Procedure 3 (Door key cylinder switch check) Refer to BL-106, "FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK" . If the above systems are "OK", check main power window and door lock/unlock switch.	
	Security indicator does not turn "ON".		Diagnostic Procedure 2 (Security indicator lamp check) Refer to BL-103, "TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID SWITCH CHECK" . If the above systems are "OK", replace BCM.
	2	*1 Vehicle security system does not alarm when	Any door is opened. Diagnostic Procedure 1 (Door and trunk room lamp switch check) Refer to BL-101, "Door Switch Check" . If the above systems are "OK", replace BCM.
			Horn alarm Diagnostic Procedure 5 (Vehicle security horn alarm check) Refer to BL-106, "VEHICLE SECURITY HORN ALARM CHECK" . If the above systems are "OK", check horn system. Refer to WW-36, "HORN" .
3	Vehicle security alarm does not activate.	Head lamp alarm Diagnostic Procedure 6 (Head lamp alarm check) Refer to BL-106, "VEHICLE SECURITY HEADLAMP ALARM CHECK" . If the above systems are "OK", replace BCM.	
		Driver door outside key Diagnostic Procedure 3 (Door key cylinder switch check) Refer to BL-106, "FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK" . If the above systems are "OK", check main power window and door lock/unlock switch.	
4	Vehicle security system cannot be canceled by	Trunk lid key Diagnostic Procedure 4 (Trunk lid key cylinder switch check) Refer to BL-104, "TRUNK KEY CYLINDER SWITCH (UNLOCK SWITCH) SIGNAL" . If the above systems are "OK", replace BCM.	
		Keyfob Check remote keyless entry function. If the above systems are "OK", replace BCM.	
		Driver door outside key Diagnostic Procedure 3 (Door key cylinder switch check) Refer to BL-106, "FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK" . If the above systems are "OK", check main power window and door lock/unlock switch.	
		Trunk lid key Diagnostic Procedure 4 (Trunk lid key cylinder switch check) Refer to BL-104, "TRUNK KEY CYLINDER SWITCH (UNLOCK SWITCH) SIGNAL" . If the above systems are "OK", replace BCM.	

*1: Make sure the system is in the armed phase.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS003JH

BCM Power Supply and Ground Circuit Check

1. CHECK FUSE

Check the following BCM fuses and fusible link.

Component Parts	Terminal No. (SIGNAL)	Ampere	No.	Location
BCM	11 (ACC power supply)	10A	6	Fuse block (J/B)
	57 (BAT power supply)	10A	21	Fuse block (J/B)
	70 (BAT power supply)	50A	f	Fuse and fusible link box

NOTE:

Refer to [BL-16. "Component Parts and Harness Connector Location"](#) .

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of problem before installing new fuse. Refer to [PG-4. "POWER SUPPLY ROUTING CIRCUIT"](#) .

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM.
- Check voltage between BCM connectors M20 terminals 57, 70 and M18 terminal 11 and ground.

Connector	Terminals (Wire color)		Signal name	Ignition switch	Voltage (V) (Approx.)
	(+)	(-)			
M18	11 (PU)	Ground	ACC power supply	ACC	Battery voltage
M20	57 (W)		Battery power supply	OFF	Battery voltage
	70 (W/B)		Battery power supply	OFF	Battery voltage



OK or NG

OK >> GO TO 3.

NG >> Repair or replace harness.

3. CHECK GROUND CIRCUIT


Check continuity between BCM connector M20 terminal 67 and ground.

Connector	Terminals (Wire color)		Continuity
	(+)	(-)	
M20	67 (B)	Ground	Yes

OK or NG

OK >> Power supply and ground circuit is OK.

NG >> Repair or replace harness.



VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS003JI

Door Switch Check

1. CHECK DOOR SWITCHES INPUT SIGNAL

 With CONSULT-II

Check door switches ("DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR") in DATA MONITOR mode with CONSULT-II. Refer to [BL-27, "DATA MONITOR"](#).

- When any doors are open:

DOOR SW-DR : ON
DOOR SW-AS : ON
DOOR SW-RL : ON
DOOR SW-RR : ON

- When any doors are closed:

DOOR SW-DR : OFF
DOOR SW-AS : OFF
DOOR SW-RL : OFF
DOOR SW-RR : OFF


DATA MONITOR	
MONITOR	
DOOR SW - DR	OFF
DOOR SW - AS	OFF
DOOR SW - RR	OFF
DOOR SW - RL	OFF

PIIA6222E

 Without CONSULT-II

Check voltage between BCM connector M18 or M19 terminals 12, 13, 47, 48 and ground.

Connector	Item	Terminals (Wire color)		Condition	Voltage (V) (Approx.)
		(+)	(-)		
M18	Front door switch RH	12 (P/L)	Ground	Door Open ↓ Closed	0 ↓ Battery voltage
	Rear door switch RH	13 (R/W)			
M19	Front door switch LH	47 (SB)			
	Rear door switch LH	48 (R/B)			



OK or NG

- OK >> System is OK.
 NG >> GO TO 2.

VEHICLE SECURITY (THEFT WARNING) SYSTEM

2. CHECK DOOR SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect door switch and BCM.
3. Check continuity between door switch connector B8 (front LH) or B108 (front RH) terminal 2, B18 (rear LH) or B116 (rear RH) terminal 1 and BCM connector M18, M19 terminals 12, 13, 47 and 48.

- 1 (R/B) - 48 (R/B) : Continuity should exist**
1 (R/W) - 13 (R/W) : Continuity should exist
2 (SB) - 47 (SB) : Continuity should exist
2 (P/L) - 12 (P/L) : Continuity should exist

4. Check continuity between door switch connector B8 (front LH) or B108 (front RH) terminal 2, B18 (rear LH) or B116 (rear RH) terminal 1 and ground.

- 1 (R/B or R/W) - Ground : Continuity should not exist**
2 (SB or P/L) - Ground : Continuity should not exist

OK or NG

- OK >> GO TO 3.
 NG >> Repair or replace harness.



3. CHECK DOOR SWITCHES

1. Disconnect door switch harness.
2. Check continuity between door switch connector terminals.

	Terminals	Condition	Continuity
Rear door switch LH/RH	1 – Ground	Door Open	Yes
		Door Closed	No
Front door switch LH/RH	2 – Ground	Door Open	Yes
		Door Closed	No

OK or NG

- OK >> Check door switch case ground condition.
 NG >> Replace door switch.



VEHICLE SECURITY (THEFT WARNING) SYSTEM


TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID SWITCH CHECK E/S003JJ

1. CHECK TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID INPUT SIGNAL

④ With CONSULT-II

Check "TRNK OPN MNTR" in "DATA MONITOR" mode with CONSULT-II.

When trunk lid is open : TRNK OPN MNTR ON
When trunk lid is closed : TRNK OPN MNTR OFF




⊗ Without CONSULT-II

Check voltage between BCM harness connector M19 terminal 42 (PU/W) and ground.

Refer to [BL-90, "FIG. 2"](#).

OK or NG

OK >> Trunk lamp switch and trunk release solenoid is OK.
 NG >> GO TO 2.



2. CHECK TRUNK LAMP SWITCH AND TRUNK RELEASE SOLENOID

1. Turn ignition switch OFF.
2. Disconnect trunk lamp switch and trunk release solenoid.
3. Check continuity between trunk lamp switch and trunk release solenoid connector B32 terminals 1 and 2.


Connector	Terminals	Condition	Continuity
B32	1 - 2	Closed	No
		Open	Yes

OK or NG

OK >> Check the following:

- Trunk lamp switch and trunk release solenoid ground circuit
- Harness for open or short between trunk lamp switch and trunk release solenoid and BCM

NG >> Replace trunk lamp switch and trunk release solenoid.



VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS003JK

TRUNK KEY CYLINDER SWITCH (UNLOCK SWITCH) SIGNAL

1. TRUNK KEY CYLINDER SWITCH (UNLOCK SWITCH) SIGNAL CHECK

Ⓟ With CONSULT-II


Check trunk key cylinder switch ("TRUNK KEY SW") in "DATA MONITOR" mode with CONSULT-II.

- When key in key cylinder is at "NEUTRAL" position,

TRUNK KEY SW: OFF

- When key is at "UNLOCK" position,

TRUNK KEY SW: ON




⊗ Without CONSULT-II

Check voltage between BCM harness connector M19 terminal 41(L/B) and ground.

Condition	Voltage (V) (Approx.)
Neutral	5
Unlocked	0

OK or NG

- OK >> Trunk key cylinder switch is OK.
- NG >> GO TO 2.




2. CHECK TRUNK KEY CYLINDER SWITCH (UNLOCK SWITCH)

- Disconnect trunk key cylinder switch connector.
- Check continuity between trunk key cylinder switch connector B34 terminals 1 and 2.

Condition	Continuity
Neutral	No
Unlocked	Yes

OK or NG

- OK >> Check the following:
 - Trunk key cylinder switch ground circuit
 - Harness for open or short between trunk key cylinder switch and BCM
- NG >> Replace trunk key cylinder switch.




VEHICLE SECURITY (THEFT WARNING) SYSTEM

EIS003JL

SECURITY INDICATOR LAMP CHECK

1. SECURITY INDICATOR LAMP ACTIVE TEST

Ⓜ With CONSULT-II
Check "THEFT IND" in "ACTIVE TEST" mode with CONSULT-II.




ⓧ Without CONSULT-II

1. Disconnect BCM.
2. Check voltage between BCM harness connector M18 terminal 23 and ground.

Connector	Terminal (Wire color)		Voltage (V) (Approx.)
	(+)	(-)	
M18	23 (G/OR)	Ground	Battery voltage

OK or NG

- OK >> Security indicator lamp is OK.
NG >> GO TO 2.



2. SECURITY INDICATOR LAMP CHECK

Check indicator lamp condition.
Refer to [BL-89, "FIG. 1"](#).

OK or NG

- OK >> GO TO 3.
NG >> Replace indicator lamp.


3. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and security indicator lamp connector.
3. Check continuity between BCM connector M18 terminal 23 and security indicator lamp harness connector M14 terminal 2 and ground.

23 (G/OR) - 2 (G/OR) : Continuity should exist.

OK or NG

- OK >> Check the following:
- 10A fuse [No. 19, located in fuse block (J/B)]
 - Harness for open or short between security indicator lamp and fuse
- NG >> Repair or replace harness.



VEHICLE SECURITY (THEFT WARNING) SYSTEM

FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) CHECK

EIS003JM

1. FRONT DOOR LOCK ASSEMBLY LH (KEY CYLINDER SWITCH) OPERATION

Check door key cylinder switch with key.

Do doors lock/unlock when using the key?

YES >> Front door lock assembly LH (key cylinder switch) is OK.

NO >> Check front door lock assembly LH (key cylinder switch) circuit. Refer to [BL-106, "FRONT DOOR LOCK ASSEMBLY LH \(KEY CYLINDER SWITCH\) CHECK"](#) .

VEHICLE SECURITY HORN ALARM CHECK

EIS003JN

1. CHECK HORN OPERATION

Check if horn sounds with horn switch.

Does horn operate?

YES >> Check harness for open or short between IPDM E/R and horn relay.

NO >> Check horn circuit. Refer to [WW-36, "HORN"](#) .

VEHICLE SECURITY HEADLAMP ALARM CHECK

EIS003JO

1. CHECK VEHICLE SECURITY HEADLAMP ALARM OPERATION

Check if headlamps operate with lighting switch.

Do headlamps come on when turning switch ON?

YES >> Headlamp alarm is OK.

NO >> Check headlamp system. Refer to [LT-6, "HEADLAMP \(FOR USA\)"](#) or [LT-33, "HEADLAMP \(FOR CANADA\) - DAYTIME LIGHT SYSTEM -"](#) .

DOOR LOCK/UNLOCK SWITCH CHECK

EIS003JP

1. CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

Check if power door lock operates with door lock/unlock switch.

Do doors lock/unlock when using each door lock/unlock switch?

YES >> Door lock/unlock switch is OK.

NO >> Refer to [BL-106, "DOOR LOCK/UNLOCK SWITCH CHECK"](#) .

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)


NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

PF2:28591

Component Parts and Harness Connector Location

EIS003JQ

A
B
C
D
E
F
G
H
BL
J
K
L
M



NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS003JR

System Description

NVIS (Nissan Vehicle Immobilizer System-NATS) has the following immobilizer functions:

- Since only NVIS (NATS) ignition keys, whose IDs have been registered into the ECM and BCM, allow the engine to run, operation of a stolen vehicle without a NVIS (NATS) registered key is prevented by NVIS (NATS).
NVIS (NATS) will immobilize the engine if someone tries to start it without the registered key of NVIS (NATS).
- All of the originally supplied ignition key IDs have been NVIS (NATS) registered.
If requested by the vehicle owner, a maximum of five key IDs can be registered into the NVIS (NATS) components.
- The security indicator blinks when the ignition switch is in OFF or ACC position. NVIS (NATS) warns outsiders that the vehicle is equipped with the anti-theft system.
- When NVIS (NATS) detects trouble, the security indicator lamp lights up while ignition key is in the ON position.
- NVIS (NATS) trouble diagnoses, system initialization and additional registration of other NVIS (NATS) ignition key IDs must be carried out using CONSULT-II hardware and CONSULT-II NVIS (NATS) software. When NVIS (NATS) initialization has been completed, the ID of the inserted ignition key is automatically NVIS (NATS) registered. Then, if necessary, additional registration of other NVIS (NATS) ignition key IDs can be carried out.
Regarding the procedures of NVIS (NATS) initialization and NVIS (NATS) ignition key ID registration, refer to CONSULT-II Operation Manual NATS-IVIS/NVIS.
- **When servicing a malfunction of the NVIS (NATS) (indicated by lighting up of Security Indicator Lamp) or registering another NVIS (NATS) ignition key ID, it may be necessary to re-register original key identification. Therefore, be sure to receive ALL KEYS from vehicle owner.**

System Composition


EIS003JS

The immobilizer function of the NVIS (NATS) consists of the following:

- NATS ignition key
- NATS antenna amp. located in the ignition key cylinder
- Body control module (BCM)
- Engine control module (ECM)
- Security indicator lamp

NOTE:

The communication between ECM and BCM uses the CAN communication system.



PIA1121E

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

ECM Re-communicating Function

EIS003JT

The following procedure can automatically perform re-communication of ECM and BCM, but only when the ECM has been replaced with a new one which has never been energized on-board.
(In this step, initialization procedure by CONSULT-II is not necessary.)

NOTE:

- **When registering new Key IDs or replacing the ECM other than brand new, refer to CONSULT-II Operation Manual NATS-IVIS/NVIS.**
 - **If multiple keys are attached to the key holder, separate them before work.**
 - **Distinguish keys with unregistered key ID from those with registered ID.**
1. Install ECM.
 2. Using a registered key (*1), turn ignition switch to ON.
*1: To perform this step, use the key that has been used before performing ECM replacement.
 3. Maintain ignition switch in ON position for at least 5 seconds.
 4. Turn ignition switch to OFF.
 5. Start engine.
If engine can be started, procedure is completed.
If engine cannot be started, refer to CONSULT-II Operation Manual NATS-IVIS/NVIS and initialize control unit.

A
B
C
D
E
F
G
H
J
K
L
M



BL

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS003JU

Wiring Diagram — NATS —

BL-NATS-01



WIWA1024E

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

Terminals and Reference Value for BCM

EIS003JV

Terminal	Wire Color	Item	Condition	Voltage (V) (Approx.)
21	P	NATS antenna amp.	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
23	G/OR	Security indicator lamp	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0
25	Y/B	NATS antenna amp.	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move.
38	R	Ignition switch (ON or START)	Ignition switch (ON or START position)	Battery voltage
39	L	CAN-H	—	—
40	P	CAN-L	—	—
57	W	Battery power supply	—	Battery voltage
67	B	Ground	—	0
70	W/B	Battery power supply	—	Battery voltage

CONSULT-II


EIS003JW

CONSULT-II INSPECTION PROCEDURE

CAUTION:


If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communications

1. Turn ignition switch OFF.
2. Connect CONSULT-II and CONSULT-II CONVERTER to data link connector.



3. Insert NVIS (NATS) program card into CONSULT-II.


Program card : NATS (AEN04A-1) or later




4. Turn ignition switch ON.
5. Touch "START".

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

6. Select "NATS V.5.0".



7. Perform each diagnostic test mode according to each service procedure.



For further information, see the "CONSULT-II OPERATION MANUAL IVIS/NVIS".

CONSULT-II DIAGNOSTIC TEST MODE FUNCTION

CONSULT-II DIAGNOSTIC TEST MODE	Description
C/U INITIALIZATION	When replacing any of the following components, C/U initialization and re-registration of all NATS ignition keys are necessary. [(NATS ignition key/ BCM/ ECM]
SELF-DIAG RESULTS	Detected items (screen terms) are as shown in the chart. Refer to BL-113. "NVIS (NATS) SELF-DIAGNOSTIC RESULTS ITEM CHART" .


NOTE:

- When any initialization is performed, all IDs previously registered will be erased and all NATS ignition keys must be registered again.
- The engine cannot be started with an unregistered key. In this case, the system will show "DIFFERENCE OF KEY" or "LOCK MODE" as a self-diagnostic result on the CONSULT-II screen.
- In rare case, "CHAIN OF ECM-IMMU" might be stored as a self-diagnostic result during key registration procedure, even if the system is not malfunctioning.

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS003JX

Work Flow



LIA1152E

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS003JY

Trouble Diagnoses SYMPTOM MATRIX CHART 1

Self-diagnosis related item

Symptom	Displayed "SELF-DIAG RESULTS" on CONSULT-II screen.	Diagnostic Procedure (Reference page)	System (Malfunctioning part or mode)	Reference Part No. Of Illustration On System Diagram
<ul style="list-style-type: none"> ● Security indicator lighting up* ● Engine cannot be started 	CHAIN OF ECM-IMMU [P1612]	PROCEDURE 1 (BL-117)	In rare case, "CHAIN OF ECM-IMMU" might be stored during key registration procedure, even if the system is not malfunctioning.	—
			Open circuit in battery voltage line of BCM circuit	C1
			Open circuit in ignition line of BCM circuit	C2
			Open circuit in ground line of BCM circuit	C3
			Open or short circuit between BCM and ECM communication line	C4
			ECM	B
			BCM	A
	DIFFERENCE OF KEY [P1615]	PROCEDURE 2 (BL-118)	Unregistered key	D
			BCM	A
	CHAIN OF IMMU-KEY [P1614]	PROCEDURE 5 (BL-121)	Malfunction of key ID chip	E5
			Communication line between ANT/ AMP and BCM:	E1
			Open circuit or short circuit of battery voltage line or ground line	E2
			Open circuit in power source line of ANT/ AMP circuit	E3
			Open circuit in ground line of ANT/ AMP circuit	E4
			NATS antenna amp.	E6
			BCM	A
	ID DISCORD, IMM-ECM [P1611]	PROCEDURE 3 (BL-119)	System initialization has not yet been completed.	F
			ECM	B
LOCK MODE [P1610]	PROCEDURE 4 (BL-120)	LOCK MODE	D	
Security indicator lighting up*	DON'T ERASE BEFORE CHECKING ENG DIAG	WORK FLOW (BL-114)	Engine trouble data and NVIS (NATS) trouble data have been detected in ECM	—

*: When NVIS (NATS) detects trouble, the security indicator lights up while ignition key is in the "ON" position.

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)


SYMPTOM MATRIX CHART 2

Non self-diagnosis related item

Symptom	Diagnostic Procedure (Reference page)	System (Malfunctioning part or mode)	Reference Part No. Of Illustration On System Diagram
Security indicator does not light up*.	PROCEDURE 6 (BL-124)	Security indicator lamp	—
		Open circuit between Fuse and BCM	—
		BCM	A

*: CONSULT-II self-diagnostic results display screen “no malfunction is detected”.

DIAGNOSTIC SYSTEM DIAGRAM



NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS003JZ

Diagnostic Procedure 1

Self-diagnostic results:

“CHAIN OF ECM-IMMU” displayed on CONSULT-II screen

First perform the “SELF-DIAG RESULTS” in “BCM” with CONSULT-II, then perform the trouble diagnosis of malfunction system indicated “SELF-DIAG RESULTS” of “BCM”. Refer to [BL-111, "CONSULT-II"](#)

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS “CHAIN OF ECM-IMMU” displayed on CONSULT-II screen.

NOTE:

In rare case, “CHAIN OF ECM-IMMU” might be stored during key registration procedure, even if the system is not malfunctioning.

Is CONSULT-II screen displayed as shown?

Yes >> GO TO 2.

No >> GO TO [BL-115, "SYMPTOM MATRIX CHART 1"](#).

SELF DIAGNOSIS	
DTC RESULTS	TIME
CHAIN OF ECM-IMMU [P1612]	0

PIIA1260E

2. CHECK POWER SUPPLY CIRCUIT FOR BCM

- Turn ignition switch OFF.
- Check voltage between BCM connector M20 terminal 70 and ground.

70 (W/B) – Ground : Battery voltage


OK or NG

OK >> GO TO 3.

NG >> Check the following:

- 50A fusible link (letter f , located in fuse and fusible link box)
- Harness for open or short between fuse and BCM connector

Ref. Part No. C1



3. CHECK IGNITION SWITCH ON SIGNAL

- Turn ignition switch ON.
- Check voltage between BCM connector M18 terminal 38 and ground.

38 (R) – Ground : Battery voltage


OK or NG

OK >> GO TO 4.

NG >> Check the following:

- 10A fuse [No. 1, located in the fuse block (J/B)]
- Harness for open or short between fuse and BCM connector

Ref. part No. C2



NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)


4. CHECK GROUND CIRCUIT FOR BCM

1. Turn ignition switch OFF.
2. Check continuity between BCM connector M18 terminal 67 and ground.

67 (B) – Ground : Continuity should exist

OK or NG

- OK >> GO TO 5.
NG >> Repair or replace harness. **Ref. part No. C3**



5. REPLACE BCM

1. Replace BCM. **Ref. part No. A**
2. Perform initialization with CONSULT-II.
For initialization, refer to “CONSULT-II Operation Manual NATS-IVIS/NVIS”.

Does the engine start?

- Yes >> BCM is malfunctioning.
No >> ● ECM is malfunctioning.
- Replace ECM. **Ref. part No. B**
 - Perform initialization or re-communicating function.
 - For initialization, refer to “CONSULT-II Operation Manual NATS-IVIS/NVIS”.
 - For re-communicating function, refer to [BL-109, "ECM Re-communicating Function"](#).

Diagnostic Procedure 2

EIS003K0

Self-diagnostic results:

“DIFFERENCE OF KEY” displayed on CONSULT-II screen

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS “DIFFERENCE OF KEY” displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as shown?

- Yes >> GO TO 2.
No >> GO TO [BL-115, "SYMPTOM MATRIX CHART 1"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
DIFFERENCE OF KEY [P1615]	0

PIA1261E

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

2. PERFORM INITIALIZATION WITH CONSULT-II

Perform initialization with CONSULT-II. Re-register all NATS ignition key IDs.


For initialization and registration of NATS ignition key IDs, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows message on the screen.

Can the system be initialized and can the engine be started with re-registered NATS ignition key?

- Yes >> ● Ignition key ID was unregistered. **Ref. part No. D**
- No >> ● BCM is malfunctioning.
- Replace BCM. **Ref. part No. A**
 - Perform initialization with CONSULT-II.
 - For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



Diagnostic Procedure 3

Self-diagnostic results:

"ID DISCORD, IMM-ECM" displayed on CONSULT-II screen

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS "ID DISCORD, IMM-ECM" displayed on CONSULT-II screen.

NOTE:

"ID DISCORD IMM-ECM":

Registered ID of BCM is in discord with that of ECM.

Is CONSULT-II screen displayed as shown?

- Yes >> GO TO 2.
- No >> GO TO [BL-115, "SYMPTOM MATRIX CHART 1"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
ID DISCORD, IMM-ECM [P1611]	0

PIIA1262E

2. PERFORM INITIALIZATION WITH CONSULT-II

Perform initialization with CONSULT-II. Re-register all NATS ignition key IDs.


For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows message on the screen.

Can the system be initialized?

- Yes >> ● Start engine. (END)
- System initialization had not been completed. **Ref. part No. F**
- No >> ● ECM is malfunctioning.
- Replace ECM. **Ref. part No. B**
 - Perform initialization with CONSULT-II.
- For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS003K2

Diagnostic Procedure 4

Self-diagnostic results:

“LOCK MODE” displayed on CONSULT-II screen

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS “LOCK MODE” is displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as shown?

Yes >> GO TO 2.

No >> GO TO [BL-115, "SYMPTOM MATRIX CHART 1"](#).

SELF DIAG RESULTS	
DTC RESULTS	TIME
LOCK MODE [P1610]	0

PIA1264E

2. ESCAPE FROM LOCK MODE

1. Turn ignition switch OFF.
2. Turn ignition switch ON with registered key. (Do not start engine.) Wait 5 seconds.
3. Return the key to OFF position. Wait 5 seconds.
4. Repeat steps 2 and 3 twice (total of three cycles).
5. Start the engine.

Does engine start?

Yes >> System is OK (Now system is escaped from “LOCK MODE”).

No >> GO TO 3.

3. PERFORM INITIALIZATION WITH CONSULT-II

Perform initialization with CONSULT-II.

For initialization, refer to “CONSULT-II Operation Manual NATS-IVIS/NVIS”.

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows the message on the screen.

Can the system be initialized?

Yes >> System is OK.

No >> GO TO 4.

IMMU INITIALIZATION
INITIALIZATION FAIL
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.

SEL297W

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

4. PERFORM INITIALIZATION WITH CONSULT-II AGAIN


1. Replace BCM.
2. Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

NOTE:

If the initialization is not completed or malfunctions, CONSULT-II shows the message on the screen.

Can the system be initialized?

- Yes >> System is OK. BCM is malfunctioning. **Ref. part No. A**
- No >> ● ECM is malfunctioning.
- Replace ECM. **Ref. part No. B**
 - Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



Diagnostic Procedure 5

EIS003K3

Self-diagnostic results:

"CHAIN OF IMMU-KEY" displayed on CONSULT-II screen

1. CONFIRM SELF-DIAGNOSTIC RESULTS

Confirm SELF-DIAGNOSTIC RESULTS "CHAIN OF IMMU-KEY" displayed on CONSULT-II screen.

Is CONSULT-II screen displayed as shown?

- Yes >> GO TO 2.
- No >> GO TO [BL-115, "SYMPTOM MATRIX CHART 1"](#) .

SELF DIAGNOSIS	
DTC RESULTS	TIME
CHAIN OF IMMU-KEY [P1614]	0

PIIA1263E

2. CHECK NATS ANTENNA AMP. INSTALLATION

Check NATS antenna amp. installation. Refer to [BL-125, "How to Replace NVIS \(NATS\) IMMU"](#) .

OK or NG

- OK >> GO TO 3.
- NG >> Reinstall NATS antenna amp. correctly.

3. CHECK NVIS (NATS) IGNITION KEY ID CHIP

Start engine with another registered NATS ignition key.

Does the engine start?

- Yes >> ● Ignition key ID chip is malfunctioning.
- Replace the ignition key.
Ref. part No. E5
 - Perform initialization with CONSULT-II.
For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".
- No >> GO TO 4.

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

4. CHECK POWER SUPPLY FOR NATS ANTENNA AMP.


Check voltage between NATS antenna amp. connector M27 terminal 1 and ground.

1 (W/L) – Ground : Battery voltage

OK or NG

OK >> GO TO 5.

NG >> Repair or replace fuse or harness. **Ref. part No. E3**



5. CHECK NATS ANTENNA AMP. SIGNAL LINE- 1

Check voltage between NATS antenna amp. connector M27 terminal 2 and ground with analog tester.

Before inserting key into ignition key cylinder


Voltage: Battery voltage

After inserting key into ignition key cylinder

2 (P) – Ground : Pointer of tester should move for approx. 30 seconds, then return to battery voltage.

Just after turning ignition switch ON

: Pointer of tester should move for approx. 1 second, then return to battery voltage.



OK or NG

OK >> GO TO 6.

NG >> ● Repair or replace harness.

NOTE:

If harness is OK, replace BCM, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

6. CHECK NATS ANTENNA AMP. SIGNAL LINE- 2

Check voltage between NATS antenna amp. connector M27 terminal 4 and ground with analog tester.

Before inserting key into ignition key cylinder

Voltage: Battery voltage


After inserting key into ignition key cylinder

**4 (Y/B) –
Ground**

: Pointer of tester should move for approx. 30 seconds, then return to battery voltage.

Just after turning ignition switch ON

: Pointer of tester should move for approx. 1 second, then return to battery voltage.



OK or NG

OK >> GO TO 7.

NG >> ● Repair or replace harness.

NOTE:

If harness is OK, replace BCM, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".

7. CHECK NATS ANTENNA AMP. GROUND LINE CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect NATS antenna amp. connector.
3. Check continuity between NATS antenna amp. connector M27 terminal 3 and ground.

3 (B) – Ground : Continuity should exist.

OK or NG


OK >> ● NATS antenna amp. is malfunctioning.

Ref. part No. E6

NG >> ● Repair or replace harness.

NOTE:

If harness is OK, replace BCM, perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual NATS-IVIS/NVIS".



NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

EIS003K4

Diagnostic Procedure 6

“SECURITY INDICATOR LAMP DOES NOT LIGHT UP”

1. CHECK FUSE

Check 10A fuse [No.19, located in the fuse block (J/B)]

NOTE:

Refer to [BL-107, "Component Parts and Harness Connector Location"](#).

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. CHECK SECURITY INDICATOR LAMP

1. Start engine and turn ignition switch OFF.
2. Check the security indicator lamp.

Security indicator lamp should light up.

OK or NG

OK >> Inspection End.

NG >> GO TO 3.

3. CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT


1. Disconnect security indicator lamp connector.
2. Check voltage between security indicator lamp connector M14 terminal 1 and ground.

1 (Y/R) – Ground : Battery voltage

OK or NG

OK >> GO TO 4.

NG >> Repair or replace harness.



4. CHECK BCM (NATS CONTROL UNIT) FUNCTION

1. Connect security indicator lamp connector.
2. Disconnect BCM.
3. Check voltage between BCM connector M18 terminal 23 and ground.

23 (G/OR) – Ground : Battery voltage


OK or NG

OK >> BCM is malfunctioning.

- Replace BCM.
Ref. part No. A
- Perform initialization with CONSULT-II.
- For initialization, refer to “CONSULT-II Operation Manual NATS-IVIS/NVIS”.

NG >> Check the following.

- Harness for open or short between security indicator lamp and BCM (NATS control unit).
- Indicator lamp condition




NVIS(NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS)

How to Replace NVIS (NATS) IMMU

EIS003K5

NOTE:

- If NVIS (NATS) IMMU is not installed correctly, NVIS (NATS) system will not operate properly and SELF-DIAG RESULTS on CONSULT-II screen will show "LOCK MODE" or "CHAIN OF IMMU-KEY".



A
B
C
D
E
F
G
H
BL
J
K
L
M

HOMELINK UNIVERSAL TRANSCEIVER



PFP:96401

HOMELINK UNIVERSAL TRANSCEIVER

Wiring Diagram — TRNSCV —

EIS003K6

BL-TRNSCV-01



LIWA0399E

HOMELINK UNIVERSAL TRANSCEIVER

EIS003K7

Trouble Diagnoses DIAGNOSTIC PROCEDURE

SYMPTOM: Transmitter does not activate receiver.

Before conducting the procedure given below, make sure that system receiver (garage door opener, etc.) operates with original, hand-held transmitter. If NG, receiver or hand-held transmitter is at fault, not vehicle related.


1. ILLUMINATION CHECK

- Turn ignition switch OFF.
- Does red light (LED) of transmitter illuminate when any button is pressed?

YES or NO

YES >> GO TO 2.

NO >> GO TO 3.



2. TRANSMITTER CHECK

Check transmitter with Tool*.

*:For details, refer to Technical Service Bulletin.

OK or NG

OK >> Receiver or hand-held transmitter malfunction, not vehicle related.

NG >> Replace transmitter with sun visor assembly.

3. POWER SUPPLY CHECK

1. Disconnect transmitter connector.
2. Turn ignition switch OFF.
3. Check voltage between transmitter harness connector R2 terminal 1 Y/R and body ground.


Battery voltage should exist.

OK or NG

OK >> GO TO 4.

NG >> ● Check 10A fuse [No. 19 located in the fuse block (J/B)]

- Harness for open or short between fuse and transmitter



4. GROUND CIRCUIT CHECK


Check continuity between transmitter harness connector R2 terminal 2 (B) and body ground.

Continuity should exist.

OK or NG

OK >> Replace transmitter with sun visor assembly.

NG >> Repair harness.




BODY REPAIR

PF6:60100

EIS003K8

BODY REPAIR

Body Exterior Paint Color



LIA0126E

Component			Color code	A15	A20	BW9	C12	DY2	K11	KH3	KY1	KY2	QX3
			Description	Sonoma Sunset	Code Red	Majestic Blue	Coral Sand	Mystic Emerald	Smoke	Super Black	Sheer Silver	Polished Pewter	Satin White
			Paint type	2M	2M	2M	2M	2M	2M	2S	2M	2M	3P
			Hard clear coat	X	X	X	X	X	X	X	X	X	X
1	Bumper fascia	Body	Body color	A15	A20	BW9	C12	DY2	K11	KH3	KY1	KY2	BQX3
2	Radiator grille	Center	Black	AG01	AG01	AG01	AG01	AG01	AG01	AG01	AG01	AG01	AG01
		Outer	Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
3	Outside mirror	Body	Body color	A15	A20	BW9	C12	DY2	K11	KH3	KY1	KY2	QX3
		Base	Black	AG01	AG01	AG01	AG01	AG01	AG01	AG01	AG01	AG01	AG01
4	Side guard molding	Body	Body color	A15	A20	BW9	C12	DY2	K11	KH3	KY1	KY2	QX3
		Base	Black	AG01	AG01	AG01	AG01	AG01	AG01	AG01	AG01	AG01	AG01
5	Door sash		Black tape	X	X	X	X	X	X	X	X	X	X
6	Outside handle		Body color	A15	A20	BW9	C12	DY2	K11	KH3	KY1	KY2	QX3
7	Rear Spoiler		Body color	A15	A20	BW9	C12	DY2	K11	KH3	KY1	KY2	QX3
8	Trunk lid finisher		Body color	A15	A20	BW9	C12	DY2	K11	KH3	KY1	KY2	QX3
9	Center mud-guard		Body color	A15	A20	BW9	C12	DY2	K11	KH3	KY1	KY2	QX3


2S: Solid Color with Clear, 2M: Metallic with Clear, 3P:3-Coat Pearl

BODY REPAIR

Body Component Parts UNDERBODY COMPONENT PARTS

EIS003K9

A
B
C
D
E
F
G
H
BL
J
K
L
M



-  : Indicates both-side anti-corrosive pre-coated steel portions
-  : Indicates high strength steel (HSS) portions
-  : Indicates both-side anti-corrosive pre-coated steel and (HSS) portions


LIA1668E

BODY REPAIR

1. 2nd crossmember assembly
2. Front floor)
3. Transmission control reinforcement
4. Front floor reinforcement RH/LH
5. Lower dash assembly
6. Upper dash
7. Front cowl top
8. Cowl top extension bracket RH/LH
9. Center cowl top
10. Cowl top reinforcement RH/LH
11. Cowl top extension
12. Cowl top side brace RH/LH
13. Front side member assembly RH/LH
14. Side member closing plate assembly RH/LH
15. Lower front hoodledge assembly RH/LH
16. Lower rear hoodledge RH/LH
17. Upper hoodledge RH/LH
18. Front hoodledge reinforcement RH/LH
19. Hoodledge reinforcement gusset RH/LH
20. Rear hoodledge reinforcement RH/LH
21. Side cowl top RH/LH
22. Front side member extension reinforcement RH/LH
23. Front side member front extension RH/LH
24. Front inner sill reinforcement RH/LH
25. Inner sill RH/LH
26. Inner sill extension RH/LH
27. Front side member center extension RH/LH
28. Front side member rear extension RH/LH
29. Fuel tank protector RH/LH
30. Rear side member assembly RH/LH
31. Rear side member extension assembly RH/ LH
32. Rear center crossmember
33. Rear seat bracket
34. Inner rear seatbelt anchor reinforcement
35. Rear seat crossmember assembly
36. Rear seat crossmember reinforcement
37. Rear parking brake bracket
38. Front floor reinforcement assembly
39. Rear floor front extension
40. Rear floor front
41. Rear floor side LH
42. Rear floor rear
43. Rear floor side RH

BODY REPAIR

BODY COMPONENT PARTS



A
B
C
D
E
F
G
H
I
J
K
L
M

BL

BODY REPAIR

1. Standard roof
2. Front roof rail assembly
3. Front roof bow
4. Center roof bow assembly
5. Rear roof rail assembly
6. Roof (if equipped with sunroof)
7. Roof reinforcement assembly (if equipped with sunroof)
8. Hood assembly
9. Upper inner front pillar RH/LH
10. Lower inner front pillar RH/LH
11. Front fender RH/LH
12. Front pillar upper hinge brace assembly RH/LH
13. Front pillar lower reinforcement RH/LH
14. Front pillar lower hinge brace assembly RH/LH
15. Front outer sill reinforcement RH/LH
16. Sill outer reinforcement assembly RH/LH
17. Front body side outer assembly RH/LH
18. Front door assembly RH/LH
19. Rear door assembly RH/LH
20. Fuel door assembly
21. Fuel filler base assembly
22. Rear body side outer assembly RH/LH
23. Rear pillar inner reinforcement RH/LH
24. Outer rear wheel house RH/LH
25. Rear outer sill reinforcement RH/LH
26. Center pillar reinforcement RH/LH
27. Inner center pillar RH/LH
28. Front pillar outer reinforcement RH/LH
29. Roof side outer reinforcement assembly RH/LH
30. Rear wheelhouse outer extension assembly RH/LH
31. Rear wheelhouse inner assembly RH/LH
32. Rear seatback side support assembly RH/LH
33. Rear pillar inner RH/LH
34. Rear fender corner assembly RH/LH
35. Parcel shelf side RH/LH
36. Parcel shelf assembly RH/LH
37. Rear panel assembly
38. Trunk lid assembly

BODY REPAIR

EIS003KA

Corrosion Protection


DESCRIPTION

To provide improved corrosion prevention, the following anti-corrosive measures have been implemented in NISSAN production plants. When repairing or replacing body panels, it is necessary to use the same anti-corrosive measures.

ANTI-CORROSIVE PRECOATED STEEL (GALVANNEALED STEEL)

To improve repairability and corrosion resistance, a new type of anti-corrosive precoated steel sheet has been adopted replacing conventional zinc-coated steel sheet.

Galvannealed steel is electroplated and heated to form Zinc-iron alloy, which provides excellent and long term corrosion resistance with cationic electrodeposition primer.




Nissan Genuine Service Parts are fabricated from galvannealed steel. Therefore, it is recommended that GENUINE NISSAN PARTS or equivalent be used for panel replacement to maintain the anti-corrosive performance built into the vehicle at the factory.

PHOSPHATE COATING TREATMENT AND CATIONIC ELECTRODEPOSITION PRIMER

A phosphate coating treatment and a cationic electrodeposition primer, which provide excellent corrosion protection, are employed on all body components.

CAUTION:

Confine paint removal during welding operations to an absolute minimum.





Nissan Genuine Service Parts are also treated in the same manner. Therefore, it is recommended that GENUINE NISSAN PARTS or equivalent be used for panel replacement to maintain anti-corrosive performance built into the vehicle at the factory.


BODY REPAIR

ANTI-CORROSIVE WAX

To improve corrosion resistance, anti-corrosive wax is applied inside the body sill and inside other closed sections. Accordingly, when replacing these parts, be sure to apply anti-corrosive wax to the appropriate areas of the new parts. Select an excellent anti-corrosive wax which will penetrate after application and has a long shelf life.



 : Indicates anti-corrosive wax coated portions inside doors.



LIA0005E

BODY REPAIR


UNDERCOATING

The underside of the floor and wheelhouse are undercoated to prevent rust, vibration, noise and stone chipping. Therefore, when such a panel is replaced or repaired, apply undercoating to that part. Use an undercoating which is rust preventive, soundproof, vibration-proof, shock-resistant, adhesive, and durable.

Precautions in undercoating

1. Do not apply undercoating to any place unless specified (such as the areas above the muffler and three way catalyst which are subjected to heat).
2. Do not undercoat the exhaust pipe or other parts which become hot.
3. Do not undercoat rotating parts.
4. Apply bitumen wax after applying undercoating.

 : Indicates undercoated portions.





LIA0129E

BODY REPAIR

EIS003KB


Body Sealing DESCRIPTION

The following figure shows the areas which are sealed at the factory. Sealant which has been applied to these areas should be smooth and free from cuts or gaps. Care should be taken not to apply an excess amount of sealant and not to allow other unaffected parts to come into contact with the sealant.



WIIA0402E

BODY REPAIR





WIHA0130E

BODY REPAIR

Body Construction BODY CONSTRUCTION

EIS003KC



A
B
C
D
E
F
G
H
BL
J
K
L
M



WIIA0131E

BODY REPAIR

EIS003KD

Body Alignment BODY CENTER MARKS

A mark has been placed on each part of the body to indicate the vehicle center. When repairing parts damaged by an accident which might affect the vehicle frame (members, pillars, etc.), more accurate and effective repair will be possible by using these marks together with body alignment specifications.






LIA1365E

BODY REPAIR

PANEL PARTS MATCHING MARKS

A mark has been placed on each body panel to indicate the parts matching positions. When repairing parts damaged by an accident which might affect the vehicle structure (members, pillars, etc.), more accurate and effective repair will be possible by using these marks together with body alignment specifications.




W1IA0132E

A
B
C
D
E
F
G
H
BL
J
K
L
M

BODY REPAIR

DESCRIPTION


- All dimensions indicated in the figures are actual.
- When using a tracking gauge, adjust both pointers to equal length. Then check the pointers and gauge itself to make sure there is no free play.
- When a measuring tape is used, check to be sure there is no elongation, twisting or bending.
- Measurements should be taken at the center of the mounting holes.
- An asterisk (*) following the value at the measuring point indicates that the measuring point on the other side is symmetrically the same value.
- The coordinates of the measurement points are the distances measured from the standard line of "X", "Y" and "Z".



PIIA0104E

BODY REPAIR







ENGINE COMPARTMENT MEASUREMENT



A
B
C
D
E
F
G
H
BL
J
K
L
M

BODY REPAIR

MEASUREMENT POINTS



Unit: mm

WIHA0403E

BODY REPAIR

UNDERBODY MEASUREMENT

Unit : mm


Figures marked with a (*) indicate symmetrically identical dimensions on both right and left hand sides of the vehicle.

★ : Bolt head
As viewed from underside.

All dimensions indicated in this figure are actual.

LH side

RH side




A
B
C
D
E
F
G
H
J
K
L
M

BL

BODY REPAIR

MEASUREMENT POINTS




Coordinates:

- (A), (a)
X : ±494
Y : -617.5
Z : 140.3
- (B), (b)
X : ±495
Y : -500
Z : 357
- (C), (c)
X : ±440
Y : 122.2
Z : 337.6
- (D), (d)
X : ±310
Y : 327.5
Z : 71.987
- (E), (e)
X : ±405
Y : 1190
Z : 97.9
- (F), (f)
X : ±406.5
Y : 1727
Z : 89.3
- (G), (g)
X : ±661
Y : 2080
Z : 164.6
- (H), (h)
X : ±510
Y : 2563
Z : 151.8
- (I), (i)
X : ±496.0
Y : 2936.7
Z : 359.6
- (J), (j)
X : ±466
Y : 3132
Z : 225
- (K), (k)
X : ±476
Y : 3550
Z : 336.8

Strut tower centers

Coordinates:

- (L), (l) Front
X : ±547.6
Y : 28.9
Z : 794.2
- (M), (m) Rear
X : ±531.1
Y : 2833.1
Z : 812.7




Unit: mm

W11A0404E

BODY REPAIR

PASSENGER COMPARTMENT MEASUREMENT



Point	Dimension	Point	Dimension
E-e	1192	Q-I*	939
F-f	1450	R-K	1075
G-g	1468	R-k	1167
I-i	1451	R-L	814
I-F	885	R-l	963
J-j	1467	R-M	751
L-l	1448	R-m	912
M-m	1469	R-N	1106
N-n	1332	R-n	1211
O-L*	840	R-P	697
P-p	1468	R-p	868
Q-G*	919	S-U*	1152
Q-H*	1255	T-V*	1132

= Figures marked with a () indicate symmetrically identical dimensions on both right and left hand sides of the vehicle.

Unit: mm









LIA1369E

A
B
C
D
E
F
G
H
I
J
K
L
M

BL

BODY REPAIR

MEASUREMENT POINTS




Unit: mm

WIHA0405E

BODY REPAIR

REAR BODY MEASUREMENT

= Figures marked with a () indicate symmetrically identical dimensions on both right and left hand sides of the vehicle.








Unit: mm

LIA1371E

BODY REPAIR

MEASUREMENT POINTS



LIIA0066E

BODY REPAIR

EIS003KE



Handling Precautions for Plastics HANDLING PRECAUTIONS FOR PLASTICS

Abbreviation	Material name	Heatresisting temperature °C (°F)	Resistance to gasoline and solvents	Other cautions
PE	Polyethylene	60 (140)	Gasoline and most solvents are harmless if applied for a very short time (wipe up quickly).	Flammable
PVC	Polyvinyl Chloride	80 (176)	Same as above.	Poison gas is emitted when burned.
EPM/EPDM	Ethylene Propylene (Diene) rubber	80 (176)	Same as above.	Flammable
TPO/TPR	Thermoplastic Olefine/ Thermoplastic Rubber	80 (176)	Same as above.	Flammable
PP	Polypropylene	90 (194)	Same as above.	Flammable, avoid battery acid.
UP	Polyester thermoset	90 (194)	Same as above.	Flammable
PS	Polystyrene	80 (176)	Avoid solvents.	Flammable
ABS	Acrylonitrile Butadiene Styrene resin	80 (176)	Avoid gasoline and solvents.	
AES	Acrylonitrile Ethylene Styrene	80 (176)	Same as above.	
PMMA	Polymethyl Methacrylate	85 (185)	Same as above.	
AAS	Acrylonitrile Acrylic Styrene	85 (185)	Same as above.	
AS	Acrylonitrile Styrene	85 (185)	Same as above.	
EVA	Polyvinyl Ethyl Acetate	90 (194)	Same as above.	
ASA	Acrylonitrile Styrene Acrylate	100 (222)	Same as above.	Flammable
PPO/PPE	Polyphenylene Oxide/ Polyphenylene Ether	110 (230)	Same as above.	
PC	Polycarbonate	120 (248)	Same as above.	
PAR	Polyacrylate	180 (356)	Same as above.	
L-LDPE	Linear Low Density PE	45 (100)	Gasoline and most solvents are harmless.	Flammable
PUR	Polyurethane	90 (194)	Same as above.	
TPU	Thermoplastic Urethane	110 (230)	Same as above.	
PPC	Polypropylene Composite	115 (239)	Same as above.	Flammable
POM	Polyacetal	120 (248)	Same as above.	Avoid battery acid.
PBT+PC	Polybutylene Terephthalate+Polycarbonate	120 (248)	Same as above.	Flammable
PA	Polyamide (Nylon)	140 (284)	Same as above.	Avoid immersing in water.
PBT	Polybutylene Terephthalate	140 (284)	Same as above.	
FRP	Fiber Reinforced Plastics	170 (338)	Same as above.	Avoid battery acid.
PET	Polyethylene Terephthalate	180 (356)	Same as above.	
PEI	Polyetherimide	200 (392)	Same as above.	

1. When repairing and painting a portion of the body adjacent to plastic parts, consider their characteristics (influence of heat and solvent) and remove them if necessary or take suitable measures to protect them.
2. Plastic parts should be repaired and painted using methods suiting the materials' characteristics.


BODY REPAIR

LOCATION OF PLASTIC PARTS



LIIA0088E

BODY REPAIR



A
B
C
D
E
F
G
H
BL
J
K
L
M

BODY REPAIR

EIS003KF

Precautions in Repairing High Strength Steel

High strength steel is used for body panels in order to reduce vehicle weight.

Accordingly, precautions in repairing automotive bodies made of high strength steel are described below:

HIGH STRENGTH STEEL (HSS) USED IN NISSAN VEHICLES

Tensile strength	Nissan/Infiniti designation	Major applicable parts
373 N/mm ² (38kg/mm ² ,54klb/sq in)	SP130	<ul style="list-style-type: none"> ● Front side member assembly ● Upper hoodledge ● Upper pillar hinge brace assembly ● Rear side member extension ● Other reinforcements
785-981 N/mm ² (80-100kg/mm ² 114-142klb/sq in)	SP150	<ul style="list-style-type: none"> ● Front bumper reinforcement ● Rear bumper reinforcement

SP130 is the most commonly used HSS.

SP150 HSS is used only on parts that require much more strength.


Read the following precautions when repairing HSS:

1. Additional points to consider


- The repair of reinforcements (such as side members) by heating is not recommended since it may weaken the component. When heating is unavoidable, do not heat HSS parts above 550°C (1,022°F).

Verify heating temperature with a thermometer.


(Crayon-type and other similar type thermometer are appropriate.)



- When straightening body panels, use caution in pulling any HSS panel. Because HSS is very strong, pulling may cause deformation in adjacent portions of the body. In this case, increase the number of measuring points, and carefully pull the HSS panel.




- When cutting HSS panels, avoid gas (torch) cutting if possible. Instead, use a saw to avoid weakening surrounding areas due to heat. If gas (torch) cutting is unavoidable, allow a minimum margin of 50 mm (1.97in).




BODY REPAIR

- When welding HSS panels, use spot welding whenever possible in order to minimize weakening surrounding areas due to heat. If spot welding is impossible, use M.I.G. welding. Do not use gas (torch) welding because it is inferior in welding strength.




- The spot weld on HSS panels is harder than that of an ordinary steel panel. Therefore, when cutting spot welds on a HSS panel, use a low speed high torque drill (1,000 to 1,200 rpm) to increase drill bit durability and facilitate the operation.
- SP150 HSS panels with a tensile strength of 785 to 981 N/mm² (80 to 100 kg/mm², 114 to 142 klb/sq in), used as reinforcement in the door guard beams, is too strong to repair. When these HSS parts are damaged, the outer panels also sustain substantial damage; therefore, the assembly parts must be replaced.




2. Precautions in spot welding HSS

This work should be performed under standard working conditions. Always note the following when spot welding HSS:

- The electrode tip diameter must be sized properly according to the metal thickness.



- The panel surfaces must fit flush to each other, leaving no gaps.




BODY REPAIR

- Follow the specifications for the proper welding pitch.

Thickness (t)	Minimum pitch (l)
0.6 (0.024)	10 (0.39) or over
0.8 (0.031)	12 (0.47) or over
1.0 (0.039)	18 (0.71) or over
1.2 (0.047)	20 (0.79) or over
1.6 (0.063)	27 (1.06) or over
1.8 (0.071)	31 (1.22) or over

Unit:mm



EIS00489

Foam Repair


During factory body assembly, foam insulators are installed in certain body panels and locations around the vehicle. Use the following procedure(s) to replace any factory-installed foam insulators.

URETHANE FOAM APPLICATIONS

Use commercially available spray foam for sealant (foam material) repair of material used on vehicle. Read instructions on product for fill procedures.

FILL PROCEDURES

1. Fill procedures after installation of service part.
 - Remove foam material remaining on vehicle side.
 - Clean area in which foam was removed.
 - Install service part.
 - Insert nozzle into hole near fill area and fill foam material or fill in enough to close gap with the service part.



2. Fill procedures before installation of service part.
 - Remove foam material remaining on vehicle side.
 - Clean area in which foam was removed.
 - Fill foam material on wheelhouse outer side.


NOTE:

Fill in enough to close gap with service part while avoiding flange area.

- Install service part.

NOTE:

Refer to label for information on working times.



BODY REPAIR

Replacement Operations

EIS003KG

DESCRIPTION

This section is prepared for technicians who have attained a high level of skill and experience in repairing collision-damaged vehicles and also use modern service tools and equipment. Persons unfamiliar with body repair techniques should not attempt to repair collision-damaged vehicles by using this section.

Technicians are also encouraged to read Body Repair Manual (Fundamentals) in order to ensure that the original functions and quality of the vehicle can be maintained. The Body Repair Manual (Fundamentals) contains additional information, including cautions and warnings, that are not including in this manual. Technicians should refer to both manuals to ensure proper repairs.

Please note that this information is prepared for worldwide usage, and as such, certain procedures may not apply in some regions or countries.

A

B

C

D

E

F

G

H

BL

J








K

L

M

BODY REPAIR


The symbols used in this section for cutting and welding / brazing operations are shown below.

 Saw cut or air chisel cut		
<p>Spot weld</p> <p>●●●● 2-spot welds</p> <p>●●●●● 3-spot welds</p> 	<p>2-spot welds (2-panel overlapping portions)</p> <p>3-spot welds (3-panel overlapping portions)</p> 	
<p>■ ■ ■</p> <p>MIG plug weld</p> 		
<p>~~~~~</p> <p>MIG seam weld/ Point weld</p> 		
<p>▨ ▨ ▨</p> <p>Brazing</p> 		
<p>▩ ▩ ▩</p> <p>Soldering</p> 		
<p>—————</p> <p>Sealing</p>		


PIA0149E

BODY REPAIR


- Front pillar butt joint can be determined anywhere within shaded area as shown in the figure. The best location for the butt joint is at position A due to the construction of the vehicle. Refer to [BL-165, "FRONT PILLAR"](#).



- Determine cutting position and record distance from the locating indent. Use this distance when cutting the service part. Cut outer front pillar over 60 mm above inner front pillar cut position.




- Prepare a cutting jig to make outer pillar easier to cut. Also, this will permit service part to be accurately cut at joint position.



- An example of cutting operation using a cutting jig is as follows.

1. Mark cutting lines.
A: Cut position of outer pillar
B: Cut position of inner pillar
2. Align cutting line with notch on jig. Clamp jig to pillar.
3. Cut outer pillar along groove of jig. (At position A)
4. Remove jig and cut remaining portions.
5. Cut inner pillar at position B in same manner.




BODY REPAIR

HOODLEDGE


- Work after radiator core support has been removed.

Service Joint


Perform with closed plate panel removed




2-spot welds



3-spot welds



MIG Plug weld



For 3 panels plug weld method



MIG seam weld/
Point weld




LIA1529E

BODY REPAIR

HOODLEGE (PARTIAL REPLACEMENT)


- Work after radiator core support has been removed.

Service Joint




Unit: mm


2-spot welds



3-spot welds



MIG Plug weld



(For 3 panels plug weld method)



MIG seam weld/
Point weld




LIIA1530E

BODY REPAIR


FRONT SIDE MEMBER

- Work after hoodledge and radiator core support have been removed.


Service Joint




2-spot welds




3-spot welds



MIG Plug weld



(For 3 panels plug weld method)




MIG seam weld/
Point weld




LIA0136E

BODY REPAIR

Service Joint



A
B
C
D
E
F
G
H
BL
J
K
L
M




LIA1372E

BODY REPAIR

FRONT SIDE MEMBER (PARTIAL REPLACEMENT)


- Work after radiator core support has been removed.

Service Joint




Unit: mm



2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




LIA1373E

BODY REPAIR

FRONT PILLAR


- Work after rear hoodedge reinforcement has been removed.

Service Joint




Unit: mm



2-spot welds



3-spot welds



MIG Plug weld




MIG seam weld/
Point weld



LIIA1374E

BODY REPAIR

Service Joint






2-spot welds

3-spot welds

MIG Plug weld

For 3 panels plug weld method


MIG seam weld/
Point weld



LIA1375E


BODY REPAIR

Service Joint




Unit : mm


2-spot welds



3-spot welds



MIG Plug weld



For 3 panels plug weld method



MIG seam weld/
Point weld



LIA1376E


BODY REPAIR

CENTER PILLAR

Service Joint

With outer sill removed


Front



Center pillar reinforcement


Before installing outer center pillar

Front




8

Front



4




Center pillar reinforcement

Urethane form


Unit:mm

LIIA1377E



2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




LIIA1377E


BODY REPAIR

OUTER SILL


Service Joint




2-spot welds



3-spot welds



MIG Plug weld



MIG seam weld/
Point weld




A
B
C
D
E
F
G
H
BL
J
K
L
M

LIIA0142E

BODY REPAIR


REAR FENDER

Service Joint




Unit: mm


2-spot welds



3-spot welds



MIG Plug weld



(For 3 panels plug weld method)



MIG seam weld/
Point weld




LIIA1378E

BODY REPAIR

REAR PANEL

A
B
C
D
E
F
G
H
BL
J
K
L
M




LIA0144E

BODY REPAIR

REAR FLOOR REAR

- Work after rear panel has been removed.




LIA0145E

BODY REPAIR

REAR SIDE MEMBER EXTENSION

- Work after rear panel and rear end crossmember have been removed.



A

B

C

D

E

F

G

H

BL

J

K

L

M

BODY REPAIR
