

SECTION **LAN**  
LAN SYSTEM

A  
B  
C

CONTENTS

D  
E

<b>CAN</b>		
<b>PRECAUTIONS</b> .....	<b>4</b>	
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	4	
Precautions When Using CONSULT-II .....	4	
CHECK POINTS FOR USING CONSULT-II .....	4	
Precautions For Trouble Diagnosis .....	4	
CAN SYSTEM .....	4	
Precautions For Harness Repair .....	5	
CAN SYSTEM .....	5	
<b>TROUBLE DIAGNOSES WORK FLOW</b> .....	<b>6</b>	
When Displaying CAN Communication System Errors .....	6	
WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM .....	6	
WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM .....	6	
TROUBLE DIAGNOSIS FLOW CHART .....	7	
Diagnosis Procedure .....	8	
SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE) .....	8	
ACQUISITION OF DATA BY CONSULT-II .....	9	
HOW TO USE CHECK SHEET TABLE .....	10	
CAN Diagnostic Support Monitor .....	16	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM .....	16	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TCM .....	17	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR BCM .....	18	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) .....	18	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR IPDM E/R .....	19	
DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR DISPLAY CONTROL UNIT .....	20	
<b>CAN COMMUNICATION</b> .....	<b>21</b>	
System Description .....	21	
CAN Communication Unit .....	21	
TYPE1/TYPE2 .....	21	
TYPE3/TYPE4 .....	23	
TYPE5/TYPE6 .....	25	
TYPE7/TYPE9 .....	27	
TYPE8/TYPE10 .....	29	
<b>CAN SYSTEM (TYPE 1)</b> .....	<b>32</b>	
Component Parts and Harness Connector Location .....	32	
Schematic .....	33	
Wiring Diagram - CAN - .....	34	
CHECK SHEET .....	37	
CHECK SHEET RESULTS (EXAMPLE) .....	38	
ECM Circuit Check .....	43	
Data Link Connector Circuit Check .....	43	
BCM Circuit Check .....	44	
Combination Meter Circuit Check .....	44	
IPDM E/R Circuit Check .....	45	
CAN Communication Circuit Check .....	45	
<b>CAN SYSTEM (TYPE 2)</b> .....	<b>49</b>	
Component Parts and Harness Connector Location .....	49	
Schematic .....	50	
Wiring Diagram - CAN - .....	51	
CHECK SHEET .....	54	
CHECK SHEET RESULTS (EXAMPLE) .....	56	
ECM Circuit Check .....	62	
Display Control Unit Circuit Check .....	62	
Data Link Connector Circuit Check .....	63	
BCM Circuit Check .....	63	
Combination Meter Circuit Check .....	64	
IPDM E/R Circuit Check .....	64	
CAN Communication Circuit Check .....	65	
<b>CAN SYSTEM (TYPE 3)</b> .....	<b>68</b>	
Component Parts and Harness Connector Location .....	68	
Schematic .....	69	
Wiring Diagram - CAN - .....	70	
CHECK SHEET .....	73	
CHECK SHEET RESULTS (EXAMPLE) .....	74	
Circuit Check Between Data Link Connector and		

F

G

H

I

J

LAN

L

M

ABS Actuator and Electric Unit (Control Unit) .....	81	CAN Communication Circuit Check .....	154
ECM Circuit Check .....	82	IPDM E/R Ignition Relay Circuit Check .....	157
Data Link Connector Circuit Check .....	82	<b>CAN SYSTEM (TYPE 7) .....</b>	<b>158</b>
BCM Circuit Check .....	83	Component Parts and Harness Connector Location	158
Combination Meter Circuit Check .....	83	Schematic .....	159
ABS Actuator and Electric Unit (Control Unit) Circuit		Wiring Diagram - CAN - .....	160
Check .....	84	CHECK SHEET .....	163
IPDM E/R Circuit Check .....	84	CHECK SHEET RESULTS (EXAMPLE) .....	165
CAN Communication Circuit Check .....	85	Circuit Check Between TCM and Data Link Con-	
IPDM E/R Ignition Relay Circuit Check .....	88	connector .....	174
<b>CAN SYSTEM (TYPE 4) .....</b>	<b>89</b>	Circuit Check Between Data Link Connector and	
Component Parts and Harness Connector Location..	89	ABS Actuator and Electric Unit (Control Unit) .....	175
Schematic .....	90	ECM Circuit Check .....	176
Wiring Diagram - CAN - .....	91	TCM Circuit Check .....	176
CHECK SHEET .....	94	Data Link Connector Circuit Check .....	177
CHECK SHEET RESULTS (EXAMPLE) .....	96	BCM Circuit Check .....	177
Circuit Check Between Data Link Connector and		Combination Meter Circuit Check .....	178
ABS Actuator and Electric Unit (Control Unit) .....	104	ABS Actuator and Electric Unit (Control Unit) Circuit	
ECM Circuit Check .....	105	Check .....	178
Display Control Unit Circuit Check .....	106	IPDM E/R Circuit Check .....	179
Data Link Connector Circuit Check .....	106	CAN Communication Circuit Check .....	180
BCM Circuit Check .....	107	IPDM E/R Ignition Relay Circuit Check .....	183
Combination Meter Circuit Check .....	107	<b>CAN SYSTEM (TYPE 8) .....</b>	<b>184</b>
ABS Actuator and Electric Unit (Control Unit) Circuit		Component Parts and Harness Connector Location	184
Check .....	108	Schematic .....	185
IPDM E/R Circuit Check .....	108	Wiring Diagram - CAN - .....	186
CAN Communication Circuit Check .....	109	CHECK SHEET .....	189
IPDM E/R Ignition Relay Circuit Check .....	112	CHECK SHEET RESULTS (EXAMPLE) .....	191
<b>CAN SYSTEM (TYPE 5) .....</b>	<b>113</b>	Circuit Check Between TCM and Data Link Con-	
Component Parts and Harness Connector Location	113	connector .....	200
Schematic .....	114	Circuit Check Between Data Link Connector and	
Wiring Diagram - CAN - .....	115	ABS Actuator and Electric Unit (Control Unit) .....	201
CHECK SHEET .....	118	ECM Circuit Check .....	202
CHECK SHEET RESULTS (EXAMPLE) .....	119	TCM Circuit Check .....	202
Circuit Check Between TCM and Data Link Con-		Data Link Connector Circuit Check .....	203
connector .....	126	BCM Circuit Check .....	203
ECM Circuit Check .....	127	Combination Meter Circuit Check .....	204
TCM Circuit Check .....	127	ABS Actuator and Electric Unit (Control Unit) Circuit	
Data Link Connector Circuit Check .....	128	Check .....	204
BCM Circuit Check .....	128	IPDM E/R Circuit Check .....	205
Combination Meter Circuit Check .....	129	CAN Communication Circuit Check .....	206
IPDM E/R Circuit Check .....	129	IPDM E/R Ignition Relay Circuit Check .....	209
CAN Communication Circuit Check .....	130	<b>CAN SYSTEM (TYPE 9) .....</b>	<b>210</b>
IPDM E/R Ignition Relay Circuit Check .....	133	Component Parts and Harness Connector Location	210
<b>CAN SYSTEM (TYPE 6) .....</b>	<b>134</b>	Schematic .....	211
Component Parts and Harness Connector Location	134	Wiring Diagram - CAN - .....	212
Schematic .....	135	CHECK SHEET .....	215
Wiring Diagram - CAN - .....	136	CHECK SHEET RESULTS (EXAMPLE) .....	217
CHECK SHEET .....	139	Circuit Check Between TCM and Data Link Con-	
CHECK SHEET RESULTS (EXAMPLE) .....	141	connector .....	227
Circuit Check Between TCM and Data Link Con-		Circuit Check Between Data Link Connector and	
connector .....	149	ABS Actuator and Electric Unit (Control Unit) .....	228
ECM Circuit Check .....	150	ECM Circuit Check .....	229
TCM Circuit Check .....	150	TCM Circuit Check .....	229
Display Control Unit Circuit Check .....	151	Display Control Unit Circuit Check .....	230
Data Link Connector Circuit Check .....	151	Data Link Connector Circuit Check .....	230
BCM Circuit Check .....	152	BCM Circuit Check .....	231
Combination Meter Circuit Check .....	152	Combination Meter Circuit Check .....	231
IPDM E/R Circuit Check .....	153	ABS Actuator and Electric Unit (Control Unit) Circuit	

Check .....	232	ABS Actuator and Electric Unit (Control Unit) .....	255	
IPDM E/R Circuit Check .....	232	ECM Circuit Check .....	256	A
CAN Communication Circuit Check .....	233	TCM Circuit Check .....	256	
IPDM E/R Ignition Relay Circuit Check .....	236	Display Control Unit Circuit Check .....	257	
<b>CAN SYSTEM (TYPE 10) .....</b>	<b>237</b>	Data Link Connector Circuit Check .....	257	B
Component Parts and Harness Connector Location	237	BCM Circuit Check .....	258	
Schematic .....	238	Combination Meter Circuit Check .....	258	
Wiring Diagram - CAN - .....	239	ABS Actuator and Electric Unit (Control Unit) Circuit		C
CHECK SHEET .....	242	Check .....	259	
CHECK SHEET RESULTS (EXAMPLE) .....	244	IPDM E/R Circuit Check .....	259	
Circuit Check Between TCM and Data Link Con-		CAN Communication Circuit Check .....	260	
nector .....	254	IPDM E/R Ignition Relay Circuit Check .....	263	D
Circuit Check Between Data Link Connector and				E
				F
				G
				H
				I
				J
				LAN
				L
				M

**PRECAUTIONS**

PFP:00001

**Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”**

UKS0010F

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

**Precautions When Using CONSULT-II**

UKS001R6

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

**CHECK POINTS FOR USING CONSULT-II**

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
  - If YES, GO TO 2.
  - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
  - If YES, GO TO 3.
  - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-6. "TROUBLE DIAGNOSES WORK FLOW"](#) .

**Precautions For Trouble Diagnosis  
CAN SYSTEM**

UKS0010G

- Do not apply voltage of 7.0V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0V or less.
- Be sure to turn ignition switch off and disconnect negative battery terminal before checking the circuit.


# PRECAUTIONS

[CAN]


UKS0010H

## Precautions For Harness Repair CAN SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in)]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

---

## TROUBLE DIAGNOSES WORK FLOW

PFP:00004

### When Displaying CAN Communication System Errors

#### WHEN A MALFUNCTION IS DETECTED BY CAN COMMUNICATION SYSTEM


UKS001Y0

- CAN communication line is open. (CAN H, CAN L, or both)
- CAN communication line is shorted. (Ground, between CAN lines, or other harnesses)
- The areas related to CAN communication of unit is malfunctioning.

#### WHEN A MALFUNCTION IS DETECTED EXCEPT CAN COMMUNICATION SYSTEM

- Removal and installation of parts : When the units that perform CAN communication or the sensors related to CAN communication are removed and installed, malfunction may be detected (or DTC other than CAN communication may be detected).
- Fuse blown out (removed): CAN communication of the unit may be stopped at such time.
- Low voltage : If the voltage decreases because of battery discharge when IGN is ON, malfunction may be detected by self-diagnosis according to the units.

## TROUBLE DIAGNOSIS FLOW CHART



- Step 1 : Refer to [LAN-8, "SELECTING CAN SYSTEM TYPE \(HOW TO USE SPECIFICATION TABLE\)"](#) .
- Step 2 : Refer to [LAN-9, "ACQUISITION OF DATA BY CONSULT-II"](#) .
- Step 3 : Refer to [LAN-10, "HOW TO USE CHECK SHEET TABLE"](#) .
- Step 4 : Refer to [LAN-11, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) .
- Step 5 : Check and repair according to system diagnosis.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

UKS001YP

## Diagnosis Procedure

### SELECTING CAN SYSTEM TYPE (HOW TO USE SPECIFICATION TABLE)

Determine CAN system type from the equipment of the vehicle to select applicable check sheet.

(Example) Sedan/2WD/VQ35DE/5AT/TCS/With navigation system

#### CAN Communication Unit

Go to CAN system, when selecting your CAN system type from the following table.

Body type	Sedan										
Axle	2WD										
Engine	QR25DE		VQ35DE				QR25DE		VQ35DE		
Transmission	M/T				4A/T		5A/T				
Brake control	NO ABS	ABS	NO ABS	ABS	TCS	NO ABS	ABS	ABS	TCS	ABS	TCS
Navigation system				x		x		x		x	x
CAN system type	1		2	3	4	5	6	7	8	9	10
CAN system trouble diagnosis	XXXX		XX	XX	XX	XX	XX	XX	XX	XX	XX

Check basic specification of the vehicle.

Select "x" if it is model with navigation system.

Which number is selected when sequentially selecting from the top of the specification table?  
The number is "CAN system type" of the applicable vehicle.

In the case of this example:  
It corresponds to type 10.

x: Applicable

SKIB0597E

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## ACQUISITION OF DATA BY CONSULT-II

Attach the data acquired by CONSULT-II on the check sheet determined according to CAN system type. (For display control unit, transfer the data from the LCD monitor screen of the vehicle to the CAN diagnosis support monitor check sheet [AV-131, "CAN Communication Line Check"](#) .)

Copy "SELECT SYSTEM" screen of CONSULT- II .

SELECT SYSTEM	
ENGINE	
ABS	
BCM	
TRANSMISSION	
BACK	LIGHT COPY

AV section

Copy CAN diagnosis support monitor check sheet of CAN communication check.

Diagnosis item	Screen display		Diagnosis item	Screen display	
CANCOMM	OK	NG	CAN_CRIC_5	OK	UNKWN
CAN_CRIC_1	OK	UNKWN	CAN_CRIC_6	OK	UNKWN
CAN_CRIC_2	OK	UNKWN	CAN_CRIC_7	OK	UNKWN
CAN_CRIC_3	OK	UNKWN	CAN_CRIC_8	OK	UNKWN
CAN_CRIC_4	OK	UNKWN	CAN_CRIC_9	OK	UNKWN

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								SELF DIAG RESULTS		
	Initial diagnosis	Transmit diagnosis	ECM	ICM	ECM SEC	METER M/A	VDC/TCS/ABS	IPDM E/R			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
Display control unit	-	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	-	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	UNKWN	-	-	-	CAN COMM CIRCUIT (U1000)	-

Symptoms:

Attach copy of SELECT SYSTEM

Attach copy of SELECT SYSTEM

Confirmation/Adjustment Display	Check sheet table Display	Confirmation/Adjustment Display	Check sheet table Display
CAN COMM	Initial diagnosis	CAN CRIC 5	METER M/A
CAN CRIC 1	Transmit diagnosis	CAN CRIC 6	-
CAN CRIC 2	BCM	CAN CRIC 7	IPDM E/R
CAN CRIC 3	ECM	CAN CRIC 8	-
CAN CRIC 4	-	CAN CRIC 9	-

Attach copy of display control unit CAN DIAG SUPPORT MONITOR check sheet

Copy "SELF-DIAG RESULTS" screen of CONSULT- II .

SELF-DIAG RESULTS	
DTC RESULTS	TIME
CAN COMM CIRCUIT (U1000)	
ERASE	PRINT
MODE	BACK LIGHT COPY

SELF-DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	
ERASE	PRINT
MODE	BACK LIGHT COPY

Attach copy of ENGINE SELF-DIAG RESULTS

Attach copy of TRANSMISSION SELF-DIAG RESULTS

Attach copy of BCM SELF-DIAG RESULTS

Attach copy of ABS SELF-DIAG RESULTS

Attach copy of IPDM E/R SELF-DIAG RESULTS

Copy "CAN DIAG SUPPORT MNTR" screen of CONSULT- II .

CAN DIAG SUPPORT MNTR	
ENGINE	
INITIAL DIAG	OK
TRANSMIT DIAG	OK
TCM	OK
VDC/TCS/ABS	UNKWN
METER M/A	OK
ICM	UNKWN
BCM/SEC	OK
IPDM E/R	UNKWN
AWD/4WD/4WD	UNKWN
PRINT	Scroll Down
MODE	BACK LIGHT COPY

CAN DIAG SUPPORT MNTR	
ABS	
INITIAL DIAG	OK
TRANSMIT DIAG	OK
ECM	UNKWN
TCM	UNKWN
PRINT	
MODE	BACK LIGHT COPY

Attach copy of ENGINE CAN DIAG SUPPORT MNTR

Attach copy of ABS CAN DIAG SUPPORT MNTR

Attach copy of BCM CAN DIAG SUPPORT MNTR

Attach copy of CAN DIAG SUPPORT MNTR

Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

## HOW TO USE CHECK SHEET TABLE

Check sheet table		Use when the initial conditions are reproduced								Use when the initial conditions are not reproduced			
		CAN DIAG SUPPORT MNTR										SELF-DIAG RESULTS	
		SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	Receive diagnosis								
ECM	TCM				BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	UNKWN	-	CAN COMM CIRCUIT (U1000)	-	
Display control unit	-	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	UNKWN	-	-	
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	-	-	UNKWN	CAN COMM CIRCUIT (U1000)	-	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-	CAN COMM CIRCUIT (U1000)	-	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	-	-	-	CAN COMM CIRCUIT (U1000)	-	

SKIB0616E

1. Unit names displayed on CONSULT-II
2. "No indication" : Put a check mark to it if the unit name described in step 1 is not displayed on "SELECT SYSTEM" screen of CONSULT-II. (Unit communicating with CONSULT-II via CAN communication line)  
"-" : Column not used (Unit communicating with CONSULT-II excluding CAN communication line)
3. "NG" : Display "NG" when malfunction is detected in the initial diagnosis of the diagnosed unit. Replace the unit if "NG" is displayed.  
"-" : Column not used (Initial diagnosis is not performed.)
4. "UNKWN" : Display "UNKWN" when the diagnosed unit does not transmit the data normally. Put a check mark to it if "UNKWN" is displayed on CONSULT-II.
5. "UNKWN" : Display "UNKWN" when the diagnosed unit does not receive the data normally. Put a check mark to it if "UNKWN" is displayed on CONSULT-II.  
"-" : Column not used (It is not necessary for CAN communication trouble diagnosis.)

**NOTE:**


CAN communication diagnosis checks if CAN communication works normally. (Contents of data are not diagnosed.)

- Refer to [LAN-11, "Example of Filling in Check Sheet When Initial Conditions Are Reproduced"](#) when the initial conditions are reproduced.
- Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#) when the initial conditions are not reproduced.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## Example of Filling in Check Sheet When Initial Conditions Are Reproduced



- Put a check mark to "No indication" if some of unit names listed on the column of diagnosis system selection screen of a check sheet table are not displayed on "SELECT SYSTEM" screen attached to the check sheet.

**NOTE:**

Put a check mark to "No indication" of IPDM E/R because IPDM E/R is not displayed on "SELECT SYSTEM" screen.

- Confirm the unit name that "UNKWN" is displayed from the copy of "CAN DIAG SUPPORT MNTR" screen of "ENGINE" attached to the check sheet, and then put a check mark to the check sheet table.

**NOTE:**

In "CAN DIAG SUPPORT MNTR" screen, "UNKWN" is displayed on "VDC/TCS/ABS", "ICC", "IPDM E/R" and "AWD/4WD/e4WD". But put a check mark to "VDC/TCS/ABS" and "IPDM E/R" because "UNKWN" is listed on the column of reception diagnosis of the check sheet table.

- Confirm the unit name that "UNKWN" is displayed on the copy of "CAN DIAG SUPPORT MNTR" screen of "TRANSMISSION" as well as "ENGINE". And then, put a check mark to the check sheet table.

**NOTE:**


- For "TRANSMISSION", "UNKWN" is displayed on "VDC/TCS/ABS". Put a check mark to it.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# TROUBLE DIAGNOSES WORK FLOW


[CAN]



- Display control unit reads the CAN diagnosis support monitor check sheet (B) [AV-131, "CAN Communication Line Check"](#) transferred from the LCD monitor screen(A). The transferred CAN diagnosis support monitor check sheet is copied to the Check sheet, and conversed according to the Display control unit Translation Sheet. And then put a check mark to the check sheet table.

**NOTE:**

In the CAN diagnosis support monitor check sheet (B), check marks are put to "CAN CIRC 4", "CAN CIRC 6", "CAN CIRC 7", "CAN CIRC 8" and "CAN CIRC 9". But, in the column of the check sheet table indication in Display control unit Translation Sheet (C), "IPDM E/R" is listed only for "CAN CIRC 7". Therefore, put a check mark to "IPDM E/R" because "UNKWN" is listed on the column of reception diagnosis of the check sheet table.



- Confirm the unit name that "UNKWN" is displayed on the copy of "CAN DIAG SUPPORT MNTR" screen of "BCM" and "ABS" as well as "ENGINE". And then, put a check mark to the check sheet table.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

**NOTE:**

- For “BCM”, “UNKWN” is displayed on “IPDM E/R”. Put a check mark to it.
- For “ABS”, “UNKWN” is displayed on “ECM” and “TCM”. Put a check mark to it.

The arranged results of CAN diagnosis support monitor

Check sheet table

SELECT SYSTEM screen		Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
				Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
ENGINE	—	NG	UNKWN	—	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	UNKWN	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—

Choose similar indications between the results of CAN diagnosis support monitor and the results of the check sheet. Malfunctioning parts are found.


Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit).

Check sheet results (example)

SELECT SYSTEM screen		Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
				Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	—	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	—	—	—	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	—

//// : Malfunctioning part



SKIB0620E

**NOTE:**

There is a check mark in VDC/TCS/ABS of “A/T” in “The arranged results of CAN diagnosis support monitor” sheet. Also, there is a mark of “—” both in VDC/TCS/ABS of “A/T” in the check sheet results (example). Therefore, neglect a check mark both in VDC/TCS/ABS of “A/T” in “The arranged results of CAN diagnosis support monitor” sheet.

6. Perform system diagnosis for possible causes identified.
7. Perform diagnosis again after inspection and repair. Make sure that repair is completely performed, and then end the procedure.

Start CAN system trouble diagnosis if this procedure can be confirmed. [LAN-21, "CAN Communication Unit"](#)

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	

SYSTEM ENGINE

SELF-DIAG RESULTS

DTC RESULTS      TIME

CAN COMM CIRCUIT [U1001]      1t

SYSTEM BCM

SELF-DIAG RESULTS

DTC RESULTS      TIME

NO DTC IS DETECTED.  
FURTHER TESTING  
MAY BE REQUIRED.

SYSTEM ABS

SELF-DIAG RESULTS

DTC RESULTS      TIME

NO DTC IS DETECTED.  
FURTHER TESTING  
MAY BE REQUIRED.

SYSTEM IPDM E/R

SELF-DIAG RESULTS

DTC RESULTS      TIME

CAN COMM CIRCUIT [U1000]      1

SKIB0621E

- See “SELF-DIAG RESULTS” of all units attached to the check sheet. If “CAN COMM CIRCUIT”, “CAN COMM CIRCUIT [U1000]” or “CAN COMM CIRCUIT [U1001]” is displayed, put a check mark to the applicable column of self-diagnostic results of the check sheet table.

**NOTE:**

- For “ENGINE”, “CAN COMM CIRCUIT [U1001]” are displayed. Put a check mark to it.
- For “BCM”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “ABS”, “NO DTC IS DETECTED” is displayed. Do not put a check mark to it.
- For “IPDM E/R”, “CAN COMM CIRCUIT [U1000]” is displayed. Put a check mark to it.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

Check sheet table


The arranged results of self-diagnosis

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				PDM E/R		
				ECM	BCM /SEC	METER /M/A	VDC/TCS /ABS			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	UNKWN	-	-	-	CAN COMM CIRCUIT (U1000)	-

When the arranged results of self-diagnosis and check sheet results (example) are corresponding, possible causes can be selected.


Case 4  
Check BCM circuit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				PDM E/R		
				ECM	BCM /SEC	METER /M/A	VDC/TCS /ABS			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1000)
BCM	No indicator	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	UNKWN	-	-	-	CAN COMM CIRCUIT (U1000)	-



Case 7  
Check IPDM E/R circuit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis				PDM E/R		
				ECM	BCM /SEC	METER /M/A	VDC/TCS /ABS			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1000)
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	CAN COMM CIRCUIT (U1000)	-
PDM E/R	No indicator	-	UNKWN	UNKWN	UNKWN	-	-	-	CAN COMM CIRCUIT (U1000)	-



SKIB0622E

**NOTE:**

There is a case that some of "CAN DIAG SUPPORT MNTR" and "SELF-DIAG RESULTS" are not needed for diagnosis. In the case, "UNKWN" and "CAN COMM CIRCUIT(U1000)" in "Check sheet results (example)" change to "-". Then, ignore check marks on the Check sheet table.

2. For the selected possible causes, it is expected that malfunctions have been found in the past.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

UKS001YQ

## CAN Diagnostic Support Monitor

### DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR ECM

(Example)	CAN DIAG SUPPORT MNTR	CAN DIAG SUPPORT MNTR																																																				
	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">ENGINE</th></tr> <tr><td></td><td style="text-align: right;">PRSNT</td></tr> <tr><td>INITIAL DIAG</td><td style="text-align: right;">OK</td></tr> <tr><td>TRANSMIT DIAG</td><td style="text-align: right;">OK</td></tr> <tr><td>TCM</td><td style="text-align: right;">OK</td></tr> <tr><td>VDC/TCS/ABS</td><td style="text-align: right;">OK</td></tr> <tr><td>METER/M&amp;A</td><td style="text-align: right;">OK</td></tr> <tr><td>ICC</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>BCM/SEC</td><td style="text-align: right;">OK</td></tr> <tr><td>IPDM E/R</td><td style="text-align: right;">OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>PRINT</td><td style="text-align: right;">Scroll Down</td></tr> <tr><td>MODE</td><td style="text-align: right;">BACK LIGHT COPY</td></tr> </table>	ENGINE			PRSNT	INITIAL DIAG	OK	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	PRINT	Scroll Down	MODE	BACK LIGHT COPY	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2">ENGINE</th></tr> <tr><td></td><td style="text-align: right;">PRSNT</td></tr> <tr><td>TRANSMIT DIAG</td><td style="text-align: right;">OK</td></tr> <tr><td>TCM</td><td style="text-align: right;">OK</td></tr> <tr><td>VDC/TCS/ABS</td><td style="text-align: right;">OK</td></tr> <tr><td>METER/M&amp;A</td><td style="text-align: right;">OK</td></tr> <tr><td>ICC</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>BCM/SEC</td><td style="text-align: right;">OK</td></tr> <tr><td>IPDM E/R</td><td style="text-align: right;">OK</td></tr> <tr><td>AWD/4WD/e4WD</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>EPS</td><td style="text-align: right;">UNKWN</td></tr> <tr><td>PRINT</td><td style="text-align: right;">Scroll Up</td></tr> <tr><td>MODE</td><td style="text-align: right;">BACK LIGHT COPY</td></tr> </table>	ENGINE			PRSNT	TRANSMIT DIAG	OK	TCM	OK	VDC/TCS/ABS	OK	METER/M&A	OK	ICC	UNKWN	BCM/SEC	OK	IPDM E/R	OK	AWD/4WD/e4WD	UNKWN	EPS	UNKWN	PRINT	Scroll Up	MODE	BACK LIGHT COPY
ENGINE																																																						
	PRSNT																																																					
INITIAL DIAG	OK																																																					
TRANSMIT DIAG	OK																																																					
TCM	OK																																																					
VDC/TCS/ABS	OK																																																					
METER/M&A	OK																																																					
ICC	UNKWN																																																					
BCM/SEC	OK																																																					
IPDM E/R	OK																																																					
AWD/4WD/e4WD	UNKWN																																																					
PRINT	Scroll Down																																																					
MODE	BACK LIGHT COPY																																																					
ENGINE																																																						
	PRSNT																																																					
TRANSMIT DIAG	OK																																																					
TCM	OK																																																					
VDC/TCS/ABS	OK																																																					
METER/M&A	OK																																																					
ICC	UNKWN																																																					
BCM/SEC	OK																																																					
IPDM E/R	OK																																																					
AWD/4WD/e4WD	UNKWN																																																					
EPS	UNKWN																																																					
PRINT	Scroll Up																																																					
MODE	BACK LIGHT COPY																																																					
		SKIB0591E																																																				

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present
ENGINE	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	ICC	ICC is not diagnosed.	UNKWN
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWN
	AWD/4WD/e4WD	AWD/4WD/e4WD is not diagnosed.	UNKWN
EPS	EPS is not diagnosed.	UNKWN	

#### Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## DESCRIPTION OF "CAN DIAG SUPPORT MNTR" SCREEN FOR TCM

### 4A/T models

(Example)

CAN DIAG SUPPORT MNTR			
A/T			
		PRSNT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
ECM		OK	
VDC/TCS/ABS		UNKWN	
METER/M&A		OK	
ICC/e4WD		UNKWN	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0628E

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present
A/T	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	VDC/TCS/ABS	VDC/TCS/ABS is not diagnosed.	UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN
	ICC/e4WD	ICC/e4WD is not diagnosed.	UNKWN

#### Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

### 5A/T models

(Example)

CAN DIAG SUPPORT MNTR			
TRANSMISSION			
		PRSNT	
INITIAL DIAG		OK	
TRANSMIT DIAG		OK	
ECM		OK	
VDC/TCS/ABS		OK	
METER/M&A		OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0592E

"SELECT SYSTEM" screen	"CAN DIAG SUPPORT MNTR" screen	Description	Present
TRANSMISSION	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	VDC/TCS/ABS	Make sure of normal reception from ABS actuator and electric unit (control unit).	OK/UNKWN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWN

#### Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR BCM

(Example)

CAN DIAG SUPPORT MNTR			
BCM			
	PRSENT		
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
IPDM E/R	OK		
METER/M&A	UNKWVN		
I-KEY	OK		
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0593E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
BCM	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWVN
	ECM	Make sure of normal reception from ECM.	OK/UNKWVN
	IPDM E/R	Make sure of normal reception from IPDM E/R.	OK/UNKWVN
	METER/M&A	Make sure of normal reception from combination meter.	OK/UNKWVN
	I-KEY	I-KEY is not diagnosed.	OK

### Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWVN : The diagnosed unit does not transmit or receive the applicable data normally.

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### ABS models

(Example)

CAN DIAG SUPPORT MNTR			
ABS			
	PRSENT		
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
PRINT			
MODE	BACK	LIGHT	COPY

PKIA8949E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ABS	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWVN
	ECM	Make sure of normal reception from ECM.	OK/UNKWVN

### Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWVN : The diagnosed unit does not transmit or receive the applicable data normally.

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## TCS models

(Example) CAN DIAG SUPPORT MNTR

ABS			
		PRSENT	
INITIAL DIAG	OK		
TRANSMIT DIAG	OK		
ECM	OK		
TCM	OK		
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0594E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present
ABS	INITIAL DIAG	Make sure that microcomputer in ECU works normally.	OK/NG
	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN
	ECM	Make sure of normal reception from ECM.	OK/UNKWN
	TCM	Make sure of normal reception from TCM.	OK/UNKWN

### Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR IPDM E/R

(Example) CAN DIAG SUPPORT MNTR

IPDM E/R			
		PRSENT	PAST
TRANSMIT DIAG	OK	OK	
ECM	OK	OK	
BCM/SEC	OK	OK	
PRINT			
MODE	BACK	LIGHT	COPY

SKIB0595E

“SELECT SYSTEM” screen	“CAN DIAG SUPPORT MNTR” screen	Description	Present	Past
IPDM E/R	TRANSMIT DIAG	Make sure of normal transmission.	OK/UNKWN/–	
	ECM	Make sure of normal reception from ECM.	OK/UNKWN/–	OK/0/1~39/–
	BCM/SEC	Make sure of normal reception from BCM.	OK/UNKWN/–	

### Display Results (Present)

- OK : Normal
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.
- – : There is no received unit or the unit is not in the condition that reception diagnosis is performed

### Display Results (Past)

- OK : Normal
- 0 : There is malfunction now.
- 1 ~ 39 : Displays when it is normal at present and finds malfunction in the past. It increases like 0→1→2...38→39 after returning to the normal condition whenever IGN OFF→ON. If it is over 39, it is fixed to 39 until the self-diagnostic results are erased. It returns to 0 when malfunction is detected again in the process.
- – : Undiagnosed

# TROUBLE DIAGNOSES WORK FLOW

[CAN]

## DESCRIPTION OF “CAN DIAG SUPPORT MNTR” SCREEN FOR DISPLAY CONTROL UNIT

(Example)

CAN DIAG SUPPORT MONITOR			
CAN_COMM	OK	0	<input type="button" value="Delete"/>
CAN_CIRC_1	OK	0	
CAN_CIRC_2	OK	0	
CAN_CIRC_3	OK	0	
CAN_CIRC_4	UNKWN	1	
CAN_CIRC_5	UNKWN	1	
CAN_CIRC_6	UNKWN	1	
CAN_CIRC_7	OK	0	
CAN_CIRC_8	OK	0	
CAN_CIRC_9	OK	0	

SKIB0645E

Unit name	Diagnosis item	Description	“CAN DIAG SUPPORT MONITOR” screen	Error counter (Reference)
Display control unit	CAN COMM	Make sure that microcomputer in ECU works normally.	OK/NG	0/1~50
	CAN CIRC 1	Make sure of normal transmission.	OK/UNKWN	
	CAN CIRC 2	Make sure of normal reception from BCM.	OK/UNKWN	
	CAN CIRC 3	Make sure of normal reception from ECM.	OK/UNKWN	
	CAN CIRC 4	CAN CIRC 4 is not diagnosed.	UNKWN	
	CAN CIRC 5	Make sure of normal reception from combination meter.	OK/UNKWN	
	CAN CIRC 6	CAN CIRC 6 is not diagnosed.	UNKWN	
	CAN CIRC 7	Make sure of normal reception from IPDM E/R.	OK/UNKWN	
	CAN CIRC 8	CAN CIRC 8 is not diagnosed.	UNKWN	
	CAN CIRC 9	CAN CIRC 9 is not diagnosed.	UNKWN	

### Display Results (Present)

- OK : Normal
- NG : Malfunction
- UNKWN : The diagnosed unit does not transmit or receive the applicable data normally.
- – : There is no received unit or the unit is not in the condition that reception diagnosis is performed.

### Display Results : Error Counter (Reference)

- 0 : It is normal now.
- 1 ~ 50 : Displays when it finds malfunction in the past even if it is normal or there is a malfunction at present. Also, displays when diagnosis is not performed. It increase like 0→1→2...49→50 after returning to the normal condition whenever IGN OFF→ON. If it is over 50, it is fixed to 50 until the self-diagnostic results are erased. Keep this condition until resetting it.

## CAN COMMUNICATION

### System Description

UKS0010C

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### CAN Communication Unit


UKS0010E

Go to CAN system, when selecting your CAN system type from the following table.

Body type	Sedan														
Axle	2WD														
Engine	QR25DE			VQ35DE					QR25DE				VQ35DE		
Transmission	M/T							4A/T				5A/T			
Brake control	No ABS	ABS	No ABS	ABS	TCS			No ABS	ABS	ABS	TCS	ABS	TCS	ABS	TCS
Navigation system			×		×		×		×		×			×	×
CAN system type	1		2	1	2	3	4	5	6	5	6	7	8	9	10
CAN system trouble diagnosis	<a href="#">LAN-37</a>		<a href="#">LAN-49</a>	<a href="#">LAN-32</a>	<a href="#">LAN-54</a>	<a href="#">LAN-73</a>	<a href="#">LAN-94</a>	<a href="#">LAN-118</a>	<a href="#">LAN-134</a>	<a href="#">LAN-113</a>	<a href="#">LAN-139</a>	<a href="#">LAN-163</a>	<a href="#">LAN-189</a>	<a href="#">LAN-215</a>	<a href="#">LAN-242</a>

×: Applicable


Vehicles equipped with TCS can be identified by the presence of a TCS ON/OFF switch.



### TYPE1/TYPE2

#### System diagram


- Type1



# CAN COMMUNICATION

[CAN]

● Type2



## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Display control unit*	BCM	Combination meter	IPDM E/R
Engine speed signal	T	R		R	
Engine coolant temperature signal	T			R	
Fuel consumption monitor signal	T			R	
		R		T	
A/C switch signal	R		T		
A/C compressor signal	R				T
A/C compressor request signal	T				R
Blower fan switch signal	R		T		
Cooling fan motor operation signal	R				T
Cooling fan speed request signal	T				R
Position lights request			T	R	R
Low beam request			T		R
Low beam status	R				T
High beam request			T	R	R
High beam status	R				T
Front fog light request			T		R
Vehicle speed signal	R	R		T	
Oil pressure switch signal				R	T
Sleep request1			T	R	
Sleep request2			T		R
Seat belt buckle switch signal			R	T	
Door switch signal		R	T	R	R
Turn indicator signal			T	R	
Buzzer output signal			T	R	
Trunk switch signal			T	R	
Wiper stop position signal			R		T
Rear window defogger switch signal			T		R
Rear window defogger control signal	R	R	R		T

# CAN COMMUNICATION

[CAN]

Signals	ECM	Display control unit*	BCM	Combination meter	IPDM E/R
Hood switch signal			R		T
Theft warning horn status signal			R		T
Distance to empty signal		R		T	
Fuel level low warning signal		R		T	
Theft warning horn request signal			T		R
Horn chirp signal			T		R
Fuel level sensor signal	R			T	
ASCD SET lamp signal	T			R	
ASCD CRUISE lamp signal	T			R	
Malfunction indicator lamp signal	T			R	


**NOTE:**

\*:Navigation system only


**TYPE3/TYPE4**

**System diagram**

- TYPE3



- TYPE4



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN COMMUNICATION

[CAN]

## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	Display control unit*	BCM	Combination meter	ABS actuator and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R		R	R	
Engine coolant temperature signal	T			R		
Fuel consumption monitor signal	T			R		
		R		T		
A/C switch signal	R		T			
A/C compressor signal	R					T
A/C compressor request signal	T					R
Cooling fan motor operation signal	R					T
Cooling fan speed request signal	T					R
Position lights request			T	R		R
Low beam request			T			R
Low beam status	R					T
High beam request			T	R		R
High beam status	R					T
Front fog light request			T			R
Vehicle speed signal				R	T	
	R	R	R	T		
Oil pressure switch signal				R		T
Sleep request1			T	R		
Sleep request2			T			R
Seat belt buckle switch signal			R	T		
Door switch signal		R	T	R		R
Turn indicator signal			T	R		
Buzzer output signal			T	R		
Trunk switch signal			T	R		
Wiper stop position signal			R			T
Rear window defogger switch signal			T			R
Rear window defogger control signal	R	R	R			T
Hood switch signal			R			T
Theft warning horn status signal			R			T
Distance to empty signal		R		T		
Fuel level low warning signal		R		T		
Theft warning horn request signal			T			R
Horn chirp signal			T			R
Blower fan switch signal	R		T			
Fuel level sensor signal	R			T		
ASCD SET lamp signal	T			R		
ASCD CRUISE lamp signal	T			R		
Malfunction indicator lamp signal	T			R		


**NOTE:**

\*:Navigation system only


## TYPE5/TYPE6

### System diagram

- TYPE5



- TYPE6



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Display control unit*	BCM	Combination meter	IPDM E/R
Engine speed signal	T		R		R	
Engine coolant temperature signal	T				R	
Fuel consumption monitor signal	T				R	
			R		T	
A/T check indicator lamp signal		T			R	
A/T position indicator signal		T			R	
A/C switch signal	R			T		
A/C compressor signal	R					T
A/C compressor request signal	T					R
Blower fan switch signal	R			T		
Cooling fan motor operation signal	R					T

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit*	BCM	Combination meter	IPDM E/R
Cooling fan speed request signal	T					R
Position lights request				T	R	R
Low beam request				T		R
Low beam status	R					T
High beam request				T	R	R
High beam status	R					T
Front fog light request				T		R
Vehicle speed signal	R		R	R	T	
Oil pressure switch signal					R	T
Sleep request1				T	R	
Sleep request2				T		R
Seat belt buckle switch signal				R	T	
Door switch signal			R	T	R	R
Turn indicator signal				T	R	
Buzzer output signal				T	R	
Trunk switch signal				T	R	
Wiper stop position signal				R		T
Rear window defogger switch signal				T		R
Rear window defogger control signal	R		R	R		T
Hood switch signal				R		T
Theft warning horn status signal				R		T
Distance to empty signal			R		T	
Fuel level low warning signal			R		T	
Theft warning horn request signal				T		R
Horn chirp signal				T		R
3rd position switch signal		R			T	
Closed throttle position signal	T	R				
Wide open throttle position signal	T	R				
Stop lamp switch signal		R			T	
Engine and A/T integrated control signal	T	R				
	R	T				
A/T self-diagnosis signal	R	T				
Output shaft revolution signal	R	T				
Fuel level sensor signal	R				T	
ASCD SET lamp signal	T				R	
ASCD CRUISE lamp signal	T				R	
Malfunction indicator lamp signal	T				R	


**NOTE:**

\*:Navigation system only


## TYPE7/TYPE9

### System diagram

- TYPE7



- TYPE9



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	Display control unit*	BCM	Combina-tion meter	ABS actua-tor and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R	R		R		
Engine coolant temperature signal	T	R			R		
Fuel consumption monitor signal	T				R		
			R		T		
A/T warning lamp signal		T			R		
A/T position indicator signal		T			R		
ABS operation signal		R				T	
A/C switch signal	R			T			
A/C compressor signal	R						T

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit*	BCM	Combina-tion meter	ABS actua-tor and electric unit (control unit)	IPDM E/R
A/C compressor request signal	T						R
Cooling fan motor operation signal	R						T
Cooling fan speed request signal	T						R
Position lights request				T	R		R
Low beam request				T			R
Low beam status	R						T
High beam request				T	R		R
High beam status	R						T
Front fog light request				T			R
Vehicle speed signal					R	T	
	R	R	R	R	T		
Oil pressure switch signal					R		T
Sleep request1				T	R		
Sleep request2				T			R
Seat belt buckle switch signal				R	T		
Door switch signal			R	T	R		R
Turn indicator signal				T	R		
Buzzer output signal				T	R		
Trunk switch signal				T	R		
Wiper stop position signal				R			T
Rear window defogger switch signal				T			R
Rear window defogger control signal	R		R	R			T
Hood switch signal				R			T
Theft warning horn status signal				R			T
Distance to empty signal			R		T		
Fuel level low warning signal			R		T		
Theft warning horn request signal				T			R
Horn chirp signal				T			R
ASCD operation signal	T	R					
ASCD OD cancel request signal	T	R					
Manual mode indicator signal		T			R		
Electric throttle control signal	T	R					
Stop lamp switch signal		R			T		
Blower fan switch signal	R			T			
A/T self-diagnostic signal	R	T					
Output shaft revolution signal	R	T					
Turbine revolution signal	R	T					
Fuel level sensor signal	R				T		
ASCD SET lamp signal	T				R		
ASCD CRUISE lamp signal	T				R		
Malfunction indicator lamp signal	T				R		


**NOTE:**

\*:Navigation system only


**TYPE8/TYPE10**

**System diagram**

- TYPE8



- TYPE10



**Input/output signal chart**

T: Transmit R: Receive

Signals	ECM	TCM	Display control unit*	BCM	Combina-tion meter	ABS actua-tor and electric unit (control unit)	IPDM E/R
Engine speed signal	T	R	R		R	R	
Engine coolant temperature signal	T	R			R		
Accelerator pedal position signal	T					R	
Fuel consumption monitor signal	T				R		
			R		T		
A/T warning lamp signal		T			R		
A/T position indicator signal		T			R	R	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M

LAN

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	Display control unit*	BCM	Combina-tion meter	ABS actua-tor and electric unit (control unit)	IPDM E/R
ABS operation signal		R				T	
A/C switch signal	R			T			
A/C compressor signal	R						T
A/C compressor request signal	T						R
Cooling fan motor operation signal	R						T
Cooling fan speed request signal	T						R
Position lights request				T	R		R
Low beam request				T			R
Low beam status	R						T
High beam request				T	R		R
High beam status	R						T
Front fog light request				T			R
Vehicle speed signal	R	R	R	R	R	T	
Oil pressure switch signal					R		T
Sleep request1				T	R		
Sleep request2				T			R
Seat belt buckle switch signal				R	T		
Door switch signal			R	T	R		R
Turn indicator signal				T	R		
Buzzer output signal				T	R		
Trunk switch signal				T	R		
Wiper stop position signal				R			T
Rear window defogger switch signal				T			R
Rear window defogger control signal	R		R	R			T
Hood switch signal				R			T
Theft warning horn status signal				R			T
Distance to empty signal			R		T		
Fuel level low warning signal			R		T		
Theft warning horn request signal				T			R
Horn chirp signal				T			R
ASCD operation signal	T	R					
ASCD OD cancel request signal	T	R					
Manual mode indicator signal		T			R		
Electric throttle control signal	T	R					
Stop lamp switch signal		R			T		
Blower fan switch signal	R			T			
A/T self-diagnosis signal	R	T					
Output shaft revolution signal	R	T					
Turbine revolution signal	R	T					
Fuel level sensor signal	R				T		
ASCD SET lamp signal	T				R		

# CAN COMMUNICATION

**[CAN]**

Signals	ECM	TCM	Display control unit*	BCM	Combina- tion meter	ABS actua- tor and electric unit (control unit)	IPDM E/R
ASCD CRUISE lamp signal	T				R		
Malfunction indicator lamp signal	T				R		

**NOTE:**

\*:Navigation system only

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

CAN SYSTEM (TYPE 1)

PF2:23710

Component Parts and Harness Connector Location

UKS001YE




BKIA0023E

# CAN SYSTEM (TYPE 1)

[CAN]

## Schematic

UKS001YF



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



BKWA0118E

Wiring Diagram - CAN -

UKS001YG

LAN-CAN-01

▬ : DATA LINE




REFER TO THE FOLLOWING.  
 (F54) - ELECTRICAL UNITS

BKWA0119E

# CAN SYSTEM (TYPE 1)

[CAN]

## LAN-CAN-02



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

(M22)  
W



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

(M24)  
W

REFER TO THE FOLLOWING.  
(M18) - ELECTRICAL UNITS

BKWA0120E

▬ : DATA LINE



# CAN SYSTEM (TYPE 1)

[CAN]

UKS001RW

## CHECK SHEET

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA8886E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check ECM circuit. Refer to [LAN-43, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8943E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 2

Check data link connector circuit. Refer to [LAN-43, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8944E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 3

Check BCM circuit. Refer to [LAN-44, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8971E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 4

Check combination meter circuit. Refer to [LAN-44, "Combination Meter Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8972E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 5

Check IPDM E/R circuit. Refer to [LAN-45, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8973E



## Case 6

Check CAN communication circuit. Refer to [LAN-45, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8974E

**ECM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, connector side and harness side).
  - ECM connector
  - Harness connector F59
  - Harness connector M71

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132Ω**

**OK or NG**

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and data link connector.

**Data Link Connector Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66Ω**

**OK or NG**

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).  
 NG >> Repair harness between data link connector and combination meter.



**BCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66Ω**

OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between data link connector and BCM.

**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 26 (L) and 27 (P).

**26 (L) - 27 (P) : Approx. 54 - 66Ω**

OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between data link connector and combination meter.



**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, connector side and harness side).
  - IPDM E/R connector
  - Harness connector E28
  - Harness connector M7

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132Ω**

**OK or NG**

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and data link connector.

**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
  - ECM
  - BCM
  - Combination meter
  - IPDM E/R
  - Between ECM and IPDM E/R

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LAN

L  
M


## 2. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
  - ECM connector
  - Harness connector F59
- Check continuity between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Continuity should not exist.**

### OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness between ECM and harness connector F59.



## 3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F54 terminals 94 (L), 86 (P) and ground.

**94 (L) - Ground : Continuity should not exist.**

**86 (P) - Ground : Continuity should not exist.**

### OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness between ECM and harness connector F59.




## 4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
  - BCM connector
  - Combination meter connector
  - Harness connector M7
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

### OK or NG

- OK >> GO TO 5.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M71
  - Harness between data link connector and BCM
  - Harness between data link connector and combination meter
  - Harness between data link connector and harness connector M7



## 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (P) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



## 6. CHECK HARNESS FOR SHORT CIRCUIT


1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Continuity should not exist.**

### OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector E28 and IPDM E/R.



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E121 terminals 48 (L), 49 (P) and ground.


**48 (L) - Ground : Continuity should not exist.**

**49 (P) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E28 and IPDM E/R.




## 8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	

### OK or NG

- OK >> GO TO 9.  
 NG >> Replace ECM and/or IPDM E/R.



## 9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

### OK or NG

- OK >> GO TO 10.  
 NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

## 10. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.


1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Disconnect the unit connector.
4. Connect battery cable at negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
  - BCM
  - Combination meter
  - ECM
  - IPDM E/R

### Inspection results

- Reproduced>>Install removed unit, and then check the other unit.  
 Not reproduced>>Replace removed unit.

CAN SYSTEM (TYPE 2)

Component Parts and Harness Connector Location



BKIA0025E


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 2)

[CAN]

## Schematic

UKS001Y4



BKWA0114E

# CAN SYSTEM (TYPE 2)


[CAN]

## Wiring Diagram - CAN -


UKS001Y5

### LAN-CAN-04

▬ : DATA LINE







A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



REFER TO THE FOLLOWING.  
 (F54) - ELECTRICAL UNITS

BKWA0115E





REFER TO THE FOLLOWING.

M18 - ELECTRICAL UNITS

## LAN-CAN-06

▬ : DATA LINE



BKWA0117E

# CAN SYSTEM (TYPE 2)

[CAN]

UKS001RV

## CHECK SHEET

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table									
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Display control unit Translation Sheet: Rewrite the following names, and put a check mark on the above check sheet table.			
Confirmation/Adjustment Display	Check sheet table Display	Confirmation/Adjustment Display	Check sheet table Display
CAN COMM	Initial diagnosis	CAN CIRC 5	METER/M&A
CAN CIRC 1	Transmit diagnosis	CAN CIRC 6	—
CAN CIRC 2	BCM	CAN CIRC 7	IPDM E/R
CAN CIRC 3	ECM	CAN CIRC 8	—
CAN CIRC 4	—	CAN CIRC 9	—


  

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR check sheet

PKIA8887E

# CAN SYSTEM (TYPE 2)

[CAN]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check ECM circuit. Refer to [LAN-62. "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U <del>0</del> 01)
Display control unit	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—
BCM	No indication	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—	CAN COMM CIRCUIT (U <del>0</del> 00)	—

PKIA8901E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 2

Check display control unit circuit. Refer to [LAN-62, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8902E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 3

Check data link connector circuit. Refer to [LAN-63, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8903E




## Case 4

Check BCM circuit. Refer to [LAN-63, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
Display control unit	—	NG	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8904E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

LAN

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 5

Check combination meter circuit. Refer to [LAN-64, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN ✓	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8905E



# CAN SYSTEM (TYPE 2)


[CAN]

## Case 6

Check IPDM E/R circuit. Refer to [LAN-64, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8906E



## Case 7

Check CAN communication circuit. Refer to [LAN-65, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR						SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis					
				ECM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8907E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

**ECM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, connector side and harness side).
  - ECM connector
  - Harness connector F59
  - Harness connector M71

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and data link connector.

**Display Control Unit Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

**25 (L) - 26 (P) : Approx. 54 - 66Ω**

OK or NG

- OK >> Replace display control unit.  
 NG >> Repair harness between data link connector and display control unit.



**Data Link Connector Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66Ω**

**OK or NG**

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#) .  
 NG >> Repair harness between data link connector and combination meter.

**BCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66Ω**

**OK or NG**

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between data link connector and BCM.



**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 26 (L) and 27 (P).

**26 (L) - 27 (P) : Approx. 54 - 66Ω**

OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between data link connector and combination meter.

**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, connector side and harness side).
  - IPDM E/R connector
  - Harness connector E28
  - Harness connector M7

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132Ω**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and data link connector.



**CAN Communication Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
  - ECM
  - Display control unit
  - BCM
  - Combination meter
  - IPDM E/R
  - Between ECM and IPDM E/R

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR SHORT CIRCUIT**

1. Disconnect following connectors.
  - ECM connector
  - Harness connector F59
2. Check continuity between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Continuity should not exist.**

**OK or NG**

- OK >> GO TO 3.  
 NG >> Repair harness between ECM and harness connector F59.


**3. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between ECM harness connector F54 terminals 94 (L), 86 (P) and ground.

**94 (L) - Ground : Continuity should not exist.**  
**86 (P) - Ground : Continuity should not exist.**

**OK or NG**

- OK >> GO TO 4.  
 NG >> Repair harness between ECM and harness connector F59.



## 4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
  - Display control unit connector
  - BCM connector
  - Combination meter connector
  - Harness connector M7
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


**6 (L) - 14 (P) : Continuity should not exist.**

### OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and Display control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



## 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (P) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and Display control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



## 6. CHECK HARNESS FOR SHORT CIRCUIT


- Disconnect IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Continuity should not exist.**

### OK or NG

OK >> GO TO 7.

NG >> Repair harness between harness connector E28 and IPDM E/R.



**7. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between IPDM E/R harness connector E121 terminals 48 (L), 49 (P) and ground.


**48 (L) - Ground : Continuity should not exist.**

**49 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E28 and IPDM E/R.



**8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION**


1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



**9. CHECK SYMPTOM**

1. Full in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

**10. UNIT REPRODUCIBILITY INSPECTION**

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Disconnect the unit connector.
4. Connect battery cable at negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
  - Display control unit
  - BCM
  - Combination meter
  - ECM
  - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

CAN SYSTEM (TYPE 3)

Component Parts and Harness Connector Location

UKS001XR




# CAN SYSTEM (TYPE 3)

[CAN]

## Schematic

UKS001XS





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

BKWA0110E

Wiring Diagram - CAN -

LAN-CAN-07

▬ : DATA LINE




REFER TO THE FOLLOWING.  
 (F54) - ELECTRICAL UNITS

# CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-08



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

M22  
W



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

M24  
W

REFER TO THE FOLLOWING.  
M18 - ELECTRICAL UNITS

BKWA0112E

LAN-CAN-09



REFER TO THE FOLLOWING.  
 (E125) - ELECTRICAL UNITS

BKWA0113E

# CAN SYSTEM (TYPE 3)

[CAN]

UKS001RU

## CHECK SHEET

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA8888E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-81, "Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8976E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-82, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8977E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LAN

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 3

Check data link connector circuit. Refer to [LAN-82, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8978E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 4

Check BCM circuit. Refer to [LAN-83, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U000) ✓	—

PKIA8979E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LAN

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 5

Check combination meter circuit. Refer to [LAN-83, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8980E



PKIA9047E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 6

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-84, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8981E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 7

Check IPDM E/R circuit. Refer to [LAN-84, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8982E



## Case 8

Check CAN communication circuit. Refer to [LAN-85, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8983E

## Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-88, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	UNKWN	-	-	-	CAN COMM CIRCUIT (U1000)	-

PKIA8984E

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-88, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
BCM	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	-	-	-	-	-	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	UNKWN	-	-	-	CAN COMM CIRCUIT (U1000)	-

PKIA8985E

## Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)

UKS001XU

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M7
  - Harness connector E28

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M7.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M7 terminals 10 (L), 9 (P).

**6 (L) - 10 (L) : Continuity should exist.**  
**14 (P) - 9 (P) : Continuity should exist.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.



### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E28 terminals 10 (L), 9 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 30 (L), 29 (P).


**10 (L) - 30 (L) : Continuity should exist.**

**9 (P) - 29 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



UKS001XV

## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, connector side and harness side).
  - ECM connector
  - Harness connector F59
  - Harness connector M71

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132Ω**

OK or NG

OK >> Replace ECM.

NG >> Repair harness between ECM and data link connector.



UKS001XW

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and combination meter.



UKS001XX

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between data link connector and BCM.



UKS001XY

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 26 (L) and 27 (P).

**26 (L) - 27 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between data link connector and combination meter.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

UKS001XZ

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 30 (L) and 29 (P).

**30 (L) - 29 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between harness connector E28 and ABS actuator and electric unit (control unit).



## IPDM E/R Circuit Check

UKS001Y0

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between harness connector E28 and IPDM E/R.



UKS001Y1

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
  - ECM
  - BCM
  - Combination meter
  - ABS actuator and electric unit (control unit)
  - IPDM E/R
  - Between ECM and IPDM E/R

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - Harness connector F59
2. Check continuity between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Continuity should not exist.**

### OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness between ECM and harness connector F59.



SKIA6865E

### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector F54 terminals 94 (L), 86 (P) and ground.


**94 (L) - Ground : Continuity should not exist.**

**86 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector F59.



### 4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
  - BCM connector
  - Combination meter connector
  - Harness connector M7
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


**6 (L) - 14 (P) : Continuity should not exist.**

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



### 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



**6. CHECK HARNESS FOR SHORT CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).


**48 (L) - 49 (P) : Continuity should not exist.**

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E28 and ABS actuator and electric unit (control unit)
- Harness between harness connector E28 and IPDM E/R



**7. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between IPDM E/R harness connector E121 terminals 48 (L), 49 (P) and ground.

**48 (L) - Ground : Continuity should not exist.**


**49 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E28 and ABS actuator and electric unit (control unit)
- Harness between harness connector E28 and IPDM E/R



**8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION**


1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



**9. CHECK SYMPTOM**

1. Full in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

---

## 10. UNIT REPRODUCIBILITY INSPECTION

---

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Disconnect the unit connector.
4. Connect battery cable at negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
  - BCM
  - Combination meter
  - ABS actuator and electric unit (control unit)
  - ECM
  - IPDM E/R

### Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

### **IPDM E/R Ignition Relay Circuit Check**


UKS001Y2

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

## CAN SYSTEM (TYPE 4)

### Component Parts and Harness Connector Location



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

# CAN SYSTEM (TYPE 4)

[CAN]

## Schematic

UKS001V0



BKWA0106E

# CAN SYSTEM (TYPE 4)


[CAN]

## Wiring Diagram - CAN -


UKS001VP

### LAN-CAN-10

▬ : DATA LINE




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



REFER TO THE FOLLOWING.  
 (F54) - ELECTRICAL UNITS

BKWA0107E

## LAN-CAN-11



16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

M22  
W

20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

M24  
W

56	54	52	50	48	46	44	42	40	38	36	34	32	30	28	26
55	53	51	49	47	45	43	41	39	37	35	33	31	29	27	25


M95  
W

REFER TO THE FOLLOWING.


M18 - ELECTRICAL UNITS

BKWA0108E

## LAN-CAN-12



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



REFER TO THE FOLLOWING.  
 (E125) - ELECTRICAL UNITS

BKWA0109E

# CAN SYSTEM (TYPE 4)

[CAN]

UKS001RT

## CHECK SHEET

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Display control unit Translation Sheet: Rewrite the following names, and put a check mark on the above check sheet table.


Confirmation/Adjustment Display	Check sheet table Display	Confirmation/Adjustment Display	Check sheet table Display
CAN COMM	Initial diagnosis	CAN CIRC 5	METER/M&A
CAN CIRC 1	Transmit diagnosis	CAN CIRC 6	—
CAN CIRC 2	BCM	CAN CIRC 7	IPDM E/R
CAN CIRC 3	ECM	CAN CIRC 8	—
CAN CIRC 4	—	CAN CIRC 9	—

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR check sheet

PKIA8889E

# CAN SYSTEM (TYPE 4)

[CAN]



A

B

C

D

E

F

G

H

I

J

LAN

L

M

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-104, "Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN ✓	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN ✓	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8909E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-105, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
Display control unit	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	—
BCM	No indication	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	—	UNKW <sup>N</sup>	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW <sup>N</sup>	UNKW <sup>N</sup>	UNKW <sup>N</sup>	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8910E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 3

Check display control unit circuit. Refer to [LAN-106, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
Display control unit	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8911E



PKIA9052E

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 4

Check data link connector circuit. Refer to [LAN-106, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8912E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 5

Check BCM circuit. Refer to [LAN-107, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8913E



PKIA9054E

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 6

Check combination meter circuit. Refer to [LAN-107, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	✓	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8914E



# CAN SYSTEM (TYPE 4)


[CAN]

## Case 7

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-108, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001)
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8915E



PKIA9056E

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 8

Check IPDM E/R circuit. Refer to [LAN-108, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8916E



## Case 9

Check CAN communication circuit. Refer to [LAN-109, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
Display control unit	—	NG	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8917E

## Case 10

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-112, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8918E

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-112, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
Display control unit	—	NG	UNKWN	UNKWN	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8919E

## Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)

UKS001VQ

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M7
  - Harness connector E28

#### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M7.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M7 terminals 10 (L), 9 (P).


**6 (L) - 10 (L) : Continuity should exist.**

**14 (P) - 9 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



## 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E28 terminals 10 (L), 9 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 30 (L), 29 (P).


**10 (L) - 30 (L) : Continuity should exist.**

**9 (P) - 29 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, connector side and harness side).
  - ECM connector
  - Harness connector F59
  - Harness connector M71

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM and data link connector.



UKS001VS

## Display Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

**25 (L) - 26 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace display control unit.  
 NG >> Repair harness between data link connector and display control unit.



UKS001VT

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and combination meter.



SKIA6868E

UKS001VV

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between data link connector and BCM.



SKIA6869E

UKS001VV

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 26 (L) and 27 (P).

**26 (L) - 27 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between data link connector and combination meter.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

UKS001VW

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 30 (L) and 29 (P).

**30 (L) - 29 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between harness connector E28 and ABS actuator and electric unit (control unit).



## IPDM E/R Circuit Check

UKS001VX

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between harness connector E28 and IPDM E/R.



UKS001VY

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
  - ECM
  - Display control unit
  - BCM
  - Combination meter
  - ABS actuator and electric unit (control unit)
  - IPDM E/R
  - Between ECM and IPDM E/R

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - Harness connector F59
2. Check continuity between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Continuity should not exist.**

### OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness between ECM and harness connector F59.



### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector F54 terminals 94 (L), 86 (P) and ground.


**94 (L) - Ground : Continuity should not exist.**

**86 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness between ECM and harness connector F59.



### 4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
  - Display control unit connector
  - BCM connector
  - Combination meter connector
  - Harness connector M7
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


**6 (L) - 14 (P) : Continuity should not exist.**

OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and Display control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



### 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and Display control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



**6. CHECK HARNESS FOR SHORT CIRCUIT**

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).


**48 (L) - 49 (P) : Continuity should not exist.**

OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E28 and ABS actuator and electric unit (control unit)
- Harness between harness connector E28 and IPDM E/R



**7. CHECK HARNESS FOR SHORT CIRCUIT**

Check continuity between IPDM E/R harness connector E121 terminals 48 (L), 49 (P) and ground.

**48 (L) - Ground : Continuity should not exist.**


**49 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E28 and ABS actuator and electric unit (control unit)
- Harness between harness connector E28 and IPDM E/R



**8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION**


1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



**9. CHECK SYMPTOM**

1. Full in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

---

## 10. UNIT REPRODUCIBILITY INSPECTION

---

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Disconnect the unit connector.
4. Connect battery cable at negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
  - Display control unit
  - BCM
  - Combination meter
  - ABS actuator and electric unit (control unit)
  - ECM
  - IPDM E/R

### Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

### **IPDM E/R Ignition Relay Circuit Check**

UKS001VZ

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

# CAN SYSTEM (TYPE 5)


[CAN]

## CAN SYSTEM (TYPE 5)

PFP:23710

### Component Parts and Harness Connector Location

UKS001VB



BKIA0027E


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 5)

[CAN]

## Schematic

UKS001VC



BKWA0098E

# CAN SYSTEM (TYPE 5)


[CAN]

## Wiring Diagram - CAN -

UKS001VD

### LAN-CAN-13

— : DATA LINE




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



REFER TO THE FOLLOWING.  
 (F54), (F56) - ELECTRICAL  
 UNITS

BKWA0099E

LAN-CAN-14



16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

(M22)  
W

20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

(M24)  
W



REFER TO THE FOLLOWING.  
(M18) - ELECTRICAL UNITS

# CAN SYSTEM (TYPE 5)

[CAN]

## LAN-CAN-15

▬ : DATA LINE



BKWA0101E

# CAN SYSTEM (TYPE 5)

[CAN]

UKS001RS

## CHECK SHEET

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
A/T  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
A/T  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA8890E

# CAN SYSTEM (TYPE 5)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-126. "Circuit Check Between TCM and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8986E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-127, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	UNKWN	—	—	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U100) ✓	—

PKIA8987E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 3

Check TCM circuit. Refer to [LAN-127, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	—	—	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8988E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 4

Check data link connector circuit. Refer to [LAN-128, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8989E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 5

Check BCM circuit. Refer to [LAN-128, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8990E




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

## Case 6

Check combination meter circuit. Refer to [LAN-129, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	-	NG	UNKWN	UNKWN	-	-	-	-	-	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN ✓	UNKWN	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	UNKWN	-	-	CAN COMM CIRCUIT (U1000)	-

PKIA8991E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 7

Check IPDM E/R circuit. Refer to [LAN-129, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	✓	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8992E



## Case 8

Check CAN communication circuit. Refer to [LAN-130, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS			
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	✓	✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	—	—	—	—	—	—	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8993E

## Case 9

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-133, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	-	NG	UNKWN	-	✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	-	NG	UNKWN	UNKWN	-	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	UNKWN	-	-	CAN COMM CIRCUIT (U1000)	-

PKIA8994E

## Circuit Check Between TCM and Data Link Connector

UKS001VE

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F59
  - Harness connector M71

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector and harness connector F59.
2. Check continuity between TCM harness connector F56 terminals 5 (L), 6 (P) and harness connector F59 terminals 23 (L), 22 (P).

**5 (L) - 23 (L) : Continuity should exist.**  
**6 (P) - 22 (P) : Continuity should exist.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair harness.




### 3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M71 terminals 23 (L), 22 (P) and data link connector M22 terminals 6 (L), 14 (P).

**23 (L) - 6 (L) : Continuity should exist.**  
**22 (P) - 14 (P) : Continuity should exist.**

#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#) .  
 NG >> Repair harness.



**ECM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between harness connector F59 and ECM.

**TCM Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect TCM connector.
2. Check resistance between TCM harness connector F56 terminals 5 (L) and 6 (P).

**5 (L) - 6 (P) : Approx. 54 - 66Ω**

OK or NG

- OK >> Replace TCM.  
 NG >> Repair harness between harness connector F59 and TCM.



## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66Ω**

#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#) .  
 NG >> Repair harness between data link connector and combination meter.



UKS001VI

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66Ω**

#### OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#) .  
 NG >> Repair harness between data link connector and BCM.



**Combination Meter Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 26 (L) and 27 (P).

**26 (L) - 27 (P) : Approx. 54 - 66Ω**

OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between data link connector and combination meter.

**IPDM E/R Circuit Check****1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - IPDM E/R connector
  - Harness connector E28
  - Harness connector M7

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132Ω**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and data link connector.



## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
  - ECM
  - TCM
  - BCM
  - Combination meter
  - IPDM E/R
  - Between ECM and IPDM E/R

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - TCM connector
  - Harness connector F59
2. Check continuity between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
  - Harness between ECM and harness connector F59
  - Harness between TCM and harness connector F59



### 3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F54 terminals 94 (L), 86 (P) and ground.

**94 (L) - Ground : Continuity should not exist.**

**86 (P) - Ground : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 4.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
  - Harness between ECM and harness connector F59
  - Harness between TCM and harness connector F59




#### 4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
  - BCM connector
  - Combination meter connector
  - Harness connector M7
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

##### OK or NG

- OK >> GO TO 5.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M71
  - Harness between data link connector and BCM
  - Harness between data link connector and combination meter
  - Harness between data link connector and harness connector M7



#### 5. CHECK HARNESS FOR SHORT CIRCUIT


- Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

##### OK or NG

- OK >> GO TO 6.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M71
  - Harness between data link connector and BCM
  - Harness between data link connector and combination meter
  - Harness between data link connector and harness connector M7




#### 6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Continuity should not exist.**

##### OK or NG

- OK >> GO TO 7.  
 NG >> Repair harness between harness connector E28 and IPDM E/R.



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E121 terminals 48 (L), 49 (P) and ground.


**48 (L) - Ground : Continuity should not exist.**

**49 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E28 and IPDM E/R.



## 8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION


1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



## 9. CHECK SYMPTOM

1. Full in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

## 10. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Disconnect the unit connector.
4. Connect battery cable at negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
  - TCM
  - BCM
  - Combination meter
  - ECM
  - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

## IPDM E/R Ignition Relay Circuit Check

UKS001VM

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

A

B

C

D

E

F

G

H

I

J

LAN

L


M

CAN SYSTEM (TYPE 6)

PF2:23710

Component Parts and Harness Connector Location

UKS00176




# CAN SYSTEM (TYPE 6)

[CAN]

## Schematic

UKS001T7



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

BKWA0094E

Wiring Diagram - CAN -

LAN-CAN-16

— : DATA LINE





1	2	3	4	5	6	7	8	9	10	11	F59		
12	13	14	15	16	17	18	19	20	21	22	23	24	W

REFER TO THE FOLLOWING.  
 (F54), (F56) - ELECTRICAL  
 UNITS


# CAN SYSTEM (TYPE 6)

[CAN]


## LAN-CAN-17



(M22)  
W



(M24)  
W





(M95)  
W

REFER TO THE FOLLOWING.  
(M18) - ELECTRICAL UNITS

BKWA0096E

LAN-CAN-18

▬ : DATA LINE



BKWA0097E

# CAN SYSTEM (TYPE 6)

[CAN]

UKS001RR

## CHECK SHEET

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	-	NG	UNKWN	UNKWN	-	-	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
Display control unit	-	NG	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	-	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	UNKWN	-	-	CAN COMM CIRCUIT (U1000)	-

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Display control unit Translation Sheet: Rewrite the following names, and put a check mark on the above check sheet table.

Confirmation/Adjustment Display	Check sheet table Display	Confirmation/Adjustment Display	Check sheet table Display
CAN COMM	Initial diagnosis	CAN CIRC 5	METER/M&A
CAN CIRC 1	Transmit diagnosis	CAN CIRC 6	-
CAN CIRC 2	BCM	CAN CIRC 7	IPDM E/R
CAN CIRC 3	ECM	CAN CIRC 8	-
CAN CIRC 4	-	CAN CIRC 9	-

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR check sheet

PKIA8891E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 6)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of BCM SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

PKIA8899E

# CAN SYSTEM (TYPE 6)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-149, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	NG	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8920E



PKIA9065E

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-150, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
A/T	—	NG	UNKW <sup>✓</sup> N	—	—	—	UNKW <sup>✓</sup> N	—	—	—
Display control unit	—	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—
BCM	No indication	NG	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKW <sup>✓</sup> N	UNKW <sup>✓</sup> N	—	UNKW <sup>✓</sup> N	—	—	CAN COMM CIRCUIT (U100)	—

PKIA8921E



PKIA9066E

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 3

Check TCM circuit. Refer to [LAN-150, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
A/T	—	NG	—	—	—	—	—	—	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8922E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 4

Check display control unit circuit. Refer to [LAN-151, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8923E



PKIA9068E

# CAN SYSTEM (TYPE 6)


[CAN]

## Case 5

Check data link connector circuit. Refer to [LAN-151, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8924E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 6

Check BCM circuit. Refer to [LAN-152, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U001) ✓
A/T	—	NG	UNKWN	UNKWN	—	—	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U000) ✓	—

PKIA8925E



# CAN SYSTEM (TYPE 6)


[CAN]

## Case 7

Check combination meter circuit. Refer to [LAN-152, "Combination Meter Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
A/T	—	NG	UNKWN	UNKWN	—	—	—	—	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8926E




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

## Case 8

Check IPDM E/R circuit. Refer to [LAN-153, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	UNKW <del>N</del>	UNKW <del>N</del>	—	—
BCM	No indication ✓	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	UNKW <del>N</del>	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8927E



## Case 9

Check CAN communication circuit. Refer to [LAN-154, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR							SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	BCM /SEC	METER /M&A	IPDM E/R		
ENGINE	—	NG	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
A/T	—	NG	—	—	—	—	—	—	—	—
Display control unit	—	NG	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	UNKW <del>N</del> ✓	—	—
BCM	No indication ✓	NG	UNKW <del>N</del>	UNKW <del>N</del>	—	—	UNKW <del>N</del>	UNKW <del>N</del>	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKW <del>N</del>	UNKW <del>N</del>	—	UNKW <del>N</del>	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8928E



### 3. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between harness connector M71 terminals 23 (L), 22 (P) and data link connector M22 terminals 6 (L), 14 (P).


**23 (L) - 6 (L) : Continuity should exist.**

**22 (P) - 14 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



UKS001TA

## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132Ω**

OK or NG

OK >> Replace ECM.

NG >> Repair harness between harness connector F59 and ECM.



UKS001TB

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect TCM connector.
2. Check resistance between TCM harness connector F56 terminals 5 (L) and 6 (P).

**5 (L) - 6 (P)**

**: Approx. 54 - 66Ω**

OK or NG

- OK >> Replace TCM.  
 NG >> Repair harness between harness connector F59 and TCM.



UKS001TC

## Display Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

**25 (L) - 26 (P)**

**: Approx. 54 - 66Ω**

OK or NG

- OK >> Replace display control unit.  
 NG >> Repair harness between data link connector and display control unit.



UKS001TD

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and combination meter.



UKS001TE

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between data link connector and BCM.



UKS001TF

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 26 (L) and 27 (P).

**26 (L) - 27 (P) : Approx. 54 - 66Ω**

OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between data link connector and combination meter.



UKS001TG

## IPDM E/R Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side and harness side).
  - IPDM E/R connector
  - Harness connector E28
  - Harness connector M7

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132Ω**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R and data link connector.



SKIA6873E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
  - ECM
  - TCM
  - Display control unit
  - BCM
  - Combination meter
  - IPDM E/R
  - Between ECM and IPDM E/R

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - TCM connector
  - Harness connector F59
2. Check continuity between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between ECM and harness connector F59
  - Harness between TCM and harness connector F59



### 3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F54 terminals 94 (L), 86 (P) and ground.

**94 (L) - Ground : Continuity should not exist.**

**86 (P) - Ground : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 4.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between ECM and harness connector F59
  - Harness between TCM and harness connector F59




## 4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
  - Display control unit connector
  - BCM connector
  - Combination meter connector
  - Harness connector M7
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

### OK or NG

- OK >> GO TO 5.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M71
  - Harness between data link connector and Display control unit
  - Harness between data link connector and BCM
  - Harness between data link connector and combination meter
  - Harness between data link connector and harness connector M7



## 5. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

### OK or NG

- OK >> GO TO 6.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between data link connector and harness connector M71
  - Harness between data link connector and Display control unit
  - Harness between data link connector and BCM
  - Harness between data link connector and combination meter
  - Harness between data link connector and harness connector M7




## 6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Continuity should not exist.**

### OK or NG

- OK >> GO TO 7.  
 NG >> Repair harness between harness connector E28 and IPDM E/R.



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E121 terminals 48 (L), 49 (P) and ground.


**48 (L) - Ground : Continuity should not exist.**

**49 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 8.

NG >> Repair harness between harness connector E28 and IPDM E/R.



## 8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION


1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



## 9. CHECK SYMPTOM

1. Full in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

## 10. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF. A
2. Disconnect battery cable at negative terminal. B
3. Disconnect the unit connector.
4. Connect battery cable at negative terminal. C
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced. D
  - TCM
  - Display control unit
  - BCM E
  - Combination meter
  - ECM
  - IPDM E/R F

### Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit. G

### **IPDM E/R Ignition Relay Circuit Check**

*UKS001T1*

Check the following. If no malfunction is found, replace the IPDM E/R. H

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) . I

J

LAN


L

M

## CAN SYSTEM (TYPE 7)

### Component Parts and Harness Connector Location

UKS001SS




# CAN SYSTEM (TYPE 7)

[CAN]

## Schematic

UKS001ST



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

BKWA0331E

# CAN SYSTEM (TYPE 7)



[CAN]

## Wiring Diagram - CAN -

UKS001SU

### LAN-CAN-19

— : DATA LINE




REFER TO THE FOLLOWING.  
 (F54), (F56) - ELECTRICAL  
 UNITS

BKWA0087E

# CAN SYSTEM (TYPE 7)

[CAN]

## LAN-CAN-20



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

(M22)  
W



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

(M24)  
W

REFER TO THE FOLLOWING.  
(M18) - ELECTRICAL UNITS

BKWA0088E

LAN-CAN-21



REFER TO THE FOLLOWING.  
 (E125) - ELECTRICAL UNITS

BKWA0089E

# CAN SYSTEM (TYPE 7)

**[CAN]**

UKS001RQ

## CHECK SHEET

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIA8892E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 7)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
TRANSMISSION  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
TRANSMISSION  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA8900E

# CAN SYSTEM (TYPE 7)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-174, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8995E



PKIA9073E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to LAN-175, "Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)".

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8996E



PKIA9074E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 3

Check ECM circuit. Refer to [LAN-176, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
TRANSMISSION	No indication	NG	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100)	—

PKIA8997E



PKIA9075E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-176, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8998E



PKIA9076E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 5

Check data link connector circuit. Refer to [LAN-177, "Data Link Connector Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8999E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 6

Check BCM circuit. Refer to [LAN-177, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9000E



PKIA9078E

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 7

Check combination meter circuit. Refer to [LAN-178, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9001E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 7)


[CAN]

## Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-178, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	<del>NG</del>	<del>UNKWN</del>	<del>UNKWN</del>	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9002E




PKIA9080E

## Case 9

Check IPDM E/R circuit. Refer to [LAN-179, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	

PKIA9003E



## Case 10

Check CAN communication circuit. Refer to [LAN-180, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓	
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—	

PKIA9004E

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-183, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U100) ✓	CAN COMM CIRCUIT (U101) ✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9005E

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-183, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9006E

## Circuit Check Between TCM and Data Link Connector

UKS001SV

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F59
  - Harness connector M71

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector and harness connector F59.
2. Check continuity between TCM harness connector F56 terminals 3 (L), 4 (P) and harness connector F59 terminals 23 (L), 22 (P).


**3 (L) - 23 (L) : Continuity should exist.**

**4 (P) - 22 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



## 3. CHECK HARNESS FOR OPEN CIRCUIT

- Check continuity between harness connector M71 terminals 23 (L), 22 (P) and data link connector M22 terminals 6 (L), 14 (P).


**23 (L) - 6 (L) : Continuity should exist.**

**22 (P) - 14 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



## Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)

UKS001SW

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M7
  - Harness connector E28

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M7.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M7 terminals 10 (L), 9 (P).


**6 (L) - 10 (L) : Continuity should exist.**

**14 (P) - 9 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E28 terminals 10 (L), 9 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 30 (L), 29 (P).


**10 (L) - 30 (L) : Continuity should exist.**

**9 (P) - 29 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



SKIB0566E

UKS001SX

## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132Ω**

OK or NG

OK >> Replace ECM.

NG >> Repair harness between harness connector F59 and ECM.



SKIB0567E

UKS001SY

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect TCM connector.
2. Check resistance between TCM harness connector F56 terminals 3 (L) and 4 (P).

**3 (L) - 4 (P)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace TCM.  
 NG >> Repair harness between harness connector F59 and TCM.



UKS001SZ

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6. "TROUBLE DIAGNOSES WORK FLOW"](#) .  
 NG >> Repair harness between data link connector and combination meter.



UKS001T0

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between data link connector and BCM.



UKS001T1

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 26 (L) and 27 (P).

**26 (L) - 27 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between data link connector and combination meter.



UKS001T2

## ABS Actuator and Electric Unit (Control Unit) Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 30 (L) and 29 (P).

**30 (L) - 29 (P) : Approx. 54 - 66Ω**

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between harness connector E28 and ABS actuator and electric unit (control unit).



UKS001T3

## IPDM E/R Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132Ω**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between harness connector E28 and IPDM E/R.



## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
  - ECM
  - TCM
  - BCM
  - Combination meter
  - ABS actuator and electric unit (control unit)
  - IPDM E/R
  - Between ECM and IPDM E/R

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - TCM connector
  - Harness connector F59
2. Check continuity between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between ECM and harness connector F59
  - Harness between TCM and harness connector F59



### 3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F54 terminals 94 (L), 86 (P) and ground.

**94 (L) - Ground : Continuity should not exist.**

**86 (P) - Ground : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 4.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between ECM and harness connector F59
  - Harness between TCM and harness connector F59



#### 4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
  - BCM connector
  - Combination meter connector
  - Harness connector M7
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


**6 (L) - 14 (P) : Continuity should not exist.**

##### OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



#### 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (P) - Ground : Continuity should not exist.**

##### OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



#### 6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).


**48 (L) - 49 (P) : Continuity should not exist.**

##### OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E28 and ABS actuator and electric unit (control unit)
- Harness between harness connector E28 and IPDM E/R



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E121 terminals 48 (L), 49 (P) and ground.

**48 (L) - Ground : Continuity should not exist.**


**49 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E28 and ABS actuator and electric unit (control unit)
- Harness between harness connector E28 and IPDM E/R



## 8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION


1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



## 9. CHECK SYMPTOM

1. Full in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

**10. UNIT REPRODUCIBILITY INSPECTION**

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Disconnect the unit connector.
4. Connect battery cable at negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
  - TCM
  - BCM
  - Combination meter
  - ABS actuator and electric unit (control unit)
  - ECM
  - IPDM E/R

Inspection results

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

**IPDM E/R Ignition Relay Circuit Check**

UKS00175

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

LAN

## CAN SYSTEM (TYPE 8)

### Component Parts and Harness Connector Location

UKS001SE




# CAN SYSTEM (TYPE 8)

[CAN]

## Schematic

UKS001SF



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

BKWA0331E

# CAN SYSTEM (TYPE 8)



[CAN]

## Wiring Diagram - CAN -

UKS001SG

### LAN-CAN-22

— : DATA LINE




REFER TO THE FOLLOWING.  
 (F54), (F56) - ELECTRICAL  
 UNITS

BKWA0192E

# CAN SYSTEM (TYPE 8)

[CAN]

## LAN-CAN-23



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1

(M22)  
W



20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

(M24)  
W

REFER TO THE FOLLOWING.  
(M18) - ELECTRICAL UNITS

BKWA0193E

LAN-CAN-24



REFER TO THE FOLLOWING.  
 (E125) - ELECTRICAL UNITS

BKWA0194E

# CAN SYSTEM (TYPE 8)

[CAN]

UKS001RP

## CHECK SHEET

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

PKIA8893E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 8)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
TRANSMISSION  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
TRANSMISSION  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA8900E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-200, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	-
BCM	No indication	NG	UNKWN	UNKWN ✓	-	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN ✓	UNKWN ✓	-	-	-	-	CAN COMM CIRCUIT (U1000) ✓	-
IPDM E/R	No indication	-	UNKWN	UNKWN ✓	-	UNKWN	-	-	-	CAN COMM CIRCUIT (U1000) ✓	-

PKIA9007E



PKIA9073E

# CAN SYSTEM (TYPE 8)


[CAN]

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-201, "Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\)"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9008E




PKIA9074E

## Case 3

Check ECM circuit. Refer to [LAN-202, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
TRANSMISSION	No indication	NG	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U100)	—

PKIA9009E




## Case 4

Check TCM circuit. Refer to [LAN-202, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U100)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9010E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 5

Check data link connector circuit. Refer to [LAN-203, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	UNKWN	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9011E




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

## Case 6

Check BCM circuit. Refer to [LAN-203, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA9012E




PKIA9078E

## Case 7

Check combination meter circuit. Refer to [LAN-204, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9013E



# CAN SYSTEM (TYPE 8)


[CAN]

## Case 8

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-204, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9014E




PKIA9080E

## Case 9

Check IPDM E/R circuit. Refer to [LAN-205, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA9015E



## Case 10

Check CAN communication circuit. Refer to [LAN-206, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R			
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA9016E

## Case 11

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-209, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U100)	CAN COMM CIRCUIT (U101)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9017E

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-209, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9018E

## Circuit Check Between TCM and Data Link Connector

UKS001SH

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F59
  - Harness connector M71

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector and harness connector F59.
2. Check continuity between TCM harness connector F56 terminals 3 (L), 4 (P) and harness connector F59 terminals 23 (L), 22 (P).


**3 (L) - 23 (L) : Continuity should exist.**

**4 (P) - 22 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



## 3. CHECK HARNESS FOR OPEN CIRCUIT

- Check continuity between harness connector M71 terminals 23 (L), 22 (P) and data link connector M22 terminals 6 (L), 14 (P).


**23 (L) - 6 (L) : Continuity should exist.**

**22 (P) - 14 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



## Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)

UKS001SI

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M7
  - Harness connector E28

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M7.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M7 terminals 10 (L), 9 (P).


**6 (L) - 10 (L) : Continuity should exist.**

**14 (P) - 9 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E28 terminals 10 (L), 9 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 30 (L), 29 (P).


**10 (L) - 30 (L) : Continuity should exist.**

**9 (P) - 29 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



UKS001SJ

## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132Ω**

OK or NG

OK >> Replace ECM.

NG >> Repair harness between harness connector F59 and ECM.



UKS001SK

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect TCM connector.
2. Check resistance between TCM harness connector F56 terminals 3 (L) and 4 (P).

**3 (L) - 4 (P)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace TCM.  
 NG >> Repair harness between harness connector F59 and TCM.



UKS001SL

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT


Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P)**

**: Approx. 54 - 66Ω**

### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6. "TROUBLE DIAGNOSES WORK FLOW"](#) .  
 NG >> Repair harness between data link connector and combination meter.



UKS001SM

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between data link connector and BCM.



UKS001SN

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 26 (L) and 27 (P).

**26 (L) - 27 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace combination meter.
- NG >> Repair harness between data link connector and combination meter.



UKS001SO

## ABS Actuator and Electric Unit (Control Unit) Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 30 (L) and 29 (P).

**30 (L) - 29 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between harness connector E28 and ABS actuator and electric unit (control unit).



UKS001SP

## IPDM E/R Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between harness connector E28 and IPDM E/R.



SKIA6873E

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
  - ECM
  - TCM
  - BCM
  - Combination meter
  - ABS actuator and electric unit (control unit)
  - IPDM E/R
  - Between ECM and IPDM E/R

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - TCM connector
  - Harness connector F59
2. Check continuity between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between ECM and harness connector F59
  - Harness between TCM and harness connector F59



### 3. CHECK HARNESS FOR SHORT CIRCUIT


Check continuity between ECM harness connector F54 terminals 94 (L), 86 (P) and ground.

**94 (L) - Ground : Continuity should not exist.**

**86 (P) - Ground : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 4.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
- Harness between ECM and harness connector F59
  - Harness between TCM and harness connector F59



#### 4. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect following connectors.
  - BCM connector
  - Combination meter connector
  - Harness connector M7
- Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


**6 (L) - 14 (P) : Continuity should not exist.**

##### OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



#### 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (P) - Ground : Continuity should not exist.**

##### OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



#### 6. CHECK HARNESS FOR SHORT CIRCUIT

- Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).


**48 (L) - 49 (P) : Continuity should not exist.**

##### OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E28 and ABS actuator and electric unit (control unit)
- Harness between harness connector E28 and IPDM E/R



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E121 terminals 48 (L), 49 (P) and ground.

**48 (L) - Ground : Continuity should not exist.**


**49 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E28 and ABS actuator and electric unit (control unit)
- Harness between harness connector E28 and IPDM E/R



## 8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION


1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value (Ω) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	

OK or NG

OK >> GO TO 9.

NG >> Replace ECM and/or IPDM E/R.



## 9. CHECK SYMPTOM

1. Full in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

OK or NG

OK >> GO TO 10.

NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

**10. UNIT REPRODUCIBILITY INSPECTION**

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Disconnect the unit connector.
4. Connect battery cable at negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
  - TCM
  - BCM
  - Combination meter
  - ABS actuator and electric unit (control unit)
  - ECM
  - IPDM E/R

**Inspection results**

Reproduced>>Install removed unit, and then check the other unit.

Not reproduced>>Replace removed unit.

**IPDM E/R Ignition Relay Circuit Check**

UKS001SR

Check the following. If no malfunction is found, replace the IPDM E/R.


- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

LAN

## CAN SYSTEM (TYPE 9)

### Component Parts and Harness Connector Location

UKS001SD




# CAN SYSTEM (TYPE 9)

[CAN]

## Schematic

UKS001RY



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

BKWA0082E

# CAN SYSTEM (TYPE 9)



[CAN]

UKS001RZ

## Wiring Diagram - CAN -

### LAN-CAN-25





— : DATA LINE



REFER TO THE FOLLOWING.  
 (F54), (F56) - ELECTRICAL  
 UNITS

BKWA0083E

## LAN-CAN-26




REFER TO THE FOLLOWING.

M18 - ELECTRICAL UNITS

BKWA0084E

LAN-CAN-27



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(M7)  
W

45	46	47	48	49	50	51	52
53	54	55	56	57	58	59	60

(E121)  
W

REFER TO THE FOLLOWING.

(E125) - ELECTRICAL UNITS

BKWA0085E

# CAN SYSTEM (TYPE 9)

[CAN]

UKS001RO

## CHECK SHEET

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Display control unit Translation Sheet: Rewrite the following names, and put a check mark on the above check sheet table.

Confirmation/Adjustment Display	Check sheet table Display	Confirmation/Adjustment Display	Check sheet table Display
CAN COMM	Initial diagnosis	CAN CIRC 5	METER/M&A
CAN CIRC 1	Transmit diagnosis	CAN CIRC 6	—
CAN CIRC 2	BCM	CAN CIRC 7	IPDM E/R
CAN CIRC 3	ECM	CAN CIRC 8	—
CAN CIRC 4	—	CAN CIRC 9	—

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR check sheet

PKIA8894E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 9)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
TRANSMISSION  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
TRANSMISSION  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA8900E

# CAN SYSTEM (TYPE 9)

[CAN]

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-227, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA9019E



PKIA9082E

# CAN SYSTEM (TYPE 9)


[CAN]

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-228, "Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\)"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9020E




PKIA9083E

### Case 3

Check ECM circuit. Refer to [LAN-229, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication	NG	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—
Display control unit	—	NG	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA9021E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-229, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9022E



PKIA9085E

# CAN SYSTEM (TYPE 9)


[CAN]

## Case 5

Check display control unit circuit. Refer to [LAN-230, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9023E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 6

Check data link connector circuit. Refer to [LAN-230, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9024E




PKIA9087E

## Case 7

Check BCM circuit. Refer to [LAN-231, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN ✓	UNKWN	-	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	CAN COMM CIRCUIT (U1000)	-
Display control unit	-	NG	UNKWN	UNKWN	-	UNKWN ✓	UNKWN	-	UNKWN	-	-
BCM	No indication ✓	NG	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	CAN COMM CIRCUIT (U1000)	-
ABS	-	NG	UNKWN	UNKWN	-	-	-	-	-	CAN COMM CIRCUIT (U1000)	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	UNKWN ✓	-	-	-	CAN COMM CIRCUIT (U1000)	-

PKIA9025E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 8

Check combination meter circuit. Refer to [LAN-231, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9026E



PKIA9089E

# CAN SYSTEM (TYPE 9)


[CAN]

## Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-232, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	<b>NG</b>	<b>UNKWN</b>	<b>UNKWN</b>	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9027E



# CAN SYSTEM (TYPE 9)


[CAN]

## Case 10

Check IPDM E/R circuit. Refer to [LAN-232, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA9028E



## Case 11

Check CAN communication circuit. Refer to [LAN-233, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—
Display control unit	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA9029E

**Case 12**

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-236, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIA9030E

**Case 13**

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-236, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	—	—	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

PKIA9031E

**Circuit Check Between TCM and Data Link Connector**

UKS001S0

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F59
  - Harness connector M71

OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector and harness connector F59.
2. Check continuity between TCM harness connector F56 terminals 3 (L), 4 (P) and harness connector F59 terminals 23 (L), 22 (P).


**3 (L) - 23 (L) : Continuity should exist.**

**4 (P) - 22 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



## 3. CHECK HARNESS FOR OPEN CIRCUIT

- Check continuity between harness connector M71 terminals 23 (L), 22 (P) and data link connector M22 terminals 6 (L), 14 (P).


**23 (L) - 6 (L) : Continuity should exist.**

**22 (P) - 14 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



## Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)

UKS001S1

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M7
  - Harness connector E28

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M7.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M7 terminals 10 (L), 9 (P).


**6 (L) - 10 (L) : Continuity should exist.**

**14 (P) - 9 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



### 3. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E28 terminals 10 (L), 9 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 30 (L), 29 (P).

**10 (L) - 30 (L) : Continuity should exist.**

**9 (P) - 29 (P) : Continuity should exist.**

#### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness.



UKS001S2

## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

#### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132Ω**

#### OK or NG

- OK >> Replace ECM.
- NG >> Repair harness between harness connector F59 and ECM.



UKS001S3

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).

#### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector.
2. Check resistance between TCM harness connector F56 terminals 3 (L) and 4 (P).

**3 (L) - 4 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace TCM.  
 NG >> Repair harness between harness connector F59 and TCM.



## Display Control Unit Circuit Check

UKS001S4

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

**25 (L) - 26 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace display control unit.  
 NG >> Repair harness between data link connector and display control unit.



## Data Link Connector Circuit Check

UKS001S5

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and combination meter.



UKS001S6

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between data link connector and BCM.



UKS001S7

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 26 (L) and 27 (P).

**26 (L) - 27 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between data link connector and combination meter.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

UKS001S8

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 30 (L) and 29 (P).

**30 (L) - 29 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between harness connector E28 and ABS actuator and electric unit (control unit).



## IPDM E/R Circuit Check

UKS001S9

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between harness connector E28 and IPDM E/R.



UKS001SA

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
  - ECM
  - TCM
  - Display control unit
  - BCM
  - Combination meter
  - ABS actuator and electric unit (control unit)
  - IPDM E/R
  - Between ECM and IPDM E/R

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - TCM connector
  - Harness connector F59
2. Check continuity between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Continuity should not exist.**

### OK or NG

- OK >> GO TO 3.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
  - Harness between ECM and harness connector F59
  - Harness between TCM and harness connector F59



### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector F54 terminals 94 (L), 86 (P) and ground.

**94 (L) - Ground : Continuity should not exist.**


**86 (P) - Ground : Continuity should not exist.**

#### OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ECM and harness connector F59
- Harness between TCM and harness connector F59



### 4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.

- Display control unit connector
- BCM connector
- Combination meter connector
- Harness connector M7

2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


**6 (L) - 14 (P) : Continuity should not exist.**

#### OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and Display control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



## 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (P) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and Display control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



## 6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).


**48 (L) - 49 (P) : Continuity should not exist.**

### OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E28 and ABS actuator and electric unit (control unit)
- Harness between harness connector E28 and IPDM E/R



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E121 terminals 48 (L), 49 (P) and ground.

**48 (L) - Ground : Continuity should not exist.**


**49 (P) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E28 and ABS actuator and electric unit (control unit)
- Harness between harness connector E28 and IPDM E/R




## 8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	

### OK or NG

- OK >> GO TO 9.  
 NG >> Replace ECM and/or IPDM E/R.



## 9. CHECK SYMPTOM

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

### OK or NG

- OK >> GO TO 10.  
 NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

## 10. UNIT REPRODUCIBILITY INSPECTION

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Disconnect the unit connector.
4. Connect battery cable at negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
  - TCM
  - Display control unit
  - BCM
  - Combination meter
  - ABS actuator and electric unit (control unit)
  - ECM
  - IPDM E/R

### Inspection results

- Reproduced>>Install removed unit, and then check the other unit.  
 Not reproduced>>Replace removed unit.

## IPDM E/R Ignition Relay Circuit Check


UKS001SB

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

CAN SYSTEM (TYPE 10)

Component Parts and Harness Connector Location




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN SYSTEM (TYPE 10)

[CAN]

## Schematic

UKS001R8



BKWA0082E

# CAN SYSTEM (TYPE 10)


[CAN]

## Wiring Diagram - CAN -


UKS001R9

### LAN-CAN-28

— : DATA LINE







A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M




REFER TO THE FOLLOWING.  
 (F54), (F56) - ELECTRICAL  
 UNITS

BKWA0195E




REFER TO THE FOLLOWING.  
(M18) - ELECTRICAL UNITS

## LAN-CAN-30



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



REFER TO THE FOLLOWING.  
E125 - ELECTRICAL UNITS

BKWA0197E

# CAN SYSTEM (TYPE 10)

[CAN]

UKS001RA

## CHECK SHEET

**NOTE:**

If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS		
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								IPDM E/R
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS				
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—	
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—	
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—	
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—	
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—	

Symptoms :

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Display control unit Translation Sheet: Rewrite the following names, and put a check mark on the above check sheet table.

Confirmation/Adjustment Display	Check sheet table Display	Confirmation/Adjustment Display	Check sheet table Display
CAN COMM	Initial diagnosis	CAN CIRC 5	METER/M&A
CAN CIRC 1	Transmit diagnosis	CAN CIRC 6	—
CAN CIRC 2	BCM	CAN CIRC 7	IPDM E/R
CAN CIRC 3	ECM	CAN CIRC 8	—
CAN CIRC 4	—	CAN CIRC 9	—

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR check sheet

PKIA8895E

# CAN SYSTEM (TYPE 10)

[CAN]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
TRANSMISSION  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
TRANSMISSION  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

PKIA8900E

## CHECK SHEET RESULTS (EXAMPLE)

### NOTE:


If a check mark is put on "NG" on "INITIAL DIAG (Initial diagnosis)", replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-254, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—
Display control unit	—	NG	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8930E



PKIA9082E

# CAN SYSTEM (TYPE 10)


[CAN]

## Case 2

Check harness between data link connector and ABS actuator and electric unit (control unit). Refer to [LAN-255, "Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit \(Control Unit\)"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8931E




PKIA9083E

### Case 3

Check ECM circuit. Refer to [LAN-256, "ECM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication	NG	UNKWN	—	—	—	UNKWN	UNKWN	—	—	—
Display control unit	—	NG	UNKWN	UNKWN ✓	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN ✓	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN ✓	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN ✓	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8932E



# CAN SYSTEM (TYPE 10)


[CAN]

## Case 4

Check TCM circuit. Refer to [LAN-256, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8933E



# CAN SYSTEM (TYPE 10)


[CAN]

## Case 5

Check display control unit circuit. Refer to [LAN-257, "Display Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8934E




## Case 6

Check data link connector circuit. Refer to [LAN-257, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8935E




## Case 7

Check BCM circuit. Refer to [LAN-258, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN ✓	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN ✓	UNKWN	—	UNKWN	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN ✓	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8936E




## Case 8

Check combination meter circuit. Refer to [LAN-258, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN ✓	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	—	UNKWN	—	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN ✓	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN ✓	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8937E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 10)


[CAN]

## Case 9

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-259, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	—	—	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8938E



PKIA9090E

# CAN SYSTEM (TYPE 10)


[CAN]

## Case 10

Check IPDM E/R circuit. Refer to [LAN-259, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8939E



## Case 11

Check CAN communication circuit. Refer to [LAN-260, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	CAN COMM CIRCUIT (U1000) ✓	CAN COMM CIRCUIT (U1001) ✓
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	—	—
Display control unit	—	NG	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	UNKWN ✓	—	UNKWN ✓	—	—
BCM	No indication ✓	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG ✓	UNKWN ✓	UNKWN ✓	UNKWN ✓	—	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—
IPDM E/R	No indication ✓	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000) ✓	—

PKIA8940E

**Case 12**

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-263, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	UNKWN	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8941E

**Case 13**

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-263, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								SELF-DIAG RESULTS	
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	BCM /SEC	METER /M&A	VDC/TCS /ABS	IPDM E/R		
ENGINE	—	NG	UNKWN	—	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	CAN COMM CIRCUIT (U1000)	CAN COMM CIRCUIT (U1001)
TRANSMISSION	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	UNKWN	—	CAN COMM CIRCUIT (U1000)	—
Display control unit	—	NG	UNKWN	UNKWN	—	UNKWN	UNKWN	—	UNKWN	—	—
BCM	No indication	NG	UNKWN	UNKWN	—	—	UNKWN	—	UNKWN	CAN COMM CIRCUIT (U1000)	—
ABS	—	NG	UNKWN	—	UNKWN	—	—	—	—	CAN COMM CIRCUIT (U1000)	—
IPDM E/R	No indication	—	UNKWN	UNKWN	—	UNKWN	—	—	—	CAN COMM CIRCUIT (U1000)	—

PKIA8942E

**Circuit Check Between TCM and Data Link Connector**

UKS001RB

**1. CHECK CONNECTOR**

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector F59
  - Harness connector M71

**OK or NG**

- OK >> GO TO 2.
- NG >> Repair terminal or connector.

## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector and harness connector F59.
2. Check continuity between TCM harness connector F56 terminals 3 (L), 4 (P) and harness connector F59 terminals 23 (L), 22 (P).


**3 (L) - 23 (L) : Continuity should exist.**

**4 (P) - 22 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



## 3. CHECK HARNESS FOR OPEN CIRCUIT

- Check continuity between harness connector M71 terminals 23 (L), 22 (P) and data link connector M22 terminals 6 (L), 14 (P).


**23 (L) - 6 (L) : Continuity should exist.**

**22 (P) - 14 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



## Circuit Check Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)

UKS001RC

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (connector side and harness side).
  - Harness connector M7
  - Harness connector E28

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect harness connector M7.
2. Check continuity between data link connector M22 terminals 6 (L), 14 (P) and harness connector M7 terminals 10 (L), 9 (P).


**6 (L) - 10 (L) : Continuity should exist.**

**14 (P) - 9 (P) : Continuity should exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair harness.



### 3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between harness connector E28 terminals 10 (L), 9 (P) and ABS actuator and electric unit (control unit) harness connector E125 terminals 30 (L), 29 (P).


**10 (L) - 30 (L) : Continuity should exist.**

**9 (P) - 29 (P) : Continuity should exist.**

OK or NG

OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).

NG >> Repair harness.



UKS001RD

## ECM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ECM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.

### 2. CHECK HARNESS FOR OPEN CIRCUIT


1. Disconnect ECM connector.
2. Check resistance between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Approx. 108 - 132Ω**

OK or NG

OK >> Replace ECM.

NG >> Repair harness between harness connector F59 and ECM.



UKS001RE

## TCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of TCM for damage, bend and loose connection (control module side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect TCM connector.
2. Check resistance between TCM harness connector F56 terminals 3 (L) and 4 (P).

**3 (L) - 4 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace TCM.  
 NG >> Repair harness between harness connector F59 and TCM.



UKS001RI

## Display Control Unit Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of display control unit for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect display control unit connector.
2. Check resistance between display control unit harness connector M95 terminals 25 (L) and 26 (P).

**25 (L) - 26 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace display control unit.  
 NG >> Repair harness between data link connector and display control unit.



UKS001RF

## Data Link Connector Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of data link connector for damage, bend and loose connection (connector side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Connect all the connectors and diagnose again. Refer to [LAN-6, "TROUBLE DIAGNOSES WORK FLOW"](#).
- NG >> Repair harness between data link connector and combination meter.



UKS001RH

## BCM Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of BCM for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check resistance between BCM harness connector M18 terminals 39 (L) and 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace BCM. Refer to [BCS-20, "Removal and Installation of BCM"](#).
- NG >> Repair harness between data link connector and BCM.



UKS001RG

## Combination Meter Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of combination meter for damage, bend and loose connection (meter side and harness side).

### OK or NG

- OK >> GO TO 2.
- NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect combination meter connector.
2. Check resistance between combination meter harness connector M24 terminals 26 (L) and 27 (P).

**26 (L) - 27 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between data link connector and combination meter.



## ABS Actuator and Electric Unit (Control Unit) Circuit Check

UKS001RJ

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of ABS actuator and electric unit (control unit) for damage, bend and loose connection (control unit side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check resistance between ABS actuator and electric unit (control unit) harness connector E125 terminals 30 (L) and 29 (P).

**30 (L) - 29 (P) : Approx. 54 - 66Ω**

### OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between harness connector E28 and ABS actuator and electric unit (control unit).



## IPDM E/R Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check terminals and connector of IPDM E/R for damage, bend and loose connection (control module side and harness side).

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check resistance between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132Ω**

### OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between harness connector E28 and IPDM E/R.



UKS001RL

## CAN Communication Circuit Check

### 1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Check following terminals and connectors for damage, bend and loose connection (control module side, control unit side, meter side, and harness side).
  - ECM
  - TCM
  - Display control unit
  - BCM
  - Combination meter
  - ABS actuator and electric unit (control unit)
  - IPDM E/R
  - Between ECM and IPDM E/R

### OK or NG

- OK >> GO TO 2.  
 NG >> Repair terminal or connector.


## 2. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.
  - ECM connector
  - TCM connector
  - Harness connector F59
2. Check continuity between ECM harness connector F54 terminals 94 (L) and 86 (P).

**94 (L) - 86 (P) : Continuity should not exist.**

### OK or NG

- OK >> GO TO 3.  
 NG >> Check the following harnesses. If any harness is damaged, repair the harness.
  - Harness between ECM and harness connector F59
  - Harness between TCM and harness connector F59



### 3. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between ECM harness connector F54 terminals 94 (L), 86 (P) and ground.

**94 (L) - Ground : Continuity should not exist.**


**86 (P) - Ground : Continuity should not exist.**

#### OK or NG

OK >> GO TO 4.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between ECM and harness connector F59
- Harness between TCM and harness connector F59



### 4. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect following connectors.

- Display control unit connector
- BCM connector
- Combination meter connector
- Harness connector M7

2. Check continuity between data link connector M22 terminals 6 (L) and 14 (P).


**6 (L) - 14 (P) : Continuity should not exist.**

#### OK or NG

OK >> GO TO 5.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and Display control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



## 5. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**


**14 (P) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 6.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between data link connector and harness connector M71
- Harness between data link connector and Display control unit
- Harness between data link connector and BCM
- Harness between data link connector and combination meter
- Harness between data link connector and harness connector M7



## 6. CHECK HARNESS FOR SHORT CIRCUIT

1. Disconnect ABS actuator and electric unit (control unit) connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector E121 terminals 48 (L) and 49 (P).


**48 (L) - 49 (P) : Continuity should not exist.**

### OK or NG

OK >> GO TO 7.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E28 and ABS actuator and electric unit (control unit)
- Harness between harness connector E28 and IPDM E/R



## 7. CHECK HARNESS FOR SHORT CIRCUIT

Check continuity between IPDM E/R harness connector E121 terminals 48 (L), 49 (P) and ground.

**48 (L) - Ground : Continuity should not exist.**


**49 (P) - Ground : Continuity should not exist.**

### OK or NG

OK >> GO TO 8.

NG >> Check the following harnesses. If any harness is damaged, repair the harness.

- Harness between harness connector E28 and ABS actuator and electric unit (control unit)
- Harness between harness connector E28 and IPDM E/R




**8. ECM/IPDM E/R INTERNAL CIRCUIT INSPECTION**

1. Remove ECM and IPDM E/R from vehicle.
2. Check resistance between ECM terminals 94 and 86.
3. Check resistance between IPDM E/R terminals 48 and 49.

Unit	Terminal	Resistance value ( $\Omega$ ) (Approx.)
ECM	94 - 86	108 - 132
IPDM E/R	48 - 49	

**OK or NG**

- OK >> GO TO 9.  
 NG >> Replace ECM and/or IPDM E/R.

**9. CHECK SYMPTOM**

1. Fill in described symptoms on the column "Symptom" in the check sheet.
2. Connect all connectors, and then make sure that the symptom is reproduced.

**OK or NG**

- OK >> GO TO 10.  
 NG >> Refer to [LAN-14, "Example of Filling in Check Sheet When Initial Conditions Are Not Reproduced"](#)

**10. UNIT REPRODUCIBILITY INSPECTION**

Perform the following procedure for each unit, and then perform reproducibility test.

1. Turn ignition switch OFF.
2. Disconnect battery cable at negative terminal.
3. Disconnect the unit connector.
4. Connect battery cable at negative terminal.
5. Make sure that the symptom filled in the "Symptom" of the check sheet is reproduced. (Do not confuse it with the symptom related to removed unit.)
6. Make sure that the same symptom is reproduced.
  - TCM
  - Display control unit
  - BCM
  - Combination meter
  - ABS actuator and electric unit (control unit)
  - ECM
  - IPDM E/R

**Inspection results**

- Reproduced>>Install removed unit, and then check the other unit.  
 Not reproduced>>Replace removed unit.

**IPDM E/R Ignition Relay Circuit Check**

UKS001RM

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-25, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

