

A
B
MT
D
E
F
G
H
I
J
K
L
M

SECTION **MT**

MANUAL TRANSAXLE

CONTENTS

RS5F51A	
PRECAUTIONS	4
Caution	4
PREPARATION	5
Special Service Tools	5
Commercial Service Tools	7
NOISE, VIBRATION, AND HARSHNESS (NVH)	
TROUBLESHOOTING	8
NVH Troubleshooting Chart	8
DESCRIPTION	9
Cross-sectional View	9
DOUBLE-CONE SYNCHRONIZER	10
TRIPLE-CONE SYNCHRONIZER	10
REVERSE GEAR	10
M/T OIL	11
Replacement	11
DRAINING	11
FILLING	11
Checking	11
OIL LEAKAGE AND OIL LEVEL	11
SIDE OIL SEAL	12
Removal and Installation	12
REMOVAL	12
INSTALLATION	12
POSITION SWITCH	13
Removal and Installation	13
Checking	13
BACK-UP LAMP SWITCH	13
PARK/NEUTRAL POSITION SWITCH	13
CONTROL LINKAGE	14
Removal and Installation	14
Cable Adjustment	15
AIR BREATHER HOSE	16
Removal and Installation	16
TRANSAXLE ASSEMBLY	17
Removal and Installation	17
REMOVAL	17
INSTALLATION	19
Component Parts	20
CASE AND HOUSING COMPONENTS	20
GEAR COMPONENTS	21
SHIFT CONTROL COMPONENTS	23
FINAL DRIVE COMPONENTS	24
Disassembly and Assembly	24
DISASSEMBLY	24
ASSEMBLY	28
Adjustment	34
INPUT SHAFT END PLAY	34
DIFFERENTIAL SIDE BEARING PRELOAD	35
MAINSHAFT END PLAY	36
REVERSE IDLER GEAR END PLAY	37
INPUT SHAFT AND GEARS	39
Disassembly and Assembly	39
DISASSEMBLY	39
INSPECTION AFTER DISASSEMBLY	40
ASSEMBLY	42
MAINSHAFT AND GEARS	47
Disassembly and Assembly	47
DISASSEMBLY	47
INSPECTION AFTER DISASSEMBLY	48
ASSEMBLY	51
REVERSE IDLER SHAFT AND GEARS	56
Disassembly and Assembly	56
DISASSEMBLY	56
INSPECTION AFTER DISASSEMBLY	56
ASSEMBLY	57
FINAL DRIVE	58
Disassembly and Assembly	58
PRE-INSPECTION	58
DISASSEMBLY	58
INSPECTION AFTER DISASSEMBLY	59
ASSEMBLY	59
SHIFT CONTROL	62
Inspection	62
SHIFT FORK	62
SERVICE DATA AND SPECIFICATIONS (SDS)	63
General Specifications	63
TRANSAXLE	63
FINAL GEAR	64
Gear End Play	64

REVERSE IDLER GEAR ADJUSTING SHIM ..	132	SHIM(S)	132
6TH MAIN GEAR ADJUSTING SHIM	132		
Available Shims	132		
BEARING PRELOAD	132		
DIFFERENTIAL SIDE BEARING ADJUSTING			

A

B

MT

D

E

F

G

H

I

J

K

L

M

PRECAUTIONS

PFP:00001

Caution





ECS0093X

- Do not reuse transaxle oil, properly dispose of it after it has been drained out.
- Check the oil level or replace the oil only with the vehicle parked on level ground.
- During removal or installation, keep inside of transaxle clear of dust or dirt.
- Check for the correct installation status prior to removal or disassembly. If mating marks are required, be certain they do not interfere with the function of the parts when applied.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, use it.
- Be careful not to damage sliding surfaces and mating surfaces.

PREPARATION

Special Service Tools








The actual shapes of Kent-Moore tools may differ from those of special tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV381054S0 (J-34286) Puller  <p style="text-align: right;">ZZA0601D</p>	<ul style="list-style-type: none"> ● Removing side bearing outer race ● Removing mainshaft front bearing
ST35321000 (—) Drift  <p style="text-align: right;">ZZA1000D</p>	<ul style="list-style-type: none"> ● Installing input shaft oil seal ● Installing reverse main gear ● Installing 1st bushing ● Installing 1st-2nd synchronizer hub ● Installing 2nd bushing ● Installing 3rd main gear <p>a: 49 mm (1.93 in) dia. b: 41 mm (1.61 in) dia.</p>
ST30720000 (J-25405) Drift  <p style="text-align: right;">ZZA0811D</p>	<ul style="list-style-type: none"> ● Installing differential oil seal ● Installing differential side bearing outer race ● Installing mainshaft rear bearing ● Installing differential side bearing <p>a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.</p>
ST33200000 (J-26082) Drift  <p style="text-align: right;">ZZA1002D</p>	<ul style="list-style-type: none"> ● Installing mainshaft front bearing ● Installing 4th main gear ● Installing 5th main gear <p>a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.</p>
ST33061000 (J-8107-2) Drift  <p style="text-align: right;">ZZA1000D</p>	<ul style="list-style-type: none"> ● Installing bore plug ● Removing differential side bearing <p>a: 38 mm (1.50 in) dia. b: 28.5 mm (1.122 in) dia.</p>
ST33052000 (—) Drift  <p style="text-align: right;">ZZA1023D</p>	<ul style="list-style-type: none"> ● Installing welch plug ● Removing input shaft rear bearing ● Removing input shaft bearing spacer and 5th stopper ● Removing 5th bushing, thrust washer, 4th input gear, 4th gear bushing, 3rd-4th synchronizer hub and 3rd input gear ● Installing input shaft front bearing ● Removing mainshaft rear bearing ● Removing 4th main gear and 5th main gear <p>a: 22 mm (0.87 in) dia. b: 28 mm (1.10 in) dia.</p>

A
B
MT
D
E
F
G
H
I
J
K
L
M



PREPARATION

[RS5F51A]

Tool number (Kent-Moore No.) Tool name	Description
KV40105020 (—) Drift	 <p style="text-align: right; margin-right: 20px;">ZZA1133D</p> <ul style="list-style-type: none"> ● Removing 5th input gear and synchronizer hub ● Removing 3rd main gear, 2nd main gear, 2nd bushing, 1st-2nd synchronizer hub, 1st main gear, reverse main gear and 1st bushing <p> a: 39.7 mm (1.563 in) dia. b: 35 mm (1.38 in) dia. c: 15 mm (0.59 in). </p>
KV40105710 (—) Press stand	 <p style="text-align: right; margin-right: 20px;">ZZA1058D</p> <ul style="list-style-type: none"> ● Installing 3rd-4th synchronizer hub ● Installing 4th bushing ● Installing 5th bushing ● Installing 5th synchronizer hub ● Installing 2nd bushing ● Installing 3rd main gear <p> a: 46 mm (1.81 in) dia. b: 41 mm (1.61 in). </p>
ST38220000 (—) Press stand	 <p style="text-align: right; margin-right: 20px;">ZZA1058D</p> <ul style="list-style-type: none"> ● Installing reverse main gear ● Installing 1st bushing ● Installing 1st-2nd synchronizer hub <p> a: 63 mm (2.48 in) dia. b: 65 mm (2.56 in). </p>
ST30032000 (J-26010-01) Drift	 <p style="text-align: right; margin-right: 20px;">ZZA0978D</p> <ul style="list-style-type: none"> ● Installing 5th stopper and input shaft bearing spacer ● Installing input shaft front bearing <p> a: 80 mm (3.15 in) dia. b: 38 mm (1.50 in) dia. c: 31 mm (1.22 in) dia. </p>
ST30901000 (J-26010-01) Drift	 <p style="text-align: right; margin-right: 20px;">ZZA0978D</p> <ul style="list-style-type: none"> ● Installing input shaft rear bearing ● Installing 4th main gear ● Installing 5th main gear ● Installing mainshaft rear bearing <p> a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35.2 mm (1.386 in) dia. </p>
ST30031000 (J-22912-01) Puller	 <p style="text-align: right; margin-right: 20px;">ZZA0537D</p> <p>Measuring wear of 1st and 2nd baulk ring</p>
KV40101630 (J-35870) Drift	 <p style="text-align: right; margin-right: 20px;">ZZA1003D</p> <p>Installing reverse main gear</p> <p> a: 68 mm (2.68 in) dia. b: 60 mm (2.36 in) dia. </p>

PREPARATION




[RS5F51A]

Tool number (Kent-Moore No.) Tool name	Description
KV38102510 (—) Drift	 <p>ZZA0838D</p> <ul style="list-style-type: none"> ● Installing 1st bushing ● Installing 1st-2nd synchronizer hub ● Installing differential side bearing <p>a: 71 mm (2.80 in) dia. b: 65 mm (2.56 in) dia.</p>
— (J-39713) Preload adapter	 <p>NT087</p> <p>Checking differential side gear end play</p>

A
B
MT

Commercial Service Tools

ECS0093Z

Tool name	Description
Puller	 <p>ZZB0823D</p> <p>Removing each bearing gear and bushing</p>
Puller	 <p>NT077</p> <p>Removing each bearing gear and bushing</p>
Pin punch	 <p>ZZA0815D</p> <p>Removing and installing each retaining pin Tip diameter: 4.5 mm (0.177 in) dia.</p>
Power tool	 <p>PBIC0190E</p> <p>Loosening bolts and nuts</p>

F
G
H
I
J
K
L
M

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

[RS5F51A]

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

NVH Troubleshooting Chart

ECS00940

Use the chart below to help you find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.


Symptoms		Suspected Parts (Possible cause)												
		(Oil level is low.)	(Wrong oil)	(Oil level is high.)	Gasket (Damaged)	Oil Seal (Worn or damaged)	O-Ring (Worn or damaged)	Shift Control Linkage (Worn)	Check Plug Return Spring and Check Ball (Worn or damaged)	Shift Fork (Worn)	Gear (Worn or damaged)	Bearing (Worn or damaged)	Baulk Ring (Worn or damaged)	Insert Spring (Damaged)
Reference page		MA-28. "Checking M/T Oil"	GI-45. "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"	MA-28. "Checking M/T Oil"	MT-11	MT-11	MT-11	MT-14	MT-40	MT-62	MT-40	MT-40	MT-40	MT-62
	Noise	1	2							3	3			
	Oil leakage		3	1	2	2								
	Hard to shift or will not shift		1	1				2				3	3	
	Jumps out of gear						1	2	3	3				

DESCRIPTION

PFP:00000

Cross-sectional View

ECS00941



WCIA0342E


A
B
MT
D
E
F
G
H
I
J
K
L
M

DOUBLE-CONE SYNCHRONIZER

Double-cone synchronizer is adopted for 1st and 3rd gears to reduce operating force of the shift lever.


TRIPLE-CONE SYNCHRONIZER

Triple cone synchronizer is adopted for 2nd gear to reduce operating force of the shift lever.



REVERSE GEAR

See figure for description of reverse gear components.



M/T OIL**Replacement
DRAINING**

1. Start the engine and let it run to warm up the transaxle oil.
2. Stop the engine. Remove drain plug and drain oil.
3. Set a gasket on the drain plug and install it in transaxle case.

Drain plug : 30 - 39 N·m (3.1 - 4.0 kg·m, 23 - 28 ft·lb)

CAUTION:

Do not reuse gasket.

FILLING

1. Remove speedometer pinion gear. Fill the transaxle with new oil.

Oil grade and capacity : Refer to MA-12, "Fluids and Lubricants" .

2. After refilling oil, check oil level. Set a new O-ring on the speedometer pinion gear, then install it in transaxle case.

Speedometer pinion gear : 4.9 - 6.8 N·m (0.5 - 0.7 kg·m, 43 - 61 in·lb)

CAUTION:

Do not reuse O-ring.


**Checking
OIL LEAKAGE AND OIL LEVEL**

- Check that oil is not leaking from transaxle.
- Remove speedometer pinion gear.
- Measure oil level using suitable gauge as shown, and check if "L" is within the specifications.

Oil level "L" : 49 - 55 mm (1.93 - 2.17 in)

CAUTION:

Never start engine while checking oil level.



- Set a new O-ring on the speedometer pinion gear, then install it in transaxle case.

Speedometer pinion gear : 4.9 - 6.8 N·m (0.5 - 0.7 kg·m, 43 - 61 in·lb)

CAUTION:

Do not reuse O-ring.

SIDE OIL SEAL


Removal and Installation

REMOVAL

1. Remove the drive shaft from the transaxle case. Refer to [FAX-11, "Removal and Installation"](#) .
2. Remove the oil seal using suitable tool.

CAUTION:

Be careful not to damage the transaxle case surface when removing the oil seal.



INSTALLATION

Installation is in the reverse order of removal.


- Using Tool, drive the oil seal straight in until it protrudes from the transaxle case end equal to dimension "A" as shown.

Dimension "A" : Within 0.5 mm (0.02 in) flush with case.

Tool number : ST30720000 (J-25405)

CAUTION:

- Before installing oil seals, apply multi-purpose grease to oil seal lips.
 - Do not reuse oil seals.
- Check the transaxle oil level after installation. Refer to [MT-11, "Checking"](#) .



POSITION SWITCH

Removal and Installation

Refer to [MT-20, "CASE AND HOUSING COMPONENTS"](#) .

Checking BACK-UP LAMP SWITCH


- Check continuity.

Gear position	Continuity
Reverse	Yes
Except reverse	No

PARK/NEUTRAL POSITION SWITCH

- Check continuity.

Gear position	Continuity
Neutral	Yes
Except neutral	No




A
B
MT
D
E
F
G
H
I
J
K
L
M

CONTROL LINKAGE

PF3:34103

Removal and Installation

ECS00947



WCIA0203E

- 1. Snap pin
- 2. Washer
- 3. Cable
- 4. Manual lever
- 5. Shift cable
- 6. Lock plate
- 7. Control device assembly
- 8. Lock plate
- 9. Select cable
- 10. Shift cable
- 11. Control lever knob
- 12. Control lever

- | | | |
|-----------------------------|--------------------|----------------------------|
| 13. Control device assembly | 14. Cover plate | 15. Select cable |
| 16. Floor pan | 17. Control lever | 18. Shift cable |
| 19. Washer | 20. Clutch housing | 21. Cable mounting bracket |
| 22. Select cable | 23. Shift cable | 24. Lock plate |
| 25. Lock plate | | |

CAUTION:

- Note that the select side lock plate for securing the control cable is different from the one on the shift side.
- After assembly, make sure selector lever automatically returns to Neutral when it is moved to 1st, 2nd, or Reverse.


Cable Adjustment

ECS00948

NOTE:

After installation of the select cable, the cable must be adjusted for proper operation. This adjustment is performed before installing the interior console and shift boot.

1. Slide clip "B" from under clip "A" as shown.




2. Shift the control lever to the neutral position.


CAUTION:

Do not move the control lever when adjusting the cables.

3. Push clip "A" into the cable end case until it snaps into place as shown.



4. Slide clip "B" back over clip "A" until it snaps into place and holds clip "A" in place as shown.




A
B
MT
D
E
F
G
H
I
J
K
L
M


AIR BREATHER HOSE Removal and Installation

Refer to the figure for air breather hose removal and installation information.

QR25DE Engine



VQ35DE Engine



CAUTION:


- Make sure there are no pinched or restricted areas on the air breather hose caused by bending or twisting when installing it.
- Be sure to insert hose into the transaxle tube until overlap area reaches the spool.

TRANSAXLE ASSEMBLY

PF3:32010

Removal and Installation

ECS0094A



REMOVAL

1. Remove the air cleaner and air duct. Refer to [EM-17, "Removal and Installation"](#) (QR25DE), [EM-120, "Removal and Installation"](#) (VQ35DE).
2. Remove the battery tray and battery.
3. Remove air breather hose from the transaxle.
4. Remove the clutch operating cylinder and position it aside without disconnecting the hydraulic lines. Refer to [CL-11, "Removal and Installation"](#).

CAUTION:



Do not depress clutch pedal during removal procedure.

5. Remove the two shift cables from the transaxle. Refer to [MT-14, "Removal and Installation"](#).
6. Disconnect and remove the harnesses for the back-up lamp switch and ground straps.
7. Remove the starter motor using power tool. Refer to [SC-17, "Removal and Installation"](#).
8. Raise vehicle and remove the engine undercover and splash shields using power tool.
9. Drain the gear oil from the transaxle. Refer to [MT-11, "Replacement"](#).
10. Disconnect and remove the harnesses for:
 - Vehicle speed sensor
 - PNP switch
 - Crankshaft position sensor
11. Remove the bolt and heated oxygen sensor harness clamp bracket, then remove the crankshaft position sensor.
12. Remove the exhaust front tube using power tool. Refer to [EX-4, "Removal and Installation"](#) (QR25DE) or [EX-7, "Removal and Installation"](#) (VQ35DE).
13. Remove the drive shafts using power tool. Refer to [FAX-11, "Removal and Installation"](#).


TRANSAXLE ASSEMBLY

[RS5F51A]

- Lower vehicle, then install a suitable engine slinger on the front of the left bank cylinder head, and on the rear of the right bank cylinder head as shown.



- Support the engine using an engine support fixture or suitable tool.
- Remove the five upper bolts that mount the transaxle to the engine using power tool.
- Disconnect the LH transaxle mounting insulator using power tool.
- Raise vehicle, then remove front suspension member, LH engine insulator, and LH engine mount bracket. Refer to [EM-71, "Removal and Installation"](#) (QR25DE), [EM-219, "Removal and Installation"](#) (VQ35DE).
- Place a suitable jack support under the transaxle.



CAUTION:

When setting the jack, be careful not to bring it into contact with the switches.

- Remove the five lower bolts that mount the transaxle to the engine using power tool.
- Remove the transaxle from the vehicle.

INSTALLATION

Installation is in the reverse order of removal.


- When installing the transaxle to the engine, use the specified tightening torque in the numerical sequence shown below:

CAUTION:

When installing the transaxle, do not allow the transaxle input shaft to make contact with the clutch cover.


QR engine models:

Bolt No.	1	2	3	4	5	6	7	8	9	10
Bolt length "ℓ" mm (in)	40 (1.57)	82 (3.23)	47 (1.85)	47 (1.85)	52 (2.05)	40 (1.57)	40 (1.57)	40 (1.57)	30 (1.18)	30 (1.18)
Tightening torque N·m (kg·m, ft·lb)	30 - 40 (3.1 - 4.1, 22 - 29)		70 - 80 (7.1 - 8.1, 52 - 59)			30 - 40 (3.1 - 4.1, 22 - 29)				



VQ engine models:

Bolt No.	1	2	3	4	5	6	7	8	9	10
Bolt length "ℓ" mm (in)	52 (2.05)	113 (4.45)	113 (4.45)	52 (2.05)	52 (2.05)	52 (2.05)	40 (1.57)	40 (1.57)	40 (1.57)	40 (1.57)
Tightening torque N·m (kg·m, ft·lb)	70 - 80 (7.1 - 8.1, 52 - 59)					30 - 40 (3.1 - 4.1, 22 - 29)				



- After installation, check oil level, and look for leaks and loose mechanisms.


A
B
MT
D
E
F
G
H
I
J
K
L
M

TRANSAXLE ASSEMBLY

[RS5F51A]


ECS0094B

Component Parts CASE AND HOUSING COMPONENTS



- | | | |
|--------------------------|---------------------------|----------------------------------|
| 1. Differential oil seal | 2. Ball pin | 3. Washer |
| 4. Back-up lamp switch | 5. Oil gutter | 6. Baffle plate |
| 7. Transaxle case | 8. Filler plug | 9. Gasket |
| 10. Welch plug | 11. Bore plug | 12. Drain plug |
| 13. Gasket | 14. Differential oil seal | 15. Park/Neutral position switch |
| 16. Air breather tube | 17. Input shaft oil seal | 18. Oil channel |
| 19. Magnet | 20. Clutch housing | 21. Speedometer pinion gear |
| 22. O-ring | | |

GEAR COMPONENTS




A
B
MT
D
E
F
G
H
I
J
K
L
M

- | | | |
|---------------------------------|---|---------------------------------------|
| 1. Input shaft front bearing | 2. Input shaft | 3. Needle bearing |
| 4. 3rd input gear | 5. 3rd inner baulk ring | 6. 3rd gear synchronizer cone |
| 7. 3rd outer baulk ring | 8. Spread spring | 9. 3rd and 4th synchronizer hub |
| 10. 3rd and 4th shifting insert | 11. 4th baulk ring | 12. 3rd and 4th coupling sleeve |
| 13. Bushing | 14. Needle bearing | 15. 4th input gear |
| 16. Thrust washer | 17. Bushing | 18. Needle bearing |
| 19. 5th input gear | 20. 5th baulk ring | 21. 5th shifting insert |
| 22. 5th synchronizer hub | 23. 5th coupling sleeve | 24. 5th stopper |
| 25. Input shaft bearing spacer | 26. Snap ring | 27. Input shaft rear bearing |
| 28. Oil channel | 29. Input shaft rear bearing adjusting shim | 30. Lock pin |
| 31. Reverse idler shaft | 32. Thrust needle bearing | 33. Needle bearing |
| 34. Reverse idler gear (front) | 35. Reverse baulk ring | 36. Reverse coupling sleeve |
| 37. Insert spring | 38. Reverse idler gear (rear) | 39. Reverse idler gear adjusting shim |
| | 3rd gear synchronizer cone | 3rd outer baulk ring |

TRANSAXLE ASSEMBLY

[RS5F51A]

SEC. 322




SCIA0386E

- | | | |
|--------------------------------|---|--------------------------------|
| 1. Mainshaft front bearing | 2. Mainshaft bearing retainer | 3. Mainshaft |
| 4. Reverse main gear | 5. 1st main gear | 6. Bushing |
| 7. Needle bearing | 8. 1st inner baulk ring | 9. 1st gear synchronizer cone |
| 10. 1st outer baulk ring | 11. Spread spring | 12. 1st & 2nd shifting insert |
| 13. 1st & 2nd synchronizer hub | 14. 2nd outer baulk ring | 15. 2nd gear synchronizer cone |
| 16. 2nd inner baulk ring | 17. 1st & 2nd coupling sleeve | 18. Bushing |
| 19. Needle bearing | 20. 2nd main gear | 21. 3rd main gear |
| 22. 3rd & 4th mainshaft spacer | 23. 4th main adjusting shim | 24. 4th main gear |
| 25. 5th main gear | 26. Snap ring | 27. Mainshaft rear bearing |
| 28. Mainshaft C-ring | 29. C-ring holder | 30. Snap ring |
| 31. Snap ring | 32. Mainshaft rear bearing adjusting shim | |

SHIFT CONTROL COMPONENTS


SEC. 328



WCIA0260E

- | | | |
|----------------------------|----------------------------|------------------------------|
| 1. Stopper ring | 2. 5th & reverse bracket | 3. Reverse lever assembly |
| 4. Shifter cap | 5. Reverse shift fork | 6. Reverse fork rod |
| 7. Check plug | 8. Check spring | 9. Shift check sleeve |
| 10. Check ball | 11. 3rd & 4th fork rod | 12. 5th and reverse fork rod |
| 13. 5th shift fork | 14. Retaining pin | 15. Stopper bolt |
| 16. Shift check | 17. Control rod assembly | 18. O-ring |
| 19. 1st and 2nd fork rod | 20. Interlock pin | 21. 1st and 2nd bracket |
| 22. 1st and 2nd shift fork | 23. 3rd and 4th shift fork | 24. 3rd and 4th bracket |

FINAL DRIVE COMPONENTS




- | | | |
|---|---|------------------------------|
| 1. Differential side bearing outer race | 2. Differential side bearing | 3. Speedometer drive gear |
| 4. Differential case | 5. Final gear | 6. Differential side bearing |
| 7. Differential side bearing outer race | 8. Differential side bearing adjusting shim | 9. Pinion mate shaft |
| 10. Side gear | 11. Side gear thrust washer | 12. Pinion mate gear |
| 13. Pinion mate gear washer | 14. Retaining pin | |

Disassembly and Assembly

DISASSEMBLY

ECS0094C

1. Remove drain plug and filler plug.
2. Remove park/neutral position switch and back-up lamp switch.




3. After removing shift check and stopper bolt, remove control assembly.


TRANSAXLE ASSEMBLY

[RS5F51A]

4. Remove check plugs (3 pieces), check springs (3 pieces), check balls (3 pieces) and shift check sleeve (1 piece).



5. Remove transaxle case bolts.




6. Remove the bore plug.

CAUTION:


Be careful not to damage transaxle case.

7. While spreading the snap ring of mainshaft rear bearing located at bore plug hole, remove transaxle case.
8. Remove the oil gutter and baffle plate.
9. Remove snap ring, mainshaft rear bearing adjusting shim and input shaft rear bearing adjusting shim from transaxle case.
10. Remove differential side bearing outer race (transaxle case side) and then adjust shim.

Tool number : **KV381054S0 (J-34286)**



11. Remove welch plug.




A
B
MT
D
E
F
G
H
I
J
K
L
M

TRANSAXLE ASSEMBLY

[RS5F51A]

12. Remove differential oil seal.




13. Remove magnet from clutch housing.

14. With shift lever in 5th position, remove bracket bolts from reverse lever assembly. Lift reverse lever assembly to remove.


CAUTION:

Be careful not to lose shifter cap.




15. Pull out reverse fork rod then remove reverse shift fork.

16. Shift 3rd & 4th fork rod to 3rd position. Remove retaining pin of 5th shift fork using pin punch.



17. Remove stopper rings for 5th & reverse bracket.




18. Pull out 5th & reverse fork rod and remove 5th shift fork and 5th & reverse bracket.

19. Remove check balls (2 pieces) and interlock pin.


TRANSAXLE ASSEMBLY

[RS5F51A]

20. Remove retaining pin of 3rd & 4th bracket using pin punch.



21. Remove stopper rings for 3rd & 4th shift fork.
22. Pull out 3rd & 4th fork rod and remove 3rd & 4th shift fork and bracket.
23. Remove shift check sleeve from clutch housing.
24. Remove retaining pin of 1st & 2nd shift fork using pin punch.




25. Pull out 1st & 2nd with bracket.
26. Remove 1st & 2nd shift fork.
27. Remove retaining pin of 1st & 2nd bracket using pin punch and separate 1st & 2nd fork rod and bracket.
28. Remove gear components from clutch housing in the following procedure.

- a. While tapping input shaft with plastic hammer, remove input shaft assembly, mainshaft assembly and reverse idler gear assembly as a set.

CAUTION:


Always withdraw mainshaft straight out. Failure to do so can damage resin oil channel on clutch housing side.



- b. Remove final drive assembly.
29. Remove the mainshaft bearing retainer and then the mainshaft front bearing.

Tool number

:KV381054S0 (J-34286)




30. Remove the oil channel on the mainshaft side.
31. Remove the differential oil seal (clutch housing side).

TRANSAXLE ASSEMBLY

[RS5F51A]


32. Remove differential side bearing outer race (clutch housing side).

Tool number : KV381054S0 (J-34286)



33. Remove input shaft oil seal.


CAUTION:
Be careful not to damage clutch housing.



ASSEMBLY

1. Using a drift, install a new input shaft oil seal from the clutch housing end of side to the depth of 1.8 - 2.8 mm (0.071 - 0.110 in).


CAUTION:
Oil seals are not reusable.



2. Using a drift, install a new differential oil seal.


CAUTION:
Oil seals are not reusable.

Tool number : ST30720000 (J-25405)



3. Install oil channel on mainshaft side as shown.

CAUTION:
Use the correct orientation for installation as shown.



TRANSAXLE ASSEMBLY


[RS5F51A]

4. Using a drift, install mainshaft front bearing.

CAUTION:

Use the correct orientation for installation as shown.


Tool number : **ST3320000 (J-26082)**



5. Install bearing retainer.


CAUTION:

Install with the punched surface facing up.




6. Install differential side bearing outer race.

Tool number : **ST30720000 (J-25405)**




7. Install final drive assembly into clutch housing.



8. Install input shaft assembly, mainshaft assembly, and reverse idler gear assembly into clutch housing.

CAUTION:

Be sure not to damage input shaft oil seal.



A
B
MT

D
E
F
G

H
I
J
K

L
M


TRANSAXLE ASSEMBLY

[RS5F51A]

9. Install 1st-2nd fork rod bracket onto 1st-2nd fork rod, and then install retaining pin.

CAUTION:


Retaining pins are not reusable. Never reuse them.



10. Install 1st-2nd fork rod and 1st-2nd shift fork, and then install retaining pin.


CAUTION:

Retaining pins are not reusable. Never reuse them.



11. Install shift check sleeve.

12. Install 3rd-4th bracket, 3rd-4th shift fork, and 3rd-4th fork rod with interlock pin.



13. Install stopper ring onto 3rd-4th shift fork.

CAUTION:

Stopper rings are not reusable. Never reuse them.


14. Install retaining pin onto 3rd-4th bracket.

CAUTION:

Retaining pins are not reusable. Never reuse them.

15. Install 2 check balls.

16. Install 5th-reverse bracket, 5th shift fork, and 5th-reverse fork rod.



17. Install stopper ring onto 5th-reverse bracket.


CAUTION:

Stopper rings are not reusable. Never reuse them.

18. Install retaining pin onto 5th shift fork.

CAUTION:

Retaining pins are not reusable. Never reuse them.




19. Install reverse shift fork and reverse fork rod.
20. Install reverse lever assembly following procedures below.
 - a. Install shifter cap onto reverse lever assembly cam, and then install them onto reverse shift fork.

CAUTION:


Do not drop shifter cap.

- b. While lifting reverse shift fork, align cam with 5th-reverse bracket.



- c. Tighten mounting bolts to specified torque, and then install reverse lever assembly.

Bracket bolts : 11.8 – 15.6 N·m (1.2 – 1.5 kg·m, 9 – 11 ft·lb)



21. Install the magnet onto clutch housing.
22. Install the selected input shaft adjusting shim onto the input shaft.
 - For selection of adjusting shims, refer to [MT-66, "Available Adjusting Shims"](#) .
23. Install selected differential side bearing adjusting shim and differential side bearing outer race. For selection adjusting shim, refer to [MT-35, "DIFFERENTIAL SIDE BEARING PRELOAD"](#) .
24. Install baffle plate and oil gutter.
25. Install transaxle case using the following procedure:
 - a. Install selected mainshaft rear bearing adjusting shim into transaxle case.
 - For selection of adjusting shims, refer to [MT-66, "Available Adjusting Shims"](#) .
 - b. Temporarily install a new snap ring of mainshaft rear bearing into transaxle case.

CAUTION:

Do not reuse the snap ring.

A
B
MT
D
E
F
G
H
I
J
K
L
M


TRANSAXLE ASSEMBLY

[RS5F51A]


- c. Apply Genuine Silicone RTV or equivalent to mating surfaces of transaxle case and clutch housing. Refer to [GI-45, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#).

CAUTION:


Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.



- d. With snap ring of mainshaft rear bearing temporarily installed, place transaxle case over clutch housing.



- e. Through bore plug mounting hole, with snap ring stretched, lift up mainshaft assembly from the control assembly mounting hole.



- f. Securely install snap ring onto mainshaft rear bearing.

TRANSAXLE ASSEMBLY

[RS5F51A]


- g. Tighten the bolts "A" and the new bolts "B".

Bolt "A" : 50.0 - 53.9 N·m (5.1 - 5.4 kg·m, 37 - 39 ft·lb)

Bolt "B" : 63.0 - 66.9 N·m (6.5 - 6.8 kg·m, 47 - 49 ft·lb)

CAUTION:

Always replace bolts "B" because they are self-sealing bolts.



- h. Apply gear oil to the O-ring and install it to the control assembly. Then install control assembly to transaxle case. Tighten bolts to the specified torque. Refer to [MT-23, "SHIFT CONTROL COMPONENTS"](#).

CAUTION:

Do not reuse O-ring.

- i. Install shift check and a new stopper bolt.

CAUTION:


Shift check and stopper bolt are not reusable.

26. Using Tool, install a new bore plug as shown.

CAUTION:


Bore plugs are not reusable.

Tool number : ST33061000 (J-8107-2)



27. Using Tool, install a welch plug as shown.


Tool number : ST33052000 (—)




28. Install 1 shift check sleeve, 3 check balls, 3 check springs, and 3 check ball plugs.

CAUTION:

Check ball plugs are not reusable. Never reuse them.



29. Apply Genuine Silicone RTV or equivalent to threads of Park/Neutral position switch and Back-up lamp switch, then install them into transaxle case. Refer to [GI-45, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#).



30. Install gaskets onto drain plug and filler plug, then install them into transaxle case.

CAUTION:


- Gaskets are not reusable. Never reuse them.
- After oil is filled, tighten filler plug to specified torque. Refer to [MT-20, "CASE AND HOUSING COMPONENTS"](#).

Adjustment INPUT SHAFT END PLAY

ECS0094D

- When adjusting input shaft end play, select adjusting shim for input shaft bearing. To select adjusting shim, measure clearance between transaxle case and input shaft rear bearing.
- Calculate dimension "O" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for input shaft rear bearing.

- End play : 0 - 0.06 mm (0 - 0.0024 in)**
- Dimension "O" = ("O1" - "O2") - End play**
- "O" : Thickness of adjusting shim**
- "O1" : Distance between transaxle case end face and mounting face of adjusting shim**
- "O2" : Distance between clutch housing case end face and end face of input shaft rear bearing**



Adjusting Shim

Shim thickness	Part number	Shim thickness	Part number	Shim thickness	Part number
0.40 mm (0.0157 in)	32225 8H500	0.88 mm (0.0346 in)	32225 8H512	1.36 mm (0.0535 in)	32225 8H524
0.44 mm (0.0173 in)	32225 8H501	0.92 mm (0.0362 in)	32225 8H513	1.40 mm (0.0551 in)	32225 8H560
0.48 mm (0.0189 in)	32225 8H502	0.96 mm (0.0378 in)	32225 8H514	1.44 mm (0.0567 in)	32225 8H561
0.52 mm (0.0205 in)	32225 8H503	1.00 mm (0.0394 in)	32225 8H515	1.48 mm (0.0583 in)	32225 8H562
0.56 mm (0.0220 in)	32225 8H504	1.04 mm (0.0409 in)	32225 8H516	1.52 mm (0.0598 in)	32225 8H563
0.60 mm (0.0236 in)	32225 8H505	1.08 mm (0.0425 in)	32225 8H517	1.56 mm (0.0614 in)	32225 8H564
0.64 mm (0.0252 in)	32225 8H506	1.12 mm (0.0441 in)	32225 8H518	1.60 mm (0.0630 in)	32225 8H565
0.68 mm (0.0268 in)	32225 8H507	1.16 mm (0.0457 in)	32225 8H519	1.64 mm (0.0646 in)	32225 8H566
0.72 mm (0.0283 in)	32225 8H508	1.20 mm (0.0472 in)	32225 8H520	1.68 mm (0.0661 in)	32225 8H567
0.76 mm (0.0299 in)	32225 8H509	1.24 mm (0.0488 in)	32225 8H521	1.72 mm (0.0677 in)	32225 8H568
0.80 mm (0.0315 in)	32225 8H510	1.28 mm (0.0504 in)	32225 8H522		
0.84 mm (0.0331 in)	32225 8H511	1.32 mm (0.0520 in)	32225 8H523		


CAUTION:

Only 1 adjusting shim can be selected.


TRANSAXLE ASSEMBLY

[RS5F51A]

- Using depth micrometer and straight edge, measure dimension "O1" between transaxle case end face and mounting face of adjusting shim as shown.



- Using depth micrometer and straight edge, measure dimension "O2" between clutch housing case end face and end face of input shaft rear bearing as shown.



- Install selected input shaft rear bearing adjusting shim onto input shaft.

DIFFERENTIAL SIDE BEARING PRELOAD

- When adjusting differential side bearing preload, select adjusting shim for differential side bearing. To select adjusting shim, measure clearance "L" between transaxle case and differential side bearing outer race.
- Calculate dimension "L" (thickness of adjusting shim) using the following procedure to satisfy specification of preload for differential side bearing.


Preload : 0.15 - 0.21 mm (0.0059 - 0.0083 in)

Dimension "L" = ("L1" - "L2") + Preload

"L" : Thickness of adjusting shim

"L1" : Distance between transaxle case end face and mounting face of adjusting shim

"L2" : Distance between differential side bearing and clutch housing end face



Adjusting Shim

Shim thickness	Part number
0.48 mm (0.0189 in)	31438 80X00
0.52 mm (0.0205 in)	31438 80X01
0.56 mm (0.0220 in)	31438 80X02
0.60 mm (0.0236 in)	31438 80X03
0.64 mm (0.0252 in)	31438 80X04
0.68 mm (0.0268 in)	31438 80X05
0.72 mm (0.0283 in)	31438 80X06
0.76 mm (0.0299 in)	31438 80X07
0.80 mm (0.0315 in)	31438 80X08
0.84 mm (0.0331 in)	31438 80X09
0.88 mm (0.0346 in)	31438 80X10
0.92 mm (0.0362 in)	31438 80X11

CAUTION:


Up to 2 adjusting shims can be selected.

A
B
MT
D
E
F
G
H
I
J
K
L
M


TRANSAXLE ASSEMBLY

[RS5F51A]

1. Using depth micrometer and straightedge, measure dimension "L₁" between transaxle case end face and mounting face of adjusting shim as shown.




2. Install outer race onto differential side bearing on final gear side. Holding lightly the outer race horizontally by hand, rotate final gear five times or more (for smooth movement of bearing roller).
3. Using depth micrometer and straightedge, measure dimension "L₂" between differential side bearing outer race and clutch housing end face as shown.



4. Install selected adjusting shim and then differential side bearing outer race using Tool as shown.

Tool number : ST30720000 (J-25405)



MAINSHAFT END PLAY


- When adjusting mainshaft end play, select adjusting shim for mainshaft rear bearing. To select adjusting shim, measure clearance "M" between transaxle case and mainshaft rear bearing.
- Calculate dimension "P" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for mainshaft rear bearing.

End play : 0 - 0.06 mm (0 - 0.0024 in)

Dimension "P" = "M" - End play

"P" : Thickness of adjusting shim

"M" : Distance between mainshaft rear bearing and transaxle case




Adjusting Shim

Shim thickness	Part number
0.44 mm (0.0173 in)	32238 8H510
0.48 mm (0.0189 in)	32238 8H511
0.52 mm (0.0205 in)	32238 8H512
0.56 mm (0.0220 in)	32238 8H513
0.60 mm (0.0236 in)	32238 8H514
0.64 mm (0.0252 in)	32238 8H515
0.68 mm (0.0268 in)	32238 8H516
0.72 mm (0.0283 in)	32238 8H517
0.76 mm (0.0299 in)	32238 8H518
0.80 mm (0.0315 in)	32238 8H519
0.84 mm (0.0331 in)	32238 8H520
0.88 mm (0.0346 in)	32238 8H521
0.92 mm (0.0362 in)	32238 8H522
0.96 mm (0.0378 in)	32238 8H523
1.00 mm (0.0394 in)	32238 8H524
1.04 mm (0.0409 in)	32238 8H560
1.08 mm (0.0425 in)	32238 8H561

CAUTION:

Only 1 adjusting shim can be selected.

1. Install mainshaft assembly to clutch housing.
2. Install snap ring to transaxle case.
3. Install transaxle case to clutch housing, and temporarily assemble them with the bolts. Install temporarily snap ring to mainshaft rear bearing.
4. Install dial gauge to snap ring access hole, and expand snap ring. Lift mainshaft assembly through control assembly installation hole, and push it against transaxle case. This state shall be defined as base. Moving distance of mainshaft assembly, with snap ring fit on main bearing, becomes "M".



REVERSE IDLER GEAR END PLAY

- When adjusting reverse idler gear end play, select adjusting shim for reverse idler gear. To select adjusting shim, measure clearance between transaxle case and reverse idler gear.
- Calculate dimension "Q" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for reverse idler gear.


End play : 0.04 - 0.10 mm (0.0016 - 0.0039 in)

Dimension "Q" = ("Q1" - "Q2") - End play

"Q" : Thickness of adjusting shim

"Q1" : Distance between transaxle case end face and mounting face of adjusting shim

"Q2" : Distance between clutch housing case end face and end face of reverse idler gear



TRANSAXLE ASSEMBLY

[RS5F51A]


Adjusting Shim

Shim thickness mm (in)	Part number	Shim thickness mm (in)	Part number
1.76 (0.0693)	32237 8H800	2.24 (0.0882)	32237 8H812
1.80 (0.0709)	32237 8H801	2.28 (0.0898)	32237 8H813
1.84 (0.0724)	32237 8H802	2.32 (0.0913)	32237 8H814
1.88 (0.0740)	32237 8H803	2.36 (0.0929)	32237 8H815
1.92 (0.0756)	32237 8H804	2.40 (0.0945)	32237 8H816
1.96 (0.0772)	32237 8H805	2.44 (0.0961)	32237 8H817
2.00 (0.0787)	32237 8H806	2.48 (0.0976)	32237 8H818
2.04 (0.0803)	32237 8H807	2.52 (0.0992)	32237 8H819
2.08 (0.0819)	32237 8H808	2.56 (0.1008)	32237 8H820
2.12 (0.0835)	32237 8H809	2.60 (0.1024)	32237 8H821
2.16 (0.0850)	32237 8H810	2.64 (0.1039)	32237 8H822
2.20 (0.0866)	32237 8H811		


CAUTION:

Only 1 adjusting shim can be selected.

- Using depth micrometer and straight edge, measure dimension "Q₁" between transaxle case end face and mounting face of adjusting shim as shown.



- Using depth micrometer and straight edge, measure dimension "Q₂" between clutch housing case end face and end face of reverse idler gear as shown.



- Install selected reverse idler gear adjusting shim onto reverse idler gear.

INPUT SHAFT AND GEARS

Disassembly and Assembly

DISASSEMBLY

1. Before disassembling, measure end play for 3rd, 4th, and 5th input gears.

End play standard value


3rd gear : 0.18 - 0.31 mm (0.0071 - 0.0122 in)

4th gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)

5th gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)

CAUTION:

If measurement is outside the standard range, disassemble to check contact surfaces of gear, shaft, and hub. Adjust with snap ring at assembly.




2. Remove oil channel.
3. Remove input shaft rear bearing.


Tool number

A: ST33052000 (—)

B: Commercial service tool



4. Remove the snap ring.




5. Remove input shaft bearing spacer and 5th stopper simultaneously.

Tool number

A: ST33052000 (—)

B: Commercial service tool



A
B
MT
D
E
F
G
H
I
J
K
L
M

INPUT SHAFT AND GEARS


[RS5F51A]

6. Remove 5th input gear and synchronizer hub assembly simultaneously.

Tool number

A: KV40105020 (—)

B: Commercial service tool




7. Remove 5th needle bearing.
8. Remove 5th bushing, thrust washer, 4th input gear, 4th needle bearing, 4th gear bushing, 4th baulk ring, 3rd-4th synchronizer hub assembly, 3rd gear synchronizer assembly, and 3rd input gear simultaneously.


Tool number

A: ST33052000 (—)

B: Commercial service tool



9. Remove 3rd needle bearing.
10. Remove input shaft front bearing.




INSPECTION AFTER DISASSEMBLY

Input Shaft and Gears

Check items below. If necessary, replace them with new ones.


- Damage, peeling, dent, uneven wear, bending, etc. of shaft
- Excessive wear, damage, peeling, etc. of gears




Synchronizer

Check items below. If necessary, replace them with new ones.

- Damage and excessive wear of contact surfaces of coupling sleeve, synchronizer hub, and shifting insert.
- Coupling sleeve and synchronizer hub must move smoothly.



- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.



Baulk Ring Clearance for Single Cone Synchronizer (4th and 5th)

Press baulk ring against cone, and measure clearance between baulk ring and cone. If measurement is below limit, replace it with a new one.


Clearance

Standard value

4th : 0.8 - 1.45 mm (0.035 - 0.057 in)

5th : 0.95 - 1.4 mm (0.037 - 0.055 in)

Limit value : 0.7 mm (0.028 in)




Baulk Ring Clearance for Double Cone Synchronizer (3rd)

Follow the instructions below and inspect the clearance of outer baulk ring, synchronizer cone, inner baulk ring.

CAUTION:


Outer baulk ring, synchronizer cone, and inner baulk ring determine the clearances "A" and "B" as an assembly. Replace the outer baulk ring, synchronizer cone and inner baulk ring as an assembly if either of the clearances "A" or "B" exceed the limit value.




INPUT SHAFT AND GEARS

[RS5F51A]

- Be careful with orientation of coupling sleeve.



- Be sure not to hook ends of 2 spread springs (front and back have two each) on same shifting insert.




4. Install 3rd-4th synchronizer hub assembly.

Tool number : KV40105710 (—)


CAUTION:

Align grooves of shifting insert and 3rd baulk ring.



5. Install 4th bushing.

Tool number : KV40105710 (—)



6. Install 4th baulk ring.

7. Install 4th input gear and 4th needle bearing.

A
B
MT

D
E
F
G

H
I
J
K


L
M

INPUT SHAFT AND GEARS

[RS5F51A]

8. Select thrust washer so that dimension "C2" satisfies standard below. Then install it onto input shaft.

**Standard for dimension "C2" : 154.7 - 154.8 mm
(6.091 - 6.094 in)**



Thrust Washer


Thickness	Part number	Thickness	Part number
3.84 mm (0.1512 in)	32347 8H500	4.02 mm (0.1583 in)	32347 8H503
3.90 mm (0.1535 in)	32347 8H501	4.08 mm (0.1606 in)	32347 8H504
3.96 mm (0.1559 in)	32347 8H502	4.14 mm (0.1630 in)	32347 8H505

CAUTION:

Only one thrust washer can be selected.

9. Install 5th bushing.


Tool number : KV40105710 (—)



10. Install 5th needle bearing and 5th input gear.
 11. Install 5th baulk ring.
 12. Install spread spring, shifting insert and 5th synchronizer hub onto 5th coupling sleeve.

CAUTION:


- Be careful with orientation of synchronizer hub and shifting insert.




INPUT SHAFT AND GEARS

[RS5F51A]

- Be careful with orientation of coupling sleeve.



- Be sure not to hook ends of 2 spread springs (front and back have two each) on same shifting insert.




13. Install 5th synchronizer hub assembly.

Tool number : KV40105710 (—)


CAUTION:

Align grooves of 5th shifting insert and 5th baulk ring.



14. Install 5th stopper and then input shaft bearing spacer.


Tool number : ST30032000 (J-26010-01)



15. Install snap ring onto input shaft, and check that end play (gap between snap ring and groove) of input shaft bearing spacer satisfies standard.

End play standard value : 0 - 0.1 mm (0 - 0.004 in)

- If measurement is outside the standard range, select snap ring.



A
B
MT

D
E
F
G

H
I
J
K

L
M

INPUT SHAFT AND GEARS

[RS5F51A]


Snap Rings

Thickness	Part number	Thickness	Part number
1.71 mm (0.0673 in)	32204 8H510	2.01 mm (0.0791 in)	32204 8H516
1.76 mm (0.0693 in)	32204 8H511	2.06 mm (0.0811 in)	32204 8H517
1.81 mm (0.0713 in)	32204 8H512	2.11 mm (0.0831 in)	32204 8H518
1.86 mm (0.0732 in)	32204 8H513	2.16 mm (0.0850 in)	32204 8H519
1.91 mm (0.0752 in)	32204 8H514	2.21 mm (0.0871 in)	32204 8H520
1.96 mm (0.0772 in)	32204 8H515	2.26 mm (0.0890 in)	32204 8H521

16. Install input shaft rear bearing.


Tool number : ST30901000 (J-26010-01)

CAUTION:
Install input shaft rear bearing with its brown surface facing the input gear side.



17. Install input shaft front bearing.

Tool number A: ST33052000 (—)
B: ST30032000 (J-26010-01)



18. Install oil channel onto input shaft.


19. Check end play of 3rd, 4th, and 5th input gears.

End play standard value

3rd gear : 0.18 - 0.31 mm (0.0071 - 0.0122 in)

4th gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)

5th gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)



MAINSHAFT AND GEARS

Disassembly and Assembly

DISASSEMBLY

1. Before disassembling, measure end play of 1st and 2nd main gears.


End play standard value

1st gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)


2nd gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)

CAUTION:

If measurement is outside the standard range, disassemble to check contact surfaces of gear, shaft, and hub. Adjust with snap ring at assembly.



2. Remove the snap ring.
3. Remove C-ring holder, and then mainshaft C-ring.




4. Remove mainshaft rear bearing.

Tool number


A: Commercial service tool

B: Commercial service tool

C: ST33052000 (—)




5. Remove the snap ring.



A
B
MT
D
E
F
G
H
I
J
K
L
M

- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.




Baulk Ring Clearance for Double Cone Synchronizer (1st)

Follow the instructions below and inspect the clearance of outer baulk ring, synchronizer cone, and inner baulk ring.

CAUTION:

Outer baulk ring, synchronizer cone and inner baulk ring determine the clearances “A” and “B” as an assembly. Replace the outer baulk ring, synchronizer cone and inner baulk ring as an assembly if either of the clearances “A” or “B” exceed the limit value.




- Using a dial gauge, measure clearance “A” at 2 or more points diagonally opposite, and calculate mean value.

Tool number : ST30031000 (J-22912-01)

Clearance “A”

Standard value : 0.6 - 0.8 mm (0.024 - 0.031 in)

Limit value : 0.2 mm (0.008 in)




- Using a feeler gauge, measure clearance “B” at 2 or more points diagonally opposite, and calculate mean value.

Clearance “B”

Standard value : 0.6 - 1.1 mm (0.024 - 0.043 in)

Limit value : 0.2 mm (0.008 in)




A
B
MT
D
E
F
G
H
I
J
K
L
M

Baulk Ring Clearance for Triple Cone Synchronizer (2nd)

Follow the instructions below and inspect the clearance of outer baulk ring, synchronizer cone, inner baulk ring.

CAUTION:

Outer baulk ring, synchronizer cone and inner baulk ring determine the clearances "A", "B" and "C" as an assembly. Replace the outer baulk ring, synchronizer cone and inner baulk ring as an assembly if any of the clearances "A", "B" and "C" exceed the limit value.




- Measure clearance "A" at two points or more on the opposite side using a feeler gauge when pressing baulk ring toward clutch gear taper cone, then calculate the average.

Clearance "A"

Standard value : 0.6 - 1.2 mm (0.024 - 0.047 in)

Limit value : 0.3 mm (0.012 in)




- Measure clearance "B" at two points or more on the opposite side using a feeler gauge, then calculate the average.

Clearance "B"

Standard value : 0.6 - 1.1 mm (0.024 - 0.043 in)

Limit value : 0.2 mm (0.008 in)




- Measure clearance "C" at two points or more on the opposite side using a feeler gauge when pressing baulk ring toward clutch gear taper cone, then calculate the average.

Clearance "C"

Standard value : 0.7 - 1.1 mm (0.028 - 0.043 in)


Limit value : 0.3 mm (0.012 in)



Bearing

Check items below. If necessary, replace them with new ones.

- Damage and rough rotation of bearing




ASSEMBLY

1. Install reverse main gear.


Tool number

A: ST35321000 (—)
B: KV40101630 (J-35870)
C: ST38220000 (—)



CAUTION:


Be careful with orientation of reverse main gear.



2. Install 1st bushing.

Tool number

A: ST35321000 (—)
B: KV38102510 (—)
C: ST38220000 (—)




3. Install needle bearing, and then 1st main gear.

4. Install spread spring, shifting insert and 1st-2nd synchronizer hub onto 1st-2nd coupling sleeve.


A
B
MT
D
E
F
G
H
I
J
K
L
M

CAUTION:


- Be careful with orientation of synchronizer hub.



- Be careful with orientation of coupling sleeve.



- Be sure not to hook ends of 2 spread springs (front and back have two each) on same shifting insert.




5. Install 1st gear synchronizer assembly onto mainshaft, and synchronizer hub assembly onto mainshaft.

Tool number **A: ST35321000 (—)**
 B: KV38102510 (—)
 C: ST38220000 (—)

CAUTION:

- Outer baulk ring, synchronizer cone, and inner baulk ring on 2nd gear-side must have been removed.
- Be careful with orientation of coupling sleeve.




MAINSHAFT AND GEARS

[RS5F51A]

6. Install 2nd bushing.

Tool number **A: ST35321000 (—)**
 B: KV40105710 (—)

7. Install outer baulk ring, synchronizer cone, and inner baulk ring on 2nd gear-side.
 8. Install 2nd needle bearing and 2nd gear.




9. Install 3rd main gear.

Tool number **A: ST35321000 (—)**
 B: KV40105710 (—)


CAUTION:
Be careful with orientation of 3rd main gear.

10. Install 3rd-4th mainshaft spacer.



11. Select suitable adjusting shim so that dimension "C1" satisfies standard value below, and install it onto mainshaft.

Standard for dimension "C1" : 173.85 - 173.95 mm
 (6.844 - 6.848 in)



Adjusting Shim

Thickness	Part number	Thickness	Part number
0.52 mm (0.0205 in)	32238 8H500	0.84 mm (0.0331 in)	32238 8H504
0.60 mm (0.0236 in)	32238 8H501	0.92 mm (0.0362 in)	32238 8H505
0.68 mm (0.0268 in)	32238 8H502	1.00 mm (0.0394 in)	32238 8H506
0.76 mm (0.0299 in)	32238 8H503	1.08 mm (0.0425 in)	32238 8H507

CAUTION:
Only one adjusting shim can be selected.

MAINSHAFT AND GEARS

[RS5F51A]

12. Install 4th main gear.


Tool number

A: ST33200000 (J-26082)

B: ST30901000 (J-26010-01)

CAUTION:

Be careful with orientation of 4th main gear.



13. Install 5th main gear.


Tool number

A: ST33200000 (J-26082)

B: ST30901000 (J-26010-01)

CAUTION:


Be careful with orientation of 5th main gear.



14. Install snap ring onto mainshaft, and check that end play of 5th main gear satisfies standard value.

End play standard value : 0 - 0.1 mm (0 - 0.004 in)

- If measurement is outside the standard range, reselect snap ring.



Snap Rings


Thickness	Part number	Thickness	Part number
1.85 mm (0.0728 in)	32204 8H500	2.05 mm (0.0807 in)	32204 8H504
1.90 mm (0.0748 in)	32204 8H501	2.10 mm (0.0827 in)	32204 8H505
1.95 mm (0.0768 in)	32204 8H502	2.15 mm (0.0846 in)	32204 8H506
2.00 mm (0.0787 in)	32204 8H503	2.20 mm (0.0866 in)	32204 8H507

15. Install mainshaft rear bearing.

Tool number

A: ST30720000 (J-25405)

B: ST30901000 (J-26010-01)




MAINSHAFT AND GEARS

[RS5F51A]

16. Install C-ring onto mainshaft, and check that end play of mainshaft rear bearing satisfies standard value.

End play standard value : 0 - 0.06 mm (0 - 0.0024 in)


- If measurement is outside the standard range, reselect C-ring.



C-ring

Thickness	Part number	Thickness	Part number
2.535 mm (0.0998 in)	32348 8H800	2.835 mm (0.1116 in)	32348 8H810
2.565 mm (0.1010 in)	32348 8H801	2.865 mm (0.1128 in)	32348 8H811
2.595 mm (0.1022 in)	32348 8H802	2.895 mm (0.1140 in)	32348 8H812
2.625 mm (0.1033 in)	32348 8H803	2.925 mm (0.1152 in)	32348 8H813
2.655 mm (0.1045 in)	32348 8H804	2.955 mm (0.1163 in)	32348 8H814
2.685 mm (0.1057 in)	32348 8H805	2.985 mm (0.1175 in)	32348 8H815
2.715 mm (0.1069 in)	32348 8H806	3.015 mm (0.1187 in)	32348 8H816
2.745 mm (0.1081 in)	32348 8H807	3.045 mm (0.1199 in)	32348 8H817
2.775 mm (0.1093 in)	32348 8H808	3.075 mm (0.1211 in)	32348 8H818
2.805 mm (0.1104 in)	32348 8H809		

17. Fit the C-ring holder, and install the snap ring.




18. Check the end play of the 1st and 2nd main gears.

End play standard value

1st gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)

2nd gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)



REVERSE IDLER SHAFT AND GEARS

Disassembly and Assembly DISASSEMBLY


1. Remove reverse idler gear adjusting shim.
2. Remove reverse idler gear (rear), reverse coupling sleeve and insert spring simultaneously.
3. Remove reverse idler gear needle bearing.
4. Remove thrust needle bearing.
5. Remove reverse baulk ring.
6. Remove reverse idler gear (front).
7. Remove reverse idler gear needle bearing.
8. Remove thrust needle bearing.
9. Pull off locking pin from reverse idler shaft.

INSPECTION AFTER DISASSEMBLY

Reverse Idler Shaft and Gears

Check items below. If necessary, replace them with new ones.


- Damage, peeling, dent, uneven wear, bending, and other non-standard conditions of the shaft.
- Excessive wear, damage, peeling, and other non-standard conditions of the gears.




Synchronizer

Check items below. If necessary, replace them with new ones.

- Damage and unusual wear on contact surfaces of coupling sleeve, synchronizer hub, and insert spring.
- Coupling sleeve and synchronizer hub must move smoothly.



- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.



REVERSE IDLER SHAFT AND GEARS

[RS5F51A]


Baulk Ring Clearance

- Press baulk ring against cone, and measure clearance between baulk ring and cone. If measurement is below limit, replace it with a new one.

Clearance

Standard : 0.95 - 1.4 mm (0.0374 - 0.055 in)

Limit value : 0.7 mm (0.028 in)



Bearing

Check items below. If necessary, replace them with new ones.


- Damage and rough rotation of bearing.

ASSEMBLY

Paying attention to following work, assemble in reverse order of disassembly.

CAUTION:

- Be careful with orientation of insert spring.



A
B
MT
D
E
F
G
H
I
J
K
L
M

FINAL DRIVE


PFP:38411

Disassembly and Assembly PRE-INSPECTION

ECS0094H

Check the clearance between side gear and differential case using Tool and a dial indicator as follows:

Tool number : — (J-39713)




1. Clean final drive assembly sufficiently to prevent side gear thrust washer, differential case, side gear, and other parts from sticking by gear oil.
2. Upright the differential case so that the side gear to be measured faces upward.
3. Place final drive adapter and dial indicator onto side gear. Move side gear up and down, and measure the clearance.

Clearance between side gear and differential case : 0.1 - 0.2 mm
(0.004 - 0.008 in)

CAUTION:

There should be no resistance with the gears rotating freely.




4. If not within specification, adjust the clearance by changing thrust washer thickness.
5. Turn differential case upside down, and measure the clearance between side gear and differential case on the other side in the same way.

DISASSEMBLY

1. Remove mounting bolts. Then, separate the final gear from differential case.
2. Remove speedometer drive gear.
3. Remove the differential side bearing (clutch housing side) using the pullers and Tool as shown.

Tool number **A: Commercial service tool**
 B: Commercial service tool
 C: ST33061000 (J-8107-2)




FINAL DRIVE

[RS5F51A]


4. Remove the differential side bearing (transaxle case side) using the pullers and Tool as shown.

Tool number

A: Commercial service tool
B: Commercial service tool
C: ST33061000 (J-8107-2)



5. Pull out the lock pin and pinion mate shaft using a pin punch.




6. Rotate pinion mate gears, and remove pinion mate gears, pinion mate thrust washers, side gears, and side gear thrust washers from the differential case.

INSPECTION AFTER DISASSEMBLY

Gear, Washer, Shaft and Case

- Check side gears, side gear thrust washers, pinion mate shaft, pinion mate gears, pinion mate thrust washers and differential case. If necessary, replace with a new one.




Bearing

- Check for bearing damage and rough rotation. If necessary, replace with a new one.

CAUTION:

When replacing tapered roller bearing, replace outer and inner races as a set.




ASSEMBLY

1. Apply gear oil to sliding area of differential case, each gear, and thrust washer.

FINAL DRIVE

[RS5F51A]


2. Install side gear thrust washers and side gears into differential case.



3. While rotating pinion mate thrust washers and pinion mate gears, aligning them diagonally, install them into differential case.
4. Insert pinion mate shaft into differential case.

CAUTION:


Be sure not to damage pinion mate thrust washers.



5. Measure end play of side gears using the procedure below, then select a side gear thrust washer.

Tool number : — (J-39713)

- a. Upright the differential case so that its side gear to be measured face upward.
- b. Place final drive adapter and dial indicator onto side gears.




- c. Move side gears up and down to measure end play, and select thrust washer so that it satisfies standard.

End play standard : 0.1 - 0.2 mm (0.004 - 0.008 in)

CAUTION:

- There should be no resistance with the gears rotating freely.
- Place differential case upside down. Be sure to measure end play for opposite side-gears likewise.



Thrust washer

Thickness	Part number
0.75 mm (0.0295 in)	38424 81X00
0.80 mm (0.0315 in)	38424 81X01
0.85 mm (0.0335 in)	38424 81X02
0.90 mm (0.0354 in)	38424 81X03
0.95 mm (0.0374 in)	38424 81X04

CAUTION:

Only one thrust washer can be selected.


FINAL DRIVE

[RS5F51A]

6. Drive a new lock pin into the pinion mate shaft using suitable tool.

CAUTION:

Do not reuse the lock pin.




7. Install differential side bearing (transaxle case side) using Tools as shown.


Tool number

A: ST30720000 (J-25405)

B: KV38102510 (—)



8. Align and install speedometer drive gear onto differential case.




9. Install differential side bearing (clutch housing side) using Tools as shown.

Tool number

A: ST30720000 (J-25405)


B: KV38102510 (—)



10. Install differential gear into differential case, and tighten final gear bolts.

Final gear bolts

: Refer to [MT-24, "FINAL DRIVE COMPONENTS"](#).




A
B
MT
D
E
F
G
H
I
J
K
L
M

SHIFT CONTROL

Inspection


- Check contact surfaces and sliding area for wear, damage, bending, etc. If necessary, replace parts.



SHIFT FORK

- Check if the width of shift fork hook (sliding area with coupling sleeve) is within allowable specification below.

Item	One-side wear specification	Sliding width of new part
1st & 2nd	0.2 mm (0.008 in)	7.80 - 7.93 mm (0.3071 - 0.3122 in)
3rd & 4th	0.2 mm (0.008 in)	7.80 - 7.93 mm (0.3071 - 0.3122 in)
5th	0.2 mm (0.008 in)	6.10 - 6.23 mm (0.2402 - 0.2453 in)
Reverse	0.2 mm (0.008 in)	12.80 - 12.93 mm (0.5039 - 0.5091 in)



SERVICE DATA AND SPECIFICATIONS (SDS)

[RS5F51A]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

General Specifications TRANSAXLE

ECS0094J

Engine		QR25DE	VQ35DE	
Transaxle model		RS5F51A		
Model code number		9J506	9J504	
Number of speed		5		
Synchronesh type		Warner		
Shift pattern		 <p style="text-align: center; font-size: small;">SCIA0821E</p>		
Gear ratio	1st	3.416	3.153	
	2nd	1.944	1.842	
	3rd	1.258		
	4th	0.947		
	5th	0.772		
	Reverse	3.252	3.002	
Number of teeth	Input gear	1st	12	13
		2nd	18	19
		3rd	31	
		4th	38	
		5th	44	
		Reverse	12	13
	Main gear	1st	41	
		2nd	35	
		3rd	39	
		4th	36	
		5th	34	
		Reverse	38	
	Reverse idler gear	Front	37	
		Rear	38	
Oil capacity (Reference)		2.2 ℓ (2-3/8 US qt, 2 Imp qt)		
Oil level		49 - 55 mm (1.93 - 2.17 in)		
Oil type		Genuine NISSAN Manual Transmission Fluid (MTF) HQ Multi 75W-85 or API GL-4, Viscosity SAE 75W-85		
Remarks	Reverse synchronizer	Installed		
	Double cone synchronizer	1st & 3rd		
	Triple cone synchronizer	2nd		

SERVICE DATA AND SPECIFICATIONS (SDS)

[RS5F51A]

FINAL GEAR

Engine	QR25DE	VQ35DE
Transaxle model	RS5F51A	
Model code number	9J506	9J504
Final gear ratio	4.133	3.812
Number of teeth	Final gear/Pinion	62/15
	Side gear/Pinion mate gear	14/10
	Triple cone synchronizer	2nd

Gear End Play

ECS0094K



Unit: mm (in)

Gear	End play
1st main gear	0.20 - 0.30 (0.0079 - 0.0118)
2nd main gear	0.06 - 0.16 (0.0024 - 0.0063)
3rd input gear	0.18 - 0.31 (0.0071 - 0.0122)
4th input gear	0.20 - 0.30 (0.0079 - 0.0118)
5th input gear	0.06 - 0.16 (0.0024 - 0.0063)

Baulk Ring Clearance

ECS0094L

Unit: mm (in)

Measurement point	Standard	Limit Value
<p>1st and 3rd (Double-cone synchronizer)</p> <ul style="list-style-type: none"> ● Clearance between synchronizer cone and inner baulk ring end face "A" ● Clearance between outer baulk ring paul and synchronizer cone "B" <div style="text-align: center;">  <p style="font-size: small;">PCIB0249E</p> </div>	<p>A: 0.6 - 0.8 (0.024 - 0.031) B: 0.6 - 1.1 (0.024 - 0.043)</p>	<p>0.2 (0.008) 0.2 (0.008)</p>
<p>2nd (Triple-cone synchronizer)</p> <ul style="list-style-type: none"> ● Clearance between synchronizer cone and clutch gear end face "A" ● Clearance between outer baulk ring paul and synchronizer cone "B" ● Clearance between inner baulk ring and clutch gear end face "C" <div style="text-align: center;">  <p style="font-size: small;">PCIB0772E</p> </div>	<p>A: 0.6 - 1.2 (0.024 - 0.047) B: 0.6 - 1.1 (0.024 - 0.043) C: 0.7 - 1.1 (0.028 - 0.043)</p>	<p>0.3 (0.012) 0.2 (0.008) 0.3 (0.012)</p>
4th	0.8 - 1.45 (0.035 - 0.057)	0.7 (0.028)
5th	0.95 - 1.4 (0.037 - 0.055)	0.7 (0.028)
Reverse	0.95 - 1.4 (0.037 - 0.055)	0.7 (0.028)

SERVICE DATA AND SPECIFICATIONS (SDS)

[RS5F51A]

Available Snap Rings INPUT SHAFT SPACER

ECS0094M

End play		0 - 0.1 mm (0 - 0.004 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
1.71 (0.0673)	32204 8H510	2.01 (0.0791)	32204 8H516
1.76 (0.0693)	32204 8H511	2.06 (0.0811)	32204 8H517
1.81 (0.0713)	32204 8H512	2.11 (0.0831)	32204 8H518
1.86 (0.0732)	32204 8H513	2.16 (0.0850)	32204 8H519
1.91 (0.0752)	32204 8H514	2.21 (0.0871)	32204 8H520
1.96 (0.0772)	32204 8H515	2.26 (0.0890)	32204 8H521

*: Always check with the Parts Department for the latest parts information.

5TH MAIN GEAR

End play		0 - 0.1 mm (0 - 0.004 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
1.85 (0.0728)	32204 8H500	2.05 (0.0807)	32204 8H504
1.90 (0.0748)	32204 8H501	2.10 (0.0827)	32204 8H505
1.95 (0.0768)	32204 8H502	2.15 (0.0846)	32204 8H506
2.00 (0.0787)	32204 8H503	2.20 (0.0866)	32204 8H507

*: Always check with the Parts Department for the latest parts information.

Available C-Rings MAINSHAFT C-RING


ECS0094N

End play		0 - 0.06 mm (0 - 0.0024 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
2.535 (0.0998)	32348 8H800	2.835 (0.1116)	32348 8H810
2.565 (0.1010)	32348 8H801	2.865 (0.1128)	32348 8H811
2.595 (0.1022)	32348 8H802	2.895 (0.1140)	32348 8H812
2.625 (0.1033)	32348 8H803	2.925 (0.1152)	32348 8H813
2.655 (0.1045)	32348 8H804	2.955 (0.1163)	32348 8H814
2.685 (0.1057)	32348 8H805	2.985 (0.1175)	32348 8H815
2.715 (0.1069)	32348 8H806	3.015 (0.1187)	32348 8H816
2.745 (0.1081)	32348 8H807	3.045 (0.1199)	32348 8H817
2.775 (0.1093)	32348 8H808	3.075 (0.1211)	32348 8H818
2.805 (0.1104)	32348 8H809		

*: Always check with the Parts Department for the latest parts information.

Available Thrust Washer INPUT SHAFT THRUST WASHER

ECS0094O



SCIA1008E

Standard length "C2"		154.7 - 154.8 mm (6.091 - 6.094in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
3.84 (0.1512)	32347 8H500	4.02 (0.1583)	32347 8H503
3.90 (0.1535)	32347 8H501	4.08 (0.1606)	32347 8H504
3.96 (0.1559)	32347 8H502	4.14 (0.1630)	32347 8H505

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

[RS5F51A]


DIFFERENTIAL SIDE GEAR THRUST WASHER

Allowable clearance between side gear and differential case with washer	0.1 - 0.2 mm (0.004 - 0.008 in)	
Thickness mm (in)	Part number*	
0.75 (0.0295)	38424 81X00	
0.80 (0.0315)	38424 81X01	
0.85 (0.0335)	38424 81X02	
0.90 (0.0354)	38424 81X03	
0.95 (0.0374)	38424 81X04	

*: Always check with the Parts Department for the latest parts information.

Available Adjusting Shims MAINSHAFT ADJUSTING SHIM

ECS0094P



SCIA1009E

Standard length "C1"		173.85 - 173.95 mm (6.844 - 6.848in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.52 (0.0205)	32238 8H500	0.84 (0.0331)	32238 8H504
0.60 (0.0236)	32238 8H501	0.92 (0.0362)	32238 8H505
0.68 (0.0268)	32238 8H502	1.00 (0.0394)	32238 8H506
0.76 (0.0299)	32238 8H503	1.08 (0.0425)	32238 8H507

*: Always check with the Parts Department for the latest parts information.

INPUT SHAFT REAR BEARING ADJUSTING SHIM

End play			0 - 0.06 mm (0 - 0.0024 in)		
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.40 (0.0157)	32225 8H500	0.88 (0.0346)	32225 8H512	1.36 (0.0535)	32225 8H524
0.44 (0.0173)	32225 8H501	0.92 (0.0362)	32225 8H513	1.40 (0.0551)	32225 8H560
0.48 (0.0189)	32225 8H502	0.96 (0.0378)	32225 8H514	1.44 (0.0567)	32225 8H561
0.52 (0.0205)	32225 8H503	1.00 (0.0394)	32225 8H515	1.48 (0.0583)	32225 8H562
0.56 (0.0220)	32225 8H504	1.04 (0.0409)	32225 8H516	1.52 (0.0598)	32225 8H563
0.60 (0.0236)	32225 8H505	1.08 (0.0425)	32225 8H517	1.56 (0.0614)	32225 8H564
0.64 (0.0252)	32225 8H506	1.12 (0.0441)	32225 8H518	1.60 (0.0630)	32225 8H565
0.68 (0.0268)	32225 8H507	1.16 (0.0457)	32225 8H519	1.64 (0.0646)	32225 8H566
0.72 (0.0283)	32225 8H508	1.20 (0.0472)	32225 8H520	1.68 (0.0661)	32225 8H567
0.76 (0.0299)	32225 8H509	1.24 (0.0488)	32225 8H521	1.72 (0.0677)	32225 8H568
0.80 (0.0315)	32225 8H510	1.28 (0.0504)	32225 8H522		
0.84 (0.0331)	32225 8H511	1.32 (0.0520)	32225 8H523		

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

[RS5F51A]

MAINSHAFT REAR BEARING ADJUSTING SHIM

End play		0 - 0.06 mm (0 - 0.0024 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.44 (0.0173)	32238 8H510	0.80 (0.0315)	32238 8H519
0.48 (0.0189)	32238 8H511	0.84 (0.0331)	32238 8H520
0.52 (0.0205)	32238 8H512	0.88 (0.0346)	32238 8H521
0.56 (0.0220)	32238 8H513	0.92 (0.0362)	32238 8H522
0.60 (0.0236)	32238 8H514	0.96 (0.0378)	32238 8H523
0.64 (0.0252)	32238 8H515	1.00 (0.0394)	32238 8H524
0.68 (0.0268)	32238 8H516	1.04 (0.0409)	32238 8H560
0.72 (0.0283)	32238 8H517	1.08 (0.0425)	32238 8H561
0.76 (0.0299)	32238 8H518		

*: Always check with the Parts Department for the latest parts information.

REVERSE IDLER GEAR ADJUSTING SHIMS

End play		0.04 - 0.10 mm (0.0016 - 0.0039 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
1.76 (0.0693)	32237 8H800	2.24 (0.0882)	32237 8H812
1.80 (0.0709)	32237 8H801	2.28 (0.0898)	32237 8H813
1.84 (0.0724)	32237 8H802	2.32 (0.0913)	32237 8H814
1.88 (0.0740)	32237 8H803	2.36 (0.0929)	32237 8H815
1.92 (0.0756)	32237 8H804	2.40 (0.0945)	32237 8H816
1.96 (0.0772)	32237 8H805	2.44 (0.0961)	32237 8H817
2.00 (0.0787)	32237 8H806	2.48 (0.0976)	32237 8H818
2.04 (0.0803)	32237 8H807	2.52 (0.0992)	32237 8H819
2.08 (0.0819)	32237 8H808	2.56 (0.1008)	32237 8H820
2.12 (0.0835)	32237 8H809	2.60 (0.1024)	32237 8H821
2.16 (0.0850)	32237 8H810	2.64 (0.1039)	32237 8H822
2.20 (0.0866)	32237 8H811		

*: Always check with the Parts Department for the latest parts information.

Available Differential Side Bearing Preload and Adjusting Shims

ECS00940

BEARING PRELOAD

Differential side bearing preload: L*	0.15 - 0.21 mm (0.0059 - 0.0083)
---------------------------------------	----------------------------------

*: Install shims which are "deflection of differential case" + "L" in thickness.

DIFFERENTIAL SIDE BEARING ADJUSTING SHIMS

Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.48 (0.0189)	31438 80X00	0.72 (0.0283)	31438 80X06
0.52 (0.0205)	31438 80X01	0.76 (0.0299)	31438 80X07
0.56 (0.0220)	31438 80X02	0.80 (0.0315)	31438 80X08
0.60 (0.0236)	31438 80X03	0.84 (0.0331)	31438 80X09
0.64 (0.0252)	31438 80X04	0.88 (0.0346)	31438 80X10
0.68 (0.0268)	31438 80X05	0.92 (0.0362)	31438 80X11

*: Always check with the Parts Department for the latest parts information.

PRECAUTIONS

Caution

- Do not reuse transaxle oil.
- Drain, fill and check transaxle oil with the vehicle on level ground.
- During removal and installation, keep inside of transaxle clean of dust and dirt.
- Check for the correct installation orientation prior to removal or disassembly. If mating marks are required, be certain they do not interfere with the function of the parts they are applied to.
- In principle, tighten bolts or nuts gradually in several steps working diagonally and from inside to outside as applicable. If a tightening sequence is specified, follow it.
- Be careful not to damage the sliding surfaces and mating surfaces of parts.

PREPARATION

[RS6F51A]





PF0:00002

ECS0094S

PREPARATION








Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV381054S0 (J-34286) Puller	 ZZA0601D Removing side bearing outer race Removing mainshaft front bearing
ST35321000 (—) Drift	 ZZA1000D Installing input shaft oil seal Installing reverse main gear Installing 1st bushing Installing 1st-2nd synchronizer hub Installing 2nd bushing Installing 3rd main gear a: 49 mm (1.93 in) dia. b: 41 mm (1.61 in) dia.
ST30720000 (J-25405) Drift	 ZZA0811D Installing differential oil seal Installing differential side bearing outer race Installing mainshaft rear bearing Installing differential side bearing a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.
ST33200000 (J-26082) Drift	 ZZA1002D Installing mainshaft front bearing Installing 6th bushing Installing 4th main gear Installing 5th main gear Installing 6th main gear a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.
ST33061000 (J-8107-2) Drift	 ZZA1000D Installing bore plug Removing differential side bearing a: 38 mm (1.50 in) dia. b: 28.5 mm (1.122 in) dia.
ST33052000 (—) Drift	 ZZA1023D Installing welch plug Removing input shaft rear bearing Removing 5th bushing, thrust washer, 4th input gear, 4th gear bushing, 3rd-4th synchronizer hub and 3rd input gear Installing input shaft front bearing Removing 6th input gear and 6th bushing Removing mainshaft rear bearing Removing 4th main gear and 5th main gear Removing 6th main gear a: 22 mm (0.87 in) dia. b: 28 mm (1.10 in) dia.



PREPARATION

[RS6F51A]

Tool number (Kent-Moore No.) Tool name	Description
KV40105020 (—) Drift	 <p style="text-align: center; font-size: small;">ZZA1133D</p> <p>Removing 5th input gear and synchronizer hub Removing 3rd main gear, 2nd main gear, 2nd bushing, 1st-2nd synchronizer hub, 1st main gear, reverse main gear and 1st bushing a: 39.7 mm (1.563 in) dia. b: 35 mm (1.38 in) dia. c: 15 mm (0.59 in)</p>
KV40105710 (—) Press stand	 <p style="text-align: center; font-size: small;">ZZA1058D</p> <p>Installing 3rd-4th synchronizer hub Installing 4th bushing Installing 5th bushing Installing 5th-6th synchronizer hub Installing 2nd bushing Installing 3rd main gear a: 46 mm (1.81 in) dia. b: 41 mm (1.61 in)</p>
ST38220000 (—) Press stand	 <p style="text-align: center; font-size: small;">ZZA1058D</p> <p>Installing reverse main gear Installing 1st bushing Installing 1st-2nd synchronizer hub a: 63 mm (2.48 in) dia. b: 65 mm (2.56 in)</p>
ST30032000 (J-26010-01) Drift	 <p style="text-align: center; font-size: small;">ZZA0978D</p> <p>Installing input shaft front bearing a: 80 mm (3.15 in) dia. b: 38 mm (1.50 in) dia. c: 31 mm (1.22 in) dia.</p>
ST30901000 (J-26010-01) Drift	 <p style="text-align: center; font-size: small;">ZZA0978D</p> <p>Installing input shaft rear bearing Installing 4th main gear Installing 5th main gear Installing 6th main gear Installing mainshaft rear bearing a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35.2 mm (1.386 in) dia.</p>
ST30031000 (J-22912-01) Puller	 <p style="text-align: center; font-size: small;">ZZA0537D</p> <p>Measuring wear of 1st and 2nd baulk ring</p>
KV40101630 (J-35870) Drift	 <p style="text-align: center; font-size: small;">ZZA1003D</p> <p>Installing reverse main gear a: 68 mm (2.68 in) dia. b: 60 mm (2.36 in) dia.</p>

PREPARATION




[RS6F51A]

Tool number (Kent-Moore No.) Tool name	Description
KV38102510 (J-35870) Drift  ZZA0838D	Installing 1st bushing Installing 1st-2nd synchronizer hub Installing differential side bearing a: 71 mm (2.80 in) dia. b: 65 mm (2.56 in) dia.
— (J-39713) Drift  NT087	Measuring end play of side gear

A
B
MT
D
E
F

Commercial Service Tools

ECS0094T

Tool name	Description
Puller  ZZB0823D	Removing each bearing gear and bushing
Power tool  PBIC0190E	Loosening bolts and nuts
Puller  NT077	Removing each bearing gear and bushing
Pin punch  ZZA0815D	Removing and installing each retaining pin Tip: 4.5 mm (0.177 in) dia.

G
H
I
J
K
L
M

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

[RS6F51A]

NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

PFP:00003

NVH Troubleshooting Chart

ECS0094U

Use the chart below to help you find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

Reference page		MT-75	MT-75	MT-75	MT-76			MT-78	MT-88		MT-84			
Suspected parts (possible cause)		(oil level is low)	(wrong oil)	(oil level is high)	Gasket (damaged)	Oil seal (worn or damaged)	O-Ring (worn or damaged)	Control device and cable (worn)	Check plug return spring and check ball (worn or damaged)	Shift fork (worn)	Gear (worn or damaged)	Bearing (worn or damaged)	Baulk ring (worn or damaged)	Insert spring, shifting insert (damaged)
Symptom	Noise	1	2								3	3		
	Oil leakage		3	1	2	2	2							
	Hard to shift or will not shift		1	1				2					3	3
	Jumps out of gear							1	2	3	3			

DESCRIPTION

[RS6F51A]


DESCRIPTION

PF0:0000

Cross-sectional View

ECS0094V

RS6F51A



A

B

MT

D

E

F

G

H

I

J

K

L


M

WCIA0263E

- | | | |
|--------------------------------|---------------------------------------|---------------------------|
| 1. Input shaft rear bearing | 2. 6th input gear | 3. 5th & 6th synchronizer |
| 4. 5th input gear | 5. 4th input gear | 6. 3rd & 4th synchronizer |
| 7. 3rd input gear | 8. Reverse idler gear (rear) | 9. Reverse synchronizer |
| 10. Reverse idler gear (front) | 11. Reverse idler shaft | 12. Clutch housing |
| 13. Input shaft front bearing | 14. Input shaft | 15. Mainshaft |
| 16. Mainshaft front bearing | 17. Differential side bearing (front) | 18. Final gear |
| 19. Differential case | 20. Differential side bearing (rear) | 21. Reverse main gear |
| 22. 1st main gear | 23. 1st & 2nd synchronizer | 24. 2nd main gear |
| 25. 3rd main gear | 26. 4th main gear | 27. 5th main gear |
| 28. 6th main gear | 29. Mainshaft rear bearing | |


DOUBLE-CONE SYNCHRONIZER

The 3rd gear is equipped with a double-cone synchronizer to reduce the operating force of the shift lever as shown.




TRIPLE-CONE SYNCHRONIZER

The 1st and 2nd gears are equipped with a triple-cone synchronizer to reduce the operating force of the control lever as shown.



REVERSE GEAR

Description of reverse gear components is as shown.



M/T OIL**Replacement
DRAINING**

1. Start the engine and let it run to warm up the transaxle oil.
2. Stop the engine. Remove drain plug and drain oil.
3. Set a gasket on the drain plug and install it in the transaxle case.

Drain plug : 34.5 N·m (3.5 kg-m, 25 ft-lb)

CAUTION:
Do not reuse gasket.

FILLING

1. Remove speedometer pinion gear. Fill transaxle with new oil.

Oil grade and capacity : Refer to MA-12, "Fluids and Lubricants" .

2. After refilling oil, check oil level. Set a new O-ring on the speedometer pinion gear, then install it in transaxle case.

Speedometer pinion gear : 5.6 N·m (0.6 kg-m, 50 in-lb)


CAUTION:
Do not reuse O-ring.

**Checking
OIL LEAKAGE AND OIL LEVEL**

- Check that oil is not leaking from transaxle.
- Remove speedometer pinion gear.
- Measure oil level using suitable gauge as shown, and check if "L" is within the specifications.

Oil level "L" : 49 - 55 mm (1.93 - 2.17 in)

CAUTION:
Never start engine while checking oil level.



- Set a new O-ring on the speedometer pinion gear, then install it in the transaxle case.

Speedometer pinion gear : 5.6 N·m (0.6 kg-m, 50 in-lb)

CAUTION:
Do not reuse O-ring.

SIDE OIL SEAL


Removal and Installation

REMOVAL

1. Remove the drive shaft from the transaxle case. Refer to [FAX-11, "Removal and Installation"](#) .
2. Remove the oil seal with a slotted screwdriver as shown.

CAUTION:

Be careful not to damage the transaxle case surface when removing the oil seal.



INSTALLATION

Installation is in the reverse order of removal.


- Using Tool, drive the oil seal straight in until it protrudes from the transaxle case end equal to dimension "A" as shown.

Dimension "A" : Within 0.5 mm (0.02 in) or flush with the case.

Tool number : ST30720000 (J-25405)

CAUTION:

- Before installing oil seal, apply multi-purpose grease to oil seal lips.
- Do not reuse oil seal.
- Check the transaxle oil level after installation. Refer to [MA-28, "Checking M/T Oil"](#) .



POSITION SWITCH

Checking


NOTE:

For removal and installation of the switches. Refer to [MT-84, "CASE AND HOUSING COMPONENTS"](#).

BACK-UP LAMP SWITCH

- Check continuity.

Gear position	Continuity
Reverse	Yes
Except reverse	No



PARK/NEUTRAL POSITION SWITCH

- Check continuity.

Gear position	Continuity
Neutral	Yes
Except neutral	No


A
B
MT
D
E
F
G
H
I
J
K
L
M

CONTROL LINKAGE

PF3:34103

Removal and Installation of Control Device and Cable

ECS00950



WCIA0203E

- 1. Snap pin
- 2. Washer
- 3. Cable
- 4. Manual lever
- 5. Shift cable
- 6. Lock plate
- 7. Control device assembly
- 8. Lock plate
- 9. Select cable
- 10. Shift cable
- 11. Control lever knob
- 12. Control lever

CONTROL LINKAGE

[RS6F51A]

-
- | | | | |
|-----------------------------|--------------------|----------------------------|---|
| 13. Control device assembly | 14. Cover | 15. Select cable | |
| 16. Floor | 17. Pin | 18. Shift cable | A |
| 19. Washer | 20. Clutch housing | 21. Cable mounting bracket | |
| 22. Select cable | 23. Shift cable | 24. Lock plate | B |
| 25. Lock plate | | | |

CAUTION:

- Note that the select side lock plate for securing the control cable is different from the one on the shift side.
- After assembly, make sure selector lever automatically returns to Neutral when it is moved to 1st, 2nd, or Reverse.

MT

D

E

F

G

H

I


J

K

L

M

AIR BREATHER HOSE Removal and Installation



LCIA0034E

CAUTION:


- Make sure there are no pinched or restricted areas on the air breather hose caused by bending or winding when installing it.
- Insert the air breather hose into the transaxle tube until the overlap area reaches the spool.

TRANSAXLE ASSEMBLY

PF3:32010

Removal and Installation

ECS00952



REMOVAL

1. Remove the air cleaner and air duct. Refer to [EM-17, "AIR CLEANER AND AIR DUCT"](#) .
2. Remove the battery tray and battery.
3. Remove air breather hose from the transaxle.
4. Remove the clutch operating cylinder and position it aside without disconnecting the hydraulic lines. Refer to [CL-11, "Removal and Installation"](#) .

CAUTION:



Do not depress clutch pedal during removal procedure.

5. Remove the two shift cables from the transaxle. Refer to [MT-14, "Removal and Installation"](#) .
6. Disconnect and remove the harnesses for the back-up lamp switch and ground straps.
7. Remove the starter motor using power tool. Refer to [SC-17, "Removal and Installation"](#) .
8. Raise vehicle and remove the engine undercover and splash shields using power tool.
9. Drain the gear oil from the transaxle. Refer to [MT-11, "Replacement"](#) .
10. Disconnect and remove the harnesses for:
 - Vehicle speed sensor
 - PNP switch
 - Crankshaft position sensor
11. Remove the bolt and heated oxygen sensor harness clamp bracket, then remove the crankshaft position sensor.
12. Remove the exhaust front tube using power tool. Refer to [EX-7, "Removal and Installation"](#) .
13. Remove the drive shafts using power tool. Refer to [FAX-11, "Removal and Installation"](#) .


TRANSAXLE ASSEMBLY

[RS6F51A]

14. Lower vehicle, then install suitable engine slinger on the front of the left bank cylinder head, and the rear of the right bank cylinder head as shown.



15. Support the engine using an engine support fixture or suitable tool.
16. Remove the five upper bolts that mount the transaxle to the engine using power tool.
17. Disconnect the LH transaxle mounting insulator using power tool.
18. Raise vehicle, then remove front suspension member, LH engine insulator, and LH engine mount bracket. Refer to [EM-220, "REMOVAL"](#).
19. Place a suitable jack support under the transaxle.



CAUTION:

When setting the jack, be careful not to bring it into contact with the switches.

20. Remove the five lower bolts that mount the transaxle to the engine using power tool.
21. Remove the transaxle from the vehicle.

TRANSAXLE ASSEMBLY

[RS6F51A]

INSTALLATION


Installation is in the reverse order of removal.

- When installing the transaxle to the engine, use the specified tightening torque in the numerical sequence shown below:

CAUTION:

When installing the transaxle, do not allow the transaxle input shaft to make contact with the clutch cover.

Bolt No.	1	2	3	4	5	6	7	8	9	10
Bolt length "ℓ" mm (in)	40 (1.57)	82 (3.23)	47 (1.85)	47 (1.85)	52 (2.05)	40 (1.57)	40 (1.57)	40 (1.57)	30 (1.18)	30 (1.18)
Tightening torque N·m (kg·m, ft·lb)	30 - 40 (3.1 - 4.1, 22 - 29)		70 - 80 (7.1 - 8.1, 52 - 59)			30 - 40 (3.1 - 4.1, 22 - 29)				




TRANSAXLE ASSEMBLY

[RS6F51A]


ECS00953

Component Parts CASE AND HOUSING COMPONENTS



- | | | |
|--------------------------|---------------------------|----------------------------------|
| 1. Differential oil seal | 2. Ball pin | 3. Washer |
| 4. Back-up lamp switch | 5. Oil gutter | 6. Baffle plate |
| 7. Transaxle case | 8. Filler plug | 9. Gasket |
| 10. Welch plug | 11. Bore plug | 12. Drain plug |
| 13. Gasket | 14. Differential oil seal | 15. Park/Neutral position switch |
| 16. Air breather tube | 17. Input shaft oil seal | 18. Oil channel |
| 19. Magnet | 20. Clutch housing | 21. Speedometer pinion gear |
| 22. O-ring | | |

GEAR COMPONENTS




- | | | |
|---|---------------------------------------|--------------------------------|
| 1. Input shaft front bearing | 2. Input shaft | 3. Needle bearing |
| 4. 3rd input gear | 5. 3rd inner baulk ring | 6. 3rd gear synchronizer cone |
| 7. 3rd outer baulk ring | 8. Spread spring | 9. 3rd & 4th synchronizer hub |
| 10. 3rd & 4th shifting insert | 11. 4th baulk ring | 12. 3rd & 4th coupling sleeve |
| 13. Bushing | 14. Needle bearing | 15. 4th input gear |
| 16. Thrust washer | 17. Bushing | 18. Needle bearing |
| 19. 5th input gear | 20. 5th baulk ring | 21. 5th & 6th shifting insert |
| 22. 5th & 6th synchronizer hub | 23. 5th & 6th coupling sleeve | 24. Baulk ring |
| 25. 6th input gear | 26. Needle bearing | 27. Bushing |
| 28. Snap ring | 29. Input shaft rear bearing | 30. Oil channel |
| 31. Input shaft rear bearing adjusting shim | 32. Retaining pin | 33. Reverse idler shaft |
| 34. Thrust bearing | 35. Needle bearing | 36. Reverse idler gear (Front) |
| 37. Reverse baulk ring | 38. Reverse coupling sleeve | 39. Insert spring |
| 40. Reverse idler gear (Rear) | 41. Reverse idler gear adjusting shim | |

TRANSAXLE ASSEMBLY

[RS6F51A]


SEC. 322



SCIA0957E

- | | | |
|--------------------------------|---|--------------------------------|
| 1. Mainshaft front bearing | 2. Mainshaft bearing retainer | 3. Mainshaft |
| 4. Reverse main gear | 5. 1st main gear | 6. Bushing |
| 7. Needle bearing | 8. 1st inner baulk ring | 9. 1st gear synchronizer cone |
| 10. 1st outer baulk ring | 11. Spread spring | 12. 1st & 2nd shifting insert |
| 13. 1st & 2nd synchronizer hub | 14. 2nd outer baulk ring | 15. 2nd gear synchronizer cone |
| 16. 2nd inner baulk ring | 17. 1st & 2nd coupling sleeve | 18. Bushing |
| 19. Needle bearing | 20. 2nd main gear | 21. 3rd main gear |
| 22. 3rd & 4th mainshaft spacer | 23. 4th main adjusting shim | 24. 4th main gear |
| 25. 5th main gear | 26. 6th main gear | 27. Mainshaft rear bearing |
| 28. Mainshaft C-ring | 29. C-ring holder | 30. Snap ring |
| 31. Snap ring | 32. Mainshaft rear bearing adjusting shim | 33. 5th & 6th mainshaft spacer |
| 34. 6th main adjusting shim | | |


SHIFT CONTROL COMPONENTS



- | | | |
|---------------------------|------------------------------|--------------------------|
| 1. Reverse shift fork | 2. Shifter cap | 3. Reverse fork rod |
| 4. Reverse lever assembly | 5. 5th & 6th bracket | 6. 5th & 6th fork rod |
| 7. 5th & 6th shift fork | 8. Retaining pin | 9. 3rd & 4th bracket |
| 10. 3rd & 4th shift fork | 11. 3rd & 4th fork rod | 12. 1st & 2nd shift fork |
| 13. 1st & 2nd bracket | 14. 1st & 2nd fork rod | 15. Shift check sleeve |
| 16. Inter lock pin | 17. Check ball | 18. Shift check sleeve |
| 19. Check spring | 20. Check plug | 21. Control assembly |
| 22. O-ring | 23. Shift check | 24. Stopper bolt |
| 25. Stopper ring | 26. Reverse bracket fork rod | 27. Reverse bracket |

FINAL DRIVE COMPONENTS

SEC. 381




- | | | |
|---|---|------------------------------|
| 1. Differential side bearing outer race | 2. Differential side bearing | 3. Speedometer drive gear |
| 4. Differential case | 5. Final gear | 6. Differential side bearing |
| 7. Differential side bearing outer race | 8. Differential side bearing adjusting shim | 9. Pinion mate shaft |
| 10. Side gear | 11. Side gear thrust washer | 12. Pinion mate gear |
| 13. Pinion mate thrust washer | 14. Lock pin | |

Disassembly and Assembly

DISASSEMBLY

ECS00954

1. Remove the drain plug and filler plug.
2. Remove the park/neutral position switch and back-up lamp switch.
3. After removing the shift check and stopper bolt, remove the control assembly.




TRANSAXLE ASSEMBLY

[RS6F51A]


4. Remove the 2 check ball plugs, 2 check springs, 2 check balls as shown. Discard the check ball plugs.

CAUTION:

Check ball plugs are not reusable.



5. Remove the transaxle case fixing bolts as shown.



6. Remove the bore plug.


CAUTION:

Be careful not to damage transaxle case.


7. While spreading the snap ring of the mainshaft rear bearing located at bore plug hole, remove the transaxle case.
8. Remove the oil gutter and baffle plate.
9. Remove the snap ring, mainshaft rear bearing adjusting shim, and input shaft rear bearing adjusting shim from the transaxle case.

10. Remove the differential side bearing outer race (transaxle case side) using Tool as shown, and then remove the adjusting shim.

Tool number : KV381054S0 (J-34286)



11. Remove the welch plug with a suitable punch and hammer as shown.




A
B
MT
D
E
F
G
H
I
J
K
L
M

TRANSAXLE ASSEMBLY

[RS6F51A]

12. Remove the differential oil seal with a suitable tool as shown.



13. Remove the magnet from the clutch housing.

14. Remove the reverse check ball plug, reverse check spring, reverse shift check sleeve, and check ball. Discard the check ball.


CAUTION:

- Do not reuse the check ball plug.
- Do not drop the check ball.

15. With the shift lever in 5th position, remove the bracket bolts from the reverse lever assembly as shown. Lift the reverse lever assembly to remove.


CAUTION:

Retain the shifter cap for installation.



16. Pull out the reverse fork rod then remove the reverse shift fork.


17. Remove the retaining pin of the reverse bracket.



18. Pull out the reverse lever and the reverse bracket fork rod.

19. Remove the check ball (2 pieces) and the interlock pin.


20. Shift the 3rd-4th fork rod to the 3rd position. Remove the retaining pin of the 5th-6th shift fork using a pin punch.



TRANSAXLE ASSEMBLY

[RS6F51A]

21. Remove the stopper rings for the 5th-6th bracket.




22. Pull out the 5th-6th fork rod and remove the 5th-6th shift fork and the 5th-6th bracket.

23. Remove the check balls (2 pieces) and interlock pin.

24. Remove the retaining pin of 3rd-4th bracket using pin punch.


25. Remove the stopper rings for 3rd-4th shift fork.



26. Pull out the 3rd-4th fork rod and remove 3rd-4th shift fork and bracket.

27. Remove the shift check sleeve from the clutch housing.

28. Remove the retaining pin of 1st-2nd shift fork using a suitable pin punch.



29. Pull out the 1st-2nd fork rod with bracket.

30. Remove the 1st-2nd shift fork.

31. Remove the retaining pin of 1st-2nd bracket using a suitable pin punch and separate the fork rod and bracket.


32. Remove the gear components from the clutch housing.

a. While tapping the input shaft with a plastic hammer, remove the input shaft assembly, mainshaft assembly, and reverse idler gear assembly as a set.

CAUTION:

Always withdraw the mainshaft straight out. Failure to do so can damage the resin oil channel on the clutch housing side.

b. Remove the final drive assembly.




A
B
MT
D
E
F
G
H
I
J
K
L
M

TRANSAXLE ASSEMBLY


[RS6F51A]

33. Remove the bearing retainer and then the mainshaft front bearing as shown.
34. Remove the oil channel on the mainshaft side.




35. Remove the differential oil seal (clutch housing side).
36. Remove the differential side bearing outer race (clutch housing side) using Tool as shown.

Tool number : **KV381054S0 (J-34286)**



37. Remove the input shaft oil seal using a suitable tool as shown.

CAUTION:
Do not damage the clutch housing sealing surface.




ASSEMBLY

1. Install a new input shaft oil seal from the clutch housing end of the side, to the depth of 1.8 - 2.8 mm (0.071 - 0.110 in) using Tool as shown.

Tool number : **ST35321000 (—)**

CAUTION:
Oil seals are not reusable.




TRANSAXLE ASSEMBLY

[RS6F51A]

2. Install a new differential oil seal using Tool as shown.


Tool number : ST30720000 (J-25405)

CAUTION:
Oil seals are not reusable.



3. Install the oil channel on the mainshaft side as shown.


CAUTION:
Position the oil channel with the orientation as shown, for installation.



4. Install the mainshaft front bearing using Tool as shown.

Tool number : ST33200000 (J-26082)


CAUTION:
Position the mainshaft front bearing with the orientation as shown, for installation.



5. Install the mainshaft front bearing retainer.


CAUTION:
Install the bearing retainer with the punched surface facing up.

Retainer bolt : 6.27 - 8.33 N·m (0.64 - 0.84 kg·m,
56 - 73 in-lb)



6. Install the differential side bearing outer race using Tool as shown.

Tool number : ST30720000 (J-25405)




A
B
MT
D
E
F
G
H
I
J
K
L
M

TRANSAXLE ASSEMBLY


[RS6F51A]

7. Install the final drive assembly into the clutch housing.




8. Install the input shaft assembly, mainshaft assembly, and reverse idler gear assembly into the clutch housing.

CAUTION:
Do not damage the input shaft oil seal.




9. Install the 1st-2nd fork rod bracket onto the 1st-2nd fork rod, and then install a new retaining pin as shown.

CAUTION:
Retaining pins are not reusable.



10. Install the 1st-2nd fork rod and the 1st-2nd shift fork, and then install a new retaining pin.

CAUTION:
Retaining pins are not reusable.



11. Install the shift check sleeve.

12. Install the 3rd-4th bracket, 3rd-4th shift fork, and 3rd-4th fork rod with the interlock pin.

TRANSAXLE ASSEMBLY


[RS6F51A]

13. Install the new stopper rings onto the 3rd-4th shift fork.

CAUTION:
Stopper rings are not reusable.

14. Install a new retaining pin onto the 3rd-4th bracket.

CAUTION:
Retaining pins are not reusable.




15. Install the 2 check balls.

16. Install the 5th-6th bracket, 5th-6th shift fork, and 5th-6th fork rod.


17. Install new stopper rings onto the 5th-6th bracket with interlock pin.

CAUTION:
Stopper rings are not reusable.



18. Install a new retaining pin onto the 5th-6th shift fork.

CAUTION:
Retaining pins are not reusable.



19. Install the two check balls.

20. Install the 5th-6th check ball, 5th-6th shift check sleeve, 5th-6th check spring, and the 5th-6th check ball plug.


CAUTION:

- Do not reuse the check ball plug.
- Do not drop the check ball.

21. Install the reverse bracket fork rod and reverse lever bracket.

22. Install a new retaining pin onto the reverse bracket.

CAUTION:
Retaining pins are not reusable.



23. Install the reverse shift fork and reverse fork rod.

A
B
MT
D
E
F
G
H
I
J
K
L
M


24. Install the reverse lever assembly using the following steps:

- a. Install the shifter cap onto the reverse lever assembly cam, and then install them onto the reverse shift fork.

CAUTION:


Do not drop the shifter cap.

- b. While lifting the reverse shift fork, align the cam with the reverse bracket.



- c. Tighten the bracket bolts to specification, and install the reverse lever assembly.

Bracket bolts : 13.7 N·m (1.4 kg·m, 10 ft·lb)



25. Install the check ball, reverse shift check sleeve, reverse check spring, and the reverse check ball plug.

CAUTION:

- Do not reuse the check ball plug.
- Do not drop the check ball.

26. Install the magnet onto the clutch housing.

27. Install the selected input shaft adjusting shim onto the input shaft. Refer to [MT-99, "INPUT SHAFT END PLAY"](#) .

28. Install selected differential side bearing adjusting shim and differential side bearing outer race. Refer to [MT-100, "DIFFERENTIAL SIDE BEARING PRELOAD"](#) .

29. Install the baffle plate and oil gutter.

30. Install the transaxle case using the following steps:

- a. Install the selected mainshaft rear bearing adjusting shim into the transaxle case. Refer to [MT-101, "MAINSHAFT END PLAY"](#) .

- b. Temporarily install the snap ring of the mainshaft rear bearing into the transaxle case.


CAUTION:

Do not reuse the snap ring.

- c. Apply sealant to the mating surfaces of the transaxle case and clutch housing as shown. Use Genuine Silicone RTV or equivalent. Refer to [GI-45, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#) .

CAUTION:


Remove any old sealant adhering to the mounting surfaces. Also remove any moisture, oil, or foreign material adhering to the sealant application and mounting surfaces.




TRANSAXLE ASSEMBLY

[RS6F51A]

- d. Using a snap ring of the mainshaft rear bearing temporarily, install the transaxle case over the clutch housing as shown.



- e. Through the bore plug mounting hole, with the snap ring stretched, lift up the mainshaft assembly from the control assembly mounting hole.
 f. Securely install the snap ring onto the mainshaft rear bearing as shown.




- g. Tighten the "A" bolts (gold) and new "B" bolts (black) to specification.

"A" Bolt : 52.0 N-m (5.3 kg-m, 38 ft-lb)

"B" Bolt : 65.0 N-m (6.6 kg-m, 48 ft-lb)

CAUTION:

Always replace the "B" bolts as they are self-sealing bolts.



- h. Apply gear oil to the O-ring and install it to the control assembly. Then install control assembly to transaxle case. Tighten bolts to the specified torque. Refer to [MT-87, "SHIFT CONTROL COMPONENTS"](#).

CAUTION:

Do not reuse the O-ring.

- i. Install a new shift check and a new stopper bolt.

CAUTION:

Shift check and stopper bolt are not reusable.


TRANSAXLE ASSEMBLY

[RS6F51A]

31. Install a new bore plug using Tool as shown.

Tool number : ST33061000 (J-8107-2)


CAUTION:
Bore plugs are not reusable.



32. Install the new welch plug using Tool as shown.


Tool number : ST33052000 (—)

CAUTION:
Do not reuse the welch plug.




33. Install the 2 check balls, 2 check springs, and the 2 new check ball plugs.

CAUTION:
Check ball plugs are not reusable.



34. Apply sealant to the threads of the park/neutral position switch and back-up lamp switch. Then install them into the transaxle case. Refer to [MT-84, "CASE AND HOUSING COMPONENTS"](#). Use Genuine Silicone RTV or equivalent. Refer to [GI-45, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#).




35. Install new gaskets onto the drain plug and filler plug, and then install them into the transaxle case.

CAUTION:

- Gaskets are not reusable.
- After oil is filled, tighten filler plug to specification. Refer to [MT-84, "CASE AND HOUSING COMPONENTS"](#).

Adjustment INPUT SHAFT END PLAY

- When adjusting the input shaft end play, select the adjusting shim for the input shaft bearing. To select the correct thickness for the adjusting shim, measure the clearance between the transaxle case and input shaft rear bearing.
- Calculate the dimension "O" (thickness of adjusting shim) using the following steps to adjust the input shaft rear bearing for the specified end play.



CAUTION:

Only 1 adjusting shim can be selected.

End play : 0 - 0.06 mm (0 - 0.0024 in)

Dimension "O" = (O₁ - O₂) - End play

"O" : Thickness of adjusting shim


"O₁" : Distance between transaxle case end face and mounting face of adjusting shim

"O₂" : Distance between clutch housing case end face and end face of input shaft rear bearing


Adjusting Shims

Shim thickness	Part number	Shim thickness	Part number	Shim thickness	Part number
0.40 mm (0.0157 in)	32225 8H500	0.88 mm (0.0346 in)	32225 8H512	1.36 mm (0.0535 in)	32225 8H524
0.44 mm (0.0173 in)	32225 8H501	0.92 mm (0.0362 in)	32225 8H513	1.40 mm (0.0551 in)	32225 8H560
0.48 mm (0.0189 in)	32225 8H502	0.96 mm (0.0378 in)	32225 8H514	1.44 mm (0.0567 in)	32225 8H561
0.52 mm (0.0205 in)	32225 8H503	1.00 mm (0.0394 in)	32225 8H515	1.48 mm (0.0583 in)	32225 8H562
0.56 mm (0.0220 in)	32225 8H504	1.04 mm (0.0409 in)	32225 8H516	1.52 mm (0.0598 in)	32225 8H563
0.60 mm (0.0236 in)	32225 8H505	1.08 mm (0.0425 in)	32225 8H517	1.56 mm (0.0614 in)	32225 8H564
0.64 mm (0.0252 in)	32225 8H506	1.12 mm (0.0441 in)	32225 8H518	1.60 mm (0.0630 in)	32225 8H565
0.68 mm (0.0268 in)	32225 8H507	1.16 mm (0.0457 in)	32225 8H519	1.64 mm (0.0646 in)	32225 8H566
0.72 mm (0.0283 in)	32225 8H508	1.20 mm (0.0472 in)	32225 8H520		
0.76 mm (0.0299 in)	32225 8H509	1.24 mm (0.0488 in)	32225 8H521		
0.80 mm (0.0315 in)	32225 8H510	1.28 mm (0.0504 in)	32225 8H522		
0.84 mm (0.0331 in)	32225 8H511	1.32 mm (0.0520 in)	32225 8H523		

- Using a depth micrometer and straight edge, measure the dimension "O₁" between the transaxle case end face and mounting face of the adjusting shim as shown.



- Using a depth micrometer and straight edge, measure the dimension "O₂" between the clutch housing case end face and end face of the input shaft rear bearing as shown.



- Install the selected input shaft rear bearing adjusting shim onto the input shaft.

DIFFERENTIAL SIDE BEARING PRELOAD

- When adjusting differential side bearing preload, select adjusting shim for differential side bearing. To select adjusting shim, measure clearance "L" between transaxle case and differential side bearing outer race.
- Calculate dimension "L" (thickness of adjusting shim) using the following procedure to meet specification of preload for differential side bearing.


Preload : 0.15 - 0.21 mm (0.0059 - 0.0083 in)

Dimension "L" = ("L₁" - "L₂") + Preload

"L" : Thickness of adjusting shim

"L₁" : Distance between transaxle case end face and mounting face of adjusting shim

"L₂" : Distance between differential side bearing and clutch housing end face




CAUTION:

Up to only 2 adjusting shims can be selected.

Adjusting Shim

Shim thickness	Part number
0.48 mm (0.0189 in)	31438 80X00
0.52 mm (0.0205 in)	31438 80X01
0.56 mm (0.0220 in)	31438 80X02
0.60 mm (0.0236 in)	31438 80X03
0.64 mm (0.0252 in)	31438 80X04
0.68 mm (0.0268 in)	31438 80X05
0.72 mm (0.0283 in)	31438 80X06
0.76 mm (0.0299 in)	31438 80X07
0.80 mm (0.0315 in)	31438 80X08
0.84 mm (0.0331 in)	31438 80X09
0.88 mm (0.0346 in)	31438 80X10
0.92 mm (0.0362 in)	31438 80X11


- Using a depth micrometer and straight edge, measure the dimension "L₁" between the transaxle case end face and mounting face of the adjusting shim as shown.



TRANSAXLE ASSEMBLY


[RS6F51A]

2. Install the outer race onto the differential side bearing on the final gear side. Holding the outer race horizontally by hand, rotate the final gear five times or more (for smooth movement of the bearing roller).
3. Using a depth micrometer and straight edge, measure the dimension "L2" between the differential side bearing outer race and clutch housing end face as shown.



4. Install the selected adjusting shim and then the differential side bearing outer race using Tool as shown.

Tool number : ST30720000 (J-25405)



MAINSHAFT END PLAY


- When adjusting the mainshaft end play, select the adjusting shim for the mainshaft rear bearing. To select the adjusting shim, measure clearance "M" between the transaxle case and mainshaft rear bearing.
- Calculate the dimension "P" (thickness of adjusting shim) using the following procedure to meet specification of end play for mainshaft rear bearing.

End play : 0 - 0.06 mm (0 - 0.0024 in)

Dimension "P" = "M" - End play

"P" : Thickness of adjusting shim

"M" : Distance between mainshaft rear bearing and transaxle case




CAUTION:

Only 1 adjusting shim can be selected.

Adjusting Shim

Shim thickness	Part number
0.44 mm (0.0173 in)	32238 8H510
0.48 mm (0.0189 in)	32238 8H511
0.52 mm (0.0205 in)	32238 8H512
0.56 mm (0.0220 in)	32238 8H513
0.60 mm (0.0236 in)	32238 8H514
0.64 mm (0.0252 in)	32238 8H515
0.68 mm (0.0268 in)	32238 8H516
0.72 mm (0.0283 in)	32238 8H517
0.76 mm (0.0299 in)	32238 8H518
0.80 mm (0.0315 in)	32238 8H519
0.84 mm (0.0331 in)	32238 8H520
0.88 mm (0.0346 in)	32238 8H521
0.92 mm (0.0362 in)	32238 8H522
0.96 mm (0.0378 in)	32238 8H523
1.00 mm (0.0394 in)	32238 8H524
1.04 mm (0.0409 in)	32238 8H560
1.08 mm (0.0425 in)	32238 8H561

1. Install the mainshaft assembly to the clutch housing.
2. Install the snap ring to the transaxle case.
3. Install the transaxle case to clutch housing, and temporarily assemble them with bolts. Temporarily install the snap ring to the mainshaft rear bearing.
4. Install the dial gauge to the snap ring access hole, and expand the snap ring as shown. Lift the mainshaft assembly through the control assembly installation hole, and push it against the transaxle case. This state shall be defined as base. Moving the distance of the mainshaft assembly, with the snap ring installed on the main bearing, becomes "M".



REVERSE IDLER GEAR END PLAY

- When adjusting the reverse idler gear end play, select the adjusting shim for the reverse idler gear. To select the correct thickness of adjusting shim, measure the clearance between the transaxle case and reverse idler gear.
- Calculate the dimension "Q" (thickness of adjusting shim) using the following steps to adjust the end play of the reverse idler gear to specification.


End play : 0.04 - 0.10 mm (0.0016 - 0.0039 in)

Dimension "Q" = ("Q1 " - "Q2 ") – End play

"Q" : Thickness of adjusting shim

"Q1 " : Distance between transaxle case end face and mounting face of adjusting shim

"Q2 " : Distance between clutch housing case end face and end face of reverse idler gear



CAUTION:

Only 1 adjusting shim can be selected.

TRANSAXLE ASSEMBLY

[RS6F51A]


Adjusting Shim

Shim thickness mm (in)	Part number	Shim thickness mm (in)	Part number
1.76 (0.0693)	32237 8H800	2.24 (0.0882)	32237 8H812
1.80 (0.0709)	32237 8H801	2.28 (0.0898)	32237 8H813
1.84 (0.0724)	32237 8H802	2.32 (0.0913)	32237 8H814
1.88 (0.0740)	32237 8H803	2.36 (0.0929)	32237 8H815
1.92 (0.0756)	32237 8H804	2.40 (0.0945)	32237 8H816
1.96 (0.0772)	32237 8H805	2.44 (0.0961)	32237 8H817
2.00 (0.0787)	32237 8H806	2.48 (0.0976)	32237 8H818
2.04 (0.0803)	32237 8H807	2.52 (0.0992)	32237 8H819
2.08 (0.0819)	32237 8H808	2.56 (0.1008)	32237 8H820
2.12 (0.0835)	32237 8H809	2.60 (0.1024)	32237 8H821
2.16 (0.0850)	32237 8H810	2.64 (0.1039)	32237 8H822
2.20 (0.0866)	32237 8H811		


CAUTION:

Only 1 adjusting shim can be selected.

- Using a depth micrometer and straight edge, measure the dimension "Q₁" between the transaxle case end face and the mounting face of the adjusting shim as shown.



- Using a depth micrometer and straight edge, measure the dimension "Q₂" between the clutch housing case end face and the end face of reverse idler gear as shown.



- Install the selected reverse idler gear adjusting shim onto the reverse idler gear.

INPUT SHAFT AND GEARS

Disassembly and Assembly DISASSEMBLY

1. Before disassembling, measure the end play for the 3rd, 4th, 5th, and 6th input gears.

End play standard values

3rd gear : 0.18 - 0.31 mm (0.0071 - 0.0122 in)


4th gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)

5th gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)

6th gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)

CAUTION:

If the measurement is outside the standard value, disassemble to check the contact surfaces of the gear, shaft, and hub. Adjust using the correct size snap ring for assembly.




2. Remove the oil channel.
3. Remove the input shaft rear bearing using Tool as shown.

Tool number

A: Commercial service tool

B: ST33052000 (—)

4. Remove the snap ring.




5. Remove the 6th input gear, 6th bushing, and 6th needle bearing using Tool as shown.

Tool number

A: Commercial service tool

B: ST33052000 (—)

6. Remove the 6th baulk ring, 5th-6th coupling sleeve, and shifting insert.




7. Remove the 5th input gear and synchronizer hub assembly simultaneously using Tool as shown.

Tool number

A: KV40105020 (—)

B: Commercial service tool

8. Remove the 5th needle bearing.



INPUT SHAFT AND GEARS

[RS6F51A]

9. Remove the 5th bushing, thrust washer, 4th input gear, 4th needle bearing, 4th bushing, 4th baulk ring, 3rd-4th synchronizer hub assembly, 3rd baulk ring, and 3rd input gear simultaneously using Tool as shown.



Tool number

A: ST33052000 (—)

B: Commercial service tool

10. Remove the 3rd needle bearing.

11. Remove the input shaft front bearing using Tool as shown.




INSPECTION AFTER DISASSEMBLY

Input Shaft and Gear

Check the items listed. If necessary, replace them with new ones.


- Damage, peeling, dent, uneven wear, or bending of the input shaft.
- Excessive wear, damage, or peeling of the input gears.



Synchronizer


Check the items listed. If necessary, replace them with new ones.

- Damage and excessive wear of the contact surfaces of coupling sleeve, synchronizer hub, and shifting insert.
- Coupling sleeve and synchronizer hub must move smoothly as shown.



A
B
MT
D
E
F
G
H
I
J
K
L
M

- If any cracks, damage, or excessive wear is found on the cam face of baulk ring or working face of the insert as shown, replace it.



Baulk Ring Clearance for Single Cone Synchronizer (4th, 5th and 6th)


- Press the baulk ring against cone, and measure clearance between baulk ring and cone. If measurement is below limit, replace it with a new one.

Clearance - standard

4th : 0.9 - 1.45 mm (0.035 - 0.0571 in)

5th and 6th : 0.95 - 1.4 mm (0.0374 - 0.055 in)

Limit : 0.7 mm (0.028 in)




Baulk Ring Clearance for Double-cone Synchronizer (3rd)

- Follow the instructions below and inspect the clearance of the outer baulk ring, synchronizer cone, and inner baulk ring.

CAUTION:

Outer baulk ring, synchronizer cone, and inner baulk ring act as a set to control the clearances "A" and "B". If the measurement exceeds the service limit value, replace all of them as a set.




1. Using a dial gauge and Tool, measure clearance "A" at two or more points diagonally opposite, and calculate mean value.

Tool number : ST30031000 (J-22912-01)

Clearance "A"

Standard : 0.6 - 0.8 mm (0.024 - 0.031 in)

Limit value : 0.2 mm (0.008 in)



INPUT SHAFT AND GEARS


[RS6F51A]

- Using a feeler gauge, measure clearance "B" at two or more points diagonally opposite, and calculate mean value as shown.

Clearance "B"

Standard : 0.6 - 1.1 mm (0.024 - 0.043 in)


Limit value : 0.2 mm (0.008 in)



Bearing

Check the item listed. If necessary, replace it with a new one.

- Damage and rough rotation of the bearing as shown.




ASSEMBLY


- Install the 3rd needle bearing.
- Install the 3rd input gear and 3rd baulk ring.
- Install the spread spring, shifting insert, and a new 3rd-4th synchronizer hub onto the 3rd-4th coupling sleeve.

CAUTION:

- Install with the orientation of the new synchronizer hub as shown.
- Do not reuse the 3rd-4th synchronizer hub.




- Install with the orientation of the coupling sleeve as shown.



INPUT SHAFT AND GEARS

[RS6F51A]


- Do not hook the ends of the two spread springs (front and back have two each) on the same shifting insert.



4. Install the 3rd-4th synchronizer assembly using Tool as shown.

Tool number : KV40105710 (—)


CAUTION:
Align grooves of the shifting insert and 3rd baulk ring.



5. Install the 4th bushing using Tool as shown.

Tool number : KV40105710 (—)


6. Install the 4th baulk ring.
7. Install the 4th input gear and 4th needle bearing.



8. Measure the dimension "C2" as shown. Select a suitable thrust washer so that dimension "C2" satisfies the standard dimension specification. Then install the thrust washer onto the input shaft.

Standard for dimension "C2" : 154.7 - 154.8 mm
(6.091 - 6.094 in)

CAUTION:
Only 1 thrust washer can be selected.



INPUT SHAFT AND GEARS

[RS6F51A]

Thrust Washer


Thickness	Part number	Thickness	Part number
3.84 mm (0.1512 in)	32347 8H500	4.02 mm (0.1583 in)	32347 8H503
3.90 mm (0.1535 in)	32347 8H501	4.08 mm (0.1606 in)	32347 8H504
3.96 mm (0.1559 in)	32347 8H502	4.14 mm (0.1630 in)	32347 8H505

9. Install the 5th bushing using Tool as shown.

Tool number : KV40105710 (—)

10. Install the 5th needle bearing and 5th input gear.


11. Install the 5th baulk ring.




12. Install the synchronizer assembly onto a new 5th-6th synchronizer hub.

CAUTION:

- Install with the orientation of the new synchronizer hub as shown.
- Do not reuse the 5th-6th synchronizer hub.



- Do not hook the ends of the 2 spread springs (front and back have two each) on the same shifting insert.




13. Install the 5th-6th synchronizer hub assembly using Tool as shown.

Tool number : KV40105710 (—)

CAUTION:

Align the grooves of the 5th-6th shifting insert and the 5th-6th baulk ring.




INPUT SHAFT AND GEARS

[RS6F51A]

14. Install the needle bearing, 6th input gear and then 6th bushing using Tool as shown.


Tool number : **ST33200000 (J-26082)**



15. Install the snap ring onto the input shaft, and measure to check that end play (gap between snap ring and groove) of the 6th bushing is within specification.

End play standard value : **0 - 0.1 mm (0 - 0.004 in)**

- If the measurement is outside the standard value, select the appropriate size snap ring.




Snap Rings

Thickness	Part number	Thickness	Part number
1.76 mm (0.0693 in)	32204 8H511	2.01 mm (0.0791 in)	32204 8H516
1.81 mm (0.0713 in)	32204 8H512	2.06 mm (0.0811 in)	32204 8H517
1.86 mm (0.0732 in)	32204 8H513	2.11 mm (0.0831 in)	32204 8H518
1.91 mm (0.0752 in)	32204 8H514	2.16 mm (0.0850 in)	32204 8H519
1.96 mm (0.0772 in)	32204 8H515	2.21 mm (0.0871 in)	32204 8H520

16. Install the input shaft rear bearing using Tool as shown.

Tool number : **ST30901000 (J-26010-01)**


CAUTION:
Install input shaft rear bearing with its brown surface facing the input gear side.



17. Install the input shaft front bearing using Tool as shown.

Tool number **A: ST33052000 (—)**
B: ST30032000 (J-26010-01)

18. Install the oil channel onto the input shaft.



INPUT SHAFT AND GEARS

[RS6F51A]

19. Check the end play of the 3rd, 4th, 5th and 6th input gears as shown.


End play standard values

3rd gear : 0.18 - 0.31 mm (0.0071 - 0.0122 in)

4th gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)

5th gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)

6th gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)



A

B

MT

D

E

F

G

H

I

J


K

L

M

9. Remove the 3rd main gear, 2nd main gear, 2nd gear needle bearing, 2nd bushing, 1st-2nd synchronizer assembly, 1st main gear, reverse main gear, 1st gear needle bearing, and 1st bushing simultaneously using Tool as shown.

Tool number : KV40105020 (—)




INSPECTION AFTER DISASSEMBLY

Mainshaft and Gears

Check the items listed as shown. If necessary, replace them with new ones.


- Damage, peeling, dent, uneven wear, and bending of the mainshaft.
- Excessive wear, damage and peeling of the mainshaft gears.




Synchronizer

Check the items listed as shown. If necessary, replace them with new ones.

- Damage, excessive wear on contact surfaces of the coupling sleeve, synchronizer hub, and shifting insert.
- Coupling sleeve and synchronizer hub must move smoothly as shown.



- If any cracks, damage, or excessive wear is found on the cam face of baulk ring or working face of the insert as shown, replace it.



A
B
MT
D
E
F
G
H
I
J
K
L
M

Triple Cone Synchronizer (1st and 2nd)


- Check the clearance of the outer baulk ring, synchronizer cone, and inner baulk ring of the 1st and 2nd triple cone synchronizers, using the following procedure.

CAUTION:

The outer baulk ring, synchronizer cone, and inner baulk ring operate as a set to control the clearances “A”, “B”, and “C”. If the measured clearances exceed the service limit value, replace the components as a set.

NOTE:

To calculate the mean value of two or more measured values, add the highest and lowest measured values and divide by two.




- Press the baulk ring on to the clutch gear taper cone by hand, then measure the clearance “A” at two or more points diagonally opposite with a feeler gauge, and then calculate the mean value.

Clearance “A”

Standard : 0.6 - 1.2 mm (0.024 - 0.047 in)

Limit : 0.3 mm (0.012 in)




- Measure clearances “B” at two or more points diagonally opposite with a feeler gauge, and then calculate the mean value.

Clearance “B”

Standard : 0.6 - 1.1 mm (0.024 - 0.043 in)

Limit : 0.2 mm (0.008 in)




- Press the baulk ring on to the clutch gear taper cone by hand, then measure the clearance “C” at two or more points diagonally opposite with a feeler gauge, and then calculate the mean value.

Clearance “C”

Standard : 0.7 - 1.1 mm (0.028 - 0.043 in)


Limit : 0.3 mm (0.012 in)



Bearing

Check the item listed. If necessary, replace it with a new one.

- Damage and rough rotation of the bearing as shown.



ASSEMBLY


1. Install the reverse main gear using Tools as shown.

Tool number

A: ST35321000 (—)


B: KV40101630 (J-35870)

C: ST38220000 (—)



CAUTION:

Install with the orientation of reverse main gear as shown.



2. Install the 1st bushing using Tool as shown.


Tool number

A: ST35321000 (—)

B: KV38102510 (J-35870)

C: ST38220000 (—)

3. Install the needle bearing, and then the 1st main gear.




4. Install the spread spring, shifting insert, and a new 1st-2nd synchronizer hub onto the 1st-2nd coupling sleeve.


A
B
MT
D
E
F
G
H
I
J
K
L
M

CAUTION:


- Install with the orientation of the new synchronizer hub as shown.
- Do not reuse 1st-2nd synchronizer hub



- Install with the orientation of coupling sleeve as shown.



- Do not hook the ends of the two spread springs (front and back have two each) on the same shifting insert.




5. Install the 1st gear synchronizer assembly onto the mainshaft, and the synchronizer hub assembly onto the mainshaft using Tool as shown.

Tool number **A: ST35321000 (—)**
 B: KV38102510 (J-35870)
 C: ST38220000 (—)

CAUTION:

- Outer baulk ring, synchronizer cone, and inner baulk ring on the 2nd gear-side must have been removed.
- Install the coupling sleeve with the proper orientation.




MAINSHAFT AND GEARS

[RS6F51A]

6. Install the 2nd bushing using Tool as shown.

Tool number **A: ST35321000 (—)**
 B: KV40105710 (—)

7. Install the outer baulk ring, synchronizer cone, and inner baulk ring on 2nd gear-side.
 8. Install the 2nd needle bearing and 2nd gear.




9. Install the 3rd main gear.

Tool number **A: ST35321000 (—)**
 B: KV40105710 (—)

CAUTION:
Install the 3rd main gear with the orientation as shown.


10. Install the 3rd-4th mainshaft spacer.



11. Measure the dimension "C1" . Select a suitable adjusting shim so that the dimension "C1 " satisfies the standard dimension specification, and install it onto the mainshaft.

Standard for dimension "C1" : 173.85 - 173.95 mm (6.844 - 6.848 in)

CAUTION:
Only 1 adjusting shim can be selected.



Adjusting Shim

Thickness	Part number	Thickness	Part number
0.52 mm (0.0205 in)	32238 8H500	0.84 mm (0.0331 in)	32238 8H504
0.60 mm (0.0236 in)	32238 8H501	0.92 mm (0.0362 in)	32238 8H505
0.68 mm (0.0268 in)	32238 8H502	1.00 mm (0.0394 in)	32238 8H506
0.76 mm (0.0299 in)	32238 8H503	1.08 mm (0.0425 in)	32238 8H507

MAINSHAFT AND GEARS

[RS6F51A]

12. Install the 4th main gear with the specified orientation, using Tool as shown.


Tool number

A: ST33200000 (J-26082)

B: ST30901000 (J-26010-01)

CAUTION:

Install the 4th main gear with the orientation as shown.



13. Install the 5th main gear with the specified orientation, using Tool as shown.

Tool number


A: ST33200000 (J-26082)

B: ST30901000 (J-26010-01)

CAUTION:

Install the 5th main gear with the orientation as shown.

14. Install the 5th-6th mainshaft spacer.




15. Install the 6th main gear using Tool as shown.

Tool number

A: ST33200000 (J-26082)

B: ST30901000 (J-26010-01)



16. Select the 6th main adjusting shim and then install it onto the mainshaft.

- Calculate thickness "S" of 6th main adjusting shim by procedure below so that end play dimension between 6th main gear and mainshaft rear bearing becomes the dimension specified.

End play : 0 - 0.1 mm (0 - 0.004 in)

Dimension "S" = ("S1 " - "S2 ") - End play


"S" : Thickness of adjusting shim

"S1" : Dimension from mainshaft standard face to mainshaft rear bearing press-fit end face

"S2" : Dimension from mainshaft standard face to 6th main gear end face

CAUTION:

Only 1 adjusting shim can be selected.



MAINSHAFT AND GEARS

[RS6F51A]

Adjusting Shim


Thickness	Part number	Thickness	Part number
0.88 mm (0.0346 in)	32237 8H560	1.20 mm (0.0472 in)	32237 8H564
0.96 mm (0.0378 in)	32237 8H561	1.28 mm (0.0504 in)	32237 8H565
1.04 mm (0.0409 in)	32237 8H562	1.36 mm (0.0535 in)	32237 8H566
1.12 mm (0.0441 in)	32237 8H563		

- a. Using a height gauge, measure the dimension "S1" and "S2" as shown.
 - b. Install the selected 6th main adjusting shim to the mainshaft.
17. Install the mainshaft rear bearing using Tool as shown.

Tool number

A: ST30720000 (J-25405)


B: ST30901000 (J-26010-01)



18. Install the C-ring onto the mainshaft, and check that the end play of mainshaft rear bearing meets specifications.

End play standard value : 0 - 0.06 mm (0 - 0.0024 in)


- If the measurement is outside the specified standard value, reselect a new C-ring.



C-Ring

Thickness	Part number	Thickness	Part number
2.535 mm (0.0998 in)	32348 8H800	2.835 mm (0.1116 in)	32348 8H810
2.565 mm (0.1010 in)	32348 8H801	2.865 mm (0.1128 in)	32348 8H811
2.595 mm (0.1022 in)	32348 8H802	2.895 mm (0.1140 in)	32348 8H812
2.625 mm (0.1033 in)	32348 8H803	2.925 mm (0.1152 in)	32348 8H813
2.655 mm (0.1045 in)	32348 8H804	2.955 mm (0.1163 in)	32348 8H814
2.685 mm (0.1057 in)	32348 8H805	2.985 mm (0.1175 in)	32348 8H815
2.715 mm (0.1069 in)	32348 8H806	3.015 mm (0.1187 in)	32348 8H816
2.745 mm (0.1081 in)	32348 8H807	3.045 mm (0.1199 in)	32348 8H817
2.775 mm (0.1093 in)	32348 8H808	3.075 mm (0.1211 in)	32348 8H818
2.805 mm (0.1104 in)	32348 8H809		

19. Fit the C-ring holder, and install the snap ring as shown.



MAINSHAFT AND GEARS


[RS6F51A]

20. Check the end play of the 1st and 2nd main gears as shown.

End play standard values

1st gear : 0.20 - 0.30 mm (0.0079 - 0.0118 in)

2nd gear : 0.06 - 0.16 mm (0.0024 - 0.0063 in)



REVERSE IDLER SHAFT AND GEARS

Disassembly and Assembly DISASSEMBLY


1. Remove the reverse idler gear adjusting shim.
2. Remove the reverse idler gear (rear), reverse coupling sleeve and insert spring simultaneously.
3. Remove the reverse idler gear needle bearing.
4. Remove the thrust needle bearing.
5. Remove the reverse baulk ring.
6. Remove the reverse idler gear (front).
7. Remove the reverse idler gear needle bearing.
8. Remove the thrust needle bearing.
9. Pull off the locking pin from the reverse idler shaft.

INSPECTION AFTER DISASSEMBLY

Reverse Idler Shaft and Gears

Check the items listed. If necessary, replace them with new ones.


- Damage, peeling, dent, uneven wear and bending of the reverse idler shaft.
- Excessive wear, damage and peeling, of the reverse idler gears.




Synchronizer

Check the items listed. If necessary, replace them with new ones.

- Damage and excessive wear on contact surfaces of coupling sleeve, synchronizer hub, and insert spring.
- Coupling sleeve and synchronizer hub must move smoothly as shown.



- If any crack, damage, or excessive wear is found on the cam face of the baulk ring or working face of the insert as shown, replace it.




Baulk ring clearance

- Press the baulk ring against the cone, and measure the clearance between the baulk ring and cone as shown. If the measurement is below the specified limit, replace it with a new one.

Baulk ring to gear clearance

Standard : 0.95 - 1.4 mm (0.0374 - 0.055 in)


Limit value : 0.7 mm (0.028 in)



Bearing

Check the item listed. If necessary, replace it with a new one.

- Damage and rough rotation of the bearing.




ASSEMBLY

Assembly is in the reverse order of disassembly.

CAUTION:

- Install the insert spring with the orientation as shown.




FINAL DRIVE

Disassembly and Assembly PRE-INSPECTION

1. Clean final drive assembly sufficiently to prevent side gear thrust washer, differential case, side gear, and other parts from sticking by gear oil.
2. Upright the differential case so that the side gear to be measured faces upward.
3. Place final drive adapter and dial indicator onto side gears using Tool as shown.

Tool number : — (J-39713)




4. Move side gears up and down, and measure the clearance as shown.

Clearance between side gear and differential case : 0.1 - 0.2 mm (0.004 - 0.008 in)

CAUTION:

There must be no resistance and the gears must rotate freely.




5. If the clearance measured is not within specification, adjust the clearance by changing the thrust washer thickness.
6. Turn the differential case upside down, and measure the clearance between the side gear and differential case on the other side to the same specifications, adjust using a thrust washer as necessary.

DISASSEMBLY


1. Remove the mounting bolts and then separate the final gear from the differential case.
2. Remove speedometer drive gear.
3. Remove the differential side bearing (clutch housing side) using tool and puller as shown.

Tool number : ST33061000 (J-8107-2)




- Remove the differential side bearing (transaxle case side) using tool and puller as shown.

Tool number : ST33061000 (J-8107-2)



- Using a pin punch, pull out lock pin and pinion mate shaft as shown.




- Rotate pinion mate gears, and remove pinion mate gears, pinion mate thrust washers, side gears, and side gear thrust washers from differential case.

INSPECTION AFTER DISASSEMBLY

Gear, Washer, Shaft and Case

Check side gears, side gear thrust washers, pinion mate shaft, pinion mate gears, pinion mate thrust washers and differential case as shown. If necessary, replace with new parts.




Bearing

Check for bearing damage and rough rotation as shown. If necessary, replace with new parts.

CAUTION:

When replacing the tapered roller bearing, replace the outer and inner races as a set.




ASSEMBLY

- Apply gear oil to sliding area of differential case, each gear, and thrust washer.

FINAL DRIVE

[RS6F51A]


2. Install side gear thrust washers and side gears into differential case as shown.



3. While rotating pinion mate thrust washers and pinion mate gears, and aligning them diagonally, install them into differential case.

4. Insert pinion mate shaft into differential case as shown.


CAUTION:
Be sure not to damage pinion mate thrust washers.



5. Measure end play of side gears, using the procedure below. Then select side gear thrust washer.

- a. Upright the differential case so that the side gear to be measured faces upward.
- b. Place final drive adapter and dial indicator onto side gears using tool as shown.

Tool number : — (J-39713)




- c. Move side gears up and down to measure end play, and select thrust washer so that it meets specification.

End play standard value : 0.1 - 0.2 mm (0.004 - 0.008 in)

CAUTION:

- There must be no resistance and the gears must rotate freely.
- Place differential case upside down. Measure the end play for opposite side-gears using the same procedure.
- Only one thrust washer can be selected.



Thrust washers

Thickness	Part number
0.75 mm (0.0295 in)	38424 81X00
0.80 mm (0.0315 in)	38424 81X01
0.85 mm (0.0335 in)	38424 81X02
0.90 mm (0.0354 in)	38424 81X03
0.95 mm (0.0374 in)	38424 81X04


FINAL DRIVE

[RS6F51A]

6. Drive a new lock pin into the pinion mate shaft using a pin punch as shown.

CAUTION:

Do not reuse the lock pin.




7. Install differential side bearing (transaxle case side) using Tool as shown.


Tool number

A: ST30720000 (J-25405)

B: KV38102510 (J-35870)



8. Align and install the speedometer drive gear onto the differential case as shown.




9. Install differential side bearing (clutch housing side) using Tool as shown.

Tool number


A: ST30720000 (J-25405)

B: KV38102510 (J-35870)



10. Install the final gear into the differential case, and tighten the final gear bolts to specification.


Final gear bolts : 122.5 - 137.5 N-m (13 - 14 kg-m, 91 - 101 ft-lb)



SHIFT CONTROL


Inspection

- Check the contact surfaces and sliding area for wear, damage, or bending as shown. If necessary, replace the parts.



SHIFT FORK

- Check if the width of the shift fork hook (sliding area with coupling sleeve) is within specification, as shown.



Shift Fork

Item	One-side wear specification	Sliding width of new part
1st & 2nd	0.2 mm (0.008 in)	7.80 - 7.93 mm (0.3071 - 0.3122 in)
3rd & 4th	0.2 mm (0.008 in)	7.80 - 7.93 mm (0.3071 - 0.3122 in)
5th & 6th	0.2 mm (0.008 in)	6.10 - 6.23 mm (0.2402 - 0.2453 in)
Reverse	0.2 mm (0.008 in)	12.80 - 12.93 mm (0.5039 - 0.5091 in)

SERVICE DATA AND SPECIFICATIONS (SDS)


[RS6F51A]

SERVICE DATA AND SPECIFICATIONS (SDS)

PFP:00030

General Specifications TRANSAXLE

ECS0095B

Engine		VQ35DE	
Transaxle model		RS6F51A	
Model code number		7Y466	
Number of speeds		6	
Synchromesh type		Warner	
Shift pattern		 <p style="text-align: center; font-size: small;">SCIA0955E</p>	
Gear ratio	1st	3.153	
	2nd	1.944	
	3rd	1.392	
	4th	1.055	
	5th	0.809	
	6th	0.630	
	Reverse	3.002	
Number of teeth	Input gear	1st	13
		2nd	18
		3rd	28
		4th	36
		5th	42
		6th	46
		Reverse	13
	Main gear	1st	41
		2nd	35
		3rd	39
		4th	38
		5th	34
		6th	29
		Reverse	38
Reverse idler gear	Front	37	
	Rear	38	
Oil capacity (Reference)		2.2 ℓ (2 3/8 US qt, 2 Imp qt)	
Oil Level		49 - 55 mm (1.93 - 2.17 in)	
Oil type		Genuine NISSAN Manual Transmission Fluid (MTF) HQ Multi 75W-85 or API GL-4, Viscosity SAE 75W-85	
Remarks	Reverse synchronizer	Installed	
	Double cone synchronizer	3rd	
	Triple cone synchronizer	1st and 2nd	

SERVICE DATA AND SPECIFICATIONS (SDS)

[RS6F51A]

FINAL GEAR

Engine		VQ35DE
Transaxle model		RS6F51A
Model code number		7Y466
Final gear ratio		4.133
Number of teeth	Final gear/Pinion	62/15
	Side gear/Pinion mate gear	—

Gear End Play

ECS0095C

Unit: mm (in)

Gear	End play
1st main gear	0.20 - 0.30 (0.0079 - 0.0118)
2nd main gear	0.06 - 0.16 (0.0024 - 0.0063)
3rd input gear	0.18 - 0.31 (0.0071 - 0.0122)
4th input gear	0.20 - 0.30 (0.0079 - 0.0118)
5th input gear	0.06 - 0.16 (0.0024 - 0.0063)
6th input gear	0.06 - 0.16 (0.0024 - 0.0063)

Clearance Between Baulk Ring and Gear 4TH, 5TH, 6TH & REVERSE BAULK RING

ECS0095D

Unit: mm (in)

Baulk ring	Standard	Wear limit
4th	0.9 - 1.45 (0.035 - 0.0571)	0.7 (0.028)
5th	0.95 - 1.4 (0.0374 - 0.055)	0.7 (0.028)
6th	0.95 - 1.4 (0.0374 - 0.055)	0.7 (0.028)
Reverse	0.95 - 1.4 (0.0374 - 0.055)	0.7 (0.028)


SERVICE DATA AND SPECIFICATIONS (SDS)

[RS6F51A]


1ST, 2ND AND 3RD BAULK RING

Unit: mm (in)

1st, 2nd and 3rd Double Bauk Ring



1st and 2nd Triple Bauk Ring



Dimension	Standard	Wear limit		
		Triple baulk ring	Double baulk ring	Triple baulk ring
A	0.6 - 0.8 (0.024 - 0.031)	0.6 - 1.2 (0.024 - 0.047)	0.2 (0.008)	0.3 (0.012)
B	0.6 - 1.1 (0.024 - 0.043)	0.6 - 1.1 (0.024 - 0.043)	0.2 (0.008)	0.2 (0.008)
C	—	0.7 - 1.1 (0.028 - 0.043)	—	0.3 (0.012)

Available Snap Rings 6TH BUSHING

ECS0095E

End play		0 - 0.1 mm (0 - 0.004 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
1.76 (0.0693)	32204 8H511	2.01 (0.0791)	32204 8H516
1.81 (0.0713)	32204 8H512	2.06 (0.0811)	32204 8H517
1.86 (0.0732)	32204 8H513	2.11 (0.0831)	32204 8H518
1.91 (0.0752)	32204 8H514	2.16 (0.0850)	32204 8H519
1.96 (0.0772)	32204 8H515	2.21 (0.0871)	32204 8H520

*: Always check with the Parts Department for the latest parts information.

Available C-rings MAINSHAFT C-RING


ECS0095F

End play		0 - 0.06 mm (0 - 0.0024 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
2.535 (0.0998)	32348 8H800	2.835 (0.1116)	32348 8H810
2.565 (0.1010)	32348 8H801	2.865 (0.1128)	32348 8H811
2.595 (0.1022)	32348 8H802	2.895 (0.1140)	32348 8H812
2.625 (0.1033)	32348 8H803	2.925 (0.1152)	32348 8H813
2.655 (0.1045)	32348 8H804	2.955 (0.1163)	32348 8H814
2.685 (0.1057)	32348 8H805	2.985 (0.1175)	32348 8H815
2.715 (0.1069)	32348 8H806	3.015 (0.1187)	32348 8H816
2.745 (0.1081)	32348 8H807	3.045 (0.1199)	32348 8H817
2.775 (0.1093)	32348 8H808	3.075 (0.1211)	32348 8H818
2.805 (0.1104)	32348 8H809		

*: Always check with the Parts Department for the latest parts information.

Available Thrust Washers
INPUT SHAFT THRUST WASHER

ECS0095G




SCIA1008E

Standard length "C2"		154.7 - 154.8 mm (6.091 - 6.094in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
3.84 (0.1512)	32347 8H500	4.02 (0.1583)	32347 8H503
3.90 (0.1535)	32347 8H501	4.08 (0.1606)	32347 8H504
3.96 (0.1559)	32347 8H502	4.14 (0.1630)	32347 8H505

*: Always check with the Parts Department for the latest parts information.

Available Adjusting Shims
MAINSHAFT ADJUSTING SHIM

ECS0095H



SCIA1009E

Standard length "C1"		173.85 - 173.95 mm (6.844 - 6.848in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.52 (0.0205)	32238 8H500	0.84 (0.0331)	32238 8H504
0.60 (0.0236)	32238 8H501	0.92 (0.0362)	32238 8H505
0.68 (0.0268)	32238 8H502	1.00 (0.0394)	32238 8H506
0.76 (0.0299)	32238 8H503	1.08 (0.0425)	32238 8H507

*: Always check with the Parts Department for the latest parts information.

INPUT SHAFT REAR BEARING ADJUSTING SHIM

End play			0 - 0.06 mm (0 - 0.0024 in)		
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.40 (0.0157)	32225 8H500	0.88 (0.0346)	32225 8H512	1.36 (0.0535)	32225 8H524
0.44 (0.0173)	32225 8H501	0.92 (0.0362)	32225 8H513	1.40 (0.0551)	32225 8H560
0.48 (0.0189)	32225 8H502	0.96 (0.0378)	32225 8H514	1.44 (0.0567)	32225 8H561
0.52 (0.0205)	32225 8H503	1.00 (0.0394)	32225 8H515	1.48 (0.0583)	32225 8H562
0.56 (0.0220)	32225 8H504	1.04 (0.0409)	32225 8H516	1.52 (0.0598)	32225 8H563
0.60 (0.0236)	32225 8H505	1.08 (0.0425)	32225 8H517	1.56 (0.0614)	32225 8H564
0.64 (0.0252)	32225 8H506	1.12 (0.0441)	32225 8H518	1.60 (0.0630)	32225 8H565
0.68 (0.0268)	32225 8H507	1.16 (0.0457)	32225 8H519	1.64 (0.0646)	32225 8H566
0.72 (0.0283)	32225 8H508	1.20 (0.0472)	32225 8H520		
0.76 (0.0299)	32225 8H509	1.24 (0.0488)	32225 8H521		
0.80 (0.0315)	32225 8H510	1.28 (0.0504)	32225 8H522		
0.84 (0.0331)	32225 8H511	1.32 (0.0520)	32225 8H523		

SERVICE DATA AND SPECIFICATIONS (SDS)

[RS6F51A]

*: Always check with the Parts Department for the latest parts information.

MAINSHAFT REAR BEARING ADJUSTING SHIM

End play		0 - 0.06 mm (0 - 0.0024 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.44 (0.0173)	32238 8H510	0.80 (0.0315)	32238 8H519
0.48 (0.0189)	32238 8H511	0.84 (0.0331)	32238 8H520
0.52 (0.0205)	32238 8H512	0.88 (0.0346)	32238 8H521
0.56 (0.0220)	32238 8H513	0.92 (0.0362)	32238 8H522
0.60 (0.0236)	32238 8H514	0.96 (0.0378)	32238 8H523
0.64 (0.0252)	32238 8H515	1.00 (0.0394)	32238 8H524
0.68 (0.0268)	32238 8H516	1.04 (0.0409)	32238 8H560
0.72 (0.0283)	32238 8H517	1.08 (0.0425)	32238 8H561
0.76 (0.0299)	32238 8H518		

*: Always check with the Parts Department for the latest parts information.

REVERSE IDLER GEAR ADJUSTING SHIM

End play		0.04 - 0.10 mm (0.0016 - 0.0039 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
1.76 (0.0693)	32237 8H800	2.24 (0.0882)	32237 8H812
1.80 (0.0709)	32237 8H801	2.28 (0.0898)	32237 8H813
1.84 (0.0724)	32237 8H802	2.32 (0.0913)	32237 8H814
1.88 (0.0740)	32237 8H803	2.36 (0.0929)	32237 8H815
1.92 (0.0756)	32237 8H804	2.40 (0.0945)	32237 8H816
1.96 (0.0772)	32237 8H805	2.44 (0.0961)	32237 8H817
2.00 (0.0787)	32237 8H806	2.48 (0.0976)	32237 8H818
2.04 (0.0803)	32237 8H807	2.52 (0.0992)	32237 8H819
2.08 (0.0819)	32237 8H808	2.56 (0.1008)	32237 8H820
2.12 (0.0835)	32237 8H809	2.60 (0.1024)	32237 8H821
2.16 (0.0850)	32237 8H810	2.64 (0.1039)	32237 8H822
2.20 (0.0866)	32237 8H811		

*: Always check with the Parts Department for the latest parts information.

6TH MAIN GEAR ADJUSTING SHIM

End play		0 - 0.1 mm (0 - 0.004 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.88 (0.0346)	32237 8H560	1.20 (0.0472)	32237 8H564
0.96 (0.0378)	32237 8H561	1.28 (0.0504)	32237 8H565
1.04 (0.0409)	32237 8H562	1.36 (0.0535)	32237 8H566
1.12 (0.0441)	32237 8H563		

*: Always check with the Parts Department for the latest parts information.

Available Shims

ECS0095I

— Differential Side Bearing Preload and Adjusting Shim —

BEARING PRELOAD

Differential side bearing preload: L*	0.15 - 0.21 mm (0.0059 - 0.0083 in)
---------------------------------------	-------------------------------------

*: Install shims which are "deflection of differential case" + "L" in thickness.

DIFFERENTIAL SIDE BEARING ADJUSTING SHIM(S)

End play		0.1 - 0.2 mm (0.004 - 0.008 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.48 (0.0189)	31438 80X00	0.72 (0.0283)	31438 80X06
0.52 (0.0205)	31438 80X01	0.76 (0.0299)	31438 80X07
0.56 (0.0220)	31438 80X02	0.80 (0.0315)	31438 80X08
0.60 (0.0236)	31438 80X03	0.84 (0.0331)	31438 80X09
0.64 (0.0252)	31438 80X04	0.88 (0.0346)	31438 80X10
0.68 (0.0268)	31438 80X05	0.92 (0.0362)	31438 80X11

*: Always check with the Parts Department for the latest parts information.