

SECTION SE

SEAT

CONTENTS

SERVICE INFORMATION	2	PREPARATION	22
SQUEAK AND RATTLE TROUBLE DIAGNOSES	2	PREPARATION	22
Work Flow	2	Special Service Tool	22
Generic Squeak and Rattle Troubleshooting	4	Commercial Service Tool	22
Diagnostic Worksheet	6		
COMPONENT DIAGNOSIS	8	ON-VEHICLE REPAIR	23
POWER SEAT	8	FRONT SEAT	23
Wiring Diagram — Driver Side —	8	Component	23
Wiring Diagram — Passenger Side —	12	Removal and Installation	28
HEATED SEAT	15	REAR SEAT	29
Description	15	Removal and Installation	29
Wiring Diagram	16		
PRECAUTION	21	DISASSEMBLY AND ASSEMBLY	32
PRECAUTIONS	21	FRONT SEAT	32
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	21	Component	32
Precaution for Work	21	Seatback Assembly	37
		Seat Cushion Trim and Pad	38
		REAR SEAT	40
		Disassembly and Assembly	40

SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SERVICE INFORMATION >

SERVICE INFORMATION

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000004055959



SBT842

CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [SE-6, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SERVICE INFORMATION >

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.

Refer to [SE-4, "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-43980) is available through your authorized NISSAN Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

Always check with the Parts Department for the latest parts information.

The following materials are contained in the NISSAN Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100×135 mm (3.94×5.31 in)/76884-71L01: 60×85 mm (2.36×3.35 in)/76884-71L02: 15×25 mm (0.59×0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50×50 mm (1.97×1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50×50 mm (1.97×1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30×50 mm (1.18×1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SERVICE INFORMATION >

68370-4B000: 15×25 mm (0.59×0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll. The following materials not found in the kit can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used instead of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

INFOID:000000004055960

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-43980) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SERVICE INFORMATION >

2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headliner and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

1. Loose harness or harness connectors.
2. Front console map/reading lamp lense loose.
3. Loose screws at console attachment points.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SERVICE INFORMATION >

Diagnostic Worksheet

INFOID:000000004055961





Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SERVICE INFORMATION >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> Anytime | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> When it is raining or wet |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions |
| <input type="checkbox"/> Only when it is hot outside | <input type="checkbox"/> Other: |

A

B

C

D

III. WHEN DRIVING:

- | | |
|---|--|
| <input type="checkbox"/> Through driveways | <input type="checkbox"/> Squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> Over rough roads | <input type="checkbox"/> Creak (like walking on an old wooden floor) |
| <input type="checkbox"/> Over speed bumps | <input type="checkbox"/> Rattle (like shaking a baby rattle) |
| <input type="checkbox"/> Only about _____ mph | <input type="checkbox"/> Knock (like a knock at the door) |
| <input type="checkbox"/> On acceleration | <input type="checkbox"/> Tick (like a clock second hand) |
| <input type="checkbox"/> Coming to a stop | <input type="checkbox"/> Thump (heavy muffled knock noise) |
| <input type="checkbox"/> On turns: left, right or either (circle) | <input type="checkbox"/> Buzz (like a bumble bee) |
| <input type="checkbox"/> With passengers or cargo | |
| <input type="checkbox"/> Other: _____ | |
| <input type="checkbox"/> After driving _____ miles or _____ minutes | |

E

F

G

H

IV. WHAT TYPE OF NOISE

- | |
|--|
| <input type="checkbox"/> Squeak (like tennis shoes on a clean floor) |
| <input type="checkbox"/> Creak (like walking on an old wooden floor) |
| <input type="checkbox"/> Rattle (like shaking a baby rattle) |
| <input type="checkbox"/> Knock (like a knock at the door) |
| <input type="checkbox"/> Tick (like a clock second hand) |
| <input type="checkbox"/> Thump (heavy muffled knock noise) |
| <input type="checkbox"/> Buzz (like a bumble bee) |

SE

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

YES

NO

Initials of person performing

K

Vehicle test driven with customer

- Noise verified on test drive

- Noise source located and repaired

- Follow up test drive performed to confirm repair

L

M

N

VIN: _____ Customer Name: _____

W.O.# _____ Date: _____

O

P

This form must be attached to Work Order

POWER SEAT

< COMPONENT DIAGNOSIS >


COMPONENT DIAGNOSIS

POWER SEAT

Wiring Diagram — Driver Side —

INFOID:0000000004055962

POWER SEAT FOR DRIVER SIDE



ABJWA0057GB

POWER SEAT

< COMPONENT DIAGNOSIS >

POWER SEAT FOR DRIVER SIDE CONNECTORS


Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5J	G	-



Terminal No.	Color of Wire	Signal Name
5J	G	-



Terminal No.	Color of Wire	Signal Name
12	B	-
13	G	-

Terminal No.	Color of Wire	Signal Name
6	W	-



Terminal No.	Color of Wire	Signal Name
1	2	3
2	4	5
3	6	-

Connector No.	M82
Connector Name	CIRCUIT BREAKER-2
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	P	-

SE


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

ABJIA0178GB

POWER SEAT


< COMPONENT DIAGNOSIS >

Connector No.	B200
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5J	G	-

Terminal No.	Color of Wire	Signal Name
5J	G	-



Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	B	-
13	G	-



Connector No.	B206
Connector Name	LIFTING MOTOR (FRONT)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	R/W	-
2	G/W	-



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	Y/B	-



ABJIA0179GB

POWER SEAT

< COMPONENT DIAGNOSIS >

A

B

C

D

E

F

G

H

I

SE

K

L


M

N

O

P

Connector No.	B208
Connector Name	FRONT POWER SEAT LH
Connector Color	WHITE



Connector No.	B207
Connector Name	LIFTING MOTOR (REAR)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L/W	-
3		
4		
5	R	-
6	Y/B	-
7	B	-
8	W/L	-
9	L/W	-
10	L	-

AAJIA0039GB


POWER SEAT

< COMPONENT DIAGNOSIS >

Wiring Diagram — Passenger Side —

INFOID:0000000004055963

POWER SEAT FOR PASSENGER SIDE




ABJWA0058GB

POWER SEAT


< COMPONENT DIAGNOSIS >

POWER SEAT FOR PASSENGER SIDE CONNECTORS

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M17
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	W	-

Terminal No.	Color of Wire	Signal Name
7	6	5
8	4	3
9	15	14
10	13	12
11	11	10
12	10	9
13	12	11
14	11	10
15	10	9
16	9	8




Terminal No.	Color of Wire	Signal Name
1	G	-
2	P	-



Terminal No.	Color of Wire	Signal Name
8	LG	-




Terminal No.	Color of Wire	Signal Name
1	G	-
2	P	-



Terminal No.	Color of Wire	Signal Name
8	LG	-




Terminal No.	Color of Wire	Signal Name
1	G	-
2	P	-



Terminal No.	Color of Wire	Signal Name
8	LG	-




Terminal No.	Color of Wire	Signal Name
1	G	-
2	P	-



Terminal No.	Color of Wire	Signal Name
8	LG	-




Terminal No.	Color of Wire	Signal Name
12	B	-
13	LG	-



Terminal No.	Color of Wire	Signal Name
8	LG	-



Terminal No.	Color of Wire	Signal Name
12	B	-
13	LG	-




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
AAJIA0040GB

POWER SEAT

< COMPONENT DIAGNOSIS >

Connector No.	B308
Connector Name	POWER SEAT SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/B	-
2	Y/B	-

Terminal No.	Color of Wire	Signal Name
12	B	-
13	W/L	-

Connector No.	B302
Connector Name	RECLINING MOTOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G/B	-
2	Y/B	-

Connector No.	B309
Connector Name	SLIDING MOTOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	W/L	-
3	G	-
4	B	-
5	W/L	-
6	G/B	-

Terminal No.	Color of Wire	Signal Name
1	G	-
2	Y	-

ABJIA0180GB

HEATED SEAT

< COMPONENT DIAGNOSIS >


HEATED SEAT

Description

INFOID:0000000004055964

- When handling seat, be extremely careful not to scratch heating unit (1).
- To replace heating unit for vehicles without side air bags, seat trim and pad should be separated. For vehicles equipped with side air bags, seat trim and pad should be separated for the front seat cushion LH. For seatback and front seat cushion RH, complete cushion (2) or seatback assembly (3) must be replaced.
- Do not use any organic solvent, such as thinner, benzene, alcohol, etc. to clean trim.

Thermostat operation	ON	OFF
Trim temperature °C (°F)	25 -35 (77 - 95)	35 - 45 (95 - 113)



A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P


HEATED SEAT

< COMPONENT DIAGNOSIS >

Wiring Diagram

INFOID:000000004055965

HEATED SEAT



ABJWA0059GB

HEATED SEAT

< COMPONENT DIAGNOSIS >

HEATED SEAT CONNECTORS

Connector No.	M17
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	W	-
10	GR	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
73G	W/R	-



Terminal No.	Color of Wire	Signal Name
62J	LG	-
64J	GR	-

Connector No.	M160
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-



Terminal No.	Color of Wire	Signal Name
2	W	-
3	GR	-
4	B	-




Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-


Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10J	9J	8J
10U	9U	7J



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-




Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-



Terminal No.	Color of Wire	Signal Name

HEATED SEAT


< COMPONENT DIAGNOSIS >

Terminal No.	Color of Wire	Signal Name
73G	W/R	-

Connector No.	E152
Connector Name	WIRES TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/R	-
2	GR	-
3	LG	-
4	B	-



11G	12G	13G	14G	15G	16G	17G	18G	19G	20G	21G
22G	23G	24G	25G	26G	27G	28G	29G	30G		
31G	32G	33G	34G	35G	36G	37G	38G	39G	40G	41G
42G	43G	44G	45G	46G	47G	48G	49G	50G		
51G	52G	53G	54G	55G	56G	57G	58G	59G	60G	61G
62G	63G	64G	65G	66G	67G	68G	69G	70G		
71G	72G	73G	74G	75G						
76G	77G	78G	79G	80G						



62G	63G	64G	65G	66G	67G	68G	69G	70G
71G	72G	73G	74G	75G				

Connector No.	B37
Connector Name	WIRES TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	LG	-
6	GR	-
7	B	-

Connector No.	M161
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE




HEATED SEAT

< COMPONENT DIAGNOSIS >

Connector No.	B154
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
62J	LG	-
64J	GR	-



Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	GR	-
6	W	-
7	B	-



Connector No.	B209
Connector Name	FRONT SEAT HEATER LH
Connector Color	WHITE





Connector No.	B200
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B163
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	G/W	-
3	Y/B	-




HEATED SEAT

< COMPONENT DIAGNOSIS >


Connector No.	B303
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B303
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B307
Connector Name	FRONT SEAT HEATER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	Y/B	-
6	Y	-
7	G/W	-

Terminal No.	Color of Wire	Signal Name
1	Y	-
2	G/W	-
3	Y/B	-

ABJIA0184GB

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000004055966

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution for Work

INFOID:0000000004055967

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
 - Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.
Then rub with a soft and dry cloth.
 - Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >



PREPARATION

PREPARATION

Special Service Tool


INFOID:0000000004055968

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-39570) Chassis ear	 SIIA0993E Locating the noise
— (J-43980) NISSAN Squeak and Rattle Kit	 SIIA0994E Repairing the cause of noise

Commercial Service Tool

INFOID:0000000004055969

(Kent-Moore No.) Tool name	Description
(J-39565) Engine ear	 SIIA0995E Locating the noise

FRONT SEAT

< ON-VEHICLE REPAIR >

ON-VEHICLE REPAIR FRONT SEAT

Component

INFOID:000000004055970

A

B

C

D

E

F

G

H

I

SE

K

L


M

N

O

P

Power Driver Seat



WIIA1061E

FRONT SEAT


< ON-VEHICLE REPAIR >

- | | | |
|--|---------------------------------------|--|
| 1. Headrest | 2. Seatback pad without side air bag | 3. Seatback heating element |
| 4. Seatback assembly with side air bag | 5. Seatback trim without side air bag | 6. Power seat cushion rear finisher |
| 7. Leg Cover | 8. Seat frame assembly | 9. Seat belt buckle assembly |
| 10. Seat cushion inner finisher | 11. Seat cushion front finisher | 12. Driver seat wiring harness |
| 13. Seat cushion outer finisher | 14. Leg cover | 15. Bolt cover |
| 16. Seat cushion frame | 17. Recliner switch knob | 18. Slide switch knob |
| 19. Power seat switch escutcheon | 20. Switch assembly | 21. Seat cushion pad |
| 22. Seat cushion heating element | 23. Seat cushion trim | 24. Lumbar support assembly |
| 25. Seatback frame | 26. Seatback board | 27. Headrest holder with multi position lock |
| 28. Headrest holder | 29. Lumbar support lever knob | 30. Snap ring |

FRONT SEAT

< ON-VEHICLE REPAIR >

Manual Driver Seat



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

LIIA2407E

1. Headrest
2. Seatback pad without side air bag
3. Seatback trim without side air bag
4. Seatback assembly with side air bag
5. Seat cushion trim cover
6. Seat cushion pad
7. Seat cushion frame
8. Seat cushion inner finisher
9. Seat belt buckle assembly
10. Seat frame assembly
11. Leg cover
12. Bolt cover
13. Recline lever
14. Seat cushion outer finisher
15. Leg cover
16. Seat cushion rear finisher
17. Seat cushion lift knobs
18. Lumbar support assembly


FRONT SEAT

< ON-VEHICLE REPAIR >

- | | | |
|---|-------------------------------|--|
| 19. Seatback frame without side air bag | 20. Seatback board | 21. Headrest holder with multi position lock |
| 22. Headrest holder | 23. Lumbar support lever knob | 24. Snap ring |

Conventional Passenger Seat

SEC. 870



LIIA2408E

- | | | |
|---------------------------------------|---------------------------------|--|
| 1. Seatback trim without side air bag | 2. Headrest | 3. Seatback assembly with side air bag |
| 4. Switch assembly | 5. Power seat switch escutcheon | 6. Recliner switch knob |
| 7. Slide switch knob | 8. Seat cushion assembly | 9. Seat cushion outer cover |


FRONT SEAT

< ON-VEHICLE REPAIR >

- | | | |
|--|---------------------------------|---------------------------------------|
| 10. Leg cover | 11. Seat cushion front finisher | 12. Passenger seat wiring harness |
| 13. Power seat frame assembly | 14. Seat cushion inner finisher | 15. Seat belt buckle assembly |
| 16. Leg cover | 17. Seat cushion rear finisher | 18. Manual seat frame assembly |
| 19. Recline lever | 20. Seat cushion rear finisher | 21. Seatback board |
| 22. Headrest holder with multi position lock | 23. Headrest holder | 24. Seatback pad without side air bag |
| 25. Seatback frame without side air bag | 26. Damper assembly | 27. Seatback heating element |

Fold Flat Passenger Seat

SEC. 870



A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< ON-VEHICLE REPAIR >

- | | | |
|--|---|--|
| 1. Front seatback lever | 2. Seatback trim without side air bag | 3. Headrest |
| 4. Seatback assembly with side air bag | 5. Seat cushion assembly | 6. Seat cushion outer finisher |
| 7. Leg cover | 8. Seat frame assembly | 9. Passenger seat wiring harness |
| 10. Seat cushion inner cover | 11. Leg cover | 12. Seat belt buckle assembly |
| 13. Inboard reclining arm outer cover | 14. Inboard reclining arm inner cover | 15. Outboard reclining arm inner cover |
| 16. Outboard reclining arm outer cover | 17. Seat cushion rear finisher | 18. Seatback board |
| 19. Headrest holder with multi position lock | 20. Headrest holder | 21. Seatback pad without side air bag |
| 22. Seatback frame without side air bag | 23. Seatback fold flat release lever assembly | 24. Damper assembly |

Removal and Installation

INFOID:000000004055971

REMOVAL

When removing or installing the seat trim, handle it carefully to keep dirt out and avoid damage.

CAUTION:

- Before removing the front seat, turn the ignition switch off, disconnect both battery terminals and wait at least 3 minutes.
- When checking the power seat circuit for continuity using a circuit tester, do not confuse its connector with the side air bag module connector. Such an error may cause the air bag to deploy.
- Do not drop, tilt, or bump the side air bag module while installing the seat. Always handle it with care.
- After front side air bag module inflates, front seatback assembly must be replaced.
- Front passenger seat is equipped with an Occupant Classification System sensor and control module. Do not disassemble front passenger seat cushion assembly or remove the trim as this will affect the Occupant Classification System calibration.
- Always replace passenger seat cushion as an assembly.

1. Slide the seat until the four body bolts are visible and a tool can be inserted.

NOTE:

Set the front/rear cushion lifters to the top position.

2. Disconnect both battery terminals and wait at least 3 minutes.
3. Disconnect the side air bag module harness connector (if equipped).
4. Remove the four body bolts.
5. Disconnect the power seat harness connectors and remove the seat from the vehicle.

NOTE:

When removing and installing the seat, use shop cloths to protect the vehicle from damage.

INSTALLATION

Installation is in the reverse order of removal.

REAR SEAT

< ON-VEHICLE REPAIR >

REAR SEAT


Removal and Installation

INFOID:0000000004055972


JUMP SEAT (KING CAB)

Removal


1. Remove seat base trim panel.



2. Remove the seat cushion bolts and assembly.



3. Remove the bolt, lift and remove the seatback assembly.



Installation

Installation is in the reverse order of removal.

BENCH SEAT LH (CREW CAB)


Removal

1. Remove the seat hinge finishers.


REAR SEAT

< ON-VEHICLE REPAIR >

2. Release the seatback latch and tilt the seatback down. Remove the nuts.



3. Raise the seatback.
4. Tilt the seat cushion up.
5. Remove the seat bolts.
6. Remove the seat.



Installation

Installation is in the reverse order of removal.

NOTE:

Make sure the washers are on the rear studs prior to seat assembly installation.


Seat nuts : 45 N·m (4.6 kg·m, 33 ft-lb)

Seat bolts : 45 N·m (4.6 kg·m, 33 ft-lb)

BENCH SEAT RH (CREW CAB)

Removal

1. Remove the seat hinge finishers.
2. Release the seatback latch and tilt the seatback down. Remove the nuts.




3. Raise the seatback.

REAR SEAT

< ON-VEHICLE REPAIR >

4. Remove the seat belt buckle from the cushion.
5. Remove the seat bolts.
6. Remove the seat assembly.



Installation

Installation is in the reverse order of removal.

NOTE:

Make sure the washers are on the rear studs prior to seat assembly installation.

A
B
C
D
E
F
G
H
I
SE
K
L
M
N
O
P

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >


DISASSEMBLY AND ASSEMBLY

FRONT SEAT

Component

INFOID:0000000004055973

Power Driver Seat



WIIA1061E

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

- | | | | |
|--|---------------------------------------|--|---|
| 1. Headrest | 2. Seatback pad without side air bag | 3. Seatback heating element | A |
| 4. Seatback assembly with side air bag | 5. Seatback trim without side air bag | 6. Power seat cushion rear finisher | |
| 7. Leg Cover | 8. Seat frame assembly | 9. Seat belt buckle assembly | B |
| 10. Seat cushion inner finisher | 11. Seat cushion front finisher | 12. Driver seat wiring harness | |
| 13. Seat cushion outer finisher | 14. Leg cover | 15. Bolt cover | C |
| 16. Seat cushion frame | 17. Recliner switch knob | 18. Slide switch knob | |
| 19. Power seat switch escutcheon | 20. Switch assembly | 21. Seat cushion pad | D |
| 22. Seat cushion heating element | 23. Seat cushion trim | 24. Lumbar support assembly | |
| 25. Seatback frame | 26. Seatback board | 27. Headrest holder with multi position lock | |
| 28. Headrest holder | 29. Lumbar support lever knob | 30. Snap ring | E |

A

B

C

D

E

F

G

H

I

SE

K

L

M

N


O

P

FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

Manual Driver Seat



LIIA2407E

- | | | |
|--|--------------------------------------|---------------------------------------|
| 1. Headrest | 2. Seatback pad without side air bag | 3. Seatback trim without side air bag |
| 4. Seatback assembly with side air bag | 5. Seat cushion trim cover | 6. Seat cushion pad |
| 7. Seat cushion frame | 8. Seat cushion inner finisher | 9. Seat belt buckle assembly |
| 10. Seat frame assembly | 11. Leg cover | 12. Bolt cover |
| 13. Recline lever | 14. Seat cushion outer finisher | 15. Leg cover |
| 16. Seat cushion rear finisher | 17. Seat cushion lift knobs | 18. Lumbar support assembly |


FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

- | | | |
|---|-------------------------------|--|
| 19. Seatback frame without side air bag | 20. Seatback board | 21. Headrest holder with multi position lock |
| 22. Headrest holder | 23. Lumbar support lever knob | 24. Snap ring |

Conventional Passenger Seat

SEC. 870



LIIA2408E

- | | | |
|---------------------------------------|---------------------------------|--|
| 1. Seatback trim without side air bag | 2. Headrest | 3. Seatback assembly with side air bag |
| 4. Switch assembly | 5. Power seat switch escutcheon | 6. Recliner switch knob |
| 7. Slide switch knob | 8. Seat cushion assembly | 9. Seat cushion outer cover |


FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

- | | | |
|--|---------------------------------|---------------------------------------|
| 10. Leg cover | 11. Seat cushion front finisher | 12. Passenger seat wiring harness |
| 13. Power seat frame assembly | 14. Seat cushion inner finisher | 15. Seat belt buckle assembly |
| 16. Leg cover | 17. Seat cushion rear finisher | 18. Manual seat frame assembly |
| 19. Recline lever | 20. Seat cushion rear finisher | 21. Seatback board |
| 22. Headrest holder with multi position lock | 23. Headrest holder | 24. Seatback pad without side air bag |
| 25. Seatback frame without side air bag | 26. Damper assembly | 27. Seatback heating element |

Fold Flat Passenger Seat

SEC. 870



FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

- | | | |
|--|---|--|
| 1. Front seatback lever | 2. Seatback trim without side air bag | 3. Headrest |
| 4. Seatback assembly with side air bag | 5. Seat cushion assembly | 6. Seat cushion outer finisher |
| 7. Leg cover | 8. Seat frame assembly | 9. Passenger seat wiring harness |
| 10. Seat cushion inner cover | 11. Leg cover | 12. Seat belt buckle assembly |
| 13. Inboard reclining arm outer cover | 14. Inboard reclining arm inner cover | 15. Outboard reclining arm inner cover |
| 16. Outboard reclining arm outer cover | 17. Seat cushion rear finisher | 18. Seatback board |
| 19. Headrest holder with multi position lock | 20. Headrest holder | 21. Seatback pad without side air bag |
| 22. Seatback frame without side air bag | 23. Seatback fold flat release lever assembly | 24. Damper assembly |

A

B

C

D

E

F

G

H

I

SE

K

L

M

N

O

P

Seatback Assembly


INFOID:0000000004055974

REMOVAL

NOTE:


On vehicles equipped with side air bags, only complete seatback assemblies can be replaced.

1. Remove the front seat assembly. Refer to [SE-28, "Removal and Installation"](#).
2. Remove the seatback board from the back of the seatback.



PIIA0163E

3. Remove the retainer.



SIIA0113E

4. Disconnect the seatback heater harness.

5. Remove the seatback bolts (2 for each side) and seatback assembly.

DISASSEMBLY

NOTE:

On vehicles equipped with side air bags, only complete seatback assemblies can be replaced.

1. Remove the seatback assembly.
2. Remove the headrest.


FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >


3. From inside of the seatback, squeeze the headrest holder tabs at the base of the stay pipe and pull up to remove.

NOTE:

Before installing the headrest holder, check its orientation (front/rear and right/left).



4. Remove the snap ring and the lumbar support lever knob.



5. Remove the seatback trim and pad assembly.

6. Remove the hog ring to separate the seatback trim from the pad and the heating element (if equipped).

ASSEMBLY

Assembly is in the reverse order of disassembly.

INSTALLATION

Installation is in the reverse order of removal.

Seat Cushion Trim and Pad


INFOID:000000004055975

REMOVAL

CAUTION:

- Front passenger seat is equipped with an Occupant Classification System sensor and control module. Do not disassemble front passenger seat cushion assembly or remove the trim as this will affect the Occupant Classification System calibration.
- Always replace passenger seat cushion as an assembly.
- When removed, the passenger seat cushion must always be placed pan side UP to prevent damage.
- During installation, the wire harness clips must be reinstalled in the holes they were originally in. Do not add additional clips.
- The Occupant Classification System control module can only be replaced as part of the seat cushion assembly.


1. Remove the front seat assembly. Refer to [SE-28, "Removal and Installation"](#).
2. Remove the power seat switch knobs and power seat switch escutcheon (if equipped) (or lift knobs on manual seats).




FRONT SEAT

< DISASSEMBLY AND ASSEMBLY >

3. Remove the seat cushion outer finisher.



4. Remove the power seat switch screws.
5. Remove four bolts and the seat cushion assembly.
 - On the fold flat passenger seat it is necessary to unclip the rear flap j-clip from the seat pan.



6. Remove the retainer on the seat cushion frame, then remove the harness connector for the seat cushion heater (if equipped).

DISASSEMBLY

CAUTION:

- Front passenger seat is equipped with an Occupant Classification System sensor and control module. Do not disassemble front passenger seat cushion assembly or remove the trim as this will affect the Occupant Classification System calibration.

1. Remove the seat cushion assembly.
2. On the drivers seat only, remove the hog rings to separate the trim cover from the pad and seat cushion heater unit.

ASSEMBLY

Assembly is in the reverse order of disassembly.

INSTALLATION

Installation is in the reverse order of removal.

REAR SEAT

< DISASSEMBLY AND ASSEMBLY >


REAR SEAT

Disassembly and Assembly

INFOID:0000000004055976

Jump Seat (King Cab)

SEC. 880



扳手 : N·m (kg-m, in-lb)

扭力扳手 : N·m (kg-m, ft-lb)

LIIA1957E

1. Headrest
2. Seatback pad and frame
3. Seatback trim cover
4. Seat base trim panel
5. Seat cushion assembly
6. Seat cushion trim cover
7. Bushing
8. Spacer
9. Seat cushion pad and frame


REAR SEAT

< DISASSEMBLY AND ASSEMBLY >

- | | | |
|--|--------------------------------|-----------------------------------|
| 10. Child seat extension (Passenger side only) | 11. Child seat extension hinge | 12. Inboard jump seat pivot riser |
| 13. Outboard jump seat pivot riser | 14. RH headrest plate | 15. LH headrest plate |
| 16. Inboard headrest locking guide | 17. Outboard headrest guide | |

Bench Seat LH (Crew Cab)

SEC. 880



A vertical column of letters on the right side of the diagram indicates assembly steps: A, B, C, D, E, F, G, H, I, SE, K, L, M, N, O, P.

SE

- | | | |
|------------------------|---------------------------|------------------------------|
| 1. Headrest | 2. Inboard headrest guide | 3. Seatback pad |
| 4. Seatback trim cover | 5. Inboard pivot cover | 6. Seat cushion bumper RH/LH |


REAR SEAT

< DISASSEMBLY AND ASSEMBLY >

- | | | |
|---------------------------------------|---------------------------------------|-------------------------------------|
| 7. Inboard seat cushion pivot riser | 8. Seat cushion trim cover | 9. Seat cushion pad |
| 10. Seat cushion pan | 11. Seat cushion hinge release handle | 12. Seat cushion hinge cover |
| 13. Outboard seat cushion pivot riser | 14. Seat cushion hinge assembly | 15. Seatback frame |
| 16. Seatback latch assembly | 17. Seatback latch release strap | 18. Outboard headrest locking guide |
| 19. Seat cushion assembly | 20. Seatback assembly | |

Bench Seat RH (Crew Cab)

SEC. 880



WIIA1060E

REAR SEAT

< DISASSEMBLY AND ASSEMBLY >

- | | | | |
|------------------------------------|---------------------------------|---------------------------------------|----|
| 1. Headrest | 2. Seatback latch assembly | 3. Seatback latch release strap | A |
| 4. Seatback frame | 5. Armrest frame | 6. Armrest pad | |
| 7. Armrest trim cover | 8. Seatback pad | 9. Seatback trim cover | |
| 10. Seatback armrest opening board | 11. Seat cushion trim cover | 12. Seat cushion pad | B |
| 13. Seat cushion frame | 14. Inboard pivot riser | 15. Seat cushion bumper RH/LH | |
| 16. Inboard pivot riser cover | 17. Seat cushion hinge assembly | 18. Seat cushion hinge release handle | C |
| 19. Outboard pivot riser | 20. Outboard pivot riser cover | 21. Outboard headrest guide | |
| 22. Inboard headrest locking guide | 23. Armrest assembly | 24. Seatback assembly | D |
| 25. Seat cushion assembly | | | E |
| | | | F |
| | | | G |
| | | | H |
| | | | I |
| | | | SE |
| | | | K |
| | | | L |
| | | | M |
| | | | N |
| | | | O |
| | | | P |