

ALPHABETICAL INDEX

SECTION **IDX**

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ALPHABETICAL INDEX

A

ABS (anti-lock brake system).....BR-39
 ABS - Wiring diagramBR-44
 ABS sensor rotorAX-18
 Absolute pressure sensorEC-199
 A/C air flow.....HA-26, 175
 A/C component layout.....HA-20, 173
 A/C compressor clutch removal and
 installation.....HA-143, 230
 A/C compressor descriptionHA-168
 A/C compressor precautionHA-8, 161
 A/C compressor special service tool.....HA-11, 164
 A/C control linkage adjustment (manual
 A/C)HA-193, 212, 215
 A/C control operation (auto A/C).....HA-24
 A/C control operation (manual A/C).....HA-174
 A/C diagnostic work flow (auto A/C)HA-64
 A/C diagnostic work flow (manual A/C).....HA-184
 A/C HFC134a (R134a) system
 precaution.....HA-3, 156
 A/C HFC134a (R134a) system service
 procedure.....HA-138, 224
 A/C HFC134a (R134a) system service
 tools.....HA-12, 165
 A/C HFC134a system service equip-
 ment precaution.....HA-8, 161
 A/C lubricant (R134a)HA-140, 226
 A/C operational check.....HA-65, 185
 A/C performance chart.....HA-112, 203
 A/C performance test diagnoses.....HA-110, 201
 A/C relayHA-107, 222
 A/C self-diagnoses (auto A/C).....HA-43
 A/C service data specification.....HA-155, 242
 A/C system description (auto A/C).....HA-24
 A/C trouble diagnoses (auto A/C)HA-28
 A/C trouble diagnoses (manual A/C)HA-177
 A/C, A - Wiring diagramHA-31, 35
 A/C, M - Wiring diagramHA-180
 Accelerator control systemFE-3
 Accelerator pedal position (APP)
 sensor.....EC-302, 309, 559
 Air bag.....RS-13
 Air bag disposal.....RS-26
 Air bag precautionsGI-3
 Air bleeding (hydraulic clutch)CL-7
 Air bleeding for brake systemBR-9
 Air cleaner filter replacement.....MA-16
 Air conditioner cut controlEC-35
 Air flow meter - See Mass air flow
 sensor.....EC-186, 193, 463
 Air mix door control linkage
 adjustment.....HA-86, 212
 Air mix. door motorHA-83, 135, 209
 Air spoiler, rear.....BT-42
 Alternator.....SC-31
 Ambient sensorHA-123
 Angular tightening application.....EM-3
 Antenna - See Power antennaEL-193

Anti-lock brake system - See ABS.....BR-39
 Anti-lock brake system - Wiring
 diagram.....BR-44
 ASCD (automatic speed control device)EL-246
 A/T - Wiring diagramAT-16
 A/T - Wiring diagram - AT - FTSAT-112
 A/T - Wiring diagram - AT - MAIN.....AT-101
 A/T - Wiring diagram - AT - PNP/SW.....AT-106
 A/T - Wiring diagram - AT - VSS A/TAT-118, 214
 A/T fluid temperature sensor.....AT-110
 A/T self-diagnosesAT-41, 51
 A/T shift lock system.....AT-271
 A/T shift lock system - Wiring diagram.....AT-272
 A/T trouble diagnosesAT-57
 A/T Wiring diagram - AT - ENG SSAT-123
 A/T Wiring diagram AT - 1ST.....AT-129
 A/T Wiring diagram AT - 2ND.....AT-135
 A/T Wiring diagram AT - 3RD.....AT-141
 A/T Wiring diagram AT - 4TH.....AT-148
 A/T Wiring diagram AT - BA/FTS.....AT-198
 A/T Wiring diagram AT - CAN.....AT-210
 A/T Wiring diagram AT - LPSV.....AT-170
 A/T Wiring diagram AT - NONDTC.....AT-221
 A/T Wiring diagram AT - OVRCSV.....AT-193
 A/T Wiring diagram AT - SSV/A.....AT-176
 A/T Wiring diagram AT - SSV/B.....AT-181
 A/T Wiring diagram AT - TCCSIG.....AT-161
 A/T Wiring diagram AT - TCV.....AT-155
 A/T Wiring diagram AT - TPS.....AT-187
 A/T Wiring diagram AT - VSSMTR.....AT-205
 Audio.....EL-180
 AUDIO - Wiring diagram.....EL-183
 Audio and A/C control removal and
 installation - See Instrument panelBT-29
 AUT/DP - Wiring diagramEL-215
 Auto air conditioner - Wiring diagramHA-31, 35
 Auto anti-dazzling inside mirrorEL-202
 Automatic amplifier.....HA-39, 71
 Automatic drive positionerEL-210
 Automatic speed control system - See
 ASCDEL-246
 Automatic transmission fluid
 replacement.....MA-21
 Automatic transmission numberGI-45

B

Back-up lamp.....EL-74
 Back-up lamp switch (M/T)MT-10
 BACK/L - Wiring diagram.....EL-74
 Ball joint (front).....SU-13
 Basic inspectionEC-121
 Battery.....SC-4
 Battery/Starting/Charging System
 Tester.....SC-7, 13, 24
 Baulk ring (M/T).....MT-16
 B/COMP - Wiring diagramEL-132
 Blower and cooling unit.....HA-148, 235
 Blower motorHA-91, 195
 Blower resistor.....HA-195

ALPHABETICAL INDEX

Board computerEL-130
 Board-on liftGI-47
 Body alignmentBT-65
 Brake boosterBR-20
 Brake fluid changeBR-8
 Brake fluid levelMA-24
 Brake fluid level and line checkBR-8
 Brake hydraulic lineBR-10
 Brake inspectionMA-24
 Brake lines and cables inspectionMA-24
 Brake master cylinderBR-14, 17
 Brake pedalBR-12
 Brake switchEC-691
 BRK/SW - Wiring diagramEC-692
 Bulb specificationsEL-476
 Bumper, frontBT-13
 Bumper, rearBT-16
 BYPS/V - Wiring diagramEC-637, 644

C

Camshaft inspectionEM-48
 Camshaft position sensor (PHASE)EC-335
 CAN (Controller Area Network)EL-429, 430, 436
 CAN - Wiring diagramEL-431, 437
 CAN communicationAT-100, BR-109,
 EL-429, 430, 436
 Canister - See EVAP canisterEC-36
 CHARGE - Wiring diagramSC-23
 Charging systemSC-22
 Chassis and body maintenanceMA-20
 CHIME - Wiring diagramEL-146
 CIGAR - Wiring diagramEL-165
 Cigarette lighterEL-165
 Circuit breakerEL-18
 Closed loop control (Bank 1)EC-524
 Closed loop control (Bank 2)EC-524
 Clutch coverCL-15
 Clutch discCL-15
 Clutch fluid levelMA-20
 Clutch master cylinderCL-8
 Clutch operating cylinderCL-10
 Clutch pedalCL-6
 Clutch release bearingCL-13
 Clutch release mechanismCL-13
 Clutch withdrawal leverCL-13
 Coil spring (front)SU-9
 Coil spring (rear)SU-22
 Collision diagnosisRS-62
 Combination lamp, front, removal and
 installationBT-13
 Combination lamp, rear, removal and
 installationBT-42
 Combination meterEL-117
 Combination meter removal and instal-
 lation - See Instrument panelBT-29
 Combination switchEL-31
 Component Location (auto A/C)HA-28
 Component Location (manual A/C)HA-177
 Compression pressureEM-13

Compressor clutch removal and
 installationHA-143, 230
 Compressor descriptionHA-168
 Compressor precautionHA-8, 161
 Compressor special service toolHA-11, 164
 Connecting rodEM-69
 Connecting rod bearing clearanceEM-73
 Connecting rod bushing clearanceEM-74
 Connector inspectionGI-21
 Console box - See Instrument panelBT-29
 CONSULT for ABSBR-48
 CONSULT for engineEC-101
 CONSULT for TCSBR-95
 Control lever (M/T)MT-11
 Control valve (A/T)AT-309
 Controller Area Network (CAN)EL-429, 430, 436
 Converter housing installationAT-370
 COOL/F - Wiring diagramEC-534
 Coolant mixture ratioMA-12
 Coolant replacementMA-14
 Cooling circuit (engine)LC-12
 Cooling fan controlEC-530
 Cooling fan control systemLC-21
 Coupling sleeve (M/T)MT-16
 Crankcase emission control system -
 See positive crankcase ventilationEC-51
 CrankshaftEM-71
 Crankshaft position sensor (POS)EC-328
 Crash zone sensorRS-18
 Cruise control - See ASCDEL-246
 Cylinder blockEM-66
 Cylinder headEM-44
 Cylinder head bolt tighteningEM-55

D

Data link connector for ConsultEC-101
 Daytime light systemEL-51
 Daytime running light - See Daytime
 light systemEL-51
 DEF - Wiring diagramEL-169
 Detonation sensor - See Knock sensorEC-323
 Diagnosis sensor unitRS-17
 Diagnostic trouble code (DTC) for OBD
 systemEC-9, 76
 Diagnostic trouble code (DTC) inspec-
 tion priority chartEC-126
 Differential gear (FF A/T)AT-353
 Differential gear (FF M/T)MT-19, 38
 DimensionsGI-46
 DLC - Wiring diagramEC-761
 D/LOCK - Wiring diagramEL-263
 Dome light - See Interior lampEL-92
 Door glassBT-21
 Door lockBT-25
 Door mirrorBT-63
 Door trimBT-37
 Door, frontBT-20
 Door, rearBT-20
 Drive plate runoutEM-75

ALPHABETICAL INDEX

Drive shaft (front).....AX-9
Dropping resistor (A/T).....AT-168
DTC work support.....EC-113
DTRL - Wiring diagram.....EL-55

E

ECM input/output signal.....EC-139
ECM power supply.....EC-459
ECM/PW - Wiring diagram.....EC-460
ECTS - Wiring diagram.....EC-207
Electric sun roof.....EL-196
Electric throttle control actuator.....EC-469, 471
Electrical diagnoses.....GI-24
Electrical ignition system.....EC-34
Electrical unit.....Foldout
Electrical units location.....EL-449
EMNT - Wiring diagram.....EC-734
Engine compartment.....BT-66
Engine control circuit diagram.....EC-28
Engine control component parts
location.....EC-24
Engine control module (ECM).....EC-453
Engine control system diagram and
chart.....EC-29
Engine coolant temperature sensor
(ECTS).....EC-205, 211
Engine fail-safe system.....EC-127
Engine mounting control (Front).....EC-733
Engine oil filter replacement.....MA-17
Engine oil precautions.....GI-7
Engine oil replacement.....MA-16
Engine outer component parts.....EM-9
Engine removal.....EM-62
Engine room - See Engine
compartment.....BT-66
Engine serial number.....GI-45
EVAP canister.....EC-37
EVAP canister purge volume control
solenoid valve.....EC-36, 374, 586
EVAP canister vent control
valve.....EC-381, 599, 607
EVAP control system (small leak)
diagnosis.....EC-359, 415, 571, 616
EVAP control system pressure
sensor.....EC-388, 394
EVAP control system purge flow moni-
toring diagnosis.....EC-349
EVAP vapor lines inspection.....MA-19
Evaporative emission (EVAP) system.....EC-36
Exhaust system.....FE-9
Exhaust system inspection.....MA-20
Exterior.....BT-42

F

Fan control amp.....HA-94
Fan switch.....HA-195

F/FOG - Wiring diagram.....EL-76
Final drive (FF A/T).....AT-353
Final drive (FF M/T).....MT-19, 38
Finisher, interior - See Trim.....BT-34
Finisher, trunk lid.....BT-41
Floor trim.....BT-34
FLS1 - Wiring diagram.....EC-431
FLS2 - Wiring diagram.....EC-437
Fluid temperature sensor (A/T).....AT-110
Fluids.....MA-11
Flywheel (clutch).....CL-15
Flywheel runout.....EM-75
Fog lamp, front.....EL-75
Fog lamp, front, removal and
installation.....BT-13
Fork rod (M/T).....MT-18
Forward clutch.....AT-331
F/PUMP - Wiring diagram.....EC-727
Freeze frame data.....EC-77
Front axle.....AX-2
Front bumper.....BT-13
Front combination lamp removal and
installation.....BT-13
Front disc brake.....BR-23
Front door.....BT-20
Front fog lamp.....EL-75
Front fog lamp removal and installation.....BT-13
Front seat.....BT-48
Front seat belt.....RS-4
Front suspension.....SU-2
Front washer.....EL-159
Front wiper.....EL-159
FTTS - Wiring diagram.....EC-285
Fuel cut control (at no load & high
engine speed).....EC-36
Fuel gauge.....EL-117
Fuel injection system (Bank 1).....EC-265, 273
Fuel injection system (Bank 2).....EC-265, 273
Fuel level sensor.....EC-430, 434
Fuel line inspection.....MA-15
Fuel precautions.....GI-8
Fuel pressure check.....EC-56
Fuel pressure release.....EC-56
Fuel pump.....EC-726
Fuel system.....FE-4
Fuel tank temperature sensor.....EC-280, 283
Fuel tank vacuum relief valve.....EC-37
FUELB1 - Wiring diagram.....EC-267, 275
FUELB2 - Wiring diagram.....EC-268, 276
Fuse.....EL-18
Fuse and fusible link box.....Foldout
Fuse block.....Foldout
Fusible link.....EL-18

G

Garage jack and safety stand.....GI-48
Gauges.....EL-117
Gear components (M/T).....MT-16
Generator - See Alternator.....SC-31

ALPHABETICAL INDEX

Generic scan tool (GST).....EC-115
GlassBT-21
Grease.....MA-11
Ground distribution.....EL-19

H

Harness connector.....EL-6
Harness connector inspectionGI-21
Harness layoutEL-453
Hazard warning lamp.....EL-80
HeadlampEL-37
Headlamp removal and installationBT-13
Headlining - See Roof trimBT-39
Heated oxygen sensor 1
(bank 1).....EC-218, 226, 238, 490, 497
Heated oxygen sensor 1
(bank 2).....EC-218, 226, 238, 490, 497
Heated oxygen sensor 1 heater
(bank 1).....EC-173
Heated oxygen sensor 1 heater
(bank 2).....EC-173
Heated oxygen sensor 2
(bank 1).....EC-247, 255, 504, 514
Heated oxygen sensor 2
(bank 2).....EC-247, 255, 504, 514
Heated oxygen sensor 2 heater
(bank 1).....EC-179
Heated oxygen sensor 2 heater
(bank 2).....EC-179
Heated seat.....BT-51, EL-208
Heated steering.....EL-34
Heater unit (heater core).....HA-147, 234
Height (Dimensions)GI-46
HFC134a (R134a) system precautionHA-3, 156
HFC134a (R134a) system service
procedure.....HA-138, 224
HFC134a (R134a) system service
toolsHA-12, 165
HFC134a system service equipment
precautionHA-8, 161
High clutch.....AT-326
H/LAMP - Wiring diagramEL-41
Homelink universal transceiverEL-353
Hood.....BT-13
HornEL-164
HORN - Wiring diagram.....EL-164
How to erase DTC for OBD system.....EC-91
HSEAT - Wiring diagram.....EL-208
H/STRG - Wiring diagram.....EL-36

I

IATS - Wiring diagramEC-202
Identification plate.....GI-45
Idle mixture ratio.....EC-59
Idle speed.....EC-59
Ignition control systemEC-705

Ignition timingEC-59
IGNSYS - Wiring diagramEC-706
ILL - Wiring diagramEL-87
IlluminationEL-85
I/MIRR - Wiring diagramEL-202
In vehicle sensorHA-126
INJECT - Wiring diagramEC-717
InjectorEC-716
Injector removal and installationEC-57
Input shaft (FF M/T)MT-16, 24
Instrument panelBT-29
Intake air temperature sensor.....EC-201, 214
Intake door control linkage adjustment..HA-90, 193
Intake door motor.....HA-87, 190
Intake manifold.....EM-11
Intake sensorHA-133
Integrated homelink transmitterEL-353
InteriorBT-34
Interior lampEL-92
Interior lamp on-off control.....EL-94
IVIS (Infiniti vehicle immobilizer
system).....EL-356

J

Jacking points.....GI-48
Joint connector (J/C)Foldout
Junction box (J/B).....Foldout

K

KEYLES - Wiring diagramEL-282
Knock sensor (KS)EC-323
Knuckle spindleAX-5
KS - Wiring diagram.....EC-324

L

Length (Dimensions)GI-46
License lampEL-65
Lifting pointsGI-49
Line pressure solenoid valveAT-168
Line pressure test (A/T)AT-67
Liquid gasket applicationEM-3
LOAD - Wiring diagramEC-757
Location of electrical unitsEL-449
Lock, doorBT-25
Low and reverse brakeAT-336
Lubricant (R134a) A/CHA-140, 226
Lubricants.....MA-11
Lubrication circuit (engine)LC-4
Lubrication-locks, hinges and hood
latchesMA-26

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ALPHABETICAL INDEX

M

MAFS - Wiring diagramEC-189, 195, 465
Magnet clutch.....HA-101, 143, 230
MAIN - Wiring diagram.....EC-155
Mainshaft (M/T)MT-16, 29
Maintenance (engine)MA-13
MAJOR OVERHALL.....AT-283
Malfunction indicator lamp (MIL)EC-455
Manual air conditioner - Wiring diagram.....HA-180
Manual transmission oil replacementMA-20
Mass air flow sensor (MAFS)EC-186, 193, 463
Master cylinder (brake)BR-14, 17
Master cylinder (clutch)CL-8
MeterEL-117
METER - Wiring diagram.....EL-121
MIL - Wiring diagram.....EC-456
MIRROR - Wiring diagram.....EL-201
Mirror defoggerEL-167
Mirror, door.....BT-63
MisfireEC-315
Mode door control linkage adjustment...HA-81, 215
Mode door motor.....HA-75, 213
Model variationGI-43
Molding - See Exterior.....BT-42
M/T major overhaulMT-15
M/T removal and installationMT-13
MULTI - Wiring diagram.....EL-282
Multi-remote control system.....EL-277
Multiplex communicationHA-136
Multiport fuel injection (MFI) systemEC-32
Multiport fuel injection precautions.....GI-6

N

NATS (Nissan anti-theft system)
 precautionsGI-3
NATS - Wiring diagramEL-358
NAVI - wiring diagramEL-384
Navigation System.....EL-376
NVH troubleshooting (AX)AX-3
NVH troubleshooting (BR).....BR-7
NVH troubleshooting (CL)CL-4
NVH troubleshooting (M/T)MT-7
NVH troubleshooting (ST).....ST-5
NVH troubleshooting (SU).....SU-4
NVIS (Nissan vehicle immobilizer
 system).....EL-356
NVIS (Nissan vehicle immobilizer sys-
 tem) precautionsGI-3

O

O2H1B1 - Wiring diagramEC-175
O2H1B2 - Wiring diagramEC-176
O2H2B1 - Wiring diagramEC-181
O2H2B2 - Wiring diagramEC-182

O2S1B1 - Wiring diagram.....EC-220, 229, 241
O2S1B2 - Wiring diagram.....EC-221, 230, 242
O2S2B1 - Wiring diagram ...EC-249, 258, 507, 517
O2S2B2 - Wiring diagram ...EC-250, 259, 508, 518
Oil change (capacity)MA-11
Oil cooler (engine)LC-9
Oil pan (engine)EM-14
Oil pressure (engine)LC-6
Oil pump (A/T).....AT-305
Oil pump (engine)LC-6
Oil pump regulator valve (engine)LC-8
Oil seal replacement (engine).....EM-41
On board diagnostic systemEC-75
Operating cylinder (clutch).....CL-10
ORVR (On-board Refueling Vapor
 Recovery).....EC-42
Overheat.....EC-530
Overrun clutch.....AT-331
Overrun clutch solenoid valve.....AT-191

P

P/ANT - Wiring diagram.....EL-193
Park/Neutral position switchEC-680
Park/neutral position switch (A/T)AT-104
Park/neutral position switch (M/T).....MT-10
Parking brake controlBR-35, 37
Parking lampEL-65
PCV (positive crankcase ventilation)EC-51
PGC/V - Wiring diagramEC-376, 589
PHASE - Wiring diagramEC-337
Piston assemblyEM-76
Piston pin inspection.....EM-68
Piston ring inspection.....EM-68
Piston to bore clearance.....EM-70
PNP/SW - Wiring diagramEC-682
POS - Wiring diagramEC-330
POWER - Wiring diagramEL-11
Power antennaEL-193
Power door lockEL-261
Power door mirrorEL-201
Power seatEL-205
Power steering fluid level.....MA-25, ST-7
Power steering gear.....ST-14
Power steering hydraulic pressureST-9
Power steering oil pumpST-24
Power steering pressure (PSP) sensorEC-448
Power steering system bleeding.....ST-7
Power supply routingEL-10
Power transistor & ignition coil.....EC-705
Power windowEL-247
PRE/SE - Wiring diagramEC-390, 396
Precations for Leak detection dyeHA-4, 157
Precautions (General)GI-4
Pressure plate - See Clutch coverCL-15
Pressure test (A/T)AT-67
PS/SEN - Wiring diagramEC-449

ALPHABETICAL INDEX

R

RadiatorLC-20, 21
 Radio - See Audio.....EL-180
 Rear air spoilerBT-42
 Rear axleAX-16
 Rear axle (disc brake type)AX-18
 Rear bumperBT-16
 Rear combination lamp removal and
 installationBT-42
 Rear disc brakeBR-27
 Rear doorBT-20
 Rear seatBT-52
 Rear seat beltRS-6
 Rear suspensionSU-16
 Rear windowBT-61
 Rear window defogger.....EL-167
 Refrigerant pressure sensorHA-107, 222
 Refrigerant connection precautionHA-5, 158
 Refrigerant discharging evacuating
 chargingHA-138
 Refrigerant general precautionHA-4, 157
 Refrigerant linesHA-149, 236
 Refrigerant pressure sensor.....EC-737
 Refrigeration cycleHA-15, 168
 Release bearing (clutch).....CL-13
 Remote keyless entry system.....EL-277
 Removal and installation (A/T).....AT-280
 Reverse clutch.....AT-323
 Reverse idler shaft (M/T)MT-16, 37
 Reverse lamp switch (M/T) - See
 Back-up lamp switch (M/T).....MT-10
 Reverse main gear (M/T).....MT-16, 37
 Revolution sensor (A/T).....AT-116
 Road wheel sizeGI-46
 Roof trimBT-39
 Room lamp - See Interior lampEL-92
 ROOM/L - Wiring diagramEL-96
 RP/SEN - Wiring diagramEC-738

S

SAE J1930 terminology listGI-53
 Seal - See ExteriorBT-42
 SEAT - Wiring diagramEL-205
 Seat belt inspectionMA-27, RS-8
 Seat belt pre-tensionerRS-3
 Seat belt pre-tensioner disposalRS-26
 Seat belt, front.....RS-4
 Seat belt, rear.....RS-6
 Seat, frontBT-48
 Seat, rearBT-52
 SHIFT - Wiring diagramAT-272
 Shift control components (M/T)MT-18
 Shift fork (M/T)MT-18
 Shift lever.....MT-11
 Shift lock systemAT-271
 Shift schedule.....AT-376

Shift solenoid valve A (A/T).....AT-174
 Shift solenoid valve B (A/T)AT-179
 Shock absorber (front)SU-10
 Shock absorber (rear)SU-22
 Side air bagRS-24
 Side trim.....BT-34
 Smart entrance control unitEL-342
 SMJ (super multiple junction)Foldout
 Spare tire sizeGI-46
 Spark plug replacement.....MA-17
 SpeedometerEL-117
 Spiral cable.....RS-20
 Spring (Wheelarch) heightSU-6
 SROOF - Wiring diagramEL-197
 SRS - See Supplemental Restraint
 SystemRS-13
 SRS - Wiring diagramRS-38
 S/SIG - Wiring diagramEC-723
 Stabilizer bar (front)SU-11
 Stall test (A/T)AT-63
 Standardized relayEL-8
 START - Wiring diagram.....SC-11
 Start signalEC-722
 StarterSC-19
 Starting system.....SC-10
 Steering gear and linkage inspectionMA-25
 Steering linkageST-14
 Steering switch.....EL-33
 Steering wheel and columnST-10
 Steering wheel playST-6
 Steering wheel turning force.....ST-8
 Stop lamp.....EL-73
 STOP/L - Wiring diagram.....EL-73
 Strut (front)SU-9
 Strut (rear)SU-20
 Sunload sensorHA-129
 Sunroof.....BT-53
 Sunroof, electricEL-196
 Supplemental Restraint SystemRS-13
 Supplemental restraint system - Wiring
 diagramRS-38
 Symbols and abbreviationsGI-10
 Symptom matrix chartEC-129
 Synchronizer (M/T)MT-16
 System readiness test (SRT) codeEC-77

T

Tachometer.....EL-117
 Tail lamp.....EL-65
 TAIL/L - Wiring diagramEL-68
 TCM circuit diagramAT-16
 TCM inspection tableAT-97
 TCS (traction control system)BR-86
 TCS - Wiring diagramBR-90
 TCS component parts and connector
 locationBR-89
 TCS control unitBR-88
 TCS system componentsBR-87
 TCS trouble diagnoses.....BR-103

ALPHABETICAL INDEX

TCS wheel sensorsBR-89
THEFT - Wiring diagram.....EL-316
Theft warning system.....EL-308
Thermostat.....LC-18
Three way catalyst precautions.....GI-6
Throttle bodyEM-11
Throttle control motorEC-485
Throttle control motor relayEC-479
Throttle position sensor (TPS)EC-288, 295, 548,
555, 557
Throttle position switchAT-184, 264
Throwout bearing - See Clutch release
bearingCL-13
Tie-rodST-14
Tie-rod ball joints.....ST-18
Tightening torque of standard bolts.....GI-51
Timing chain.....EM-21
Tire rotationMA-23
Tire sizeGI-46
Torque converter clutch solenoid valve.....AT-153
Torque converter installationAT-281, 370
Tow truck towingGI-50
Traction control system - See TCSBR-86
Traction control system - Wiring
diagramBR-90
Transaxle serial numberGI-45
Transmission case (M/T).....MT-15
TRANSMT - Wiring diagramEL-353
Tread-FR&RR (Dimensions).....GI-46
TrimBT-34
TRNSCV - Wiring diagramEL-353
Trouble diagnosesGI-34
Trunk lidBT-16
Trunk lid finisher.....BT-41
Trunk lid opener - See Trunk lidBT-16
Trunk lid trimBT-41
Trunk room trim.....BT-41
Turbine revolution sensor.....AT-212
TURN - Wiring diagramEL-82
Turn signal lampEL-80
Two trip detection logicEC-75
Two-pole liftGI-49

U

Under bodyBT-68

V

Vacuum cut valveEC-36

Vacuum cut valve bypass valve.....EC-36, 635, 641
Vacuum hose (brake system).....BR-22
Vacuum hose drawing (Engine control)EC-30
Valve clearance.....EM-58
Valve guide.....EM-50
Valve seat.....EM-51
Valve spring.....EM-52
Vehicle recovery (freeing a stuck
vehicle).....GI-50
Vehicle security (theft warning) systemEL-308
Vehicle speed sensor (VSS)EC-440
VEHSEC - Wiring Diagram.....EL-316
VENT/V - Wiring diagramEC-383, 601, 610
Ventilation air filter.....HA-154, 241
VIASEC-686, 697
VIAS - Wiring diagramEC-699
Viscosity number (SAE)MA-11
VSS - Wiring diagramEC-442

W

WARN - Wiring diagramEL-137
Warning chimeEL-144
Warning lampsEL-136
Washer, front.....EL-159
Water pumpLC-14
Water temperature gaugeEL-117
Weatherstrip - See ExteriorBT-42
Wheel alignment (front)SU-6
Wheel alignment (rear).....SU-18
Wheel balanceMA-22
Wheel bearing (front).....AX-4
Wheel bearing (rear)AX-17
Wheel hub (front).....AX-5
Wheel hub (rear)AX-18
Wheel sensors (ABS).....BR-138
Wheel sensors (TCS).....BR-138
Wheelarch heightSU-6
Wheelbase (Dimensions)GI-46
Width (Dimensions)GI-46
WINDOW - Wiring diagramEL-251
Window, rearBT-61
Windshield.....BT-61
WIPER - Wiring diagramEL-161
Wiper, front.....EL-159
Wiring Diagram (Cell code) list.....EL-477
Wiring diagramsGI-11
Withdrawal lever (clutch)CL-13
Wrist pin - See Piston pin inspection.....EM-68