

MANUAL TRANSAXLE

SECTION MT

CONTENTS

PREPARATION	3	INSPECTION.....	37	CL
Special Service Tools	3	ASSEMBLY	38	
Commercial Service Tools	5	Final Drive.....	38	
NOISE, VIBRATION AND HARSHNESS (NVH)		PRE-INSPECTION	38	
TROUBLESHOOTING	7	DISASSEMBLY.....	39	
NVH Troubleshooting Chart.....	7	INSPECTION.....	39	
MANUAL TRANSAXLE	7	ASSEMBLY	40	
DESCRIPTION	8	Shift Control Components	42	
Cross-sectional View	8	INSPECTION.....	42	
DOUBLE-CONE SYNCHRONIZER	9	ADJUSTMENT	43	
REVERSE GEAR NOISE PREVENTION		Input Shaft End Play.....	43	
FUNCTION (SYNCHRONIZING METHOD).....	9	Mainshaft End Play.....	44	
ON-VEHICLE SERVICE	10	Differential Side Bearing Preload	45	
Replacing Oil Seal	10	Reverse Idler Gear End Play	46	
DIFFERENTIAL OIL SEAL	10	ASSEMBLY	48	
Position Switch Check.....	10	SERVICE DATA AND SPECIFICATIONS (SDS)	54	
BACK-UP LAMP SWITCH	10	General Specifications.....	54	
PARK/NEUTRAL POSITION SWITCH	10	TRANSAXLE	54	
Control Device and Cable	11	FINAL GEAR	55	
Air Breather Hose.....	12	Gear End Play	55	
REMOVAL AND INSTALLATION	13	Clearance Between Baulk Ring and Gear	55	
Removal.....	13	3RD, 4TH, 5TH, 6TH & REVERSE BAULK RING	55	
Installation.....	14	1ST AND 2ND DOUBLE BAULK RING	55	
OVERHAUL	15	Available Snap Rings	56	
Case and Housing Components	15	6TH BUSHING.....	56	
Gear Components	16	Available C-rings.....	56	
Shift Control Components	18	MAINSHAFT C-RING	56	
Final Drive Components.....	19	Available Thrust Washer.....	56	
DISASSEMBLY	20	INPUT SHAFT THRUST WASHER	56	
REPAIR FOR COMPONENT PARTS	24	DIFFERENTIAL SIDE GEAR THRUST WASHER.....	57	
Input Shaft and Gears	24	Available Adjusting Shims	57	
DISASSEMBLY	24	MAINSHAFT ADJUSTING SHIM.....	57	
INSPECTION.....	25	INPUT SHAFT REAR BEARING ADJUSTING		
ASSEMBLY	26	SHIM	57	
Mainshaft and Gears	29	MAINSHAFT REAR BEARING ADJUSTING SHIM	58	
DISASSEMBLY	29	REVERSE IDLER GEAR ADJUSTING SHIM	58	
INSPECTION.....	30	6TH MAIN GEAR ADJUSTING SHIM.....	58	
ASSEMBLY	32	Available Shims - Differential Side Bearing		
Reverse Idler Shaft and Gears.....	37	Preload and Adjusting Shim	58	
DISASSEMBLY	37	BEARING PRELOAD	58	

CONTENTS (Cont'd)

DIFFERENTIAL SIDE BEARING ADJUSTING
SHIM(S)59






PREPARATION

Special Service Tools

Special Service Tools

NFMT0001

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.







Tool number (Kent-Moore No.) Tool name	Description	
KV381054S0 (J34286) Puller	 <p>Side bearing outer race removal Mainshaft front bearing removal</p> <p>ZZA0601D</p>	GI MA EM LC EC
ST35321000 (—) Drift	 <p>Input shaft oil seal installation Reverse main gear installation 1st bushing installation 1st-2nd synchronizer hub installation 2nd bushing installation 3rd main gear installation a: 49 mm (1.93 in) dia. b: 41 mm (1.61 in) dia.</p> <p>ZZA1000D</p>	FE CL
ST30720000 (J25405) Drift	 <p>Differential oil seal installation Differential side bearing outer race installation Mainshaft rear bearing installation Differential side bearing installation a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.</p> <p>ZZA0811D</p>	MT AT AX SU
ST33200000 (J26082) Drift	 <p>Mainshaft front bearing installation 6th bushing installation 4th main gear installation 5th main gear installation 6th main gear installation a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.</p> <p>ZZA1002D</p>	BR ST RS
ST33061000 (J8107-2) Drift	 <p>Bore plug installation Differential side bearing removal a: 38 mm (1.50 in) dia. b: 28.5 mm (1.122 in) dia.</p> <p>ZZA1000D</p>	BT HA SC

EL

IDX





PREPARATION

Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description
ST33052000 (—) Drift	 <p>ZZA1023D</p> <p>Welch plug installation Input shaft rear bearing removal 5th bushing, thrust washer, 4th input gear, 4th gear bushing, 3rd-4th synchronizer hub and 3rd input gear removal Input shaft front bearing installation 6th input gear and 6th bushing removal Mainshaft rear bearing removal 4th main gear and 5th main gear removal 6th main gear removal a: 22 mm (0.87 in) dia. b: 28 mm (1.10 in) dia.</p>
KV40105020 (—) Drift	 <p>ZZA1133D</p> <p>5th input gear and synchronizer hub removal 3rd main gear, 2nd main gear, 2nd bushing, 1st-2nd synchronizer hub, 1st main gear, reverse main gear and 1st bushing removal a: 39.7 mm (1.563 in) dia. b: 35 mm (1.38 in) dia. c: 15 mm (0.59 in)</p>
KV40105710 (—) Press stand	 <p>ZZA1058D</p> <p>3rd-4th synchronizer hub installation 4th bushing installation 5th bushing installation 5th-6th synchronizer hub installation 2nd bushing installation 3rd main gear installation a: 46 mm (1.81 in) dia. b: 41 mm (1.61 in)</p>
ST38220000 (—) Press stand	 <p>ZZA1058D</p> <p>Reverse main gear installation 1st bushing installation 1st-2nd synchronizer hub installation a: 63 mm (2.48 in) dia. b: 65 mm (2.56 in)</p>
ST30032000 (J26010-01) Drift	 <p>ZZA0978D</p> <p>Input shaft front bearing installation a: 80 mm (3.15 in) dia. b: 38 mm (1.50 in) dia. c: 31 mm (1.22 in) dia.</p>
ST30901000 (J26010-01) Drift	 <p>ZZA0978D</p> <p>Input shaft rear bearing installation 4th main gear installation 5th main gear installation 6th main gear installation Mainshaft rear bearing installation a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35.2 mm (1.386 in) dia.</p>



PREPARATION

Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description	
ST30031000 (J22912-01) Puller	Measuring wear of 1st and 2nd baulk ring	GI
		MA
	ZZA0537D	EM
KV40101630 (J35870) Drift	Reverse main gear installation a: 68 mm (2.68 in) dia. b: 60 mm (2.36 in) dia.	LC
		EC
	ZZA1003D	FE
KV38102510 (—) Drift	1st bushing installation 1st-2nd synchronizer hub installation Differential side bearing installation a: 71 mm (2.80 in) dia. b: 65 mm (2.56 in) dia.	CL
		MT
	ZZA0838D	AT
(J39713) Preload adapter	Checking differential side gear end play	AX
		SU
	NT087	BR



Commercial Service Tools

NFMT0002

Tool name	Description	
Puller	Each bearing gear and bushing removal	ST
		RS
	ZZB0823D	BT
Puller	Each bearing gear and bushing removal	HA
		SC
	NT077	EL
		IDX

PREPARATION

Commercial Service Tools (Cont'd)

Tool name	Description	
Pin punch		Each retaining pin removal and installation Tip diameter: 4.5 mm (0.177 in) dia.
	ZZA0815D	
Power tool		Loosening bolts and nuts
	PBIC0190E	

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NFMT0003

NVH Troubleshooting Chart

NVH Troubleshooting Chart

NFMT0003S01

Use the chart below to help you find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

MANUAL TRANSAXLE

NFMT0003S0101

Reference page		Refer to MA-20, "Checking M/T Oil".			MT-15	MT-15	MT-15	MT-11	MT-18	MT-18	MT-16	MT-16	MT-16	MT-16
SUSPECTED PARTS (Possible cause)		(Oil level is low.)	(Wrong oil.)	(Oil level is high.)	GASKET (Damaged)	OIL SEAL (Worn or damaged)	O-RING (Worn or damaged)	SHIFT CONTROL LINKAGE (Worn)	CHECK PLUG RETURN SPRING AND CHECK BALL (Worn or damaged)	SHIFT FORK (Worn)	GEAR (Worn or damaged)	BEARING (Worn or damaged)	BAULK RING (Worn or damaged)	INSERT SPRING (Damaged)
Symptoms	Noise	1	2								3	3		
	Oil leakage		3	1	2	2	2							
	Hard to shift or will not shift		1	1				2					3	3
	Jumps out of gear							1	2	3	3			

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


DESCRIPTION

Cross-sectional View

Cross-sectional View

NFMT0004S01


RS6F51A



SMT115E

DESCRIPTION


Cross-sectional View (Cont'd)



DOUBLE-CONE SYNCHRONIZER

NFMT0004S0101

Double-cone synchronizer is adopted for 1st and 2nd gears to reduce operating force of the shift lever.



REVERSE GEAR NOISE PREVENTION FUNCTION (SYNCHRONIZING METHOD)

NFMT0004S0102

The gear can be matched smoothly in a structure by setting synchronizer hub, coupling sleeve, baulk ring and insert spring to reverse gear, and letting gear be synchronized.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX

ON-VEHICLE SERVICE

Replacing Oil Seal



Replacing Oil Seal DIFFERENTIAL OIL SEAL

NFMT0005

NFMT0005S01

1. Drain gear oil from transaxle.
2. Remove driveshaft. Refer to AX-10, "Drive Shaft".
3. Remove differential oil seals.

CAUTION:

Be careful not to damage the case surface when removing the oil seal.

4. Using a drift (special service tool), drive the oil seal straight until it protrudes from the case end equal to dimension A shown in the figure.

Dimension "A":


Within 0.5 mm (0.020 in) of flush with the case.

Drift to be used:

ST30720000 (J25405)

CAUTION:

- When installing oil seals, apply multi-purpose grease to oil seal lips.
 - Oil seals are not reusable. Never reuse them.
5. Install all parts in reverse order of removal and check oil level after installation.



Position Switch Check BACK-UP LAMP SWITCH

NFMT0006

NFMT0006S01

- Check continuity.

Gear position	Continuity
Reverse	Yes
Except reverse	No

PARK/NEUTRAL POSITION SWITCH

NFMT0006S02







- Check continuity.

Gear position	Continuity
Neutral	Yes
Except neutral	No

Control Device and Cable

Refer to the figure for removal and installation procedure.

SEC. 341



CAUTION:


- Keep in mind that the select side lock plate for securing the control cable is different from the one on the shift side.
- After assembly, make sure selector lever automatically returns to Neutral when it is moved to 1st, 2nd, or Reverse.

SMT122E

Air Breather Hose

Refer to the figure for air breather hose removal and installation information.

NFMT0030



SMT118E






CAUTION:

- Make sure there are no pinched or restricted areas on the air breather hose caused by bending or winding when installing it.
- Be sure to insert hose into the transaxle tube until overlap area reaches the spool.

REMOVAL AND INSTALLATION

Removal

NFMTO008S01



Removal

CAUTION:

Remove the crankshaft position sensor (POS) from transaxle assembly before separating transaxle from engine. Be careful not to damage sensor edge.

1. Remove battery and its bracket.
2. Remove air duct and air cleaner box with mass air flow sensor.
3. Remove air breather hose.
4. Disconnect control cable from transaxle.
5. Remove control cable mounting bracket.

6. Remove clutch operating cylinder from transaxle.
7. Disconnect PNP switch, back-up lamp switch and ground harness connectors.

8. Remove starter motor from transaxle.
9. Remove crankshaft position sensor (POS) from transaxle front side.

10. Drain gear oil from transaxle.
11. Draw out drive shafts from transaxle. Refer to AX-10, "Drive Shaft".
12. Support engine of transaxle by placing a jack under oil pan.

CAUTION:

Do not place jack under oil pan drain plug.

13. Remove center member.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

REMOVAL AND INSTALLATION


Removal (Cont'd)



14. Remove LH mount.
15. Remove bolts securing transaxle.
16. Lower transaxle while supporting it with a jack.

Installation

- Tighten LH mount and center member bolts. Refer to ^{NFMT0008S02}EM-62, "ENGINE ASSEMBLY".
- Tighten clutch operating cylinder bolts. Refer to CL-10, "OPERATING CYLINDER".
- Install drive shafts. Refer to AX-11, "Drive Shaft".
- Tighten all transaxle bolts and any part removed.



Bolt No.	Tightening torque N·m (kg-m, ft-lb)	"ℓ" mm (in)
1	69.6 - 79.4 (7.1 - 8.0, 52 - 58)	52 (2.05)
2	69.6 - 79.4 (7.1 - 8.0, 52 - 58)	113 (4.45)
3	36 - 47 (3.7 - 4.7, 27 - 34)	40 (1.57)


OVERHAUL

Case and Housing Components

Case and Housing Components

NFMT0009S02

SEC. 321



SMT196E


- | | | |
|--------------------------|----------------------------------|-----------------------|
| 1. Clutch housing | 8. Transaxle case | 15. Air breather tube |
| 2. Input shaft oil seal | 9. Welch plug | 16. Baffle plate |
| 3. Oil channel | 10. Bore plug | 17. Filler plug |
| 4. Magnet | 11. Differential oil seal | 18. Gasket |
| 5. Differential oil seal | 12. Park/Neutral position switch | 19. Drain plug |
| 6. Ball pin | 13. Oil gutter | 20. Gasket |
| 7. Washer | 14. Back-up lamp switch | |

OVERHAUL

Gear Components

NFMT0009S03

SEC. 322



★ : Select proper thickness.


NOTE :

- Apply gear oil to gears, shafts, synchronizers and bearings when assembling.
- Replace (8) and (10), (20) and (21) as a set.

SCIA0956E

- | | | |
|-------------------------------|--------------------------------|---|
| 1. Input shaft front bearing | 14. Thrust washer | 27. Input shaft rear bearing |
| 2. Input shaft | 15. Bushing | 28. Oil channel |
| 3. Needle bearing | 16. Needle bearing | 29. Input shaft rear bearing adjusting shim |
| 4. 3rd input gear | 17. 5th input gear | 30. Retaining pin |
| 5. 3rd baulk ring | 18. 5th baulk ring | 31. Reverse idler shaft |
| 6. Spread spring | 19. 5th & 6th shifting insert | 32. Thrust bearing |
| 7. 3rd & 4th shifting insert | 20. 5th & 6th synchronizer hub | 33. Needle bearing |
| 8. 3rd & 4th synchronizer hub | 21. 5th & 6th coupling sleeve | 34. Reverse idler gear (Front) |
| 9. 4th baulk ring | 22. 6th baulk ring | 35. Reverse baulk ring |
| 10. 3rd & 4th coupling sleeve | 23. 6th input gear | 36. Reverse coupling sleeve |
| 11. Bushing | 24. Needle bearing | 37. Insert spring |
| 12. Needle bearing | 25. Bushing | 38. Reverse idler gear (Rear) |
| 13. 4th input gear | 26. Snap ring | 39. Reverse idler gear adjusting shim |

SEC. 322




SCIA0957E

- | | | |
|-------------------------------|--------------------------------|---|
| 1. Mainshaft front bearing | 13. 1st & 2nd synchronizer hub | 25. 5th main gear |
| 2. Mainshaft bearing retainer | 14. 2nd outer baulk ring | 26. 6th main gear |
| 3. Mainshaft | 15. 2nd gear synchronizer cone | 27. Mainshaft rear bearing |
| 4. Reverse main gear | 16. 2nd inner baulk ring | 28. Mainshaft C ring |
| 5. 1st main gear | 17. 1st & 2nd coupling sleeve | 29. C ring holder |
| 6. Bushing | 18. Bushing | 30. Snap ring |
| 7. Needle bearing | 19. Needle bearing | 31. Snap ring |
| 8. 1st inner baulk ring | 20. 2nd main gear | 32. Mainshaft rear bearing adjusting shim |
| 9. 1st gear synchronizer cone | 21. 3rd main gear | 33. 5th & 6th mainshaft spacer |
| 10. 1st outer baulk ring | 22. 3rd & 4th mainshaft spacer | 34. 6th main adjusting shim |
| 11. Spread spring | 23. 4th main adjusting shim | |
| 12. 1st & 2nd shifting insert | 24. 4th main gear | |

Shift Control Components

NFMT0009S04

SEC. 328




SCIA0958E

- | | | |
|---------------------------|--------------------------|------------------------------|
| 1. Reverse shift fork | 10. 3rd & 4th shift fork | 19. Check spring |
| 2. Shifter cap | 11. 3rd & 4th fork rod | 20. Check plug |
| 3. Reverse fork rod | 12. 1st & 2nd shift fork | 21. Control assembly |
| 4. Reverse lever assembly | 13. 1st & 2nd bracket | 22. O ring |
| 5. 5th & 6th bracket | 14. 1st & 2nd fork rod | 23. Shift check |
| 6. 5th & 6th fork rod | 15. Shift check sleeve | 24. Stopper bolt |
| 7. 5th & 6th shift fork | 16. Inter lock pin | 25. Stopper ring |
| 8. Retaining pin | 17. Check ball | 26. Reverse bracket fork rod |
| 9. 3rd & 4th bracket | 18. Shift check sleeve | 27. Reverse bracket |

Final Drive Components

NFM70009S05

SEC. 381



SCIA0998E

- | | | |
|---|---|-----------------------------|
| 1. Differential side bearing outer race | 6. Differential side bearing | 10. Side gear |
| 2. Differential side bearing | 7. Differential side bearing outer race | 11. Side gear thrust washer |
| 3. Speedometer drive gear | 8. Differential side bearing adjusting shim | 12. Pinion mate gear |
| 4. Differential case | 9. Pinion mate shaft | 13. Pinion mate gear washer |
| 5. Final gear | | 14. Retaining pin |

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX


DISASSEMBLY



1. Remove drain plug and filler plug.
2. Remove park/neutral position switch and back-up lamp switch.
3. After removing shift check and stopper bolt, remove control assembly.



4. Remove check plugs (4 pieces), check springs (4 pieces), check balls (4 pieces) and shift check sleeve (2 pieces).




5. Remove transaxle case fixing bolts.

6. Remove bore plug.


CAUTION:

Be careful not to damage transaxle case.

7. While spreading the snap ring of mainshaft rear bearing located at bore plug hole, remove transaxle case.
8. Remove oil gutter, baffle plate.
9. Remove snap ring, mainshaft rear bearing adjusting shim and input shaft rear bearing adjusting shim from transaxle case.




10. Remove differential side bearing outer race (transaxle case side) and then adjusting shim.




11. Remove welch plug.

DISASSEMBLY



12. Remove differential oil seal (transaxle case side).
13. Remove magnet from clutch housing.




14. With shift lever in 5th position, remove bracket bolts from reverse lever assembly. Lift reverse lever assembly to remove.


CAUTION:

Be careful not to lose shifter cap.


15. Pull out reverse fork rod then remove reverse shift fork.



16. Remove retaining pin of reverse bracket.
17. Pull out reverse bracket and reverse bracket fork rod.
18. Remove check ball (2 pieces) and inter lock pin.



19. Shift 3rd & 4th fork rod to 3rd position. Remove retaining pin of 5th & 6th shift fork using pin punch.



20. Remove stopper rings for 5th & 6th bracket.
21. Pull out 5th & 6th fork rod and remove 5th & 6th shift fork and 5th & 6th bracket.
22. Remove check balls (2 pieces) and inter lock pin.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX


DISASSEMBLY



23. Remove retaining pin of 3rd & 4th bracket using pin punch.
24. Remove stopper rings for 3rd & 4th shift fork.
25. Pull out 3rd & 4th fork rod and remove 3rd & 4th shift fork and bracket.
26. Remove shift check sleeve from clutch housing.




27. Remove retaining pin of 1st & 2nd shift fork using pin punch.
28. Pull out 1st & 2nd fork rod with bracket.
29. Remove 1st & 2nd shift fork.
30. Remove retaining pin of 1st & 2nd bracket using pin punch and separate fork rod and bracket.




31. Remove gear components from clutch housing in the following procedure.
 - a. While tapping input shaft with plastic hammer, remove input shaft assembly, mainshaft assembly and reverse idler gear assembly as a set.

CAUTION:
Always withdraw mainshaft straight out. Failure to do so can damage resin oil channel on clutch housing side.

- b. Remove final drive assembly.




32. Remove mainshaft bearing retainer and then mainshaft front bearing.
33. Remove oil channel on mainshaft side.
34. Remove differential oil seal (clutch housing side).



35. Remove differential side bearing outer race (clutch housing side).

DISASSEMBLY



36. Remove input shaft oil seal.

CAUTION:
Be careful not to damage clutch housing.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

REPAIR FOR COMPONENT PARTS

Input Shaft and Gears



Input Shaft and Gears

DISASSEMBLY

1. Before disassembling, measure end play for 3rd, 4th, 5th and 6th input gears.

End play standard value




3rd gear: 0.18 - 0.31 mm (0.0071 - 0.0122 in)

4th gear: 0.20 - 0.30 mm (0.0079 - 0.0118 in)


5th gear: 0.06 - 0.16 mm (0.0024 - 0.0063 in)

6th gear: 0.06 - 0.16 mm (0.0024 - 0.0063 in)


2. Remove oil channel.
3. Remove input shaft rear bearing.
4. Remove the snap ring.
5. Remove 6th input gear, 6th bushing and 6th needle bearing.
6. Remove 6th baulk ring, 5th-6th coupling sleeve and shifting insert.




7. Remove 5th input gear and 5th synchronizer hub assembly simultaneously.
8. Remove 5th needle bearing.



9. Remove 5th bushing, thrust washer, 4th input gear, 4th needle bearing, 4th bushing, 4th baulk ring, 3rd-4th synchronizer hub assembly, 3rd baulk ring and 3rd input gear simultaneously.
10. Remove 3rd needle bearing.



11. Remove input shaft front bearing.



INSPECTION


Input Shaft and Gears

NFMT0012

NFMT0012S01

Check items below. If necessary, replace them with new ones.

- Damage, peeling, dent, uneven wear, bending, etc. of shaft
- Excessive wear, damage, peeling, etc. of gears




Synchronizer


NFMT0012S02

Check items below. If necessary, replace them with new ones.

- Damage and excessive wear of contact surfaces of coupling sleeve, synchronizer hub, and shifting insert
- Coupling sleeve and synchronizer hub must move smoothly.



- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.



Baulk Ring Clearance

NFMT0012S0201

- Press baulk ring against cone, and measure clearance between baulk ring and cone. If measurement is below limit, replace it with a new one.

Clearance

Standard

3rd and 4th: 0.9 - 1.45 mm (0.0354 - 0.0571 in)

5th and 6th: 0.95 - 1.4 mm (0.0374 - 0.0551 in)

Limit value: 0.7 mm (0.0276 in)

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)




Bearing

Check items below. If necessary, replace them with new ones.

NFMT0012S03

- Damage and rough rotation of bearing




ASSEMBLY

NFMT0013


1. Install 3rd needle bearing.
2. Install 3rd input gear and 3rd baulk ring.
3. Install spread spring, shifting insert and 3rd-4th synchronizer hub onto 3rd-4th coupling sleeve.

CAUTION:


- Be careful with orientation of synchronizer hub.
- Do not reuse 3rd-4th synchronizer hub.



- Be careful with orientation of coupling sleeve.



- Be sure not to hook center projection of 2 spread springs on same shifting insert.




4. Install 3rd-4th synchronizer hub assembly.

CAUTION:


Align grooves of shifting insert and 3rd baulk ring.

REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)



5. Install 4th bushing.
6. Install 4th baulk ring.
7. Install 4th input gear and 4th needle bearing.



8. Select thrust washer so that dimension "C2" satisfies standard below. Then install it onto input shaft.


Standard for dimension C2:
154.7 - 154.8 mm (6.091 - 6.094 in)

Thrust Washer


Thickness	Part number	Thickness	Part number
3.84 mm (0.1512 in)	32347 8H500	4.02 mm (0.1583 in)	32347 8H503
3.90 mm (0.1535 in)	32347 8H501	4.08 mm (0.1606 in)	32347 8H504
3.96 mm (0.1559 in)	32347 8H502	4.14 mm (0.1630 in)	32347 8H505

CAUTION:

Only one thrust washer can be selected.



9. Install 5th bushing.
10. Install 5th needle bearing and 5th input gear.
11. Install 5th baulk ring.



12. Install 5th-6th synchronizer hub, spread spring and shifting insert onto 5th-6th coupling sleeve.

CAUTION:

- Be careful with orientation of synchronizer hub.
- Do not reuse 5th-6th synchronizer hub.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)




- Be sure not to hook center projection of 2 spread springs on same shifting insert.




13. Install 5th-6th synchronizer hub assembly.

CAUTION:
Align grooves of 5th-6th shifting insert and 5th-6th baulk ring.



14. Install 6th needle bearing, 6th input gear onto 6th bushing, and then install them onto input shaft.




15. Install snap ring onto input shaft, and check that end play (gap between snap ring and groove) of 6th bushing satisfies standard.

End play standard value: 0 - 0.1 mm (0 - 0.004 in)

- If measurement is outside the standard range, select snap ring.

Snap Rings


Thickness	Part number	Thickness	Part number
1.76 mm (0.0693 in)	32204 8H511	2.01 mm (0.0791 in)	32204 8H516
1.81 mm (0.0713 in)	32204 8H512	2.06 mm (0.0811 in)	32204 8H517
1.86 mm (0.0732 in)	32204 8H513	2.11 mm (0.0831 in)	32204 8H518
1.91 mm (0.0752 in)	32204 8H514	2.16 mm (0.0850 in)	32204 8H519
1.96 mm (0.0772 in)	32204 8H515	2.21 mm (0.0870 in)	32204 8H520



16. Install input shaft rear bearing.


CAUTION:

Install input shaft rear bearing with its brown surface facing the 6th input gear side.



17. Install input shaft front bearing.

18. Install oil channel onto input shaft.



19. Check end play of 3rd, 4th, 5th and 6th input gears.


End play standard value

3rd gear: 0.18 - 0.31 mm (0.0071 - 0.0122 in)

4th gear: 0.20 - 0.30 mm (0.0079 - 0.0118 in)

5th gear: 0.06 - 0.16 mm (0.0024 - 0.0063 in)

6th gear: 0.06 - 0.16 mm (0.0024 - 0.0063 in)



Mainshaft and Gears

DISASSEMBLY


NFMT0014

1. Before disassembling, measure end play of 1st and 2nd main gears.

End play standard value

1st gear: 0.20 - 0.30 mm (0.0079 - 0.0118 in)

2nd gear: 0.06 - 0.16 mm (0.0024 - 0.0063 in)




2. Remove the snap ring.


3. Remove C-ring holder, and then mainshaft C-ring.

REPAIR FOR COMPONENT PARTS


Mainshaft and Gears (Cont'd)




4. Remove mainshaft rear bearing, adjust shim and 6th main gear.
5. Remove 5th-6th mainshaft spacer.



6. Remove 4th main gear and 5th main gear simultaneously.
7. Remove adjusting shim.
8. Remove 3rd & 4th mainshaft spacer.



9. Remove 3rd main gear, 2nd main gear, 2nd gear needle bearing, 2nd bushing, 1st-2nd synchronizer assembly, 1st main gear, reverse main gear, 1st gear needle bearing, and 1st bushing simultaneously.



INSPECTION


Mainshaft and Gears

NFMT0015

NFMT0015S01

Check items below. If necessary, replace them with new ones.

- Damage, peeling, dent, uneven wear, bending, and other non-standard conditions of the shaft.
- Excessive wear, damage, peeling, and other non-standard conditions of the gears.



Synchronizer


NFMT0015S02

Check items below. If necessary, replace them with new ones.


- Damage and unusual wear on contact surfaces of coupling sleeve, synchronizer hub, and shifting insert.
- Coupling sleeve and synchronizer hub must move smoothly.

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)



- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.




Baulk Ring Clearance

NFMT0015S0201

- Double cone synchronizer (1st and 2nd)
Check clearance of outer baulk ring, synchronizer cone, and inner baulk ring of 1st and 2nd double cone synchronizers, following procedure below.

CAUTION:

Outer baulk ring, synchronizer cone, and inner baulk ring as a set control clearance A and B. If measurement exceeds service limit value, replace all of them as a set.




1. Using a dial gauge, measure clearance A at 2 or more points diagonally opposite, and calculate mean value.

Clearance A

Standard: 0.6 - 0.8 mm (0.024 - 0.031 in)

Limit value: 0.2 mm (0.008 in) or less




2. Using a feeler gauge, measure clearance B at 2 or more points diagonally opposite, and calculate mean value.

Clearance B

Standard: 0.6 - 1.1 mm (0.024 - 0.043 in)

Limit value: 0.2 mm (0.008 in) or less



Bearing

NFMT0015S03


Check items below. If necessary, replace them with new ones.

- Damage and rough rotation of bearing

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)



NFMT0016




ASSEMBLY

1. Install reverse main gear.

CAUTION:
Be careful with orientation of reverse main gear.




2. Install 1st bushing.
3. Install needle bearing, and then 1st main gear.



4. Install spread spring, shifting insert and 1st-2nd synchronizer hub onto 1st-2nd coupling sleeve.

CAUTION:


- Be careful with orientation of synchronizer hub.
- Do not reuse 1st-2nd synchronizer hub.




- Be careful with orientation of coupling sleeve.

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)




- Be sure not to hook center projection of 2 spread springs on same shifting insert.




5. Install 1st gear synchronizer assembly onto mainshaft, and synchronizer hub assembly onto mainshaft.

CAUTION:

- Outer baulk ring, synchronizer cone, and inner baulk ring on 2nd gear-side must have been removed.
- Be careful with orientation of coupling sleeve.



6. Install 2nd bushing.
7. Install outer baulk ring, synchronizer cone, and inner baulk ring on 2nd gear-side.
8. Install 2nd needle bearing and 2nd gear.



9. Install 3rd main gear.

CAUTION:


Be careful with orientation of 3rd main gear.

10. Install 3rd-4th mainshaft spacer.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)



11. Select suitable adjusting shim so that dimension "C1" satisfies standard value below, and install it onto mainshaft.

Standard for dimension C1:


173.85 - 173.95 mm (6.844 - 6.848 in)

Adjusting Shim

Thickness	Part number	Thickness	Part number
0.52 mm (0.0205 in)	32238 8H500	0.84 mm (0.0331 in)	32238 8H504
0.60 mm (0.0236 in)	32238 8H501	0.92 mm (0.0362 in)	32238 8H505
0.68 mm (0.0268 in)	32238 8H502	1.00 mm (0.0394 in)	32238 8H506
0.76 mm (0.0299 in)	32238 8H503	1.08 mm (0.0425 in)	32238 8H507

CAUTION:


Only one adjusting shim can be selected.



12. Install 4th main gear.

CAUTION:

Be careful with orientation of 4th main gear.




13. Install 5th main gear.

CAUTION:

Be careful with orientation of 5th main gear.


14. Install 5th-6th mainshaft spacer.



15. Install 6th main gear.

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)



16. Select 6th main adjusting shim and then install it onto mainshaft.
- Calculate thickness “S” of 6th main adjusting shim by procedure below so that end play dimension between 6th main gear and mainshaft rear bearing becomes the dimension shown below.

End play: 0 - 0.1 mm (0 - 0.004 in)

Dimension “S” = (S_1 - S_2) + End play

S: Thickness of adjusting shim

S_1 : Dimension from mainshaft standard face to mainshaft rear bearing press-fit end face

S_2 : Dimension from mainshaft standard face to 6th main gear end face


Adjusting Shim

Thickness	Part number	Thickness	Part number
0.88 mm (0.0346 in)	32237 8H560	1.20 mm (0.0472 in)	32237 8H564
0.96 mm (0.0378 in)	32237 8H561	1.28 mm (0.0504 in)	32237 8H565
1.04 mm (0.0409 in)	32237 8H562	1.36 mm (0.0535 in)	32237 8H566
1.12 mm (0.0441 in)	32237 8H563		

CAUTION:

Only one adjusting shim can be selected.


- Using height gauge, measure dimension “ S_1 ” and “ S_2 ”.
- Install selected 6th main adjusting shim to mainshaft.



17. Install mainshaft rear bearing.

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)




18. Install C-ring onto mainshaft, and check that end play of mainshaft rear bearing satisfies standard value.

End play standard value: 0 - 0.06 mm (0 - 0.0024 in)


- If measurement is outside the standard range, reselect C-ring.

C-ring

Thickness	Part number	Thickness	Part number
2.535 mm (0.0998 in)	32348 8H800	2.835 mm (0.1116 in)	32348 8H810
2.565 mm (0.1010 in)	32348 8H801	2.865 mm (0.1128 in)	32348 8H811
2.595 mm (0.1022 in)	32348 8H802	2.895 mm (0.1140 in)	32348 8H812
2.625 mm (0.1033 in)	32348 8H803	2.925 mm (0.1152 in)	32348 8H813
2.655 mm (0.1045 in)	32348 8H804	2.955 mm (0.1163 in)	32348 8H814
2.685 mm (0.1057 in)	32348 8H805	2.985 mm (0.1175 in)	32348 8H815
2.715 mm (0.1069 in)	32348 8H806	3.015 mm (0.1187 in)	32348 8H816
2.745 mm (0.1081 in)	32348 8H807	3.045 mm (0.1199 in)	32348 8H817
2.775 mm (0.1093 in)	32348 8H808	3.075 mm (0.1211 in)	32348 8H818
2.805 mm (0.1104 in)	32348 8H809		



19. Fit C-ring holder, and install snap ring.



20. Check end play of 1st and 2nd main gears.

End play standard value

1st gear: 0.20 - 0.30 mm (0.0079 - 0.0118 in)

2nd gear: 0.06 - 0.16 mm (0.0024 - 0.0063 in)

Reverse Idler Shaft and Gears

DISASSEMBLY

=NFMT0032

1. Remove reverse idler gear adjusting shim.
2. Remove reverse idler gear (rear), reverse coupling sleeve and insert spring simultaneously.
3. Remove reverse idler gear needle bearing.
4. Remove thrust needle bearing.
5. Remove reverse baulk ring.
6. Remove reverse idler gear (front).
7. Remove reverse idler gear needle bearing.
8. Remove thrust needle bearing.
9. Pull off locking pin from reverse idler shaft.

GI

MA

EM


LC

EC

FE

CL

MT



INSPECTION

Reverse Idler Shaft and Gears

NFMT0033

NFMT0033S01

Check items below. If necessary, replace them with new ones.


- Damage, peeling, dent, uneven wear, bending, and other non-standard conditions of the shaft.
- Excessive wear, damage, peeling, and other non-standard conditions of the gears.

AT

AX

SU

BR



Synchronizer

NFMT0033S02

Check items below. If necessary, replace them with new ones.


- Damage and unusual wear on contact surfaces of coupling sleeve, synchronizer hub, and insert spring.
- Coupling sleeve and synchronizer hub must move smoothly.

ST

RS

BT

HA



- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.


SC

EL

IDX

REPAIR FOR COMPONENT PARTS

Reverse Idler Shaft and Gears (Cont'd)



Baulk Ring Clearance

NFMT0033S0201

- Press baulk ring against cone, and measure clearance between baulk ring and cone. If measurement is below limit, replace it with a new one.

Clearance

Standard: 0.95 - 1.4 mm (0.0374 - 0.0551 in)

Limit value: 0.7 mm (0.0276 in)

Bearing

NFMT0033S03


Check items below. If necessary, replace them with new ones.

- Damage and rough rotation of bearing.

ASSEMBLY


NFMT0034

Paying attention to following work, assemble in reverse order of disassembly.



CAUTION:

- Be careful with orientation of insert spring.



Final Drive

PRE-INSPECTION

NFMT0035

- Check the clearance between side gear and differential case as follows.

- Clean final drive assembly sufficiently to prevent side gear thrust washer, differential case, side gear, and other parts from sticking by gear oil.
- Upright the differential case so that the side gear to be measured faces upward.

- Place final drive adapter and dial indicator onto side gear. Move side gear up and down, and measure the clearance.


Clearance between side gear and differential case:






0.1 - 0.2 mm (0.004 - 0.008 in)

CAUTION:

There should be no resistance and gears should rotate freely.

- If not within specification, adjust the clearance by changing thrust washer thickness.
- Turn differential case upside down, and measure the clearance between side gear and differential case on the other side in the same way.





DISASSEMBLY

1. Remove mounting bolts. Then, separate the final gear from differential case. NFMT0017
2. Remove speedometer drive gear.
3. Using a drift and puller, remove differential side bearing (clutch housing side).
4. Using a drift and puller, remove differential side bearing (transaxle case side).
5. Using a pin punch, pull out lock pin and pinion mate shaft.
6. Rotate pinion mate gears, and remove pinion mate gears, pinion mate thrust washers, side gears, and side gear thrust washers from differential case.

INSPECTION

Gear, Washer, Shaft and Case

- Check side gears, side gear thrust washers, pinion mate shaft, pinion mate gears, pinion mate thrust washers and differential case. If necessary, replace with a new one. NFMT0018

Bearings





- Check for bearing damage and rough rotation. If necessary, replace with a new one. NFMT0018S01

CAUTION:

When replacing tapered roller bearing, replace outer and inner races as a set. NFMT0018S03

REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)



ASSEMBLY

NFMT0019

1. Apply gear oil to sliding area of differential case, each gear, and thrust washer.
2. Install side gear thrust washers and side gears into differential case.
3. While rotating pinion mate thrust washers and pinion mate gears, aligning them diagonally, install them into differential case.
4. Insert pinion mate shaft into differential case.

CAUTION:

Be sure not to damage pinion mate thrust washers.

5. Measure end play of side gears following procedure below. Then select side gear thrust washer.
 - a. Upright the differential case so that its side gear to be measured face upward.
 - b. Place final drive adapter and dial indicator onto side gears.
 - c. Move side gears up and down to measure end play, and select thrust washer so that it satisfies standard.

End play standard value:

0.1 - 0.2 mm (0.004 - 0.008 in)

CAUTION:

- There should be no resistance and gears should rotate freely.
- Place differential case upside down. Be sure to measure end play for opposite side-gears likewise.

Thrust washer


Thickness	Part number
0.75 mm (0.0295 in)	38424 81X00
0.80 mm (0.0315 in)	38424 81X01
0.85 mm (0.0335 in)	38424 81X02
0.90 mm (0.0354 in)	38424 81X03
0.95 mm (0.0374 in)	38424 81X04

CAUTION:

Only one thrust washer can be selected.


REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)




- Using a pin punch (special service tool), drive a lock pin into the pinion mate shaft.


CAUTION:
Do not reuse the lock pin.




- Using a drift (special service tool), install differential side bearing (transaxle case side).



- Align and install speedometer drive gear onto differential case.



- Using a drift (special service tool), install differential side bearing (clutch housing side).



- Install final gear into differential case, and tighten final gear mounting bolts.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX

REPAIR FOR COMPONENT PARTS

Shift Control Components



Shift Control Components

INSPECTION

- Check contact surfaces and sliding area for wear, damage, bending, etc. If necessary, replace parts.

NFMT0020

Shift Fork

- Check if the width of shift fork hook (sliding area with coupling sleeve) is within allowable specification below.


NFMT0020S01

Item	One-side wear specification	Sliding width of new part
1st & 2nd	0.2 mm (0.008 in)	7.80 - 7.93 mm (0.3071 - 0.3122 in)
3rd & 4th	0.2 mm (0.008 in)	7.80 - 7.93 mm (0.3071 - 0.3122 in)
5th & 6th	0.2 mm (0.008 in)	6.10 - 6.23 mm (0.2402 - 0.2453 in)
Reverse	0.2 mm (0.008 in)	12.80 - 12.93 mm (0.5039 - 0.5091 in)

ADJUSTMENT

Input Shaft End Play

NFMT0022S01



Input Shaft End Play

- When adjusting input shaft end play, select adjusting shim for input shaft bearing. To select adjusting shim, measure clearance between transaxle case and input shaft rear bearing.
- Calculate dimension "O" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for input shaft rear bearing.

End play: 0 - 0.06 mm (0 - 0.0024 in)

Dimension "O" = (O₁ - O₂) + End play

O: Thickness of adjusting shim

O₁: Distance between transaxle case end face and mounting face of adjusting shim



O₂: Distance between clutch housing case end face and end face of input shaft rear bearing

Adjusting Shim

Shim thickness	Part number	Shim thickness	Part number	Shim thickness	Part number
0.40 mm (0.0157 in)	32225 8H500	0.88 mm (0.0346 in)	32225 8H512	1.36 mm (0.0535 in)	32225 8H524
0.44 mm (0.0173 in)	32225 8H501	0.92 mm (0.0362 in)	32225 8H513	1.40 mm (0.0551 in)	32225 8H560
0.48 mm (0.0189 in)	32225 8H502	0.96 mm (0.0378 in)	32225 8H514	1.44 mm (0.0567 in)	32225 8H561
0.52 mm (0.0205 in)	32225 8H503	1.00 mm (0.0394 in)	32225 8H515	1.48 mm (0.0583 in)	32225 8H562
0.56 mm (0.0220 in)	32225 8H504	1.04 mm (0.0409 in)	32225 8H516	1.52 mm (0.0598 in)	32225 8H563
0.60 mm (0.0236 in)	32225 8H505	1.08 mm (0.0425 in)	32225 8H517	1.56 mm (0.0614 in)	32225 8H564
0.64 mm (0.0252 in)	32225 8H506	1.12 mm (0.0441 in)	32225 8H518	1.60 mm (0.0630 in)	32225 8H565
0.68 mm (0.0268 in)	32225 8H507	1.16 mm (0.0457 in)	32225 8H519	1.64 mm (0.0646 in)	32225 8H566
0.72 mm (0.0283 in)	32225 8H508	1.20 mm (0.0472 in)	32225 8H520		
0.76 mm (0.0299 in)	32225 8H509	1.24 mm (0.0488 in)	32225 8H521		
0.80 mm (0.0315 in)	32225 8H510	1.28 mm (0.0504 in)	32225 8H522		
0.84 mm (0.0331 in)	32225 8H511	1.32 mm (0.0520 in)	32225 8H523		

CAUTION:


Only 1 adjusting shim can be selected.



- Using depth micrometer and straight edge, measure dimension "O₁" between transaxle case end face and mounting face of adjusting shim.
- Using depth micrometer and straight edge as shown in the figure, measure dimension "O₂" between clutch housing case end face and end face of input shaft rear bearing.
- Install selected input shaft rear bearing adjusting shim onto input shaft.

ADJUSTMENT

Mainshaft End Play



Mainshaft End Play

NFMT0022S02

- When adjusting mainshaft end play, select adjusting shim for mainshaft rear bearing. To select adjusting shim, measure clearance "M" between transaxle case and mainshaft rear bearing.
- Calculate dimension "P" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for mainshaft rear bearing.

End play: 0 - 0.06 mm (0 - 0.0024 in)

Dimension "P" = "M" + End play

P: Thickness of adjusting shim

M: Distance between mainshaft rear bearing and transaxle case


Adjusting Shim

Shim thickness	Part number
0.44 mm (0.0173 in)	32238 8H510
0.48 mm (0.0189 in)	32238 8H511
0.52 mm (0.0205 in)	32238 8H512
0.56 mm (0.0220 in)	32238 8H513
0.60 mm (0.0236 in)	32238 8H514
0.64 mm (0.0252 in)	32238 8H515
0.68 mm (0.0268 in)	32238 8H516
0.72 mm (0.0283 in)	32238 8H517
0.76 mm (0.0299 in)	32238 8H518
0.80 mm (0.0315 in)	32238 8H519
0.84 mm (0.0331 in)	32238 8H520
0.88 mm (0.0346 in)	32238 8H521
0.92 mm (0.0362 in)	32238 8H522
0.96 mm (0.0378 in)	32238 8H523
1.00 mm (0.0394 in)	32238 8H524
1.04 mm (0.0409 in)	32238 8H560
1.08 mm (0.0425 in)	32238 8H561

CAUTION:

Only 1 adjusting shim can be selected.


- Install mainshaft assembly to clutch housing.
- Install snap ring to transaxle case.
- Install transaxle case to clutch housing, and temporarily assemble them with fixing bolts. Install temporarily snap ring to mainshaft rear bearing.



- Install dial gauge to snap ring access hole, and expand snap ring. Lift mainshaft assembly through control assembly installation hole, and push it against transaxle case. This state shall be defined as base. Moving distance of mainshaft assembly, with snap ring fit on main bearing, becomes "M".

ADJUSTMENT

Differential Side Bearing Preload



Differential Side Bearing Preload

NFMT0022S03

- When adjusting differential side bearing preload, select adjusting shim for differential side bearing. To select adjusting shim, measure clearance "L" between transaxle case and differential side bearing outer race.
- Calculate dimension "L" (thickness of adjusting shim) using the following procedure to satisfy specification of preload for differential side bearing.

Preload: 0.15 - 0.21 mm (0.0059 - 0.0083 in)

Dimension "L" = (L₁ - L₂) + Preload

L: Thickness of adjusting shim

L₁: Distance between clutch housing case end face and mounting face of adjusting shim



L₂: Distance between differential side bearing and transaxle case

Adjusting Shim

Shim thickness	Part number
0.48 mm (0.0189 in)	31438 80X00
0.52 mm (0.0205 in)	31438 80X01
0.56 mm (0.0220 in)	31438 80X02
0.60 mm (0.0236 in)	31438 80X03
0.64 mm (0.0252 in)	31438 80X04
0.68 mm (0.0268 in)	31438 80X05
0.72 mm (0.0283 in)	31438 80X06
0.76 mm (0.0299 in)	31438 80X07
0.80 mm (0.0315 in)	31438 80X08
0.84 mm (0.0331 in)	31438 80X09
0.88 mm (0.0346 in)	31438 80X10
0.92 mm (0.0362 in)	31438 80X11

CAUTION:


Up to 2 adjusting shims can be selected.




- Using depth micrometer and straightedge, measure dimension "L₁" between clutch housing case end face and mounting face of adjusting shim.
- Install outer race onto differential side bearing on final gear side. Holding lightly the outer race horizontally by hand, rotate final gear five times or more (for smooth movement of bearing roller).
- Using depth micrometer and straightedge as shown in the figure, measure dimension "L₂" between differential side bearing outer race and transaxle case end face.

ADJUSTMENT

Differential Side Bearing Preload (Cont'd)



4. Install selected adjusting shim and then differential side bearing outer race.



Reverse Idler Gear End Play

NFMT0022S04

- When adjusting reverse idler gear end play, select adjusting shim for reverse idler gear. To select adjusting shim, measure clearance between transaxle case and reverse idler gear.
- Calculate dimension "Q" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for reverse idler gear.

End play: 0.04 - 0.14 mm (0.0016 - 0.0055 in)

Dimension "Q" = $(Q_1 - Q_2) + \text{End play}$

Q: Thickness of adjusting shim

Q_1 : Distance between transaxle case end face and mounting face of adjusting shim


Q_2 : Distance between clutch housing case end face and end face of reverse idler gear

Adjusting Shim

Shim thickness	Part number
1.76 mm (0.0693 in)	32237 8H500
1.84 mm (0.0724 in)	32237 8H501
1.92 mm (0.0756 in)	32237 8H502
2.00 mm (0.0787 in)	32237 8H503
2.08 mm (0.0819 in)	32237 8H504
2.16 mm (0.0850 in)	32237 8H505
2.24 mm (0.0882 in)	32237 8H506
2.32 mm (0.0913 in)	32237 8H507
2.40 mm (0.0945 in)	32237 8H508
2.48 mm (0.0976 in)	32237 8H509
2.56 mm (0.1008 in)	32237 8H510
2.64 mm (0.1039 in)	32237 8H511

CAUTION:


Only 1 adjusting shim can be selected.



1. Using depth micrometer and straightedge, measure dimension " Q_1 " between transaxle case end face and mounting face of adjusting shim.

ADJUSTMENT

Reverse Idler Gear End Play (Cont'd)



2. Using depth micrometer and straightedge as shown in the figure, measure dimension "Q₂" between clutch housing case end face and end face of reverse idler gear.
3. Install selected reverse idler gear adjusting shim onto reverse idler gear assembly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC

EL


IDX

ASSEMBLY




1. Using a drift, install input shaft oil seal from clutch housing end of side to the depth of 1.8 to 2.8 mm (0.071 to 0.110 in).

CAUTION:
Do not reuse oil seal.




2. Using a drift, install differential oil seal until the face is flush with clutch housing.

CAUTION:
Do not reuse oil seal.




3. Install oil channel on mainshaft side.

CAUTION:
Be careful with orientation of installation.



4. Using a drift, install mainshaft front bearing.


CAUTION:
Be careful with orientation of installation.




5. Install bearing retainer.

CAUTION:
Install with punched surface facing up.


ASSEMBLY



6. Install differential side bearing outer race.




7. Install final drive assembly into clutch housing.




8. Install input shaft assembly, mainshaft assembly, and reverse idler gear assembly into clutch housing.

CAUTION:
Be sure not to damage input shaft oil seal.



9. Install 1st-2nd fork rod bracket onto 1st-2nd fork rod, and then install retaining pin.

CAUTION:
Do not reuse retaining pin.



10. Install 1st-2nd fork rod and 1st-2nd shift fork, and then install retaining pin.

CAUTION:
Do not reuse retaining pin.

11. Install shift check sleeve.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

ASSEMBLY



12. Install 3rd-4th bracket, 3rd-4th shift fork, and 3rd-4th fork rod with inter lock pin.

13. Install stopper ring onto 3rd-4th shift fork.

CAUTION:


Do not reuse stopper ring.

14. Install retaining pin onto 3rd-4th bracket.

CAUTION:

Do not reuse retaining pin.

15. Install 2 check balls.




16. Install 5th-6th bracket, 5th-6th shift fork, and 5th-6th fork rod with inter lock pin.

17. Install stopper ring onto 5th-6th bracket.

CAUTION:

Do not reuse stopper ring.




18. Install retaining pin onto 5th-6th shift fork.

CAUTION:

Do not reuse retaining pin.

19. Install 2 check balls.

20. Install reverse bracket fork rod and reverse lever bracket.



21. Install retaining pin onto reverse bracket.

CAUTION:

Do not reuse retaining pin.


22. Install reverse shift fork and reverse fork rod.

23. Install reverse lever assembly following procedures below.

a. Install shifter cap onto reverse lever assembly cam, and then install them onto reverse shift fork.


CAUTION:

Do not drop shifter cap.



b. While lifting reverse shift fork, align cam with reverse bracket.

ASSEMBLY




- c. Tighten mounting bolts to specified torque, and then install reverse lever assembly.
24. Install the magnet onto clutch housing.

GI

MA

EM

LC



25. Using a drift, install differential oil seal until it is flush with end face of transaxle case.

EC

CAUTION:

Do not reuse oil seal.

26. Install selected input shaft adjusting shim onto input shaft.
 - For selection of adjusting shims. Refer to MT-43, "Input Shaft End Play".

FE

CL

27. Install baffle plate and oil gutter.

28. Install transaxle case following procedures below.

- a. Install selected mainshaft rear bearing adjusting shim into transaxle case.

MT

- For selection of adjusting shims. Refer to MT-44, "Mainshaft End Play".

AT

- b. Temporarily install snap ring of mainshaft rear bearing into transaxle case.


AX

CAUTION:

Do not reuse the snap ring.

SU

BR



- c. Apply Anaerobic Liquid Gasket (Refer to GI-52, "Recommended Chemical Products and Sealants".) or equivalent to mating surfaces of transaxle case and clutch housing.

ST


CAUTION:

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.

RS

BT

HA




- d. With snap ring of mainshaft rear bearing temporarily installed, place transaxle case over clutch housing.

SC


EL

IDX

ASSEMBLY




- e. Through bore plug mounting hole, with snap ring stretched, and lift up mainshaft assembly from the control assembly mounting hole.
- f. Securely install snap ring onto mainshaft rear bearing.



- g. Tighten mounting bolts.

Bolt A:

 : 50.0 - 53.9 N·m (5.1 - 5.4 kg-m, 37 - 39 ft-lb)

Bolt B:


 : 63.0 - 66.9 N·m (6.5 - 6.8 kg-m, 47 - 49 ft-lb)

- CAUTION:**
Always replace bolts B as they are self-sealing bolts.
- h. Install control assembly.

CAUTION:
Do not reuse the O-ring.

- i. Install shift check and stopper bolt.


CAUTION:
Do not reuse shift check and stopper bolt.



29. Using a drift, install bore plug.


CAUTION:
Do not reuse bore plug.

ASSEMBLY




30. Using a drift, install weld plug.

CAUTION:
Do not reuse weld plug.



31. Install 2 shift check sleeves, 4 check balls, 4 check springs, and 4 check ball plugs.

CAUTION:
Do not reuse check ball plug.



32. Apply Anaerobic Liquid Gasket (Refer to GI-52, "Recommended Chemical Products and Sealants".) or equivalent to threads of neutral switch and reverse lamp switch. Then install them into transaxle case.

33. Install gaskets onto drain plug and filler plug, and then install them into transaxle case.

CAUTION:

- Do not reuse gasket.
- After oil is filled, tighten filler plug to specified torque.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

General Specifications

NFMT0024

TRANSAXLE

NFMT0024S01

Engine			VQ35DE		
Transaxle model			RS6F51A		
Model code number			5Y764		
Number of speed			6		
Synchromesh type			Warner		
Shift pattern			<div><div><div>1</div><div>3</div><div>5</div></div><div><div>2</div><div>4</div><div>6</div></div><div>N</div><div>R</div></div> <div>SCIA0955E</div>		
Gear ratio	1st		3.153		
	2nd		1.944		
	3rd		1.392		
	4th		1.055		
	5th		0.809		
	6th		0.630		
	Reverse		3.002		
Number of teeth	Input gear	1st	13		
		2nd	18		
		3rd	28		
		4th	36		
		5th	42		
		6th	46		
		Reverse	13		
	Main gear	1st	41		
		2nd	35		
		3rd	39		
		4th	38		
		5th	34		
		6th	29		
		Reverse	38		
	Reverse idler gear	Front	37		
		Rear	38		
Oil capacity liter (US pt, Imp pt)			2.3 (4-7/8, 4)		
Remarks	Reverse synchronizer		Installed		
	Double baulk ring type synchronizer		1st & 2nd synchronizer		

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications (Cont'd)

FINAL GEAR

=NFMT0024S02

Engine		VQ35DE
Transaxle model		RS6F51A
Model code number		5Y764
Final gear ratio		3.812
Number of teeth	Final gear/Pinion	61/16
	Side gear/Pinion mate gear	14/10

Gear End Play

NFMT0025
Unit: mm (in)

Gear	End play
1st main gear	0.20 - 0.30 (0.0079 - 0.0118)
2nd main gear	0.06 - 0.16 (0.0024 - 0.0063)
3rd input gear	0.18 - 0.31 (0.0071 - 0.0122)
4th input gear	0.20 - 0.30 (0.0079 - 0.0118)
5th input gear	0.06 - 0.16 (0.0024 - 0.0063)
6th input gear	0.06 - 0.16 (0.0024 - 0.0063)

Clearance Between Baulk Ring and Gear

NFMT0026


3RD, 4TH, 5TH, 6TH & REVERSE BAULK RING

NFMT0026S01
Unit: mm (in)

Standard		Wear limit
3rd	0.9 - 1.45 (0.0354 - 0.0571)	0.7 (0.0276)
4th	0.9 - 1.45 (0.0354 - 0.0571)	0.7 (0.0276)
5th	0.95 - 1.4 (0.0374 - 0.0551)	0.7 (0.0276)
6th	0.95 - 1.4 (0.0374 - 0.0551)	0.7 (0.0276)
Reverse	0.95 - 1.4 (0.0374 - 0.0551)	0.7 (0.0276)

1ST AND 2ND DOUBLE BAULK RING

NFMT0026S02
Unit: mm (in)



SMT138E

Dimension	Standard	Wear limit
A	0.6 - 0.8 (0.024 - 0.031)	0.2 (0.008)
B	0.6 - 1.1 (0.024 - 0.043)	0.2 (0.008)

SERVICE DATA AND SPECIFICATIONS (SDS)

Available Snap Rings

Available Snap Rings

NFMT0027

6TH BUSHING

NFMT0027S01

End play		0 - 0.1 mm (0 - 0.004 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
1.76 (0.0693)	32204 8H511	2.01 (0.0791)	32204 8H516
1.81 (0.0713)	32204 8H512	2.06 (0.0811)	32204 8H517
1.86 (0.0732)	32204 8H513	2.11 (0.0831)	32204 8H518
1.91 (0.0752)	32204 8H514	2.16 (0.0850)	32204 8H519
1.96 (0.0772)	32204 8H515	2.21 (0.0870)	32204 8H520

*: Always check with the Parts Department for the latest parts information.

Available C-rings MAINSHAFT C-RING

NFMT0036

NFMT0036S01


End play		0 - 0.06 mm (0 - 0.0024 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
2.535 (0.0998)	32348 8H800	2.835 (0.1116)	32348 8H810
2.565 (0.1010)	32348 8H801	2.865 (0.1128)	32348 8H811
2.595 (0.1022)	32348 8H802	2.895 (0.1140)	32348 8H812
2.625 (0.1033)	32348 8H803	2.925 (0.1152)	32348 8H813
2.655 (0.1045)	32348 8H804	2.955 (0.1163)	32348 8H814
2.685 (0.1057)	32348 8H805	2.985 (0.1175)	32348 8H815
2.715 (0.1069)	32348 8H806	3.015 (0.1187)	32348 8H816
2.745 (0.1081)	32348 8H807	3.045 (0.1199)	32348 8H817
2.775 (0.1093)	32348 8H808	3.075 (0.1211)	32348 8H818
2.805 (0.1104)	32348 8H809		

*: Always check with the Parts Department for the latest parts information.

Available Thrust Washer INPUT SHAFT THRUST WASHER

NFMT0037

NFMT0037S01



SCIA1008E

Standard length "C2"		154.7 - 154.8 mm (6.091 - 6.094 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
3.84 (0.1512)	32347 8H500	4.02 (0.1583)	32347 8H503
3.90 (0.1535)	32347 8H501	4.08 (0.1606)	32347 8H504
3.96 (0.1559)	32347 8H502	4.14 (0.1630)	32347 8H505

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Available Thrust Washer (Cont'd)

DIFFERENTIAL SIDE GEAR THRUST WASHER

NFMT0037S02


Allowable clearance between side gear and differential case with washer	0.1 - 0.2 mm (0.004 - 0.008 in)
Thickness mm (in)	Part number*
0.75 (0.0295)	38424 81X00
0.80 (0.0315)	38424 81X01
0.85 (0.0335)	38424 81X02
0.90 (0.0354)	38424 81X03
0.95 (0.0374)	38424 81X04

*: Always check with the Parts Department for the latest parts information.

Available Adjusting Shims MAINSHAFT ADJUSTING SHIM

NFMT0038

NFMT0038S01



SCIA1009E

Standard length "C1"		173.85 - 173.95 mm (6.844 - 6.848 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.52 (0.0205)	32238 8H500	0.84 (0.0331)	32238 8H504
0.60 (0.0236)	32238 8H501	0.92 (0.0362)	32238 8H505
0.68 (0.0268)	32238 8H502	1.00 (0.0394)	32238 8H506
0.76 (0.0299)	32238 8H503	1.08 (0.0425)	32238 8H507

*: Always check with the Parts Department for the latest parts information.

INPUT SHAFT REAR BEARING ADJUSTING SHIM

NFMT0038S02

End play			0 - 0.06 mm (0 - 0.0024 in)		
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.40 (0.0157)	32225 8H500	0.88 (0.0346)	32225 8H512	1.36 (0.0535)	32225 8H524
0.44 (0.0173)	32225 8H501	0.92 (0.0362)	32225 8H513	1.40 (0.0551)	32225 8H560
0.48 (0.0189)	32225 8H502	0.96 (0.0378)	32225 8H514	1.44 (0.0567)	32225 8H561
0.52 (0.0205)	32225 8H503	1.00 (0.0394)	32225 8H515	1.48 (0.0583)	32225 8H562
0.56 (0.0220)	32225 8H504	1.04 (0.0409)	32225 8H516	1.52 (0.0598)	32225 8H563
0.60 (0.0236)	32225 8H505	1.08 (0.0425)	32225 8H517	1.56 (0.0614)	32225 8H564
0.64 (0.0252)	32225 8H506	1.12 (0.0441)	32225 8H518	1.60 (0.0630)	32225 8H565
0.68 (0.0268)	32225 8H507	1.16 (0.0457)	32225 8H519	1.64 (0.0646)	32225 8H566
0.72 (0.0283)	32225 8H508	1.20 (0.0472)	32225 8H520		
0.76 (0.0299)	32225 8H509	1.24 (0.0488)	32225 8H521		
0.80 (0.0315)	32225 8H510	1.28 (0.0504)	32225 8H522		
0.84 (0.0331)	32225 8H511	1.32 (0.0520)	32225 8H523		

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Available Adjusting Shims (Cont'd)

MAINSHAFT REAR BEARING ADJUSTING SHIM

NFMT0038S03

End play		0 - 0.06 mm (0 - 0.0024 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.44 (0.0173)	32238 8H510	0.80 (0.0315)	32238 8H519
0.48 (0.0189)	32238 8H511	0.84 (0.0331)	32238 8H520
0.52 (0.0205)	32238 8H512	0.88 (0.0346)	32238 8H521
0.56 (0.0220)	32238 8H513	0.92 (0.0362)	32238 8H522
0.60 (0.0236)	32238 8H514	0.96 (0.0378)	32238 8H523
0.64 (0.0252)	32238 8H515	1.00 (0.0394)	32238 8H524
0.68 (0.0268)	32238 8H516	1.04 (0.0409)	32238 8H560
0.72 (0.0283)	32238 8H517	1.08 (0.0425)	32238 8H561
0.76 (0.0299)	32238 8H518		

*: Always check with the Parts Department for the latest parts information.

REVERSE IDLER GEAR ADJUSTING SHIM

NFMT0038S04

End play		0.04 - 0.10 mm (0.0016 - 0.0039 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
1.76 (0.0693)	32237 8H800	2.24 (0.0882)	32237 8H811
1.80 (0.0709)	32237 8H801	2.28 (0.0898)	32237 8H812
1.84 (0.0724)	32237 8H802	2.32 (0.0913)	32237 8H813
1.88 (0.0740)	32237 8H803	2.36 (0.0929)	32237 8H814
1.92 (0.0756)	32237 8H804	2.40 (0.0945)	32237 8H815
1.96 (0.0772)	32237 8H805	2.44 (0.0961)	32237 8H816
2.00 (0.0787)	32237 8H806	2.48 (0.0976)	32237 8H817
2.04 (0.0803)	32237 8H807	2.52 (0.0992)	32237 8H818
2.08 (0.0819)	32237 8H808	2.56 (0.1008)	32237 8H819
2.12 (0.0835)	32237 8H809	2.60 (0.1024)	32237 8H820
2.16 (0.0850)	32237 8H810	2.64 (0.1039)	32237 8H821
2.20 (0.0866)	32237 8H811		

*: Always check with the Parts Department for the latest parts information.

6TH MAIN GEAR ADJUSTING SHIM

NFMT0038S05

End play		0 - 0.1 mm (0 - 0.004 in)	
Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.88 (0.0346)	32237 8H560	1.20 (0.0472)	32237 8H564
0.96 (0.0378)	32237 8H561	1.28 (0.0504)	32237 8H565
1.04 (0.0409)	32237 8H562	1.36 (0.0535)	32237 8H566
1.12 (0.0441)	32237 8H563		

*: Always check with the Parts Department for the latest parts information.

Available Shims — Differential Side Bearing Preload and Adjusting Shim BEARING PRELOAD

NFMT0039

NFMT0039S01

Differential side bearing preload: L*	0.15 - 0.21 mm (0.0059 - 0.0083 in)
---------------------------------------	-------------------------------------

*: Install shims which are "deflection of differential case" + "L" in thickness.

SERVICE DATA AND SPECIFICATIONS (SDS)

Available Shims — Differential Side Bearing Preload and Adjusting Shim (Cont'd)

DIFFERENTIAL SIDE BEARING ADJUSTING SHIM(S)

NFMT0039S02

Thickness mm (in)	Part number*	Thickness mm (in)	Part number*
0.48 (0.0189)	31438 80X00	0.72 (0.0283)	31438 80X06
0.52 (0.0205)	31438 80X01	0.76 (0.0299)	31438 80X07
0.56 (0.0220)	31438 80X02	0.80 (0.0315)	31438 80X08
0.60 (0.0236)	31438 80X03	0.84 (0.0331)	31438 80X09
0.64 (0.0252)	31438 80X04	0.88 (0.0346)	31438 80X10
0.68 (0.0268)	31438 80X05	0.92 (0.0362)	31438 80X11

*: Always check with the Parts Department for the latest parts information.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

NOTES