

# ELECTRICAL SYSTEM

## SECTION **EL**

### CONTENTS

<b>PRECAUTIONS</b> .....	4	Trouble Diagnoses .....	55	MT
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	4	Bulb Replacement .....	60	
Wiring Diagrams and Trouble Diagnosis .....	4	Aiming Adjustment .....	60	
<b>HARNES CONNECTOR</b> .....	5	<b>PARKING, LICENSE AND TAIL LAMPS</b> .....	61	AT
Description .....	5	System Description .....	61	
<b>STANDARDIZED RELAY</b> .....	7	Schematic .....	63	
Description .....	7	Wiring Diagram - TAIL/L - .....	64	TF
<b>POWER SUPPLY ROUTING</b> .....	9	CONSULT-II Inspection Procedure .....	68	
Schematic .....	9	CONSULT-II Application Items .....	69	PD
Wiring Diagram - POWER - .....	10	Trouble Diagnoses .....	69	
Inspection .....	16	<b>STOP LAMP</b> .....	71	AX
<b>GROUND</b> .....	17	Wiring Diagram - STOP/L - .....	71	
Ground Distribution .....	17	<b>BACK-UP LAMP</b> .....	73	
<b>COMBINATION SWITCH</b> .....	28	Wiring Diagram - BACK/L - .....	73	SU
Check .....	28	<b>FRONT FOG LAMP</b> .....	74	
Replacement .....	29	System Description .....	74	
<b>STEERING SWITCH</b> .....	30	Wiring Diagram - F/FOG - .....	75	BR
Check .....	30	Aiming Adjustment .....	77	
<b>HEADLAMP (FOR USA)</b> .....	31	<b>TURN SIGNAL AND HAZARD WARNING LAMPS</b> .....	78	ST
Component Parts and Harness Connector		System Description .....	78	
Location .....	31	Wiring Diagram - TURN - .....	80	
System Description .....	31	Trouble Diagnoses .....	82	RS
Schematic .....	34	Electrical Components Inspection .....	82	
Wiring Diagram - H/LAMP - .....	35	<b>ILLUMINATION</b> .....	83	
CONSULT-II Inspection Procedure .....	39	System Description .....	83	BT
CONSULT-II Application Items .....	40	Schematic .....	85	
Trouble Diagnoses .....	40	Wiring Diagram - ILL - .....	86	
Bulb Replacement .....	43	<b>INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS</b> .....	92	HA
Aiming Adjustment .....	43	System Description .....	92	
<b>HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM</b> - .....	45	Schematic .....	94	SC
Component Parts and Harness Connector		Wiring Diagram - INT/L - .....	95	
Location .....	45	CONSULT-II Inspection Procedure .....	100	
System Description .....	45	CONSULT-II Application Items .....	101	
Schematic .....	49	Trouble Diagnoses for Interior Lamp Timer .....	103	
Wiring Diagram - DTRL - .....	50	<b>METERS AND GAUGES</b> .....	118	IDX
CONSULT-II Inspection Procedure .....	55	Component Parts and Harness Connector		
CONSULT-II Application Items .....	55	Location .....	118	
		System Description .....	118	

# CONTENTS (Cont'd)

Combination Meter .....	120	Trouble Diagnoses.....	180
Schematic .....	122	Electrical Components Inspection .....	183
Wiring Diagram - METER - .....	123	Filament Check.....	183
Meter/Gauge Operation and Odo/Trip Meter		Filament Repair .....	184
Segment Check in Diagnosis Mode.....	124	<b>AUDIO</b> .....	186
Trouble Diagnoses.....	125	System Description.....	186
Electrical Components Inspection .....	131	Wiring Diagram - AUDIO -/Base System .....	187
<b>COMPASS AND THERMOMETER</b> .....	132	Schematic/BOSE System.....	189
System Description.....	132	Wiring Diagram - AUDIO -/BOSE System.....	190
Wiring Diagram - COMPAS -.....	133	Trouble Diagnoses.....	195
Trouble Diagnoses.....	134	Inspection.....	196
Calibration Procedure for Compass .....	135	Audio Unit Removal and Installation .....	196
<b>WARNING LAMPS</b> .....	136	Wiring Diagram - REMOTE -.....	197
Schematic .....	136	<b>AUDIO ANTENNA</b> .....	198
Wiring Diagram - WARN - .....	137	System Description.....	198
Fuel Warning Lamp Sensor Check .....	145	Wiring Diagram - P/ANT - .....	199
Electrical Components Inspection .....	145	Trouble Diagnoses.....	200
<b>WARNING CHIME</b> .....	146	Location of Antenna.....	200
Component Parts and Harness Connector		Antenna Rod Replacement .....	200
Location .....	146	<b>POWER SUNROOF</b> .....	202
System Description.....	146	System Description.....	202
Wiring Diagram - CHIME - .....	148	Wiring Diagram - SROOF - .....	203
CONSULT-II Inspection Procedure.....	150	CONSULT-II Inspection Procedure.....	205
CONSULT-II Application Items .....	151	CONSULT-II Application Items .....	206
Trouble Diagnoses.....	152	Trouble Diagnoses.....	206
<b>FRONT WIPER AND WASHER</b> .....	160	<b>DOOR MIRROR</b> .....	208
System Description.....	160	Wiring Diagram - MIRROR - .....	208
Wiring Diagram - WIPER - .....	162	<b>POWER SEAT</b> .....	209
Removal and Installation .....	163	Wiring Diagram - SEAT - .....	209
Washer Nozzle Adjustment .....	164	<b>HEATED SEAT</b> .....	211
Washer Tube Layout .....	164	Wiring Diagram - HSEAT - .....	211
<b>REAR WIPER AND WASHER</b> .....	165	Seatback Heating Unit.....	212
System Description.....	165	<b>AUTOMATIC DRIVE POSITIONER</b> .....	213
Wiring Diagram - WIP/R - .....	167	Component Parts and Harness Connector	
Trouble Diagnoses.....	169	Location .....	213
Removal and Installation .....	169	System Description.....	214
Washer Nozzle Adjustment .....	170	Schematic .....	217
Washer Tube Layout .....	170	Wiring Diagram - AUT/DP - .....	218
Check Valve.....	170	On Board Diagnosis .....	223
<b>HORN</b> .....	171	Trouble Diagnoses.....	225
Wiring Diagram - HORN - .....	171	<b>AUTOMATIC SPEED CONTROL DEVICE (ASCD)</b> .....	248
<b>CIGARETTE LIGHTER</b> .....	172	Component Parts and Harness Connector	
Wiring Diagram - CIGAR - .....	172	Location .....	248
<b>CLOCK</b> .....	173	System Description.....	249
Wiring Diagram - CLOCK - .....	173	Schematic .....	251
<b>REAR WINDOW DEFOGGER</b> .....	174	Wiring Diagram - ASCD - .....	252
Component Parts and Harness Connector		Fail-safe System.....	256
Location .....	174	Trouble Diagnoses.....	257
System Description.....	174	Electrical Component Inspection.....	266
Wiring Diagram - DEF - .....	176	ASCD Wire Adjustment .....	267
CONSULT-II Inspection Procedure.....	178	<b>POWER WINDOW</b> .....	268
CONSULT-II Application Items .....	179	System Description.....	268

# CONTENTS (Cont'd)

Schematic .....	271	Component Parts and Harness Connector	
Wiring Diagram - WINDOW - .....	272	Location .....	385
CONSULT-II Inspection Procedure.....	277	System Description.....	386
CONSULT-II Application Items .....	278	System Composition.....	386
Trouble Diagnoses.....	278	Wiring Diagram - NATS - .....	387
<b>POWER DOOR LOCK</b> .....	287	CONSULT-II .....	388
Component Parts and Harness Connector		Trouble Diagnoses.....	391
Location .....	287	How to Replace NVIS (NATS) IMMU .....	404
System Description.....	287	<b>NAVIGATION SYSTEM</b> .....	405
Schematic .....	288	Component Parts Location.....	405
Wiring Diagram - D/LOCK - .....	289	System Description.....	406
CONSULT-II Inspection Procedure.....	295	Schematic .....	413
CONSULT-II Application Items .....	296	Wiring Diagram - NAVI - .....	414
Trouble Diagnoses.....	297	Self-diagnosis Mode .....	417
<b>REMOTE KEYLESS ENTRY SYSTEM</b> .....	310	Confirmation/Adjustment Mode .....	420
Component Parts and Harness Connector		Setting Mode.....	430
Location .....	310	Trouble diagnoses .....	438
System Description.....	310	This Condition is Not Abnormal.....	444
Schematic .....	314	Program Loading .....	453
Wiring Diagram - KEYLESS - .....	315	Initialization .....	454
CONSULT-II Inspection Procedure.....	319	<b>ELECTRICAL UNITS LOCATION</b> .....	457
CONSULT-II Application Items .....	320	Engine Compartment.....	457
Trouble Diagnoses.....	321	Passenger Compartment.....	458
ID Code Entry Procedure .....	334	<b>HARNES LAYOUT</b> .....	460
Keyfob Battery Replacement.....	338	How to Read Harness Layout .....	460
<b>VEHICLE SECURITY (THEFT WARNING)</b>		Outline.....	461
<b>SYSTEM</b> .....	339	Main Harness.....	462
Component Parts and Harness Connector		Engine Room Harness .....	464
Location .....	339	Engine Control Harness .....	466
System Description.....	340	Body Harness LH .....	468
Schematic .....	344	Body Harness RH.....	469
Wiring Diagram - VEHSEC - .....	346	Back Door Harness .....	470
CONSULT-II Inspection Procedure.....	352	Engine and Transmission Harness.....	471
CONSULT-II Application Item .....	353	Room Lamp Harness.....	472
Trouble Diagnoses.....	354	Air Bag Harness .....	473
<b>SMART ENTRANCE CONTROL UNIT</b> .....	372	Front Door Harness .....	474
Description .....	372	Rear Door Harness.....	475
CONSULT-II .....	374	<b>BULB SPECIFICATIONS</b> .....	476
Schematic .....	376	Headlamp.....	476
Smart Entrance Control Unit Inspection Table .....	378	Exterior Lamp .....	476
<b>HOMELINK UNIVERSAL TRANSCEIVER</b> .....	381	Interior Lamp.....	476
Wiring Diagram - TRNSCV - .....	381	<b>WIRING DIAGRAM CODES (CELL CODES)</b> .....	477
Trouble Diagnoses.....	382		
<b>NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM</b>			
<b>- NATS)</b> .....	385		

## PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

### Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NAEL0001

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN MODEL R50 is as follows:

- For a frontal collision  
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision  
The Supplemental Restraint System consists of side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

#### **WARNING:**

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow harness connector (and by yellow harness protector or yellow insulation tape before the harness connectors).**

### Wiring Diagrams and Trouble Diagnosis

NAEL0002

When you read wiring diagrams, refer to the following:

- GI-11, "HOW TO READ WIRING DIAGRAMS"
- EL-9, "POWER SUPPLY ROUTING" for power distribution circuit

When you perform trouble diagnosis, refer to the following:

- GI-35, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"
- GI-24, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT"

Check for any Service bulletins before servicing the vehicle.

# HARNESS CONNECTOR

Description

## Description

### HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

**CAUTION:**

Do not pull the harness when disconnecting the connector.

[Example]



SEL769D

GI

NAEL0003

MA

NAEL0003S01

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# HARNESS CONNECTOR

Description (Cont'd)

## HARNESS CONNECTOR (SLIDE-LOCKING TYPE)


=NAEL0003S02

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

### CAUTION:

- Do not pull the harness or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

[Example]



# STANDARDIZED RELAY

Description


## Description

### NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.

NAEL0004

NAEL0004S01




SEL881H

### TYPE OF STANDARDIZED RELAYS

NAEL0004S02

1M	1 Make	2M	2 Make
1T	1 Transfer	1M·1B	1 Make 1 Break



SEL882H

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

















SC

EL

IDX

# STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connector	Case color
1T				BLACK
				
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

GEL264







# POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

## EL-POWER-02



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX







REFER TO THE FOLLOWING.  
(E1) - SUPER MULTIPLE JUNCTION (SMJ)

MEL4020

# POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

## EL-POWER-03



MEL551P



# POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)


## ACCESSORY POWER SUPPLY — IGNITION SW. IN “ACC” OR “ON”

NAEL0248S02

### EL-POWER-04



REFER TO THE FOLLOWING.



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL4030



# POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

NAEL0248S03

## IGNITION POWER SUPPLY — IGNITION SW. IN "ON" AND/OR "START"

EL-POWER-05



REFER TO THE FOLLOWING.

(M10), (M91), (E2), (E3), (E4)

- FUSE BLOCK - JUNCTION BOX (J/B)



1	2	3	4	
6	7	8	9	10
11	12	13	14	
16	17	18	19	20
21	22			
24	25	26		
	28	29		

MEL4040


# POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

## EL-POWER-06




REFER TO THE FOLLOWING.



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# POWER SUPPLY ROUTING

## Inspection




## Inspection

NAEL0249

### FUSE

NAEL0249S01

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for “ELECTRICAL PARTS (BAT)” if vehicle is not used for a long period of time.




### FUSIBLE LINK

NAEL0249S02

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

#### CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



### CIRCUIT BREAKER (PTC THERMISTOR TYPE)

NAEL0249S03

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current.



Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.

## Ground Distribution


NAEL0250

NAEL0250S01

### MAIN HARNESS



CON-NECTOR NUMBER	CONNECT TO
M9	Data link connector (Terminal No. 4)
M10	Fuse block (J/B) • Accessory relay • Blower motor relay • Ignition relay
M19	Illumination control switch
D12	Front door speaker LH
M48	Shield wire (Audio unit)
D42	Front door speaker RH
M42	Recirculation switch (With heater and manual A/C)
M43	Fan switch (With heater and manual A/C)
M52	Heated seat switch LH
M53	Heated seat switch RH
M56	Cigarette lighter socket
M60	Fan control amp.
M78	Front wiper motor
M115	Headlamp battery saver control unit (Terminal No. 4)
M122	Smart entrance control unit (Terminal No. 43)
M123	Smart entrance control unit (Terminal No. 64)
D1	Door mirror LH (Door mirror defogger)
D6	Front power window main switch
D9	Front door key cylinder switch LH
D16	Seat memory switch




Body ground

MEL489P

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# GROUND

Ground Distribution (Cont'd)




\* : This sub-harness is not shown in "Harness Layout", EL section.

MEL490P

# GROUND

Ground Distribution (Cont'd)

**A** Preceding page



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC

EL

MEL4780


IDX

# GROUND

Ground Distribution (Cont'd)

NAEL0250S02



## ENGINE ROOM HARNESS



MEL4150

# GROUND

Ground Distribution (Cont'd)



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

MEL908N



IDX

# GROUND

Ground Distribution (Cont'd)

## ENGINE CONTROL HARNESS

NAEL0250S03




**B** Next page

MEL7040

# GROUND

Ground Distribution (Cont'd)



MEL233M

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**


IDX

# GROUND

Ground Distribution (Cont'd)

NAEL0250S04

## BODY HARNESS RH




MEL909N

## BODY HARNESS LH

NAEL0250S05

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC



\* : This sub-harness is not shown in "Harness Layout", EL section.

Next page

EL


MEL4160

IDX


# GROUND

Ground Distribution (Cont'd)


△ C △ D Preceding page



CON-NECTOR NUMBER	CONNECT TO
D103	Luggage room lamp
D302	High-mounted stop lamp



D201	Back door key cylinder switch
D202	License plate lamp (Without spare tire carrier)
D203	License plate lamp (With spare tire carrier)
D208	Back door switch
D209	Glass hatch switch
D212	Rear wiper motor




MEL911N

# GROUND

Ground Distribution (Cont'd)

## BODY HARNESS

NAEL0250S06



CON-NECTOR NUMBER	CONNECT TO
D304	Rear window defogger

MEL152M

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**



IDX

# COMBINATION SWITCH

Check

## Check

NAEL0251



LIGHTING SWITCH

	OFF	AUTO	1ST	2ND
5			<input type="radio"/>	<input type="radio"/>
11			<input type="radio"/>	<input type="radio"/>
8				<input type="radio"/>
12				<input type="radio"/>
42		<input type="radio"/>		
(8)		<input type="radio"/>		

	A	B	C
(5)	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
7	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
6	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
(8)	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
10	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
9	<input type="radio"/>		<input type="radio"/>
(12)			<input type="radio"/>

FRONT WIPER AND WASHER SWITCH

	LO	AUTO STOP	AMP	WASH	HI	EARTH
OFF	<input type="radio"/>	<input type="radio"/>				
INT	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			
LO	<input type="radio"/>					
HI					<input type="radio"/>	
WASH				<input type="radio"/>		

VARIABLE INTERMITTENT WIPER VOLUME



FOG LAMP SWITCH




	OFF	ON
31	<input type="radio"/>	
32		<input type="radio"/>

TURN SIGNAL LAMP SWITCH

	L	N	R
1	<input type="radio"/>		<input type="radio"/>
2			<input type="radio"/>
3	<input type="radio"/>		

REAR WIPER SWITCH

	WASH	OFF	INT	ON	WASH
21			<input type="radio"/>		
22			<input type="radio"/>	<input type="radio"/>	
23	<input type="radio"/>				
24	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	



## Replacement

For removal and installation of spiral cable, refer to RS-18, "Installation — Air Bag Module and Spiral Cable".

- Each switch can be replaced without removing combination switch base.
- To remove combination switch base, remove base attaching screw.
- Before installing the steering wheel, align the steering wheel guide pins with the screws which secure the combination switch as shown in the left figure.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**



IDX

# STEERING SWITCH

Check

## Check

NAEL0253



MEL447P


# HEADLAMP (FOR USA)

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

NAEL0254



SEL288Y

## System Description

NAEL0255

The headlamp operation is controlled by the lighting switch which is built into the combination switch and smart entrance control unit. And the headlamp battery saver system is controlled by the smart entrance control unit.

### OUTLINE

NAEL0255S01

Power is supplied at all times

- to headlamp LH relay terminals 1 and 3
- through 15A fuse (No. 60, located in the fuse and fusible link box), and
- to headlamp RH relay terminals 1 and 3
- through 15A fuse (No. 59, located in the fuse and fusible link box), and
- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

When the ignition switch is in the ON or START position, power is supplied

- to smart entrance control unit terminal 27
- through 7.5A fuse [No. 11, located in the fuse block (J/B)].

When the ignition switch is in the ACC or ON position, power is supplied

- to smart entrance control unit terminal 26
- through 10A fuse [No. 10, located in the fuse block (J/B)]

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M77 and M111.

### POWER SUPPLY TO LOW BEAM AND HIGH BEAM

NAEL0255S02

When lighting switch is in 2ND or PASS position, ground is supplied

- to headlamp relay (LH and RH) terminal 2 from smart entrance control unit terminals 21 and 59

# HEADLAMP (FOR USA)

## System Description (Cont'd)

---

- through smart entrance control unit terminals 22 and 60,
- from lighting switch terminal 12

Headlamp relays (LH and RH) are energized and then power is supplied to headlamps (LH and RH).

### LOW BEAM OPERATION

When the lighting switch is turned to the 2ND position and placed in LOW (“B”) position, power is supplied NAEL0255S03

- from terminal 5 of each headlamp relay
- to terminal 3 of each headlamp

Ground is supplied

- to headlamp LH terminal 2
- through lighting switch terminals 7 and 5
- through body grounds E13 and E41, and
- to headlamp RH terminal 2
- through lighting switch terminal 10 and 8
- through body grounds E13 and E41.

With power and ground supplied, the headlamp(s) will illuminate.

### HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

When the lighting switch is turned to the 2ND position and placed in HIGH (“A”) position or PASS (“C”) position, power is supplied NAEL0255S04

- from terminal 5 of each headlamp relay
- to terminal 3 of each headlamp, and
- to combination meter terminal 26 for the HIGH BEAM indicator.

Ground is supplied

- to headlamp LH terminal 1, and
- to combination meter terminal 27 for the HIGH BEAM indicator
- through lighting switch terminals 6 and 5
- through body grounds E13 and E41, and
- to headlamp RH terminal 1
- through lighting switch terminals 9 and 8
- through body grounds E13 and E41.

With power and ground supplied, the high beams and the high beam indicator illuminate.

### EXTERIOR LAMP BATTERY SAVER CONTROL

#### Except for Auto Light Control Operation

Headlamps will remain on for a short while after the ignition switch is turned from ON (or ACC) to OFF. NAEL0255S05

Continuity between terminals 21 and 22, and between terminals 59 and 60 of smart entrance control unit will be disturbed after 5 minutes, then the headlamps will be turned off. NAEL0255S0501

When the lighting switch is turned from OFF to 2ND after headlamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to headlamp LH and RH relays terminal 2 from smart entrance control unit terminals 21 and 59,
- through smart entrance control unit terminals 22 and 60 and
- through lighting switch terminal 12.

Then headlamps illuminate again.

#### Auto light control operation

While the headlamps are turned ON by “AUTO” operation, the exterior lamp battery saver is activated for 5 minutes when the ignition switch is turned from ON (or ACC) to OFF, and either LH or RH front door switch is opened. NAEL0255S0502

The smart entrance control unit controls exterior lamp battery saver activation as follows:

- When the door switch signal changes from ON to OFF while the exterior lamp battery saver is activated, the operation is discontinued, and restarts and lasts for 45 seconds, then the headlamps will be turned off.
- When the door switch signal changes from OFF to ON while the exterior lamp battery saver is activated, the operation discontinued, restarts and lasts for 45 seconds, then the headlamps will be turned off.

# HEADLAMP (FOR USA)

System Description (Cont'd)

- When the one of four door switch signals changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 5 minutes, then the headlamps will be turned off. GI
- When all the door switch ON signals are input while the exterior lamp battery saver is activated, the saver is discontinued and restarts and lasts for 45 seconds, then the headlamps will be turned off. MA
- Exterior battery saver control time can be changed using "WORK SUPPORT" mode in "HEADLAMP". EM

When the lighting switch is turned from OFF to 2ND after headlamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then, LC
- to headlamp LH and RH relays terminal 2 from smart entrance control unit terminals 21 and 59, EC
- through smart entrance control unit terminals 22 and 60 and EC
- through lighting switch terminal 12. FE

Then headlamps illuminate again.

## AUTO LIGHT OPERATION

The auto light control system has an auto light sensor inside instrument mask that detects outside brightness. FE

- to smart entrance control unit terminal 23 CL
- from lighting switch terminal 42. MT

When ignition switch is turned to "ON" or "START" position and

- Outside brightness is darker than prescribed level. MT

After 3 seconds delay, outside brightness becomes darker than prescribed level.

Ground is supplied AT

- to headlamp relay LH and RH terminals 2 TF
- through smart entrance control unit terminals 21, 59 and 43, 64. TF

Then both headlamp relays and tail lamp relay are energized, headlamps (low or high) and tail lamps are illuminated according to switch position.

Auto light operation allows headlamps and tail lamps to go off when

- Outside brightness is brighter than prescribed level, or PD
- After 5 seconds delay, outside brightness is brighter than prescribed level. AX
- Ignition switch is turned to "OFF" position. (Headlamp will be turned OFF by exterior lamp battery saver control system. Refer to EL-32.) AX

### NOTE:

**The delay time changes (maximum of 20 seconds) as the outside brightness changes.** SU

For parking license and tail lamp auto operation, refer to "PARKING, LICENSE AND TAIL LAMPS".

## VEHICLE SECURITY SYSTEM

The vehicle security system will flash the high beams if the system is triggered. Refer to "VEHICLE SECURITY (THEFT WARNING) SYSTEM" (EL-342). ST

BR

ST

RS

BT

HA

SC

EL


IDX

# HEADLAMP (FOR USA)

Schematic

## Schematic

NAEL0256





MEL390P



# HEADLAMP (FOR USA)

Wiring Diagram — H/LAMP — (Cont'd)

EL-H/LAMP-02



REFER TO THE FOLLOWING.



(E1) -SUPER MULTIPLE JUNCTION (SMJ)

MEL391P

# HEADLAMP (FOR USA)

Wiring Diagram — H/LAMP — (Cont'd)

## EL-H/LAMP-03



REFER TO THE FOLLOWING.  
 (E1) -SUPER MULTIPLE  
 JUNCTION (SMJ)


MEL853N

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HEADLAMP (FOR USA)







Wiring Diagram — H/LAMP — (Cont'd)

EL-H/LAMP-04




REFER TO THE FOLLOWING.

(B1) -SUPER  
MULTIPLE JUNCTION (SMJ)



MEL392P




## CONSULT-II Inspection Procedure

NAEL0258


NAEL0258S01

### “HEADLAMP”


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START”.



5. Touch “SMART ENTRANCE”.



6. Touch “HEADLAMP”.



7. Select diagnosis mode. “DATA MONITOR”, “ACTIVE TEST” and “WORK SUPPORT” are available.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# HEADLAMP (FOR USA)

CONSULT-II Application Items

## CONSULT-II Application Items

NAEL0453

NAEL0453S01

NAEL0453S0101

### “HEAD LAMP” Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
AUTO LIGT SW	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
AUTO LIGT SENS	Displays “Illumination outside of the vehicle (close to 5V when light/close to 0V when dark)” as judged from the optical sensor signal.
LIGHT SW 1ST	Displays status of the lighting switch as judged from the lighting switch signal. (1ST or 2ND position: ON/Other than 1ST and 2ND position: OFF)
LIGHT SW 2ND	Displays status of the lighting switch as judged from the lighting switch signal. (2ND position: ON/Other than 2ND position: OFF)
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of door switch RH.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch.

### Active Test

NAEL0453S0102

Test Item	Description
TAIL LAMP	Tail lamp relay can be operated by on-off operation of the tail lamp.
HEAD LAMP	Headlamp relay can be operated by on-off operation of the headlamp.
AUTO LIGHT	Night time dimming signal can be operated by on-off operation.

### Work Support

NAEL0453S0103

Work Item	Description
AUTO LIGHT SET	Auto light sensitivity can be changed in this mode. Sensitivity can be adjusted in four modes. ● MODE 1 (Normal)/MODE 2 (Sensitive)/MODE 3 (Desensitized)/MODE 4 (Insensitive)
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between two modes. ● MODE 1 (ON)/MODE 2 (OFF)
ILL DELAY SET	Exterior lamp battery saver control time can be changed in this mode. Selects exterior lamp battery saver control time among eight modes. ● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (30 sec.)/MODE 4 (60 sec.)/ MODE 5 (90 sec.)/ MODE 6 (120 sec.)/MODE 7 (150 sec.)/MODE 8 (180 sec.)

## Trouble Diagnoses

NAEL0260

Symptom	Possible cause	Repair order
Neither headlamp operates.	<ol style="list-style-type: none"> <li>1. 7.5A fuse</li> <li>2. Headlamp relay circuit</li> <li>3. Lighting switch</li> <li>4. Smart entrance control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse [No. 24, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 49 of smart entrance control unit.</li> <li>2. Check between smart entrance control unit and headlamp relays (LH and RH).</li> <li>3. Check Lighting switch.</li> <li>4. Check smart entrance control unit. (EL-378)</li> </ol>

# HEADLAMP (FOR USA)

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order	
Headlamp LH (low and high beam) does not operate, but headlamp RH (low and high beam) does operate.	<ol style="list-style-type: none"> <li>15A fuse</li> <li>Headlamp LH relay</li> <li>Headlamp LH relay circuit</li> </ol>	<ol style="list-style-type: none"> <li>Check 15A fuse (No. 60, located in fusible link and fuse box). Verify battery positive voltage is present at terminals 1 and 3 of headlamp LH relay.</li> <li>Check headlamp LH relay.</li> <li>Check harness between headlamp LH relay and smart entrance control unit.</li> </ol>	GI MA EM
Headlamp RH (low and high beam) does not operate, but headlamp LH (low and high beam) does operate.	<ol style="list-style-type: none"> <li>15A fuse</li> <li>Headlamp RH relay</li> <li>Headlamp RH relay circuit</li> </ol>	<ol style="list-style-type: none"> <li>Check 15A fuse (No. 59, located in fusible link and fuse box). Verify battery positive voltage is present at terminals 1 and 3 of headlamp RH relay.</li> <li>Check headlamp RH relay.</li> <li>Check harness between headlamp RH relay and smart entrance control unit.</li> </ol>	LC EC
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> <li>Bulb</li> <li>Open in the LH high beam circuit</li> <li>Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>Check bulb.</li> <li>Check harness between headlamp LH and lighting switch for open circuit.</li> <li>Check lighting switch.</li> </ol>	FE CL
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> <li>Bulb</li> <li>Open in LH low beam circuit</li> <li>Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>Check bulb.</li> <li>Check harness between headlamp LH and lighting switch for open circuit.</li> <li>Check lighting switch.</li> </ol>	MT
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> <li>Bulb</li> <li>Open in the RH high beam circuit</li> <li>Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>Check bulb.</li> <li>Check harness between headlamp RH and lighting switch for open circuit.</li> <li>Check lighting switch.</li> </ol>	AT
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> <li>Bulb</li> <li>Open in RH low beam circuit</li> <li>Lighting switch</li> </ol>	<ol style="list-style-type: none"> <li>Check bulb.</li> <li>Check harness between headlamp RH and lighting switch for open circuit.</li> <li>Check lighting switch.</li> </ol>	TF PD
High beam indicator does not work.	<ol style="list-style-type: none"> <li>Bulb</li> <li>Open in high beam circuit</li> </ol>	<ol style="list-style-type: none"> <li>Check bulb in combination meter.</li> <li>Check the following. <ol style="list-style-type: none"> <li>Harness between headlamp LH relay and combination meter for an open circuit</li> <li>Harness between high beam indicator and lighting switch</li> </ol> </li> </ol>	AX SU
Battery saver control does not operate properly.	<ol style="list-style-type: none"> <li>Door switch LH or RH circuit</li> <li>Lighting switch circuit</li> <li>Smart entrance control unit</li> </ol>	<ol style="list-style-type: none"> <li>Check the following. <ol style="list-style-type: none"> <li>Harness between smart entrance control unit and LH or RH door switch for open or short circuit.</li> <li>LH or RH door switch ground circuit.</li> <li>LH or RH door switch.</li> </ol> </li> <li>Check the following. <ol style="list-style-type: none"> <li>Harness between smart entrance control unit terminals 20 or 58 and lighting switch terminal 11 for open or short circuit.</li> <li>Harness between lighting switch terminal 5 and ground.</li> <li>Lighting switch.</li> </ol> </li> <li>Check smart entrance control unit. (EL-378)</li> </ol>	BR ST RS BT

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


# HEADLAMP (FOR USA)

## Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
When outside is dark, neither tail lamp nor headlamp turn on by auto light operation.	<ol style="list-style-type: none"> <li>1. 7.5A fuse</li> <li>2. Lighting switch "AUTO" check</li> <li>3. Lighting switch circuit check</li> <li>4. Lighting switch ground circuit check</li> <li>5. Auto light sensor check</li> <li>6. Auto light sensor circuit check</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse [NO. 11 located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 27 of smart entrance control unit.</li> <li>2. Check lighting switch (AUTO) input signal with "CONSULT-II" in "DATA MONITOR" mode. When lighting switch is in AUTO: <b>AUTO LIGHT SWITCH ON</b> When lighting switch is in OFF: <b>AUTO LIGHT SWITCH OFF</b></li> <li>3. Check harness for open or short between smart entrance control unit and lighting switch.</li> <li>4. Check harness for lighting switch and ground.</li> <li>5. Check auto light sensor input signal. (With CONSULT-II) See "AUTO LIGHT SENSOR" in DATA MONITOR mode. When auto light sensor is stuck by light: <b>More than 3V</b> When auto light sensor is not stuck by light: <b>Approx. 0.5V</b> (Without CONSULT-II) Check voltage between smart entrance control unit terminal 7 and ground. Refer to smart entrance control unit. (EL-378)</li> <li>6. Check the following. <ol style="list-style-type: none"> <li>a. Harness for open or short between smart entrance control unit terminal 8 and auto light sensor terminal 1</li> <li>b. Harness for open or short between smart entrance control unit terminal 7 and auto light sensor terminal 2</li> <li>c. Harness for open or short between smart entrance control unit terminals 9 and 3</li> </ol> </li> </ol>
When outside is dark, tail lamp turns on but headlamp does not turn on by auto light operation.	Auto light output check	<p>Check auto light output. (With CONSULT-II) See "HEADLAMP" and "TAIL LAMP" in ACTIVE TEST mode, and headlamp switch to AUTO position. <b>Headlamp and tail lamp should turn on.</b> (Without CONSULT-II) Check voltage between smart entrance control unit terminals 19, 21, 57, 59 and ground. Refer to smart entrance control unit. (EL-378)</p>
When outside is dark, headlamp turns on but tail lamp does not turn on by auto light operation.	Auto light output check	<p>Check auto light output. (With CONSULT-II) See "HEADLAMP" and "TAIL LAMP" in ACTIVE TEST mode, and headlamp switch to AUTO position. <b>Headlamp and tail lamp should turn on.</b> (Without CONSULT-II) Check voltage between smart entrance control unit terminals 19, 21, 57, 59 and ground. Refer to smart entrance control unit. (EL-378)</p>
Light does not turn off when ignition key switch is turned to "OFF" (exterior battery saver control is canceled).	<ol style="list-style-type: none"> <li>1. 7.5A fuse</li> <li>2. IGN switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse [NO. 11 located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 27 of smart entrance control unit.</li> <li>2. Check harness for open or short between smart entrance control unit and fuse.</li> </ol>

Symptom	Possible cause	Repair order
When outside is bright, neither tail lamps nor headlamps turn off by auto light operation.	Auto light sensor check	Check auto light sensor input signal. (With CONSULT-II) See "AUTO LIGHT SENSOR" in DATA MONITOR mode. When auto light sensor is stuck by light: <b>More than 3V</b> When auto light sensor is not stuck by light: <b>Approx. 0.5V</b> (Without CONSULT-II) Check voltage between smart entrance control unit terminal 7 (W/G) and ground. Refer to smart entrance control unit. (EL-378)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



## Bulb Replacement

NAEL0261

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Disconnect the battery cable.
2. Disconnect the harness connector from the back side of the bulb.
3. Pull off the rubber cap.
4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
5. Install in the reverse order of removal.

### CAUTION:

**Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.**

## Aiming Adjustment

NAEL0262


Before performing aiming adjustment, check the following.

**For details, refer to the regulations in your own country.**

- 1) Keep all tires inflated to correct pressures.
- 2) Place vehicle flat surface.
- 3) See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).

# HEADLAMP (FOR USA)


## Aiming Adjustment (Cont'd)



### LOW BEAM

1. Remove aiming adjusting screw cap.
  2. Turn headlamp low beam on.
  3. Use adjusting screws to perform aiming adjustment.
- **First tighten the adjusting screw all the way and then make adjustment by loosening the screw.**

NAEL0262S01



If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.


- **Basic illuminating area for adjustment should be within the range shown on the aiming chart. Adjust headlamps accordingly.**

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0263



SEL288Y

## System Description

NAEL0264

The headlamp system for Canada vehicles contains a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

And battery saver system is controlled by the smart entrance control unit.

Power is supplied at all times

- to headlamp LH relay terminals 1 and 3
- through 15A fuse (No. 60, located in the fuse and fusible link box), and
- to headlamp RH relay terminals 1 and 3
- through 15A fuse (No. 59, located in the fuse and fusible link box), and
- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

Ground is supplied

- to daytime light control unit terminal 16 and
- to smart entrance control unit terminals 43 and 64

When the ignition switch is in the ON or START position, power is also supplied

- to daytime light control unit terminal 3, and
- to smart entrance control unit terminal 27
- through 7.5A fuse [No. 11, located in the fuse block (J/B)].

When the ignition switch is in the ACC or ON position, power is supplied

- to smart entrance control unit terminal 26
- through 10A fuse [No. 10, located in the fuse block (J/B)].

When the ignition switch is in the START position, power is supplied

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

System Description (Cont'd)

- to daytime light control unit terminal 2
- through 7.5A fuse [No. 26, located in the fuse block (J/B)].

## HEADLAMP OPERATION

### Power Supply to Low Beam and High Beam

NAEL0264S01

NAEL0264S0101

When lighting switch is in 2ND or PASS position, ground is supplied

- to headlamp relay (LH and RH) terminal 2 from smart entrance control unit terminals 21 and 59
- through smart entrance control unit terminals 22 and 60
- from lighting switch terminal 12.

Headlamp relays (LH and RH) are energized and then power is supplied to headlamps (LH and RH).

### Low Beam Operation

NAEL0264S0102

When the lighting switch is turned to 2ND and LOW (“B”) positions, ground is supplied

- to terminal 2 of the headlamp LH
- through daytime light control unit terminals 11 and 15
- through lighting switch terminals 7 and 5
- through body grounds E13 and E41.

Ground is also supplied

- to terminal 2 of the headlamp RH
- through daytime light control unit terminals 8 and 12
- through lighting switch terminals 10 and 8
- through body grounds E13 and E41.

With power and ground supplied, the low beam headlamps illuminate.

### High Beam Operation/Flash-to-pass Operation

NAEL0264S0103

When the lighting switch is turned to 2ND and HIGH (“A”) or PASS (“C”) positions, ground is supplied

- to terminal 1 of headlamp LH
- through daytime light control unit terminals 10 and 13, and
- to combination meter terminal 27 for the HIGH BEAM indicator
- through lighting switch terminals 6 and 5
- through body grounds E13 and E41.

Ground is also supplied

- to terminal 1 of headlamp RH
- through daytime light control unit terminals 9 and 14
- through lighting switch terminals 9 and 8
- through body grounds E13 and E41.

With power and ground supplied, the high beam headlamps and HIGH BEAM indicator illuminate.

## EXTERIOR LAMP BATTERY SAVER CONTROL

NAEL0264S02

### Except for Auto Light Control Operation

NAEL0264S0201

Headlamps will remain on for a short while after the ignition switch is turned from ON (or ACC) to OFF.

Continuity between terminals 21 and 22, and between terminals 59 and 60 of smart entrance control unit will be disturbed after 5 minutes, then the headlamps will be turned off.

When the lighting switch is turned from OFF to 2ND after headlamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to headlamp LH and RH relays terminal 2 from smart entrance control unit terminals 21 and 59,
- through smart entrance control unit terminals 22 and 60 and
- through lighting switch terminal 12.

Then headlamps illuminate again.

### Auto light control operation

NAEL0264S0202

While the headlamps are turned ON by “AUTO” operation, the exterior lamp battery saver is activated for 5 minutes when the ignition switch is turned from ON (or ACC) to OFF, and either LH or RH front door switch is opened.

The smart entrance control unit controls exterior lamp battery saver activation as follows:

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

System Description (Cont'd)

- When the door switch signal changes from ON to OFF while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the headlamps will be turned off.
- When the door switch signal changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the headlamps will be turned off.
- When the one of four door switch signals changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 5 minutes, then the headlamps will be turned off.
- When all the door switch ON signals are input while the exterior lamp battery saver is activated, the saver is discontinued and restarts and lasts for 45 seconds, then the headlamps will be turned off.
- Exterior battery saver control time can be changed using “WORK SUPPORT” mode in “HEADLAMP”.

When the lighting switch is turned from OFF to 2ND after headlamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to headlamp LH and RH relays terminal 2 from smart entrance control unit terminals 21 and 59,
- through smart entrance control unit terminals 22 and 60 and
- through lighting switch terminal 12.

Then headlamps illuminate again.

## AUTO LIGHT OPERATION

For auto light operation, refer to “HEADLAMP” (EL-33).

NAEL0264S03

## DAYTIME LIGHT OPERATION

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

NAEL0264S04

- through daytime light control unit terminal 7
- to terminal 3 of headlamp RH
- through terminal 1 of headlamp RH
- to daytime light control unit terminal 9
- through daytime light control unit terminal 6
- to terminal 3 of headlamp LH.

Ground is supplied to terminal 1 of headlamp LH.

- through daytime light control unit terminals 10 and 16
- through body grounds E13 and E41.

Because the high beam headlamps are now wired in series, they operate at half illumination.

## OPERATION

After starting the engine with the lighting switch in the “OFF” or “1ST” position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

NAEL0264S05

Engine		With engine stopped									With engine running								
		OFF			1ST			2ND			OFF			1ST			2ND		
Lighting switch		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C
		Headlamp	High beam	X	X	O	X	X	O	O	X	O	△*	△*	O	△*	△*	O	O
Low beam	X		X	X	X	X	X	X	O	X	X	X	X	X	X	X	X	O	X
Clearance and tail lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O
License and instrument illumination lamp		X	X	X	O	O	O	O	O	O	X	X	X	O	O	O	O	O	O

A: “HIGH BEAM” position

B: “LOW BEAM” position

C: “FLASH TO PASS” position

O : Lamp “ON”

X : Lamp “OFF”

△ : Lamp dims. (Added functions)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

## HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

### *System Description (Cont'd)*

---


\*: When starting the engine with the parking brake released, the daytime light will come ON.  
When starting the engine with the parking brake pulled, the daytime light won't come ON.

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Schematic

NAEL0265

## Schematic



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL393P





# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL —

## Wiring Diagram — DTRL —

NAEL0266

EL-DTRL-01



REFER TO THE FOLLOWING.


(M10) - FUSE BLOCK-  
JUNCTION BOX (J/B)




# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-02



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX





REFER TO THE FOLLOWING.  
(E1) - SUPER MULTIPLE JUNCTION (SMJ)

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-03








REFER TO THE FOLLOWING.  
**(E1)** -SUPER MULTIPLE JUNCTION (SMJ)  
**(M10), (E3)** -FUSE BLOCK-JUNCTION (J/B)

MEL396P

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-04






REFER TO THE FOLLOWING.  
 (E1), (B1) -SUPER  
 MULTIPLE JUNCTION (SMJ)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Wiring Diagram — DTRL — (Cont'd)

EL-DTRL-05



REFER TO THE FOLLOWING.

(B1) -SUPER  
MULTIPLE JUNCTION (SMJ)

MEL397P

## CONSULT-II Inspection Procedure

### “HEADLAMP”

Refer to “HEADLAMP (FOR USA)” (EL-39).

NAEL0267

NAEL0267S01

GI

MA

EM

LC

EC

NAEL0268

NAEL0268S01

FE

CL

MT

AT

## Trouble Diagnoses

NAEL0269

Symptom	Possible cause	Repair order
Neither headlamp operates.	<ol style="list-style-type: none"> <li>7.5A fuse</li> <li>Lighting switch</li> <li>Smart entrance control unit</li> </ol>	<ol style="list-style-type: none"> <li>Check 7.5A fuse [No. 24, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 49 of smart entrance control unit.</li> <li>Check Lighting switch.</li> <li>Check smart entrance control unit. (EL-378)</li> </ol>
LH headlamp (low and high beam) does not operate, but RH headlamp (low and high beam) does operate.	<ol style="list-style-type: none"> <li>15A fuse</li> <li>Headlamp LH relay</li> <li>Headlamp LH relay circuit</li> <li>Headlamp LH ground circuit</li> <li>Lighting switch circuit</li> <li>Daytime light control unit</li> <li>Smart entrance control unit</li> </ol>	<ol style="list-style-type: none"> <li>Check 15A fuse (No. 60, located in fusible link and fuse box). Verify battery positive voltage is present at terminal 1 and 3 of headlamp LH relay.</li> <li>Check headlamp LH relay.</li> <li>Check the following.                             <ol style="list-style-type: none"> <li>Harness between headlamp LH relay and daytime light control unit.</li> <li>Harness between headlamp LH relay and smart entrance control unit.</li> </ol> </li> <li>Harness between headlamp LH and daytime light control unit.</li> <li>Check harness between smart entrance control unit and lighting switch.</li> <li>Check daytime light control unit. (EL-58)</li> <li>Check smart entrance control unit. (EL-378)</li> </ol>

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

## Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
RH headlamp (low and high beam) does not operate, but LH headlamp (low and high beam) does operate.	<ol style="list-style-type: none"> <li>1. 15A fuse</li> <li>2. Headlamp RH relay</li> <li>3. Headlamp RH relay circuit</li> <li>4. Headlamp RH ground circuit</li> <li>5. Lighting switch circuit</li> <li>6. Daytime light control unit</li> <li>7. Smart entrance control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 15A fuse (No. 59, located in fusible link and fuse box). Verify battery positive voltage is present at terminals 1 and 3 of headlamp RH relay.</li> <li>2. Check headlamp RH relay.</li> <li>3. Check the following.               <ol style="list-style-type: none"> <li>a. Harness between headlamp RH relay and daytime light control unit.</li> <li>b. Harness between headlamp RH relay and smart entrance control unit.</li> </ol> </li> <li>4. Harness between headlamp RH and daytime light control unit.</li> <li>5. Check harness between smart entrance control unit and lighting switch.</li> <li>6. Check daytime light control unit. (EL-58)</li> <li>7. Check smart entrance control unit. (EL-378)</li> </ol>
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Headlamp LH high beams circuit</li> <li>3. Lighting switch</li> <li>4. Lighting switch circuit</li> <li>5. Daytime light control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check harness between LH headlamp and daytime light control unit.</li> <li>3. Check lighting switch.</li> <li>4. Check harness between daytime light control unit and lighting switch.</li> <li>5. Check daytime light control unit. (EL-58)</li> </ol>
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Headlamp LH high beams circuit</li> <li>3. Lighting switch</li> <li>4. Lighting switch circuit</li> <li>5. Daytime light control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check harness between LH headlamp and daytime light control unit.</li> <li>3. Check lighting switch.</li> <li>4. Check harness between daytime light control unit and lighting switch.</li> <li>5. Check daytime light control unit. (EL-58)</li> </ol>
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Open in the RH high beams circuit</li> <li>3. Lighting switch</li> <li>4. Lighting switch circuit</li> <li>5. Daytime light control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check harness between RH headlamp and daytime light control unit.</li> <li>3. Check lighting switch.</li> <li>4. Check harness between daytime light control unit and lighting switch.</li> <li>5. Check daytime light control unit. (EL-58)</li> </ol>
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Open in the RH high beams circuit</li> <li>3. Lighting switch</li> <li>4. Lighting switch circuit</li> <li>5. Daytime light control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check harness between RH headlamp and daytime light control unit.</li> <li>3. Check lighting switch.</li> <li>4. Check harness between daytime light control unit and lighting switch.</li> <li>5. Check daytime light control unit. (EL-58)</li> </ol>
High beam indicator does not work.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Open in high beam circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb in combination meter.</li> <li>2. Check the following.               <ol style="list-style-type: none"> <li>a. Harness between headlamp LH relay and combination meter for an open circuit.</li> <li>b. Harness between high beam indicator and lighting switch.</li> </ol> </li> </ol>
Battery saver control does not operate properly.	<ol style="list-style-type: none"> <li>1. Door switch LH or RH circuit</li> <li>2. Smart entrance control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check the following.               <ol style="list-style-type: none"> <li>a. Harness between smart entrance control unit and LH or RH door switch for open or short circuit.</li> <li>b. LH or RH door switch ground circuit.</li> <li>c. LH or RH door switch.</li> </ol> </li> <li>2. Check smart entrance control unit. (EL-378)</li> </ol>

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order	
Daytime light control does not operate properly.	<ol style="list-style-type: none"> <li>1. Fuse check</li> <li>2. Parking brake switch</li> <li>3. Parking brake switch circuit</li> <li>4. Alternator circuit</li> <li>5. Daytime light control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check the following.                             <ol style="list-style-type: none"> <li>a. 7.5A fuse [No. 11, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of daytime light control unit.</li> <li>b. 7.5A fuse [No. 26, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 2 of daytime light control unit.</li> </ol> </li> <li>2. Check parking brake switch.</li> <li>3. Check harness between parking brake switch and daytime light control unit.</li> <li>4. Check harness between alternator and daytime light control unit.</li> <li>5. Check daytime light control unit. (EL-58)</li> </ol>	GI MA EM LC EC
When outside is dark, neither tail lamp nor headlamp turn on by auto light operation.	<ol style="list-style-type: none"> <li>1. 7.5A fuse</li> <li>2. Lighting switch "AUTO" check</li> <li>3. Lighting switch circuit check</li> <li>4. Lighting switch ground circuit check</li> <li>5. Auto light sensor check</li> <li>6. Auto light sensor circuit check</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse [NO. 11 located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 27 of smart entrance control unit.</li> <li>2. Check lighting switch (AUTO) input signal with "CONSULT-II" in "DATA MONITOR" mode. When lighting switch is in AUTO: <b>AUTO LIGHT SWITCH ON</b> When lighting switch is in OFF: <b>AUTO LIGHT SWITCH OFF</b></li> <li>3. Check harness for open or short between smart entrance control unit and lighting switch.</li> <li>4. Check harness for lighting switch and ground.</li> <li>5. Check auto light sensor input signal. (With CONSULT-II) See "AUTO LIGHT SENSOR" in DATA MONITOR mode. When auto light sensor is stuck by light: <b>More than 3V</b> When auto light sensor is not stuck by light: <b>Approx. 0.5V</b> (Without CONSULT-II) Check voltage between smart entrance control unit terminal 7 and ground. Refer to smart entrance control unit. (EL-378)</li> <li>6. Check the following.                             <ol style="list-style-type: none"> <li>a. Harness for open or short between smart entrance control unit terminal 8 and auto light sensor terminal 1</li> <li>b. Harness for open or short between smart entrance control unit terminal 7 and auto light sensor terminal 2</li> <li>c. Harness for open or short between smart entrance control unit terminal 9 and 3</li> </ol> </li> </ol>	FE CL MT AT TF PD AX SU BR ST
When outside is dark, tail lamp turns on but headlamp does not turn on by auto light operation.	Auto light output check	Check auto light output. (With CONSULT-II) See "HEADLAMP" and "TAIL LAMP" in ACTIVE TEST mode, and headlamp switch to AUTO position. <b>Headlamp and tail lamp should turn on.</b> (Without CONSULT-II) Check voltage between smart entrance control unit terminals 19, 21, 57, 59 and ground. Refer to smart entrance control unit. (EL-378)	RS BT HA

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
When outside is dark, headlamp turns on but tail lamp does not turn on by auto light operation.	Auto light output check	Check auto light output. (With CONSULT-II) See "HEADLAMP" and "TAIL LAMP" in ACTIVE TEST mode, and headlamp switch to AUTO position. <b>Headlamp and tail lamp should turn on.</b> (Without CONSULT-II) Check voltage between smart entrance control unit terminals 19, 21, 57, 59 and ground. Refer to smart entrance control unit. (EL-378)
Light does not turn off when ignition key switch is turned to "OFF" (exterior battery saver control is canceled).	1. 7.5A fuse 2. IGN switch circuit	1. Check 7.5A fuse [NO. 11 located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 27 of smart entrance control unit. 2. Check harness for open or short between smart entrance control unit and fuse.
When outside is bright, neither tail lamps nor headlamps turn off by auto light operation.	Auto light sensor check	Check auto light sensor input signal. (With CONSULT-II) See "AUTO LIGHT SENSOR" in DATA MONITOR mode. When auto light sensor is stuck by light: <b>More than 3V</b> When auto light sensor is not stuck by light: <b>Approx. 0.5V</b> (Without CONSULT-II) Check voltage between smart entrance control unit terminal 7 (W/G) and ground. Refer to smart entrance control unit. (EL-378)

## DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE

NAEL0269S01

Terminal No.	Wire color	Item	Condition	Voltage (Approximate values)
1	Y/B	Alternator	 When turning ignition switch to "ON"	Less than 1V
			 When engine is running	Battery voltage
			 When turning ignition switch to "OFF"	Less than 1V
2	Y/R	Start signal	 When turning ignition switch to "ST"	Battery voltage
			 When turning ignition switch to "ON" from "ST"	Less than 1V
			 When turning ignition switch to "OFF"	Less than 1V
3	G	Power source	 When turning ignition switch to "ON"	Battery voltage
			 When turning ignition switch to "ST"	Battery voltage
			 When turning ignition switch to "OFF"	Less than 1V

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

Trouble Diagnoses (Cont'd)

Terminal No.	Wire color	Item	Condition	Voltage (Approximate values)	
4	R/L	Power source	 When turning ignition switch to "ON"	Battery voltage	GI MA
			 When turning ignition switch to "OFF"	Battery voltage	EM
5	R/W	Power source	 When turning ignition switch to "ON"	Battery voltage	LC
			 When turning ignition switch to "OFF"	Battery voltage	EC
6	R	LH hi beam	When lighting switch is turned to the 2ND position with "HI BEAM" position	Battery voltage	FE
			  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in N or P position.</b>	Approx. half battery voltage	CL MT
7	L/R	RH hi beam	When lighting switch is turned to the 2ND position with "HI BEAM" position	Battery voltage	AT
			  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in N or P position.</b>	Battery voltage	TF PD
9	PU	RH hi beam (ground)	When lighting switch is turned to the 2ND position with "HI BEAM" position	Less than 1V	AX
			  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in N or P position.</b>	Approx. half battery voltage	SU BR
10	GY	LH hi beam (ground)	When lighting switch is turned to the 2ND position with "HI BEAM" position	Less than 1V	ST
			  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in N or P position.</b>	Less than 1V	RS BT
13 14	L/W W/R	Lighting switch (Hi beam)	When turning lighting switch to "HI BEAM"	Less than 1V	HA
			When turning lighting switch to "FLASH TO PASS"	Less than 1V	
16	B	Ground	—	—	SC
17	L/G	Parking brake switch	 When parking brake is released	Battery voltage	EL
			When parking brake is set	Less than 1.5V	

# HEADLAMP (FOR CANADA) — DAYTIME LIGHT SYSTEM —

*Bulb Replacement*

---

## **Bulb Replacement**

Refer to “HEADLAMP (FOR USA)” (EL-43).

NAEL0270

## **Aiming Adjustment**

Refer to “HEADLAMP (FOR USA)” (EL-43).

NAEL0271

## System Description

NAEL0272

The parking, license and tail lamp operation is controlled by the lighting switch which is built into the combination switch and smart entrance control unit. The battery saver system is controlled by the smart entrance control unit.

Power is supplied at all times

- to tail lamp relay terminals 1 and 3
- through 10A fuse (No. 61, located in the fuse and fusible link box), and
- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

When ignition switch is in ON or START position, power is supplied

- to smart entrance control unit terminal 27
- through 7.5A fuse [No. 11, located in the fuse block (J/B)].

When the ignition switch is in the ACC or ON position, power is supplied

- to smart entrance control unit terminal 26
- through 10A fuse [No. 10, located in the fuse block (J/B)].

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M77 and M111.

### LIGHTING OPERATION BY LIGHTING SWITCH

NAEL0272S01

When lighting switch is in 1ST (or 2ND) position, ground is supplied

- to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57
- through smart entrance control unit terminals 20 and 58, and
- through lighting switch and body grounds E13 and E41.

Tail lamp relay is then energized and the parking, license and tail lamps illuminate.

### LIGHTING OPERATION BY AUTO LIGHT CONTROL SYSTEM

NAEL0272S02

When lighting switch is in AUTO position, ground is supplied

- to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57
- through smart entrance control unit terminals 43 and 64, and
- to body grounds M77 and M111.

Tail lamp relay is then energized and the parking, license and tail lamps illuminate.

### EXTERIOR LAMP BATTERY SAVER CONTROL

NAEL0272S03

#### Except for Auto Light Control Operation

NAEL0272S0301

Parking, license and tail lamps will remain on for a short while after the ignition switch is turned from ON (or ACC) to OFF.

Continuity between terminals 21 and 22, and between terminals 59 and 60 of smart entrance control unit will be disturbed after 5 minutes, then the headlamps will be turned off.

When the lighting switch is turned from OFF to 2ND after parking, license and tail lamps headlamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to headlamp LH and RH relays terminal 2 from smart entrance control unit terminals 21 and 59,
- through smart entrance control unit terminals 22 and 60 and
- through lighting switch terminal 12.

Then parking, license and tail lamps illuminate again.

#### Auto light control operation

NAEL0272S0302

While the parking, license and tail lamps are turned ON by "AUTO" operation, the exterior lamp battery saver is activated for 5 minutes when the ignition switch is turned from ON (or ACC) to OFF, and either LH or RH front door switch is opened.

The smart entrance control unit controls exterior lamp battery saver activation as follows:

- When the door switch signal changes from ON to OFF while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the parking, license and tail lamps will be turned off.
- When the door switch signal changes from OFF to ON while the exterior lamp battery saver is activated,

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

## PARKING, LICENSE AND TAIL LAMPS

### *System Description (Cont'd)*

---

the operation is discontinued, restarts and lasts for 45 seconds, then the parking, license and tail lamps will be turned off.

- When the one of four door switch signals changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 5 minutes seconds, then the parking, license and tail lamps will be turned off.
- When all the door switch ON signals are input while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the parking, license and tail lamps will be turned off.
- Exterior battery saver control time can be changed using "WORK SUPPORT" mode in "HEADLAMP".

When the lighting switch is turned from OFF to 2ND after parking, license and tail lamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to tail lamp relays terminal 2 from smart entrance control unit terminals 21 and 59,
- through smart entrance control unit terminals 22 and 60 and
- through lighting switch terminal 12.


Then parking, license and tail lamps illuminate again.

# PARKING, LICENSE AND TAIL LAMPS

Schematic

NAEL0273

## Schematic



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX

MEL515P



# PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L —

## Wiring Diagram — TAIL/L —

NAEL0274

EL-TAIL/L-01



REFER TO THE FOLLOWING.

(M10) - FUSE BLOCK-  
JUNCTION BOX (J/B)




MEL398P



# PARKING, LICENSE AND TAIL LAMPS








Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-03



BD : With spare tire carrier  
 OD : Without spare tire carrier

To EL-STOP/L



REFER TO THE FOLLOWING.

B1 -SUPER MULTIPLE  
 JUNCTION (SMJ)






M91 -FUSE BLOCK-  
 JUNCTION BOX (J/B)

MEL553P

# PARKING, LICENSE AND TAIL LAMPS

Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-04




REFER TO THE FOLLOWING.

(B1) -SUPER  
MULTIPLE JUNCTION (SMJ)

MEL404P

# PARKING, LICENSE AND TAIL LAMPS

CONSULT-II Inspection Procedure




## CONSULT-II Inspection Procedure "HEADLAMP"


NAEL0275

NAEL0275S01


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "SMART ENTRANCE".



6. Touch "HEADLAMP".



7. Select diagnosis mode.  
"DATA MONITOR" and "ACTIVE TEST" are available.

## CONSULT-II Application Items

### “HEADLAMP” Data Monitor

NAEL0454

NAEL0454S01

NAEL0454S0101

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
AUTO LIGT SW	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
AUTO LIGT SENS	Displays “Illumination outside of the vehicle (close to 5V when light/close to 0V when dark)” as judged from the optical sensor signal.
LIGHT SW 1ST	Displays status of the lighting switch as judged from the lighting switch signal. (1ST or 2ND position: ON/Other than 1ST and 2ND position: OFF)
LIGHT SW 2ND	Displays status of the lighting switch as judged from the lighting switch signal. (2ND position: ON/Other than 2ND position: OFF)
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of door switch RH.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch.

### Active Test

NAEL0454S0102

Test Item	Description
TAIL LAMP	Tail lamp relay can be operated by on-off operation of the tail lamp.
HEAD LAMP	Headlamp relay can be operated by on-off operation of the headlamp.
AUTO LIGHT	Night time dimming signal can be operated by on-off operation.

### Work Support

NAEL0454S0103

Work Item	Description
AUTO LIGHT SET	Auto light sensitivity can be changed in this mode. Sensitivity can be adjusted in four modes. ● MODE 1 (Normal)/MODE 2 (Sensitive)/MODE 3 (Desensitized)/MODE 4 (Insensitive)
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between two modes. ● MODE 1 (ON)/MODE 2 (OFF)
ILL DELAY SET	Auto light delay off timer period can be changed in this mode. Selects auto light delay off timer period among eight modes. ● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (30 sec.)/MODE 4 (60 sec.)/ MODE 5 (90 sec.)/ MODE 6 (120 sec.)/MODE 7 (150 sec.)/MODE 8 (180 sec.)

## Trouble Diagnoses

NAEL0277

Symptom	Possible cause	Repair order
No lamps operate (including head-lamps).	<ol style="list-style-type: none"> <li>1. 7.5A fuse</li> <li>2. Lighting switch</li> <li>3. Smart entrance control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse [No. 24, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 49 of smart entrance control unit.</li> <li>2. Check lighting switch.</li> <li>3. Check smart entrance control unit. (EL-378)</li> </ol>

## PARKING, LICENSE AND TAIL LAMPS

### Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
No parking, license and tail lamps operate, but headlamps do operate.	<ol style="list-style-type: none"> <li>1. 10A fuse</li> <li>2. Tail lamp relay</li> <li>3. Tail lamp relay circuit</li> <li>4. Lighting switch</li> <li>5. Lighting switch circuit</li> <li>6. Smart entrance control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 10A fuse (No. 61, located in fusible and fuse block). Verify battery positive voltage is present at terminals 1 and 3 of tail lamp relay.</li> <li>2. Check tail lamp relay.</li> <li>3. Check the following.               <ol style="list-style-type: none"> <li>a. Harness between smart entrance control unit terminals 19 and 57 and tail lamp relay terminal 2</li> <li>b. Harness between tail lamp relay terminal 5 and fuse block.</li> </ol> </li> <li>4. Check lighting switch.</li> <li>5. Check the following.               <ol style="list-style-type: none"> <li>a. Harness between lighting switch terminal 11 and smart entrance control unit terminals 20 and 58.</li> <li>b. Harness between lighting switch terminal 5 and ground.</li> </ol> </li> <li>6. Check smart entrance control unit. (EL-378)</li> </ol>
Exterior lamp battery saver control does not operate properly.	<ol style="list-style-type: none"> <li>1. Driver, passenger or rear door switch circuit</li> <li>2. Smart entrance control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check the following.               <ol style="list-style-type: none"> <li>a. Harness between smart entrance control unit and driver, passenger or rear door switch for open or short circuit.</li> <li>b. Driver passenger or rear door switch ground circuit.</li> <li>c. Driver, passenger or rear door switch.</li> </ol> </li> <li>2. Check smart entrance control unit. (EL-378)</li> </ol>
Auto light malfunctioning	—	Refer to trouble diagnosis in "HEADLAMP". (EL-40)






# STOP LAMP

Wiring Diagram — STOP/L —

## Wiring Diagram — STOP/L —

NAEL0278

EL-STOP/L-01



REFER TO THE FOLLOWING.

- (B1) -SUPER
- MULTIPLE JUNCTION (SMJ)
- (M10) -FUSE BLOC-
- JUNCTION BOX (J/B)



MEL777L

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# STOP LAMP

Wiring Diagram — STOP/L — (Cont'd)

EL-STOP/L-02



MEL262M


# BACK-UP LAMP

Wiring Diagram — BACK/L —

## Wiring Diagram — BACK/L —

NAEL0279


EL-BACK/L-01



- M : With M/T
- A : With A/T
- 2M : With M/T and 2-wheel drive
- 4M : With M/T and 4-wheel drive

Refer to EL-POWER.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS



REFER TO THE FOLLOWING.

- B1 -SUPER MULTIPLE JUNCTION (SMJ)
- M10 -FUSE BLOCK-JUNCTION BOX (J/B)

BT  
HA  
SC

EL

MEL006M

IDX

# FRONT FOG LAMP

System Description

## System Description

NAEL0280

NAEL0280S01

### OUTLINE

Power is supplied at all times

- to headlamp RH relay terminals 1 and 3
- through 15A fuse (No. 59, located in the fuse and fusible link box), and
- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 24, located in the fuse block (J/B)], and
- to front fog lamp relay terminal 3
- through 15A fuse (No. 53, located in the fuse and fusible link box).

When ignition switch is in ON or START position, power is supplied

- to smart entrance control unit terminal 27
- through 7.5A fuse [No. 11, located in the fuse block (J/B)].

When the ignition switch is in the ACC or ON position, power is supplied

- to smart entrance control unit terminal 26
- through 10A fuse [No. 10, located in the fuse block (J/B)].

Ground is supplied to smart entrance control unit terminals 43 and 64.

When lighting switch is in 2ND position, ground is supplied

- to headlamp RH relay terminal 2 from smart entrance control unit terminals 21 and 59.
- through smart entrance control unit terminals 22 and 60,
- through lighting switch terminal 12, and
- through body grounds E13 and E41.

Headlamp RH relay is then energized.

### FOG LAMP OPERATION

NAEL0280S02

The front fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position and LOW ("B") position for front fog lamp operation.

With the front fog lamp switch in the ON position, ground is supplied

- to front fog lamp relay terminal 1
- through the front fog lamp switch, lighting switch and body grounds E13 and E41.

The front fog lamp relay is energized and power is supplied

- from front fog lamp relay terminal 5
- to terminal 1 of each front fog lamp.

Ground is supplied to terminal 2 of each front fog lamp through body grounds E13 and E41.

With power and ground supplied, the front fog lamps illuminate.

### EXTERIOR LAMP BATTERY SAVER CONTROL

NAEL0280S03

Front fog lamps will remain on for a short while after the ignition switch is turned from ON (or ACC) to OFF. Continuity between terminals 21 and 22, and between terminals 59 and 60 of smart entrance control unit will be disturbed after 5 minutes, then the front fog lamps will be turned off.

When the lighting switch is turned from OFF to 2ND after front fog lamps are turned off by the battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then
- to headlamp RH relay terminal 2 from smart entrance control unit terminal 21
- through smart entrance control unit terminal 22 from lighting switch terminal 12.

Then the front fog lamps illuminate again.

### NOTE:

**For Trouble Diagnoses for battery saver control, refer to "HEADLAMP (FOR USA)", EL-40.**


# FRONT FOG LAMP

Wiring Diagram — F/FOG —

## Wiring Diagram — F/FOG —


NAEL0281

EL-F/FOG-01



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(M114) W



REFER TO THE FOLLOWING.

(E1) -SUPER  
MULTIPLE JUNCTION (SMJ)

(M10) -FUSE BLOCK-  
JUNCTION BOX (J/B)





MEL523P

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


# FRONT FOG LAMP

Wiring Diagram — F/FOG — (Cont'd)



MEL584P

NAEL0282




## Aiming Adjustment


Before performing aiming adjustment, make sure of the following.

- 1) Keep all tires inflated to correct pressure.
- 2) Place vehicle on level ground.
- 3) See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

Adjust aiming in the vertical direction by turning the adjusting screw.



1. Set the distance between the screen and the center of the fog lamp lens as shown at left.
2. Turn front fog lamps ON.



3. Adjust front fog lamps so that the top edge of the high intensity zone is 200 mm (7.9 in) below the height of the fog lamp centers as shown at left.
- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# TURN SIGNAL AND HAZARD WARNING LAMPS

System Description

## System Description

NAEL0283

### TURN SIGNAL OPERATION

NAEL0283S01

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 12, located in the fuse block (J/B)]
- to hazard switch terminal 2
- through terminal 1 of the hazard switch
- to combination flasher unit terminal 1
- through terminal 3 of the combination flasher unit
- to turn signal switch terminal 1.

Ground is supplied to combination flasher unit terminal 2 through body grounds M4, M66 and M147.

### LH Turn

NAEL0283S0101

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal 3 to

- front turn signal lamp LH terminal 2
- combination meter terminal 25
- rear combination lamp LH terminal 5.

Ground is supplied to the front turn signal lamp LH terminal 1 through body grounds E13 and E41.

Ground is supplied to the rear combination lamp LH terminal 6 through body grounds B11, B22 and D210.

Ground is supplied to combination meter terminal 30 through body grounds M4, M66 and M147.

With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

### RH Turn

NAEL0283S0102

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal 2 to

- front turn signal lamp RH terminal 3
- combination meter terminal 29
- rear combination lamp RH terminal 5.

Ground is supplied to the front turn signal lamp RH terminal 1 through body grounds E13 and E41.

Ground is supplied to the rear combination lamp RH terminal 6 through body grounds B55 and B75.

Ground is supplied to combination meter terminal 30 through body grounds M4, M66 and M147.

With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

### HAZARD LAMP OPERATION

NAEL0283S02

Power is supplied at all times to hazard switch terminal 3 through:

- 15A fuse [No. 20, located in the fuse block (J/B)].

With the hazard switch in the ON position, power is supplied

- through terminal 1 of the hazard switch
- to combination flasher unit terminal 1
- through terminal 3 of the combination flasher unit
- to hazard switch terminal 4.

Ground is supplied to combination flasher unit terminal 2 through body grounds M4, M66 and M147.

Power is supplied through terminal 5 of the hazard switch to

- front turn signal lamp LH terminal 3
- combination meter terminal 25
- rear combination lamp LH terminal 5.

Power is supplied through terminal 6 of the hazard switch to

- front turn signal lamp RH terminal 3
- combination meter terminal 29
- rear combination lamp RH terminal 5.

# TURN SIGNAL AND HAZARD WARNING LAMPS

System Description (Cont'd)

Ground is supplied to terminal 1 of each front turn signal lamp through body grounds E13 and E41.  
Ground is supplied to terminal 6 of the rear combination lamp LH through body grounds B11, B22 and D210.  
Ground is supplied to terminal 6 of the rear combination lamp RH through body grounds B55 and B75.  
Ground is supplied to combination meter terminal 30 through body grounds M4, M66 and M147.  
With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

GI

MA

EM

NAEL0283S03

## REMOTE KEYLESS ENTRY SYSTEM OPERATION

Power is supplied at all times

- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

LC

Ground is supplied to smart entrance control unit terminal 43 and 64.

Refer to "REMOTE KEYLESS ENTRY SYSTEM", EL-310.

EC

When smart entrance control unit receives LOCK or UNLOCK signal from keyfob with all doors closed, power is supplied

- through terminal 47 of smart entrance control unit
- to front turn signal lamp LH terminal 3
- to combination meter terminal 25
- to rear combination lamp LH terminal 5, and
- through terminal 48 of smart entrance control unit
- to front turn signal lamp RH terminal 3
- to combination meter terminal 29
- to rear combination lamp RH terminal 5.

FE

CL

MT

AT

Ground is supplied to terminal 1 of each front turn signal lamp through body grounds E13 and E41.

Ground is supplied to terminal 6 of the rear combination lamp LH through body grounds B11, B22 and D210.

Ground is supplied to terminal 6 of the rear combination lamp RH through body grounds B55 and B75.

Ground is supplied to combination meter terminal 30 through body grounds M4, M66 and M147.

With power and ground supplied, the smart entrance control unit controls the flashing of the hazard warning lamps.

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


# TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN —





## Wiring Diagram — TURN —

NAEL0284

EL-TURN-01



Next page



REFER TO THE FOLLOWING.




(M10) - FUSE BLOCK-  
JUNCTION BOX (J/B)

MEL861N

# TURN SIGNAL AND HAZARD WARNING LAMPS

Wiring Diagram — TURN — (Cont'd)

EL-TURN-02



REFER TO THE FOLLOWING.  
(E1), (B1) -SUPER  
MULTIPLE JUNCTION (SMJ)

MEL862N


# TURN SIGNAL AND HAZARD WARNING LAMPS

Trouble Diagnoses

## Trouble Diagnoses

NAEL0285

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> <li>1. Hazard switch</li> <li>2. Combination flasher unit</li> <li>3. Open in combination flasher unit circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check hazard switch.</li> <li>2. Refer to combination flasher unit check.</li> <li>3. Check wiring to combination flasher unit for open circuit.</li> </ol>
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> <li>1. 7.5A fuse</li> <li>2. Hazard switch</li> <li>3. Combination switch (turn signal)</li> <li>4. Open in combination switch (turn signal) circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse [No. 12, located in fuse block (J/B)]. Turn ignition switch ON and verify battery positive voltage is present at terminal 2 of hazard switch.</li> <li>2. Check hazard switch.</li> <li>3. Check combination switch (turn signal).</li> <li>4. Check the wire between combination flasher unit terminal 3 and combination switch (turn signal) terminal 1 for open circuit.</li> </ol>
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> <li>1. 15A fuse</li> <li>2. Hazard switch</li> <li>3. Open in hazard switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 15A fuse [No. 20, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 3 of hazard switch.</li> <li>2. Check hazard switch.</li> <li>3. Check the wire between combination flasher unit terminal 3 and hazard switch terminal 4 for open circuit.</li> </ol>
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds E13 and E41</li> <li>3. Open in front turn signal lamp circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds E13 and E41.</li> <li>3. Check harness between front turn signal lamp and combination switch.</li> </ol>
Rear combination lamp LH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds B11, B22 and D210</li> <li>3. Open in rear combination lamp LH circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds B11, B22 and D210.</li> <li>3. Check harness between rear combination lamp LH and hazard switch.</li> </ol>
Rear combination lamp RH does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Grounds B55 and B75</li> <li>3. Open in rear combination lamp RH circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb.</li> <li>2. Check grounds B55 and B75.</li> <li>3. Check harness between rear combination lamp RH and hazard switch.</li> </ol>
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> <li>1. Ground</li> </ol>	<ol style="list-style-type: none"> <li>1. Check grounds M4, M66 and M147.</li> </ol>
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> <li>1. Bulb</li> <li>2. Open in turn indicator circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check bulb in combination meter.</li> <li>2. Check harness between combination meter and hazard switch.</li> </ol>



## Electrical Components Inspection COMBINATION FLASHER UNIT CHECK

NAEL0286

NAEL0286S01

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

## System Description

NAEL0287

The illumination lamp operation is controlled by the lighting switch which is built into the combination switch and smart entrance control unit. The battery saver system is controlled by smart entrance control unit. Power is supplied at all times

- to tail lamp relay terminals 1 and 3
- through 10A fuse (No. 61, located in the fuse and fusible link box), and
- to smart entrance control unit terminal 49
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

When ignition switch is in ON or START position, power is supplied

- to smart entrance control unit terminal 27
- through 7.5A fuse [No. 11, located in the fuse block (J/B)], and

When the ignition switch is in ACC or ON position, power is supplied

- to smart entrance control unit terminal 26
- through 10A fuse [No. 10, located in the fuse block (J/B)].

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M77 and M111.

### LIGHTING OPERATION BY LIGHTING SWITCH

NAEL0287S01

When lighting switch is 1ST (or 2ND) position, ground is supplied

- to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57
- through smart entrance control unit terminals 20 and 58, and
- through lighting switch and body grounds E13 and E41.

Tail lamp relay is then energized and illumination lamps illuminate.

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The ground for all of the components except for grove box lamp, ashtray and compass and thermometer are controlled through terminals 2 and 3 of the illumination control switch and body grounds M77 and M111.

### LIGHTING OPERATION BY AUTO LIGHT CONTROL SYSTEM

NAEL0287S02

When auto light operation is operated, ground is supplied

- to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57
- through smart entrance control unit terminals 43 and 64, and
- to body grounds M77 and M111.

Tail lamp relay is then energized and the illumination lamps illuminate.

The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Connector No.	Power terminal	Ground terminal
Illumination control switch	M19	1	3
4WD shift switch	M141	7	8
Ashtray	B76	1	2
A/T indicator	B59	3	4
Cigarette lighter	M57	3	4
Audio unit	M48	8	7
Compass and thermometer	R4	5	2
Hazard switch	M35	7	8
Rear window defogger switch	M36	5	6

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# ILLUMINATION

## System Description (Cont'd)

Component	Connector No.	Power terminal	Ground terminal
CD player	M92, M93	3	5
CD auto changer	M125	2	9
A/C switch illumination	M45	2	1
Power window main switch	D6	16	18
Front power window switch RH	D36	10	17
Display & NAVI control unit	M117, M118	8	24
A/C auto amp.	M102	24	25
Clock	M40	3	4
Globe box lamp	M30	1	2

The ground for all of the components except for compass and thermometer, glove box lamp and ashtray are controlled through terminals 2 and 3 of the illumination control switch and body grounds M77 and M111.

## EXTERIOR LAMP BATTERY SAVER CONTROL

NAEL0287S03

### Except for Auto Light Control Operation

NAEL0287S0301

Illumination lamps will remain on for a short while after the ignition switch is turned from ON (or ACC) to OFF. Continuity between terminals 19 and 20, and between terminals 57 and 58 of smart entrance control unit will be disturbed after 5 minutes, then the illumination lamp will be turned off.

When the lighting switch is turned from OFF to 1ST (or 2ND) after illumination lamps are turned off by the battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and
- to tail lamp relay terminal 2 from smart entrance control unit terminals 19 and 57.

Then illumination lamps illuminate again.

### Auto light control operation

NAEL0287S0302

While the illumination lamps are turned ON by "AUTO" operation, the exterior lamp battery saver is activated for 5 minutes when the ignition switch is turned from ON (or ACC) to OFF, and either LH or RH front door switch is opened.

The smart entrance control unit controls exterior lamp battery saver activation as follows:

- When the door switch signal changes from ON to OFF while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the illumination lamps will be turned off.
- When the door switch signal changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the illumination lamps will be turned off.
- When the one of four door switch signals changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 5 minutes seconds, then the illumination lamps will be turned off.
- When all the door switch ON signals are input while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the illumination lamps will be turned off.
- Exterior battery saver control time can be changed using "WORK SUPPORT" mode in "HEADLAMP".

When the lighting switch is turned from OFF to 2ND after illumination lamps are turned to off by the exterior lamp battery saver control, ground is supplied

- to smart entrance control unit terminals 20 and 58 from lighting switch terminal 11, and then,
- to tail lamp relays terminal 2 from smart entrance control unit terminals 21 and 59,
- through smart entrance control unit terminals 22 and 60 and
- through lighting switch terminal 12.

Then illumination lamps illuminate again.

### NOTE:


For Trouble Diagnoses for battery saver control, refer to "PARKING, LICENSE AND TAIL LAMPS" (EL-69).

# ILLUMINATION

Schematic

NAEL0288

## Schematic



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



# ILLUMINATION

Wiring Diagram — ILL —

## Wiring Diagram — ILL —

NAEL0289

EL-ILL-01



REFER TO THE FOLLOWING.

(M10) - FUSE BLOCK-  
JUNCTION BOX (J/B)





MEL400P

# ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-02



REFER TO THE FOLLOWING.

(E1) -SUPER MULTIPLE

JUNCTION (SMJ)

(M10) , (E3) -FUSE BLOCK-

JUNCTION BOX (J/B)

MEL405P

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



# ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

## EL-ILL-04




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

AA : With auto A/C

NV : With navigation system

WC : With CD auto changer

ON : Without navigation system





MEL401P

# ILLUMINATION

Wiring Diagram — ILL — (Cont'd)

EL-ILL-05



REFER TO THE FOLLOWING.  
 (M91) - FUSE BLOCK-  
 JUNCTION BOX (J/B)

MEL402P



# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

System Description

## System Description

NAEL0290

NAEL0290S01

### POWER SUPPLY AND GROUND

Power is supplied at all times:

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to key switch terminal 2 and
- to smart entrance control unit terminal 49.

When the key is removed from ignition key cylinder, power is interrupted:

- through key switch terminal 1
- to smart entrance control unit terminal 25.

With the ignition key switch in the ON or START position, power is supplied:

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27.

Ground is supplied:

- to smart entrance control unit terminals 43 and 64
- through body grounds terminals M77 and M111.

When the front driver side door is opened, ground is supplied:

- through body grounds B11, B22 and D210
- to front door switch (LH) terminal 2
- from front door switch (LH) terminal 1
- to smart entrance control unit terminal 1.

When the front passenger side door is opened, ground is supplied:

- through body grounds terminals B55 and B75
- to front door switch (RH) terminal 2
- from front door switch (RH) terminal 1
- to smart entrance control unit terminal 2.

When any other door (except front door) is opened, ground is supplied to smart entrance control unit terminal 3 in the same manner as the front door switch.

When the front driver side door is unlocked by the central switch, the smart entrance control unit receives a ground signal:

- through body grounds terminals M77 and M111 (LH) or M4, M66 and M147 (RH)
- to door lock and unlock switch terminal 5 (LH) or 7 (RH)
- from door lock and unlock switch terminal 19 (LH) or 18 (RH)
- to smart entrance control unit terminal 4.

When the front LH door is unlocked by the front door key cylinder switch and back door key cylinder switch, the smart entrance control unit receives a ground signal:

- through body grounds terminals M77 and M111
- to front door key cylinder switch LH terminal 2
- from front door key cylinder switch LH terminal 1
- to smart entrance control unit terminal 10, and
- through body grounds terminals B11, B22 and D210
- to back door key cylinder switch terminal 4
- from back door key cylinder switch terminal 2
- to smart entrance control unit terminal 10.

When a signal, or combination of signals is received by the smart entrance control unit, ground is supplied:

- through smart entrance control unit terminal 31
- to interior lamp terminal 2.

With power and ground supplied, the interior lamp illuminates.

### SWITCH OPERATION

When interior lamp switch is ON, ground is supplied:

- through case grounds of interior lamp
- to interior lamp.

NAEL0290S02

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

System Description (Cont'd)

And power is supplied:

- to interior lamp terminal 1
- from smart entrance control unit terminal 50.

When spot lamp (LH and/or RH) is ON, ground is supplied:

- through body grounds M4, M66 and M147
- to spot lamp terminal 2.

And power is supplied:

- to spot lamp terminal 1
- from smart entrance control unit terminal 50.

When vanity mirror illumination (LH and/or RH) is ON, ground is supplied:

- through body grounds M4, M66 and M147
- to vanity mirror illuminations (LH and RH) terminals 2.

And power is supplied:

- to vanity mirror illuminations (LH and RH) terminals 1
- from smart entrance control unit terminal 50.

With power and ground supplied, interior lamps turn ON.

## INTERIOR LAMP TIMER OPERATION

When interior lamp switch is in the "DOOR" position, the smart entrance control unit keeps the interior lamp illuminated for about 30 seconds when:

- unlock signal is supplied from door lock and unlock switch while all doors are closed and key is out of ignition key cylinder
- unlock signal is supplied from keyfob or door key cylinder while driver's door is locked and all doors are closed
- key is removed from ignition key cylinder while all doors are closed
- driver's door is opened and then closed while key is out of the ignition key cylinder. (However, if the driver's door is closed with the key inserted in the ignition key cylinder after the driver's door is opened with the key removed, the timer is operated.)

The timer is canceled when:

- driver's door is locked,
- driver's door is opened, or
- ignition switch is turned ON.

When driver's door is locked, interior room lamp timer is canceled as described before.

## ON-OFF CONTROL

When the driver side door, front passenger door, rear LH or RH door is opened, the interior room lamp turns on while the interior room lamp switch is in the "DOOR" position.

## INTERIOR LAMP BATTERY SAVER

The lamp turns off automatically when interior lamp, luggage room lamp, spot lamp and/or vanity mirror illumination is illuminated with the ignition key is in OFF position, if the lamp remains lit by the door switch open signal or if the lamp switch is in ON position for more than 30 minutes.

After lamps turn OFF by the battery saver system, the lamps illuminate again when:

- driver's door is locked or unlocked,
- door is opened or closed,
- key is removed from ignition key cylinder or inserted in ignition key cylinder

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Schematic

## Schematic

NAEL0291



MEL407P



# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L —

## Wiring Diagram — INT/L —

NAEL0292

EL-INT/L-01







REFER TO THE FOLLOWING.  
 (E1), (B1) -SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (M10), (E3) -FUSE BLOCK-  
 JUNCTION BOX (J/B)

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
 EL  
 IDX

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)

EL-INT/L-02





REFER TO THE FOLLOWING.

(B1) -SUPER MULTIPLE JUNCTION (SMJ)

MEL713N

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)











REFER TO THE FOLLOWING.  
 (B1) -SUPER MULTIPLE JUNCTION (SMJ)

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
**EL**  
 IDX

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS


Wiring Diagram — INT/L — (Cont'd)

EL-INT/L-04



# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Wiring Diagram — INT/L — (Cont'd)




EL-INT/L-05

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST

RS  
BT  
HA  
SC

EL

IDX




REFER TO THE FOLLOWING.

(B1) - SUPER MULTIPLE JUNCTION (SMJ)

MEL410P

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

CONSULT-II Inspection Procedure




## CONSULT-II Inspection Procedure

=NAEL0293


NAEL0293S01

### "INT LAMP"/"BATTERY SAVER"


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "SMART ENTRANCE".



6. Touch "INT LAMP" or "BATTERY SAVER".



7. Select diagnosis mode.  
"DATA MONITOR" and "ACTIVE TEST" are available for "INT LAMP" and "BATTERY SAVER".

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

CONSULT-II Application Items

## CONSULT-II Application Items

NAEL0294

NAEL0294S01

NAEL0294S0101

### “INT LAMP” Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-RR	Indicates [ON/OFF] condition of ignition switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
LOCK SW DR/AS	Indicates [ON/OFF] condition of front door lock switch.
UNLK SW DR/AS	Indicates [ON/OFF] condition of front door lock switch.
KEY CYL LK-SW	Indicates [ON/OFF] condition of front door key cylinder switch.
KEY CYL UN-SW	Indicates [ON/OFF] condition of front door key cylinder switch.
LK BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.

### Active Test

NAEL0294S0102

Test Item	Description
INT LAMP	This test enables to check interior lamp operation. When “ON” on CONSULT-II screen is touched: <ul style="list-style-type: none"> <li>Interior lamp turns on when the switch is at DOOR. (Smart entrance control unit supplies power and ground to interior lamp.)</li> </ul>
IGN ILLUM	This test enables to check ignition key hole illumination operation. The illumination turns on when “ON” on CONSULT-II screen is touched.
STEP LAMP	This test enables to check step lamp operation. The illumination turns on when “ON” on CONSULT-II screen is touched.

#### NOTE:

Even though ignition key hole illumination and step lamp are actually displayed on the CONSULT-II screen, those are not equipped, therefore, they cannot be activated.

### Work Support

NAEL0294S0103

Work Item	Description
ROOM LAMP TIMER SET	Interior lamp timer mode can be changed by mode setting. Selects ON-OFF of the room lamp illumination at the time the driver door is unlocked. <b>NOTE:</b> Even though ignition keyhole illumination and step lamp are actually displayed on the CONSULT-II screen, those are not equipped, therefore, they cannot be activated.

### “BATTERY SAVER” Data Monitor

NAEL0294S02

NAEL0294S0201

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-RR	Indicates [ON/OFF] condition of ignition switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

CONSULT-II Application Items (Cont'd)

Monitored Item	Description
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
LOCK SW DR/AS	Indicates [ON/OFF] condition of front door lock switch.
UNLK SW DR/AS	Indicates [ON/OFF] condition of front door lock switch.
KEY CYL LK-SW	Indicates [ON/OFF] condition of front door key cylinder switch.
KEY CYL UN-SW	Indicates [ON/OFF] condition of front door key cylinder switch.
LK BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.

## Active Test

NAEL0294S0202

Test Item	Description
BATTERY SAVER	<p>This test enables to check interior lamp and spot lamp and vanity mirror illuminations operations.</p> <p>When touch "ON" on CONSULT-II screen.</p> <ul style="list-style-type: none"><li>● Interior lamp turns on when the switch is in ON. (Smart entrance control unit supplies power to interior lamp.)</li><li>● Spot lamp and vanity mirror illuminations turn on when the switch is in ON. (Smart entrance control unit supplies power to spot lamp, and vanity mirror illuminations.)</li></ul>

## Work Support

NAEL0294S0203

Work Item	Description
ROOM LAMP BAT SAV SET	<p>Interior lamp battery saver control period can be changed by mode setting. Selects interior lamp battery saver control period between two modes.</p> <ul style="list-style-type: none"><li>● MODE 1 (30 minutes)/MODE 2 (60 minutes)</li></ul>

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer


## Trouble Diagnoses for Interior Lamp Timer

=NAEL0295

### DIAGNOSTIC PROCEDURE 1

NAEL0295S01


**SYMPTOM: Interior lamp timer does not operate.**


<b>1</b>	<b>CHECK IGNITION ON SIGNAL</b>																
<p> <b>With CONSULT-II</b> Check ignition switch ON signal ("IGN ON SW") in "DATA MONITOR" mode with CONSULT-II.</p>																	
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th></th> </tr> </thead> <tbody> <tr> <td>IGN ON SW</td> <td>ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR		IGN ON SW	ON									
DATA MONITOR																	
MONITOR																	
IGN ON SW	ON																
<p>When ignition switch is ON: <b>IGN ON SW ON</b></p> <p>When ignition switch is OFF: <b>IGN ON SW OFF</b></p>																	
SEL318W																	
<p> <b>Without CONSULT-II</b> Check voltage between smart entrance control unit harness connector M122 terminal 27 (W/G) and ground.</p>																	
<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;">  <p>Smart entrance control unit connector</p>  </div> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">Terminals</th> <th colspan="3">Ignition switch position</th> </tr> <tr> <th>(+)</th> <th>(-)</th> <th>OFF</th> <th>ACC</th> <th>ON</th> </tr> </thead> <tbody> <tr> <td>27</td> <td>Ground</td> <td>0V</td> <td>0V</td> <td>Battery voltage</td> </tr> </tbody> </table> </div>			Terminals		Ignition switch position			(+)	(-)	OFF	ACC	ON	27	Ground	0V	0V	Battery voltage
Terminals		Ignition switch position															
(+)	(-)	OFF	ACC	ON													
27	Ground	0V	0V	Battery voltage													
SEL003Y																	
<b>OK or NG</b>																	
OK	▶	GO TO 2.															
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 11, located in fuse block (J/B)]</li> <li>● Harness for open or short between smart entrance control unit and fuse</li> </ul>															

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS


Trouble Diagnoses for Interior Lamp Timer (Cont'd)


<b>2</b>	<b>CHECK FRONT LH DOOR SWITCH INPUT SIGNAL</b>						
<p> <b>With CONSULT-II</b> Check driver door switch signal ("DOOR SW-DR") in "DATA MONITOR" mode with CONSULT-II.</p>							
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>DOOR SW-DR</td><td>OFF</td></tr> </table>		DATA MONITOR		MONITOR		DOOR SW-DR	OFF
DATA MONITOR							
MONITOR							
DOOR SW-DR	OFF						
<p>When front LH door is open: <b>DOOR SW-DR ON</b></p> <p>When driver's door is closed: <b>DOOR SW-DR OFF</b></p>							
SEL319WA							
<p> <b>Without CONSULT-II</b> Check voltage between smart entrance control unit harness connector M121 terminal 1 (G/R) and ground.</p>							
<p>Smart entrance control unit connector</p> 							
<p><b>Voltage [V]:</b> Condition of driver's door: <b>CLOSED</b> Approx. 5 Condition of driver's door: <b>OPENED</b> 0</p>							
SEL004Y							
<b>OK or NG</b>							
OK	▶ GO TO 4.						
NG	▶ GO TO 3.						

<b>3</b>	<b>CHECK FRONT LH DOOR SWITCH</b>
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Continuity between front LH door switch connector B9 terminals 1 and 2</li> <li>● Continuity between front LH door switch B9 terminal 3 and ground</li> </ul>	
<p>Front door switch LH</p> 	
<p><b>Continuity:</b> Door switch is pushed. No Door switch is released. Yes</p>	
SEL277Y	
<b>OK or NG</b>	
OK	▶ <b>Check the following.</b>
<ul style="list-style-type: none"> <li>● Front LH door switch ground circuit and condition</li> <li>● Harness for open or short between smart entrance control unit and front LH door switch</li> </ul>	
NG	▶ Replace front LH door switch.

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)


<b>4</b>	<b>CHECK FRONT RH DOOR SWITCH INPUT SIGNAL</b>							
<p> <b>With CONSULT-II</b> Check driver door switch signal ("DOOR SW-AS") in "DATA MONITOR" mode with CONSULT-II.</p>								
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>DOOR SW-AS</td><td>OFF</td></tr> </table>			DATA MONITOR		MONITOR		DOOR SW-AS	OFF
DATA MONITOR								
MONITOR								
DOOR SW-AS	OFF							
<p>When front RH door is open: <b>DOOR SW-AS ON</b></p> <p>When driver's door is closed: <b>DOOR SW-AS OFF</b></p>								
SEL153Y								
<p> <b>Without CONSULT-II</b> Check voltage between smart entrance control unit harness connector M121 terminal 2 (Y) and ground.</p>								
<div style="display: flex; align-items: center;"> <div style="flex: 1;"> <p style="text-align: center;">Smart entrance control unit connector</p>  </div> <div style="flex: 1; text-align: center;">  </div> <div style="flex: 1;"> <p><b>Voltage [V]:</b></p> <p>Condition of front RH door: <b>CLOSED</b> Approx. 5</p> <p>Condition of front RH door: <b>OPENED</b> 0</p> </div> </div>								
OK or NG								
OK	▶	GO TO 6.						
NG	▶	GO TO 5.						


<b>5</b>	<b>CHECK FRONT RH DOOR SWITCH</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Continuity between front RH door switch connector B68 terminals 1 and 2</li> <li>● Continuity between front RH door switch connector B68 terminal 3 and ground</li> </ul>		
<div style="display: flex; align-items: center;"> <div style="flex: 1;"> <p style="text-align: center;">Front door switch RH</p>  </div> <div style="flex: 1; text-align: center;">  </div> <div style="flex: 1;"> <p><b>Continuity:</b></p> <p>Door switch is pushed. No</p> <p>Door switch is released. Yes</p> </div> </div>		
OK or NG		
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Front RH door switch ground circuit and condition</li> <li>● Harness for open or short between smart entrance control unit and front RH door switch</li> </ul>
NG	▶	Replace front RH door switch.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS


Trouble Diagnoses for Interior Lamp Timer (Cont'd)


<b>6</b>	<b>CHECK REAR AND BACK DOOR SWITCHES INPUT SIGNAL</b>							
<p> <b>With CONSULT-II</b> Check door switches ("DOOR SW-RR") in "DATA MONITOR" mode with CONSULT-II.</p>								
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>DOOR SW-RR</td><td>OFF</td></tr> </table>			DATA MONITOR		MONITOR		DOOR SW-RR	OFF
DATA MONITOR								
MONITOR								
DOOR SW-RR	OFF							
		<p>When rear door LH,RH and/or back is open: <b>DOOR SW-RR ON</b></p> <p>When driver's door is closed: <b>DOOR SW-RR OFF</b></p>						
SEL154YA								
<p> <b>Without CONSULT-II</b> Check voltage between smart entrance control unit harness connector M121 terminal 3 (R/L) and ground.</p>								
<p>Smart entrance control unit connector</p> 								
		<p><b>Voltage [V]:</b> Condition of rear LH and/or RH door: <b>CLOSED</b> Approx. 5 Condition of rear LH and/or RH door: <b>OPENED</b> 0</p>						
SEL155Y								
<b>OK or NG</b>								
OK	▶	GO TO 8.						
NG	▶	GO TO 7.						

<b>7</b>	<b>CHECK REAR AND BACK DOOR SWITCHES</b>	
<p>1. Disconnect door switch harness connector. 2. Check the following.</p> <ul style="list-style-type: none"> <li>● Continuity between rear door switches connector B18 and B71 terminal 1 and ground</li> <li>● Continuity between back door switch connector D208 terminals 1 and 2</li> </ul>		
<p>Rear door switch connector      Back door switch connector</p> 		
		<p><b>Continuity:</b> Door switch is pushed. No Door switch is released. Yes</p>
SEL279Y		
<b>OK or NG</b>		
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Rear LH, RH and/or back door switch ground circuit or door switch ground condition</li> <li>● Harness for open or short between smart entrance control unit and rear LH, RH and/or back door switch</li> </ul>
NG	▶	Replace rear LH, RH and/or back door switch.

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS



Trouble Diagnoses for Interior Lamp Timer (Cont'd)

<b>8</b>	<b>CHECK KEY SWITCH INPUT SIGNAL</b>	<p><b>Ⓟ With CONSULT-II</b> Check key switch ("KEY ON SW") in "DATA MONITOR" mode with CONSULT-II.</p> <div style="display: flex; align-items: flex-start;"> <table border="1" style="margin-right: 20px;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th></th> </tr> </thead> <tbody> <tr> <td>KEY ON SW</td> <td>ON</td> </tr> </tbody> </table> <div style="margin-top: 10px;"> <p>When key is inserted to ignition key cylinder: <b>KEY ON SW ON</b></p> <p>When key is removed from ignition key cylinder: <b>KEY ON SW OFF</b></p> </div> </div> <p style="text-align: right; font-size: small;">SEL315W</p>	DATA MONITOR		MONITOR		KEY ON SW	ON	GI MA EM LC EC FE
DATA MONITOR									
MONITOR									
KEY ON SW	ON								
<p><b>⊗ Without CONSULT-II</b> Check voltage between smart entrance control unit harness connector M122 terminal 25 (W/R) and ground.</p> <p>Smart entrance control unit connector</p> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p><b>Voltage [V]:</b></p> <p><b>Condition of key switch: Key is inserted.</b> <b>Approx. 12</b></p> <p><b>Condition of key switch: Key is removed.</b> <b>0</b></p> </div> </div> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p> <p style="text-align: right; font-size: small;">SEL011Y</p>		CL MT AT TF PD							
OK	▶	GO TO 10.							
NG	▶	GO TO 9.							

<b>9</b>	<b>CHECK KEY SWITCH (INSERT)</b>	<p>Check continuity between terminals 1 and 2.</p> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;"> <p><b>Continuity:</b></p> <p><b>Condition of key switch: Key is inserted.</b> <b>Yes</b></p> <p><b>Condition of key switch: Key is removed.</b> <b>No</b></p> </div> </div> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p> <p style="text-align: right; font-size: small;">SEL308X</p>	SU BR ST RS BT HA
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 24, located in fuse block (J/B)]</li> <li>● Harness for open or short between key switch and fuse</li> <li>● Harness for open or short between smart entrance control unit and key switch</li> </ul>	SC
NG	▶	Replace key switch.	<b>EL</b>



# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

<b>10</b>	<b>CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL</b>													
<p> <b>With CONSULT-II</b>                  Check door lock/unlock switch (“LOCK SW DR/AS”/“UNLK SW DR/AS”) in “DATA MONITOR” mode with CONSULT-II.</p>														
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>LOCK SW DR/AS</td><td>OFF</td></tr> <tr><td>UNLK SW DR/AS</td><td>OFF</td></tr> </table>		DATA MONITOR		MONITOR		LOCK SW DR/AS	OFF	UNLK SW DR/AS	OFF					
DATA MONITOR														
MONITOR														
LOCK SW DR/AS	OFF													
UNLK SW DR/AS	OFF													
<p>When lock/unlock switch is turned to LOCK:  <b>LOCK SW DR/AS ON</b></p> <p>When lock/unlock switch is turned to UNLOCK:  <b>UNLK SW DR/AS ON</b></p>														
SEL341W														
<p> <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Disconnect smart entrance control unit harness connector .</li> <li>2. Check continuity between smart entrance control unit harness connector M121 terminal 4 (LG/R) or 5 (BR) and ground.</li> </ol>														
<div style="display: flex; align-items: center; justify-content: space-around;"> <div style="text-align: center;"> <p>Smart entrance control unit connector</p>  </div> <div style="text-align: center;">  </div> </div>														
<table border="1" style="margin: auto;"> <thead> <tr> <th>Terminals</th> <th>Door lock/unlock switch (LH or RH) condition</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">4 - Ground</td> <td>Lock</td> <td>Yes</td> </tr> <tr> <td>N and Unlock</td> <td>No</td> </tr> <tr> <td rowspan="2">5 - Ground</td> <td>Unlock</td> <td>Yes</td> </tr> <tr> <td>N and Lock</td> <td>No</td> </tr> </tbody> </table>		Terminals	Door lock/unlock switch (LH or RH) condition	Continuity	4 - Ground	Lock	Yes	N and Unlock	No	5 - Ground	Unlock	Yes	N and Lock	No
Terminals	Door lock/unlock switch (LH or RH) condition	Continuity												
4 - Ground	Lock	Yes												
	N and Unlock	No												
5 - Ground	Unlock	Yes												
	N and Lock	No												
SEL157Y														
<b>OK or NG</b>														
OK	▶ GO TO 12.													
NG	▶ GO TO 11.													

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

11	CHECK DOOR LOCK/UNLOCK SWITCH																																						
	<p>1. Disconnect door lock/unlock switch harness connector.</p> <p>2. Check continuity between each door lock/unlock switch terminals.</p> <ul style="list-style-type: none"> <li>Power window main switch (Door lock/unlock switch connector)</li> </ul> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>P/W main switch connector</p> </div> <div> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th rowspan="2">Condition</th> <th colspan="3">Terminals</th> </tr> <tr> <th>5</th> <th>19</th> <th>6</th> </tr> </thead> <tbody> <tr> <td>Lock</td> <td style="text-align: center;">○</td> <td style="text-align: center;">—</td> <td style="text-align: center;">○</td> </tr> <tr> <td>N</td> <td colspan="3" style="text-align: center;">No continuity</td> </tr> <tr> <td>Unlock</td> <td style="text-align: center;">○</td> <td style="text-align: center;">—</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right; margin-right: 20px;">SEL310X</p> <ul style="list-style-type: none"> <li>Door lock/unlock switch RH connector</li> </ul> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Lock/unlock switch RH connector</p> </div> <div> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th rowspan="2">Condition</th> <th colspan="3">Terminals</th> </tr> <tr> <th>7</th> <th>18</th> <th>8</th> </tr> </thead> <tbody> <tr> <td>Lock</td> <td style="text-align: center;">○</td> <td style="text-align: center;">—</td> <td style="text-align: center;">○</td> </tr> <tr> <td>N</td> <td colspan="3" style="text-align: center;">No continuity</td> </tr> <tr> <td>Unlock</td> <td style="text-align: center;">○</td> <td style="text-align: center;">—</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right; margin-right: 20px;">SEL311X</p> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p>	Condition	Terminals			5	19	6	Lock	○	—	○	N	No continuity			Unlock	○	—	○	Condition	Terminals			7	18	8	Lock	○	—	○	N	No continuity			Unlock	○	—	○
Condition	Terminals																																						
	5	19	6																																				
Lock	○	—	○																																				
N	No continuity																																						
Unlock	○	—	○																																				
Condition	Terminals																																						
	7	18	8																																				
Lock	○	—	○																																				
N	No continuity																																						
Unlock	○	—	○																																				
OK	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>Ground circuit for door lock/unlock switch</li> <li>Harness for open or short between door lock/unlock switch and smart entrance control unit connector</li> </ul>																																						
NG	<p>▶ Replace door lock/unlock switch.</p>																																						

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

## 12 CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

### With CONSULT-II

Check front door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

When key inserted in front key cylinder is turned to LOCK:

**KEY CYL LK-SW ON**

When key inserted in front key cylinder is turned to UNLOCK:


**KEY CYL UN-SW ON**

SEL342W


### Without CONSULT-II

Check voltage between smart entrance control unit harness connector M121 terminals 10 (LG) or 11 (Y) and ground.


Front door LH



Smart entrance control unit connector



Back door



Door	Terminals		Key position	Voltage V
	(+)	(-)		
Front door LH	11	Ground	Neutral/Unlock	Approx. 5
			Lock	0
	10	Ground	Neutral/Lock	Approx. 5
			Unlock	0
Back door	11	Ground	Between neutral and lock	0
			Other positions	Approx. 5
	10	Ground	Between neutral and unlock	0
			Other positions	Approx. 5



SEL280Y

**OK or NG**

OK	▶	Replace smart entrance control unit.
NG	▶	GO TO 13.

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

13	CHECK DOOR KEY CYLINDER SWITCH																												
	<p>1. Disconnect door key cylinder switch harness connector.                      2. Check continuity between each key cylinder switch terminals.</p> <ul style="list-style-type: none"> <li>● Front door key cylinder switch harness connector D9</li> </ul> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Front door key cylinder switch connector</p> </div> <div style="text-align: left;"> <p>① : Door unlock switch terminal                      ② : Ground terminal                      ③ : Door lock switch terminal</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">③ - ②</td> <td>Neutral/Unlock</td> <td>No</td> </tr> <tr> <td>Lock</td> <td>Yes</td> </tr> <tr> <td rowspan="2">① - ②</td> <td>Neutral/Lock</td> <td>No</td> </tr> <tr> <td>Unlock</td> <td>Yes</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL187YA</p> <ul style="list-style-type: none"> <li>● Back door key cylinder switch harness connector D201</li> </ul> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Back door key cylinder switch (D201)</p> </div> <div style="text-align: left;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Key position</th> <th colspan="3">Terminals</th> </tr> <tr> <th>1</th> <th>2</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>Between neutral and lock (Back door)</td> <td style="text-align: center;">○</td> <td></td> <td style="text-align: center;">○</td> </tr> <tr> <td>Between neutral and unlock (Back door)</td> <td></td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL315X</p> <p style="text-align: center;"><b>OK or NG</b></p>	Terminals	Key position	Continuity	③ - ②	Neutral/Unlock	No	Lock	Yes	① - ②	Neutral/Lock	No	Unlock	Yes	Key position	Terminals			1	2	4	Between neutral and lock (Back door)	○		○	Between neutral and unlock (Back door)		○	○
Terminals	Key position	Continuity																											
③ - ②	Neutral/Unlock	No																											
	Lock	Yes																											
① - ②	Neutral/Lock	No																											
	Unlock	Yes																											
Key position	Terminals																												
	1	2	4																										
Between neutral and lock (Back door)	○		○																										
Between neutral and unlock (Back door)		○	○																										
OK	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Front or back door key cylinder switch ground circuit</li> <li>● Harness for open or short between front or back door key cylinder switch and smart entrance control unit connector</li> </ul>																												
NG	<p>▶ Replace front or back door key cylinder switch.</p>																												

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

## DIAGNOSTIC PROCEDURE 2



NAEL0295S02


**SYMPTOM: Interior lamp timer does not cancel properly.**

<b>1</b>	<b>CHECK IGNITION ON SIGNAL</b>																
<p> <b>With CONSULT-II</b> Check ignition switch ON signal ("IGN ON SW") in "DATA MONITOR" mode with CONSULT-II.</p>																	
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th></th> </tr> </thead> <tbody> <tr> <td>IGN ON SW</td> <td>ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR		IGN ON SW	ON									
DATA MONITOR																	
MONITOR																	
IGN ON SW	ON																
<p>When ignition switch is ON: <b>IGN ON SW ON</b></p> <p>When ignition switch is OFF: <b>IGN ON SW OFF</b></p>																	
SEL318W																	
<p> <b>Without CONSULT-II</b> Check voltage between smart entrance control unit harness connector M122 terminal 27 (W/B) and ground.</p>																	
<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;">  </div> <div style="margin-right: 20px;"> <p>Smart entrance control unit connector</p>  </div> <div style="margin-right: 20px;">  </div> <div> <table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">Terminals</th> <th colspan="3">Ignition switch position</th> </tr> <tr> <th>(+)</th> <th>(-)</th> <th>OFF</th> <th>ACC</th> <th>ON</th> </tr> </thead> <tbody> <tr> <td>27</td> <td>Ground</td> <td>0V</td> <td>0V</td> <td>Battery voltage</td> </tr> </tbody> </table> </div> </div>			Terminals		Ignition switch position			(+)	(-)	OFF	ACC	ON	27	Ground	0V	0V	Battery voltage
Terminals		Ignition switch position															
(+)	(-)	OFF	ACC	ON													
27	Ground	0V	0V	Battery voltage													
SEL995X																	
<b>OK or NG</b>																	
OK	▶	GO TO 2.															
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 11, located in fuse block (J/B)]</li> <li>● Harness for open or short between smart entrance control unit and fuse</li> </ul>															

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

<b>2</b>	<b>CHECK FRONT LH DOOR SWITCH INPUT SIGNAL</b>		GI
<p> <b>With CONSULT-II</b>                  Check driver door switch signal ("DOOR SW-DR") in "DATA MONITOR" mode with CONSULT-II.</p>			
		<p>When front LH door is open:  <b>DOOR SW-DR ON</b></p> <p>When driver's door is closed:  <b>DOOR SW-DR OFF</b></p>	
SEL319WA			
<p> <b>Without CONSULT-II</b>                  Check voltage between smart entrance control unit harness connector M121 terminal 1 (G/R) and ground.</p>			
<p>Smart entrance control unit connector</p> 		<p><b>Voltage [V]:</b>                  Condition of driver's door: <b>CLOSED</b>                  Approx. 5                  Condition of driver's door: <b>OPENED</b>                  0</p>	
OK or NG			
OK		▶	GO TO 4.
NG		▶	GO TO 3.

<b>3</b>	<b>CHECK FRONT LH DOOR SWITCH</b>		MA
<p>Check continuity between door switch connector B9 terminals 1 and 2.</p>			
<p>Front door switch LH</p> 		<p><b>Continuity:</b>                  Door switch is pushed.                  No                  Door switch is released.                  Yes</p>	
SEL277Y			
OK or NG			
OK		▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Front LH door switch ground circuit and condition</li> <li>● Harness for open or short between smart entrance control unit and front LH door switch</li> </ul>
NG		▶	Replace front LH door switch.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

## 4 CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

### With CONSULT-II

Check door lock/unlock switch ("LOCK SW DR/AS"/"UNLK SW DR/AS") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
LOCK SW DR/AS	OFF
UNLK SW DR/AS	OFF

When lock/unlock switch is turned to LOCK:

**LOCK SW DR/AS ON**

When lock/unlock switch is turned to UNLOCK:



**UNLK SW DR/AS ON**

SEL341W

### Without CONSULT-II

1. Disconnect smart entrance control unit harness connector .
2. Check continuity between smart entrance control unit harness connector M121 terminal 4 (LG/R) or 5 (BR) and ground.

Smart entrance control unit connector



Terminals	Door lock/unlock switch (LH or RH) condition	Continuity
4 - Ground	Lock	Yes
	N and Unlock	No
5 - Ground	Unlock	Yes
	N and Lock	No



SEL157Y

OK or NG

OK	▶	GO TO 6.
NG	▶	GO TO 5.

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

5	CHECK DOOR LOCK/UNLOCK SWITCH																																						
	<p>1. Disconnect door lock/unlock switch harness connector.</p> <p>2. Check continuity between each door lock/unlock switch terminals.</p> <ul style="list-style-type: none"> <li>Power window main switch (Door lock/unlock switch connector)</li> </ul> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>P/W main switch connector</p> </div> <div style="text-align: center;"> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Condition</th> <th colspan="3">Terminals</th> </tr> <tr> <th>5</th> <th>19</th> <th>6</th> </tr> </thead> <tbody> <tr> <td>Lock</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> <tr> <td>N</td> <td colspan="3" style="text-align: center;">No continuity</td> </tr> <tr> <td>Unlock</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL310X</p> <ul style="list-style-type: none"> <li>Door lock/unlock switch RH connector</li> </ul> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Lock/unlock switch RH connector</p> </div> <div style="text-align: center;"> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Condition</th> <th colspan="3">Terminals</th> </tr> <tr> <th>7</th> <th>18</th> <th>8</th> </tr> </thead> <tbody> <tr> <td>Lock</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> <tr> <td>N</td> <td colspan="3" style="text-align: center;">No continuity</td> </tr> <tr> <td>Unlock</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL311X</p> <p style="text-align: center;"><b>OK or NG</b></p>	Condition	Terminals			5	19	6	Lock	○	○	○	N	No continuity			Unlock	○	○	○	Condition	Terminals			7	18	8	Lock	○	○	○	N	No continuity			Unlock	○	○	○
Condition	Terminals																																						
	5	19	6																																				
Lock	○	○	○																																				
N	No continuity																																						
Unlock	○	○	○																																				
Condition	Terminals																																						
	7	18	8																																				
Lock	○	○	○																																				
N	No continuity																																						
Unlock	○	○	○																																				
OK	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>Ground circuit for door lock/unlock switch</li> <li>Harness for open or short between door lock/unlock switch and smart entrance control unit connector</li> </ul>																																						
NG	<p>▶ Replace door lock/unlock switch.</p>																																						

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

## 6 CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

### With CONSULT-II

Check front door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

When key inserted in front key cylinder is turned to LOCK:

**KEY CYL LK-SW ON**

When key inserted in front key cylinder is turned to UNLOCK:


**KEY CYL UN-SW ON**

SEL342W


### Without CONSULT-II

Check voltage between smart entrance control unit harness connector M121 terminals 10 (LG) or 11 (Y) and ground.


Front door LH



Smart entrance control unit connector



Back door



Door	Terminals		Key position	Voltage V
	(+)	(-)		
Front door LH	11	Ground	Neutral/Unlock	Approx. 5
			Lock	0
	10	Ground	Neutral/Lock	Approx. 5
			Unlock	0
Back door	11	Ground	Between neutral and lock	0
			Other positions	Approx. 5
Back door	10	Ground	Between neutral and unlock	0
			Other positions	Approx. 5

SEL280Y

**OK or NG**

OK	▶	Replace smart entrance control unit.
NG	▶	GO TO 7.

# INTERIOR, SPOT, VANITY MIRROR AND LUGGAGE ROOM LAMPS

Trouble Diagnoses for Interior Lamp Timer (Cont'd)

7	CHECK DOOR KEY CYLINDER SWITCH																												
	<p>1. Disconnect door key cylinder switch harness connector.                      2. Check continuity between each key cylinder switch terminals.</p> <ul style="list-style-type: none"> <li>● Front door key cylinder switch harness connector D9</li> </ul> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Front door key cylinder switch connector</p> </div> <div style="text-align: left;"> <p>① : Door unlock switch terminal                      ② : Ground terminal                      ③ : Door lock switch terminal</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">③ - ②</td> <td>Neutral/Unlock</td> <td>No</td> </tr> <tr> <td>Lock</td> <td>Yes</td> </tr> <tr> <td rowspan="2">① - ②</td> <td>Neutral/Lock</td> <td>No</td> </tr> <tr> <td>Unlock</td> <td>Yes</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL187YA</p> <ul style="list-style-type: none"> <li>● Back door key cylinder switch harness connector D201</li> </ul> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p>Back door key cylinder switch harness connector (D201)</p> </div> <div style="text-align: left;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Key position</th> <th colspan="3">Terminals</th> </tr> <tr> <th>1</th> <th>2</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>Between neutral and lock (Back door)</td> <td style="text-align: center;">○</td> <td></td> <td style="text-align: center;">○</td> </tr> <tr> <td>Between neutral and unlock (Back door)</td> <td></td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL315X</p> <p style="text-align: center;"><b>OK or NG</b></p>	Terminals	Key position	Continuity	③ - ②	Neutral/Unlock	No	Lock	Yes	① - ②	Neutral/Lock	No	Unlock	Yes	Key position	Terminals			1	2	4	Between neutral and lock (Back door)	○		○	Between neutral and unlock (Back door)		○	○
Terminals	Key position	Continuity																											
③ - ②	Neutral/Unlock	No																											
	Lock	Yes																											
① - ②	Neutral/Lock	No																											
	Unlock	Yes																											
Key position	Terminals																												
	1	2	4																										
Between neutral and lock (Back door)	○		○																										
Between neutral and unlock (Back door)		○	○																										
OK	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Front or back door key cylinder switch ground circuit</li> <li>● Harness for open or short between front or back door key cylinder switch and smart entrance control unit connector</li> </ul>																												
NG	▶ Replace front or back door key cylinder switch.																												


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# METERS AND GAUGES

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0296



SEL486Y

## System Description

NAEL0297


### UNIFIED CONTROL METER

NAEL0297S01

- Speedometer, odo/trip meter, tachometer, fuel gauge and water temperature gauge are controlled totally by control unit.
- Digital meter is adopted for odo/trip meter.\*  
\*The record of the odo meter is kept even if the battery cable is disconnected. The record of the trip meter is erased when the battery cable is disconnected.
- Odo/trip meter segment can be checked in diagnosis mode.
- Meter/gauge can be checked in diagnosis mode.

### HOW TO CHANGE THE DISPLAY FOR ODO/TRIP METER

NAEL0297S02



SEL175W

### NOTE:

Turn ignition switch to the "ON" position to operate odo/trip meter.

## POWER SUPPLY AND GROUND CIRCUIT

NAEL0297S03

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to combination meter terminal 62.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to combination meter terminal 66.

Ground is supplied

- to combination meter terminal 59
- through body grounds M4, M66 and M147.

## WATER TEMPERATURE GAUGE

NAEL0297S04

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal 18 of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

## TACHOMETER

NAEL0297S05

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal

- from terminal 25 of the ECM
- to combination meter terminal 16 for the tachometer.

## FUEL GAUGE

NAEL0297S06

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal 17 for the fuel gauge
- from terminal 3 of the fuel level sensor unit
- through terminal 2 of the fuel level sensor unit and
- through body grounds B11, B22 and D210.

## SPEEDOMETER

NAEL0297S07

The ABS actuator and electric unit provides a voltage signal to the combination meter for the speedometer.

The voltage is supplied

- from combination meter terminal 15 for the speedometer
- to terminal 19 of the ABS actuator and electric unit.

The speedometer converts the voltage into the vehicle speed displayed.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



# METERS AND GAUGES

Combination Meter

## Combination Meter CHECK

NAEL0298

NAEL0298S01



Bulb socket color	Bulb wattage
Black (*1)	1.4W
Black (*2)	3.0W

( ) : Warning bulb socket color

(U) : For USA

(C) : For Canada

(AW) : With all-mode 4-wheel drive


(PW) : With part-time 4-wheel drive

(AT) : With A/T

MEL9150

## CONSTRUCTION

NAEL0298S02



SEL482Y

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**


IDX

# METERS AND GAUGES

Schematic

NAEL0299

## Schematic



- : With A/T
- : With spare tire carrier
- : With 4-wheel drive
- : With all-mode 4-wheel drive
- : With A/T and 4-wheel drive
- : For Canada

MEL411P

# METERS AND GAUGES


Wiring Diagram — METER —

## Wiring Diagram — METER —

NAEL0300

### EL-METER-01




**A** : With A/T



COMBINATION METER  
**M24** ,  
**M26**

REFER TO THE FOLLOWING.

- E1** , **B1** -SUPER MULTIPLE JUNCTION (SMJ)
- M10** -FUSE BLOCK-JUNCTION BOX (J/B)
- M120** , **F24** -ELECTRICAL UNITS-



MEL412P

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
 EL  
 IDX

# METERS AND GAUGES

Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

## Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode

NAEL0301

### DIAGNOSIS FUNCTION


NAEL0301S01

- Odo/trip meter segment can be checked in diagnosis mode.
- Meters/gauges can be checked in diagnosis mode.


### HOW TO ALTERNATE DIAGNOSIS MODE

NAEL0301S02

1. Turn ignition switch to ON and change odo/trip meter to "TRIP A" or "TRIP B".
2. Turn ignition switch to OFF.
3. Turn ignition switch to ON when pushing odo/trip meter switch.
4. Push odo/trip meter switch 1 second.
5. Release odo/trip meter switch.
6. Push odo/trip meter switch more than three times within 7 seconds.



SEL176W



SEL177W

7. All odo/trip meter segments should be turned on.

#### NOTE:

If some segments are not turned on, unified meter control unit with odo/trip meter should be replaced.

At this point, the unified control meter is turned to diagnosis mode.

8. Push odo/trip meter switch. Indication of each meter/gauge should be as shown left during pushing odo/trip meter switch if it is no malfunctioning.

#### NOTE:


It takes about a few seconds for indication of fuel gauge and water temperature gauge to become stable.

## Trouble Diagnoses PRELIMINARY CHECK

NAEL0302

NAEL0302S01

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



SEL494Y

\*1: Meter/Gauge Operation and Odo/Trip Meter Segment Check in Diagnosis Mode (EL-124)

\*2: POWER SUPPLY AND GROUND CIRCUIT CHECK (EL-126)

\*3: Symptom Chart 1 (EL-125)

## SYMPTOM CHART


NAEL0302S02

Symptom	Possible causes	Repair order
One of speedometer/tachometer/fuel gauge/water temp. gauge is malfunctioning.	1. Sensor signal - Vehicle speed signal - Engine revolution signal - Fuel gauge - Water temp. gauge 2. Unified meter control unit	1. Check the sensor for malfunctioning meter/gauge. INSPECTION/VEHICLE SPEED SIGNAL (Refer to EL-127.) INSPECTION/ENGINE REVOLUTION SIGNAL (Refer to EL-128.) INSPECTION/FUEL LEVEL SENSOR UNIT (Refer to EL-129.) INSPECTION/THERMAL TRANSMITTER (Refer to EL-130.)
Multiple meter/gauge are malfunctioning. (except odo/trip meter)	Unified meter control unit	2. Replace unified meter control unit assembly.

Before starting trouble diagnoses below, perform PRELIMINARY CHECK, EL-125.

# METERS AND GAUGES

Trouble Diagnoses (Cont'd)



## POWER SUPPLY AND GROUND CIRCUIT CHECK

=NAEL0302S03


### Power Supply Circuit Check

NAEL0302S0301

Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
62	Ground	Battery voltage	Battery voltage	Battery voltage
66	Ground	0V	0V	Battery voltage

If NG, check the following.

- 7.5A fuse [No. 24, located in fuse block (J/B)]
- 10A fuse [No. 8, located in fuse block (J/B)]
- Harness for open or short between fuse and combination meter



### Ground Circuit Check

NAEL0302S0302

Terminals		Continuity
(+)	(-)	
Connector	Terminal (wire color)	Yes
M26	59 (B)	
	63 (SB)	Ground

## INSPECTION/VEHICLE SPEED SIGNAL


=NAEL0302S04

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

### 1 CHECK ABS CONTROL UNIT OUTPUT SIGNAL

#### With CONSULT-II


- Lift up drive wheels.
- Start engine and drive vehicle at more than 20 km/h (12 MPH).
- Check signal between combination meter harness connector M24 terminal 15 (G/Y) and ground when rotating wheels with engine at idle. (Use "SIMPLE OSCILLOSCOPE" in "SUB MODE" with CONSULT-II.)




SEL938W

#### Without CONSULT-II

- Lift up drive wheels.
- Start engine and drive vehicle at more than 20 km/h (12 MPH).
- Check voltage between combination meter harness connector M24 terminal 15 (G/Y) and ground when rotating wheels with engine at idle.



Voltage: Approx. 0 - 5V



SEL939WA

OK or NG



OK	▶	ABS control unit is OK.
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>• Harness for open or short between ABS actuator and electric unit and combination meter.</li> <li>• ABS actuator and electric unit. Refer to BR-59, "Wheel Sensor or Rotor".</li> </ul>

# METERS AND GAUGES

Trouble Diagnoses (Cont'd)

## INSPECTION/ENGINE REVOLUTION SIGNAL

NAEL0302S05


<b>1</b>	<b>CHECK ECM OUTPUT</b>	<p>1. Start engine. 2. Check voltage between combination meter terminals 16 and ground at idle and 2,000 rpm.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Combination meter connector (M24)</p>  </div> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p><b>Higher rpm = Higher voltage</b> <b>Lower rpm = Lower voltage</b> <b>Voltage should change with rpm.</b></p> </div> </div> <p style="text-align: right;">SEL364WB</p>	
<b>OK or NG</b>			
OK	▶	Engine revolution signal is OK.	
NG	▶	Harness for open or short between ECM and combination meter	

# METERS AND GAUGES


Trouble Diagnoses (Cont'd)

## INSPECTION/FUEL LEVEL SENSOR UNIT

=NAEL0302S06

<b>1</b>	<b>CHECK GROUND CIRCUIT FOR FUEL LEVEL SENSOR UNIT</b>		
<p>Check harness continuity between fuel level sensor unit terminal 2 and ground.</p>			
			
<b>Continuity should exist.</b>			
SEL299X			
<b>OK or NG</b>			
OK	▶	GO TO 2.	
NG	▶	Repair harness or connector.	

<b>2</b>	<b>CHECK FUEL LEVEL SENSOR UNIT</b>		
<p>Refer to "FUEL LEVEL SENSOR UNIT CHECK" (EL-131).</p>			
<b>OK or NG</b>			
OK	▶	GO TO 3.	
NG	▶	Replace fuel level sensor unit.	

<b>3</b>	<b>CHECK HARNESS FOR OPEN OR SHORT</b>		
<p>1. Disconnect combination meter connector and fuel level sensor unit connector.                  2. Check continuity between combination meter terminal 17 and fuel level sensor unit terminal 3.                  3. Check continuity between combination meter terminal 17 and ground.</p>			
			
<b>Continuity:</b>			
<b>Combination meter terminal 17 and fuel level sensor unit terminal 3</b>			
Yes			
<b>Combination meter terminal 17 and ground</b>			
No			
SEL300X			
<b>OK or NG</b>			
OK	▶	Fuel level sensor unit is OK.	
NG	▶	Repair harness or connector.	

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# METERS AND GAUGES


Trouble Diagnoses (Cont'd)

## INSPECTION/THERMAL TRANSMITTER

=NAEL0302S07

<b>1</b>	<b>CHECK THERMAL TRANSMITTER</b>	
Refer to "THERMAL TRANSMITTER CHECK" (EL-131).		
<b>OK or NG</b>		
OK	▶	GO TO 2.
NG	▶	Replace.

<b>2</b>	<b>CHECK HARNESS FOR OPEN OR SHORT</b>	
<ol style="list-style-type: none"> <li>1. Disconnect combination meter connector and thermal transmitter connector.</li> <li>2. Check continuity between combination meter terminal 18 and thermal transmitter terminal 1. <b>Continuity should exist.</b></li> <li>3. Check continuity between combination meter terminal 18 and ground. <b>Continuity should not exist.</b></li> </ol>		
SEL184WA		
<b>OK or NG</b>		
OK	▶	Thermal transmitter is OK.
NG	▶	Repair harness or connector.



## Electrical Components Inspection

=NAEL0303


### FUEL LEVEL SENSOR UNIT CHECK

NAEL0303S02

- For removal, refer to FE-4, "FUEL SYSTEM".
- Check the resistance between terminals 3 and 2.

Ohmmeter		Float position mm (in)		Resistance value $\Omega$
(+)	(-)			
3	2	*1	Full	95 (3.74)
		*2	1/2	184 (7.24)
		*3	Empty	265 (10.43)
				Approx. 4 - 6
				31 - 34
				80 - 83

\*1 and \*3: When float rod is in contact with stopper.



## THERMAL TRANSMITTER CHECK

NAEL0303S03

Check the resistance between the terminals of thermal transmitter and body ground.

Water temperature	Resistance
60°C (140°F)	Approx. 170 - 210 $\Omega$
100°C (212°F)	Approx. 47 - 53 $\Omega$


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# COMPASS AND THERMOMETER

System Description

## System Description

NAEL0304



This unit displays following items:

- Earth magnetism and heading direction of vehicle.
- Outside air temperature.
- Caution for frozen road surfaces.

### OUTSIDE TEMPERATURE DISPLAY

Push the switch when the ignition key is in the “ACC” or “ON” position. The outside temperature will be displayed in “°F”. NAEL0304S01

- Selecting the indication range  
Push the switch to change from “°F” to “°C”.
- When the outside temperature drops below freezing point, ICE is displayed on the unit.
- When the outside temperature is between 55°C (130°F) and 70°C (158°F), the display shows 55°C (130°F).
- When the outside temperature is lower than -30°C (-20°F) or higher than 70°C (158°F), the display shows only “---” though it is operating. This is not a problem.
- The indicated temperature on the thermometer is not readily affected by engine heat. It changes only when one of the following conditions is present.
  - a) The temperature detected by the ambient air temperature sensor is lower than the indicated temperature on the thermometer.
  - b) The difference in temperature detected during a period of 40 seconds is less than 1°C (1.8°F) when vehicle speed has been greater than 24 km/h (15 MPH) for more than 100 seconds.  
(This is to prevent the indicated temperature from being affected by engine heat or cooling fan operation during low-speed driving.)
  - c) The ignition key has been turned to the “OFF” position for more than 4 hours. (The engine is cold.)

### DIRECTION DISPLAY



Push the switch when the ignition key is in the “ACC” or “ON” position. The direction will be displayed. NAEL0304S02

# COMPASS AND THERMOMETER

Wiring Diagram — COMPAS —

## Wiring Diagram — COMPAS —

NAEL0305



REFER TO THE FOLLOWING.

- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10) -FUSE BLOCK-JUNCTION BOX (J/B)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# COMPASS AND THERMOMETER

Trouble Diagnoses

## Trouble Diagnoses

NAEL0306

### PRELIMINARY CHECK FOR THERMOMETER

NAEL0306S01

<b>1</b>	<b>COOL DOWN CHECK</b>	
1. Turn the ignition key switch to the "ACC" position. 2. Cool down the ambient air temperature sensor with water or ice, so that the indicated temperature falls.		
<b>Does the indicated temperature fall?</b>		
Yes	▶	GO TO 2.
No	▶	The system is malfunctioning. Check the system following "INSPECTION/COMPASS AND THERMOMETER".

<b>2</b>	<b>WARM UP CHECK</b>	
1. Leave the vehicle for 10 minutes, so that the indicated temperature rises. 2. With the ignition key in the "ACC" position, disconnect and reconnect the ambient air temperature sensor connector.		
<b>Does the indicated temperature rise?</b>		
Yes	▶	The system is OK.
No	▶	The system is malfunctioning. Check the system following "INSPECTION/COMPASS AND THERMOMETER".

#### NOTE:

- When the outside temperature is between 55°C (130°F) and 70°C (158°F), the display shows 55°C (130°F). When the outside temperature is lower than -30°C (-20°F) or higher than 70°C (158°F), the display shows only "---".
- The indicated temperature on the thermometer is not readily affected by engine heat. It changes only when one of the following conditions is present.
  - a) The temperature detected by the ambient air temperature sensor is lower than the indicated temperature on the thermometer.
  - b) The difference in temperature detected during a period of 40 seconds is less than 1°C (1.8°F) when vehicle speed has been greater than 24 km/h (15 MPH) for more than 100 seconds.  
(This is to prevent the indicated temperature from being affected by engine heat or cooling fan operation during low-speed driving.)
  - c) The ignition key has been turned to the "OFF" position for more than 4 hours. (The engine is cold.)

### INSPECTION/COMPASS AND THERMOMETER

NAEL0306S02


Symptom	Possible causes	Repair order
No display at all	1. 10A fuse 2. Ground circuit 3. Compass and thermometer	1. Check 10A fuse [No. 9, located in fuse block (J/B)]. Turn the ignition switch ON and verify that battery positive voltage is at terminal 7 of compass and thermometer. 2. Check ground circuit for compass and thermometer. 3. Replace compass and thermometer.
Forward direction indication slips off the mark or incorrect.	1. In manual correction mode (Bar and display vanish.) 2. Zone variation change is not done.	1. Drive the vehicle and turn at an angle of 90°. 2. Perform the zone variation change.
Compass reading remains unchanged.	1. Vehicle speed signal is not entered. 2. Compass and thermometer	1. Check harness for open or short between combination meter terminal 13 and compass and thermometer terminal 1. 2. Replace compass and thermometer.
Displays wrong temperature when ambient temperature is between -30°C (-20°F) and 55°C (130°F). (See NOTE above.)	1. Check operation 2. Ambient air temperature sensor circuit 3. Vehicle speed signal is not entered. 4. Ambient air temperature sensor 5. Compass and thermometer	1. Perform preliminary check shown above. 2. Check harness for open or short between ambient air temperature sensor and compass and thermometer. 3. Check harness for open or short between combination meter terminal 13 and compass and thermometer terminal 1. 4. Replace ambient air temperature sensor. 5. Replace compass and thermometer.

## Calibration Procedure for Compass

NAEL0307

The difference between magnetic North and geographical North can sometimes be great enough to cause false compass readings. In order for the compass to operate accurately in a particular zone, it must be calibrated using the following procedure.


Zone Variation Chart



1. Determine your location on the zone map. Record your zone number.
2. Turn the ignition switch to ACC or ON position.
3. Push the "Mode" switch continuously for five seconds until the current zone entry number is displayed.
4. Press the "Mode" switch repeatedly until the desired zone number is displayed.

Once the desired zone number is displayed, stop pressing the "Mode" switch and the display will show compass direction after a few seconds.

SEL738UA



### CORRECTION FUNCTIONS OF COMPASS

NAEL0307S01

The direction display is equipped with automatic correction function. If the direction is not shown correctly, carry out initial correction.

### INITIAL CORRECTION PROCEDURE FOR COMPASS

NAEL0307S02

1. Pushing the "Mode" switch for about 10 seconds will enter the initial correction mode. The direction bar starts blinking.
2. Turn the vehicle slowly in an open, safe place. The initial correction is completed in one or two turns.

**NOTE:**

In places where the terrestrial magnetism is extremely disturbed, the initial correction may start automatically.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# WARNING LAMPS

Schematic

NAEL0308

## Schematic



MEL4310

# WARNING LAMPS






Wiring Diagram — WARN —

## Wiring Diagram — WARN —

NAEL0309

### EL-WARN-01

Ⓢ : For Canada



REFER TO THE FOLLOWING.

- (E1) -SUPER
- MULTIPLE JUNCTION (SMJ)
- (M10) -FUSE BLOCK-
- JUNCTION BOX (J/B)
- (F24) -ELECTRICAL UNITS-

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX




# WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

## EL-WARN-02

(TC) : With spare tire carrier

COMBINATION  
METER  
(M24) , (M26)




REFER TO THE FOLLOWING.  
(E1) , (B1) -SUPER  
MULTIPLE JUNCTION (SMJ)

MEL414P

# WARNING LAMPS




Wiring Diagram — WARN — (Cont'd)

EL-WARN-03



COMBINATION METER (M24, M26)

- (A4) : With A/T and 4-wheel drive
- (AW) : With all-mode 4-wheel drive
- (U) : For USA
- (C) : For Canada



REFER TO THE FOLLOWING.  
(E1), (B1) -SUPER  
MULTIPLE JUNCTION (SMJ)


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL4050


# WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-04



- (A) : With A/T
- (A4) : With A/T and 4-wheel drive
- (4W) : With 4-wheel drive





REFER TO THE FOLLOWING.  
 (E1) -SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (M119) -ELECTRICAL UNIT-

MEL4320

# WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

## EL-WARN-05



REFER TO THE FOLLOWING.  
 (B1) - SUPER MULTIPLE  
 JUNCTION (SMJ)



MEL4060

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

## EL-WARN-06





REFER TO THE FOLLOWING.  
**(E1)** -SUPER  
 MULTIPLE JUNCTION (SMJ)  
**(M10)** -FUSE BLOCK-  
 JUNCTION BOX (J/B)

MEL415P

# WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

## EL-WARN-07





MEL416P

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


# WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)



MEL417P

# WARNING LAMPS



## Fuel Warning Lamp Sensor Check

NAEL0310


1. Turn ignition switch "OFF".
2. Disconnect fuel level sensor unit harness connector B12.
3. Connect a resistor (80Ω) between fuel tank gauge unit harness connector terminals 2 and 3.
4. Turn ignition switch "ON".

The fuel warning lamp should come on.

### NOTE:

ECM might store the 1st trip DTC P0180 during this inspection. If the DTC is stored in ECM memory, erase the DTC after reconnecting fuel tank gauge unit harness connector. Refer to EC-73, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



## Electrical Components Inspection


### OIL PRESSURE SWITCH CHECK

NAEL0311

NAEL0311S01

	Oil pressure kPa (kg/cm <sup>2</sup> , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1 - 3)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1 - 3)	YES

Check the continuity between the terminals of oil pressure switch and body ground.



### DIODE CHECK

NAEL0311S02

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.
- Check diodes at the combination meter harness connector instead of checking them on the combination meter assembly. Refer to EL-137, "WARNING LAMP" wiring diagrams.

### NOTE:


Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.

# WARNING CHIME

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0312



SEL046WA

## System Description

NAEL0313

The warning chime is controlled by the smart entrance control unit. The warning chime is located in the smart entrance control unit. Power is supplied at all times

- through 7.5A fuse [No. 24, located in fuse block (J/B)]
- to smart entrance control unit terminal 49 and
- to key switch terminal 2,
- through 10A fuse (No. 61, located in the fuse and fusible link box
- to tail lamp relay terminals 1 and 3.

When the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27.

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M77 and M111.

When a signal, or combination of signals, is received by the smart entrance control unit, the warning chime will sound.

### IGNITION KEY WARNING CHIME

NAEL0313S01

When the key in the ignition switch in the OFF position, and the driver's door open, the warning chime will sound. Power is supplied

- from key switch terminal 1
- to smart entrance control unit terminal 25.

Ground is supplied

- from front door switch (driver side) terminal 1
- to smart entrance control unit terminal 1.

Front door switch (driver side) terminal 2 is grounded through body grounds B11, B22 and D210.

### LIGHT WARNING CHIME

NAEL0313S02

When ignition switch OFF, driver's door open, and lighting switch in 1ST or 2ND position, warning chime will sound. Power is supplied.

- from tail lamp relay terminal 2

# WARNING CHIME

System Description (Cont'd)

- to smart entrance control unit terminal 19 and 57.

Ground is supplied

- from front door switch (driver side) terminal 1
- to smart entrance control unit terminal 1.

Front door switch (driver side) terminal 2 is grounded through body grounds B11, B22 and D210.

## SEAT BELT WARNING CHIME

With ignition switch turned ON and seat belt unfastened (seat belt switch ON), warning chime will sound for approximately 6 seconds.

NAEL0313S03

Ground is supplied

- from seat belt switch terminal 1
- to smart entrance control unit terminal 28.

Seat belt switch terminal 2 is grounded through body grounds B11, B22 and D210.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX




# WARNING CHIME

Wiring Diagram — CHIME —


## Wiring Diagram — CHIME —

NAEL0314

EL-CHIME-01



REFER TO THE FOLLOWING.  
 (E1) - SUPER MULTIPLE JUNCTION (SMJ)  
 (M10), (E3) - FUSE BLOCK - JUNCTION BOX (J/B)







MEL554P

# WARNING CHIME

Wiring Diagram — CHIME — (Cont'd)

## EL-CHIME-02



REFER TO THE FOLLOWING.


(B1) -SUPER MULTIPLE  
JUNCTION (SMJ)

MEL555P

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# WARNING CHIME

CONSULT-II Inspection Procedure




## CONSULT-II Inspection Procedure "KEY WARN ALM"/"LIGHT WARN ALM"/"SEAT BELT ALM"


=NAEL0315

NAEL0315S01


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "SMART ENTRANCE".



6. Touch "KEY WARN ALM", "LIGHT WARN ALM" or "SEAT BELT ALM".



- DATA MONITOR and ACTIVE TEST are available for the warning chime.

# WARNING CHIME

CONSULT-II Application Items

## CONSULT-II Application Items

### “KEY WARNING ALARM”

NAEL0316

#### Data Monitor

NAEL0316S01

NAEL0316S0101

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW DR	Indicates [ON/OFF] condition of front door switch LH.

#### Active Test

NAEL0316S0102

Test Item	Description
CHIME	This test is able to check key warning chime operation. Key warning chime sounds for 2 seconds after touching “ON” on CONSULT-II screen.

### “LIGHT WARN ALM”

NAEL0316S02

#### Data Monitor

NAEL0316S0201

Monitored Item	Description
LIGHT SW 1ST	Indicates [ON/OFF] condition of lighting switch.
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.

#### Active Test

NAEL0316S0202

Test Item	Description
CHIME	This test is able to check light warning chime operation. Light warning chime sounds for 2 seconds after touching “ON” on CONSULT-II screen.

### “SEAT BELT WARM ALM”

NAEL0316S03

#### Data Monitor

NAEL0316S0301

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
SEAT BELT SW	Indicates [ON/OFF] condition of seat belt switch.

#### Active Test

NAEL0316S0302

Test Item	Description
CHIME	This test is able to check seat belt warning chime operation. Seat belt warning chime sounds for 2 seconds after touching “ON” on CONSULT-II screen.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# WARNING CHIME


Trouble Diagnoses

## Trouble Diagnoses SYMPTOM CHART

NAEL0317

NAEL0317S01

REFERENCE PAGE (EL- )	152	154	155	156	157
SYMPTOM	POWER SUPPLY AND GROUND CIRCUIT CHECK	DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH INPUT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INSERT SIGNAL CHECK)	DIAGNOSTIC PROCEDURE 3 (SEAT BELT BUCKLE SWITCH CHECK)	DIAGNOSTIC PROCEDURE 4
Light warning chime does not activate.	X	X			X
Ignition key warning chime does not activate.	X		X		X
Seat belt warning chime does not activate.	X			X	X
All warning chimes do not activate.	X				X



### POWER SUPPLY AND GROUND CIRCUIT CHECK Power Supply Circuit Check

NAEL0317S02

NAEL0317S0201


Terminals		Voltage
(+)	(-)	
Connector	Terminal (Wire color)	Battery voltage
M122	49 (G/R)	

If NG, check the following.

- 7.5A fuse [No. 24, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse

# WARNING CHIME

Trouble Diagnoses (Cont'd)



## Ground Circuit Check

NAEL0317S0202

Terminals		Continuity
(+)	(-)	
Connector	Terminal (Wire color)	Yes
M122	43 (B)	
M123	64 (B)	Ground

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX

# WARNING CHIME

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 1 (LIGHTING SWITCH INPUT SIGNAL CHECK)

-NAEL0317S03


<b>1</b>	<b>CHECK LIGHTING SWITCH INPUT SIGNAL</b>									
<p> <b>With CONSULT-II</b>                  Check lighting switch ("LIGHT SW 1ST") in "DATA MONITOR" mode with CONSULT-II.</p>										
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%; text-align: center; border: 1px solid black; padding: 5px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2" style="text-align: center;">DATA MONITOR</th></tr> <tr><th colspan="2" style="text-align: center;">MONITOR</th></tr> <tr><td style="text-align: center;">LIGHT SW 1ST</td><td style="text-align: center;">OFF</td></tr> </table> </td> <td style="padding-left: 20px; vertical-align: top;"> <p>When lighting switch is in 1st or 2nd position:  <b>LIGHT SW 1ST ON</b></p> <p>When lighting switch is in OFF position:  <b>LIGHT SW 1ST OFF</b></p> </td> </tr> </table>			<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2" style="text-align: center;">DATA MONITOR</th></tr> <tr><th colspan="2" style="text-align: center;">MONITOR</th></tr> <tr><td style="text-align: center;">LIGHT SW 1ST</td><td style="text-align: center;">OFF</td></tr> </table>	DATA MONITOR		MONITOR		LIGHT SW 1ST	OFF	<p>When lighting switch is in 1st or 2nd position:  <b>LIGHT SW 1ST ON</b></p> <p>When lighting switch is in OFF position:  <b>LIGHT SW 1ST OFF</b></p>
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2" style="text-align: center;">DATA MONITOR</th></tr> <tr><th colspan="2" style="text-align: center;">MONITOR</th></tr> <tr><td style="text-align: center;">LIGHT SW 1ST</td><td style="text-align: center;">OFF</td></tr> </table>	DATA MONITOR		MONITOR		LIGHT SW 1ST	OFF	<p>When lighting switch is in 1st or 2nd position:  <b>LIGHT SW 1ST ON</b></p> <p>When lighting switch is in OFF position:  <b>LIGHT SW 1ST OFF</b></p>			
DATA MONITOR										
MONITOR										
LIGHT SW 1ST	OFF									
SEL991X										
<p> <b>Without CONSULT-II</b>                  Check voltage between smart entrance control unit harness connector M121 terminal 19 (R), connector M123 terminal 57 (R) and ground.</p>										
<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 40%; text-align: center; vertical-align: top;"> <p>Smart entrance control unit connector</p> </td> <td style="padding-left: 20px; vertical-align: top;"> <p><b>Voltage [V]:</b>                  Condition of lighting switch: 1ST or 2ND                  0                  Condition of lighting switch: OFF                  Approx. 12</p> </td> </tr> </table>			<p>Smart entrance control unit connector</p>	<p><b>Voltage [V]:</b>                  Condition of lighting switch: 1ST or 2ND                  0                  Condition of lighting switch: OFF                  Approx. 12</p>						
<p>Smart entrance control unit connector</p>	<p><b>Voltage [V]:</b>                  Condition of lighting switch: 1ST or 2ND                  0                  Condition of lighting switch: OFF                  Approx. 12</p>									
SEL992XA										
<b>OK or NG</b>										
OK	▶	Replace smart entrance control unit.								
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 10A fuse (No. 61, located in the fuse and fusible link box)</li> <li>● Harness for open or short between smart entrance control unit and tail lamp relay</li> </ul>								


# WARNING CHIME

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 2 (KEY SWITCH INSERT SIGNAL CHECK)

-NAEL0317S04

<b>1</b>	<b>CHECK KEY SWITCH INPUT SIGNAL</b>							
<p> <b>With CONSULT-II</b> Check key switch ("KEY ON SW") in "DATA MONITOR" mode with CONSULT-II.</p>								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th></th> </tr> </thead> <tbody> <tr> <td>KEY ON SW</td> <td>ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR		KEY ON SW	ON
DATA MONITOR								
MONITOR								
KEY ON SW	ON							
<p>When key is inserted to ignition key cylinder: <b>KEY ON SW ON</b></p> <p>When key is removed from ignition key cylinder: <b>KEY ON SW OFF</b></p>								
SEL315W								
<p> <b>Without CONSULT-II</b> Check voltage between smart entrance control unit harness connector M122 terminal 25 (W/R) and ground.</p>								
<p>Smart entrance control unit connector</p>  <p style="margin-left: 300px;"> <b>CONNECT</b>   : Approx. 12V   : 0V         </p>								
<p><b>Voltage [V]:</b>  <b>Condition of key switch: Key is inserted.</b>  <b>Approx. 12</b>  <b>Condition of key switch: Key is removed.</b>  <b>0</b></p>								
SEL011Y								
<b>OK or NG</b>								
OK	▶	Replace smart entrance control unit.						
NG	▶	GO TO 2.						

<b>2</b>	<b>CHECK KEY SWITCH (INSERT)</b>	
Check continuity between terminals 1 and 2.		
<p>Key switch connector </p>  <p style="margin-left: 300px;"> <b>DISCONNECT</b>  </p>		
<p><b>Continuity:</b>  <b>Condition of key switch: Key is inserted.</b>  <b>Yes</b>  <b>Condition of key switch: Key is removed.</b>  <b>No</b></p>		
SEL308X		
<b>OK or NG</b>		
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 10A fuse [No. 13, located in fuse block (J/B)]</li> <li>● Harness for open or short between key switch and fuse</li> <li>● Harness for open or short between smart entrance control unit and key switch</li> </ul>
NG	▶	Replace key switch.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


# WARNING CHIME

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 3 (SEAT BELT BUCKLE SWITCH CHECK)

-NAEL0317S05

<b>1</b>	<b>CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL</b>						
<p> <b>With CONSULT-II</b> Check seat belt buckle switch ("SEAT BELT SW") in "DATA MONITOR" mode with CONSULT-II.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 80%;">MONITOR</th> <th></th> </tr> </thead> <tbody> <tr> <td>SEAT BELT SW</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table> </div> <div> <p>When seat belt is fastened: <b>SEAT BELT SW ON</b></p> <p>When seat belt is released: <b>SEAT BELT SW OFF</b></p> </div> </div> <p style="text-align: right; margin-top: 10px;">SEL317W</p>		DATA MONITOR		MONITOR		SEAT BELT SW	ON
DATA MONITOR							
MONITOR							
SEAT BELT SW	ON						
<p> <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch "ON".</li> <li>2. Check voltage between smart entrance control unit harness connector M122 terminal 28 (B/Y) and ground.</li> </ol> <div style="display: flex; justify-content: space-between; align-items: flex-start; margin-top: 10px;"> <div style="width: 40%;"> <p>Smart entrance control unit connector</p>  </div> <div style="width: 55%;"> <p><b>Voltage [V]:</b></p> <p>Condition of seat belt buckle switch: Fastened Approx. 5</p> <p>Condition of seat belt buckle switch: Unfastened 0</p> </div> </div> <p style="text-align: right; margin-top: 10px;">SEL994X</p> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p>							
OK	▶	Replace smart entrance control unit.					
NG	▶	GO TO 2.					

<b>2</b>	<b>CHECK SEAT BELT BUCKLE SWITCH</b>	
<p>Check continuity between terminals 1 and 2 when seat belt is fastened and unfastened.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start; margin-top: 10px;"> <div style="width: 40%;"> <p>Seat belt buckle switch connector (B6)</p>  </div> <div style="width: 55%;"> <p><b>Continuity:</b></p> <p>Seat belt is fastened. No</p> <p>Seat belt is unfastened. Yes</p> </div> </div> <p style="text-align: right; margin-top: 10px;">SEL381X</p> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p>		
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Seat belt buckle switch ground circuit</li> <li>● Harness for open or short between smart entrance control unit and seat belt buckle switch</li> </ul>
NG	▶	Replace seat belt buckle switch.

# WARNING CHIME

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 4

NAEL0317S06

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

### 1 CHECK IGNITION ON SIGNAL

#### With CONSULT-II

Check ignition switch ON signal ("IGN ON SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
IGN ON SW	ON


When ignition switch is ON:  
**IGN ON SW ON**

When ignition switch is OFF:  
**IGN ON SW OFF**

SEL318W

#### Without CONSULT-II

Check voltage between smart entrance control unit harness connector M122 terminal 27 (W/B) and ground.



Terminals		Ignition switch position		
(+)	(-)	OFF	ACC	ON
27	Ground	0V	0V	Battery voltage

SEL995X

**OK or NG**


OK ► GO TO 2.


NG ► **Check the following.**

- 7.5A fuse [No. 11, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse

# WARNING CHIME

Trouble Diagnoses (Cont'd)

<b>2</b>	<b>CHECK DOOR SWITCH INPUT SIGNAL</b>								
<p> <b>With CONSULT-II</b>                  Check driver door switch signal ("DOOR SW-DR") in "DATA MONITOR" mode with CONSULT-II.</p>									
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>DOOR SW-DR</td><td>OFF</td></tr> </table>		DATA MONITOR		MONITOR		DOOR SW-DR	OFF	<p>When driver's door is open:  <b>DOOR SW-DR ON</b></p> <p>When driver's door is closed:  <b>DOOR SW-DR OFF</b></p>	
DATA MONITOR									
MONITOR									
DOOR SW-DR	OFF								
SEL319W									
<p> <b>Without CONSULT-II</b>                  Check voltage between smart entrance control unit harness connector M121 terminal 1 (G/R) and ground.</p>									
<p>Smart entrance control unit connector</p> 		<p><b>Voltage [V]:</b>                  Condition of driver's door: <b>CLOSED</b>                  Approx. 5                  Condition of driver's door: <b>OPENED</b>                  0</p>							
SEL996X									
<b>OK or NG</b>									
OK	▶	GO TO 4.							
NG	▶	GO TO 3.							

<b>3</b>	<b>CHECK DRIVER SIDE DOOR SWITCH</b>		
<p>Check continuity between terminals 2 and 3.</p>			
<p>Front door switch LH connector </p> 		<p><b>Continuity:</b>                  Door switch is pushed.                  No                  Door switch is released.                  Yes</p>	
SEL383X			
<b>OK or NG</b>			
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Driver side door switch ground circuit and condition</li> <li>● Harness for open or short between smart entrance control unit and driver side door switch</li> </ul>	
NG	▶	Replace driver side door switch.	

# WARNING CHIME

Trouble Diagnoses (Cont'd)

<b>4</b>	<b>CHECK WARNING CHIME</b>							
<p> <b>With CONSULT-II</b> Perform "CHIME" in "ACTIVE TEST" mode with CONSULT-II.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="border: 1px solid black; padding: 5px; text-align: center;"> <table border="1"> <tr><th colspan="2">ACTIVE TEST</th></tr> <tr><td>CHIME</td><td>OFF</td></tr> <tr><td>ON</td><td></td></tr> </table> </div> <div style="text-align: center; flex-grow: 1;"> <p><b>Warning chime should operate.</b></p> </div> <div style="text-align: right;"> <p>SEL320W</p> </div> </div> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p>			ACTIVE TEST		CHIME	OFF	ON	
ACTIVE TEST								
CHIME	OFF							
ON								
OK	▶	System is OK.						
NG	▶	Replace smart entrance control unit.						

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX

# FRONT WIPER AND WASHER

System Description

## System Description

NAEL0318

NAEL0318S01

### WIPER OPERATION

The front wiper switch is controlled by a lever built into the combination switch. There are three wiper switch positions:

- LO speed
- HI speed
- INT (Intermittent)

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 19, located in the fuse block (J/B)]
- to front wiper motor terminal 1, and
- to front wiper switch terminal 15.

### Low and High Speed Wiper Operation

NAEL0318S0101

Ground is supplied to front wiper switch terminal 17 through body grounds E13 and E41.

When the wiper switch is placed in the LO position, ground is supplied

- through terminal 14 of the front wiper switch
- to front wiper motor terminal 5.

With power and ground supplied, the front wiper motor operates at low speed.

When the front wiper switch is placed in the HI position, ground is supplied

- through terminal 16 of the front wiper switch
- to front wiper motor terminal 3.

With power and ground supplied, the front wiper motor operates at high speed.

### Auto Stop Operation

NAEL0318S0102

With front wiper switch turned OFF, front wiper motor will continue to operate until wiper arms reach windshield base.

When wiper arms are not located at base of windshield with front wiper switch OFF, ground is provided

- from terminal 14 of the front wiper switch
- to front wiper motor terminal 5, in order to continue front wiper motor operation at low speed.

Ground is also supplied

- to terminal 13 of the front wiper switch
- through front wiper motor terminal 4
- through terminal 6 of the front wiper motor, and
- through body grounds M77 and M111.

When wiper arms reach base of windshield, front wiper motor terminals 1 and 4 are connected instead of terminals 4 and 6. Wiper motor will then stop wiper arms at the PARK position.

### Intermittent Operation

NAEL0318S0103

The front wiper motor operates the wiper arms one time at low speed at a set interval of approximately 2 to 13 seconds. This feature is controlled by the wiper amplifier built in the front wiper switch.

When the front wiper switch is placed in the INT position, ground is supplied

- to wiper amplifier (INT SW)
- from front wiper switch terminal 17
- through body grounds E13 and E41, and
- to front wiper motor terminal 5
- through the front wiper switch terminal 14
- through wiper amplifier (OUTPUT)

### WASHER OPERATION

NAEL0318S02

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 19, located in the fuse block (J/B)]
- to front washer motor terminal 1.

When the lever is pulled to the WASH position, ground is supplied

- to front washer motor terminal 2
- through terminal 18 of the front wiper switch

# FRONT WIPER AND WASHER

System Description (Cont'd)

- through terminal 17 of the front wiper switch, and
- through body grounds E13 and E41.

With power and ground supplied, the front washer motor operates.

When the lever is pulled to the WASH position for one second or more, the front wiper motor operates at low speed for approximately 3 seconds to clean windshield. This feature is controlled by the wiper amplifier in the same manner as the intermittent operation.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX




# FRONT WIPER AND WASHER

Wiring Diagram — WIPER —

## Wiring Diagram — WIPER —


NAEL0319

EL-WIPER-01



REFER TO THE FOLLOWING.  
 (E1) -SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (M10), (E4) -FUSE BLOCK-  
 JUNCTION BOX (J/B)

MEL349N



## Removal and Installation

NAEL0320

### WIPER ARMS

NAEL0320S01


1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L<sub>1</sub>" & "L<sub>2</sub>" immediately before tightening nut.
3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
4. Ensure that wiper blades stop within clearance "L<sub>1</sub>" & "L<sub>2</sub>".

**Clearance "L<sub>1</sub>": 29 - 39 mm (1.14 - 1.54 in)**

**Clearance "L<sub>2</sub>": 32 - 42 mm (1.26 - 1.65 in)**

- Tighten wiper arm nuts to specified torque.


**Front wiper: 21 - 26 N·m (2.1 - 2.7 kg·m, 15 - 20 ft·lb)**



- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

### WIPER LINKAGE

NAEL0320S02



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# FRONT WIPER AND WASHER

Removal and Installation (Cont'd)

## Removal

NAEL0320S0201


1. Remove 4 bolts that secure wiper motor.
2. Detach wiper motor from wiper linkage at ball joint.
3. Remove wiper linkage.

**Be careful not to break ball joint rubber boot.**

## Installation

NAEL0320S0202

- Grease ball joint portion before installation.
1. Installation is the reverse order of removal.




## Washer Nozzle Adjustment

NAEL0321

- Adjust washer nozzle with suitable tool as shown in the figure at left.

**Adjustable range: ±10°**



Unit: mm (in)

*1	251 (9.88)	*6	459 (18.07)
*2	315 (12.40)	*7	256 (10.08)
*3	165 (6.50)	*8	67 (2.64)
*4	269 (10.59)	*9	40 (1.57)
*5	167 (6.57)		


\*A: The diameters of these circles are less than 80 mm (3.15 in).

\*B: The diameters of these circles are less than 138 × 80 mm (5.43 × 3.15 in).

\*C: The diameters of these circles are less than 96 × 80 mm (3.78 × 3.15 in).

## Washer Tube Layout

NAEL0322



## System Description

### WIPER OPERATION

#### Power Supply and Ground

With ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 29, located in the fuse block (J/B)]
- to rear wiper motor terminal 4.

When the glass hatch switch is OPEN, ground is supplied

- to rear wiper motor terminal 6
- through glass hatch switch terminal 1 and 2
- through body grounds B11, B22 and D210.

Ground is supplied

- to rear wiper motor terminal 8
- through body grounds B11, B22 and D210.

#### Wiper Operation

When the rear wiper switch is turned ON, ground is supplied

- to rear wiper motor terminal 2
- through combination switch terminals 22 and 24
- through body grounds E13 and E41.

Then, power is supplied

- to rear wiper motor terminal 4.

Ground is supplied

- to rear wiper motor terminal 8
- through body grounds B11, B22 and D210.

With power and ground supplied, the wiper motor operates.

#### Auto Stop Operation

With rear wiper switch turned OFF, rear wiper motor will continue to operate until wiper arm reaches rear wiper stopper.

Then wiper motor turns the other way and wiper arm moves once until wiper arm reaches stopper.

#### Intermittent Operation

The rear wiper motor operates the wiper arms at low speed approximately every 7 seconds.

When the wiper switch is placed in the INT position, ground is supplied

- to wiper motor terminal 3
- through rear wiper switch terminal 21 and 24
- through body grounds E13 and E41.

Then, power is supplied

- to rear wiper motor terminal 4.

Ground is supplied

- to rear wiper motor terminal 8
- through body grounds B11, B22 and D210.

With power and ground supplied, rear wiper operates at intermittent.

#### WIPER OPERATION PROHIBIT CONTROL

When glass hatch is open with back door key cylinder while rear wiper is operated, wiper operation is stopped. (Wiper operation prohibit control)

When glass hatch is closed and rear wiper switch turns from OFF and then rear wiper switch is turned to ON, wiper operation prohibit control is canceled.

#### WASHER OPERATION

When the rear wiper switch is turned to WASH position, ground is supplied

- to rear wiper motor terminal 5
- through terminals 23 and 24
- through body grounds E13 and E41.

	GI
<small>NAEL0323</small>	
<small>NAEL0323S01</small>	
<small>NAEL0323S0101</small>	MA
	EM
	LC
	EC
	FE
<small>NAEL0323S0102</small>	CL
	MT
	AT
	TF
	PD
<small>NAEL0323S0103</small>	AX
<small>NAEL0323S0104</small>	SU
	BR
	ST
	RS
	BT
<small>NAEL0323S02</small>	HA
	SC
<small>NAEL0323S03</small>	EL
	IDX

## REAR WIPER AND WASHER

### *System Description (Cont'd)*

---

Then, power is supplied

- to rear washer motor terminal 2
- through 10 A fuse [No. 29, located in the fuse block (J/B)].

Ground is supplied

- to rear washer motor terminal 1
- through rear wiper switch terminals 23 and 24
- through body grounds E13 and E41.

With power and ground supplied, the rear washer motor operates.

When the rear wiper switch is turned to WASH position for 0.4 seconds or more, the rear wiper motor operates approximately 3 times after the rear wiper switch is released.


# REAR WIPER AND WASHER

Wiring Diagram — WIP/R —


## Wiring Diagram — WIP/R —

NAEL0324

EL-WIP/R-01



Next page



REFER TO THE FOLLOWING.

- (B1), (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M91) -FUSE BLOCK-JUNCTION BOX (J/B)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL4070

# REAR WIPER AND WASHER

Wiring Diagram — WIP/R — (Cont'd)

EL-WIP/R-02



MEL4080

## Trouble Diagnoses

NAEL0325

NAEL0325S01



### REAR WIPER MOTOR INSPECTION TABLE

(Data are reference values.)

Terminal No.	Item	Condition		Voltage (Approximate value)	
2	ON switch		Rear wiper switch	ON	Less than 1V
				OFF or INT	Battery voltage
3	Intermittent switch		Rear wiper switch	INT	Less than 1V
				OFF, ON or WASH	Battery voltage
4	Power supply (ACC)		—		Battery voltage
5	Washer switch		Rear wiper switch	WASH	Less than 1V
				OFF, ON or INT	Battery voltage
6	Glass hatch switch		Glass hatch	Open	Less than 1V
				Closed	Battery voltage
8	Ground	—		—	

**NOTE:**

Power to the rear wiper motor will be interrupted when the rear glass hatch is opened. In that case, conduct the inspection of the rear wiper motor with the rear glass hatch closed, unless otherwise indicated.



### Removal and Installation

#### WIPER ARMS

NAEL0326

NAEL0326S01

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
2. Install wiper arm to portion A as in figure below and tighten wiper arm nut to specification.
3. Then, set wiper arm to portion B.


 : 13 - 18 N·m (1.3 - 1.8 kg·m, 9 - 13 ft·lb)

- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# REAR WIPER AND WASHER

## Washer Nozzle Adjustment




## Washer Nozzle Adjustment

NAEL0327


- Adjust washer nozzle with suitable tool as shown in the figure at left.

**Adjustable range: ±10° (In any direction)**



## Washer Tube Layout


NAEL0328



## Check Valve

NAEL0329



- A check valve is provided in the washer fluid line. Be careful not to connect check valve to washer tube in the wrong direction.



Wiring Diagram — HORN —

NAEL0330

EL-HORN-01



\* : This connector is not shown in "HARNES LAYOUT", EL section.

REFER TO THE FOLLOWING.

(E1) -SUPER  
MULTIPLE JUNCTION (SMJ)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX




# CLOCK

Wiring Diagram — CLOCK —


## Wiring Diagram — CLOCK —

NAEL0332

### EL-CLOCK-01



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



REFER TO THE FOLLOWING.

(M10) - FUSE BLOCK-  
JUNCTION BOX (J/B)


MEL035M

# REAR WINDOW DEFOGGER

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0333



SEL483Y

## System Description

NAEL0334

The rear window defogger system is controlled by the smart entrance control unit. The rear window defogger operates only for approximately 15 minutes.

Power is supplied at all times

- to rear window defogger relay terminal 3
- through 20A fuse (No. 56, located in the fuse and fusible link box) and
- to rear window defogger relay terminal 6
- through 20A fuse (No. 57, located in the fuse and fusible link box)
- to smart entrance control unit terminal 49
- through 7.5A [No. 24, located in fuse block (J/B)]

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to the rear window defogger relay terminal 1, and
- to smart entrance control unit terminal 27.

Ground is supplied

- to terminal 1 of the rear window defogger switch
- through body grounds M4, M66 and M147,
- to smart entrance control unit terminals 43 and 64
- through body grounds M77 and M111.

When the rear window defogger switch is turned ON, ground is supplied

# REAR WINDOW DEFOGGER

System Description (Cont'd)

- through terminal 2 of the rear window defogger switch
- to smart entrance control unit terminal 14.

Terminal 37 of the smart entrance control unit then supplies ground to the rear window defogger relay terminal 2.

With power and ground supplied, the rear window defogger relay is energized.

Power is supplied

- through terminals 5 and 7 of the rear window defogger relay
- to the rear window defogger.

The rear window defogger has an independent ground.

With power and ground supplied, the rear window defogger filaments heat and defog the rear window.

When the system is activated, the rear window defogger indicator illuminates in the rear window defogger switch.

Power is supplied

- to terminal 3 of the rear window defogger switch
- from terminal 7 of the rear window defogger relay.

Terminal 4 of the rear window defogger switch is grounded through body grounds M4, M66 and M147.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX



# REAR WINDOW DEFOGGER

Wiring Diagram — DEF —

## Wiring Diagram — DEF —

NAEL0335

EL-DEF-01



REFER TO THE FOLLOWING.

- (E1), (B1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10), (E3) -FUSE BLOCK-JUNCTION BOX (J/B)




MEL867N

# REAR WINDOW DEFOGGER

Wiring Diagram — DEF — (Cont'd)

EL-DEF-02










Refer to EL-POWER.

Preceding page A B/L

REFER TO THE FOLLOWING.

(B1) - SUPER MULTIPLE JUNCTION (SMJ)




MEL418P

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# REAR WINDOW DEFOGGER

CONSULT-II Inspection Procedure




## CONSULT-II Inspection Procedure "REAR DEFOGGER"


NAEL0336

NAEL0336S01


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "SMART ENTRANCE".



6. Touch "REAR DEFOGGER".



7. Select diagnosis mode.  
"DATA MONITOR" and "ACTIVE TEST" are available.

# REAR WINDOW DEFOGGER

CONSULT-II Application Items

## CONSULT-II Application Items

### “REAR DEFOGGER” Data Monitor

NAEL0337

NAEL0337S01

NAEL0337S0101

GI

MA

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
REAR DEF SW	Indicates [ON/OFF] condition of rear window defogger switch.

EM

LC

### Active Test

NAEL0337S0102

Test Item	Description
REAR DEFOGGER	This test is able to check rear window defogger operation. Rear window defogger activates when “ON” on CONSULT-II screen is touched.

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX


# REAR WINDOW DEFOGGER

Trouble Diagnoses

## Trouble Diagnoses DIAGNOSTIC PROCEDURE SYMPTOM: Rear window defogger does not activate, or does not go off after activating.

NAEL0338

NAEL0338S01

<b>1</b>	<b>CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL</b>	
<p> <b>With CONSULT-II</b> Select "ACTIVE TEST" in "REAR DEFOGGER" with CONSULT-II.</p> <div style="display: flex; justify-content: space-between; align-items: center;"> <div style="border: 1px solid black; padding: 5px; width: 150px;"> <p style="text-align: center; margin: 0;">ACTIVE TEST</p> <p style="margin: 0;">REAR DEFOGGER    OFF</p> <p style="text-align: center; margin-top: 20px; background-color: black; color: white; padding: 2px;">ON</p> </div> <div style="text-align: center; padding: 10px;"> <p><b>Rear window defogger and rear window defogger switch indicator should operate when the "ON" button on the CONSULT-II screen is touched.</b></p> </div> </div> <p style="text-align: right; margin-top: 10px;">SEL353W</p>		
<p> <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Turn ignition switch to ON position.</li> <li>2. Check voltage between smart entrance control unit harness connector M122 terminal 37 (G/B) and ground.</li> </ol> <div style="display: flex; justify-content: space-between; align-items: center; margin-top: 10px;"> <div style="text-align: center;"> <p>Smart entrance control unit connector</p>  </div> <div style="text-align: center;">  </div> <div style="text-align: left; padding-left: 20px;"> <p><b>Voltage [V]:</b></p> <p>Rear window defogger switch is "OFF". Approx. 12</p> <p>Rear window defogger switch is "ON". 0</p> </div> </div> <p style="text-align: right; margin-top: 10px;">SEL997X</p> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p>		
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Rear window defogger relay (Refer to EL-183.)</li> <li>● Rear window defogger circuit</li> <li>● Rear window defogger filament (Refer to EL-183.)</li> </ul>
NG	▶	GO TO 2.

# REAR WINDOW DEFOGGER


Trouble Diagnoses (Cont'd)


2	<b>CHECK DEFOGGER RELAY COIL SIDE CIRCUIT</b>	
<p>1. Disconnect control unit connector.                  2. Turn ignition switch to ON position.                  3. Check voltage between smart entrance control unit harness connector M122 terminal 37 (G/B) and ground.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div data-bbox="370 321 711 619"> <p>Smart entrance control unit connector</p> </div> <div data-bbox="751 338 824 537"> </div> <div data-bbox="922 443 1271 474"> <p><b>Battery voltage should exist.</b></p> </div> </div> <p style="text-align: right;">SEL998X</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 3.
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 11, located in the fuse block (J/B)]</li> <li>● Rear window defogger relay</li> <li>● Harness for open or short between fuse and rear window defogger relay</li> <li>● Harness for open or short between rear window defogger relay and smart entrance control unit</li> </ul>

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

<b>3</b>	<b>CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL</b>							
<p> <b>With CONSULT-II</b>                  Select "REAR DEF SW" in "DATA MONITOR" mode with CONSULT-II.</p>								
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th colspan="2">MONITOR</th></tr> <tr><td>REAR DEF SW</td><td>ON</td></tr> </table>			DATA MONITOR		MONITOR		REAR DEF SW	ON
DATA MONITOR								
MONITOR								
REAR DEF SW	ON							
<p>When rear window defogger switch is pushed:  <b>REAR DEF SW should be ON.</b></p>								
SEL352W								
<p> <b>Without CONSULT-II</b>                  Check continuity between smart entrance control unit harness connector M121 terminal 14 (OR) and ground.</p>								
								
<p><b>Continuity:</b>                  Rear window defogger switch is pushed.  <b>Continuity should exist.</b>                  Rear window defogger switch is released.  <b>Continuity should not exist.</b></p>								
SEL999X								
<b>OK or NG</b>								
OK	▶	GO TO 4.						
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Rear window defogger switch (Refer to EL-183.)</li> <li>● Harness for open or short between smart entrance control unit and rear window defogger switch</li> <li>● Rear window defogger switch ground circuit</li> </ul>						

<b>4</b>	<b>CHECK POWER SUPPLY AND IGNITION INPUT SIGNAL</b>																					
<p>Check voltage between smart entrance control unit harness connector M122 terminal 27 (W/B), M123 terminal 49 (G/R) and ground.</p>																						
																						
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">Terminals</th> <th colspan="3">Ignition switch position</th> </tr> <tr> <th>(+)</th> <th>(-)</th> <th>OFF</th> <th>ACC</th> <th>ON</th> </tr> </thead> <tbody> <tr> <td>49</td> <td>Ground</td> <td>Battery voltage</td> <td>Battery voltage</td> <td>Battery voltage</td> </tr> <tr> <td>27</td> <td>Ground</td> <td>0V</td> <td>0V</td> <td>Battery voltage</td> </tr> </tbody> </table>			Terminals		Ignition switch position			(+)	(-)	OFF	ACC	ON	49	Ground	Battery voltage	Battery voltage	Battery voltage	27	Ground	0V	0V	Battery voltage
Terminals		Ignition switch position																				
(+)	(-)	OFF	ACC	ON																		
49	Ground	Battery voltage	Battery voltage	Battery voltage																		
27	Ground	0V	0V	Battery voltage																		
SEL001Y																						
<b>OK or NG</b>																						
OK	▶	GO TO 5.																				
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 11 or No. 24, located in the fuse block (J/B)]</li> <li>● Harness for open or short between smart entrance control unit and fuse</li> </ul>																				

# REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

**5 CHECK CONTROL UNIT GROUND CIRCUIT**


Check continuity between smart entrance control unit harness connector M122 terminal 43 (B), M123 terminal 64 (B) and ground.

Smart entrance control unit connector      Smart entrance control unit connector

Continuity should exist.

SEL002Y

Yes	▶	Replace smart entrance control unit.
No	▶	Repair harness or connectors.



## Electrical Components Inspection


### REAR WINDOW DEFOGGER RELAY

NAEL0339

Check continuity between terminals 3 and 5, 6 and 7.

NAEL0339S01

Condition	Continuity
12V direct current supply between terminals 1 and 2	Yes
No current supply	No




### REAR WINDOW DEFOGGER SWITCH

NAEL0339S02

Check continuity between terminals when rear window defogger switch is pushed and released.

Terminals	Condition	Continuity
1 - 2	Rear window defogger switch is pushed	Yes
	Rear window defogger switch is released	No



### Filament Check


NAEL0340

1. Attach probe circuit tester (in volt range) to middle portion of each filament.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


# REAR WINDOW DEFOGGER

## Filament Check (Cont'd)



SEL265

2. If a filament is burned out, circuit tester registers 0 or 12 volts.
3. To locate burned out point, move probe to left and right along filament. Test needle will swing abruptly when probe passes the point.



SEL122R


- When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.

## Filament Repair REPAIR EQUIPMENT

NAEL0341

NAEL0341S01

- 1) Conductive silver composition (Dupont No. 4817 or equivalent)
- 2) Ruler 30 cm (11.8 in) long
- 3) Drawing pen
- 4) Heat gun
- 5) Alcohol
- 6) Cloth



BE540

## REPAIRING PROCEDURE

NAEL0341S02


1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

### Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.


# REAR WINDOW DEFOGGER

Filament Repair (Cont'd)



4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

**Do not touch repaired area while test is being conducted.**



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

## System Description

NAEL0342

Refer to Owner's Manual for audio system operating instructions.

### BASE SYSTEM

NAEL0342S01

Power is supplied at all times

- through 15A fuse [No. 4, located in the fuse block (J/B)]
- to audio unit terminal 6, and
- to CD player terminal 4 (with CD player).

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to audio unit terminal 10, and
- to CD player terminal 1 (with CD player).

Ground is supplied through the case of the audio unit.

When the audio unit power knob is pushed to the ON position, audio signals are supplied

- through audio unit terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to the front and rear speakers.

### BOSE SYSTEM

NAEL0342S02

Power is supplied at all times

- through 15A fuse [No. 4, located in the fuse block (J/B)]
- to audio unit terminal 6,
- to audio amp. relay terminal 3,
- to rear speaker amp. terminal 11,
- to CD auto changer terminal 12 (with CD auto changer) and
- to AUX box terminal 7 (with rear TV).

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to audio unit terminal 10,
- to CD auto changer terminal 16 (with CD auto changer) and
- to AUX box terminal 6 (with rear TV).

Ground is supplied through the case of the audio unit.

Ground is supplied

- to audio amp. relay terminal 2,
- through body grounds M4, M66 and M147
- to front door speaker LH terminal 5 and
- to front door speaker RH terminal 5
- through body grounds M77 and M111
- to rear speaker amp. terminal 24 and
- to AUX box terminal 8 (with rear TV)
- through body grounds B11, B22 and D210
- to CD auto changer terminal 15 and
- to rear TV switch terminal 3
- through body grounds M4, M66 and M147.

When the audio unit POWER button is pressed, power is supplied to rear speaker amp. terminal 9 and audio amp. relay terminal 1 from audio unit terminal 12. Then audio amp. relay is energized and power is supplied

- to front door speaker LH terminal 4 and
- to front door speaker RH terminal 4.

Audio signals are supplied

- through audio unit terminals 1, 2, 3, 4, 13, 14, 15 and 16
- to terminals 2 and 6 of the LH and RH front speakers and terminals 5, 7, 18 and 20 of the rear speaker amp.
- to LH and RH tweeters through terminals 1 and 3 of the front speakers
- to rear LH and RH speakers through terminals 1, 2, 25 and 26 of the rear speaker amp.

# AUDIO



Wiring Diagram — AUDIO —/Base System

## Wiring Diagram — AUDIO —/Base System

NAEL0343

### EL-AUDIO-01

Ⓢ : With CD player



REFER TO THE FOLLOWING.  
 (M10), (M81) - FUSE BLOCK-  
 JUNCTION BOX (J/B)




MEL355N

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# AUDIO

Wiring Diagram — AUDIO —/Base System (Cont'd)

EL-AUDIO-02




REFER TO THE FOLLOWING.

(B1) -SUPER  
MULTIPLE JUNCTION (SMJ)

MEL038M

Schematic/BOSE System

NAEL0344



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC

EL

# AUDIO

Wiring Diagram — AUDIO —/BOSE System

## Wiring Diagram — AUDIO —/BOSE System



NAEL0345

### EL-AUDIO-03

⬡WC⬡ : With CD auto changer

⬡RT⬡ : With rear TV

Refer to EL-POWER.



REFER TO THE FOLLOWING.  
 ⬡M10⬡, ⬡M81⬡ - FUSE BLOCK-  
 JUNCTION BOX (J/B)





MEL357N



# AUDIO

Wiring Diagram — AUDIO —/BOSE System (Cont'd)

## EL-AUDIO-05




REFER TO THE FOLLOWING.

(B1) - SUPER MULTIPLE JUNCTION (SMJ)

# AUDIO


Wiring Diagram — AUDIO —/BOSE System (Cont'd)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

REFER TO THE FOLLOWING.

(B1) - SUPER MULTIPLE  
JUNCTION (SMJ)






MEL556P

# AUDIO

Wiring Diagram — AUDIO —/BOSE System (Cont'd)

EL-AUDIO-07



MEL044M

## Trouble Diagnoses

NAEL0346

NAEL0346S01

### AUDIO UNIT

Symptom	Possible causes	Repair order
Audio unit inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> <li>10A fuse</li> <li>Poor audio unit case ground</li> <li>Audio unit</li> </ol>	<ol style="list-style-type: none"> <li>Check 10A fuse [No. 10, located in fuse block (J/B)]. Turn ignition switch ON and verify that battery positive voltage is present at terminal 10 of audio unit.</li> <li>Check audio unit case ground.</li> <li>Remove audio unit for repair.</li> </ol>
Audio unit presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> <li>15A fuse</li> <li>Audio unit</li> </ol>	<ol style="list-style-type: none"> <li>Check 15A fuse [No. 4, located in fuse block (J/B)] and verify that battery positive voltage is present at terminal 6 of audio unit.</li> <li>Remove audio unit for repair.</li> </ol>
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> <li>Antenna</li> <li>Poor audio unit ground</li> <li>Audio unit</li> </ol>	<ol style="list-style-type: none"> <li>Check antenna.</li> <li>Check audio unit ground.</li> <li>Remove audio unit for repair.</li> </ol>
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> <li>Window antenna</li> <li>Audio unit</li> </ol>	<ol style="list-style-type: none"> <li>Check window antenna.</li> <li>Remove audio unit for repair.</li> </ol>
Audio unit generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> <li>Poor audio unit ground</li> <li>Loose or missing ground bonding straps</li> <li>Ignition condenser or rear window defogger noise suppressor condenser</li> <li>Alternator</li> <li>Ignition coil or secondary wiring</li> <li>Audio unit</li> </ol>	<ol style="list-style-type: none"> <li>Check audio unit ground.</li> <li>Check ground bonding straps.</li> <li>Replace ignition condenser or rear window defogger noise suppressor condenser.</li> <li>Check alternator.</li> <li>Check ignition coil and secondary wiring.</li> <li>Remove audio unit for repair.</li> </ol>
Audio unit generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> <li>Poor audio unit ground</li> <li>Antenna</li> <li>Accessory ground</li> <li>Faulty accessory</li> </ol>	<ol style="list-style-type: none"> <li>Check audio unit ground.</li> <li>Check antenna.</li> <li>Check accessory ground.</li> <li>Replace accessory.</li> </ol>

### BASE SYSTEM

NAEL0346S02

Symptom	Possible causes	Repair order
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> <li>Speaker</li> <li>Audio unit output</li> <li>Speaker circuit</li> <li>Audio unit</li> </ol>	<ol style="list-style-type: none"> <li>Check speaker.</li> <li>Check audio unit output voltages.</li> <li>Check wires for open or short between audio unit and speaker.</li> <li>Remove audio unit for repair.</li> </ol>

### BOSE SYSTEM

NAEL0346S03

Symptom	Possible causes	Repair order
Audio unit controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> <li>15A fuse</li> <li>Audio unit output</li> <li>Audio unit</li> </ol>	<ol style="list-style-type: none"> <li>Check 15A fuse [No. 4, located in fuse block (J/B)]. Verify battery positive voltage is present at terminal 2 of audio amp. relay.</li> <li>Check audio unit output voltage (Terminal 12).</li> <li>Remove audio unit for repair.</li> </ol>
All front speakers are inoperative.	<ol style="list-style-type: none"> <li>Audio amp. relay</li> <li>Audio amp. relay ground</li> <li>Amp. ON signal</li> </ol>	<ol style="list-style-type: none"> <li>Check audio amp. relay.</li> <li>Check audio amp. relay ground (Terminal 3).</li> <li>Turn ignition switch ACC and audio unit ON. Verify battery positive voltage is present at terminal 1 of audio amp. relay.</li> </ol>
Individual front speaker is noisy or inoperative.	<ol style="list-style-type: none"> <li>Speaker ground</li> <li>Power supply</li> <li>Audio unit output</li> <li>Speaker</li> </ol>	<ol style="list-style-type: none"> <li>Check speaker ground (Terminal 5).</li> <li>Check power supply for speaker (Terminal 4).</li> <li>Check audio unit output voltage for speaker.</li> <li>Replace speaker.</li> </ol>

# AUDIO

## Trouble Diagnoses (Cont'd)

Symptom	Possible causes	Repair order
Both rear speakers are inoperative.	<ol style="list-style-type: none"><li>1. Poor rear speaker amp. ground</li><li>2. Power supply</li><li>3. Amp. ON signal</li><li>4. Rear speaker amp.</li></ol>	<ol style="list-style-type: none"><li>1. Check rear speaker amp. ground circuit.</li><li>2. Check power supply for rear speaker amp. (Terminal 11).</li><li>3. Turn ignition switch ACC and audio unit ON. Verify battery positive voltage is present at terminal 9 of rear speaker amp.</li><li>4. Remove rear speaker amp. for repair.</li></ol>
Individual rear speaker is noisy or inoperative.	<ol style="list-style-type: none"><li>1. Speaker</li><li>2. Audio unit/amp. output</li><li>3. Speaker circuit</li><li>4. Audio unit</li></ol>	<ol style="list-style-type: none"><li>1. Check speaker.</li><li>2. Check audio unit/amp. output.</li><li>3. Check wires for open or short between audio unit/amp. and speakers.</li><li>4. Remove audio unit for repair.</li></ol>

## Inspection

NAEL0347

### AUDIO UNIT AND AMP.

NAEL0347S01

All voltage inspections are made with:

- Ignition switch ON or ACC
- Audio unit ON
- Audio unit and amps. connected (If audio unit or amp. is removed for inspection, supply a ground to the case using a jumper wire.)

### ANTENNA

NAEL0347S02

1. Using a jumper wire, clip an auxiliary ground between antenna and body.
- If reception improves, check antenna ground (at body surface).
- If reception does not improve, check main feeder cable for short circuit or open circuit.

## Audio Unit Removal and Installation

NAEL0348

1. Lock the CD changer unit mechanism (if so equipped) prior to removing a malfunctioning CD changer unit. Refer to "LOCKING CD CHANGER UNIT MECHANISM", EL-196.
2. Remove CD changer unit. Refer to BT-22, "INSTRUMENT PANEL ASSEMBLY".

### LOCKING CD CHANGER UNIT MECHANISM

NAEL0348S01

#### CAUTION:

- **Prior to removing a malfunctioning CD changer unit that will be shipped for repair, the changer mechanism MUST BE LOCKED to prevent the mechanism from being damaged during shipping.**
  - **If a CD is jammed or unable to be removed from the unit, do NOT lock the changer mechanism. If the unit is to be shipped for repair, carefully package the unit to prevent vibration and shock.**
1. Eject and remove any CDs from the CD changer unit.
  2. Turn ignition switch OFF. Wait until CD changer unit display is off and mechanism stops moving (mechanism sound stops).
  3. Press any one of the disc selection buttons once. When a display shows on the CD changer unit, press the same disc selection button again within 5 seconds.
    - The changer mechanism will lock itself within 10 seconds.
  4. After mechanism stops moving (mechanism sound stops), disconnect the CD changer unit connectors.


#### NOTE:

After installing a new or remanufactured CD changer unit, switching the CD changer unit ON will automatically unlock the mechanism. A special unlocking procedure is not required.

Wiring Diagram — REMOTE —


NAEL0349

EL-REMOTE-01



REFER TO THE FOLLOWING.

- (E1) -SUPER
- MULTIPLE JUNCTION (SMJ)
- (M10) -FUSE BLOCK-
- JUNCTION BOX (J/B)



\* : This connector is not shown in "HARNESS LAYOUT", EL section.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# AUDIO ANTENNA

*System Description*

---

## System Description

NAEL0350

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to power antenna terminal 6.

Ground is supplied to the power antenna terminal 2 through body grounds M4, M66 and M147.

When the audio unit is turned to the ON position, battery positive voltage is supplied

- through audio unit terminal 5
- to power antenna terminal 4.

The antenna raises and is held in the extended position.

When the audio unit is turned to the OFF position, battery positive voltage is interrupted

- from audio unit terminal 5
- to power antenna terminal 4.

The antenna retracts.


# AUDIO ANTENNA

Wiring Diagram — P/ANT —

## Wiring Diagram — P/ANT —

NAEL0351

EL-P/ANT-01



REFER TO THE FOLLOWING.

(M10) - FUSE BLOCK - JUNCTION BOX (J/B)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL824L

# AUDIO ANTENNA

Trouble Diagnoses

## Trouble Diagnoses

NAEL0352



NAEL0352S01

### POWER ANTENNA

Symptom	Possible causes	Repair order
Power antenna does not operate.	<ol style="list-style-type: none"> <li>7.5A fuse</li> <li>Audio unit signal</li> <li>Grounds M4, M66 and M147</li> </ol>	<ol style="list-style-type: none"> <li>Check 7.5A fuse [No. 24, located in fuse block (J/B)]. Verify that battery positive voltage is present at terminal 6 of power antenna.</li> <li>Turn ignition switch and audio unit ON. Verify that battery positive voltage is present at terminal 4 of power antenna.</li> <li>Check grounds M4, M66 and M147.</li> </ol>

### Location of Antenna

NAEL0353



### Antenna Rod Replacement REMOVAL


NAEL0354

NAEL0354S01

- Remove antenna nut and antenna base.

# AUDIO ANTENNA

Antenna Rod Replacement (Cont'd)



2. Withdraw antenna rod while raising it by operating antenna motor.


GI

MA

EM

LC

EC



## INSTALLATION

NAEL0354S02

1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

## System Description

NAEL0355

NAEL0355S01

### OUTLINE

Electric sunroof system consists of

- Sunroof switch
- Sunroof motor
- Smart entrance control unit

Smart entrance control unit controls retained power operation.

### OPERATION

NAEL0355S02

The sunroof can be tilted up or down with the tilt switch.

The sunroof can be opened or closed automatically with the sunroof switch.

### RETAINED POWER OPERATION

NAEL0355S04

When the ignition switch is turned to OFF position from ON or START position, power is supplied for 45 seconds

- to power window relay terminal 2
- from smart entrance control unit terminal 46.

Ground is always supplied

- to power window relay terminal 1
- through body grounds.

When power and ground are supplied, power window relay continues to be energized, and the electrical sunroof can be operated.

When power is supplied, the electrical sunroof can be operated.

The retained power operation is canceled when the driver or passenger side door is opened.

RAP signal period can be changed by CONSULT-II. (EL-206)

### INTERRUPTION DETECTION FUNCTION

NAEL0355S05

The CPU of sunroof motor monitors the sunroof motor operation and the sunroof position (full closed or other) for sunroof by the signals from encoder and limit switch in sunroof motor.

When sunroof motor detects interruption during the following close operation,

- automatic close operation when ignition switch is in the "ON" position
- automatic close operation during retained power operation

sunroof switch controls the motor for open and the sunroof will operate about 150 mm (5.91 in).


# POWER SUNROOF

Wiring Diagram — SROOF —


## Wiring Diagram — SROOF —

NAEL0356

EL-SROOF-01




Next page



REFER TO THE FOLLOWING.

- (B1) - SUPER MULTIPLE JUNCTION (SMJ)
- (M10) - FUSE BLOCK - JUNCTION BOX (J/B)








GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# POWER SUNROOF

Wiring Diagram — SROOF — (Cont'd)


EL-SROOF-02



REFER TO THE FOLLOWING.

(E1) - SUPER MULTIPLE JUNCTION (SMJ)

MEL420P




## CONSULT-II Inspection Procedure

=NAEL0357


NAEL0357S01

### “RETAINED PWR”


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START”.



5. Touch “SMART ENTRANCE”.



6. Touch “RETAINED PWR”.



7. Select diagnosis mode.  
“DATA MONITOR” and “ACTIVE TEST” are available.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# POWER SUNROOF

CONSULT-II Application Items

## CONSULT-II Application Items

NAEL0455

### “RETAINED PWR”

NAEL0455S01

#### Data Monitor

NAEL0455S0101

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.

#### Active Test

NAEL0455S0102

Test Item	Description
RETAINED PWR	<p>This test is able to supply RAP signal (power) from smart entrance control unit to power window system, power sunroof system. Those systems can be operated when turning on “RETAINED PWR” on CONSULT-II screen even if the ignition switch is tuned OFF.</p> <p><b>NOTE:</b>  <b>During this test, CONSULT-II can be operated with ignition switch “OFF” position. “RETAINED PWR” should be turned “ON” or “OFF” on CONSULT-II screen when ignition switch is ON. Then turn ignition switch OFF for checking retained power operation. CONSULT-II might be stuck if “RETAINED PWR” is turned “ON” or “OFF” on CONSULT-II screen when ignition switch is OFF.</b></p>

#### Work Support

NAEL0455S0103

Work Item	Description
RETAINED PWR SET	<p>RAP signal's power supply period can be changed by mode setting. Selects RAP signal's power supply period between three steps.</p> <ul style="list-style-type: none"> <li>● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (2 min.)</li> </ul>

## Trouble Diagnoses

NAEL0456

Symptom	Possible cause	Repair order
Power sunroof cannot be operated using any switch.	<ol style="list-style-type: none"> <li>1. 7.5A fuse, 40A fusible link and M145 circuit breaker</li> <li>2. Power window relay ground circuit</li> <li>3. Sunroof motor ground circuit</li> <li>4. Power window relay</li> <li>5. Sunroof motor circuit</li> <li>6. Sunroof switch</li> <li>7. Sunroof switch circuit</li> <li>8. Sunroof motor</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse [No. 11, located in fuse block (J/B)], 40A fusible link (letter f, located in fuse and fusible link box) and M145 circuit breaker. Turn ignition switch “ON” and verify battery positive voltage is present at terminals 2 and 3 of power window relay and terminal 1 of sunroof motor.</li> <li>2. Check power window relay ground circuit.</li> <li>3. Check sunroof motor ground circuit.</li> <li>4. Check power window relay.</li> <li>5. Check the wire between power window relay and sunroof motor.</li> <li>6. Check sunroof switch.</li> <li>7. Check harness between sunroof switch and sunroof motor.</li> <li>8. Check sunroof motor.</li> </ol>
Power sunroof cannot be operated using one of the sunroof switches.	<ol style="list-style-type: none"> <li>1. Sunroof switch</li> <li>2. Sunroof switch circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check sunroof switch.</li> <li>2. Check the harness between sunroof motor and sunroof switch.</li> </ol>

# POWER SUNROOF

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
Power sunroof cannot be opened or closed fully.	<ol style="list-style-type: none"> <li>1. Full closed position not initialized</li> <li>2. Sunroof slide mechanism</li> <li>3. Sunroof switch</li> <li>4. Sunroof switch circuit</li> <li>5. Sunroof motor</li> </ol>	<ol style="list-style-type: none"> <li>1. Initialize full closed position.</li> <li>2. Check the following.                             <ol style="list-style-type: none"> <li>a. Check obstacles in sunroof, etc.</li> <li>b. Check worn or deformed sunroof.</li> <li>c. Check sunroof sash tilted too far inward or outward.</li> </ol> </li> <li>3. Check sunroof switch.</li> <li>4. Check harness between sunroof motor and sunroof switch.</li> <li>5. Replace sunroof motor.</li> </ol>
Retained power operation does not operate properly.	<ol style="list-style-type: none"> <li>1. RAP signal circuit</li> <li>2. Driver or passenger side door switch circuit</li> <li>3. Smart entrance control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check RAP signal.                             <ol style="list-style-type: none"> <li>a. (With CONSULT-II) Check RAP signal with CONSULT-II. Use "ACTIVE TEST" mode, "RETAINED PWR" in "SMART ENTRANCE". (Refer to EL-206.) If NG, go to the step b. below.</li> <li>b. Verify 12 positive voltage from smart entrance control unit is present at terminal 2 of power window relay:                                     <ul style="list-style-type: none"> <li>● Within 45 seconds after ignition switch turns off.</li> <li>● When front door LH and RH is closed.</li> </ul> </li> </ol> </li> <li>2. Check harness between smart entrance control unit and driver or passenger side door switch. Check driver or passenger side door switch. Check driver or passenger side door switch.</li> <li>3. Check smart entrance control unit. (EL-378)</li> </ol>

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



# DOOR MIRROR

Wiring Diagram — MIRROR —

## Wiring Diagram — MIRROR —

NAEL0360

EL-MIRROR-01



REFER TO THE FOLLOWING.

(M10) - FUSE BLOCK -  
JUNCTION BOX (J/B)

MEL421P



# POWER SEAT

Wiring Diagram — SEAT —

## Wiring Diagram — SEAT —

NAEL0361

EL-SEAT-01



REFER TO THE FOLLOWING.

(E1), (B1) - SUPER  
MULTIPLE JUNCTION (SMJ)


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL830L

# POWER SEAT

Wiring Diagram — SEAT — (Cont'd)

EL-SEAT-02



MEL601F


# HEATED SEAT

Wiring Diagram — HSEAT —


## Wiring Diagram — HSEAT —

NAEL0362

EL-HSEAT-01



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



\* : This connector is not shown in "HARNESS LAYOUT", EL section.

REFER TO THE FOLLOWING.

- (B1) -SUPER
- MULTIPLE JUNCTION (SMJ)
- (M91) -FUSE BLOCK- JUNCTION BOX (J/B)


MEL046M

# HEATED SEAT

Seatback Heating Unit

## Seatback Heating Unit

NAEL0363




SBT314

# AUTOMATIC DRIVE POSITIONER

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0364



SEL190Y

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX

# AUTOMATIC DRIVE POSITIONER

System Description

## System Description

=NAEL0365

### OPERATIVE CONDITION

The drive position can be set in 2 ways, manually and automatically.

NAEL0365S01

#### Manual Operation

The driver's seat can be adjusted for sliding, reclining, front cushion height and rear cushion height with the LH power seat switches. The manual operation can be adjusted with the IGN key in any position.

NAEL0365S0101

#### Automatic Operation

The driver's seat is adjusted to the proper positions for the driver automatically, in 3 different ways: MEMORY AUTOMATIC SET, AUTOMATIC EXITING SETTING and AUTOMATIC SET RETURN. (Automatic Drive Positioner = ADP)

NAEL0365S0102

### CONDITIONS INHIBITING AUTOMATIC OPERATION

Automatic memory setting procedures are suspended under any of the following conditions:

NAEL0365S02

- 1) When vehicle speed is more than 7 km/h (4 MPH).
- 2) When driver's side power seat switch is turned on.
- 3) When any two of the switches (set switch and memory switches 1 and 2) are turned ON.
- 4) When cancel switch is turned on.
- 5) When selector lever is in any position other than "P".
- 6) When ignition switch is turned to "START" position.  
(Operation resumes when ignition switch is returned to "ON".)
- 7) When detention switch malfunction is detected:
  - Detention switch failure is sensed when detention switch remains off for at least 2 seconds at a vehicle speed of greater than 7 km/h (4 MPH).

### FAIL-SAFE SYSTEM

#### Output Failure

When the ignition switch is in the ON position, if any of the parts (indicated in the following chart) move more than the specified amount within a period "T2" when no "ON" input is sent from any of the switches (indicated in the following chart), or an output from the automatic drive positioner is not produced, an output failure is sensed. Motor operation will be suspended automatically, and all automatic operations will be ineffective. (In this case, the motor will not operate manually.)

NAEL0365S03

NAEL0365S0301

OPERATED PORTION	T2	Allowable measurement
Seat sliding	Approx. 2.5 sec.	Within 6 mm (0.24 in)
Seat reclining	Same as above	Change angle within 1°

#### Absolving

When moving selector lever back to "P" position after having moved it to any position except "P", fail-safe operation will be canceled.

NAEL0365S0302

### INITIALIZATION

After reconnecting battery cable, perform initialization procedure A or B. If initialization has not been performed, automatic drive positioner will not operate.

NAEL0365S04

#### PROCEDURE A

- 1) Insert key in the ignition key cylinder. (Ignition switch is in "OFF" position.)
- 2) Open → close → open driver side door. (Do not perform with the door switch operation.)
- 3) End

#### PROCEDURE B

- 1) Drive the vehicle at more than 25 km/h (16 MPH).
- 2) End


## MEMORY AUTOMATIC SET

=NAEL0365S05

Two drive positions can be retained in the memory. Press memory switch to set driver's seat to preset position.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

### PROCEDURE FOR STORING MEMORY




SEL592W

### NOTE:

- When memory switch for which driver's seat positions are already retained in memory is pressed, new seat positions will be retained in memory in place of the previously set positions.
- Drive position is erased from the memory when battery cable is disconnected more than 30 seconds. After connecting battery cable, perform initialization procedures.

### SELECTING THE MEMORIZED POSITION



SEL593W

# AUTOMATIC DRIVE POSITIONER

System Description (Cont'd)

**NOTE:**

- 1) Do not keep cancel switch pressed as it will not operate.
- 2) Automatic exiting setting will be performed.
- 3) The driver's seat position (see the following Table) operates in the order of priority.


The order of priority	Operated portion
1	Seat sliding
2	Seat reclining
3	Seat front lifting
4	Seat rear lifting

**AUTOMATIC EXITING SETTING**

NAEL0365S06

"Exiting" positions:

Driver's seat ... Slides about 40 mm (1.57 in) rear from normal sitting position.




SEL594W

**AUTOMATIC SET RETURN**

NAEL0365S07

With driver's seat set to the "exiting" position, operating one of the following procedures moves it to the position previously retained in memory.




SEL595W

# AUTOMATIC DRIVE POSITIONER

Schematic

NAEL0366

## Schematic



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL422P




# AUTOMATIC DRIVE POSITIONER

Wiring Diagram — AUT/DP —

## Wiring Diagram — AUT/DP —

NAEL0367

EL-AUT/DP-01



\* : This connector is not shown in "HARNES LAYOUT", EL section.

REFER TO THE FOLLOWING.

- (E1), (B1) -SUPER
- MULTIPLE JUNCTION (SMJ)
- (M10), (E3) -FUSE BLOCK-
- JUNCTION BOX (J/B)








MEL557P

# AUTOMATIC DRIVE POSITIONER

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-02

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



\* : This connector is not shown in "HARNES LAYOUT", EL section.



REFER TO THE FOLLOWING.

(B1) -SUPER  
MULTIPLE JUNCTION (SMJ)

# AUTOMATIC DRIVE POSITIONER

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-03









\* : This connector is not shown in "HARNESS LAYOUT", EL section.

MEL423P

# AUTOMATIC DRIVE POSITIONER

Wiring Diagram — AUT/DP — (Cont'd)

## EL-AUT/DP-04



\* : This connector is not shown in "HARNES LAYOUT", EL section.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC

EL




MEL186M

IDX

# AUTOMATIC DRIVE POSITIONER

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-05




\* : This connector is not shown in "HARNESS LAYOUT", EL section.

MEL187M


## On Board Diagnosis

GI  
NAEL0368



### HOW TO PERFORM SELF-DIAGNOSIS

FE  
NAEL0368S01



CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
SEL596W

\*1: If no malfunction is indicated, self-diagnosis will end after the vehicle speed sensor diagnosis is performed.

\*2: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.

EL

IDX





# AUTOMATIC DRIVE POSITIONER

On Board Diagnosis (Cont'd)

## MALFUNCTION CODE TABLE

=NAEL0368S02

In this mode, a malfunction code is indicated by the number of flashes from the automatic drive positioner indicator lamps (indicator lamp 1, indicator lamp 2) as shown below.

Code No.	Detected items	Indication of seat memory switches 1 and 2	Explanation
1	Seat sliding	IND1, IND2 	While the seat motors are moving for 2.5 seconds, if the number of seat sliding/reclining/lifting encoder pulses changes 2 times or less, the seat device is determined to be malfunctioning.
2	Seat reclining	IND1, IND2 	
3	Seat lifting front	IND1, IND2 	
4	Seat lifting rear	IND1, IND2 	
9	Vehicle speed signal circuit	IND1, IND2 	If the vehicle speed signal output of less than 7 km/h (4 MPH) is detected, the ABS actuator and electric unit is determined to be malfunctioning.
-	No malfunction in the above items	SW1 IND 	—


SEL597WA

Code No.	Detected items	Diagnostic procedure	Reference page	Code No.	Detected items	Diagnostic procedure	Reference page
1	Seat sliding	PROCEDURE 2 (Sliding encoder check) PROCEDURE 6 (Sliding motor check)	EL-230 EL-238	4	Seat lifting rear	PROCEDURE 5 [Lifting encoder (rear) check] PROCEDURE 9 [Lifting motor (rear) check]	EL-236 EL-241
2	Seat reclining	PROCEDURE 3 (Reclining encoder check) PROCEDURE 7 (Reclining motor check)	EL-232 EL-239	9	Vehicle speed sensor	PROCEDURE 12 (Vehicle speed sensor check)	EL-244
3	Seat lifting front	PROCEDURE 4 [Lifting encoder (front) check] PROCEDURE 8 [Lifting motor (front) check]	EL-234 EL-240				

## Trouble Diagnoses WORK FLOW

NAEL0369

NAEL0369S01



\*1 EL-223

\*2 EL-224

SEL599W


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## PRELIMINARY CHECK

NAEL0369S02



SEL600W

\*1: After reconnecting battery cable, perform initialization procedure A or B.  
If initialization has not been performed, automatic drive positioner will not operate.

### PROCEDURE A

- 1) Insert key in the ignition key cylinder. (Ignition switch is in "OFF" position.)
- 2) Open → close → open driver side door. (Do not perform with the door switch operation.)
- 3) End

### PROCEDURE B

- 1) Drive the vehicle at more than 30 km/h (19 MPH).

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

2) End

After performing preliminary check, go to symptom chart below.

Before starting trouble diagnoses below, perform preliminary check, EL-226. Symptom numbers in the symptom chart correspond with those of preliminary check.

## SYMPTOM CHART

NAEL0369S03

PROCEDURE		Diagnostic procedure						
REFERENCE PAGE (EL- )		229	230	232	234	236	238	239
SYMPTOM		DIAGNOSTIC PROCEDURE 1 (Power supply and ground circuit for Driver's seat control unit)	DIAGNOSTIC PROCEDURE 2 (Sliding encoder check)	DIAGNOSTIC PROCEDURE 3 (Reclining encoder check)	DIAGNOSTIC PROCEDURE 4 [Lifting encoder (front) check]	DIAGNOSTIC PROCEDURE 5 [Lifting encoder (rear) check]	DIAGNOSTIC PROCEDURE 6 (Sliding motor check)	DIAGNOSTIC PROCEDURE 7 (Reclining motor check)
1	No seat system functions operate.	X						
2	Some of the seat system functions do not operate during automatic/manual operation.	Sliding					X	
		Reclining						X
		Lifting (Front)						
		Lifting (Rear)						
3	No functions operate during automatic operation, and some/all functions do not during manual operation.							
4	Some of the seat system functions do not operate during automatic operation.	Sliding	X					
		Reclining		X				
		Lifting (Front)			X			
		Lifting (Rear)				X		
5	No automatic operation functions operate.							
6	Drive position cannot be retained in the memory.							
7	Does not operate during manual operation. (Operates during automatic operation.)	Sliding						
		Reclining						
		Lifting (Front)						
		Lifting (Rear)						
8	Automatic operation cannot be canceled.							
9	Memory indicator does not light up.							

X : Applicable

# AUTOMATIC DRIVE POSITIONER


## Trouble Diagnoses (Cont'd)

PROCEDURE		Diagnostic procedure						
REFERENCE PAGE (EL- )		240	241	242	243	244	247	247
SYMPTOM		DIAGNOSTIC PROCEDURE 8 [Lifting motor (front) check]	DIAGNOSTIC PROCEDURE 9 [Lifting motor (rear) check]	DIAGNOSTIC PROCEDURE 10 (Power seat switch check)	DIAGNOSTIC PROCEDURE 11 (Cancel switch check)	DIAGNOSTIC PROCEDURE 12 (Key, park position, door switch and vehicle speed sensor check)	DIAGNOSTIC PROCEDURE 13 (Seat memory switch check)	DIAGNOSTIC PROCEDURE 14 (Memory indicator check)
1	No seat system functions operate.							
2	Some of the seat system functions do not operate during automatic/manual operation.	Sliding						
		Reclining						
		Lifting (Front)	X					
		Lifting (Rear)		X				
3	No functions operate during automatic operation, and some/all functions do not during manual operation.			X		X (ACC, ON START signal)		
4	Some of the seat system functions do not operate during automatic operation.	Sliding						
		Reclining						
		Lifting (Front)						
		Lifting (Rear)						
5	No automatic operation functions operate.				X	X		
6	Drive position cannot be retained in the memory.					X (IGN ON signal)	X	
7	Does not operate during manual operation. (Operates during automatic operation.)	Sliding			X			
		Reclining			X			
		Lifting (Front)			X			
		Lifting (Rear)			X			
8	Automatic operation cannot be canceled.				X			
9	Memory indicator does not light up.							X

X : Applicable

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)



## DIAGNOSTIC PROCEDURE 1

(Power supply and ground circuit for driver's seat control unit) =NAEL0369S04


### Power Supply Circuit Check

Check voltage between seat control unit LH terminal 1 and ground. NAEL0369S0401

Terminals	Ignition switch position			
	OFF	ACC	ON	START
1 - Ground	Battery voltage			

If NG, check the following.

- 40A fusible link (letter f, located in the fuse and fusible link box)
- Circuit breaker
- Harness for open or short between circuit breaker and seat control unit LH



### Ground Circuit Check

Check continuity between seat control unit LH terminal 33 and ground. NAEL0369S0402

Terminals	Continuity
33 - Ground	Yes

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 2 (Sliding encoder check)

=NAEL0369S05

<b>1</b>	<b>CHECK SLIDING ENCODER OUTPUT SIGNAL</b>	
<p>Measure voltage between seat control unit LH terminal 18 and ground with CONSULT-II or oscilloscope when power seat slide is operated.</p>		
SEL603W		
<b>OK or NG</b>		
OK	▶	Sliding encoder is OK.
NG	▶	GO TO 2.

<b>2</b>	<b>CHECK SLIDING ENCODER INPUT SIGNAL</b>	
<p>Check voltage between seat control unit LH terminal 17 and ground.</p>		
SEL604W		
<b>OK or NG</b>		
OK	▶	GO TO 3.
NG	▶	Replace seat control unit LH.

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

<b>3</b>	<b>CHECK SLIDING ENCODER OPEN CIRCUIT</b>													
<p>1. Disconnect seat control unit LH connector and sliding device LH connector.</p> <p>2. Check harness continuity between seat control unit LH connector and sliding device LH connector.</p>														
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Continuity</th> </tr> <tr> <th>Seat control unit LH</th> <th>Sliding device LH (Sliding encoder)</th> </tr> </thead> <tbody> <tr> <td>17</td> <td>3</td> <td rowspan="3" style="text-align: center;">Yes</td> </tr> <tr> <td>18</td> <td>4</td> </tr> <tr> <td>28</td> <td>5</td> </tr> </tbody> </table>		Terminals		Continuity	Seat control unit LH	Sliding device LH (Sliding encoder)	17	3	Yes	18	4	28	5	
Terminals		Continuity												
Seat control unit LH	Sliding device LH (Sliding encoder)													
17	3	Yes												
18	4													
28	5													
SEL605WA														
<b>OK or NG</b>														
OK	▶	GO TO 4.												
NG	▶	Repair harness.												

<b>4</b>	<b>CHECK SLIDING ENCODER SHORT CIRCUIT</b>							
Check harness continuity between seat control unit LH connector and ground.								
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Terminals</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>17 - Ground</td> <td rowspan="3" style="text-align: center;">No</td> </tr> <tr> <td>18 - Ground</td> </tr> <tr> <td>28 - Ground</td> </tr> </tbody> </table>		Terminals	Continuity	17 - Ground	No	18 - Ground	28 - Ground	
Terminals	Continuity							
17 - Ground	No							
18 - Ground								
28 - Ground								
SEL606W								
<b>OK or NG</b>								
OK	▶	Replace sliding encoder.						
NG	▶	Repair harness.						

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 3 (Reclining encoder check)

=NAEL0369S06

<b>1</b>	<b>CHECK RECLINING ENCODER OUTPUT SIGNAL</b>	
<p>Measure voltage between seat control unit LH terminal 29 and ground with CONSULT-II or oscilloscope when power seat reclining is operated.</p>		
SEL607W		
<b>OK or NG</b>		
OK	▶	Reclining encoder is OK.
NG	▶	GO TO 2.

<b>2</b>	<b>CHECK RECLINING ENCODER INPUT SIGNAL</b>	
<p>Check voltage between seat control unit LH terminal 17 and ground.</p>		
SEL608W		
<b>OK or NG</b>		
OK	▶	GO TO 3.
NG	▶	Replace seat control unit LH.

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

<b>3</b>	<b>CHECK RECLINING ENCODER OPEN CIRCUIT</b>	
<p>1. Disconnect seat control unit LH connector and reclining device LH connector.</p> <p>2. Check harness continuity between seat control unit LH connector and reclining LH connector.</p>		
		SEL609WA
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	Repair harness.

<b>4</b>	<b>CHECK RECLINING ENCODER SHORT CIRCUIT</b>	
<p>Check harness continuity between seat control unit LH connector and ground.</p>		
		SEL610W
<b>OK or NG</b>		
OK	▶	Replace reclining encoder.
NG	▶	Repair harness.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



# AUTOMATIC DRIVE POSITIONER


Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 4

[Lifting encoder (front) check]

=NAEL0369S07

<b>1</b>	<b>CHECK LIFTING ENCODER (FRONT) OUTPUT SIGNAL</b>	<p>Measure voltage between seat control unit LH terminal 19 and ground with CONSULT-II or oscilloscope when power seat lifting (front) is operated.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Seat control unit LH (B512)</p> </div> <div style="text-align: center;">  <p>HI: Approx. 5V LO: Approx. 0V</p> </div> </div> <p style="text-align: right;">SEL611W</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶	Lifting encoder (front) is OK.	
NG	▶	GO TO 2.	

<b>2</b>	<b>CHECK LIFTING ENCODER (FRONT) INPUT SIGNAL</b>	<p>Check voltage between seat control unit LH terminal 17 and ground.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Seat control unit LH (B512)</p> </div> <div style="text-align: center;"> <p><b>Battery voltage should exist.</b></p> </div> </div> <p style="text-align: right;">SEL612W</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶	GO TO 3.	
NG	▶	Replace seat control unit LH.	

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

**3 CHECK LIFTING ENCODER (FRONT) OPEN CIRCUIT**

1. Disconnect seat control unit LH connector and front lifting device LH connector.  
 2. Check harness continuity between seat control unit LH connector and front lifting device LH connector.

Seat control unit LH (8512)

Front lifting device LH connector (8516)

Terminals		Continuity
Seat control unit LH	Front lifting device LH Lifting encoder (front)	
17	4	Yes
19	5	
28	6	

SEL613WA

**OK or NG**

OK	▶	GO TO 4.
NG	▶	Repair harness.

**4 CHECK LIFTING ENCODER (FRONT) SHORT CIRCUIT**

Check harness continuity between seat control unit LH connector and ground.

Seat control unit LH (8512)

Terminals	Continuity
17 - Ground	No
19 - Ground	
28 - Ground	

SEL614W

**OK or NG**

OK	▶	Replace lifting encoder (front).
NG	▶	Repair harness.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 5 [Lifting encoder (rear) check]

=NAEL0369S08

<b>1</b>	<b>CHECK LIFTING ENCODER (REAR) OUTPUT SIGNAL</b>	
<p>Measure voltage between seat control unit LH terminal 30 and ground with CONSULT-II or oscilloscope when power seat lifting (rear) is operated.</p>		
SEL615W		
<b>OK or NG</b>		
OK	▶	Lifting encoder (rear) is OK.
NG	▶	GO TO 2.

<b>2</b>	<b>CHECK LIFTING ENCODER (REAR) INPUT SIGNAL</b>	
<p>Check voltage between seat control unit LH terminal 17 and ground.</p>		
SEL616W		
<b>OK or NG</b>		
OK	▶	GO TO 3.
NG	▶	Replace seat control unit LH.

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

<b>3</b>	<b>CHECK LIFTING ENCODER (REAR) OPEN CIRCUIT</b>													
<p>1. Disconnect seat control unit LH connector and rear lifting device LH connector.</p> <p>2. Check harness continuity between seat control unit LH connector and rear lifting device LH connector.</p>														
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Continuity</th> </tr> <tr> <th>Seat control unit LH</th> <th>Rear lifting device LH Lifting encoder (rear)</th> </tr> </thead> <tbody> <tr> <td>17</td> <td>4</td> <td rowspan="3" style="text-align: center;">Yes</td> </tr> <tr> <td>28</td> <td>6</td> </tr> <tr> <td>30</td> <td>5</td> </tr> </tbody> </table>		Terminals		Continuity	Seat control unit LH	Rear lifting device LH Lifting encoder (rear)	17	4	Yes	28	6	30	5	
Terminals		Continuity												
Seat control unit LH	Rear lifting device LH Lifting encoder (rear)													
17	4	Yes												
28	6													
30	5													
SEL617WA														
<b>OK or NG</b>														
OK	▶	GO TO 4.												
NG	▶	Repair harness.												

<b>4</b>	<b>CHECK LIFTING ENCODER (REAR) SHORT CIRCUIT</b>							
Check harness continuity between seat control unit LH connector and ground.								
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Terminals</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td>17 - Ground</td> <td rowspan="3" style="text-align: center;">No</td> </tr> <tr> <td>28 - Ground</td> </tr> <tr> <td>30 - Ground</td> </tr> </tbody> </table>		Terminals	Continuity	17 - Ground	No	28 - Ground	30 - Ground	
Terminals	Continuity							
17 - Ground	No							
28 - Ground								
30 - Ground								
SEL618W								
<b>OK or NG</b>								
OK	▶	Replace lifting encoder (rear).						
NG	▶	Repair harness.						


GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
 EL  
 IDX


# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 6 (Sliding motor check)

=NAEL0369S09

<b>1</b>	<b>CHECK OUTPUT SIGNAL TO SLIDING MOTOR</b>															
<p>Check voltage between seat control unit LH terminals 3 or 10 and ground.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  <p>Seat control unit LH (B513)</p> </div> <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th rowspan="2">Condition of sliding switch</th> <th colspan="2">Terminals</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>+</th> <th>-</th> </tr> </thead> <tbody> <tr> <td>Forward</td> <td>3</td> <td>Ground</td> <td>Approx. 12</td> </tr> <tr> <td>Backward</td> <td>10</td> <td>Ground</td> <td>Approx. 12</td> </tr> </tbody> </table> </div>			Condition of sliding switch	Terminals		Voltage [V]	+	-	Forward	3	Ground	Approx. 12	Backward	10	Ground	Approx. 12
Condition of sliding switch	Terminals			Voltage [V]												
	+	-														
Forward	3	Ground	Approx. 12													
Backward	10	Ground	Approx. 12													
SEL619W																
<b>OK or NG</b>																
OK	▶	GO TO 2.														
NG	▶	Replace seat control unit LH.														

<b>2</b>	<b>CHECK SLIDING MOTOR</b>												
<p>1. Disconnect sliding device LH connector. 2. Apply 12V DC direct current to motor and check operation.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  <p>Sliding device LH (B518)</p> </div> <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Operation</th> </tr> <tr> <th>+</th> <th>-</th> </tr> </thead> <tbody> <tr> <td>2</td> <td>1</td> <td>Forward</td> </tr> <tr> <td>1</td> <td>2</td> <td>Backward</td> </tr> </tbody> </table> </div>			Terminals		Operation	+	-	2	1	Forward	1	2	Backward
Terminals		Operation											
+	-												
2	1	Forward											
1	2	Backward											
SEL620WA													
<b>OK or NG</b>													
OK	▶	Check harness for operation between seat control unit LH and sliding motor.											
NG	▶	Replace sliding motor.											

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 7 (Reclining motor check)

=NAEL0369S10

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

**1 CHECK OUTPUT SIGNAL TO RECLINING MOTOR**

Check voltage between seat control unit LH terminals 4 or 12 and ground.

Condition of reclining switch	Terminals		Voltage [V]
	+	-	
Forward	4	Ground	Approx. 12
Backward	12	Ground	Approx. 12

SEL621W

**OK or NG**

OK	▶	GO TO 2.
NG	▶	Replace seat control unit LH.

**2 CHECK RECLINING MOTOR**

1. Disconnect reclining device LH connector.
2. Apply 12V DC direct current to motor and check operation.

Terminals		Operation
+	-	
1	3	Forward
3	1	Backward

SEL622WA

**OK or NG**

OK	▶	Check harness for operation between seat control unit LH and reclining motor.
NG	▶	Replace reclining motor.

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 8

### [Lifting motor (front) check]

=NAEL0369S11

<b>1</b>	<b>CHECK OUTPUT SIGNAL TO LIFTING MOTOR (FRONT)</b>															
<p>Check voltage between seat control unit LH terminals 5 or 13 and ground.</p>																
<p>Seat control unit LH (BS13)</p>																
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th rowspan="2">Condition of lifting switch (front)</th> <th colspan="2">Terminals</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>+</th> <th>-</th> </tr> </thead> <tbody> <tr> <td>Up</td> <td>13</td> <td>Ground</td> <td>Approx. 12</td> </tr> <tr> <td>Down</td> <td>5</td> <td>Ground</td> <td>Approx. 12</td> </tr> </tbody> </table>			Condition of lifting switch (front)	Terminals		Voltage [V]	+	-	Up	13	Ground	Approx. 12	Down	5	Ground	Approx. 12
Condition of lifting switch (front)	Terminals			Voltage [V]												
	+	-														
Up	13	Ground	Approx. 12													
Down	5	Ground	Approx. 12													
SEL623W																
<b>OK or NG</b>																
OK	▶	GO TO 2.														
NG	▶	Replace seat control unit LH.														

<b>2</b>	<b>CHECK LIFTING MOTOR (FRONT)</b>												
<p>1. Disconnect front lifting device LH connector. 2. Apply 12V DC direct current to motor and check operation.</p>													
<p>Front lifting device LH (BS18)</p>													
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Operation</th> </tr> <tr> <th>+</th> <th>-</th> </tr> </thead> <tbody> <tr> <td>3</td> <td>1</td> <td>Up</td> </tr> <tr> <td>1</td> <td>3</td> <td>Down</td> </tr> </tbody> </table>			Terminals		Operation	+	-	3	1	Up	1	3	Down
Terminals		Operation											
+	-												
3	1	Up											
1	3	Down											
SEL624WA													
<b>OK or NG</b>													
OK	▶	Check harness for operation between seat control unit LH and lifting motor (front).											
NG	▶	Replace lifting motor (front).											

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 9

### [Lifting motor (rear) check]

=NAEL0369S12

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

<b>1</b>	<b>CHECK OUTPUT SIGNAL TO LIFTING MOTOR (REAR)</b>															
<p>Check voltage between seat control unit LH terminals 6 or 7 and ground.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 45%;"> <p>Seat control unit LH (8513)</p> </div> <div style="width: 45%;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Condition of lifting switch (rear)</th> <th colspan="2">Terminals</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>+</th> <th>-</th> </tr> </thead> <tbody> <tr> <td>Up</td> <td>6</td> <td>Ground</td> <td>Approx. 12</td> </tr> <tr> <td>Down</td> <td>7</td> <td>Ground</td> <td>Approx. 12</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL625W</p> <p style="text-align: center;"><b>OK or NG</b></p>			Condition of lifting switch (rear)	Terminals		Voltage [V]	+	-	Up	6	Ground	Approx. 12	Down	7	Ground	Approx. 12
Condition of lifting switch (rear)	Terminals			Voltage [V]												
	+	-														
Up	6	Ground	Approx. 12													
Down	7	Ground	Approx. 12													
OK	▶	GO TO 2.														
NG	▶	Replace seat control unit LH.														


<b>2</b>	<b>CHECK LIFTING MOTOR (REAR)</b>												
<p>1. Disconnect rear lifting device LH connector. 2. Apply 12V DC direct current to motor and check operation.</p> <div style="display: flex; justify-content: space-between; align-items: center;"> <div style="width: 45%;"> <p>Rear lifting device LH (8517)</p> </div> <div style="width: 45%;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2">Terminals</th> <th rowspan="2">Operation</th> </tr> <tr> <th>+</th> <th>-</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>3</td> <td>Up</td> </tr> <tr> <td>3</td> <td>1</td> <td>Down</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL626WA</p> <p style="text-align: center;"><b>OK or NG</b></p>			Terminals		Operation	+	-	1	3	Up	3	1	Down
Terminals		Operation											
+	-												
1	3	Up											
3	1	Down											
OK	▶	Check harness for operation between seat control unit LH and lifting motor (rear).											
NG	▶	Replace lifting motor (rear).											

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 10 (Power seat switch check)

=NAEL0369S13

<b>1</b>	<b>CHECK POWER SEAT SWITCH</b>	<p>1. Disconnect power seat switch LH connector. 2. Check continuity between power seat switch terminals.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Power seat switch LH (B514)</p> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr><td>1</td><td>2</td><td>3</td><td>4</td></tr> <tr><td>5</td><td>6</td><td>8</td><td>9 10</td></tr> </table> <p>1, 2, 3, 4, 5, 6, 9, 10</p>  </div> <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th rowspan="2">Switch</th> <th rowspan="2">Condition</th> <th colspan="10">Terminals</th> </tr> <tr> <th>8</th><th>1</th><th>2</th><th>3</th><th>4</th><th>5</th><th>6</th><th>9</th><th>10</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Sliding</td> <td>Forward</td> <td>○</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>○</td> </tr> <tr> <td>Backward</td> <td>○</td><td></td><td></td><td></td><td>○</td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td rowspan="2">Reclining</td> <td>Forward</td> <td>○</td><td>○</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td>Backward</td> <td>○</td><td></td><td>○</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> <tr> <td rowspan="2">Lifting (Front)</td> <td>Up</td> <td>○</td><td></td><td></td><td></td><td></td><td>○</td><td></td><td></td><td></td><td></td> </tr> <tr> <td>Down</td> <td>○</td><td></td><td></td><td></td><td></td><td></td><td>○</td><td></td><td></td><td></td> </tr> <tr> <td rowspan="2">Lifting (Rear)</td> <td>Up</td> <td>○</td><td></td><td></td><td></td><td></td><td></td><td></td><td>○</td><td></td><td></td> </tr> <tr> <td>Down</td> <td>○</td><td></td><td></td><td>○</td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </tbody> </table> </div>		1	2	3	4	5	6	8	9 10	Switch	Condition	Terminals										8	1	2	3	4	5	6	9	10	Sliding	Forward	○									○	Backward	○				○						Reclining	Forward	○	○									Backward	○		○								Lifting (Front)	Up	○					○					Down	○						○				Lifting (Rear)	Up	○							○			Down	○			○						
1	2	3	4																																																																																																																									
5	6	8	9 10																																																																																																																									
Switch	Condition	Terminals																																																																																																																										
		8	1	2	3	4	5	6	9	10																																																																																																																		
Sliding	Forward	○									○																																																																																																																	
	Backward	○				○																																																																																																																						
Reclining	Forward	○	○																																																																																																																									
	Backward	○		○																																																																																																																								
Lifting (Front)	Up	○					○																																																																																																																					
	Down	○						○																																																																																																																				
Lifting (Rear)	Up	○							○																																																																																																																			
	Down	○			○																																																																																																																							
<b>OK or NG</b>																																																																																																																												
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Ground circuit for power seat switch</li> <li>● Harness for open or short between seat control unit LH and power seat switch</li> </ul>																																																																																																																										
NG	▶	<p>Replace power seat switch.</p>																																																																																																																										

SEL569X

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 11 (Cancel switch check)

=NAEL0369S14

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX


1		CHECK CANCEL SWITCH								
<p>1. Disconnect cancel switch connector. 2. Check continuity between cancel switch terminals.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="border: 1px solid black; padding: 5px;"> <table border="1"> <thead> <tr> <th>Terminals</th> <th>Cancel switch condition</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">1-2</td> <td>ON</td> <td>Yes</td> </tr> <tr> <td>OFF</td> <td>No</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL628WA</p>			Terminals	Cancel switch condition	Continuity	1-2	ON	Yes	OFF	No
Terminals	Cancel switch condition	Continuity								
1-2	ON	Yes								
	OFF	No								
<b>OK or NG</b>										
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Ground circuit for cancel switch</li> <li>● Harness for open or short between seat control unit LH and cancel switch</li> </ul>								
NG	▶	Replace cancel switch.								


# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 12

(Key, detention, door switch and vehicle speed signal check) =NAEL0369S15

<b>1</b>	<b>CHECK KEY SWITCH INPUT SIGNAL</b>							
<p>Check voltage between seat control unit LH terminal 2 and ground.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  <p>Seat control unit LH (6513)</p>  </div> <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th style="border: none;">Condition</th> <th style="border: none;">Voltage [V]</th> </tr> </thead> <tbody> <tr> <td style="border: none;">Key is inserted</td> <td style="border: none;">Approx. 12</td> </tr> <tr> <td style="border: none;">Key is removed</td> <td style="border: none;">0</td> </tr> </tbody> </table> </div> <p style="text-align: right; font-size: small;">SEL629W</p>			Condition	Voltage [V]	Key is inserted	Approx. 12	Key is removed	0
Condition	Voltage [V]							
Key is inserted	Approx. 12							
Key is removed	0							
<b>OK or NG</b>								
OK	▶	GO TO 2.						
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 24, located in fuse block (J/B)]</li> <li>● Key switch</li> <li>● Harness for open or short between key switch and fuse</li> <li>● Harness for open or short between seat control unit LH and key switch</li> </ul>						

<b>2</b>	<b>CHECK IGNITION SWITCH INPUT SIGNAL (ON AND START)</b>																					
<p>Check voltage between seat control unit LH terminals and ground.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  <p>Seat control unit LH (6512)</p>  </div> <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2" style="border: none;">Terminals</th> <th colspan="3" style="border: none;">Ignition switch position</th> </tr> <tr> <th style="border: none;">+</th> <th style="border: none;">-</th> <th style="border: none;">OFF</th> <th style="border: none;">ON</th> <th style="border: none;">START</th> </tr> </thead> <tbody> <tr> <td style="border: none;">20</td> <td style="border: none;">Ground</td> <td style="border: none;">Approx. 0V</td> <td colspan="2" style="border: none;">Battery voltage</td> </tr> <tr> <td style="border: none;">31</td> <td style="border: none;">Ground</td> <td colspan="2" style="border: none;">Approx. 0V</td> <td style="border: none;">Batttery voltage</td> </tr> </tbody> </table> </div> <p style="text-align: right; font-size: small;">SEL630W</p>			Terminals		Ignition switch position			+	-	OFF	ON	START	20	Ground	Approx. 0V	Battery voltage		31	Ground	Approx. 0V		Batttery voltage
Terminals		Ignition switch position																				
+	-	OFF	ON	START																		
20	Ground	Approx. 0V	Battery voltage																			
31	Ground	Approx. 0V		Batttery voltage																		
<b>OK or NG</b>																						
OK	▶	GO TO 3.																				
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 11, located in fuse block (J/B)]</li> <li>● 7.5A fuse [No. 26, located in fuse block (J/B)]</li> <li>● Harness for open or short between seat control unit LH and fuse</li> </ul>																				

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

<b>3</b>	<b>CHECK PARK POSITION SWITCH INPUT SIGNAL</b>	
Check voltage between seat control unit LH terminal 21 and ground.		
		SEL631W
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	<b>Check the following.</b> <ul style="list-style-type: none"> <li>● Park position switch</li> <li>● Park position switch ground circuit</li> <li>● Harness for open or short between seat control unit LH and park position switch</li> </ul>

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT

<b>4</b>	<b>CHECK DRIVER DOOR SWITCH INPUT SIGNAL</b>	
Check voltage between seat control unit LH terminal 9 and ground.		
		SEL632W
<b>OK or NG</b>		
OK	▶	GO TO 5.
NG	▶	<b>Check the following.</b> <ul style="list-style-type: none"> <li>● Driver door switch</li> <li>● Driver door switch ground circuit</li> <li>● Harness for open or short between seat control unit LH and driver door switch</li> </ul>

AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS

<b>5</b>	<b>CHECK VEHICLE SPEED SIGNAL</b>	
Does speedometer operate normally?		
<b>Yes or No</b>		
OK	▶	GO TO 6.
NG	▶	Check speedometer and ABS actuator and electric unit circuit. Refer to EL-127.

BT  
HA  
SC

EL


IDX

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## 6 CHECK VEHICLE SPEED SIGNAL PULL UP VOLTAGE

1. Turn ignition switch "ON".
2. Check voltage between seat control unit LH terminal 32 and ground.



Approx. 5V should exist.

SEL633W

OK or NG


OK	▶	Harness for open or short between seat control unit LH and combination meter.
NG	▶	Repair harness.

# AUTOMATIC DRIVE POSITIONER

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 13 (Seat memory switch check)


=NAEL0369S16

<b>1</b>	<b>CHECK SEAT MEMORY SWITCH</b>	
<p>1. Disconnect seat memory switch connector. 2. Check continuity between seat memory switch terminals.</p>		
		
SEL634WA		
<b>OK or NG</b>		
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Ground circuit for seat memory switch</li> <li>● Harness for open or short between seat control unit LH and seat memory switch</li> </ul>
NG	▶	Replace seat memory switch.

## DIAGNOSTIC PROCEDURE 14 (Memory indicator check)

NAEL0369S17

<b>1</b>	<b>CHECK INDICATOR LAMP</b>	
Check indicator lamp illumination.		
<b>OK or NG</b>		
OK	▶	GO TO 2.
NG	▶	Replace seat memory switch (indicator lamp).

<b>2</b>	<b>CHECK POWER SUPPLY CIRCUIT FOR INDICATOR LAMP</b>	
<p>1. Disconnect seat memory switch connector. 2. Check voltage between seat memory switch terminal and ground.</p>		
		
<b>Battery voltage should exist.</b>		
SEL635WA		
<b>OK or NG</b>		
OK	▶	Check harness for open or short between seat control unit LH and seat memory switch
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 24 located in the fuse block (J/B)]</li> <li>● Harness for open or short between fuse and indicator lamp</li> </ul>



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0370



SEL256Y

## System Description

Refer to Owner's Manual for ASCD operating instructions.

NAEL0371

GI

### POWER SUPPLY AND GROUND

NAEL0371S01

MA

Power is supplied at all times:

- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to the stop lamp switch terminal 1, and
- through 7.5A fuse (No. 52, located in fuse and fusible link box)
- to the horn relay terminals 1 and 3.

EM

LC

When ignition switch is in the ON or START position, power is supplied:

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to ASCD brake switch terminal 1 and
- to ASCD control unit terminal 5,
- through 10A fuse [No. 18, located in the fuse block (J/B)]
- to park/neutral position relay terminal 1,
- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to combination meter terminal 66, and

EC

FE

CL

When park/neutral position switch is in the P or N position (A/T models), ground is supplied:

- to park/neutral position relay terminal 2
- through park/neutral position switch and body grounds B55 and B75.

MT

When ASCD main switch is depressed (ON), ground is supplied:

- to ASCD control unit terminal 9
- from ASCD steering switch terminal 4
- to ASCD steering switch terminal 5
- through body grounds M4, M66 and M147

AT

TF

then ASCD control unit holds CRUISE condition and illuminates CRUISE indicator.

Ground is supplied:

- from ASCD control unit terminal 15
- to combination meter terminal 46.

PD

AX

### OPERATION

#### Set Operation

NAEL0371S02

SU

To activate the ASCD, all following conditions must exist.

- Ground is supplied to ASCD control unit terminal 9 (Main switch is in ON position.)
- Power is supplied to ASCD control unit terminal 8 [Brake pedal and clutch pedal are released (M/T models) and brake pedal is released and A/T selector lever is in other than P and N position (A/T models)].
- Vehicle speed is between 40 km/h (25 MPH) and 144 km/h (89 MPH). (Signal from combination meter)

BR

ST

When the SET/COAST switch is depressed, power is supplied:

- from ASCD steering switch terminal 2
- to ASCD control unit terminal 11.

RS

And then ASCD pump is activated to control throttle wire and ASCD control unit supply ground

- to combination meter terminals 51 to illuminate SET indicator.

BT

#### A/T Overdrive Control during Cruise Control Driving (A/T models)

NAEL0371S0202

When the vehicle speed is approximately 3 km/h (2 MPH) below set speed, a signal is sent

- from ASCD control unit terminal 10
- to TCM (transmission control module) terminal 24.

HA

SC

When this occurs, the TCM (transmission control module) cancels overdrive.

After vehicle speed is approximately 1 km/h (1 MPH) below set speed, overdrive is reactivated.

#### ASCD Shifting Control (A/T models)

NAEL0371S0203

During ASCD cruise, ASCD control unit controls A/T shifting to avoid uncomfortable shifting. This is used to control the signals below.

- Throttle position sensor from ECM

EL

IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## System Description (Cont'd)

- A/T shift solenoid valve A

### Coast Operation

NAEL0371S0204

When the SET/COAST switch is depressed during cruise control driving, ASCD actuator returns the throttle cable to decrease vehicle set speed until the switch is released. And then ASCD will keep the new set speed.

### Accel Operation

NAEL0371S0205

When the RESUME/ACCEL switch is depressed, power is supplied

- from ASCD steering switch terminal 3
- to ASCD control unit terminal 24.

If the RESUME/ACCEL switch is depressed during cruise control driving, ASCD actuator pulls the throttle cable to increase the vehicle speed until the switch is released or vehicle speed is reached to maximum controlled speed by the system. And then ASCD will keep the new set speed.

### Cancel Operation

NAEL0371S0206

When any of following condition exists, cruise operation will be canceled.

- CANCEL switch is depressed. (Power supply to ASCD control unit terminals 11 and 24)
- Brake pedal is depressed. (Power supply to ASCD control unit terminal 23 from stop lamp switch)
- Brake pedal or clutch pedal is depressed (M/T models)/brake pedal is depressed or A/T selector lever is shifted to P or N position (A/T models). (Power supply to ASCD control unit terminal 8 is interrupted.)

If MAIN switch is turned to OFF during ASCD is activated, all of ASCD operation will be canceled and vehicle speed memory will be erased.

### Resume Operation

NAEL0371S0207

When the RESUME/ACCEL switch is depressed after cancel operation other than depressing MAIN switch is performed, vehicle speed will return to last set speed. To resume vehicle set speed, vehicle condition must meet following conditions.

- Brake pedal is released.
- Clutch pedal is released (M/T models).
- A/T selector lever is in other than P and N position (A/T models).
- Vehicle speed is between 40 km/h (25 MPH) and 144 km/h (89 MPH).

### ASCD PUMP OPERATION

NAEL0371S03

The ASCD pump consists of a vacuum motor, an air valve and a release valve. When the ASCD activates, power is supplied

- from terminal 12 of ASCD control unit
- to ASCD pump terminal 1.

Ground is supplied to vacuum motor, air valve and release valve from ASCD control unit depending on the operated condition as shown in the below table.

The pump is connected to ASCD actuator by vacuum hose. When the ASCD pump is activated, the ASCD pump vacuum the diaphragm of ASCD actuator to control throttle cable.

		Air valve (*1)	Release valve (*1)	Vacuum motor	Actuator inner pressure
ASCD not operating		Open	Open	Stopped	Atmosphere
ASCD operating	Releasing throttle cable	Open	Closed	Stopped	Vacuum
	Holding throttle position	Closed	Closed	Stopped	Vacuum (*2)
	Pulling throttle cable	Closed	Closed	Operated	Vacuum

\*1: When power and ground is supplied, valve is closed.


\*2: Set position held.

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Schematic

## Schematic

NAEL0372



GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
**EL**  
 IDX

MEL424P

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD —

## Wiring Diagram — ASCD —



NAEL0373

NAEL0373S01

FIG. 1

### EL-ASCD-01

- A : A/T models
- M : M/T models



REFER TO THE FOLLOWING.

- E1 -SUPER
- MULTIPLE JUNCTION (SMJ)
- M10 -FUSE BLOCK-
- JUNCTION BOX (J/B)


# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)


FIG. 2

NAEL0373S02

EL-ASCD-02



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



REFER TO THE FOLLOWING.  
 (E1) -SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (M10) -FUSE BLOCK-  
 JUNCTION BOX (J/B)

\* : This connector is not shown in "HARNESS LAYOUT", EL section.

MEL9160



# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

**FIG. 3**

NAEL0373S03

## EL-ASCD-03



REFER TO THE FOLLOWING.  
 (E1) -SUPER  
 MULTIPLE JUNCTION (SMJ)  
 (F24) -ELECTRICAL UNITS

\* : This connector is not shown in "HARNESS LAYOUT", EL section.

MEL425P


# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)





FIG. 4

NAEL0373S04

EL-ASCD-04



Preceding page



REFER TO THE FOLLOWING.

(E1) -SUPER MULTIPLE

JUNCTION (SMJ)

(M10) -FUSE BLOCK-


JUNCTION BOX (J/B)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL426P

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Fail-safe System



## Fail-safe System

NAEL0374

### DESCRIPTION

NAEL0374S01

When the fail-safe system senses a malfunction, it deactivates ASCD operation. The SET indicator in the combination meter will then flash.

## MALFUNCTION DETECTION CONDITIONS

NAEL0374S02

Detection conditions	ASCD operation during malfunction detection
<ul style="list-style-type: none"> <li>● ASCD steering (RESUME/ACCEL, CANCEL, SET/COAST) switch is stuck.</li> <li>● Vacuum motor ground circuit or power circuit is open or shorted.</li> <li>● Air valve ground circuit or power circuit is open or shorted.</li> <li>● Release valve ground circuit or power circuit is open or shorted.</li> <li>● Vehicle speed sensor is faulty.</li> <li>● ASCD control unit internal circuit is malfunctioning.</li> </ul>	<ul style="list-style-type: none"> <li>● ASCD is deactivated.</li> <li>● Vehicle speed memory is canceled.</li> </ul>
<ul style="list-style-type: none"> <li>● ASCD brake switch or stop lamp switch is faulty.</li> </ul>	<ul style="list-style-type: none"> <li>● ASCD is deactivated.</li> <li>● Vehicle speed memory is not canceled.</li> </ul>

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses

## Trouble Diagnoses SYMPTOM CHART

NAEL0375

NAEL0375S01

PROCEDURE	Diagnostic procedure						
REFERENCE PAGE (EL- )	258	259	260	261	262	262	264
SYMPTOM	FAIL-SAFE SYSTEM CHECK	POWER SUPPLY AND GROUND CIRCUIT CHECK	ASCD BRAKE/STOP LAMP SWITCH CHECK	ASCD STEERING SWITCH CHECK	VEHICLE SPEED SENSOR CHECK	ASCD PUMP CIRCUIT CHECK	ASCD ACTUATOR/PUMP CHECK
ASCD cannot be set. ("CRUISE" indicator lamp does not ON.)		X		X★3			
ASCD cannot be set. ("SET" indicator lamp does not blink.)			X	X	X		
ASCD cannot be set. ("SET" indicator lamp blinks.★1)	X		X	X	X	X	
Vehicle speed does not decrease after SET/COAST switch has been pressed.				X			X
Vehicle speed does not return to the set speed after RESUME/ACCEL switch has been pressed.★2				X			X
Vehicle speed does not increase after RESUME/ACCEL switch has been pressed.				X			X
System is not released after CANCEL switch (steering) has been pressed.				X			X
Large difference between set speed and actual vehicle speed.					X	X	X
Deceleration is greatest immediately after ASCD has been set.					X	X	X

★1: It indicates that system is in fail-safe. After completing diagnostic procedures, perform "FAIL-SAFE SYSTEM CHECK" (EL-258) to verify repairs.

★2: If vehicle speed is greater than 40 km/h (25 MPH) after system has been released, pressing RESUME/ACCEL switch returns vehicle speed to the set speed previously achieved. However, doing so when the ASCD main switch is turned to "OFF", vehicle speed will not return to the set speed since the memory is canceled.

★3: Check only main switch built-in steering switch.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)




## FAIL-SAFE SYSTEM CHECK

=NAEL0375S02

1. Turn ignition switch to ON position.
2. Turn ASCD main switch to ON and check if the SET indicator blinks.

**If the indicator lamp blinks, check the following.**


- ASCD steering switch. Refer to EL-261.



3. Drive the vehicle at more than 40 km/h (25 MPH) and push SET/COAST switch.

**If the indicator lamp blinks, check the following.**

- Vehicle speed signal. Refer to EL-262.
- ASCD pump circuit. Refer to EL-262.
- Replace control unit.



4. Depress brake pedal slowly (brake pedal should be depressed more than 5 seconds).

**If the indicator lamp blinks, check the following.**

- ASCD brake/stop lamp switch. Refer to EL-260.

5. END. (System is OK.)


# AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Trouble Diagnoses (Cont'd)

## POWER SUPPLY AND GROUND CIRCUIT CHECK

=NAEL0375S03

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

<b>1</b>	<b>CHECK POWER SUPPLY CIRCUIT FOR ASCD CONTROL UNIT</b>	
<p>1. Disconnect ASCD control unit harness connector.                  2. Turn ignition switch ON.                  3. Check voltage between ASCD control unit harness connector terminal 5 and ground.</p>		
<p>ASCD control unit connector (M3)</p>  <p>Does battery voltage exist?</p>		
SEL256WB		
Refer to wiring diagram in EL-254.		
Yes	▶	GO TO 2.
No	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 11, located in the fuse block (J/B)]</li> <li>● Harness for open or short between ASCD control unit and fuse</li> </ul>


<b>2</b>	<b>CHECK GROUND CIRCUIT FOR ASCD CONTROL UNIT</b>	
Check continuity between ASCD control unit harness connector terminal 17 and body ground.		
<p>ASCD control unit connector (M3)</p>  <p>Does continuity exist?</p>		
SEL257WB		
Refer to wiring diagram in EL-254.		
Yes	▶	Power supply and ground circuit is OK.
No	▶	Repair harness.


# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

## ASCD BRAKE/STOP LAMP SWITCH CHECK

=NAEL0375S04

<b>1</b>	<b>CHECK ASCD BRAKE SWITCH CIRCUIT</b>
<p>1. Disconnect ASCD control unit harness connector.                  2. Turn ignition switch ON.                  3. Check voltage between ASCD control unit harness connector M3 terminal 8 and ground.</p>	
<div style="display: flex; justify-content: space-between;"> <div style="width: 30%;">  <p>DISCONNECT H.S. ASCN ASCN ASCN control unit connector</p> </div> <div style="width: 65%;"> <p>When brake or clutch pedal is depressed (M/T), or when brake pedal is depressed or A/T selector lever is in "N" or "P" range (A/T):  <b>Approx. 0V</b></p> <p>When brake and clutch pedal are released (M/T), or when both brake pedal is released and A/T selector lever is not in "N" or "P" range (A/T):  <b>Battery voltage should exist.</b></p> </div> </div>	
SEL258WF	
<b>OK or NG</b>	
OK	▶ GO TO 2.
NG	▶ <b>Check the following.</b>
	<ul style="list-style-type: none"> <li>● ASCD brake switch Refer to "Electrical Component Inspection" (EL-266).</li> <li>● ASCD clutch switch (M/T models) Refer to "Electrical Component Inspection" (EL-266).</li> <li>● Park/neutral position switch (A/T models) Refer to "Electrical Component Inspection" (EL-266).</li> <li>● Park/neutral position relay (A/T models)</li> <li>● Harness for open or short</li> </ul>

<b>2</b>	<b>CHECK STOP LAMP SWITCH CIRCUIT</b>
<p>1. Disconnect ASCD control unit harness connector.                  2. Check voltage between ASCD control unit harness connector terminal 23 and ground.</p>	
<div style="display: flex; justify-content: space-between;"> <div style="width: 30%;">  <p>DISCONNECT H.S. ASCN ASCN ASCN control unit connector (M3)</p> </div> <div style="width: 65%;"> <p>Voltage [V]:                      Stop lamp switch: Depressed  <b>Approx. 12</b>                      Stop lamp switch: Released  <b>0</b></p> </div> </div>	
Refer to wiring diagram in EL-253.	
SEL259WB	
<b>OK or NG</b>	
OK	▶ ASCD brake/stop lamp switch is OK.
NG	▶ <b>Check the following.</b>
	<ul style="list-style-type: none"> <li>● 10A fuse [No. 14, located in the fuse block (J/B)]</li> <li>● Harness for open or short between ASCD control unit and stop lamp switch</li> <li>● Harness for open or short between fuse and stop lamp switch</li> <li>● Stop lamp switch Refer to "Electrical Component Inspection" (EL-266).</li> </ul>

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

## ASCD STEERING SWITCH CHECK

=NAEL0375S05

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

**1 CHECK ASCD STEERING SWITCH CIRCUIT FOR ASCD CONTROL UNIT**

Check voltage between ASCD control unit harness connector terminals and ground.

	Terminal No.		Switch condition	
	(+)	(-)	Pressed	Released
MAIN SW	9	Ground	0V	Approx. 9V
SET/COAST SW	11	Ground	12V	0V
RESUME/ACC SW	24	Ground	12V	0V
CANCEL SW	11	Ground	12V	0V
	24	Ground	12V	0V

Refer to wiring diagram in EL-253.

SEL260WC

**OK or NG**

OK	▶	ASCD steering switch is OK.
NG	▶	GO TO 2.

**2 CHECK POWER SUPPLY FOR ASCD STEERING SWITCH**

**Does horn work?**

Yes	▶	GO TO 3.
No	▶	<b>Check the following.</b> <ul style="list-style-type: none"> <li>● 7.5A fuse (No. 52, located in the relay box)</li> <li>● Horn relay</li> <li>● Horn circuit</li> </ul>

**3 CHECK ASCD STEERING SWITCH**

1. Disconnect ASCD steering switch.  
2. Check continuity between ASCD steering switch harness connector Z30 terminals by pushing each switch.

Switch	Condition	Terminal				
		1	2	3	4	6
MAIN	ON				○	○
RESUME/ACCEL	ON	○		○		
SET/COAST	ON	○	○			
CANCEL	ON	○	▶	○		
		○	▶	○		

SEL495Y

**OK or NG**

OK	▶	Check harness for open or short between ASCD steering switch and ASCD control unit.
NG	▶	Replace ASCD steering switch.


# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

## VEHICLE SPEED SIGNAL CHECK


=NAEL0375S06

<b>1</b>	<b>CHECK SPEEDOMETER OPERATION</b>	
<b>Does speedometer operate normally?</b>		
Yes	▶	GO TO 2.
No	▶	Check speedometer and ABS actuator and electric unit circuit. Refer to wiring diagram in EL-255.

<b>2</b>	<b>CHECK VEHICLE SPEED INPUT</b>	
<p>1. Apply wheel chocks and jack up drive wheel.                  2. Disconnect ASCD control unit harness connector.                  3. Check voltage between control unit terminal 22 and ground with turning drive wheel slowly by hand.</p>		
		
<b>Does voltage pointer deflect?</b>		
SEL263WB		
Refer to wiring diagram in EL-254.		
Yes	▶	Vehicle speed signal is OK.
No	▶	Check harness for open or short between ASCD control unit terminal 22 and combination meter terminal 13.

## ASCD PUMP CIRCUIT CHECK

NAEL0375S07

<b>1</b>	<b>CHECK ASCD PUMP</b>											
<p>1. Disconnect ASCD pump connector.                  2. Measure resistance between ASCD pump terminals 1 and 2, 3, 4.</p>												
<p>ASCD pump connector (E59)</p> 												
		<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th style="width: 10%;"></th> <th style="width: 15%;">Terminals</th> <th style="width: 75%;">Resistance Ω</th> </tr> </thead> <tbody> <tr> <td rowspan="3" style="text-align: center; vertical-align: middle;">1</td> <td style="text-align: center;">2</td> <td style="text-align: center;">Approx. 65</td> </tr> <tr> <td style="text-align: center;">3</td> <td style="text-align: center;">Approx. 65</td> </tr> <tr> <td style="text-align: center;">4</td> <td style="text-align: center;">Approx. 3</td> </tr> </tbody> </table>		Terminals	Resistance Ω	1	2	Approx. 65	3	Approx. 65	4	Approx. 3
	Terminals	Resistance Ω										
1	2	Approx. 65										
	3	Approx. 65										
	4	Approx. 3										
SEL262WB												
Refer to wiring diagram in EL-254.												
<b>OK or NG</b>												
OK	▶	GO TO 2.										
NG	▶	Replace ASCD pump.										

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

**2 CHECK ASCD PUMP CIRCUIT**

1. Disconnect ASCD control unit harness connector.  
 2. Check harness for open or short between ASCD control unit and ASCD pump.



DISCONNECT  
H.S.




DISCONNECT  
E




OFF


ASCD control unit connector (M3)



1, 12, 13, 14



1, 2, 3, 4



Circuit	Terminal	
	ASCD control unit	ASCD pump
ASCD pump power supply	12	1
Air valve	13	2
Release valve	1	3
Vacuum motor	14	4

**Continuity should exist.**

SEL269WB

OK or NG

OK

▶

GO TO 3.

NG

▶

Repair harness.

**3 CHECK ASCD PUMP POWER SUPPLY**

1. Jack-up the drive wheels.  
 2. Maintain the conditions below.

- Vehicle speed is more than 40 km/h (25 MPH).
- Main switch (CRUISE lamp) is ON.
- Set/coast switch (SET lamp) is ON.

Check voltage between ASCD control unit harness connector terminal 12 and ground.




CONNECT  
H.S.



CONNECT  
E




ASCD control unit connector (M3)



12

W



**Battery voltage should exist.**

SEL381WB

OK or NG

OK

▶

ASCD pump power supply is OK.

NG

▶

Replace ASCD control unit.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Trouble Diagnoses (Cont'd)

## ASCD ACTUATOR/PUMP CHECK

=NAEL0375S08


<b>1</b>	<b>CHECK VACUUM HOSE</b>	
<p>Check vacuum hose (between ASCD actuator and ASCD pump) for breakage, cracks or fracture.</p>		
		
MEL402G		
<b>OK or NG</b>		
OK	▶	GO TO 2.
NG	▶	Repair or replace hose.

<b>2</b>	<b>CHECK ASCD WIRE</b>	
<p>Check wire for improper installation, rust formation or breaks.</p>		
<b>OK or NG</b>		
OK	▶	GO TO 3.
NG	▶	Repair or replace wire. Refer to "ASCD Wire Adjustment" (EL-267).

<b>3</b>	<b>CHECK ASCD ACTUATOR</b>	
<p>1. Disconnect vacuum hose from ASCD actuator. 2. Connect the hose of hand vacuum pump to ASCD actuator.</p>		
		
<p>Apply <math>-40\text{ kPa}</math> (<math>-0.41\text{ kg/cm}^2</math>, <math>-5.8\text{ psi}</math>) vacuum to ASCD actuator with hand vacuum pump. <b>ASCD wire should move to pull throttle drum.</b> Wait 10 seconds and check for decrease in vacuum pressure.</p> <p style="text-align: center;"><b>Vacuum pressure decrease:</b> <b>Less than <math>2.7\text{ kPa}</math> (<math>0.028\text{ kg/cm}^2</math>, <math>0.39\text{ psi}</math>)</b></p>		
SEL264W		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	Replace ASCD actuator.

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)


Trouble Diagnoses (Cont'd)

<b>4</b>	<b>CHECK ASCD PUMP</b>																	
<ol style="list-style-type: none"> <li>1. Disconnect vacuum hose from ASCD pump and ASCD pump connector.</li> <li>2. If necessary remove ASCD pump.</li> <li>3. Connect vacuum gauge to ASCD pump.</li> <li>4. Apply 12V direct current to ASCD pump and check operation.</li> </ol>																		
																		
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">12V direct current supply terminals</th> <th rowspan="2">Operation</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>Air valve</td> <td rowspan="3" style="text-align: center; vertical-align: middle;">1</td> <td style="text-align: center;">2</td> <td style="text-align: center;">Close</td> </tr> <tr> <td>Release valve</td> <td style="text-align: center;">3</td> <td style="text-align: center;">Close</td> </tr> <tr> <td>Vacuum motor</td> <td style="text-align: center;">4</td> <td style="text-align: center;">Operate</td> </tr> </tbody> </table> <p style="text-align: center;"><b>A vacuum pressure of at least <math>-40 \text{ kPa}</math> (<math>-0.41 \text{ kg/cm}^2</math>, <math>-5.8 \text{ psi}</math>) should be generated.</b></p>				12V direct current supply terminals		Operation	(+)	(-)	Air valve	1	2	Close	Release valve	3	Close	Vacuum motor	4	Operate
	12V direct current supply terminals			Operation														
	(+)	(-)																
Air valve	1	2	Close															
Release valve		3	Close															
Vacuum motor		4	Operate															
SEL265WB																		
<b>OK or NG</b>																		
OK	▶	INSPECTION END																
NG	▶	Replace ASCD pump.																

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# AUTOMATIC SPEED CONTROL DEVICE (ASCD)

## Electrical Component Inspection



## Electrical Component Inspection


### ASCD BRAKE SWITCH AND STOP LAMP SWITCH

=NAEL0376

NAEL0376S01

Condition	Continuity	
	ASCD brake switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No


**Check each switch after adjusting brake pedal — refer to BR-14, “BRAKE PEDAL AND BRACKET”.**



## PARK/NEUTRAL POSITION SWITCH (FOR A/T MODELS)

NAEL0376S02

A/T selector lever position	Continuity	
	Between terminals 1 and 2	
“P”	Yes	
“N”	Yes	
Except “P” and “N”	No	




## ASCD CLUTCH SWITCH (FOR M/T MODELS)

NAEL0376S03

Condition	Continuity
When clutch pedal is depressed	No
When clutch pedal is released	Yes

## ASCD Wire Adjustment

=NAEL0377



### CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

Adjust the tension of ASCD wire in the following manner.

1. Loosen lock nut and adjusting nut.
2. Make sure that accelerator wire is properly adjusted. Refer to FE-3, "ACCELERATOR CONTROL SYSTEM".
3. Tighten adjusting nut just until throttle drum starts to move.
4. Loosen adjusting nut again 1/2 to 1 turn.
5. Tighten lock nut.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# POWER WINDOW

System Description

## System Description

NAEL0378

Power is supplied at all times

- from 40A fusible link (letter f, located in the fuse and fusible link box)
- to circuit breaker terminal 1
- through circuit breaker terminal 2
- to power window relay terminal 3,
- to front power window main switch terminal 4, and
- to front power window switch RH terminal 6.

With ignition switch in ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27
- to smart entrance control unit terminal 46 and
- to power window relay terminal 2.

Ground is supplied to power window relay terminal 1

- through body grounds M4, M66 and M147.

The power window relay is energized and power is supplied

- through power window relay terminal 5
- to front power window main switch terminal 11,
- to front power window switch RH terminal 13 and
- to rear power window switch LH and RH terminals 5.

## MANUAL OPERATION

NAEL0378S01

### Front Door LH

NAEL0378S0101

Ground is supplied

- to front power window main switch terminal 5
- through body grounds M77 and M111.

### WINDOW UP

When the front LH switch in the front power window main switch is pressed in the up position, power is supplied

- to front power window regulator LH terminal 1
- through front power window main switch terminal 2.

Ground is supplied

- to front power window regulator LH terminal 3
- through front power window main switch terminal 3.

Then, the motor raises the window until the switch is released.

### WINDOW DOWN

When the LH switch in the front power window main switch is pressed in the down position, power is supplied

- to front power window regulator LH terminal 3
- through front power window main switch terminal 3.

Ground is supplied

- to front power window regulator LH terminal 1
- through front power window main switch terminal 2.

Then, the motor lowers the window until the switch is released.

### Front Door RH

NAEL0378S0102

Ground is supplied

- to front power window main switch terminal 5
- through body grounds M77 and M111.

### NOTE:

Numbers in parentheses are terminal numbers, when power window switch is pressed in the UP and DOWN positions respectively.

### FRONT POWER WINDOW MAIN SWITCH OPERATION

When front RH switch in the front power window main switch is pressed UP or DOWN, a signal is supplied

- through front power window main switch terminal 8
- to front power window switch RH terminal 11.

The subsequent operation is the same as the front power window switch RH operation.

## FRONT POWER WINDOW SWITCH RH OPERATION

Power is supplied

- through front power window switch RH (5, 4)
- to front power window regulator RH (1, 3).

Ground is supplied

- to front power window regulator RH (3, 1)
- through front power window switch RH (4, 5)
- to front power window switch RH terminal 12
- through front power window main switch terminal 1.

Then, the motor raises or lowers the window until the switch is released.

## Rear Door LH

NAEL0378S0103

Ground is supplied

- to front power window main switch terminal 5
- through body grounds the M77 and M111.

### NOTE:

Numbers in parentheses are terminal numbers, when the power window switch is pressed in the UP and DOWN positions.

## FRONT POWER WINDOW MAIN SWITCH OPERATION

Power is supplied

- through front power window main switch terminal (13, 12)
- to rear power window switch LH terminal (3, 4)

The subsequent operation is the same as the rear power window switch LH operation.

## REAR POWER WINDOW SWITCH LH

Power is supplied

- through rear power window switch LH (1, 2)
- to rear power window regulator LH (1, 2)

Ground is supplied

- to rear power window regulator LH (2, 1)
- through rear power window switch LH (2, 1)
- to rear power window switch LH terminal (4, 3)
- through front power window main switch terminal (12, 13)

Then, the motor raises or lowers the window until the switch is released.

## Rear Door RH

NAEL0378S0104

Rear door RH windows will rise and lower in the same manner as the rear door LH window.

## AUTO OPERATION

NAEL0378S02

The power window AUTO feature enables the driver or front passenger to open or close the driver's and front passenger's window without holding the window switch in the up or down position.

The AUTO feature only operates on the driver's and front passenger's window upward and downward movement.

## POWER WINDOW LOCK

NAEL0378S03

The power window lock is designed to lock operation of all windows except for driver's door window.

When the lock switch is pressed to lock position, the ground of the front and rear power window switches, in the power window main switch, is disconnected. This prevents the power window motors from operating.

## RETAINED POWER OPERATION

NAEL0378S04

When the ignition switch is turned to OFF position from ON or START position, power is supplied for 45 seconds

- to power window relay terminal 2
- from smart entrance control unit terminal 46.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# POWER WINDOW

System Description (Cont'd)

---

Ground is always supplied

- to power window relay terminal 1
- through body grounds M4, M66 and M147.

When power and ground are supplied, the power window relay continues to be energized, and the power window can be operated.

The retained power operation is canceled when the driver or passenger side door is opened.

**RAP signal's period can be changed by CONSULT-II. (EL-278)**

## INTERRUPTION DETECTION FUNCTION

Front power window main switch and front power window switch RH monitor the power window regulator motor operation and the power window position (full closed or other) for driver's and passenger's power window by the signals from encoder and limit switch in front power window regulator LH or RH. NAEL0378S05

When front power window main switch or front power window switch RH detects interruption during the following close operation in the driver's or front passenger's side door,

- automatic close operation when ignition switch is in the "ON" position
- automatic close operation during retained power operation

front power window main switch or front power window switch RH controls driver's or front passenger's power window regulator motor for open and the power window will be lowered about 150 mm (5.91 in).

## POWER WINDOW OPENED/CLOSED OPERATION WITH KEY CYLINDER

When ignition key switch is OFF, front power window can be opened or closed by turning the front door key cylinder LH to UNLOCK/LOCK position. NAEL0378S06

- Power window can be opened as the door key cylinder is kept fully turning to the UNLOCK position.
- Power window can be closed as the door key cylinder is kept fully turning to the LOCK position.

The power window opening stops when the following operations are carried out:

- While performing open/close the window, power window is stopped at the position as the door key cylinder is placed on Neutral.
- When the ignition switch is turned ON while the power window opening is operated.





# POWER WINDOW

Wiring Diagram — WINDOW —

## Wiring Diagram — WINDOW —

NAEL0380

EL-WINDOW-01



REFER TO THE FOLLOWING.

- (E1) , (B1) -SUPER
- MULTIPLE JUNCTION (SMJ)
- (M10) -FUSE BLOCK -
- JUNCTION BOX (J/B)




MEL4100





# POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

## EL-WINDOW-02







GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



# POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

## EL-WINDOW-03








MEL516P

# POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)

## EL-WINDOW-04





GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX




# POWER WINDOW

Wiring Diagram — WINDOW — (Cont'd)


EL-WINDOW-05



REFER TO THE FOLLOWING.  
 (B1) -SUPER  
 MULTIPLE JUNCTION (SMJ)



MEL517P




## CONSULT-II Inspection Procedure

NAEL0381


NAEL0381S01

### “RETAINED PWR”


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START”.



5. Touch “SMART ENTRANCE”.



6. Touch “RETAINED PWR”.



7. Select diagnosis mode. “DATA MONITOR”, “ACTIVE TEST” and “WORK SUPPORT” are available.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX

# POWER WINDOW

CONSULT-II Application Items

## CONSULT-II Application Items

NAEL0382

NAEL0382S01

NAEL0382S0101

### “RETAINED PWR”

#### Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.

#### Active Test

NAEL0382S0102

Test Item	Description
RETAINED PWR	<p>This test is able to supply RAP signal (power) from smart entrance control unit to power window system, power sunroof system and headlamp battery saver control unit. Those systems can be operated when turning on “RETAINED PWR” on CONSULT-II screen even if the ignition switch is tuned OFF.</p> <p><b>NOTE:</b>  <b>During this test, CONSULT-II can be operated with ignition switch in “OFF” position. “RETAINED PWR” should be turned “ON” or “OFF” on CONSULT-II screen when ignition switch is ON. Then turn ignition switch OFF to check retained power operation. CONSULT-II might be stuck if “RETAINED PWR” is turned “ON” or “OFF” on CONSULT-II screen when ignition switch is OFF.</b></p>

#### Work Support

NAEL0382S0103

Work Item	Description
RETAINED PWR SET	<p>Rap signal's power supply period can be changed by mode setting. Selects rap signal's power supply period between three steps.</p> <ul style="list-style-type: none"> <li>● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (2 min.)</li> </ul>

## Trouble Diagnoses

NAEL0383

Symptom	Possible cause	Repair order
None of the power windows can be operated using any switch.	<ol style="list-style-type: none"> <li>1. 7.5A fuse, 40A fusible link</li> <li>2. M145 circuit breaker</li> <li>3. Power window relay</li> <li>4. M145 circuit breaker circuit</li> <li>5. Power window relay circuit</li> <li>6. Ground circuit</li> <li>7. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check 7.5A fuse [No. 11, located in fuse block (J/B)], 40A fusible link (letter f, located in fuse and fusible link box).</li> <li>2. Check M145 circuit breaker.</li> <li>3. Check power window relay.</li> <li>4. Check the following. <ol style="list-style-type: none"> <li>a. Harness between M145 circuit breaker and 40A fusible link</li> <li>b. Harness between M145 circuit breaker and front power window main switch</li> </ol> </li> <li>5. Check the following. <ol style="list-style-type: none"> <li>a. Harness between 7.5A fuse and power window relay</li> <li>b. Harness between M145 circuit breaker and power window relay</li> </ol> </li> <li>6. Check the following. <ol style="list-style-type: none"> <li>a. Ground circuit of power window main switch terminal 5</li> <li>b. Power window relay ground circuit</li> </ol> </li> <li>7. Check power window main switch.</li> </ol>

# POWER WINDOW

Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order	
Driver side power window cannot be operated but other windows can be operated.	<ol style="list-style-type: none"> <li>1. Driver side power window regulator circuit</li> <li>2. Driver side power window regulator</li> <li>3. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check harness between power window main switch and driver side power window regulator for open or short circuit.</li> <li>2. Check driver side power window regulator.</li> <li>3. Check power window main switch.</li> </ol>	GI MA EM
Passenger side power window cannot be operated but other window can be operated.	<ol style="list-style-type: none"> <li>1. Power supply for front power window switch RH</li> <li>2. Front power window switch RH ground circuit</li> <li>3. Front power window switch RH circuit</li> <li>4. Front power window regulator RH circuit</li> <li>5. Front power window regulator RH</li> <li>6. Front power window main switch</li> <li>7. Front power window switch RH</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power supply for front power window switch RH terminals 6 and 13.</li> <li>2. Check front power window switch RH ground circuit.</li> <li>3. Check harness between front power window switch RH and power window main switch.</li> <li>4. Check harness between front power window switch RH and front power window regulator RH for open or short circuit.</li> <li>5. Check front power window regulator RH.</li> <li>6. Check front power window main switch.</li> <li>7. Check front power window switch RH.</li> </ol>	LC EC FE CL
One or more rear power windows except front window cannot be operated.	<ol style="list-style-type: none"> <li>1. Rear power window switches</li> <li>2. Rear power window regulators</li> <li>3. Power window main switch</li> <li>4. Rear power window circuit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check rear power window switches.</li> <li>2. Check rear power window regulator.</li> <li>3. Check power window main switch.</li> <li>4. Check the following. <ol style="list-style-type: none"> <li>a. Harness between the rear power window switches (LH and RH) terminal 5 and power window relay terminal 5</li> <li>b. Harnesses between power window main switch and rear power window switches for open/short circuit</li> <li>c. Harnesses between rear power window switches and rear power window regulator for open/short circuit</li> </ol> </li> </ol>	MT AT TF PD
Power windows except driver's side window cannot be operated using power window main switch but can be operated by power window switches.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> </ol>	AX SU
Driver side power window automatic operation does not function properly.	<ol style="list-style-type: none"> <li>1. Power window main switch</li> <li>2. Encoder and limit switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch.</li> <li>2. Check encoder and limit switch. (EL-281)</li> </ol>	BR
Front passenger side power window automatic operation does not function properly.	<ol style="list-style-type: none"> <li>1. Front power window switch RH</li> <li>2. Encoder and limit switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check front power window switch RH.</li> <li>2. Check encoder and limit switch. (EL-281)</li> </ol>	ST

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# POWER WINDOW

## Trouble Diagnoses (Cont'd)

Symptom	Possible cause	Repair order
Retained power operation does not operate properly.	<ol style="list-style-type: none"> <li>1. RAP signal circuit</li> <li>2. Driver or passenger side door switch circuit</li> <li>3. Smart entrance control unit</li> </ol>	<ol style="list-style-type: none"> <li>1. Check RAP signal.               <ol style="list-style-type: none"> <li>a. (With CONSULT-II)                   <ul style="list-style-type: none"> <li>● Check RAP signal with CONSULT-II. Use "WORK SUPPORT" mode, "RETAINED PWR" in "SMART ENTRANCE". (Refer to EL-278.)</li> <li>● Check RAP signal with CONSULT-II. Use "ACTIVE TEST" mode, "RETAINED PWR" in "SMART ENTRANCE". (Refer to EL-277.)</li> </ul> </li> <li>If NG, go to the step b. below.</li> <li>b. Verify 12 positive voltage from smart entrance control unit terminal 46 is present at terminal 2 of power window relay:                   <ul style="list-style-type: none"> <li>● Within 45 seconds after ignition switch turns off.*1</li> <li>● When front door LH and RH is closed.</li> </ul> </li> </ol> </li> <li>2. Check the following.               <ol style="list-style-type: none"> <li>a. Harness between smart entrance control unit and driver or passenger side door switch for short circuit</li> <li>b. Driver or passenger side door switch ground circuit</li> <li>c. Driver or passenger side door switch</li> </ol> </li> <li>3. Check smart entrance control unit. (EL-378)</li> </ol>
Passenger side power window cannot be operated using power window main switch but can be operated by passenger side power window switch.	<ol style="list-style-type: none"> <li>1. Front power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch. (EL-283)</li> </ol>
Rear LH power window cannot be operated using power window main switch but can be operated by rear LH power window switch.	<ol style="list-style-type: none"> <li>1. Front power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch. (EL-283)</li> </ol>
Rear RH power window cannot be operated using power window main switch but can be operated by rear RH power window switch.	<ol style="list-style-type: none"> <li>1. Front power window main switch</li> </ol>	<ol style="list-style-type: none"> <li>1. Check power window main switch. (EL-283)</li> </ol>

\*1: RAP signal's period can be changed by CONSULT-II. (EL-278)



# POWER WINDOW



Trouble Diagnoses (Cont'd)

## ENCODER AND LIMIT SWITCH CHECK

=NAEL0383S01

<b>1</b>	<b>CHECK DOOR WINDOW SLIDE MECHANISM</b>	
<p>Check the following.</p> <ul style="list-style-type: none"> <li>● Obstacles in window, glass molding, etc.</li> <li>● Worn or deformed glass molding</li> <li>● Door sash tilted too far inward or outward</li> <li>● Door window regulator</li> </ul> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 2.
NG	▶	Remove obstacles or repair door window slide mechanism.

<b>2</b>	<b>CHECK POWER SUPPLY TO LIMIT SWITCH</b>	
<p>1. Disconnect front power window regulator LH or RH harness connector.                  2. Check voltage between front power window main switch terminal 15 or front power window switch RH terminal 16 and ground.</p>		
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Front power window main switch connector (D6)</p> </div> <div style="text-align: center;">  <p>Front power window switch RH connector (D36)</p> </div> <div style="text-align: center;"> <p><b>Voltage: 5V</b></p> </div> </div> <p><b>NOTE: Check voltage when front power window regulator LH or RH harness connector is disconnected.</b></p> <p style="text-align: right;">SEL725WA</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 3.
NG	▶	Replace power window main switch or front power window switch RH.

<b>3</b>	<b>CHECK LIMIT SWITCH OPERATION</b>										
<p>1. Connect front power window regulator LH or RH harness connector.                  2. Check voltage between front power window main switch terminal 15 or front power window switch RH terminal 16 and ground during power window closing operation.</p>											
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Front power window main switch connector (D6)</p> </div> <div style="text-align: center;">  <p>Front power window switch RH connector (D36)</p> </div> <div style="border: 1px solid black; padding: 5px; margin-left: 20px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Terminal No.</th> <th style="text-align: left;">Condition</th> <th style="text-align: left;">Voltage (DCV)</th> </tr> </thead> <tbody> <tr> <td>Front power window main switch: 15 Front power window switch RH: 16</td> <td>Approx. 15 mm (0.59 in) below the full closed position to full closed position</td> <td>Approx. 5</td> </tr> <tr> <td></td> <td>Other positions</td> <td>Approx. 0</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL726WA</p> <p style="text-align: center;"><b>OK or NG</b></p>			Terminal No.	Condition	Voltage (DCV)	Front power window main switch: 15 Front power window switch RH: 16	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5		Other positions	Approx. 0
Terminal No.	Condition	Voltage (DCV)									
Front power window main switch: 15 Front power window switch RH: 16	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5									
	Other positions	Approx. 0									
OK	▶	GO TO 5.									
NG	▶	GO TO 4.									


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# POWER WINDOW

## Trouble Diagnoses (Cont'd)

**4 RESET LIMIT SWITCH**

Reset limit switch. Refer to BT-20, "Front Door Glass Limit Switch Reset". Then check voltage between front power window main switch terminal 15 or front power window switch RH terminal 16 and ground during power window closing operation at least ten times.



Terminal No.	Condition	Voltage (DCV)
Front power window main switch: 15 Front power window switch RH: 16	Approx. 15 mm (0.59 in) below the full closed position to full closed position	Approx. 5
	Other positions	Approx. 0



SEL726WA

**OK or NG**

OK	▶	GO TO 5.
NG	▶	Replace power window regulator motor.

**5 CHECK ENCODER**

Measure voltage between front power window main switch terminal 14 or front power window switch RH terminal 19 and ground with oscilloscope when power window is in automatic closing operation.

HI: Approx. 5V  
LO: Approx. 0V

SEL727WA

**OK or NG**

OK	▶	Replace power window main switch.
NG	▶	Replace power window regulator motor.

# POWER WINDOW

Trouble Diagnoses (Cont'd)

## MAIN SWITCH OPERATION CHECK Passenger Side Operation

NAEL0383S02



NAEL0383S0201

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

### 1 CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL

#### With CONSULT-II

1. Turn ignition switch to ON position.
2. Turn front power window main switch to ON (UP or DOWN).
3. Check signal between front power window main switch harness connector D6 terminal 8 (Y) and ground when power window is in open or close operation. (Use "SIMPLE OSCILLOSCOPE" in "SUB MODE" with CONSULT-II.)




**Voltage:**  
12V → 9V (10 sec.) measurement  
by analog circuit tester.

SEL496Y

#### Without CONSULT-II

1. Turn ignition switch to ON position.
2. Turn front power window main switch to ON (UP or DOWN).
3. Check signal between front power window main switch harness connector D6 terminal 8 (Y) and ground when power window is in open or close operation.



**Voltage:**  
12V → 9V (10 sec.)  
measurement by analog  
circuit tester.


SEL497Y

OK or NG

OK	▶	GO TO 2.
NG	▶	Replace front power window main switch.

# POWER WINDOW

Trouble Diagnoses (Cont'd)

2	CHECK SIGNAL CIRCUIT
<p data-bbox="154 199 1421 262">1. Check continuity between front power window switch harness connector D6 terminal 8 (Y) and front power window switch harness connector D36 RH terminal 11 (Y).</p> <div data-bbox="389 273 1266 588"><p data-bbox="966 409 1266 451"><b>Continuity should exist.</b></p></div> <p data-bbox="1388 577 1477 609" style="text-align: right;">SEL163Y</p>	
<b>Yes or No</b>	
Yes	▶ INSPECTION END
No	▶ Repair harness or connectors.

# POWER WINDOW

Trouble Diagnoses (Cont'd)

## Rear LH Side Window Operation

=NAEL0383S0202

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

**1 CHECK POWER WINDOW MAIN SWITCH OUTPUT SIGNAL**

- Turn ignition switch to ON position.
- Check voltage between front power window main switch harness connector D6 terminal 12 or 13 and ground when rear power window LH side is in open or close operation.

Front power window main switch

Terminals		Main switch condition	
(+)	(-)	Open	Close
12	Ground	0V	12V
13	Ground	0V	12V

SEL164Y

**OK or NG**

OK	▶	GO TO 2.
NG	▶	Replace front power window main switch.

**2 CHECK SIGNAL CIRCUIT**

- Check continuity between front power window main switch harness connector D6 terminal 12 and rear power window switch LH harness connector D52 terminal 4.
- Check continuity between front power window main switch harness connector D6 terminal 13 and rear power window switch LH harness connector D52 terminal 3.

Front power window main switch

Rear power window switch LH

**Continuity should exist.**

SEL165Y

**Yes or No**

Yes	▶	INSPECTION END
No	▶	Repair harness or connectors.

# POWER WINDOW

Trouble Diagnoses (Cont'd)

## Rear RH Side Window Operation

=NAEL0383S0203

<b>1</b>	<b>CHECK POWER WINDOW MAIN SWITCH OUTPUT</b>	<p>1. Turn ignition switch to ON position.</p> <p>2. Check voltage between front power window main switch harness connector D6 terminal 9 or 10 and ground when rear power window RH side is in open or close operation.</p> <div style="display: flex; align-items: center; justify-content: space-around;"> <div style="text-align: center;"> <p>Front power window main switch</p> </div> <table border="1" style="border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2">Terminals</th> <th colspan="2">Main switch condition</th> </tr> <tr> <th>(+)</th> <th>(-)</th> <th>Open</th> <th>Close</th> </tr> </thead> <tbody> <tr> <td>9</td> <td>Ground</td> <td>0V</td> <td>12V</td> </tr> <tr> <td>10</td> <td>Ground</td> <td>0V</td> <td>12V</td> </tr> </tbody> </table> </div>	Terminals		Main switch condition		(+)	(-)	Open	Close	9	Ground	0V	12V	10	Ground	0V	12V	SEL166Y
Terminals		Main switch condition																	
(+)	(-)	Open	Close																
9	Ground	0V	12V																
10	Ground	0V	12V																
<b>OK or NG</b>																			
OK	▶	GO TO 2.																	
NG	▶	Replace front power window main switch.																	


<b>2</b>	<b>CHECK SIGNAL CIRCUIT</b>	<p>1. Check continuity between front power window main switch harness connector D6 terminal 9 and rear power window switch RH harness connector D72 terminal 3.</p> <p>2. Check continuity between front power window main switch harness connector D6 terminal 10 and rear power window switch RH harness connector D72 terminal 4.</p> <div style="display: flex; align-items: center; justify-content: space-around;"> <div style="text-align: center;"> <p>Front power window main switch</p> <p>Rear power window switch RH</p> </div> <div style="text-align: center; padding-left: 20px;"> <p><b>Continuity should exist.</b></p> </div> </div>	SEL167Y
<b>Yes or No</b>			
Yes	▶	INSPECTION END	
No	▶	Repair harness or connectors.	

# POWER DOOR LOCK

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0384



SEL065WB

## System Description

NAEL0385

NAEL0385S01

### OPERATION

- The lock/unlock switch (LH and RH) on door trim can lock and unlock all doors.
- With the door key inserted in the key cylinder on front LH or back door, turning it to "LOCK", will lock all doors; turning it to "UNLOCK" once unlocks the corresponding door; turning it to "UNLOCK" again within 5 seconds after the first unlock operation unlocks all of the other doors. (Signals from door key cylinder switch)
- If the ignition key is in the ignition key cylinder and one or more of doors are open, setting the lock/unlock switch to "LOCK" locks the doors once but then immediately unlock them. (Combination signals from key switch and door switches) - (KEY REMINDER DOOR SYSTEM)


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# POWER DOOR LOCK

Schematic

## Schematic

NAEL0386



MEL431P

# POWER DOOR LOCK

Wiring Diagram — D/LOCK —



## Wiring Diagram — D/LOCK —

NAEL0387

NAEL0387S01

FIG. 1

EL-D/LOCK-01



REFER TO THE FOLLOWING.  
 (E1), (B1) -SUPER  
 MULTIPLE JUNCTION (SMJ)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL388P


# POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)


NAEL0387S02

FIG. 2

EL-D/LOCK-02



Refer to EL-POWER.



REFER TO THE FOLLOWING.

- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10) , (E3) -FUSE BLOCK-JUNCTION BOX (J/B)



# POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

FIG. 3

NAEL0387S03

EL-D/LOCK-03



REFER TO THE FOLLOWING.  
 (B1) - SUPER MULTIPLE JUNCTION (SMJ)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX






# POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)

NAEL0387S04

FIG. 4

EL-D/LOCK-04



REFER TO THE FOLLOWING.

(B1) - SUPER MULTIPLE JUNCTION (SMJ)


# POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)


FIG. 5

NAEL0387S05

EL-D/LOCK-05



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



REFER TO THE FOLLOWING.  
**(B1)** - SUPER MULTIPLE JUNCTION (SMJ)









# POWER DOOR LOCK

Wiring Diagram — D/LOCK — (Cont'd)


FIG. 6

NAEL0387S06

EL-D/LOCK-06



MEL435P




## CONSULT-II Inspection Procedure

=NAEL0388


NAEL0388S01

### “DOOR LOCK”


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” to the data link connector.




3. Turn ignition switch “ON”.
4. Turn “START”.



5. Touch “SMART ENTRANCE”.



6. Touch “DOOR LOCK”.



7. Select diagnosis mode. “DATA MONITOR”, “ACTIVE TEST” and “WORK SUPPORT” are available.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# POWER DOOR LOCK

CONSULT-II Application Items

## CONSULT-II Application Items “DOOR LOCK” Data Monitor

NAEL0389

NAEL0389S01

NAEL0389S0101

Monitored Item	Description
KEY ON SW	Indicates [ON/OFF] condition of key switch.
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from lock/unlock switch LH and RH.
DOOR SW-RR	Indicates [ON/OFF] condition of door switch (Rear).
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from lock/unlock switch LH and RH.
KEY CYL LK-SW	Indicates [ON/OFF] condition of lock signal from key cylinder.
KEY CYL UN-SW	Indicates [ON/OFF] condition of unlock signal from key cylinder.
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.

### Active Test

NAEL0389S0102

Test Item	Description
ALL D/LK MTR	This test is able to check all door lock actuators lock operation. These actuators lock when “ON” on CONSULT-II screen is touched.
DR D/UN MTR	This test is able to check front door lock actuator LH unlock operation. The actuator unlocks when “ON” on CONSULT-II screen is touched.
NON DR D/UN	This test is able to check door lock actuators (except front door lock actuator LH) unlock operation. These actuators unlock when “ON” on CONSULT-II screen is touched.

### Work Support

NAEL0389S0103

Work Item	Description
DOOR LOCK-UNLOCK SET	Select unlock mode can be changed in this mode. Selects ON-OFF of select unlock mode.
ANTI-LOCK OUT SET	Key reminder door mode can be changed in this mode. Selects ON-OFF of key reminder door mode.

# POWER DOOR LOCK

Trouble Diagnoses

## Trouble Diagnoses SYMPTOM CHART

NAEL0390

NAEL0390S01

REFERENCE PAGE (EL- )	298	299	301	302	303	305	307
SYMPTOM	MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK	DOOR SWITCH CHECK	KEY SWITCH (INSERT) CHECK	DOOR LOCK/UNLOCK SWITCH CHECK	FRONT DOOR KEY CYLINDER SWITCH CHECK	BACK DOOR KEY CYLINDER SWITCH CHECK	DOOR LOCK ACTUATOR CHECK
Key reminder door system does not operate properly.	X	X	X				X
Specific door lock actuator does not operate.	X						X
Power door lock does not operate with door lock and unlock switch (LH and RH) on door trim.	X			X			
Power door lock does not operate with front door key cylinder operation.	X				X		
Power door lock does not operate with back door key cylinder operation.	X					X	

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

**EL**

IDX

# POWER DOOR LOCK

Trouble Diagnoses (Cont'd)




## MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

=NAEL0390S02

### Main Power Supply Circuit Check

NAEL0390S0201

Terminals		Ignition switch			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M123	49 (G/R)	Ground	Battery voltage	Battery voltage	Battery voltage
	51 (W/R)				



### Ground Circuit Check

NAEL0390S0202

Terminals		(-)	Continuity
(+)			
Connector	Terminal (Wire color)		
M122	43 (B)	Ground	Yes
M123	64 (B)		

# POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

## DOOR SWITCH CHECK

=NAEL0390S03

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

### 1 CHECK DOOR SWITCH INPUT SIGNAL

#### With CONSULT-II

Check door switches ("DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RR") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
DOOR SW-RR	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF

When any doors are open:

**DOOR SW-DR ON**  
**DOOR SW-AS ON**  
**DOOR SW-RR ON**

When any doors are closed:



**DOOR SW-DR OFF**  
**DOOR SW-AS OFF**  
**DOOR SW-RR OFF**

SEL009Y

#### Without CONSULT-II

Check voltage between smart entrance control unit harness connector M121 terminals 1 (G/OR), 2 (Y) or 3 (R/L) and ground.

Smart entrance control unit connector



	Terminals		Condition	Voltage [V]
	(+)	(-)		
Front LH door switch	1	Ground	Open	0
			Closed	Approx. 5
Front RH door switch	2	Ground	Open	0
			Closed	Approx. 5
Rear door switches	3	Ground	Open	0
			Closed	Approx. 5

SEL010Y




Refer to wiring diagram in EL-289.

**OK or NG**

OK	▶	Door switch is OK.
NG	▶	GO TO 2.

# POWER DOOR LOCK


Trouble Diagnoses (Cont'd)


2	CHECK DOOR SWITCH																								
<p>1. Disconnect door switch connector.</p> <p>2. Check the following.</p> <ul style="list-style-type: none"> <li>● Continuity between front door switch harness connector B9 (LH) or B68 (RH) terminals 1 and 2</li> <li>● Continuity between front door switch harness connector B9 (LH) or B68 (RH) terminal and ground</li> <li>● Continuity between back door switch harness connector D208 terminals 1 and 2</li> <li>● Continuity between rear door switch harness connector B18 (LH) or B71 (RH) terminal 1 and ground</li> </ul>																									
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Front door switch connector</p> </div> <div style="text-align: center;">  <p>Back door switch</p> </div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 20px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <table border="1" data-bbox="893 546 1396 787"> <thead> <tr> <th></th> <th>Terminals</th> <th>Condition</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front door switches</td> <td>1 - 2</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>3 - Ground</td> <td>Open</td> <td>Yes</td> </tr> <tr> <td rowspan="2">Back door switch</td> <td rowspan="2">1 - 2</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> <tr> <td rowspan="2">Rear door switches</td> <td rowspan="2">1 - Ground</td> <td>Closed</td> <td>No</td> </tr> <tr> <td>Open</td> <td>Yes</td> </tr> </tbody> </table> </div> <div style="text-align: center; margin-top: 20px;">  <p>Rear door switch connector</p>  </div>				Terminals	Condition	Continuity	Front door switches	1 - 2	Closed	No	3 - Ground	Open	Yes	Back door switch	1 - 2	Closed	No	Open	Yes	Rear door switches	1 - Ground	Closed	No	Open	Yes
	Terminals	Condition	Continuity																						
Front door switches	1 - 2	Closed	No																						
	3 - Ground	Open	Yes																						
Back door switch	1 - 2	Closed	No																						
		Open	Yes																						
Rear door switches	1 - Ground	Closed	No																						
		Open	Yes																						
SEL287Y																									
<b>OK or NG</b>																									
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Door switches ground circuit (Front or back door) or rear door switches ground condition</li> <li>● Harness for open or short between smart entrance control unit and door switch</li> </ul>																							
NG	▶	Replace door switch.																							

## KEY SWITCH (INSERT) CHECK

=NAEL0390S04

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

<b>1</b>	<b>CHECK KEY SWITCH INPUT SIGNAL</b>						
<p> <b>With CONSULT-II</b> Check key switch ("KEY ON SW") in "DATA MONITOR" mode with CONSULT-II.</p> <div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th></th> </tr> </thead> <tbody> <tr> <td>KEY ON SW</td> <td>ON</td> </tr> </tbody> </table> </div> <div> <p>When key is inserted to ignition key cylinder: <b>KEY ON SW ON</b></p> <p>When key is removed from ignition key cylinder: <b>KEY ON SW OFF</b></p> </div> </div> <p style="text-align: right;">SEL315W</p>		DATA MONITOR		MONITOR		KEY ON SW	ON
DATA MONITOR							
MONITOR							
KEY ON SW	ON						
<p> <b>Without CONSULT-II</b> Check voltage between smart entrance control unit harness connector M122 terminal 25 (W/R) and ground.</p> <p>Smart entrance control unit connector</p> <div style="display: flex; align-items: center;">  <div style="margin-left: 20px;">  <p><b>CONNECT</b></p> <p>Approx. 12V</p> <p>Approx. 0V</p> </div> </div> <div style="margin-left: 20px;"> <p><b>Voltage [V]:</b></p> <p><b>Condition of key switch: Key is inserted.</b> Approx. 12</p> <p><b>Condition of key switch: Key is removed.</b> 0</p> </div> <p style="text-align: right;">SEL011Y</p>							
<p>Refer to wiring diagram in EL-290.</p> <p><b>OK or NG</b></p>							
OK	▶ Key switch is OK.						
NG	▶ GO TO 2.						

<b>2</b>	<b>CHECK KEY SWITCH (INSERT)</b>
<p>Check continuity between terminals 1 and 2.</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>Key switch connector (E5)</p>  </div> <div>  <p><b>T.S.</b></p> <p><b>DISCONNECT</b></p> </div> </div> <div style="margin-left: 20px;"> <p><b>Continuity:</b></p> <p><b>Condition of key switch: Key is inserted.</b> Yes</p> <p><b>Condition of key switch: Key is removed.</b> No</p> <p style="text-align: right;">SEL308X</p> </div> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 24, located in fuse block (J/B)]</li> <li>● Harness for open or short between key switch and fuse</li> <li>● Harness for open or short between smart entrance control unit and key switch</li> </ul>
NG	▶ Replace key switch.

# POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

## DOOR LOCK/UNLOCK SWITCH CHECK

=NAEL0390S05

### 1 CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

#### With CONSULT-II

Check door lock/unlock switch ("LOCK SW DR/AS"/"UNLK SW DR/AS") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
LOCK SW DR/AS	OFF
UNLK SW DR/AS	OFF

When lock/unlock switch is turned to LOCK:

**LOCK SW DR/AS ON**

When lock/unlock switch is turned to UNLOCK:

**UNLK SW DR/AS ON**


SEL341W

#### Without CONSULT-II

1. Remove key from ignition switch.
2. Check the signal between smart entrance control unit harness connector M144 terminal 33 (L) and ground with oscilloscope when door lock/unlock switch is turned "LOCK" or "UNLOCK".
3. Make sure signals which are shown in the figure below can be detected during 10 sec. just after door lock/unlock switch is turned "LOCK" or "UNLOCK".



Smart entrance control unit



**Voltage:**  
12V → 9V (10 sec.) measurement  
by analog circuit tester.

SEL487Y

Refer to wiring diagram in EL-294.

**OK or NG**

OK ► Door lock/unlock switch is OK.

NG ► **Check the following.**

- Ground circuit for each front power window switch
- Harness for open or short between each front power window switch and smart entrance control unit connector

If above systems are normal, replace the front power window switch.

# POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

## FRONT DOOR KEY CYLINDER SWITCH CHECK

=NAEL0390S06

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

### 1 CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

#### With CONSULT-II

Check front door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

When key inserted in front key cylinder is turned to LOCK:

**KEY CYL LK-SW ON**

When key inserted in front key cylinder is turned to UNLOCK:

**KEY CYL UN-SW ON**



SEL342W

#### Without CONSULT-II

1. Check the signal between smart entrance control unit harness connector M144 terminal 33 (L) and ground with oscilloscope when key inserted in front key cylinder is turned "LOCK" or "UNLOCK".
2. Make sure signals which are shown in the figure below can be detected during 10 sec. just after key is turned "LOCK" or "UNLOCK".



Smart entrance control unit



**Voltage:**  
**12V → 9V (10 sec.)**  
**measurement by analog circuit tester.**

SEL488Y


Refer to wiring diagram in EL-294.

OK or NG

OK	▶	Door key cylinder switch LH is OK.
NG	▶	GO TO 2.

# POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

2	CHECK DOOR KEY CYLINDER SWITCH														
1. Disconnect door key cylinder switch connector. 2. Check continuity between door key cylinder switch terminals.															
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 45%;">  <p>Door key cylinder switch LH connector </p>  </div> <div style="width: 45%;"> <p>① : Door unlock switch terminal                      ② : Ground terminal                      ③ : Door lock switch terminal</p> <table border="1" data-bbox="795 415 1356 567"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">LH: 3 - 2</td> <td>Neutral/Unlock</td> <td>No</td> </tr> <tr> <td>Lock</td> <td>Yes</td> </tr> <tr> <td rowspan="2">LH: 1 - 2</td> <td>Neutral/Lock</td> <td>No</td> </tr> <tr> <td>Unlock</td> <td>Yes</td> </tr> </tbody> </table> </div> </div> <div style="text-align: right; margin-top: 10px;">SEL313X</div>			Terminals	Key position	Continuity	LH: 3 - 2	Neutral/Unlock	No	Lock	Yes	LH: 1 - 2	Neutral/Lock	No	Unlock	Yes
Terminals	Key position	Continuity													
LH: 3 - 2	Neutral/Unlock	No													
	Lock	Yes													
LH: 1 - 2	Neutral/Lock	No													
	Unlock	Yes													
<b>OK or NG</b>															
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Door key cylinder switch LH ground circuit</li> <li>● Harness for open or short between smart entrance control unit and front power window main switch</li> <li>● Harness for open or short between front power window main switch and door key cylinder switch LH</li> </ul>													
NG	▶	Replace door key cylinder switch LH.													

# POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

## BACK DOOR KEY CYLINDER SWITCH CHECK

=NAEL0390S07

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

### 1 CHECK BACK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

#### With CONSULT-II

Check back door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

When key inserted in back key cylinder is turned to LOCK:

**KEY CYL LK-SW ON**


When key inserted in back key cylinder is turned to UNLOCK:

**KEY CYL UN-SW ON**

SEL342WB

#### Without CONSULT-II

Check voltage between smart entrance control unit harness connector M121 terminals 10 (LG) or 11 (Y) and ground.



	Terminals		Key position	Voltage [V]
	(+)	(-)		
Back door	11	Ground	Between neutral and lock	0
			Other positions	Approx. 5
	10	Ground	Between neutral and unlock	0
			Other positions	Approx. 5

SEL286Y


Refer to wiring diagram in EL-291.

**OK or NG**

OK	▶	Back door key cylinder switch is OK.
NG	▶	GO TO 2.

# POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

2	CHECK BACK DOOR KEY CYLINDER SWITCH																
1. Disconnect back door key cylinder switch connector. 2. Check continuity between back door key cylinder switch terminals.																	
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 45%;">  <p>Back door key cylinder switch (D201)</p> </div> <div style="width: 45%;"> <table border="1" data-bbox="787 336 1421 514"> <thead> <tr> <th rowspan="2">Key position</th> <th colspan="3">Terminals</th> </tr> <tr> <th>1</th> <th>2</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>Between neutral and lock (Back door)</td> <td style="text-align: center;">○</td> <td style="text-align: center;">—</td> <td style="text-align: center;">○</td> </tr> <tr> <td>Between neutral and unlock (Back door)</td> <td></td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right;">SEL315X</p> <p style="text-align: center;"><b>OK or NG</b></p>			Key position	Terminals			1	2	4	Between neutral and lock (Back door)	○	—	○	Between neutral and unlock (Back door)		○	○
Key position	Terminals																
	1	2	4														
Between neutral and lock (Back door)	○	—	○														
Between neutral and unlock (Back door)		○	○														
OK	▶	<b>Check the following.</b> <ul style="list-style-type: none"> <li>● Back door key cylinder switch ground circuit</li> <li>● Harness for open or short between smart entrance control unit and back door key cylinder switch</li> </ul>															
NG	▶	Replace back door key cylinder switch.															

# POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

## DOOR LOCK ACTUATOR CHECK

=NAEL0390S08

GI

MA

EM

LC

EC

FE

CL

SEL343W

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

### 1 CHECK DOOR LOCK ACTUATOR OPERATION

**With CONSULT-II**

1. Select "ACTIVE TEST" in "DOOR LOCK" with CONSULT-II.
2. Select "ALL D/LK MTR" and touch "ON".
3. Then, select "DR D/UN MTR" and touch "ON".
4. Select "NON DR D/UN" and touch "ON".

ACTIVE TEST	
ALL D/LK MTR	OFF
or	
(DR D/UN MTR	OFF)
(NON DR D/UN	OFF)
<b>ON</b>	

Door lock motor should operate.

**NOTE:**

If CONSULT-II is not available, skip this procedure and go to the next step.

OK or NG

OK	▶	Door lock actuator is OK.
NG	▶	GO TO 2.



# POWER DOOR LOCK

Trouble Diagnoses (Cont'd)

## 2 CHECK DOOR LOCK ACTUATOR CIRCUIT

- Door lock actuator front LH  
Check voltage between smart entrance control unit harness connector M145 terminal 54 (GY), 55 (W/B) and ground.

Smart entrance control unit connector





Door lock/unlock switch condition	Terminal No.		Voltage V
	(+)	(-)	
Lock	54	Ground	Approx. 12
Unlock	55	Ground	

SEL014Y

- Door lock actuator front RH and rear  
Check voltage between smart entrance control unit harness connector M145 terminal 54 (GY), 56 (G/Y) and ground.

Smart entrance control unit connector



Door lock/unlock switch condition	Terminal No.		Voltage V
	(+)	(-)	
Lock	54	Ground	Approx. 12
Unlock	56	Ground	

SEL015Y

Refer to wiring diagram in EL-292.

**OK or NG**

OK	▶	GO TO 2.
NG	▶	Replace smart entrance control unit. (Before replacing smart entrance control unit, perform "DOOR LOCK/UNLOCK SWITCH CHECK".)

3	CHECK DOOR LOCK ACTUATOR
	<p>1. Disconnect door lock actuator connector. 2. Apply 12V direct current to door lock actuator and check operation.</p> <div style="display: flex; justify-content: space-between;"> <div data-bbox="256 268 738 583"> <p>Door lock actuator connector</p> <p>Front LH: (D7) Front RH: (D37) Rear LH: (D54) Rear RH: (D74)</p> </div> <div data-bbox="868 342 1356 504"> <p>• <b>Door lock actuator operation:</b>  <b>Terminals between (+): 3 and (-): 1</b>  <b>Unlocked → Locked</b>  <b>Terminals between (+): 1 and (-): 3</b>  <b>Locked → Unlocked</b></p> </div> </div> <p style="text-align: right;">SEL318X</p> <div style="display: flex; justify-content: space-between; margin-top: 20px;"> <div data-bbox="256 640 711 919"> <p>Back door lock actuator connector (D207)</p> </div> <div data-bbox="868 693 1356 854"> <p>• <b>Back door lock actuator operation:</b>  <b>Terminals between (+): 1 and (-): 2</b>  <b>Unlocked → Locked</b>  <b>Terminals between (+): 2 and (-): 1</b>  <b>Locked → Unlocked</b></p> </div> </div> <p style="text-align: right;">SEL319X</p> <p style="text-align: center; margin-top: 10px;"><b>OK or NG</b></p>
OK	▶ Check harness for open or short between smart entrance control unit connector and door lock actuator.
NG	▶ Replace door lock actuator.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# REMOTE KEYLESS ENTRY SYSTEM

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0391



SEL290Y

## System Description

NAEL0392

NAEL0392S01

### INPUTS

Power is supplied at all times

- to smart entrance control unit terminal 49 and
- to key switch terminal 2
- through 7.5A fuse [No. 24, located in the fuse block (J/B)].

When the key switch is ON (ignition key is inserted in key cylinder), power is supplied

- through key switch terminal 1
- to smart entrance control unit terminal 25.

When the front door switch LH is ON (door is OPEN), ground is supplied

- to smart entrance control unit terminal 1
- through front door switch LH terminal 1
- to front door switch LH terminal 2
- through body grounds B11, B22 and D210.

When the front door switch RH is ON (door is OPEN), ground is supplied

- to smart entrance control unit terminal 2
- through front door switch RH terminal 1
- to front door switch RH terminal 2
- through body grounds B55 and B75.

When the all doors switches are ON (door is OPEN), ground is supplied

- to smart entrance control unit terminal 3
- through front door switches terminal 3
- to front door switches case grounds, and
- through rear door switches terminal 1
- to rear door switches case grounds, and
- through back door switch terminal 2
- to back door switch terminal 1
- through body grounds B11, B22 and D210.

GI

MA

EM

LC

When lock/unlock switch LH is LOCK, ground is supplied

- to smart entrance control unit terminal 5
- through lock/unlock switch LH terminal 6, and
- through body grounds M77 and M111.

EC

When lock/unlock switch LH is UNLOCK, ground is supplied

- to smart entrance control unit terminal 4
- through lock/unlock switch LH terminal 19, and
- through body grounds M77 and M111.

FE

CL

Remote controller signal is inputted to smart entrance control unit (The antenna of the system is combined with smart entrance control unit).

MT

## OPERATION

NAEL0392S02

The remote keyless entry system controls operation of the

- power door lock
- auto door lock
- interior lamp
- panic alarm
- hazard and horn reminder
- power window opener

AT

TF

PD

## OPERATED PROCEDURE

### Power Door Lock Operation

NAEL0392S03

AX

Smart entrance control unit receives a LOCK signal from keyfob. Smart entrance control unit locks all doors with input of LOCK signal from keyfob.

When an UNLOCK signal is sent from keyfob once, driver's door will be unlocked.

Then, if an UNLOCK signal is sent from keyfob again within 5 seconds, all other door will be unlocked.

Select unlock mode can be changed by CONSULT-II (EL-320).

NAEL0392S0301

SU

BR

### Auto Door Lock Operation

Auto lock function signal is sent for operation when any of the following signals are not sent within 5 minutes after the unlock signal is sent from the keyfob:

NAEL0392S0308

ST

- when door switch is turned ON for open.
- when the ignition switch is turned ON.
- when the lock signal is sent from the keyfob.

RS

Auto door lock mode can be changed by CONSULT-II (EL-320).

BT

### Hazard and Horn Reminder

Power is supplied at all times

NAEL0392S0302

- to horn relay terminals 1 and 3
- through 7.5A fuse (No. 52, located in the fusible link and fuse box), and
- to horn relay terminal 6
- through 10A fuse (No. 54, located in the fusible link and fuse box)

HA

SC

When smart entrance control unit receives LOCK or UNLOCK signal from remote controller with all doors closed, ground is supplied

- to horn relay terminal 2
- through smart entrance control unit terminal 42, and
- to smart entrance control unit terminals 47 and 48 from hazard warning lamp system.

EL

IDX

# REMOTE KEYLESS ENTRY SYSTEM

## System Description (Cont'd)

Horn relay are now energized, and hazard warning lamp flashes and horn sounds as a reminder. The hazard and horn reminder has C mode (horn chirp mode) and S mode (non-horn chirp mode).

### Operating function of hazard and horn reminder

	Lock		Unlock	
	Hazard warning lamp flash	Horn sound	Hazard warning lamp flash	Horn sound
C MODE	Twice	Once	Once	—
S MODE	Twice	—	—	—
MODE 3	—	—	—	—
MODE 4	Twice	—	Once	—
MODE 5	Twice	Once	—	—
MODE 6	—	Once	Once	—


### How to change hazard and horn reminder mode

☑ With CONSULT-II

Hazard and horn reminder can be changed by CONSULT-II (EL-320).

☒ Without CONSULT-II

When LOCK and UNLOCK signals are sent from the keyfob for more than 2 seconds at the same time, the hazard and horn reminder mode is changed and hazard warning lamp flashes and horn sounds as follows:



### NOTE:

Reminder mode setting cannot be changed without CONSULT-II for MODES 3,4, 5, and 6. However, C and S MODES can be changed without CONSULT-II.

### Interior Lamp Operation

When the following input signals are both supplied:

- door switch CLOSED (when all the doors are closed);
- driver's door LOCKED;

remote keyless entry system turns on interior lamp and keyhole illumination (for 30 seconds) with input of UNLOCK signal from keyfob.

For detailed description, refer to "INTERIOR, STEP, SPOT, VANITY MIRROR AND TRUNK ROOM LAMPS" (EL-92).

### Panic Alarm Operation

When key switch is OFF (when ignition key is not inserted in key cylinder), remote keyless entry system turns horn and headlamp on and off intermittently with input of PANIC ALARM signal from keyfob.

The alarm automatically turns off after 25 seconds or when smart entrance control unit receives any signal from keyfob.

For detailed description, refer to "VEHICLE SECURITY SYSTEM" (EL-343).

The panic alarm button's pressing time on keyfob can be changed with CONSULT-II (EL-320).

### Power Window Opener Operation

The front power windows open when the unlock button on keyfob is activated and kept pressed for more than 3 seconds with the ignition key OFF. The windows keep opening if the unlock button is continuously pressed. The power window opening stops when the following operations are carried out:

# REMOTE KEYLESS ENTRY SYSTEM

System Description (Cont'd)

- When the unlock button is kept pressed more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.

The unlock button's pressing time can be changed with CONSULT-II (EL-320).

Door Lock/Unlock and front power window down signal is supplied

- through smart entrance control unit terminal 33
- to front power window main switch terminal 8 and
- to front power window switch RH terminal 11.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**


IDX

# REMOTE KEYLESS ENTRY SYSTEM

Schematic

## Schematic

NAEL0393



# REMOTE KEYLESS ENTRY SYSTEM




Wiring Diagram — KEYLESS —

## Wiring Diagram — KEYLESS —

NAEL0394

NAEL0394S01

FIG. 1



REFER TO THE FOLLOWING.

- (E1) - SUPER MULTIPLE JUNCTION (SMJ)
- (M10), (E3) - FUSE BLOCK - JUNCTION BOX (J/B)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



# REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram — KEYLESS — (Cont'd)

NAEL0394S02

FIG. 2

## EL-KEYLES-02



REFER TO THE FOLLOWING.  
 (B1) -SUPER MULTIPLE  
 JUNCTION (SMJ)

MEL4120




# REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram — KEYLESS — (Cont'd)

FIG. 3

NAEL0394S03

## EL-KEYLES-03



REFER TO THE FOLLOWING.

(E1) - SUPER MULTIPLE JUNCTION (SMJ)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



# REMOTE KEYLESS ENTRY SYSTEM

Wiring Diagram — KEYLESS — (Cont'd)


NAEL0394S05

FIG. 4

EL-KEYLES-04



MEL436P




## CONSULT-II Inspection Procedure

NAEL0395


NAEL0395S01

### “MULTI REMOTE ENT”


1. Turn ignition switch “OFF”.
2. Connect “CONSULT-II” to the data link connector.




3. Turn ignition switch “ON”.
4. Touch “START”.



5. Touch “SMART ENTRANCE”.



6. Touch “MULTI REMOTE ENT”.



7. Select diagnosis mode. “DATA MONITOR”, “ACTIVE TEST” and “WORK SUPPORT” are available.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# REMOTE KEYLESS ENTRY SYSTEM

CONSULT-II Application Items

## CONSULT-II Application Items

NAEL0457

NAEL0457S01

NAEL0457S0101

### “MULTI REMOTE ENT” Data Monitor

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch in ON position.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch.
KEY ON SW	Indicates [ON/OFF] condition of key switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of door switch RH.
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from lock/unlock switch LH and RH.
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from lock/unlock switch LH and RH.
KEY CYL LK-SW	Indicates [ON/OFF] condition of lock signal from key cylinder switch.
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
TRUNK BTN/SIG	Indicates [ON/OFF] condition of trunk open signal from keyfob.
PANIC BTN	Indicates [ON/OFF] condition of panic signal from keyfob.
UN BUTTON ON	Indicates [ON/OFF] condition of unlock switch form keyfob.
LK/UN BTN ON	Indicates [ON/OFF] condition of lock/unlock signal at the same time from keyfob.

#### NOTE:

Even though TRUNK BTN/SIG is actually displayed on the CONSULT-II screen, it is not equipped, therefore, they cannot be activated.

### Active Test

NAEL0457S0102

Test Item	Description
INT/IGN ILLUM	This test is able to check interior lamp and ignition key hole illumination operation. The interior lamp and ignition key hole illumination are turned on when “ON” on CONSULT-II screen is touched.
HAZARD	This test is able to check hazard reminder operation. The hazard lamp turns on when “ON” on CONSULT-II screen is touched.
TRUNK OUTPUT	This test is able to check trunk lid opener actuator operation. The trunk is unlocked when “ON” on CONSULT-II screen is touched.
HORN	This test is able to check panic alarm and horn reminder operations. The alarm activate for 0.5 seconds after “ON” on CONSULT-II screen is touched.
HEAD LAMP	This test is able to check headlamps panic alarm operation. The headlamp illuminates for 0.5 seconds after “ON” on CONSULT-II screen is touched.
PW REMOTE DOWN SET	This test is able to check power window open operation. The front power windows activate for 10 seconds after “ON” on CONSULT-II screen is touched.

#### NOTE:

Even though TRUNK OUTPUT is actually displayed on the CONSULT-II screen, it is not equipped, therefore, they cannot be activated.

### Work Support

NAEL0457S0103

Test Item	Description
REMO CONT ID CONFIR	It can be checked whether keyfob ID code is registered or not in this mode.
REMO CONT ID REGIST	Keyfob ID code can be registered.
REMO CONT ID ERASUR	Keyfob ID code can be erased.

# REMOTE KEYLESS ENTRY SYSTEM

CONSULT-II Application Items (Cont'd)

Test Item	Description
MULTI ANSWER BACK SET	Hazard and horn reminder mode can be changed with this mode. Selects hazard and horn reminder mode among six steps (EL-311).
AUTO LOCK SET	Auto door lock mode can be selected among the following periods: ● MODE 1 (5 min.)/MODE 2 (OFF-Mode)/MODE 3 (1 min.)
PANIC ALARM SET	The panic alarm button's pressing time on keyfob can be selected among the following periods: ● MODE 1 (0.5 sec.)/MODE 2 (OFF-Mode)/MODE 3 (1.5 sec.)
TRUNK OPENER	The trunk lid opener button's pressing time on keyfob can be selected among the following periods: ● MODE 1 (0.5 sec.)/MODE 2 (OFF-Mode)/MODE 3 (1.5 sec.)
PW DOWN SET	The unlock button's pressing time on keyfob can be selected among the following periods: ● MODE 1 (3 sec.)/MODE 2 (OFF-Mode)/MODE 3 (5 sec.)

**NOTE:**

Even though TRUNK OPENER is actually displayed on the CONSULT-II screen, it is not equipped, therefore, they cannot be activated.

## Trouble Diagnoses

### SYMPTOM CHART

NAEL0397

**NOTE:**

NAEL0397S01

- Always check keyfob battery before replacing keyfob.
- The panic alarm operation of remote keyless entry system does not activate with the ignition key inserted in the ignition key cylinder.

Symptom	Diagnoses/service procedure	Reference page (EL- )
All functions of remote keyless entry system do not operate.	1. Keyfob battery and function check	323
	2. Power supply and ground circuit for smart entrance control unit check	324
	3. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	336
The new ID of keyfob cannot be entered.	1. Keyfob battery and function check	323
	2. Key switch (insert) check	328
	3. Door switch check	326
	4. Door lock/unlock switch LH check	329
	5. Power supply and ground circuit for smart entrance control unit check	324
	6. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	336
Door lock or unlock does not function. (If the power door lock system does not operate manually, check power door lock system. Refer to EL-297)	1. Keyfob battery and function check	323
	2. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	336

## REMOTE KEYLESS ENTRY SYSTEM

### Trouble Diagnoses (Cont'd)


Symptom	Diagnoses/service procedure	Reference page (EL- )
Hazard and horn reminder does not activate properly when pressing lock or unlock button of keyfob.	1. Keyfob battery and function check	323
	2. Hazard reminder check	330
	3. Horn reminder check* *: Horn chirp can be activated or deactivated. First check the horn chirp setting. Refer to "System Description", EL-311.	331
	4. Door switch check	326
	5. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	336
Interior room lamp operation do not activate properly.	1. Interior room lamp operation check	333
	2. Door switch check	326
Panic alarm (horn and headlamp) does not activate when panic alarm button is continuously pressed.	1. Keyfob battery and function check	323
	2. Theft warning operation check. Refer to "PRELIMINARY CHECK" in "VEHICLE SECURITY SYSTEM".	354
	3. Key switch (insert) check	328
	4. Replace keyfob. Refer to ID Code Entry Procedure. NOTE: If the result of keyfob function check with CONSULT-II is OK, keyfob is not malfunctioning.	336

# REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

## REMOTE CONTROLLER BATTERY AND FUNCTION CHECK

-NAEL0397S02

<b>1</b>	<b>CHECK REMOTE CONTROLLER BATTERY</b>	
<p>Remove battery (refer to EL-338) and measure voltage across battery positive and negative terminals, (+) and (-).</p> <p><b>Voltage [V]:</b> <b>2.5 - 3.0</b></p> <p><b>NOTE:</b> Keyfob does not function if battery is not set correctly.</p>		
		
SEL237W		
<b>OK or NG</b>		
OK	▶	GO TO 2.
NG	▶	Replace battery.

<b>2</b>	<b>CHECK REMOTE CONTROLLER FUNCTION</b>																						
<p> <b>With CONSULT-II</b> Check keyfob function ("LK BUTTON/SIG", "UN BUTTON/SIG", "PANIC BTN", "UN BUTTON ON" and "LK/UN BTN ON") in "DATA MONITOR" mode with CONSULT-II.</p>																							
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITOR</th> <th style="text-align: center;"></th> </tr> </thead> <tbody> <tr> <td>LK BUTTON/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>UN BUTTON/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>TRUNK BTN/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>PANIC BTN</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>UN BUTTON ON</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>LK/UN BTN ON</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR		LK BUTTON/SIG	ON	UN BUTTON/SIG	ON	TRUNK BTN/SIG	ON	PANIC BTN	ON	UN BUTTON ON	ON	LK/UN BTN ON	ON					
DATA MONITOR																							
MONITOR																							
LK BUTTON/SIG	ON																						
UN BUTTON/SIG	ON																						
TRUNK BTN/SIG	ON																						
PANIC BTN	ON																						
UN BUTTON ON	ON																						
LK/UN BTN ON	ON																						
<p><b>When pushing each button of keyfob, the corresponding monitor item should be turned as follows.</b></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Condition</th> <th colspan="2" style="text-align: center;">Monitor item</th> </tr> </thead> <tbody> <tr> <td>Pushing LOCK</td> <td>LK BUTTON/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>Pushing UNLOCK</td> <td>UN BUTTON/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>Pushing TRUNK</td> <td>TRUNK BTN/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>Pushing PANIC</td> <td>PANIC BTN/SIG</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>Pushing UNLOCK</td> <td>UN BUTTON ON</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>Pushing LOCK and UNLOCK at the same time</td> <td>LK/UN BTN ON</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table>			Condition	Monitor item		Pushing LOCK	LK BUTTON/SIG	ON	Pushing UNLOCK	UN BUTTON/SIG	ON	Pushing TRUNK	TRUNK BTN/SIG	ON	Pushing PANIC	PANIC BTN/SIG	ON	Pushing UNLOCK	UN BUTTON ON	ON	Pushing LOCK and UNLOCK at the same time	LK/UN BTN ON	ON
Condition	Monitor item																						
Pushing LOCK	LK BUTTON/SIG	ON																					
Pushing UNLOCK	UN BUTTON/SIG	ON																					
Pushing TRUNK	TRUNK BTN/SIG	ON																					
Pushing PANIC	PANIC BTN/SIG	ON																					
Pushing UNLOCK	UN BUTTON ON	ON																					
Pushing LOCK and UNLOCK at the same time	LK/UN BTN ON	ON																					
SEL423Y																							
<b>NOTE:</b> Even though TRUNK BTN/SIG is actually displayed on the CONSULT-II screen, it is not equipped, therefore, they cannot be activated.																							
<b>OK or NG</b>																							
OK	▶	Keyfob is OK. Further inspection is necessary. Refer to "SYMPTOM CHART", EL-321.																					
NG	▶	Replace keyfob. Refer to ID Code Entry Procedure.																					

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

## POWER SUPPLY AND GROUND CIRCUIT CHECK


=NAEL0397S03

<b>1</b>	<b>CHECK MAIN POWER SUPPLY CIRCUIT FOR SMART ENTRANCE CONTROL UNIT</b>	
<p>1. Disconnect smart entrance control unit harness connector.                  2. Check voltage between smart entrance control unit harness connector M123 terminal 49 (G/R) or 51 (W/R) and ground.</p>		
SEL018Y		
Refer to wiring diagram in EL-315.		
<b>OK or NG</b>		
OK	▶	GO TO 2.
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 40A fusible link (letter f, located in fuse and fusible link box)</li> <li>● 7.5A fuse [No. 24, located in fuse block (J/B)]</li> <li>● M145 circuit breaker</li> <li>● Harness for open or short between smart entrance control unit and fuse</li> </ul>

<b>2</b>	<b>CHECK IGNITION SWITCH “ACC” CIRCUIT</b>	
<p>1. Disconnect smart entrance control unit harness connector.                  2. Check voltage between smart entrance control unit harness connector M122 terminal 26 (G/W) and ground while ignition switch is “ACC”.</p>		
SEL019Y		
Refer to wiring diagram in EL-315.		
<b>OK or NG</b>		
OK	▶	GO TO 3.
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 10A fuse [No. 10, located in fuse block (J/B)]</li> <li>● Harness for open or short between smart entrance control unit and fuse</li> </ul>

# REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

3	<b>CHECK GROUND CIRCUIT FOR SMART ENTRANCE CONTROL UNIT</b>	
Check continuity between smart entrance control unit harness connector M122 terminal 43 (B) or M123 terminal 64 (B) and ground.		
<div style="display: flex; align-items: center; justify-content: space-around;"> <div style="text-align: center;"> <p>Smart entrance control unit connector</p>  </div> <div style="text-align: center;">  <p><b>Continuity should exist.</b></p> </div> </div>		
Refer to wiring diagram in EL-315. <span style="float: right;">SEL020Y</span>		
<b>OK or NG</b>		
OK	▶	Power supply and ground circuits are OK.
NG	▶	Check ground harness.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX

# REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

## DOOR SWITCH CHECK

=NAEL0397S04

### 1 CHECK DOOR SWITCH INPUT SIGNAL

#### With CONSULT-II

Check door switches ("DOOR SW-RR", "DOOR SW-DR" and "DOOR SW-AS") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
DOOR SW-RR	OFF
DOOR SW-DR	OFF
DOOR SW-AS	OFF


	Monitor item	Condition	Condition
DOOR SW-RR	Rear doors switch	Open	ON
		Closed	OFF
DOOR SW-DR	Door switch LH	Open	ON
		Closed	OFF
DOOR SW-AS	Door switch RH	Open	ON
		Closed	OFF

SEL024Y

#### Without CONSULT-II

Check voltage between smart entrance control unit harness connector M121 terminals 1 (G/OR), 2 (Y) or 3 (R/L) and ground.

Smart entrance control unit connector



	Terminals		Condition	Voltage [V]
	(+)	(-)		
Front door switch LH	1	Ground	Open	0
			Closed	Approx. 5
Front door switch RH	2	Ground	Open	0
			Closed	Approx. 5
Rear and back door switches	3	Ground	Open	0
			Closed	Approx. 5

SEL021YA

Refer to wiring diagram in EL-316.



OK or NG

OK	▶	Door switch is OK.
NG	▶	GO TO 2.

# REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


<b>2</b>	<b>CHECK DOOR SWITCH</b>		
<p>1. Disconnect door switch harness connector.                  2. Check the following.</p> <ul style="list-style-type: none"> <li>● Continuity between front door switch harness connector B9 (LH) or B68 (RH) terminals 1 and 2</li> <li>● Continuity between front door switch harness connector B9 (LH) or B68 (RH) terminal 3 and ground</li> <li>● Continuity between back door switch harness connector D208 terminals 1 and 2</li> <li>● Continuity between rear door switch harness connector B18 (LH) or B71 (RH) terminal 1 and ground</li> </ul>			
 <p>Front door switch connector      Back door switch</p>			
			
 <p>Rear door switch connector</p>			
SEL287Y			
<b>OK or NG</b>			
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Door switch ground circuit (Front or back door) or door switch ground condition</li> <li>● Harness for open or short between smart entrance control unit and door switch</li> </ul>	
NG	▶	Replace door switch.	


# REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

## KEY SWITCH (INSERT) CHECK

=NAEL0397S05

<b>1</b>	<b>CHECK KEY SWITCH INPUT SIGNAL</b>	<p> <b>With CONSULT-II</b> Check key switch ("KEY ON SW") in "DATA MONITOR" mode with CONSULT-II.</p> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="width: 50%;">MONITOR</th> <th style="width: 50%;"></th> </tr> </thead> <tbody> <tr> <td>KEY ON SW</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table> </div> <div> <p>When key is inserted to ignition key cylinder: <b>KEY ON SW ON</b></p> <p>When key is removed from ignition key cylinder: <b>KEY ON SW OFF</b></p> </div> </div> <p style="text-align: right; margin-top: 20px;">SEL315W</p>	DATA MONITOR		MONITOR		KEY ON SW	ON
DATA MONITOR								
MONITOR								
KEY ON SW	ON							
		<p> <b>Without CONSULT-II</b> Check voltage between control unit harness connector M122 terminal 25 (W/R) and ground.</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>Smart entrance control unit connector</p>  </div> <div> <p><b>Voltage [V]:</b></p> <p>Condition of key switch : Key is inserted. Approx. 12</p> <p>Condition of key switch : Key is removed. 0</p> </div> </div> <p style="text-align: right; margin-top: 20px;">SEL022Y</p>						
		OK or NG						
OK	▶	Key switch is OK.						
NG	▶	GO TO 2.						

<b>2</b>	<b>CHECK KEY SWITCH (INSERT)</b>	<p>Check continuity between key switch terminals 1 and 2.</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>Key switch connector (E5)</p>  </div> <div> <p><b>Continuity:</b></p> <p>Condition of key switch: Key is inserted. Yes</p> <p>Condition of key switch: Key is removed. No</p> </div> </div> <p style="text-align: right; margin-top: 20px;">SEL308X</p>
		OK or NG
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 24, located in fuse block (J/B)]</li> <li>● Harness for open or short between key switch and fuse</li> <li>● Harness for open or short between smart entrance control unit and key switch</li> </ul>
NG	▶	Replace key switch.

# REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

## DOOR LOCK/UNLOCK SWITCH LH CHECK

=NAEL0397S06

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

### 1 CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

#### With CONSULT-II

Check door lock/unlock switch ("LOCK SW DR/AS"/"UNLK SW DR/AS") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
LOCK SW DR/AS	OFF
UNLK SW DR/AS	OFF

When lock/unlock switch is turned to LOCK:

**LOCK SW DR/AS ON**


When lock/unlock switch is turned to UNLOCK:

**UNLK SW DR/AS ON**

SEL341W

#### Without CONSULT-II

1. Remove key from ignition switch.
2. Check the signal between smart entrance control unit harness connector M122 terminal 33 (BR) and ground with an oscilloscope when door lock/unlock switch is turned "LOCK" or "UNLOCK".
3. Make sure signals shown in the figure below can be detected during the first 10 sec. just after door lock/unlock switch is turned to "LOCK" or "UNLOCK".



**Voltage:**

**12V → 9V (10 sec.) measurement  
by analog circuit tester.**

SEL396Y

Refer to wiring diagram in EL-315.

**OK or NG**

OK ► Door lock/unlock switch is OK.

NG ►

**Check the following.**

- Ground circuit for each front power window switch
- Harness for open or short between each front power window switch and smart entrance control unit connector

If above systems are normal, replace the front power window switch.


# REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)


## HAZARD REMINDER CHECK

=NAEL0397S07

<b>1</b>	<b>CHECK HAZARD INDICATOR</b>	
Check if hazard indicator flashes with hazard switch.		
<b>Does hazard indicator operate?</b>		
Yes	▶	GO TO 2.
No	▶	Check "hazard indicator" circuit.

<b>2</b>	<b>CHECK HAZARD REMINDER OPERATION WITH CONSULT-II</b>	
<p> <b>With CONSULT-II</b></p> <p>1. Select "ACTIVE TEST" in "MULTI REMOTE ENT" with CONSULT-II. 2. Select "HAZARD" and touch "ON".</p>		
		
<b>Hazard indicator should illuminate.</b>		
<p><b>NOTE: If CONSULT-II is not available, skip this procedure and go to the next step.</b></p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	Hazard reminder operation is OK.
NG	▶	Replace smart entrance control unit.

SEL347W

<b>3</b>	<b>CHECK HAZARD REMINDER OPERATION WITHOUT CONSULT-II</b>							
<p> <b>Without CONSULT-II</b></p> <p>Apply ground to smart entrance control unit harness connector M122 terminal 47 (GY/L) and 48 (GY/R).</p>								
<div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> <p>Smart entrance control unit connector</p>  </div> <div style="margin-right: 20px;">  <p><b>H.S.</b></p> <p>CONNECT</p>   </div> <table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Condition of lock or unlock button</th> <th>Voltage (V)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Push.</td> <td style="text-align: center;">Approx. more than 0 - 12</td> </tr> <tr> <td style="text-align: center;">Do not push.</td> <td style="text-align: center;">0</td> </tr> </tbody> </table> </div>			Condition of lock or unlock button	Voltage (V)	Push.	Approx. more than 0 - 12	Do not push.	0
Condition of lock or unlock button	Voltage (V)							
Push.	Approx. more than 0 - 12							
Do not push.	0							
<p>Refer to wiring diagram in EL-317.</p> <p style="text-align: center;"><b>OK or NG</b></p>								
OK	▶	System is OK.						
NG	▶	Replace smart entrance control unit.						

SEL027Y

# REMOTE KEYLESS ENTRY SYSTEM


Trouble Diagnoses (Cont'd)

## HORN REMINDER CHECK

=NAEL0397S08

<b>1</b>	<b>CHECK HORN</b>	
Check if horn sounds with horn switch.		
<b>Does horn operate?</b>		
Yes	▶	GO TO 2.
No	▶	Check horn circuit.

<b>2</b>	<b>CHECK HORN REMINDER OPERATION WITH CONSULT-II</b>							
<p> <b>With CONSULT-II</b></p> <p>1. Select "ACTIVE TEST" in "MULTI REMOTE ENT" with CONSULT-II. 2. Select "HORN" and touch "ON".</p>								
<div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <p style="text-align: center; margin: 0;"><b>ACTIVE TEST</b></p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; padding: 2px;">HORN</td> <td style="width: 50%; padding: 2px;">OFF</td> </tr> <tr> <td colspan="2" style="height: 100px;"></td> </tr> <tr> <td style="text-align: center; padding: 2px;"><b>ON</b></td> <td style="padding: 2px;"></td> </tr> </table> </div> <div style="text-align: center;"> <p><b>Horn should sound.</b></p> </div> </div>			HORN	OFF			<b>ON</b>	
HORN	OFF							
<b>ON</b>								
SEL451Y								
<b>NOTE: If CONSULT-II is not available, skip this procedure and go to the next step.</b>								
<b>OK or NG</b>								
OK	▶	Horn reminder operation is OK.						
NG	▶	GO TO 4.						

<b>3</b>	<b>CHECK HORN REMINDER OPERATION WITHOUT CONSULT-II</b>	
<p> <b>Without CONSULT-II</b></p> <p>1. Disconnect smart entrance control unit harness connector. 2. Apply ground to smart entrance control unit harness connector M122 terminal 42 (LG/B).</p>		
		
Refer to wiring diagram in EL-317.		
<b>Does horn sound?</b>		
Yes	▶	Replace smart entrance control unit.
No	▶	GO TO 4.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC


**EL**


IDX

# REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

<b>4</b>	<b>CHECK HORN RELAY</b>
Check horn relay.	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Replace horn relay.

<b>5</b>	<b>CHECK POWER SUPPLY FOR HORN RELAY</b>
<ol style="list-style-type: none"> <li>1. Disconnect horn relay harness connector.</li> <li>2. Check voltage between horn relay harness connector E118 terminal 1 (G/B) and ground.</li> </ol>	
	
Battery voltage should exist.	
SEL326XA	
OK or NG	
OK	▶ GO TO 6.
NG	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 52, located in fuse block (J/B)]</li> <li>● Harness for open or short between horn relay and fuse</li> </ul>

<b>6</b>	<b>CHECK HORN RELAY CIRCUIT</b>
<ol style="list-style-type: none"> <li>1. Disconnect horn relay harness connector.</li> <li>2. Check voltage between horn relay harness connector E118 terminals 3 (G/B) and 5 (R).</li> <li>3. Check voltage between horn relay harness connector E118 terminals 6 (LG) and 7 (G).</li> </ol>	
	
Battery voltage should exist.	
SEL327XA	
OK or NG	
OK	▶ Check harness for open or short between smart entrance control unit and horn relay.
NG	▶ <b>Check the following.</b> <ul style="list-style-type: none"> <li>● Harness for open or short between horn relay and fuse</li> <li>● Harness for open or short between horn relay and horns</li> </ul>


# REMOTE KEYLESS ENTRY SYSTEM

Trouble Diagnoses (Cont'd)

## INTERIOR ROOM LAMP OPERATION CHECK

=NAEL0397S09

<b>1</b>	<b>CHECK ROOM INTERIOR LAMP</b>	
Check if the interior room lamp switch is in the "ON" position and the lamp illuminates.		
<b>Does interior room lamp illuminate?</b>		
Yes	▶	GO TO 2.
No	▶	<b>Check the following.</b> <ul style="list-style-type: none"> <li>● Harness for open or short between smart entrance control unit and interior room lamp</li> <li>● Interior room lamp</li> </ul>

<b>2</b>	<b>CHECK INTERIOR ROOM LAMP OPERATION</b>									
<p> <b>With CONSULT-II</b></p> <p>1. Select "ACTIVE TEST" in "MULTI REMOTE ENT" with CONSULT-II. 2. Select "INT/IGN ILLUM" and touch "ON".</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 20px;"> <table style="width: 100%; border-collapse: collapse;"> <tr><th colspan="2" style="text-align: center; padding: 2px;">ACTIVE TEST</th></tr> <tr><td style="padding: 2px;">IN/IGN ILLUM</td><td style="padding: 2px; text-align: right;">OFF</td></tr> <tr><td colspan="2" style="height: 100px;"></td></tr> <tr><td colspan="2" style="text-align: center; background-color: black; color: white; padding: 2px;">ON</td></tr> </table> </div> <div style="text-align: center;"> <p><b>Interior room lamp should illuminate.</b></p> </div> <div style="margin-left: 20px;"> <p>SEL312Y</p> </div> </div>			ACTIVE TEST		IN/IGN ILLUM	OFF			ON	
ACTIVE TEST										
IN/IGN ILLUM	OFF									
ON										
<p> <b>Without CONSULT-II</b></p> <p>Push unlock button of keyfob with all doors closed and driver's door locked, and check voltage between smart entrance control unit harness connector M122 terminal 31 (R/B) and ground.</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="margin-right: 20px;"> <p>Smart entrance control unit connector</p>  </div> <div style="margin-right: 20px;">      </div> <div> <p><b>Voltage [V]:</b></p> <p><b>Unlock button is pushed.</b> 0 (For approx. 30 seconds.)</p> <p><b>Unlock button is not pushed.</b> Battery voltage</p> </div> </div> <p>Refer to wiring diagram in EL-315.</p> <p style="text-align: center;">OK or NG</p> <p style="text-align: right;">SEL029Y</p>										
OK	▶	System is OK.								
NG	▶	Check harness open or short between smart entrance control unit and interior room lamp.								

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# REMOTE KEYLESS ENTRY SYSTEM

ID Code Entry Procedure


## ID Code Entry Procedure KEYFOB ID SET UP WITH CONSULT-II

=NAEL0398


NAEL0398S01

### NOTE:


If a keyfob is lost, the ID code of the lost keyfob must be erased to prevent unauthorized use. When the ID code of a lost keyfob is not known, all keyfob ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new keyfob must be re-registered.




1. Turn ignition switch "OFF".
2. Connect CONSULT-II to the data link connector.



3. Turn ignition switch "ON".
4. Touch "START".




5. Touch "SMART ENTRANCE".



6. Touch "MULTI REMOTE ENT".


# REMOTE KEYLESS ENTRY SYSTEM

ID Code Entry Procedure (Cont'd)



7. Touch "WORK SUPPORT".

GI



8. The items are shown on the figure at left can be set up.

MA

EM

LC

EC

- "REMO CONT ID CONFIR"  
Use this mode to confirm if a keyfob ID code is registered or not.
- "REMO CONT ID REGIST"  
Use this mode to register a keyfob ID code.

FE

CL

**NOTE:**

**Register the ID code when keyfob or smart entrance control unit is replaced, or when additional keyfob is required.**

MT

- "REMO CONT ID ERASUR"  
Use this mode to erase a keyfob ID code.

AT

Refer to the EL-320, "WORK SUPPORT" in "CONSULT-II Application Items" for the following items.

- "MULTI ANSWER BACK SET"
- "AUTO LOCK SET"
- "PANIC ALARM SET"
- "TRUNK OPENER"
- "PW DOWN SET"

TF

PD

**NOTE:**

Even though TRUNK OPENER is actually displayed on the CONSULT-II screen, it is not equipped, therefore, they cannot be activated.

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

# REMOTE KEYLESS ENTRY SYSTEM

ID Code Entry Procedure (Cont'd)

## KEYFOB ID SET UP WITHOUT CONSULT-II

NAEL0398S02



SEL170YA

# REMOTE KEYLESS ENTRY SYSTEM

ID Code Entry Procedure (Cont'd)

## NOTE:

- If a keyfob is lost, the ID code of the lost keyfob must be erased to prevent unauthorized use. A specific ID code can be erased with CONSULT-II. However, when the ID code of a lost keyfob is not known, all keyfob ID codes should be erased. After all ID codes are erased, the ID codes of all remaining and/or new keyfob must be re-registered.  
To erase all ID codes in memory, register one ID code (keyfob) four times. After all ID codes are erased, the ID codes of all remaining and/or new keyfob must be re-registered.
- When registering an additional keyfob, the existing ID codes in memory may or may not be erased. If four ID codes are stored in memory, when an additional code is registered, only the oldest code is erased. If less than four ID codes are stored in memory, when an additional ID code is registered, the new ID code is added and no ID codes are erased.
- If you need to activate more than two additional new keyfob, repeat the procedure "Additional ID code entry" for each new keyfob.
- Entry of maximum four ID codes is allowed. When more than four ID codes are entered, the oldest ID code will be erased.
- Even if the same ID code that is already in the memory is input, the same ID code can be entered. The code is counted as an additional code.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# REMOTE KEYLESS ENTRY SYSTEM





## Keyfob Battery Replacement

### Keyfob Battery Replacement

NAEL0399

#### NOTE:

- Be careful not to touch the circuit board or battery terminal.
- The keyfob is water-resistant. However, if it does get wet, immediately wipe it dry.





SEL485Y

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0400



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

SEL484Y

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

System Description

## System Description


NAEL0401

NAEL0401S01

NAEL0401S0101

### DESCRIPTION

#### 1. Operation Flow



SEL334W

#### 2. Setting The Vehicle Security System

NAEL0401S0102

##### Initial condition

- 1) Ignition switch is in OFF position.

##### Disarmed phase

When the vehicle security system is in the disarmed phase, the security indicator lamp blinks every 2.6 seconds.

##### Pre-armed phase and armed phase

When the following operation 1) or 2) is performed, the vehicle security system turns into the “pre-armed” phase. (The security indicator lamp illuminates.)

- 1) Smart entrance control unit receives LOCK signal from key cylinder switch or keyfob after hood, glass hatch and all doors are closed.
- 2) Hood, glass hatch and all doors are closed after front doors are locked by key, lock/unlock switch or multi-remote controller.

After about 30 seconds, the system automatically shifts into the “armed” phase (the system is set). (The security indicator lamp blinks every 2.6 seconds.)

#### 3. Canceling The Set Vehicle Security System

NAEL0401S0103

When the following 1) or 2) operation is performed, the armed phase is canceled.

- 1) Unlock the doors with the key or keyfob.
- 2) Open the glass hatch with the key or keyfob.

#### 4. Activating The Alarm Operation of The Vehicle Security System

NAEL0401S0104

Make sure the system is in the armed phase. (The security indicator lamp blinks every 2.6 seconds.)

When the following operation 1) or 2) is performed, the system sounds the horns and flashes the headlamps for about 50 seconds.

- 1) Engine hood, glass hatch or any door is opened during armed phase.
- 2) Disconnecting and connecting the battery connector before canceling armed phase.

#### POWER SUPPLY AND GROUND

NAEL0401S02

Power is supplied at all times

- through 7.5A fuse [No. 24, located in the fuse block (J/B)]
- to security indicator lamp terminal 1, and
- to smart entrance control unit terminal 49.

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

System Description (Cont'd)

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 11, located in the fuse block (J/B)]
- to smart entrance control unit terminal 27.

GI

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 10, located in the fuse block (J/B)]
- to smart entrance control unit terminal 26.

MA

Ground is supplied

- to smart entrance control unit terminals 43 and 64
- through body grounds M77 and M111.

EM

LC

## INITIAL CONDITION TO ACTIVATE THE SYSTEM

The operation of the vehicle security system is controlled by the doors, hood and glass hatch.

NAEL0401S03

EC

### Pattern A

To activate the vehicle security system, the smart entrance control unit must receive signals indicating the doors, hood and glass hatch are closed.

NAEL0401S0301

FE

When a door is open, smart entrance control unit terminal 1, 2 or 3 receives a ground signal from each door switch.

CL

When the hood is open, smart entrance control unit terminal 6 receives a ground signal

- from terminal 1 of the hood switch
- through body grounds E13 and E41.

MT

When the glass hatch is open, smart entrance control unit terminal 13 receives a ground signal

- from terminal 1 of the glass hatch switch
- through body grounds B11, B22 and D210.

AT

When smart entrance control unit receives LOCK signal from key cylinder switch or keyfob and none of the described conditions exist, the vehicle security system will automatically shift to armed mode.

TF

### Pattern B

To activate the vehicle security system, the smart entrance control unit must receive signal indicating any door (including hood and glass hatch) is opened.

NAEL0401S0302

PD

When the front doors are locked with key, lock/unlock switch or keyfob and then all doors are closed, the vehicle security system will automatically shift to armed mode.

AX

## VEHICLE SECURITY SYSTEM ACTIVATION

### Pattern A

With all doors (including hood and glass hatch) closed, if the key is used to lock doors, smart entrance control unit terminal 33 receives a signal from power window main switch terminal 8.

NAEL0401S04

SU

When key cylinder switch is in LOCK position, ground is supplied

- to power window main switch terminal 6
- from terminal 3 of the front key cylinder switch LH
- through terminal 2 of front key cylinder switch LH
- through body grounds M77 and M111, or

ST

smart entrance control unit terminal 11 receives a ground signal

- from terminal 1 of the back door key cylinder switch
- through body grounds B11, B22 and D210.

RS

BT

If this signal, or lock signal from keyfob is received by the smart entrance control unit, the vehicle security system will activate automatically.

HA

### NOTE:

Vehicle security system can be set even though all doors are not locked.

### Pattern B

With any door (including hood and glass hatch) open, if lock/unlock switch is used to lock doors, smart entrance control unit terminal 33 receives a LOCK signal

NAEL0401S0402

- from terminal 8 of lock/unlock switch LH
- through body grounds M77 and M111, or
- from terminal 11 of lock/unlock switch RH

SC

EL

IDX

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

## System Description (Cont'd)

---

- through body grounds M4, M66 and M147, or

With any door (including hood and glass hatch) open if the key is used to lock doors, smart entrance control unit terminal 33 receives a LOCK signal from power window main front switch terminal 8.

When key cylinder switch LOCK signal ground is supplied

- to power window main switch terminal 6
- from terminal 3 of the front key cylinder switch LH
- through terminal 2 of front key cylinder switch LH
- through body grounds M9, M25 and M87, or

smart entrance control unit terminal 11 receives a ground signal

- from terminal 1 of the back door key cylinder switch
- through body grounds B11, B22 and D210.

If these signals and lock signal from keyfob are received by the smart entrance control unit, ground signals of terminals 1, 2 and 3 are interrupted and all doors are closed, the vehicle security system will activate automatically.

### NOTE:

Vehicle security system can be set even though the rear door is not locked.

Once the vehicle security system has been activated, smart entrance control unit terminal 38 supplies ground to terminal 2 of the security indicator lamp.

The security lamp will illuminate for approximately 30 seconds and then blinks every 2.6 seconds.

Now the vehicle security system is in armed phase.

## VEHICLE SECURITY SYSTEM ALARM OPERATION

NAEL0401S05

The vehicle security system is triggered by

- opening a door
- opening the hood or the glass hatch
- detection of battery disconnect and connect.

Once the vehicle security system is in armed phase, if the smart entrance control unit receives a ground signal at terminal 1, 2, 3 (door switch), 13 (glass hatch switch) or 6 (hood switch), the vehicle security system will be triggered. The headlamps flash and the horn sounds intermittently.

Power is supplied at all times

- through 7.5A fuse (No. 52, located in fuse and fusible link box)
- to horn relay terminals 1 and 3.
- through 10A fuse (No. 54, located in fuse and fusible link box)
- to horn relay terminal 6.
- through 15A fuse (No. 60, located in fuse and fusible link box)
- to headlamp LH relay terminals 1 and 3,
- through 15A fuse (No. 59, located in fuse and fusible link box)
- to headlamp RH relay terminals 1 and 3.

When the vehicle security system is triggered, ground is supplied intermittently

- to headlamp (LH and RH) relay terminal 2 from smart entrance control unit terminals 21 and 59
- through smart entrance control unit terminals 43 and 64.

When headlamp relays (LH and RH) are energized and then power is supplied to headlamps (LH and RH). The headlamps flash intermittently.

When the vehicle security system is triggered, ground is supplied intermittently

- from smart entrance control unit terminal 42
- to horn relay terminal 2.

When horn relay are energized, then power is supplied to horn.

The horn sounds intermittently.

The alarm automatically turns off after 50 seconds but will reactivate if the vehicle is tampered with again.

## VEHICLE SECURITY SYSTEM DEACTIVATION

NAEL0401S06

To deactivate the vehicle security system, a door or glass hatch must be unlocked with the key or keyfob.

When the key is used to unlock the door, smart entrance control unit terminal 33 receives an UNLOCK signal from power window main switch terminal 18.

When key cylinder switch is in UNLOCK position, the ground is supplied

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

System Description (Cont'd)

- to power window main switch terminal 19
- from the front door key cylinder switch LH terminal 1
- through front door key cylinder switch terminal 2,
- through body grounds M77 and M111.

When the key is used to open the glass hatch, smart entrance control unit terminal 12 receives a ground signal from terminal 3 of the back door key cylinder switch.

When the smart entrance control unit receives either one of these signals or unlock signal from keyfob, the vehicle security system is deactivated. (Disarmed phase)

## PANIC ALARM OPERATION

Remote keyless entry system may or may not operate vehicle security system (horn and headlamps) as required. NAEL0401S07

When the remote keyless entry system (panic alarm) is triggered, ground is supplied intermittently

- from smart entrance control unit terminals 21 and 59
- to headlamp (LH and RH) relay terminal 2
- from smart entrance control unit terminal 42
- to horn relay terminal 2.

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off after 25 seconds or when smart entrance control unit receives any signal from keyfob.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Schematic

## Schematic


NAEL0402



MEL873N

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Schematic (Cont'd)



Ⓢ : For U.S.A.

Ⓒ : For Canada

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

MEL437P

IDX

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Wiring Diagram — VEHSEC —


## Wiring Diagram — VEHSEC —

NAEL0403

NAEL0403S01

FIG. 1


EL-VEHSEC-01



Refer to EL-POWER.

SMART ENTRANCE CONTROL UNIT (M121), (M122), (M123)

REFER TO THE FOLLOWING.  
 (E1), (B1) -SUPER MULTIPLE JUNCTION (SMJ)  
 (M10) -FUSE BLOCK-JUNCTION BOX (J/B)







# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Wiring Diagram — VEHSEC — (Cont'd)

FIG. 2

NAEL0403S02

EL-VEHSEC-02



REFER TO THE FOLLOWING.

(B1) -SUPER MULTIPLE JUNCTION (SMJ)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL438P









# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Wiring Diagram — VEHSEC — (Cont'd)

NAEL0403S03

FIG. 3

EL-VEHSEC-03





MEL439P

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Wiring Diagram — VEHSEC — (Cont'd)

FIG. 4

NAEL0403S04



REFER TO THE FOLLOWING.  
 (E1), (B1) -SUPER  
 MULTIPLE JUNCTION (SMJ)

MEL4770

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# VEHICLE SECURITY (THEFT WARNING) SYSTEM



Wiring Diagram — VEHSEC — (Cont'd)

FIG. 5

NAEL0403S05

## EL-VEHSEC-05

U : For USA  
C : For Canada



REFER TO THE FOLLOWING.  
E1 - SUPER MULTIPLE  
JUNCTION (SMJ)

MEL440P

# VEHICLE SECURITY (THEFT WARNING) SYSTEM



Wiring Diagram — VEHSEC — (Cont'd)

FIG. 6

NAEL0403S06

EL-VEHSEC-06

⬡ : For USA




GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL441P

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

CONSULT-II Inspection Procedure




## CONSULT-II Inspection Procedure

=NAEL0404


NAEL0404S01

### "THEFT WAR ALM"


1. Turn ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "SMART ENTRANCE".



6. Touch "THEFT WAR ALM".



7. Select diagnosis mode. "DATA MONITOR", "ACTIVE TEST" and "WORK SUPPORT" are available.

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

CONSULT-II Application Item

## CONSULT-II Application Item

### “THEFT WAR ALM” Data Monitor

NAEL0405

NAEL0405S01

NAEL0405S0101

Monitored Item	Description
IGN ON SW	Indicates [ON/OFF] condition of ignition switch.
ACC ON SW	Indicates [ON/OFF] condition of ignition switch in ACC position.
KEY CYL LK SW	Indicates [ON/OFF] condition of lock signal from key cylinder switch.
KEY CYL UN SW	Indicates [ON/OFF] condition of unlock signal from key cylinder switch.
DOOR SW-RR	Indicates [ON/OFF] condition of rear door switch.
DOOR SW-DR	Indicates [ON/OFF] condition of front door switch LH.
DOOR SW-AS	Indicates [ON/OFF] condition of front door switch RH.
TRUNK SW	Indicates [ON/OFF] condition of back door switch.
TRUNK KEY SW	Indicates [ON/OFF] condition of back door key cylinder switch.
HOOD SWITCH	Indicates [ON/OFF] condition of hood switch.
LOCK SW DR/AS	Indicates [ON/OFF] condition of lock signal from door lock/unlock switch LH and RH.
UNLK SW DR/AS	Indicates [ON/OFF] condition of unlock signal from door lock/unlock LH and RH.
LK BUTTON/SIG	Indicates [ON/OFF] condition of lock signal from keyfob.
UN BUTTON/SIG	Indicates [ON/OFF] condition of unlock signal from keyfob.
TRUNK BTN/SIG	Indicates [ON/OFF] condition of trunk open signal from keyfob.

#### NOTE:

Even though TRUNK BTN/SIG is actually displayed on the CONSULT-II screen, it is not equipped, therefore, they cannot be activated.

### Active Test

NAEL0405S0102

Test Item	Description
THEFT IND	This test is able to check security indicator lamp operation. The lamp will be turned on when “ON” on CONSULT-II screen is touched.
HORN	This test is able to check vehicle security alarm operation. The alarm will be activated for 0.5 seconds after “ON” on CONSULT-II screen is touched.
HEADLAMP	This test is able to check vehicle security alarm headlamp operation. The headlamp illuminates for 0.5 seconds after “ON” on CONSULT-II screen is touched.

### Work Support

NAEL0405S0103

Test Item	Description
THEFT ALM TRG	The switch which triggered theft warning alarm is recorded. This mode is able to confirm and erase the record of theft warning alarm. The trigger data can be erased by touching “CLEAR” on CONSULT-II screen.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses


## Trouble Diagnoses

### PRELIMINARY CHECK

=NAEL0406

NAEL0406S01

The system operation is canceled by turning ignition switch to "ACC" at any step between START and ARMED in the following flow chart.



SEL733W

After performing preliminary check, go to symptom chart below.

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

## SYMPTOM CHART

NAEL0406S02

REFERENCE PAGE (EL- )		354	356	357	362	364	366	369	371	321
SYMPTOM		PRELIMINARY CHECK	POWER SUPPLY AND GROUND CIRCUIT CHECK	DOOR, HOOD AND GLASS HATCH SWITCH CHECK	SECURITY INDICATOR LAMP CHECK	DOOR KEY CYLINDER SWITCH CHECK	BACK DOOR KEY CYLINDER SWITCH CHECK	VEHICLE SECURITY HORN ALARM CHECK	VEHICLE SECURITY HEADLAMP ALARM CHECK	Check "MULTI-REMOTE CONTROL" system.
1	Vehicle security indicator does not illuminate for 30 seconds.	X	X	X	X					
	Vehicle security system cannot be set by ...	All items	X	X	X					
		Door outside key	X				X			
		Back door key	X					X		
	Multi-remote control	X							X	
2	*1 Vehicle security system does not alarm when ...	Any door is opened.	X		X					
		Any door is unlocked without using key or multi-remote controller	X							
3	Vehicle security alarm does not activate.	All function	X		X					
		Horn alarm	X					X		
		Headlamp alarm	X						X	
4	Vehicle security system cannot be canceled by ...	Door outside key	X			X				
		Back door key	X				X			
		Multi-remote control	X							X

X : Applicable


\*1: Make sure the system is in the armed phase.

**Before starting trouble diagnoses above, perform preliminary check, EL-354.**

Symptom numbers in the symptom chart correspond with those of preliminary check.

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)



## POWER SUPPLY AND GROUND CIRCUIT CHECK

NAEL0406S03


### Power Supply Circuit Check

NAEL0406S0301

Terminals		Ignition switch position			
Connector	Terminal (Wire color)	(-)	(+)		
			OFF	ACC	ON
M123	49 (G/R)	Ground	Battery voltage	Battery voltage	Battery voltage
M122	26 (G/W)	Ground	0V	Battery voltage	Battery voltage
M122	27 (W/B)	Ground	0V	0V	Battery voltage

If NG, check the following.

- 7.5A fuse [No. 24, located in fuse block (J/B)]
- 7.5A fuse [No. 11, located in fuse block (J/B)]
- 10A fuse [No. 10, located in fuse block (J/B)]
- Harness for open or short between smart entrance control unit and fuse.



### Ground Circuit Check

NAEL0406S0302

Terminals		(-)	Continuity
Connector	Terminal (Wire color)		
		M122	43 (B)
M123	64 (B)		

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

## DOOR, HOOD AND GLASS HATCH SWITCH CHECK


=NAEL0406S04

### Door Switch Check

NAEL0406S0401

<b>1</b>	<b>PRELIMINARY CHECK</b>	
<p>1. Turn ignition switch OFF and remove key from ignition key cylinder.  <b>“SECURITY” indicator lamp should blink every 2.6 seconds.</b></p> <p>2. Close all doors, hood and glass hatch.</p> <p>3. Lock doors with multi-remote controller from inside the vehicle.  <b>“SECURITY” indicator lamp should turn on for 30 seconds.</b></p> <p>4. Unlock any door with the door lock knob and open the door within 30 seconds after door is locked.  <b>“SECURITY” indicator lamp should turn off.</b></p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	Door switch is OK, and go to hood switch check.
NG	▶	GO TO 2.

<b>2</b>	<b>CHECK DOOR SWITCH INPUT SIGNAL</b>																																	
<p> <b>With CONSULT-II</b>          Check door switches (“DOOR SW-RR”, “DOOR SW-DR” and “DOOR SW-AS”) in “DATA MONITOR” mode with CONSULT-II.</p>																																		
<table border="1" style="margin-bottom: 20px;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITOR</th> <th></th> </tr> </thead> <tbody> <tr> <td>DOOR SW-RR</td> <td>OFF</td> </tr> <tr> <td>DOOR SW-DR</td> <td>OFF</td> </tr> <tr> <td>DOOR SW-AS</td> <td>OFF</td> </tr> </tbody> </table> <table border="1" style="margin-bottom: 20px;"> <thead> <tr> <th></th> <th>Monitor item</th> <th>Condition</th> <th>Condition</th> </tr> </thead> <tbody> <tr> <td rowspan="2">DOOR SW-RR</td> <td rowspan="2">Rear doors switch</td> <td>Open</td> <td>ON</td> </tr> <tr> <td>Closed</td> <td>OFF</td> </tr> <tr> <td rowspan="2">DOOR SW-DR</td> <td rowspan="2">Door switch LH</td> <td>Open</td> <td>ON</td> </tr> <tr> <td>Closed</td> <td>OFF</td> </tr> <tr> <td rowspan="2">DOOR SW-AS</td> <td rowspan="2">Door switch RH</td> <td>Open</td> <td>ON</td> </tr> <tr> <td>Closed</td> <td>OFF</td> </tr> </tbody> </table>			DATA MONITOR		MONITOR		DOOR SW-RR	OFF	DOOR SW-DR	OFF	DOOR SW-AS	OFF		Monitor item	Condition	Condition	DOOR SW-RR	Rear doors switch	Open	ON	Closed	OFF	DOOR SW-DR	Door switch LH	Open	ON	Closed	OFF	DOOR SW-AS	Door switch RH	Open	ON	Closed	OFF
DATA MONITOR																																		
MONITOR																																		
DOOR SW-RR	OFF																																	
DOOR SW-DR	OFF																																	
DOOR SW-AS	OFF																																	
	Monitor item	Condition	Condition																															
DOOR SW-RR	Rear doors switch	Open	ON																															
		Closed	OFF																															
DOOR SW-DR	Door switch LH	Open	ON																															
		Closed	OFF																															
DOOR SW-AS	Door switch RH	Open	ON																															
		Closed	OFF																															
SEL024Y																																		

<p> <b>Without CONSULT-II</b>          Check voltage between smart entrance control unit harness connector M121 terminals 1 (G/OR), 2 (Y) or 3 (R/L) and ground.</p>																														
<p>Smart entrance control unit connector</p>    																														
<table border="1" style="margin-bottom: 20px;"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Terminals</th> <th rowspan="2">Condition</th> <th rowspan="2">Voltage [V]</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td rowspan="2">Front door switch LH</td> <td rowspan="2">1</td> <td rowspan="2">Ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 5</td> </tr> <tr> <td rowspan="2">Front door switch RH</td> <td rowspan="2">2</td> <td rowspan="2">Ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 5</td> </tr> <tr> <td rowspan="2">Rear and back door switches</td> <td rowspan="2">3</td> <td rowspan="2">Ground</td> <td>Open</td> <td>0</td> </tr> <tr> <td>Closed</td> <td>Approx. 5</td> </tr> </tbody> </table>				Terminals		Condition	Voltage [V]	(+)	(-)	Front door switch LH	1	Ground	Open	0	Closed	Approx. 5	Front door switch RH	2	Ground	Open	0	Closed	Approx. 5	Rear and back door switches	3	Ground	Open	0	Closed	Approx. 5
	Terminals			Condition	Voltage [V]																									
	(+)	(-)																												
Front door switch LH	1	Ground	Open	0																										
			Closed	Approx. 5																										
Front door switch RH	2	Ground	Open	0																										
			Closed	Approx. 5																										
Rear and back door switches	3	Ground	Open	0																										
			Closed	Approx. 5																										
SEL021YA																														
<p>Refer to wiring diagram in EL-347.</p> <p style="text-align: center;"><b>OK or NG</b></p>																														
OK	▶	Door switch is OK, and go to hood switch check.																												
NG	▶	GO TO 3.																												

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

## 3 CHECK DOOR SWITCH



1. Disconnect door switch connector.
2. Check the following.
  - Continuity between front door switch harness connector B9 (LH) or B68 (RH) terminals 1 and 2
  - Continuity between front door switch harness connector B9 (LH) or B68 (RH) terminals 3 and ground
  - Continuity between back door switch harness connector D208 terminals 1 and 2
  - Continuity between rear door switch harness connector B18 (LH) or B71 (RH) terminal 1 and ground




Front door switch connector



Back door switch



Rear door switch connector



	Terminals	Condition	Continuity
Front door switches	1 - 2 3 - Ground	Closed	No
		Open	Yes
Back door switch	1 - 2	Closed	No
		Open	Yes
Rear door switches	1 - Ground	Closed	No
		Open	Yes

SEL287Y

OK or NG

OK



**Check the following.**

- Door switch ground circuit (Front or back) or door switch ground condition
- Harness for open or short between smart entrance control unit and door switch

NG



Replace door switch.

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)


## Hood Switch Check

=NAEL0406S0402

<b>1</b>	<b>PRELIMINARY CHECK</b>	
<p>1. Turn ignition switch OFF and remove key from ignition key cylinder.  <b>"SECURITY" indicator lamp should blink every 2.6 seconds.</b></p> <p>2. Close all doors, hood and trunk lid.</p> <p>3. Lock doors with multi-remote controller from inside the vehicle.  <b>"SECURITY" indicator lamp should turn on for 30 seconds.</b></p> <p>4. Unlock hood with hood opener within 30 seconds after door is locked.  <b>"SECURITY" indicator lamp should turn off.</b></p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	Hood switch is OK, and go to trunk room lamp switch check.
NG	▶	GO TO 2.

<b>2</b>	<b>CHECK HOOD SWITCH FITTING CONDITION</b>	
<b>OK or NG</b>		
OK	▶	GO TO 3.
NG	▶	Adjust installation of hood switch or hood.


<b>3</b>	<b>CHECK HOOD SWITCH INPUT SIGNAL</b>							
<p> <b>With CONSULT-II</b>          Check hood switch ("HOOD SWITCH") in "DATA MONITOR" mode with CONSULT-II.</p>								
<table border="1" style="margin: auto;"> <tr><th colspan="2">DATA MONITOR</th></tr> <tr><th>MONITOR</th><th></th></tr> <tr><td>HOOD SWITCH</td><td>OFF</td></tr> </table>			DATA MONITOR		MONITOR		HOOD SWITCH	OFF
DATA MONITOR								
MONITOR								
HOOD SWITCH	OFF							
<p>When hood is open:  <b>HOOD SWITCH ON</b></p> <p>When hood is closed:  <b>HOOD SWITCH OFF</b></p>								
SEL354W								

<p> <b>Without CONSULT-II</b>          Check voltage between smart entrance control unit harness connector M121 terminal 6 (Y/B) and ground.</p>		
<p>Smart entrance control unit connector</p> 		
<p><b>Voltage [V]:</b>          Engine hood is open.  <b>0</b>          Engine hood is closed.  <b>Approx. 5</b></p>		
SEL035Y		
<b>OK or NG</b>		
OK	▶	Hood switch is OK, and go to glass hatch switch check.
NG	▶	GO TO 4.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)


4	CHECK HOOD SWITCH
	<p>1. Disconnect hood switch connector. 2. Check continuity between hood switch terminals 1 and 2.</p> <div data-bbox="467 268 747 598"><p>DISCONNECT</p><p>Hood switch connector (E3)</p></div> <div data-bbox="971 346 1258 514"><p><b>Continuity:</b> <b>Condition: Pushed</b> <b>No</b> <b>Condition: Released</b> <b>Yes</b></p></div> <p data-bbox="1388 577 1469 604">SEL338X</p> <p data-bbox="755 619 868 651">OK or NG</p>
OK	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"><li>● Hood switch ground circuit</li><li>● Harness for open or short between smart entrance control unit and hood switch</li></ul>
NG	<p>▶ Replace hood switch.</p>


# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

## Glass Hatch Switch Check

=NAEL0406S0403

<b>1</b>	<b>CHECK GLASS HATCH SWITCH INPUT SIGNAL</b>	
<p>Check voltage between smart entrance control unit harness connector M121 terminal 13 (L/W) and ground.</p>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 30%;"> <p>Smart entrance control unit connector</p>  </div> <div style="width: 20%; text-align: center;">    </div> <div style="width: 40%;"> <p><b>Voltage [V]:</b>  <b>Glass hatch is open.</b>                      Approx. 0  <b>Glass hatch is closed.</b>                      Approx. 12</p> </div> </div>		
SEL326Y		
<b>OK or NG</b>		
OK	▶	Glass hatch switch is OK.
NG	▶	GO TO 2.

<b>2</b>	<b>CHECK GLASS HATCH SWITCH</b>	
<p>1. Disconnect glass hatch switch connector.                  2. Check continuity between glass hatch switch terminals 1 and 2.</p>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 30%;"> <p style="text-align: center;">Glass hatch switch connector (D200)</p>  </div> <div style="width: 20%; text-align: center;">  </div> <div style="width: 40%;"> <p><b>Continuity:</b>  <b>Condition: Closed</b>                      No  <b>Condition: Open</b>                      Yes</p> </div> </div>		
SEL340X		
<b>OK or NG</b>		
OK	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● Glass hatch switch ground circuit</li> <li>● Harness for open or short between smart entrance control unit and glass hatch switch</li> </ul>
NG	▶	Replace glass hatch switch.



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

## SECURITY INDICATOR LAMP CHECK


=NAEL0406S05

<b>1</b>	<b>CHECK INDICATOR LAMP OPERATION</b>
<p> <b>With CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Select "ACTIVE TEST" in "THEFT WAR ALM" with CONSULT-II.</li> <li>2. Select "THEFT IND" and touch "ON".</li> </ol>	
	
<p><b>Security indicator lamp should illuminate.</b></p>	
SEL356W	
<p> <b>Without CONSULT-II</b></p> <ol style="list-style-type: none"> <li>1. Disconnect smart entrance control unit harness connector.</li> <li>2. Check voltage between smart entrance control unit harness connector M122 terminal 38 (BR/Y) and ground.</li> </ol>	
	
<p><b>Battery voltage should exist.</b></p>	
SEL037Y	
<p>Refer to wiring diagram in EL-346.</p> <p><b>OK or NG</b></p>	
OK	▶ Security indicator lamp is OK.
NG	▶ GO TO 2.

<b>2</b>	<b>CHECK INDICATOR LAMP</b>
<p><b>OK or NG</b></p>	
OK	▶ GO TO 3.
NG	▶ Replace indicator lamp.

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

<b>3</b>	<b>CHECK POWER SUPPLY CIRCUIT FOR INDICATOR LAMP</b>	
<p>1. Disconnect security lamp connector. 2. Check voltage between indicator lamp terminal 1 and ground.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;"> <p>Security indicator lamp connector (M20)</p>  </div> <div style="text-align: center;">      </div> <div style="text-align: center;"> <p><b>Battery voltage should exist.</b></p> </div> </div> <p style="text-align: right;">SEL342X</p> <p style="text-align: center;"><b>Does battery voltage exist?</b></p>		
Yes	▶	Check harness for open or short between security indicator lamp and smart entrance control unit.
No	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse [No. 24, located in fuse block (J/B)]</li> <li>● Harness for open or short between security indicator lamp and fuse</li> </ul>

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

## FRONT DOOR KEY CYLINDER SWITCH CHECK

=NAEL0406S06

### 1 CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

#### With CONSULT-II

Check front door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

When key inserted in front key cylinder is turned to LOCK:

**KEY CYL LK-SW ON**

When key inserted in front key cylinder is turned to UNLOCK:

**KEY CYL UN-SW ON**



SEL342W

#### Without CONSULT-II

1. Check the signal between smart entrance control unit harness connector M144 terminal 33 (BR) and ground with oscilloscope when key inserted in front key cylinder is turned "LOCK" or "UNLOCK".
2. Make sure signals which are shown in the figure below can be detected during 10 sec. just after key is turned "LOCK" or "UNLOCK".



Smart entrance control unit



**Voltage:**  
12V → 9V (10 sec.)  
measurement by analog circuit tester.

SEL488Y


Refer to wiring diagram in EL-348.

OK or NG

OK	▶	Door key cylinder switch LH is OK.
NG	▶	GO TO 2.

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

2	CHECK DOOR KEY CYLINDER SWITCH														
1. Disconnect door key cylinder switch LH connector. 2. Check continuity between door key cylinder switch LH terminals.	 <p>Door key cylinder switch LH connector </p> 	<p>① : Door unlock switch terminal                      ② : Ground terminal                      ③ : Door lock switch terminal</p> <table border="1" data-bbox="797 411 1357 569"> <thead> <tr> <th>Terminals</th> <th>Key position</th> <th>Continuity</th> </tr> </thead> <tbody> <tr> <td rowspan="2">LH: 3 - 2</td> <td>Neutral/Unlock</td> <td>No</td> </tr> <tr> <td>Lock</td> <td>Yes</td> </tr> <tr> <td rowspan="2">LH: 1 - 2</td> <td>Neutral/Lock</td> <td>No</td> </tr> <tr> <td>Unlock</td> <td>Yes</td> </tr> </tbody> </table>	Terminals	Key position	Continuity	LH: 3 - 2	Neutral/Unlock	No	Lock	Yes	LH: 1 - 2	Neutral/Lock	No	Unlock	Yes
Terminals	Key position	Continuity													
LH: 3 - 2	Neutral/Unlock	No													
	Lock	Yes													
LH: 1 - 2	Neutral/Lock	No													
	Unlock	Yes													
OK or NG	SEL313X														
OK	 <p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>• Door key cylinder switch LH ground circuit</li> <li>• Harness for open or short between smart entrance control unit and door key cylinder switch LH</li> </ul>														
NG	 <p>Replace door key cylinder switch LH.</p>														

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

## BACK DOOR KEY CYLINDER SWITCH CHECK

=NAEL0406S07

### 1 CHECK BACK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK/UNLOCK SIGNAL)

#### With CONSULT-II

Check back door key cylinder switch ("KEY CYL LK-SW"/"KEY CYL UN-SW") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

When key inserted in back key cylinder is turned to LOCK:

**KEY CYL LK-SW ON**


When key inserted in back key cylinder is turned to UNLOCK:

**KEY CYL UN-SW ON**

SEL342WB

#### Without CONSULT-II

Check voltage between smart entrance control unit terminals 10 (LG), 11 (Y) or 12 (G/B) and ground.



	Terminals		Key position	Voltage [V]
	(+)	(-)		
Back door	11	Ground	Between neutral and lock	0
			Other positions	Approx. 5
Back door	10	Ground	Between neutral and unlock	0
			Other positions	Approx. 5
Glass hatch	12	Ground	Unlock	0
			Other positions	Approx. 5

SEL325Y

Refer to wiring diagram in EL-349.



**OK or NG**

OK ► Back door key cylinder switch is OK.

NG ► GO TO 2.

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

2	CHECK BACK DOOR KEY CYLINDER SWITCH																									
1. Disconnect back door key cylinder switch connector. 2. Check continuity between back door key cylinder switch terminals.																										
<div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  <p>Back door key cylinder switch (D201)</p> </div> <div style="text-align: center;">  <p>Back door key cylinder switch (D201)</p> </div> <div style="margin-left: 20px;"> <table border="1" data-bbox="738 304 1445 546"> <thead> <tr> <th rowspan="2">Key position</th> <th colspan="4">Terminals</th> </tr> <tr> <th>1</th> <th>2</th> <th>3</th> <th>4</th> </tr> </thead> <tbody> <tr> <td>Between neutral and lock (Back door)</td> <td style="text-align: center;">○</td> <td></td> <td></td> <td style="text-align: center;">○</td> </tr> <tr> <td>Between neutral and unlock (Back door)</td> <td></td> <td style="text-align: center;">○</td> <td></td> <td style="text-align: center;">○</td> </tr> <tr> <td>Between lock (Back door) and unlock (glass hatch)</td> <td></td> <td></td> <td style="text-align: center;">○</td> <td style="text-align: center;">○</td> </tr> </tbody> </table> </div> </div> <p style="text-align: right; margin-right: 50px;">SEL345X</p> <p style="text-align: center;"><b>OK or NG</b></p>			Key position	Terminals				1	2	3	4	Between neutral and lock (Back door)	○			○	Between neutral and unlock (Back door)		○		○	Between lock (Back door) and unlock (glass hatch)			○	○
Key position	Terminals																									
	1	2	3	4																						
Between neutral and lock (Back door)	○			○																						
Between neutral and unlock (Back door)		○		○																						
Between lock (Back door) and unlock (glass hatch)			○	○																						
OK	► <b>Check the following.</b> <ul style="list-style-type: none"> <li>● Back door key cylinder switch ground circuit</li> <li>● Harness for open or short between smart entrance control unit and back door key cylinder switch</li> </ul>																									
NG	► Replace back door key cylinder switch.																									

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

## DOOR LOCK/UNLOCK SWITCH CHECK

=NAEL0406S08

### 1 CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL

#### With CONSULT-II

Check door lock/unlock switch ("LOCK SW DR/AS"/"UNLK SW DR/AS") in "DATA MONITOR" mode with CONSULT-II.

DATA MONITOR	
MONITOR	
LOCK SW DR/AS	OFF
UNLK SW DR/AS	OFF

When lock/unlock switch is turned to LOCK:

**LOCK SW DR/AS ON**


When lock/unlock switch is turned to UNLOCK:

**UNLK SW DR/AS ON**

SEL341W

#### Without CONSULT-II

1. Remove key from ignition switch.
2. Check the signal between smart entrance control unit harness connector M144 terminal 33 (BR) and ground with oscilloscope when door lock/unlock switch is turned "LOCK" or "UNLOCK".
3. Make sure signals which are shown in the figure below can be detected during 10 sec. just after door lock/unlock switch is turned "LOCK" or "UNLOCK".



**Voltage:**  
12V → 9V (10 sec.) measurement  
by analog circuit tester.

SEL487Y

Refer to wiring diagram in EL-348.

**OK or NG**

OK ► Door lock/unlock switch is OK.

NG ► **Check the following.**

- Ground circuit for each front power window switch
- Harness for open or short between each front power window switch and smart entrance control unit connector

If above systems are normal, replace the front power window switch.

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

## VEHICLE SECURITY HORN ALARM CHECK


=NAEL0406S09

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

### 1 CHECK VEHICLE SECURITY HORN

#### With CONSULT-II

1. Select "ACTIVE TEST" in "THEFT WAR ALM" with CONSULT-II.
2. Select "HORN" and touch "ON".




Vehicle security horn alarm should operate.

SEL041Y

#### Without CONSULT-II

1. Disconnect smart entrance control unit harness connector.
2. Apply ground to smart entrance control unit harness connector M121 terminal 42 (LG/B).



Vehicle security horn and headlamp alarm should operate.

SEL043Y

Refer to wiring diagram in EL-349.

#### NOTE:

If CONSULT-II is not available, skip this procedure and go to the next step.

OK or NG

OK	▶	Horn alarm is OK.
NG	▶	GO TO 2.

### 2 CHECK HORN RELAY


Check horn relay.


OK or NG

OK	▶	GO TO 3.
NG	▶	Replace horn relay.

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

3	CHECK POWER SUPPLY FOR HORN RELAY
<p>1. Disconnect horn relay connector. 2. Check voltage between terminal 2 and ground.</p>  <p style="text-align: right;"><b>Battery voltage should exist.</b></p> <p style="text-align: right;">SEL347X</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ GO TO 4.
NG	<p>▶ <b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse (No. 52, located in the fuse and fusible link box)</li> <li>● Harness for open or short between horn relay and fuse</li> </ul>

4	CHECK HORN RELAY CIRCUIT
<p>1. Disconnect horn relay connector. 2. Check voltage between terminals 3 and 5. 3. Check voltage between terminals 6 and 7.</p>  <p style="text-align: right;"><b>Battery voltage should exist.</b></p> <p style="text-align: right;">SEL348X</p> <p style="text-align: center;"><b>OK or NG</b></p>	
OK	▶ Check harness for open or short between horn relay and smart entrance control unit.
NG	▶ Check harness for open or short.

# VEHICLE SECURITY (THEFT WARNING) SYSTEM

Trouble Diagnoses (Cont'd)

## VEHICLE SECURITY HEADLAMP ALARM CHECK

=NAEL0406S10

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

### 1 CHECK VEHICLE SECURITY HEADLAMP ALARM OPERATION

#### With CONSULT-II

1. Select "ACTIVE TEST" in "THEFT WAR ALM" with CONSULT-II.
2. Select "HEADLAMP" and touch "ON".




Vehicle security headlamp alarm should operate.

SEL042Y

#### Without CONSULT-II

1. Disconnect smart entrance control unit connector.
2. Apply ground to smart entrance control unit terminal 4.



Vehicle security headlamp alarm should operate.

SEL198Y

Refer to wiring diagram in EL-350.

#### NOTE:

If CONSULT-II is not available, skip this procedure and go to the next step.

OK or NG

OK	▶	Headlamp is OK.
NG	▶	GO TO 2.

### 2 CHECK HEADLAMP OPERATION

Does headlamp come on when turning lighting switch "ON"?

Yes	▶	Check harness for open or short between headlamp relay and smart entrance control unit.
No	▶	Check headlamp system. Refer to "HEADLAMP".

# SMART ENTRANCE CONTROL UNIT

Description

## Description

NAEL0407

NAEL0407S01

### OUTLINE

The smart entrance control unit totally controls the following body electrical system operations.

- Headlamp auto light control system
- Warning chime
- Rear defogger and door mirror defogger timer
- Power door lock
- Remote keyless entry system
- Vehicle security system
- Interior lamp

In addition, the following timer operations are controlled by the smart entrance control unit.

- Battery saver control
- Retained power control

### BATTERY SAVER CONTROL

NAEL0407S02

#### Headlamps/Parking Lamps/License Lamps/Tail Lamps/Fog Lamps/Illumination Lamps

NAEL0407S0201

While the headlamps (including parking, license, tail, fog and illumination lamps) are turned ON by "1ST" or "2ND" of lighting switch, the exterior lamp battery saver control is activated when the ignition switch signal changes from ON (or ACC) to OFF, and either one of LH or RH front door switch ON signal is received. The headlamps (including parking, license, tail, fog and illumination lamps) are turned off after 5 minutes.

While the headlamps are turned ON by "AUTO" operation, the exterior lamp battery saver control is activated when the ignition switch is turned from ON (or ACC) to OFF, and either LH or RH front door switch ON signal is input.

The smart entrance control unit controls timer activation as follows:

- When the door switch signal changes from ON to OFF while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the headlamps (including parking, license, tail, fog and illumination lamps) will be turned off.
- When the door switch signal changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the headlamps will be turned off.
- When the one of four door switch signals changes from OFF to ON while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 5 minutes, then the headlamps (including parking, license, tail, fog and illumination lamps) will be turned off.
- When all the door switch ON signals are input while the exterior lamp battery saver is activated, the operation is discontinued, restarts and lasts for 45 seconds, then the headlamps (including parking, license, tail, fog and illumination lamps) will be turned off.

The "45" second timer's duration can be changed with the function setting mode of CONSULT-II.

#### Interior Lamp/Luggage Room Lamp/Spot Lamp/Vanity Mirror Illumination

NAEL0407S0202

The lamps turn off automatically when the interior lamp, spot lamp or/and vanity mirror illumination are illuminated with the ignition key in the OFF position, if the lamp remains lit by the door switch open signal or if the lamp switch is in the ON position for more than 30 minutes.

After lamps are turned off by the battery saver system, the lamps illuminate again when:

- Door is locked or unlocked with keyfob or door lock/unlock switch or door key cylinder.
- Ignition switch ON.
- Door is opened or closed,
- Key is inserted or removed into ignition key cylinder.

#### Rear Window Defogger/Door Mirror Defogger

NAEL0407S0203

Rear window defogger and door mirror defogger are turned off in approximately 15 minutes after the rear window defogger switch is turned on.

### RETAINED POWER CONTROL

NAEL0407S03

When the ignition switch is turned to OFF (or ACC) position from ON or START position, the following systems can be operated for 45 seconds by the RAP signal from the smart entrance control unit terminal 46.

- Electric sunroof
- Power window

The retained power operation is canceled when the driver or passenger side door is opened.

# SMART ENTRANCE CONTROL UNIT

*Description (Cont'd)*

## INPUT/OUTPUT

NAEL0407S04

System	Input	Output
Power door lock	Door lock and unlock switch LH and RH Key switch (Insert) Door switches Door key cylinder switches	Door lock actuator
Multi-remote control	Key switch (Insert) Ignition switch (ACC) Door switches Remote controller signal Door lock/unlock switch LH	Horn relay Headlamp relay (LH and RH) Hazard warning lamp Interior lamp Door lock actuator
Remote keyless entry	Key switch (Insert) Ignition switch (ACC) Door switches Keyfob signal Door lock/unlock switch LH	Horn relay Vehicle security horn relay-1 Vehicle security horn relay-2 Hazard warning lamp Interior lamp Ignition key hole illumination Door lock actuator Opener actuator
Warning chime	Key switch (Insert) Ignition switch (ON) Lighting switch (1st) Seat belt switch (driver's seat) Front door switch LH	Warning chime (located in smart entrance control unit)
Rear window defogger and door mirror defogger	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
Vehicle security	Ignition switch (ACC, ON) Door switches Hood switch Trunk room lamp switch Door lock/unlock switches Door key cylinder switches (lock/unlock) Key cylinder switch (unlock)	Vehicle security horn relay-2 Headlamp relay Security indicator
Interior lamp	Door switches Keyfob signal (lock/unlock) Door lock/unlock switches (lock/unlock) Door key cylinder switch (lock/unlock) Ignition switch (ON) Key switch (Insert)	Interior lamp Key hole illumination Step lamp Door indicator
Battery saver control for headlamps/parking lamps/licence lamps/tail lamps/fog lamps/illumination lamps	Ignition switch (ON) Front door switches Lighting switches	Headlamps Parking lamps Licence lamps Tail lamps Fog lamps Illumination lamps
Battery saver control for interior lamp/spot lamp/vanity mirror illumination	Ignition switch (ON) Front door switches Lamp switches	Interior lamp Step lamp Spot lamp Vanity mirror illumination
Battery saver control for rear window defogger and door mirror defogger	Ignition switch (ON) Rear window defogger switch	Rear window defogger relay
Retained power control for electric sunroof	Ignition switch (ON) Front door switches	Sunroof motor
Retained power control for power window	Ignition switch (ON) Front door switches	Power window relay

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX

# SMART ENTRANCE CONTROL UNIT

CONSULT-II

## CONSULT-II DIAGNOSTIC ITEMS APPLICATION

NAEL0408

NAEL0408S01

Item (CONSULT-II screen terms)	Diagnosed system	DATA MONITOR	ACTIVE TEST	WORK SUPPORT
DOOR LOCK	Power door lock	X	X	X
REAR DEFOGGER	Rear window defogger	X	X	
KEY WARN ALM	Warning chime	X	X	
LIGHT WARN ALM	Warning chime	X	X	
SEAT BELT ALM	Warning chime	X	X	
INT LAMP	Interior lamps	X	X	X
BATTERY SAVER	Battery saver control for interior lamp	X	X	X
THEFT WAR ALM	Vehicle security system	X	X	X
RETAINED PWR	Retained power control	X	X	X
MULTI REMOTE ENT	Remote keyless entry system	X	X	X
HEAD LAMP	Headlamp	X	X	X


X: Applicable

For diagnostic item in each control system, refer to the relevant pages for each system.

## DIAGNOSTIC ITEM DESCRIPTION

NAEL0408S02


MODE	Description
DATA MONITOR	Input/output data in the smart entrance control unit can be read.
ACTIVE TEST	Diagnostic Test Mode in which CONSULT-II drives some systems apart from the smart entrance control unit.
WORK SUPPORT for DOOR LOCK	<ul style="list-style-type: none"> <li>● Select unlock mode ON-OFF setting can be changed.</li> <li>● Key reminder door mode ON-OFF setting can be changed.</li> </ul>
WORK SUPPORT for INT LAMP	Interior lamp timer mode ON-OFF setting can be changed.
WORK SUPPORT for BATTERY SAVER	Interior lamp battery saver period can be changed.
WORK SUPPORT for THEFT WAR ALM	<ul style="list-style-type: none"> <li>● The recorded trigger signal when vehicle security system was activated can be checked.</li> <li>● Security alarm ON-OFF setting can be changed.</li> </ul>
WORK SUPPORT for RETAINED PWR SET	RAP signal's power supply period can be changed.
WORK SUPPORT for MULTI REMOTE ENT	<ul style="list-style-type: none"> <li>● ID code of keyfob can be registered and erased.</li> <li>● Keyless answer back mode can be changed.</li> <li>● Pressing time of panic alarm, trunk lid opener and door unlock (for power window down operation) buttons on keyfob can be changed.</li> <li>● Auto lock operation starting time can be changed.</li> </ul>
WORK SUPPORT for HEADLAMP	<ul style="list-style-type: none"> <li>● Auto light sensitivity can be changed.</li> <li>● Exterior lamp battery saver control ON-OFF setting can be changed.</li> <li>● Auto light delay off time can be changed.</li> </ul>




## CONSULT-II INSPECTION PROCEDURE

NAEL0408S03


1. Turn the ignition switch "OFF".
2. Connect "CONSULT-II" to the data link connector.



3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "SMART ENTRANCE".



6. Perform each diagnostic item according to "DIAGNOSTIC ITEMS APPLICATION". Refer to EL-374.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**


IDX

# SMART ENTRANCE CONTROL UNIT

Schematic

NAEL0409

## Schematic




SMART ENTRANCE CONTROL UNIT

MEL442P

# SMART ENTRANCE CONTROL UNIT

Schematic (Cont'd)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC

EL

MEL443P

IDX

# SMART ENTRANCE CONTROL UNIT

Smart Entrance Control Unit Inspection Table

## Smart Entrance Control Unit Inspection Table

NAEL0410

Terminal No.	Wire color	Connections	Operated condition		Voltage (Approximate values)	
1	G/OR	Driver door switch	OFF (Closed) → ON (Open)		12V → 0V	
2	Y	Passenger door switch	OFF (Closed) → ON (Open)		5V → 0V	
3	R/L	Rear door switch	OFF (Closed) → ON (Open)		5V → 0V	
4	LG/R	Door lock & unlock switches	Neutral → Unlocks		5V → 0V	
5	BR	Door lock & unlock switches	Neutral → Locks		5V → 0V	
6	Y/B	Hood switch	ON (Open) → OFF (Closed)		0V → 12V	
7	W/G	Auto light sensor (Signal)	Ignition switch ON position	Light is applied to auto light sensor.	1 to 5V	
				Light is not applied to auto light sensor.	Less than 1V	
8	L/R	Auto light sensor (GND)	—		—	
9	GY	Auto light sensor (Power)	Ignition switch (OFF → ON)		0V → 5V	
10	LG	Door key cylinder unlock switch	OFF (Neutral) → ON (Locked)		5V → 0V	
11	Y	Door key cylinder lock switch	OFF (Neutral) → ON (Locked)		5V → 0V	
12	W/PU	Back door key cylinder switch	OFF (Neutral) → ON (Unlock)		5V → 0V	
13	L/W	Glass hatch switch	ON (Open) → OFF (Closed)		0V → 12V	
14	OR	Rear window defogger switch	OFF → ON (Only when pushed)		5V → 0V	
19	R/G	Tail lamp relay (Output)	Ignition switch (with lighting switch 1ST or 2ND)	ON or START → OFF position	More than 5 minutes after ignition switch is turned to OFF position	12V
					Within 5 minutes after ignition switch is turned to OFF position	0V
				ON or START position		0V
			Headlamps illuminate by auto light control. (Operate → Not operate)		Less than 1V → 12V	
20	G	Tail lamp switch	Light switch (OFF or AUTO → 1ST or 2ND position)		12V → 0V	
21	PU/R	Headlamp LH relay	Ignition switch (with lighting switch 2ND)	ON or START → OFF position	More than 5 minutes after ignition switch is turned to OFF position	12V
					Within 5 minutes after ignition switch is turned to OFF position	0V
				ON or START position		0V
			Headlamps illuminate by auto light control.		0V	

# SMART ENTRANCE CONTROL UNIT

Smart Entrance Control Unit Inspection Table (Cont'd)

Terminal No.	Wire color	Connections	Operated condition		Voltage (Approximate values)	
22	SB	Headlamp switch	Lighting switch	Except PASS or 2ND position	12V	
				PASS or 2ND position	0V	
			Headlamps illuminate by auto light control. (Operate → Not operate)	10V → 12V		
23	L/Y	Headlamp switch	Ignition switch "ON" position	Lighting switch (Except AUTO → AUTO position)	12V → 0V	
25	W/R	Ignition key switch (Insert)	Key inserted → Key removed from IGN key cylinder		12V → 0V	
26	G/W	Ignition switch (ACC)	"ACC" position		12V	
27	W/B	Ignition switch (ON)	Ignition key is in "ON" position		12V	
28	B/Y	Seat belt buckle switch	Unfastened → Fastened (Ignition key is in "ON" position)		0V → 12V	
31	R/B	Interior lamp	When doors are locked using keyfob (Lamp switch in "DOOR" position)		0V → 12V	
37	G/B	Rear window defogger relay	OFF → ON (Ignition key is in "ON" position)		12V → 0V	
38	BR/Y	Security indicator	Goes off → Illuminates		12V → 0V	
42	LG/B	Horn relay	When panic alarm is operated using keyfob (ON → OFF)		12V → 0V	
43	B	Ground	—		—	
46	R/Y	Power window relay	Retained power operation is operated (ON → OFF)		12V → 0V	
47	GY/L	LH turn signal lamp	When door lock or unlock is operated using keyfob (ON → OFF)		12V → 0V	
48	GY/R	RH turn signal lamp	When door lock or unlock is operated using keyfob (ON → OFF)		12V → 0V	
49	G/R	Power source (Fuse)	—		12V	
50	R/W	Battery saver (Interior lamp)	Battery saver operates → Does not operate (ON → OFF)		12V → 0V	
51	W/R	Power source (PTC)	—		12V	
54	L	Door lock actuators	Door lock & unlock switch (Free → Lock)		0V → 12V	
55	W/PU	Driver door lock actuator	Door lock & unlock switch (Free → Unlock)		0V → 12V	
56	Y/B	Passenger, rear and back doors lock actuator	Door lock & unlock switch (Free → Unlock)		0V → 12V	
57	R	Tail lamp relay	Ignition switch (with lighting switch 1ST or 2ND)	ON or START → OFF position	More than 5 minutes after ignition switch is turned to OFF position	12V
					Within 5 minutes after ignition switch is turned to OFF position	0V
				ON or START position	0V	
			Headlamps illuminate by auto light control. (Operate → Not operate)	Less than 1V → 12V		

# SMART ENTRANCE CONTROL UNIT

*Smart Entrance Control Unit Inspection Table (Cont'd)*

Terminal No.	Wire color	Connections	Operated condition		Voltage (Approximate values)	
58	G/W	Tail lamp switch	Lighting switch OFF or AUTO → 1ST or 2ND		12V → 0V	
59	PU/W	Headlamp RH relay	Ignition switch (with lighting switch OFF or 1ST)	ON or START → OFF position	More than 5 minutes after ignition switch is turned to OFF position	12V
					Within 5 minutes after ignition switch is turned to OFF position	0V
				ON or START position		0V
			Headlamps illuminate by auto light control. (Operate → Not operate)		Less than 1V → 12V	
60	L	Headlamp switch	Lighting switch	Except PASS or 2ND position	12V	
				PASS or 2ND position	0V	
			Headlamps illuminate by auto light control. (Operate → Not operate)		10V → 12V	
64	B	Ground	—		—	



# HOMELINK UNIVERSAL TRANSCEIVER

Wiring Diagram — TRNSCV —

## Wiring Diagram — TRNSCV —

NAEL0411

### EL-TRNSCV-01



REFER TO THE FOLLOWING.

- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10) -FUSE BLOCK-JUNCTION BOX (J/B)

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

MEL444P

# HOMELINK UNIVERSAL TRANSCEIVER

Trouble Diagnoses


## Trouble Diagnoses DIAGNOSTIC PROCEDURE

NAEL0412

NAEL0412S01


**SYMPTOM: Transmitter does not activate receiver.**

Before conducting the procedure given below, make sure that system receiver (garage door opener, etc.) operates with original, hand-held transmitter. If NG, receiver or hand-held transmitter is at fault, not vehicle related.

<b>1</b>	<b>PRELIMINARY CHECK</b>
<p>1. Turn ignition switch "OFF". 2. Does red light (LED) of transmitter illuminate when any button is pressed?</p>	
	
<b>Yes or No</b>	
Yes	▶ GO TO 2.
No	▶ GO TO 3.

SEL442U


<b>2</b>	<b>CHECK TRANSMITTER FUNCTION</b>
<p>Check transmitter with Tool. For details, refer to Technical Service Bulletin.</p>	
<b>OK or NG</b>	
OK	▶ Receiver or handheld transmitter fault, not vehicle related.
NG	▶ Replace transmitter with sun visor assembly.

<b>3</b>	<b>CHECK POWER SUPPLY</b>
<p>1. Disconnect transmitter connector. 2. Turn ignition switch "OFF". 3. Check voltage between terminal 1 and body ground.</p>	
	
<b>Battery voltage should exist.</b>	
<b>OK or NG</b>	
OK	▶ GO TO 4.
NG	▶ GO TO 5.


SEL358X

# HOMELINK UNIVERSAL TRANSCEIVER

Trouble Diagnoses (Cont'd)

<b>4</b>	<b>CHECK GROUND CIRCUIT</b>	
<p>Check continuity between terminal 2 and ground.</p> <div style="display: flex; align-items: center; justify-content: center;">  <div style="margin-left: 20px;"> <p><b>Continuity should exist.</b></p> </div> </div> <p style="text-align: right;">SEL359X</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	Replace transmitter with sun visor assembly.
NG	▶	Repair harness.

GI  
MA  
EM  
LC  
EC  
FE  
CL

<b>5</b>	<b>CHECK MAIN POWER SUPPLY FOR SMART ENTRANCE CONTROL UNIT</b>	
<p>1. Disconnect smart entrance control unit. 2. Check voltage between smart entrance control unit harness connector M123 terminal 49 (G/R) and ground.</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="margin-right: 20px;"> <p>Smart entrance control unit connector</p>  </div> <div style="margin-right: 20px;">  </div> <div style="margin-left: 20px;"> <p><b>Battery voltage should exist.</b></p> </div> </div> <p style="text-align: right;">SEL284Y</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 6.
NG	▶	<p><b>Check the following.</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse No. 24, located in fuse block (J/B)</li> </ul>

MT  
AT  
TF  
PD  
AX  
SU  
BR


ST  
RS  
BT  
HA  
SC

**EL**

IDX

# HOMELINK UNIVERSAL TRANSCEIVER

Trouble Diagnoses (Cont'd)

6	CHECK GROUND CIRCUIT FOR SMART ENTRANCE CONTROL UNIT
<p data-bbox="154 199 1429 252">Check continuity between smart entrance control unit harness connector M122 terminal 43 (B) or M123 terminal 64 (B) and ground.</p> <div data-bbox="224 283 1266 567"><p data-bbox="341 283 568 325">Smart entrance control unit connector</p><p data-bbox="974 409 1266 451"><b>Continuity should exist.</b></p><p data-bbox="747 619 876 651"><b>OK or NG</b></p></div>	
OK	▶ Power supply and ground circuits are OK.
NG	▶ Check ground harness.


SEL285Y

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Component Parts and Harness Connector Location

## Component Parts and Harness Connector Location

NAEL0413



SEL357X

**NOTE:**

If customer reports a “No Start” condition, request ALL KEYS to be brought to the Dealer in case of an NVIS (NATS) malfunction.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

System Description

## System Description

=NAEL0414

NATS (Nissan Anti-Theft System) has the following immobilizer functions:


- Since only NVIS (NATS) ignition keys, whose ID nos. have been registered into the ECM and IMMU of NVIS (NATS), allow the engine to run, operation of a stolen vehicle without an NVIS (NATS) registered key is prevented by NVIS (NATS).  
That is to say, NVIS (NATS) will immobilise the engine if someone tries to start it without the registered key of NVIS (NATS).
- All of the originally supplied ignition key IDs (except for card plate key) have been NVIS (NATS) registered.  
If requested by the vehicle owner, a maximum of five key IDs can be registered into the NVIS (NATS) components.
- The security indicator blinks when the ignition switch is in “OFF” or “ACC” position. Therefore, NVIS (NATS) warns outsiders that the vehicle is equipped with the anti-theft system.
- When NVIS (NATS) detects trouble, the security indicator lamp lights up while ignition key is in the “ON” position.
- NVIS (NATS) trouble diagnoses, system initialization and additional registration of other NVIS (NATS) ignition key IDs must be carried out using CONSULT-II hardware and CONSULT-II NVIS (NATS) software. When NVIS (NATS) initialization has been completed, the ID of the inserted ignition key is automatically NVIS (NATS) registered. Then, if necessary, additional registration of other NVIS (NATS) ignition key IDs can be carried out.  
Regarding the procedures of NVIS (NATS) initialization and NVIS (NATS) ignition key ID registration, refer to CONSULT-II operation manual, IVIS/NVIS.
- **When servicing a malfunction of the NVIS (NATS) (indicated by lighting up of Security Indicator Lamp) or registering another NVIS (NATS) ignition key ID no., it is necessary to re-register original key identification. Therefore, be sure to receive ALL KEYS from vehicle owner.**

## System Composition

NAEL0415

The immobiliser function of the NVIS (NATS) consists of the following:

- NVIS (NATS) ignition key
- NVIS (NATS) immobilizer control unit (IMMU) located in the ignition key cylinder
- Engine control module (ECM)
- Security indicator




# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Wiring Diagram — NATS —


## Wiring Diagram — NATS —

NAEL0416

EL-NATS-01




Refer to EL-POWER.



REFER TO THE FOLLOWING.


- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10), (E3) -FUSE BLOCK-JUNCTION BOX (J/B)



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

## CONSULT-II



## CONSULT-II

### CONSULT-II INSPECTION PROCEDURE


NAEL0417

NAEL0417S01


1. Turn ignition switch OFF.
2. Insert NVIS (NATS) program card into CONSULT-II.

### Program card NATS (AEN00A)


3. Connect CONSULT-II to data link connector.



4. Turn ignition switch ON.
5. Touch "START".



6. Select "NATS V.5.0".



7. Perform each diagnostic test mode according to each service procedure.

**For further information, see the CONSULT-II Operation Manual, IVIS/NVIS.**

## CONSULT-II DIAGNOSTIC TEST MODE FUNCTION

NAEL0417S02

CONSULT-II DIAGNOSTIC TEST MODE	Description
C/U INITIALIZATION	When replacing any of the following three components, C/U initialization and re-registration of all NVIS (NATS) ignition keys are necessary. [NVIS (NATS) ignition key/IMMU/ECM]
SELF-DIAG RESULTS	Detected items (screen terms) are as shown in the chart EL-389.

**NOTE:**

- When any initialization is performed, all ID previously registered will be erased and all NVIS (NATS) ignition keys must be registered again.
- The engine cannot be started with an unregistered key. In this case, the system will show “DIFFERENCE OF KEY” or “LOCK MODE” as a self-diagnostic result on the CONSULT-II screen.
- In rare case, “CHAIN OF ECM-IMMU” might be stored as a self-diagnostic result during key registration procedure, even if the system is not malfunctioning.

## HOW TO READ SELF-DIAGNOSTIC RESULTS

NAEL0417S03

**Result display screen (When no malfunction is detected)**

SELF DIAG RESULTS	
DTC RESULTS	TIME
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	
	PRINT

**Result display screen (When malfunction is detected)**

SELF DIAG RESULTS	
DTC RESULTS	TIME
CHAIN OF ECM-IMMU	0
DIFFERENCE OF KEY	1
Scroll down	
ERASE	PRINT

Detected items →

If “Scroll Down” is indicated, there are four or more malfunctions.

When touched, the results stored in the engine control module (ECM) are erased.

← Time data

This indicates how many times the vehicle was driven after the last detection of a malfunction. If the malfunction is detected currently, the time data will be “0”.

← When touched, the results are printed out.

SEL364X

## NVIS (NATS) SELF-DIAGNOSTIC RESULTS ITEM CHART

NAEL0417S04

Detected items (NATS program card screen terms)	P No. Code (Self-diagnostic result of “ENGINE”)	Malfunction is detected when .....	Reference page
ECM INT CIRC-IMMU	NATS MAL-FUNCTION P1613	The malfunction of ECM internal circuit of IMMU communication line is detected.	EL-393
CHAIN OF ECM-IMMU	NATS MAL-FUNCTION P1612	Communication impossible between ECM and IMMU (In rare case, “CHAIN OF ECM-IMMU” might be stored during key registration procedure, even if the system is not malfunctioning.)	EL-394
DIFFERENCE OF KEY	NATS MAL-FUNCTION P1615	IMMU can receive the key ID signal but the result of ID verification between key ID and IMMU is NG.	EL-398
CHAIN OF IMMU-KEY	NATS MAL-FUNCTION P1614	IMMU cannot receive the key ID signal.	EL-399
ID DISCORD, IMM-ECM	NATS MAL-FUNCTION P1611	The result of ID verification between IMMU and ECM is NG. System initialization is required.	EL-400

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

CONSULT-II (Cont'd)


Detected items (NATS program card screen terms)	P No. Code (Self-diagnostic result of "ENGINE")	Malfunction is detected when .....	Reference page
LOCK MODE	NATS MALFUNCTION P1610	When the starting operation is carried out five or more times consecutively under the following conditions, NVIS (NATS) will shift the mode to one which prevents the engine from being started. <ul style="list-style-type: none"><li>● Unregistered ignition key is used.</li><li>● IMMU or ECM's malfunctioning.</li></ul>	EL-403
DON'T ERASE BEFORE CHECKING ENG DIAG	—	All engine trouble codes except NVIS (NATS) trouble code has been detected in ECM.	EL-391

## Trouble Diagnoses WORK FLOW

NAEL0418

NAEL0418S01

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



SEL004XA

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

## SYMPTOM MATRIX CHART 1 (Self-diagnosis related item)

NAEL0418S02

SYMPTOM	Displayed "SELF-DIAG RESULTS" on CONSULT-II screen.	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)	REFERENCE PART NO. OF ILLUSTRATION ON NEXT PAGE
<ul style="list-style-type: none"> <li>● Security indicator lighting up*</li> <li>● Engine cannot be started.</li> </ul>	ECM INT CIRC-IMMU	PROCEDURE 1 (EL-393)	ECM	B
	CHAIN OF ECM-IMMU	PROCEDURE 2 (EL-394)	In rare case, "CHAIN OF ECM-IMMU" might be stored during key registration procedure, even if the system is not malfunctioning.	—
			Open circuit in battery voltage line of IMMU circuit	C1
			Open circuit in ignition line of IMMU circuit	C2
			Open circuit in ground line of IMMU circuit	C3
			Open circuit in communication line between IMMU and ECM	C4
			Short circuit between IMMU and ECM communication line and battery voltage line	C4
			Short circuit between IMMU and ECM communication line and ground line	C4
			ECM	B
			IMMU	A
	DIFFERENCE OF KEY	PROCEDURE 3 (EL-398)	Unregistered key	D
			IMMU	A
	CHAIN OF IMMU-KEY	PROCEDURE 4 (EL-399)	Malfunction of key ID chip	E
			IMMU	A
	ID DISCORD, IMM-ECM	PROCEDURE 5 (EL-400)	System initialization has not yet been completed.	F
ECM			F	
LOCK MODE	PROCEDURE 7 (EL-403)	LOCK MODE	D	
<ul style="list-style-type: none"> <li>● MIL staying ON</li> <li>● Security indicator lighting up*</li> </ul>	DON'T ERASE BEFORE CHECKING ENG DIAG	WORK FLOW (EL-391)	Engine trouble data and NVIS (NATS) trouble data have been detected in ECM	—

\*: When NVIS (NATS) detects trouble, the security indicator lights up while ignition key is in the "ON" position.

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)


## SYMPTOM MATRIX CHART 2 (Non self-diagnosis related item)

NAEL0418S03

SYMPTOM	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)
Security ind. does not light up.	PROCEDURE 6 (EL-401)	Security ind.
		Open circuit between Fuse and IMMU
		Continuation of initialization mode
		IMMU

## DIAGNOSTIC SYSTEM DIAGRAM

NAEL0418S04



SEL087WF

SELF DIAG RESULTS	
DTC RESULTS	TIME
ECM INT CIRC-IMMU	0

SEL365X

## DIAGNOSTIC PROCEDURE 1

NAEL0418S05

**Self-diagnostic results:**  
**“ECM INT CIRC-IMMU” displayed on CONSULT-II screen**

1. Confirm SELF-DIAGNOSTIC RESULTS “ECM INT CIRC-IMMU” displayed on CONSULT-II screen. Ref. part No. B.
2. Replace ECM.
3. Perform initialization with CONSULT-II.  
 For initialization, refer to “CONSULT-II operation manual IVIS/NVIS”.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)


## DIAGNOSTIC PROCEDURE 2

=NAEL0418S06

Self-diagnostic results:


“CHAIN OF ECM-IMMU” displayed on CONSULT-II screen


<b>1</b>	<b>CONFIRM SELF-DIAGNOSTIC RESULTS</b>											
<p>Confirm SELF-DIAGNOSTIC RESULTS “CHAIN OF ECM-IMMU” displayed on CONSULT-II screen.</p> <p><b>NOTE:</b> In rare case, “CHAIN OF ECM-IMMU” might be stored during key registration procedure, even if the system is not malfunctioning.</p>												
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>CHAIN OF ECM-IMMU</td> <td style="text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	CHAIN OF ECM-IMMU	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
CHAIN OF ECM-IMMU	0											
SEL366X												
<b>Is CONSULT-II screen displayed as above?</b>												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

<b>2</b>	<b>CHECK POWER SUPPLY CIRCUIT FOR IMMU</b>	
<p>1. Disconnect IMMU connector.</p> <p>2. Check voltage between terminal 8 of IMMU and ground with CONSULT-II or tester.</p>		
		
SEL302WD		
<b>OK or NG</b>		
OK	▶	GO TO 3.
NG	▶	<p><b>Check the following</b></p> <ul style="list-style-type: none"> <li>● 7.5A fuse (No. 62, located in the fuse and fusible link box)</li> <li>● Harness for open or short between fuse and IMMU connector</li> </ul> <p><b>Ref. Part No. C1</b></p>

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

<b>3</b>	<b>CHECK IGN SW. ON SIGNAL</b>		GI
<ol style="list-style-type: none"> <li>Turn ignition switch ON.</li> <li>Check voltage between terminal 7 of IMMU and ground with CONSULT-II or tester.</li> </ol>		MA	
		EM	
SEL303WF		OK or NG	LC
OK	▶	GO TO 4.	EC
NG	▶	<b>Check the following</b> <ul style="list-style-type: none"> <li>10A fuse [No. 16, located in the fuse block (J/B)]</li> <li>Harness for open or short between fuse and IMMU connector</li> </ul> <b>Ref. part No. C2</b>	FE

<b>4</b>	<b>CHECK GROUND CIRCUIT FOR IMMU</b>		CL
<ol style="list-style-type: none"> <li>Turn ignition OFF.</li> <li>Check harness continuity between IMMU terminal 4 and ground.</li> </ol>		MT	
		AT	
SEL304WD		OK or NG	TF
OK	▶	GO TO 5.	PD
NG	▶	Repair harness. <b>Ref. part No. C3</b>	AX

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

<b>5</b>	<b>CHECK COMMUNICATION LINE OPEN CIRCUIT</b>	
<p>1. Disconnect ECM connector.                  2. Check harness continuity between ECM terminal 116 and IMMU terminal 1.</p>		
SEL305WD		
<b>OK or NG</b>		
OK	▶	GO TO 6.
NG	▶	Repair harness or connector. <b>Ref. part No. C4</b>

<b>6</b>	<b>CHECK COMMUNICATION LINE BATTERY SHORT CIRCUIT</b>	
<p>1. Turn ignition ON.                  2. Check voltage between ECM terminal 116 or IMMU terminal 1 and ground.</p>		
SEL306WD		
<b>OK or NG</b>		
OK	▶	GO TO 7.
NG	▶	Communication line is short-circuited with battery voltage line or ignition switch ON line. Repair harness or connectors. <b>Ref. part No. C4</b>

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

<b>7</b>	<b>CHECK COMMUNICATION LINE GROUND SHORT CIRCUIT</b>	
<p>1. Turn ignition switch OFF. 2. Check continuity between ECM terminal 116 or IMMU terminal 1 and ground.</p>		
<p><b>Continuity should not exist.</b></p>		
SEL307WD		
<b>OK or NG</b>		
OK	▶	GO TO 8.
NG	▶	Communication line is short-circuited with ground line. Repair harness or connectors. <b>Ref. part No. C4</b>

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT

<b>8</b>	<b>SIGNAL FROM ECM TO IMMU CHECK</b>	
<p>1. Check the signal between ECM terminal 116 and ground with CONSULT-II or oscilloscope when ignition switch is turned "ON". 2. Make sure signals which are shown in the figure below can be detected during 750 msec. just after ignition switch is turned "ON".</p>		
SEL730W		
<b>OK or NG</b>		
OK	▶	IMMU is malfunctioning. Replace IMMU. <b>Ref. part No. A</b> Perform initialization with CONSULT-II. For the operation of initialization, refer to "CONSULT-II Operation Manual IVIS/NVIS".
NG	▶	ECM is malfunctioning. Replace ECM. <b>Ref. part No. B</b> Perform initialization with CONSULT-II. For the operation of initialization, refer to "CONSULT-II Operation Manual IVIS/NVIS".

AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS

HA

SC

EL

IDX

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 3

=NAEL0418S07

Self-diagnostic results:

“DIFFERENCE OF KEY” displayed on CONSULT-II screen

<b>1</b>	<b>CONFIRM SELF-DIAGNOSTIC RESULTS</b>											
Confirm SELF-DIAGNOSTIC RESULTS “DIFFERENCE OF KEY” displayed on CONSULT-II screen.												
<table border="1"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>DIFFERENCE OF KEY</td> <td>0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	DIFFERENCE OF KEY	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
DIFFERENCE OF KEY	0											
SEL367X												
<b>Is CONSULT-II screen displayed as above?</b>												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

<b>2</b>	<b>PERFORM INITIALIZATION WITH CONSULT-II</b>				
Perform initialization with CONSULT-II. Re-register all NVIS (NATS) ignition key IDs. For initialization and registration of NVIS (NATS) ignition key IDs, refer to “CONSULT-II operation manual NVIS/NVIS”.					
<table border="1"> <thead> <tr> <th>IMMU INITIALIZATION</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">INITIALIZATION FAIL</td> </tr> <tr> <td>THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.</td> </tr> </tbody> </table>			IMMU INITIALIZATION	INITIALIZATION FAIL	THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.
IMMU INITIALIZATION					
INITIALIZATION FAIL					
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.					
SEL297W					
<b>NOTE:</b>					
If the initialization is not completed or fails, CONSULT-II shows above message on the screen.					
<b>Can the system be initialized and can the engine be started with re-registered NVIS (NATS) ignition key?</b>					
Yes	▶	Ignition key ID was unregistered. <b>Ref. part No. D</b>			
No	▶	IMMU is malfunctioning. Replace IMMU. <b>Ref. part No. A</b> Perform initialization with CONSULT-II. For initialization, refer to “CONSULT-II operation manual IVIS/NVIS”.			

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 4

=NAEL0418S08

Self-diagnostic results:  
"CHAIN OF IMMU-KEY" displayed on CONSULT-II screen

<b>1</b>	<b>CONFIRM SELF-DIAGNOSTIC RESULTS</b>											
Confirm SELF-DIAGNOSTIC RESULTS "CHAIN OF IMMU-KEY" displayed on CONSULT-II screen.												
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>CHAIN OF IMMU-KEY</td> <td style="text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	CHAIN OF IMMU-KEY	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
CHAIN OF IMMU-KEY	0											
SEL368X												
<b>Is CONSULT-II screen displayed as above?</b>												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

<b>2</b>	<b>CHECK NVIS (NATS) IGNITION KEY ID CHIP</b>	
Start engine with another registered NVIS (NATS) ignition key.		
<b>Does the engine start?</b>		
Yes	▶	Ignition key ID chip is malfunctioning. Replace the ignition key. <b>Ref. part No. E</b> Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual IVIS/NVIS".
No	▶	GO TO 3.

<b>3</b>	<b>CHECK IMMU INSTALLATION</b>	
Check IMMU installation. Refer to "How to Replace IMMU" in EL-404.		
<b>OK or NG</b>		
OK	▶	IMMU is malfunctioning. Replace IMMU. <b>Ref. part No. A</b> Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II Operation Manual IVIS/NVIS".
NG	▶	Reinstall IMMU correctly.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 5

=NAEL0418S09

Self-diagnostic results:

“ID DISCORD, IMM-ECM” displayed on CONSULT-II screen

<b>1</b>	<b>CONFIRM SELF-DIAGNOSTIC RESULTS</b>											
Confirm SELF-DIAGNOSTIC RESULTS “ID DISCORD, IMM-ECM” displayed on CONSULT-II screen.												
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td>ID DISCORD, IMM-ECM</td> <td style="text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	ID DISCORD, IMM-ECM	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
ID DISCORD, IMM-ECM	0											
SEL369X												
<p><b>NOTE:</b>                  “ID DISCORD IMM-ECM”:                  Registered ID of IMMU is in discord with that of ECM.</p>												
<b>Is CONSULT-II screen displayed as above?</b>												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

<b>2</b>	<b>PERFORM INITIALIZATION WITH CONSULT-II</b>				
Perform initialization with CONSULT-II. Re-register all NVIS (NATS) ignition key IDs. For initialization, refer to “CONSULT-II operation manual IVIS/NVIS”.					
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th>IMMU INITIALIZATION</th> </tr> </thead> <tbody> <tr> <td style="text-align: center; padding: 10px;">                     INITIALIZATION                      FAIL                 </td> </tr> <tr> <td style="font-size: small; padding: 5px;">                     THEN IGN KEY SW ‘OFF’ AND                      ‘ON’, AFTER CONFIRMING                      SELF-DIAG AND PASSWORD,                      PERFORM C/U INITIALIZATION                      AGAIN.                 </td> </tr> </tbody> </table>			IMMU INITIALIZATION	INITIALIZATION FAIL	THEN IGN KEY SW ‘OFF’ AND ‘ON’, AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.
IMMU INITIALIZATION					
INITIALIZATION FAIL					
THEN IGN KEY SW ‘OFF’ AND ‘ON’, AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.					
SEL297W					
<p><b>NOTE:</b>                  If the initialization is not completed or fails, CONSULT-II shows above message on the screen.</p>					
<b>Can the system be initialized?</b>					
Yes	▶	Start engine. (END) (System initialization had not been completed. <b>Ref. part No. F</b> )			
No	▶	ECM is malfunctioning. Replace ECM. <b>Ref. part No. F</b> Perform initialization with CONSULT-II. For initialization, refer to “CONSULT-II operation manual IVIS/NVIS”.			

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)


## DIAGNOSTIC PROCEDURE 6

### “SECURITY INDICATOR LAMP DOES NOT LIGHT UP”

=NAEL0418S10

<b>1</b>	<b>CHECK FUSE</b>	
Check 10A fuse [No. 12, located in the fuse block (J/B)].		
<b>Is 10A fuse OK?</b>		
Yes	▶	GO TO 2.
No	▶	Replace fuse.

<b>2</b>	<b>CHECK SECURITY INDICATOR LAMP</b>	
<ol style="list-style-type: none"> <li>1. Install 10A fuse.</li> <li>2. Perform initialization with CONSULT-II. For initialization, refer to “CONSULT-II Operation Manual IVIS/NVIS”.</li> <li>3. Turn ignition switch OFF.</li> <li>4. Start engine and turn ignition switch OFF.</li> <li>5. Check the security indicator lamp lighting.</li> </ol> <p><b>Security indicator lamp should be blinking.</b></p>		
<b>OK or NG</b>		
OK	▶	INSPECTION END
NG	▶	GO TO 3.

<b>3</b>	<b>CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT</b>	
<ol style="list-style-type: none"> <li>1. Disconnect security indicator lamp connector.</li> <li>2. Check voltage between security indicator lamp connector terminal 1 and ground.</li> </ol>		
		
SEL370XA		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	Check harness for open or short between fuse and security indicator lamp.

<b>4</b>	<b>CHECK SECURITY INDICATOR LAMP</b>	
Check security Indicator Lamp.		
<b>Is security indicator lamp OK?</b>		
Yes	▶	GO TO 5.
No	▶	Replace security indicator lamp.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

5	<b>CHECK IMMU FUNCTION</b>	
<ol style="list-style-type: none"> <li>1. Connect IMMU connector.</li> <li>2. Disconnect security indicator lamp connector.</li> <li>3. Check continuity between IMMU terminal 5 and ground.</li> </ol>		
<div style="display: flex; justify-content: space-between; align-items: center;"> <div data-bbox="289 323 613 569"> <p>IMMU connector (E113)</p> <p>5</p> <p>BR</p> </div> <div data-bbox="695 331 760 548"> <p>H.S.</p> <p>CONNECT</p> <p>OFF</p> </div> <div data-bbox="878 415 1344 447"> <p><b>Continuity should exist intermittently.</b></p> </div> </div> <p style="text-align: right;">SEL300WC</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	Check harness for open or short between security indicator lamp and IMMU.
NG	▶	<p>IMMU is malfunctioning.</p> <p>Replace IMMU.</p> <p>Perform initialization with CONSULT-II.</p> <p>For initialization, refer to "CONSULT-II operation manual IVIS/NVIS".</p>

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

## DIAGNOSTIC PROCEDURE 7

=NAEL0418S11

Self-diagnostic results:  
"LOCK MODE" displayed on CONSULT-II screen

<b>1</b>	<b>CONFIRM SELF-DIAGNOSTIC RESULTS</b>											
Confirm SELF-DIAGNOSTIC RESULTS "LOCK MODE" is displayed on CONSULT-II screen.												
<table border="1" style="margin: auto;"> <thead> <tr> <th colspan="2">SELF DIAG RESULTS</th> </tr> <tr> <th>DTC RESULTS</th> <th>TIME</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">LOCK MODE</td> <td style="text-align: center;">0</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>			SELF DIAG RESULTS		DTC RESULTS	TIME	LOCK MODE	0				
SELF DIAG RESULTS												
DTC RESULTS	TIME											
LOCK MODE	0											
SEL371X												
<b>Is CONSULT-II screen displayed as above?</b>												
Yes	▶	GO TO 2.										
No	▶	GO TO SYMPTOM MATRIX CHART 1.										

<b>2</b>	<b>ESCAPE FROM LOCK MODE</b>	
<ol style="list-style-type: none"> <li>1. Turn ignition switch OFF.</li> <li>2. Turn ignition switch ON with registered key. (Do not start engine.) Wait 5 seconds.</li> <li>3. Return the key to OFF position.</li> <li>4. Repeat steps 2 and 3 twice (total of three cycles).</li> <li>5. Start the engine.</li> </ol>		
<b>Does engine start?</b>		
Yes	▶	System is OK. (Now system is escaped from "LOCK MODE".)
No	▶	GO TO 3.


<b>3</b>	<b>CHECK IMMU ILLUSTRATION</b>	
Check IMMU installation. Refer to "How to Replace IMMU" in EL-404.		
<b>OK or NG</b>		
OK	▶	GO TO 4.
NG	▶	Reinstall IMMU correctly.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# NVIS (NISSAN VEHICLE IMMOBILIZER SYSTEM — NATS)

Trouble Diagnoses (Cont'd)

<b>4</b>	<b>PERFORM INITIALIZATION WITH CONSULT-II</b>				
<p>Perform initialization with CONSULT-II. For initialization, refer to "CONSULT-II operation manual IVIS/NVIS".</p>					
<table border="1" style="margin: auto;"> <tr> <td style="text-align: center;"><b>IMMU INITIALIZATION</b></td> </tr> <tr> <td style="text-align: center;">INITIALIZATION FAIL</td> </tr> <tr> <td style="text-align: center;">THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.</td> </tr> </table>			<b>IMMU INITIALIZATION</b>	INITIALIZATION FAIL	THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.
<b>IMMU INITIALIZATION</b>					
INITIALIZATION FAIL					
THEN IGN KEY SW 'OFF' AND 'ON', AFTER CONFIRMING SELF-DIAG AND PASSWORD, PERFORM C/U INITIALIZATION AGAIN.					
SEL297W					
<p><b>NOTE:</b> If the initialization is not completed or fails, CONSULT-II shows the above message on the screen.</p>					
<b>Can the system be initialized?</b>					
Yes	▶	System is OK.			
No	▶	GO TO DIAGNOSTIC PROCEDURE 4 to check "CHAIN OF IMMU-KEY", refer to EL-399.			



## How to Replace NVIS (NATS) IMMU

NAEL0419

### NOTE:

- If NVIS (NATS) IMMU is not installed correctly, NVIS (NATS) system will not operate properly and SELF-DIAG RESULTS on CONSULT-II screen will show "LOCK MODE".

## Component Parts Location

GI  
NAEL0420

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS





BT

HA

SC

**EL**


IDX



SEL508X

# NAVIGATION SYSTEM

## System Description



## System Description

=NAEL0421

### OUTLINE


NAEL0421S01

The Navigation System (Multi-AV System) relies upon three sensing devices in order to determine vehicle location at regular time intervals.

1. Vehicle speed sensor: Determines the distance the vehicle has traveled.
2. Gyro (Angular velocity sensor): Determines vehicle steering angle and directional change.
3. GPS antenna (GPS data): Determines vehicle forward movement and direction.

The data provided by the three sensing functions together with a comparison of the mapping information read from the CD-ROM drive permit accurate determination of the vehicle's current location and subsequent course (map matching). The information appears on a liquid crystal display.

This comparison of GPS data (vehicle position sensing) and map matching permits precise determination of vehicle location.







## Position Sensor Operating Principles

NAEL0421S0101

The sensor determines current vehicle location by calculating the previously sensed position, the distance traveled from this position, and the directional changes occurring during this travel.

1. Distance traveled  
The distance traveled is calculated using signals received from the vehicle speed sensor. The sensor automatically compensates for the slightly reduced wheel and tire diameter resulting from tire wear.
2. Forward movement (Direction)  
Changes in the direction of forward movement are calculated by the gyro (angular velocity sensor) and the GPS antenna (GPS data). Each of these functions has its advantage and disadvantages. Depending upon conditions, one function takes precedence over the other to accurately determine the direction of forward movement.

Function type	Advantage	Disadvantage
Gyro (Angular velocity sensor)	<ul style="list-style-type: none"> <li>• Able to accurately detect minute changes in steering angle and direction.</li> </ul>	<ul style="list-style-type: none"> <li>• Calculation errors may accumulate over a long period of continuous vehicle travel.</li> </ul>
GPS antenna (GPS data)	<ul style="list-style-type: none"> <li>• Able to sense vehicle travel in four general directions (North, South, East, and West)</li> </ul>	<ul style="list-style-type: none"> <li>• Unable to detect direction of vehicle travel at low vehicle speeds.</li> </ul>



## Map Matching

NAEL0421S0102

Map matching allows the driver to compare the sensed vehicle location data with the road map contained in the CD-ROM drive. Vehicle position is marked on the CD-ROM map. This permits the driver to accurately determine his/her present position on the highway and to make appropriate course decisions.

When GPS data reception is poor during travel, the vehicle position is not amended. At this time, manual manipulation of the CD-ROM map position marker is required.

Map matching permits the driver to make priority judgments about possible appropriate roads other than the one currently being traveled.

If there is an error in the distance or direction of travel, there will also be an error in the relative position of other routes. When two routes are closely parallel to one another, the indicated position for both routes will be nearly the same priority. This is so that, slight changes in the steering direction may cause the marker to indicate both routes alternately.

Newly constructed roads may not appear on the CD-ROM map. In this case, map matching is not possible. Changes in the course of a road will also prevent accurate map matching.

When driving on a road not shown on the CD-ROM map, the position marker used for map matching may indicate a different route. Even after returning to a route shown on the map, the position marker may jump to the position currently detected.

## GPS (Global Positioning System)

NAEL0421S0103

GPS is the global positioning system developed and operated by the US Department of Defense. GPS satellites (NAVSTAR) transmit radio waves and orbit around the earth at an altitude of approximately 21,000 km (13,000 miles).

GPS receiver calculates the three-dimensional position of the vehicle (latitude, longitude, and altitude from the sea level) by the time difference of the radio wave arriving from more than four GPS satellites (three-dimensional positioning).

When the radio wave is received from only three GPS satellites, the two-dimensional position (latitude and longitude) is calculated, using the altitude from the sea level data calculated by using four GPS satellites (two-dimensional positioning).

Positioning capability is degraded in the following cases.


- In two-dimensional positioning, when the vehicle's altitude from the sea level changes, the precision becomes lower.
- The location detection performance can have an error of about 100 m (300 ft) even in three-dimensional positioning with high precision. Because the precision is influenced by the location of GPS satellites used for positioning, the location detection performance may drop depending on the location of GPS satellites.
- When the radio wave from GPS satellites cannot be received,

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
 EL  
 IDX

# NAVIGATION SYSTEM

## System Description (Cont'd)

for example, when the vehicle is in a tunnel, in a parking lot inside building, under an elevated superhighway or near strong power lines, the location may not be detected. Turbulent/electric weather conditions may also affect positioning performance. If something is placed on the antenna, the radio wave from GPS satellites may not be received.




## COMPONENT DESCRIPTION

### Display & NAVI Control Unit

NAEL0421S02

NAEL0421S0201

- The gyro (angular speed sensor) and the CD-ROM drive are built-in units that control the navigation functions.
- Signals are received from the gyro, the vehicle speed sensor, and the GPS antenna. Vehicle location is determined by combining this data with the data contained in the CD-ROM map. Locational information is shown on liquid crystal display panel.
- Finger-operated touch switches are positioned on the liquid crystal display panel for easy operation.
- The touch switches used to control the equipment are beneath a glass sheet and two resistance membranes at the top of the liquid crystal display panel. The switches are sensitive to resistance value where touched with your finger to detect operating status.



### CD-ROM Driver

NAEL0421S0202

Maps, traffic control regulations, and other pertinent information can be easily read from the CD-ROM disc.


#### NOTE:

- When removing the CD-ROM, allow it to remain open until the liquid crystal display locks.
- The liquid crystal display must be closed when the vehicle is running.
- Do not place cups, cans or other containers containing liquids on top of the liquid crystal display.

### Map CD-ROM

NAEL0421S0203


- The map CD-ROM has maps, traffic control regulations, and other pertinent information.
- To improve CD-ROM map matching and route determination functions, the CD-ROM uses an exclusive Nissan format. Therefore, the use of a CD-ROM provided by other manufacturers cannot be used.



## Gyro (Angular Speed Sensor)

NAEL0421S0204


- The oscillator gyro sensor is used to detect changes in vehicle steering angle.
- The oscillator gyro periodically senses oscillatory variation at the oscillation terminals. This variation is caused by changes in the vehicle angular velocity. Voltage variations are sensed by ceramic voltage sensors at the left and right sides of the terminals. Vehicle angular velocity corresponds directly with these changes in voltage.
- The gyro is built into the display & navigation (NAVI) control unit.



## BIRDVIEW®

NAEL0421S0205

The BIRDVIEW® provides a detailed and easily seen display of road conditions covering the vehicle's immediate to distant area.



## Description

NAEL0421S0206

- Display area: Trapezoidal representation showing approximate distances ( $W_n$ ,  $D$ , and  $W_d$ ).
- Ten horizontal grid lines indicate display width while six vertical grid lines indicate display depth and direction.
- Drawing line area shows open space, depth, and immediate front area. Each area is to a scale of approximately 5:6:25.
- When the "ZM-" button is pushed, the view point height is increased. Pushing the "ZM+" button decreases the height. Pushing the "ZM-" button or the "ZM+" button during operation indicates the scale change and the view point height at the left-hand side of the screen.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


# NAVIGATION SYSTEM

System Description (Cont'd)

## FUNCTION OF TOUCH SWITCH (SUMMARY) Display with Pushed "MAP" Switch

=NAEL0421S03

NAEL0421S0301




The function of each touch switch is as follows:

- 1) Azimuth indication
- 2) Position marker  
The tip of the arrow shows the current position. The shaft of the arrow indicates the direction in which the vehicle is traveling.
- 3) GPS reception signal (indicates current reception conditions)
- 4) Distance display (shows the distance in a reduced scale)
- 5) Current location voice information  
(this information is available when the route guide is being activated and the designated route is being traveled.)
- 6) Switch display from map screen to BIRDVIEW<sup>®</sup> screen  
(change to map screen on display when the BIRDVIEW<sup>®</sup> is being used.)
- 7) The following items can be set.
  - Save Current Location
  - Edit Address Book
  - Guide Volume
  - System Setting
- 8) The route guide operation can be canceled.

## Display with Pushed "DEST" Switch

=NAEL0421S0302



SEL581X

The function of each touch switch is as follows:

Icon	Description
Address Book	Favorite place can be saved to memory. The destination can be selected from the memory.
Address/Street	The destination can be searched from the address.
Point of Interest (POI)	The destination of favorite facility can be searched.
Previous Dest.	The previous ten destinations stored in memory are displayed.
Intersection	The destination from the intersection name can be retrieved.
City	The destination can be searched from city name.
Map	The destination can be searched from the map.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# NAVIGATION SYSTEM

System Description (Cont'd)

## Display with Touch Screen

NAEL0421S0303



SEL476Y

The function of each touch switch is as follows:

Icon	Description
Quick Stop	The selected facility is set as the destination or way-point. (Route guidance has been turned OFF or the destination has been reached.)
Where am I?	Next, current and previous street names can be displayed.
Route Info.*	The following items can be set. <ul style="list-style-type: none"> <li>● Complete Route</li> <li>● Turn List</li> <li>● Route Simulation</li> </ul> (Displayed only when the destination area has been set.)
Detour*	Based on the selected distance, an alternative route is searched. [Displayed only when the recommended route (not its reverse) is followed.]
Edit Route*	Change the destination or add the transit points of the route set in the route guide. (Displayed only when the automatic reroute function has been turned OFF and the recommended route is not followed.)
Route Calc.	Search for a recommended route between the vehicle's current location and the destination area. (Displayed only when the destination area has been set.)


\*: When destinations have been entered, route guidance has been turned OFF or destination has been reached, "Route Info.", "Detour" and "Edit Route" are not displayed.

# NAVIGATION SYSTEM

Schematic

NAEL0422

## Schematic



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

EL

IDX

MEL270N



# NAVIGATION SYSTEM

Wiring Diagram — NAVI —

## Wiring Diagram — NAVI —

NAEL0423

EL-NAVI-01



REFER TO THE FOLLOWING.

- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (M10), (M81) -FUSE BLOCK-JUNCTION BOX (J/B)

\* : This connector is not shown in "HARNESS LAYOUT", EL section.



MEL878N

# NAVIGATION SYSTEM

Wiring Diagram — NAVI — (Cont'd)

EL-NAVI-02

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX




MEL272N

# NAVIGATION SYSTEM

Wiring Diagram — NAVI — (Cont'd)

EL-NAVI-03




MEL270M

## Self-diagnosis Mode APPLICATION ITEMS

NAEL0424

NAEL0424S01

Mode	Description	Reference page	
Self Diagnosis	Self-diagnosis for display & NAVI control unit, CD-ROM and GPS antenna connection.	EL-418	
Confirmation/ adjustment	Display Diagnosis	Color and gray gradation of display can be checked in this mode.	
	Diagnostic Signals from the Car	Several input signals to display & NAVI control unit, can be monitored in this mode.	
	Navigation	Check the map CD-ROM version	The version (parts number) of inserted CD-ROM can be checked in this mode.
		History of errors	Diagnosis results previously stored in the memory (before turning ignition switch ON) are displayed in this mode. Time and location when/where the errors occurred are also displayed.
		Longitude & Latitude	Display the map. Use the joystick to adjust position. Longitude and latitude will be displayed.
		Adjust the angle	Turning angle of the vehicle on the display can be adjusted in this mode.
		Speed Calibration	Under ordinary conditions, the navigation system distance measuring function will automatically compensate for minute decreases in wheel and tire diameter caused by tire wear or low pressure. Speed calibration immediately restores system accuracy in cases such as when distance calibration is needed because of the use of tire chains in inclement weather.
Initialize Location	This mode is for initializing the current location. Use when the vehicle is transported a long distance on a trailer, etc.		



### HOW TO PERFORM SELF-DIAGNOSIS MODE

NAEL0424S02

1. Start the engine.
2. Push both of "MAP" and "D/N" switches at the same time for more than 5 seconds.
3. Touch "Self Diagnosis" or "Confirmation/ adjustment".
  - For further procedure, refer to the following pages which describe each application item of the self-diagnosis mode.



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# NAVIGATION SYSTEM

## Self-diagnosis Mode (Cont'd)

NAEL0424S0201

### “Self Diagnosis”


1. Start the engine.
2. Push both “MAP” and “D/N” switches at the same time for more than 5 seconds.
3. Touch “Self Diagnosis”.




4. Self-diagnosis will be performed.



5. Diagnosis results will be displayed. Diagnosis results are indicated by display color. For details refer to “SELF-DIAGNOSIS RESULTS”.



To obtain detailed diagnosis results on the screen, touch “Navigation” or “GPS Antenna”.



# NAVIGATION SYSTEM

Self-diagnosis Mode (Cont'd)

## SELF-DIAGNOSIS RESULTS

=NAEL0424S03

Diagnosed item	Displayed color	Detailed result	Description	Diagnoses/service procedure <b>Recheck system at each check or replacement (When malfunction is eliminated, further repair work is not required.)</b>
"GPS Antenna" (GPS antenna connection)	Green	—	GPS antenna is connected to display & NAVI control unit correctly.	—
	Yellow	Connection to the following unit is abnormal. See the Service Manual for further diagnosis.	GPS antenna connection error is detected.	<ol style="list-style-type: none"> <li>1. Check GPS antenna feeder cable connection at display &amp; NAVI control unit.</li> <li>2. Visually check GPS antenna feeder cable. If NG, replace GPS antenna assembly.</li> <li>3. Replace GPS antenna.</li> </ol>
"Navigation" (Display & NAVI control unit)	Green	—	No failure is detected.	—
	Red	[*** is abnormal.]	Display & NAVI control unit is malfunctioning.	Replace display & NAVI control unit.
	Gray	Self-diagnosis for CD-ROM DRIVER of DISP & NAVI was not conducted due to no insertion of CD-ROM.	Any CD-ROM is not inserted or display & NAVI control unit is malfunctioning.	<ol style="list-style-type: none"> <li>1. Confirm that map CD-ROM is not inserted into display &amp; NAVI control unit.</li> <li>2. Replace display &amp; NAVI control unit.</li> </ol>
	Yellow	CD-ROM or CD-ROM DRIVER of DISP & NAVI is abnormal. See the Service Manual for further diagnosis.	Display & NAVI control unit judges that inserted CD-ROM is malfunctioning. Map CD-ROM or CD-ROM driver of the unit is malfunctioning.	<ol style="list-style-type: none"> <li>1. Confirm the disk is installed correctly (not up side down.)</li> <li>2. Perform "CHECK THE MAP CD-ROM VERSION" in EL-425 to confirm whether correct CD-ROM is inserted or not.</li> <li>3. Check the disk surface. Are there any scratches, abrasions or pits on the surface?</li> <li>4. Replace the CD-ROM.</li> <li>5. Replace display &amp; NAVI control unit.</li> </ol>
		CD-ROM is abnormal. Please check the disc.	Inserted map CD-ROM can not be read. Map CD-ROM or CD-ROM driver of the unit is malfunctioning.	
		Connection to the following unit is abnormal. See the Service Manual for further diagnosis.	GPS antenna connection error is detected.	<ol style="list-style-type: none"> <li>1. Check GPS antenna feeder cable connection at display &amp; NAVI control unit.</li> <li>2. Visually check GPS antenna feeder cable. If NG, replace GPS antenna assembly.</li> <li>3. Replace GPS antenna.</li> </ol>

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX

## Confirmation/Adjustment Mode

=NAEL0425

### “HISTORY OF ERRORS” MODE

NAEL0425S01

#### Description


NAEL0425S0101

In this mode, historical errors of the system are displayed with the following data.


- How many times the error was detected
- The last time data when the error was detected
- The last place where the error was detected

#### NOTE:


- The number of errors can be counted up to 50 times. More than 51 times will be indicated as 50 times.
- Malfunction of the GPS board (inside the display & NAVI control unit) will result in the display of incorrect time data.
- When an error occurs, an incorrect position marker appears on the display. The accuracy of the display data (position marker) will be affected.



SEL584X



SEL588X



SEL453Y


#### How to Perform

NAEL0425S0102

1. Start the engine.
2. Push both “MAP” and “D/N” switch at the same time for more than 5 seconds.
3. Touch “Confirmation/ adjustment”.
4. Touch “Navigation”.
5. Touch “Error history”.

# NAVIGATION SYSTEM

Confirmation/Adjustment Mode (Cont'd)



6. If trouble items are displayed with time count, repair/replace the system according to "HISTORY OF ERRORS" TABLE, EL-422. GI
7. If necessary, touch error item to display the time when the error was detected and the place where the error was detected. MA
8. After repairing the system, erase the diagnosis memory. EM

**NOTE:**

**When the display & NAVI control unit must be replaced, do not erase the diagnosis memory for further inspection of malfunctions.** LC

- a. Start the engine. EC
- b. Push both "Map" and "D/N" switches at the same time for more than 5 seconds. EC
- c. Touch "Confirmation/ adjustment". FE
- d. Touch "Navigation". FE
- e. Touch "Error history". CL
- f. Touch "Delete". CL
- g. Touch "Yes". CL

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# NAVIGATION SYSTEM

Confirmation/Adjustment Mode (Cont'd)

## “HISTORY OF ERRORS” TABLE

=NAEL0425S02

Detected items	Description	Diagnosis/service procedure	Reference page
Gyro sensor disconnected	Communications malfunction between display & NAVI control unit and internal gyro	Perform self-diagnosis to confirm whether the display & NAVI control unit is malfunctioning or not. If no failure is detected, a momentary and/or temporary malfunction may have been caused by strong electromagnetic wave interference.	EL-417
Connection problem of speed sensor	Input malfunction of display & NAVI control unit and speed sensor	Check vehicle speed sensor signal in “DIAGNOSTIC SIGNALS FROM THE CAR” mode. If the input signal is not detected correctly, check harness for open or short between combination meter and display & NAVI control unit.	EL-424
GPS disconnected	Communications malfunction between display & NAVI control unit and GPS board	Perform self-diagnosis to confirm whether the display & NAVI control unit is malfunctioning or not. If no failure is detected, a momentary and/or temporary malfunction may have been caused by strong electromagnetic wave interference.	EL-417
GPS transmission cable malfunction			
GPS input line connection error			
GPS TCXO over	The transmission circuit of the GPS board frequency synchronization oscillator (inside the display & NAVI control unit) is sending an oscillation frequency that is greater or less than the set value.	A location error occurs. Strong electromagnetic wave interference may have occurred. The GPS antenna may be in a very hot or very cold environment. This is usually a temporary malfunction.	—
GPS TCXO under			
GPS ROM malfunction	Internal malfunction of GPS board RAM or ROM inside the display & NAVI control unit.	Perform self-diagnosis to confirm whether the display & NAVI control unit is malfunctioning or not. If no failure is detected, a momentary and/or temporary malfunction may have been caused by strong electromagnetic wave interference.	EL-417
GPS RAM malfunction			
GPS RTC malfunction			
GPS antenna disconnected	—	Perform self-diagnosis to confirm GPS antenna connection. If no failure is detected, a momentary and/or temporary malfunction may have been caused by a strong impact.	EL-425
Low voltage of GPS	Power supply voltage for GPS board inside the display & NAVI control unit is low.	1. Check power supply circuits for display & NAVI control unit.	EL-438
		2. Perform self-diagnosis to confirm GPS antenna connection.	EL-417
		3. If above diagnosis results are OK, a momentary and/or temporary malfunction may have been caused by a strong impact.	—
CD-ROM communication error	CD-ROM driver malfunction (inside the display & NAVI control unit)	Perform self-diagnosis to confirm whether the display & NAVI control unit is malfunctioning or not. If no failure is detected, a momentary and/or temporary malfunction may have been caused by strong electromagnetic wave interference.	EL-417

# NAVIGATION SYSTEM

Confirmation/Adjustment Mode (Cont'd)

Detected items	Description	Diagnosis/service procedure	Reference page
Loading mechanism malfunction	—	Check that whether the disc can be inserted and ejected correctly. If the loading function does not operate correctly, replace NAVI & display control unit.	—
CD-ROM reading error	It is confirmed that the appropriate CD-ROM disc is positioned in the CD-ROM loader. However, no data can be read.	Perform self-diagnosis to confirm whether the inserted disc is malfunctioning or not.	EL-417
Malfunctioning of error correction for CD-ROM	Erroneous data is read from the CD-ROM. The errors cannot be corrected.		
CD-ROM focus error	CD-ROM data reading beam is out of focus.	Rough road driving might create CD skipping like music CD audio unit.	—
CD-ROM malfunction	—	Perform self-diagnosis to confirm whether the inserted disc is malfunctioning or not.	EL-417

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX

# NAVIGATION SYSTEM

Confirmation/Adjustment Mode (Cont'd)


## “DIAGNOSTIC SIGNALS FROM THE CAR” MODE =NAEL0425S03

### Description NAEL0425S0301


In “Diagnostic Signals From the Car” mode, following input signals to the display & NAVI control unit can be checked on the display.

Item	Indication	Vehicle condition
Vehicle Speed*	ON	Vehicle speed is greater than 0 km/h (0 MPH).
	OFF	Vehicle speed is 0 km/h (0 MPH).
Light	ON	Lighting switch is in 1st or 2nd position.
	OFF	Lighting switch is in “OFF” position.
IGN	ON	Ignition switch is in “ON” position.
	OFF	Ignition switch is in “ACC” position.
REVERSE*	ON	Selector/shift lever is in “Reverse” position.
	OFF	Selector/shift lever is in other than “Reverse” position.


\*: When ignition switch is in “ACC” position, indication will be changed to “-”.



SEL584X







SEL588X



SEL591X

### How to Perform NAEL0425S0302

1. Start the engine.
2. Push both “MAP” and “D/N” switches at the same time for more than 5 seconds.
3. Touch “Confirmation/ adjustment”.
4. Touch “Diagnostic Signals from the Car”.
5. Then “Diagnostic Signals from the Car” mode is performed.



## “CHECK THE MAP CD-ROM VERSION” MODE

=NAEL0425S04

### How to Perform

NAEL0425S0401

1. Start the engine.
2. Push both “MAP” and “D/N” switches at the same time for more than 5 seconds.
3. Touch “Confirmation/ adjustment”.
4. Touch “Navigation”.
5. Touch “Check the map CD-ROM version”.
6. The version (parts number) of CD-ROM loaded to the display and NAVI control unit will be displayed.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# NAVIGATION SYSTEM

Confirmation/Adjustment Mode (Cont'd)

## “DISPLAY DIAGNOSIS” MODE

=NAEL0425S05

### Description


NAEL0425S0501

Use the “Diagnosis Display” mode to check the display color brightness and shading. The display & NAVI control unit must be replaced if the color brightness and shading are abnormal.


### How to Perform

NAEL0425S0502


1. Start the engine.
2. Push both “MAP” and “D/N” switches at the same time for more than 5 seconds.
3. Touch “Confirmation/ adjustment”.
4. Touch “Display Diagnosis”.
5. Touch “Display color spectrum bar” or “Display gradation bar”.
6. Then color bar/gray scale will be displayed.




SEL584X



SEL588X



SEL454Y



SEL455Y

## “LONGITUDE & LATITUDE” MODE

NAEL0425S06

### Description

NAEL0425S0601

The “Longitude & Latitude” is used to confirm the longitude and latitude of some optional area point.

GI

MA

EM

LC

EC

NAEL0425S0602

### How to Perform

1. Start the engine.
2. Push both “MAP” and “D/N” switches at the same time for more than 5 seconds.
3. Touch “Confirmation/ adjustment”.

FE

CL

MT

AT

4. Touch “Navigation”.

TF

PD

AX

SU

5. Touch “Longitude & Latitude”.

BR

ST

RS

BT


6. Adjust the pointer with using the joystick and touch “Set”.
7. The longitude and latitude are displayed.

HA


SC

EL

IDX




SEL584X



SEL588X



SEL589X



SEL595X

# NAVIGATION SYSTEM

Confirmation/Adjustment Mode (Cont'd)

## “ADJUST THE ANGLE” MODE

=NAEL0425S07

### Description

NAEL0425S0701


If the display indicates a larger or smaller turning angle than the actual turning angle, the gyro (angular speed sensor) sensing values must be checked.

In case that the vehicle on the display makes larger angle turn than reality, touch “-”. In case that the vehicle on the display makes smaller angle turn than reality, touch “+”.


### How to Perform

NAEL0425S0702


1. Start the engine.
2. Push both “MAP” and “D/N” switches at the same time for more than 5 seconds.
3. Touch “Confirmation/ adjustment”.




SEL584X



SEL588X




SEL453Y




SEL456Y

4. Touch “Navigation”.
5. Touch “Adjust the angle”.
6. Touch “Left Turn” to adjust the angle to the left. Touch “Right Turn” to adjust the angle to the right.
7. Touch “+” to increase the angle change coefficient or “-” to reduce the angle change coefficient.
8. Touch “Set” to save the changed values in memory.
9. Then the vehicle turning angle on the display has adjusted.


=NAEL0425S08



SEL584X



SEL453Y



SEL457Y

## SPEED CALIBRATION

1. Start the engine.
2. Push both "MAP" and "D/N" switches at the same time for more than 5 seconds.
3. Touch "Confirmation/ adjustment".
4. Touch "Navigation".
5. Touch "Speed Calibration".
6. Touch "+" or "-" to adjust the distance change coefficient.
  - To make the distance change coefficient smaller, touch "-".
  - To make the distance change coefficient larger, touch "+".
7. Touch "Set".

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# NAVIGATION SYSTEM


Setting Mode

## Setting Mode APPLICATION ITEMS

=NAEL0426

NAEL0426S01

Mode	Description	Reference page
GPS Information	The GPS includes longitude, latitude and altitude (distance above sea level) of the present vehicle position, and current date and time for the area in which the vehicle is being driven. Also indicated are the GPS reception conditions and the GPS satellite position.	EL-430
Quick Stop Customer Setting	One facility of your selection can be added to your Quick Stop.	EL-433
Route Priorities	Priorities of search request and automatic re-searching can be set for route search.	EL-434
Tracking	Tracking to the present vehicle position can be displayed.	EL-435
Display Setting	The following display settings can be customized. <ul style="list-style-type: none"> <li>● Display color (Day mode or Night mode)</li> <li>● Brightness of display</li> </ul>	EL-432
Heading	Heading of the map display can be customized for either north heading or the actual driving direction of the vehicle.	EL-435
Nearby Display Icons	Icons of facilities can be displayed. Facilities to be displayed can be selected from the variety of selections.	EL-436
Adjust Current Location	Current location of position marker can be adjusted. Direction of position marker also can be calibrated when heading direction of the vehicle on the display is not matched with the actual direction.	EL-431
Avoid Area Setting	Particular area can be avoided when routing.	—
Beep On/Off	Beep sounds which correspond to the system operation can be activated/deactivated.	EL-432
Clear Memory	Address book, Previous destination or Avoid area can be deleted.	EL-436




SEL597X

### HOW TO PERFORM CONTROL PANEL MODE

NAEL0426S02

1. Start the engine.
2. Push "MAP" switch.
- For further procedures, refer to the following pages which describe each application item of the control panel mode.




SEL598X

### "GPS INFORMATION" SETTING


NAEL0426S03

1. Start the engine.
2. Push "MAP" switch.
3. Touch "Setting".




SEL461Y

4. Touch "System Setting".




SEL462Y

5. Touch "GPS Information".



SEL146W

6. Then GPS information will be displayed.




SEL460Y

## "ADJUST CURRENT LOCATION" SETTING

NAEL0426S04

1. Start the engine.
2. Push "MAP" switch.
3. Touch "Setting".
4. Touch "System Setting".




SEL463Y

5. Touch "Adjust Current Location".


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# NAVIGATION SYSTEM

## Setting Mode (Cont'd)




6. Touch “↶” or “↷” to calibrate the heading direction. (Arrow marks will rotate corresponding to the calibration key.)
7. Touch “Set”. Then the vehicle mark will be matched to the arrow mark.
8. Display will show “Heading direction has been calibrated” and then go back to the current location map.




## BEEP ON/OFF SETTING

NAEL0426S05

1. Start the engine.
2. Push “MAP” switch.
3. Touch “Setting”.
4. Touch “System Setting”.



5. Touch “Beep on/off”.



6. Touch “On” or “Off” icon.
  - If you want the beep sound, select “ON”.
  - If you do not want the beep sound, select “OFF”.
7. Push “MAP” switch, then the display will go back to the current location map.

## DISPLAY SETTING


NAEL0426S06

### Description

NAEL0426S0601

The following display setting can be changed in this mode.

- Dimmer operation (when lighting switch is turned on.)
- Display color (Day mode or Night mode)
- Brightness of display




## DISPLAY COLOR SETTING

NAEL0426S07

1. Start the engine.
2. Push "MAP" switch.
3. Touch "Setting".
4. Touch "System Setting".
5. Touch "Color". Display color will change to Day mode/Night mode.
6. Touch "Previous".

### NOTE:

- Display color can be changed independently when lighting switch is turned on and off.
- Initial setting of the color is as follows:  
 When lighting switch is turned off: Day mode  
 When lighting switch is turned on: Night mode  
 Day mode: White background  
 Night mode: Black background




## BRIGHTNESS SETTING

NAEL0426S08

1. Start the engine.
2. Push "MAP" switch.
3. Touch "Setting".
4. Touch "System Setting".
5. Touch "Display Setting".
6. Touch "Bright" or "Dark" to adjust the brightness of display.
7. Touch "Previous".

### NOTE:

- Display brightness can be adjusted independently when lighting switch is turned on and off.




## "QUICK STOP CUSTOMER SETTING" MODE

NAEL0426S09


1. Start the engine.
2. Push the "MAP" switch.
3. Touch "Setting".
4. Touch "System Setting".

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX







SEL460Y




SEL467Y



SEL470Y



SEL460Y



SEL467Y

## “TRACKING” MODE

NAEL0426S11

1. Start the engine.
2. Push the “MAP” switch.
3. Touch “Setting”.
4. Touch “System Setting”.
5. Touch “Tracking”.

6. Touch the “On” or “Off” icon.
  - If you don’t need a trail on the map, select “Off”.
  - If you need a trail on the map, select “On”.
7. Push the “MAP” switch to return the display to the current location map.

### NOTE:

**When a trail display is turned OFF, trail data is erased from the memory.**

## “HEADING” MODE


NAEL0426S12

1. Start the engine.
2. Push the “MAP” switch.
3. Touch “Setting”.
4. Touch “System Setting”.
5. Touch “Heading”.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# NAVIGATION SYSTEM

## Setting Mode (Cont'd)




6. Touch the "Heading up" or "North up" icon.
  - To display North up, select "North up".
  - To display the car heading up, select "Heading up".
7. Push the "MAP" switch, then the display will go back to the current location map.




## "NEARBY DISPLAY ICONS" MODE

NAEL0426S13


1. Start the engine.
2. Push the "MAP" switch.
3. Touch "Setting".
4. Touch "System Setting".



5. Touch "Nearby Display Icons".



6. Select and touch the itemized list.
7. Push the "MAP" switch to return the display to the current location map.



## "CLEAR MEMORY" MODE

NAEL0426S14

1. Start the engine.
2. Push the "MAP" switch.
3. Touch "Setting".
4. Touch "System Setting".



# NAVIGATION SYSTEM

Trouble diagnoses

## Trouble diagnoses SYMPTOM CHART


NAEL0427

NAEL0427S01

Symptom	Diagnoses/service procedure	Reference page
Any function of the system does not operate.	Check power supply and ground circuit for display & NAVI control unit.	EL-441
Strange screen color or unusual screen brightness.	1. Check "DISPLAY SETTING".	EL-432
	2. Check display in "Diagnosis of Display" MODE.	—
The display is not dimmed when turning lighting switch to ON.	1. Check "DISPLAY SETTING".	EL-432
	2. Check lighting switch signal input to display & NAVI control unit correctly in "DIAGNOSTIC SIGNAL FROM THE CAR" MODE.	EL-424
No navigation guide voice are heard from both front speakers.	1. Check "Voice Guidance Setting".	—
	2. Check voice guide operation.	EL-442
Beep does not sound when the system guides route.	Check "BEEP ON/OFF SETTING".	EL-432
Position marker does not trace along the route being traveled.	Go to "WORK FLOW FOR NAVIGATION INSPECTION".	EL-439
Position marker does not indicate forward or backward movement.	Check reverse signal input to display & NAVI control unit correctly by "DIAGNOSTIC SIGNAL FROM THE CAR" MODE.	EL-424
Radio wave of GPS cannot be received. (GPS marker on the display does not become green color.)	1. Is there anything obstructing the GPS antenna on the rear parcel finisher? (GPS antenna located under the rear parcel finisher.)	—
	2. Check GPS radio wave receive condition in "GPS INFORMATION SETTING".	EL-430
	3. Check GPS antenna in "Self Diagnosis".	EL-417
Heading direction of position marker does not match vehicle direction.	1. Perform "ADJUST CURRENT LOCATION" SETTING.	EL-431
	2. Go to "WORK FLOW FOR NAVIGATION INSPECTION".	EL-439
Stored location in the address book and other memory functions are lost when battery is disconnected or becomes discharged.	Stored location in the address book and other memory functions may be lost if the battery is disconnected or becomes discharged. If this should occur, charge or replace the battery as necessary and re-enter the information.	—
Map appears grey and cannot be scrolled.	The current location in the memory is out of the map data area. Perform "Initialize Location".	EL-454

## WORK FLOW FOR NAVIGATION INSPECTION

NAEL0427S02



\*1: EL-444  
\*2: EL-417  
\*3: EL-420

\*4: EL-424  
\*5: EL-440

\*6: EL-419  
\*7: EL-422

SEL629XA

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

## DRIVING TEST

=NAEL0427S03

During the driving test, diagnose the system by checking the difference of symptoms with each sensor ON or OFF.

### Test pattern 1

Test method in which current position adjustment is not made according to GPS data.

- Remove the GPS antenna connector from the display & NAVI control unit. Drive the vehicle.  
Before driving the vehicle, perform "ADJUST CURRENT LOCATION" (EL-431).

### Test pattern 2

Test procedure in which map matching is not used.

- Before driving the vehicle, perform "ADJUST CURRENT LOCATION" (EL-431). With the ignition switch OFF and the map CD-ROM removed from the display & NAVI control unit, drive the vehicle. After driving the vehicle, reinstall the map CD-ROM. Compare the saved driving tracks for the vehicle's current location with roads on the map.

### Example

<The position marker consistently indicates the wrong position when driving in the same area. Determine if this is the result of the map matching function or the GPS function.>

→ Perform test pattern 1.

<To verify the accuracy of the road configuration shown on the display>

→ Perform test patterns 1 and 2.


- Compare the map and the saved driving tracks. The precision of the saved driving tracks is within several hundred meters.

<To make distance calibration and adjustments>

→ Perform test patterns 1 and 2.

- Make adjustments by driving the vehicle over a known course (highway or other road where distances are clearly marked). Calibrate the distance against the known distance. Use the formula below.

Calibration value = Screen display distance/Actual distance



## POWER SUPPLY AND GROUND CIRCUIT CHECK FOR DISPLAY & NAVI CONTROL UNIT

=NAEL0427S04


### Power Supply Circuit Check

NAEL0427S0401

Terminal		Ignition switch		
		OFF	ACC	ON
(+)	(-)			
1	Ground	Battery voltage	Battery voltage	Battery voltage
2	Ground	Battery voltage	Battery voltage	Battery voltage
5	Ground	0V	0V	Battery voltage
6	Ground	0V	Battery voltage	Battery voltage

If NG, check the following.

- 7.5A fuse [No. 11, located in the fuse block (J/B)]
- 10A fuse [No. 10, located in the fuse block (J/B)]
- 15A fuse [No. 4, located in the fuse block (J/B)]
- Harness for open or short between fuse and display & NAVI control unit



### Ground Circuit Check

NAEL0427S0402

Terminals	Continuity
3 - Ground	Yes
4 - Ground	Yes

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


# NAVIGATION SYSTEM


Trouble diagnoses (Cont'd)




## VOICE GUIDE OPERATION CHECK

=NAEL0427S05

<b>1</b>	<b>PRELIMINARY CHECK</b>	
<ol style="list-style-type: none"> <li>Turn ignition switch to ACC position.</li> <li>Insert the music CD into the radio and CD player.</li> <li>Try to play the music CD.</li> </ol> <p><b>Is the sound emitted from all speakers?</b></p> <p style="text-align: center;">Yes or No</p>		
Yes	▶	GO TO 2.
No	▶	Repair or replace audio system. Refer to "AUDIO", EL-170.

<b>2</b>	<b>CHECK NAVI OPERATION ON SIGNAL</b>	
<ol style="list-style-type: none"> <li>Disconnect audio unit connector.</li> <li>Push "VOICE" button.</li> <li>Check voltage between terminal 28 and ground.</li> </ol>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  </div> <div style="text-align: left;"> <p><b>Voltage [V]:</b>                      Condition of VOICE button: Push.                      Approx. More than 0 - 10                      Condition of VOICE button: Do not push.                      0</p> </div> </div> <p style="text-align: right;">SEL645XA</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 3.
NG	▶	Repair or replace harness or NAVI control unit.

<b>3</b>	<b>CHECK VOICE SIGNAL CIRCUIT</b>	
<ol style="list-style-type: none"> <li>Push "VOICE" button.</li> <li>Check voltage between NAVI control unit terminal 30 or 31 and ground.</li> </ol>		
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  </div> <div style="text-align: left;"> <p><b>Voltage [V]:</b>                      Condition of VOICE button: Push.                      Approx. 5                      Condition of VOICE button: Do not push.                      0</p> </div> </div> <p style="text-align: right;">SEL648X</p> <p style="text-align: center;"><b>OK or NG</b></p>		
OK	▶	GO TO 4.
NG	▶	Repair or replace NAVI control unit.

4	CHECK VOICE SIGNAL CIRCUIT	
	<p>1. Turn ignition switch OFF.                      2. Disconnect NAVI control unit connector and AUDIO unit connector.                      3. Check continuity between NAVI control unit terminal 30 and AUDIO unit terminal 36.                      4. Check continuity between NAVI control unit terminal 31 and AUDIO unit terminal 34.</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="text-align: center; margin-right: 20px;">  </div> <div style="text-align: center; margin-right: 20px;"> <p>NAVI control unit connector (M118)</p>  </div> <div style="text-align: center; margin-right: 20px;"> <p>AUDIO unit connector (M139)</p>  </div> <div style="margin-left: 20px;"> <p><b>Does continuity exist?</b></p> </div> </div> <div style="text-align: center; margin-top: 20px;">  </div> <div style="text-align: right; margin-top: 20px;"> <p>SEL649X</p> </div>	
	<b>Yes or No</b>	
Yes	▶	Repair or replace audio system. Refer to "AUDIO", EL-170.
No	▶	Repair or replace harness or connector.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# NAVIGATION SYSTEM

*This Condition is Not Abnormal*

## This Condition is Not Abnormal

=NAEL0428

### EXAMPLE OF BASIC OPERATIONAL ERRORS

NAEL0428S01

Symptom	Possible cause	Repair order
No image is displayed.	Monitor brightness control is set to full dark.	Readjust monitor brightness.
Map does not appear on display.	Map CD is not inserted or inserted upside down.	Insert the map CD with the label facing up.
	Map mode is turned OFF.	Press the "MAP" button.
No guide tone is heard.	Voice guide adjustment OFF/Volume is set to the lowest or highest level.	Adjust the voice guide level.
Voice guide volume is too high or too low.		
Dark display/Slow image movement	Low vehicle interior temperature	Wait until vehicle interior temperature rises to appropriate level.
Small black or white dots appear on the screen.	Unique liquid crystal display phenomena	No problem
"Unable to read CD" message appears only during specified operation.	Map CD surface is tainted/CD surface is partially scratched.	Check map CD surface. If dirty, wipe clean with a soft cloth.
		If map CD surface is damaged, replace the CD.

#### Area place names are not displayed.

If area place names do not appear on the map display, these names may not be available. Use the BIRDVIEW<sup>®</sup> flat surface map display function. Display output may differ. Note the items related to BIRDVIEW<sup>®</sup> below.

- Priority is given to the display of place names in the direction of vehicle travel.
- Extended display of vehicle travel distance for both surfaces and steering angle (flat directional changes). This phenomenon disappears after the display image has been replaced by another one.
- The names of route and area might vary between the immediate front area and distance front area.
- Alphanumeric display characters are limited to maintain display simplicity and clarity. Display details may differ with time and place.
- Identical place and road names may appear on the display at more than one location.


# NAVIGATION SYSTEM

*This Condition is Not Abnormal (Cont'd)*

## EXAMPLE OF CURRENT VEHICLE POSITION MARKER ERROR

=NAEL0428S02


The navigation system reads the vehicle distance and steering angle data. Because the vehicle is moving, there will be an error in the current position indication. After the error appears, drive the vehicle for a short distance. Stop the vehicle. If the position marker does not return to its original position, perform "ADJUST CURRENT LOCATION" (EL-431).



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX



# NAVIGATION SYSTEM

*This Condition is Not Abnormal (Cont'd)*

	Possible cause	Drive condition	Service procedure
Area	Slippery road surface	On wet, icy, or gravel road where frequent wheel slippage occurs, distance calculations may be erroneous. The position marker may show the vehicle to be in inaccurate position.	
	Slanted area	Hilly areas where the road has banked curves. When the vehicle enters these banked curves, there may be an error in steering angle measurement. The position marker may show the vehicle to be in inaccurate position.	
Map data	Map display for a given road does not appear.   SEL699V	When the vehicle is driven on a newly constructed road that does not appear on the existing map. Map marking and calibration are not possible. The position marker may indicate inaccurate position in close proximity to the actual position. Subsequently, when the vehicle is driven on a road which is available as map data, the position marker may still indicate an inaccurate position.	If the position marker does not move to the correct position even after the vehicle has been driven approximately 10 km (6 miles), perform "ADJUST CURRENT LOCATION" (EL-431). If necessary, perform "SPEED CALIBRATION" (EL-429).
	The vehicle is driven on a road whose course has been altered (usually to improve the road or to eliminate some hazard).   SEL700V	When the map data shown on the display and the actual conditions are different. Map matching will not be possible. The position marker may indicate inaccurate position in close proximity to the actual position. If the vehicle is driven on the indicated road, further errors may occur.	
Vehicle	Use of tire chains (Stormy weather)	Tire chains will affect distance sensing. The position marker may indicate inaccurate position.	If the position marker does not move to the correct position even after the vehicle has been driven approximately 10 km (6 miles), perform "SPEED CALIBRATION" (EL-429). After removing the tire chains, sensing accuracy may recover by itself.

# NAVIGATION SYSTEM






*This Condition is Not Abnormal (Cont'd)*

	Possible cause	Drive condition	Service procedure
Operation	Driving immediately after starting engine.	The gyro (angular velocity sensor) needs about 15 seconds after the engine is started to precisely sense the angular velocity. Directional sensing errors will occur if the vehicle is moved immediately after starting the engine. The position marker may indicate inaccurate position.	Wait a few moments between starting the engine and actually driving the vehicle.
	Continuous driving for long distances (non-stop)	When the vehicle is driven continuously without stopping over a long distance, errors in directional sensing may occur. The position marker may indicate inaccurate position.	Stop the vehicle. Perform "SPEED CALIBRATION" (EL-429).
	Rough or violent driving	Wheel spinning (peeling out) or similar rough driving techniques can adversely affect sensing accuracy. The position marker may indicate inaccurate position.	If the position marker does not move to the correct position even after the vehicle has been driven approximately 10 km (6 miles), perform "ADJUST CURRENT LOCATION" (EL-431).
Positional calibration procedures	Positional calibration precision Within 1 mm (0.04 in)  SEL701V	If current vehicle location is roughly set, the system may be unable to locate the road that the vehicle is traveling on. (This is especially true in an area where there are many roads.)	Perform "ADJUST CURRENT LOCATION" (EL-431) within a precision standard of 1 mm (0.04 in) on the display. Note: During calibration, use the most detailed map possible.
	Position calibration direction  SEL702V	When calibrating the position, check the vehicle direction. If the vehicle direction is not correct, subsequent precision of current location will be affected.	Perform "ADJUST CURRENT LOCATION", refer to EL-431.

GI  
 MA  
 EM  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 TF  
 PD  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
**EL**  
 IDX


# NAVIGATION SYSTEM

*This Condition is Not Abnormal (Cont'd)*

Possible cause: —: Vehicle running    ---: Indication		Drive condition	Service procedure
Road shapes	<p>Y-intersection</p>  <p style="text-align: right;">SEL703V</p>	<p>In Y-intersections with a very gradual change in course, a directional sensing may be inaccurate. This may result in the position marker giving the wrong road indication.</p>	<p>If the position marker does not move to the correct position even after the vehicle has been driven approximately 10 km (6 miles), perform "Store place". If required, also perform "ADJUST CURRENT LOCATION" (EL-431).</p>
	<p>Spiral road</p>  <p style="text-align: right;">SEL704V</p>	<p>On loop bridges and similar structures which result in a large and continuous turn, turning angle may be sensed inaccurately. As a result, the position marker may separate from the route on the map.</p>	
	<p>Straight road</p>  <p style="text-align: right;">SEL705V</p>	<p>In long distance driving on a straight road or road with very gradual curves, map marking inaccuracies may occur. In such cases, the position marker may stray from the route being traveled during subsequent turns due to inaccurate distance calculation.</p>	
	<p>Winding road</p>  <p style="text-align: right;">SEL706V</p>	<p>Directional sensing precision errors may occur when traveling on winding roads. During map matching, the position marker may stray to an adjacent road having a similar shape. Subsequent position marker error may occur.</p>	
	<p>Grid-like road shape</p>  <p style="text-align: right;">SEL707V</p>	<p>Directional sensing and distance sensing, precision errors may occur because of many roads having a similar shape in the immediate area. During map matching, the position marker may stray to an adjacent road having a similar shape. Subsequent position marker error may occur.</p>	
	<p>Parallel roads</p>  <p style="text-align: right;">SEL708V</p>	<p>When driving on a parallel road, map matching errors may occur. Subsequent position marker error may also occur.</p>	

# NAVIGATION SYSTEM

This Condition is Not Abnormal (Cont'd)

	Possible cause: —: Vehicle running ---: Indication	Drive condition	Service procedure	
Location	<p>Parking lot or similar area</p>  <p>SEL709V</p>	<p>When the vehicle is driven in a parking lot or similar area, such as in an area not normally marked as a road on map, during map matching, the system may select nearby roads. This error may continue after the vehicle exits the parking area and begins to run on ordinary roads. Vehicle operation in a parking area may involve frequent turns and up and/or down operation. Directional sensing errors may occur leading to subsequent route and position mistakes.</p>		GI MA EM LC EC FE
	<p>Turntable</p>  <p>SEL710V</p>	<p>When the ignition switch is OFF (the usual situation when the vehicle is on a turntable), the navigation system receives no data from the gyro (angular velocity sensor). When the turntable rotates, no directional change is sensed. During subsequent vehicle operation, directional and route errors may occur.</p>		CL MT AT

## Position marker displays a completely different location

In circumstances such as those described below, GPS signal reception conditions may result in an erroneous position of the position marker. Perform "ADJUST CURRENT LOCATION" (EL-431).

### NOTE:

- When GPS satellite signal reception conditions are poor, the position of position marker may be erroneous. If correction is not made immediately, the position marker error will be compounded and a completely different location will be indicated. In an area where GPS satellite signal reception conditions are good, the system can be returned to normal operation.
- The vehicle is driven aboard a car ferry or is towed for some distance with the ignition switch OFF. Vehicle movement is not sensed. Current location calculations do not occur and current location data does not appear on the display screen. Use GPS to accurately determine actual vehicle position. The system can be returned to normal operation when the GPS satellite signal reception conditions are good.

## Position marker jumps

In circumstances such as those described below, the position marker may jump as a result of automatic current location corrections made by the system.

During map matching

- During map matching, the position marker may jump from one spot to another. In this case, it may be corrected to a wrong road or to an area where no road exist.

GPS location correcting

- Vehicle current location is sensed using the GPS data. Positional calibration is performed. The position marker continues to be in the wrong position. It may jump about from one area of the screen to another. In this case, it may be corrected to a wrong road or to an area where no road exist.

## Position marker indicates that the vehicle is in the middle of an ocean or large river

The navigation system does not distinguish between land and water surfaces. In some cases, a position marker error may cause the display to show the vehicle above a water surface.

## Position of position marker varies when the vehicle is repeatedly operated on the same road

Driving lane and steering wheel movement results in a variety of different positions of the position mark when traveling on the same road based on sensing results by the GPS antenna and gyro (angular velocity sensor). Slow locational correction using map matching

- The map matching function requires verification of local data. To make the map matching function, some distance needs to be driven.
- The map matching function may not provide accurate performance in an area where there are numerous parallel roads. Until the system judges the road characteristics, an incorrect position may be shown.

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# NAVIGATION SYSTEM

*This Condition is Not Abnormal (Cont'd)*

**GPS signal reception conditions are good. However, the position mark does not return to its proper position.**

- The system senses the vehicle location with an error of approximately 100 m (328 ft). Due to the limitation of precision, the position marker may be inaccurate even if the GPS signal reception condition is good.
- The navigation system uses GPS data to determine vehicle location. GPS data is compared with other locational sensing data during the map matching process. The system decides which data is more precise and uses that data.
- When the vehicle is stationary, GPS data cannot be used to make system corrections.

**Area designations on the map display and the BIRDVIEW® display differ.**

To prevent the display from becoming congested, alphanumeric information is abridged.

[No problem]

**Correct position of your vehicle is not displayed.**

Vehicle position changed after ignition key was turned to the OFF position (Vehicle is transported on car ferry, car train, or by some other means).

[Operate vehicle for short time under GPS receiving conditions.]

**The display does not change to night-time mode even though the light switch has been turned ON.**

Lights have been turned on. In "DISPLAY CHANGE" mode, night-time mode on display has been switched to day-time mode and still is.

[Turn lights on again. Set the display to night-time mode. Refer to EL-432.]

**Map does not scroll even though the position of your vehicle is changed.**

Present area does not appear on the display.

[Press the "MAP" switch.]

**Vehicle position marker does not appear.**

Present area does not appear on the display.

[Press the "MAP" switch.]

**The map surface precision display (GPS satellite marker) still remains gray.**

Vehicle is parked inside a building or in the shadow of a large building. This intercepts the GPS signal.

[Move the vehicle to a more open position.]

GPS signal is not received because objects are placed on the rear parcel shelf.

[Remove objects from the rear parcel shelf.]

GPS satellite position is bad.

[Wait until GPS satellite position improves.]

**Vehicle position precision is bad.**

The map surface precision display (GPS satellite marker) still remains gray.

[Refer to "The map surface precision display (GPS satellite marker) still remains gray" item (Symptoms)]

Vehicle speed and elapsed distance is calculated from the vehicle speed pulse. This pulse is dependent upon tire size. If tire chains are used on the vehicle, accuracy will be affected (pulse rate will be too fast or too slow). The same is true if the system installed to your vehicle is removed and installed on another vehicle.

[Drive the vehicle at a speed higher than 30 km/h (19 MPH) for approximately 30 minutes. Automatic readjustment should occur. If it does not (remains too fast or too slow), distance calibration is required. Or, drive the vehicle for a short distance. Perform "SPEED CALIBRATION" (EL-429). After removing the tire chains, sensing accuracy may recover by itself.]

Bad map data or system defect (same error consistently occurs in the same area)

## ROUTE SEARCH/ROUTE GUIDE

NAEL0428S03

- If the present location or the destination location is displayed in the avoid area, it is not possible to search routes.
- If the avoid area is set to wide range area, it may not be possible to find appropriate routes or search for alternate routes.
- The automatic re-route calculates a return to the original route. Because of this, it may not be possible to search appropriate new routes. If you deviate from the original route and wish to select an appropriate new route, touch "Route Calculation".
- The automatic re-route function may sometimes require considerable time.
- Displayed route number and directional information at a highway junction may differ from the information posted on the actual road signs.
- Displayed street name information at a highway exit may differ from the information posted on the actual road signs.
- Street name information displayed on the enlarged intersection map may differ from the information posted on the actual road signs.

# NAVIGATION SYSTEM

*This Condition is Not Abnormal (Cont'd)*

- The enlarged intersection map may display an “Unknown Street” message at some street intersections.
- Because of road configuration, etc. the guide may finish early. If this occurs, follow the marker to reach your destination.
- Destination area side information (left side and right side) may differ from actual conditions because of data error.

## Unable to Set Destination, Way Point, and/or Menu Items

NAEL0428S0301

Symptom	Possible cause	Repair order
Unable to search way points in re-search mode	A way point already crossed or determined to have been crossed.	If you desire to pass through a way point for a second time, reperform route edit.
Turn list is not displayed.	Route search does not occur.	Set designation areas and perform route search.
	Car marker does not appear on recommended route.	Drive on the recommended route.
	Route guide is canceled.	Turn the route guide ON. (Push “VOICE” switch.)
Automatic search does not function.	Vehicle is not running on search object route (road indicated by orange, brown or red line).	Drive the vehicle on the search object route or perform a manual route search. Note that all routes will be re-searched at this time.
Unable to select detour route.	Vehicle is not running on recommended route.	Use the “RE-ROUTE” mode to search again or return to the recommended route.
Detour route search results are identical to previous search.	All possible conditions were considered, but results are the same.	This is not abnormal.
Unable to set a way point.	More than five way points have been previously set (and not cleared).	More than five way points cannot be specified at the same time. Break down into smaller segments and perform search.
Unable to select starting point during route edit.	Starting point will normally be your present location during route edit.	This is not abnormal.
Cannot select certain menu items.	While vehicle is running.	Park the vehicle in a safe area and perform operation.

## Voice Guide Information

NAEL0428S0302

Symptom	Possible cause	Repair order
Voice guide does not function.	Voice guide is only available at certain intersections (marked with ♀). In some cases, the guide is not available even when the vehicle makes a turn.	This is not abnormal.
	Vehicle is not running on recommended route.	Return to recommended route or reperform route search.
	Voice guide is OFF.	Set voice guide to the ON position.
	Route guide is canceled.	Turn the route guide ON. (Push “VOICE” switch.)
The guide content does not correspond to actual conditions.	The content of the voice guide may vary depending on the type of junction.	Operate vehicle following the traffic rules and regulation.

## Route Search Information

NAEL0428S0303

Symptom	Possible cause	Repair order
Proceeding in desired direction. However, route search in desired direction does not function.	Unable to find appropriate route in the desired direction.	This is not abnormal.

# NAVIGATION SYSTEM

*This Condition is Not Abnormal (Cont'd)*

Symptom	Possible cause	Repair order
No route is displayed.	No object route is searched near destination area.	Adjust position to wide road (brown) near destination area. In an area where traffic direction is displayed separately, pay close attention to the direction of travel. Set the destination area and the way point over the road.
	Starting point and destination areas are very near.	Move destination areas away from starting point on the screen.
Recommended route which has been passed disappears from the display.	The recommended route is divided into individual control segments. When way point 1 is passed, the data from the starting point to the way point 1 is erased.	This is not abnormal.
Search recommends roundabout route.	There may be special conditions for roads near the starting point and destination area (one-way traffic, etc.). A roundabout route may be displayed.	Slightly change starting point and destination area settings.
Landmark display does not show actual conditions.	Mistaken or missing map data may result in erroneous display.	Change map CD.
Recommended route drawn slightly away from starting point, way points, and destination area.	Course search data may not exist for closely positioned starting point, way points, and destination area shown on the map. Route guide starting point, way point, and destination point may be separated.	Set the destination area to the general route (indicated by a thick brown line). However, even if the selected route is a major one, appropriate route search data may not be available.

## LOCATION OF CAR MARKER

NAEL0428S04

- If the vehicle has been parked in a multi-level parking facility or underground parking facility, the car marker position may be inaccurate immediately after exiting the parking facility.
- The GPS accuracy is within  $\pm 100$  m (300 ft). Even when receiving conditions are excellent, further positional correction may not occur.

## STREET INDICATION

NAEL0428S05

- Street names displayed on the map may differ from the actual street names.
- An "Unknown Street" message may appear on the map in place of street name information.

## RESEARCH

NAEL0428S06

- Position may be searched by house number. However, the displayed position and street may differ from the actual position and street.
- When position is searched using POI, the displayed position may differ from the actual position.
- Some data may not be available for new buildings and other structures in a map.

## GPS ANTENNA

NAEL0428S07

- Do not place metal objects above the GPS antenna mounted on the rear parcel shelf. This will cause interference with signal reception.
- Do not place mobile telephones or vehicle radio transceivers in close proximity to the GPS antenna mounted on the rear parcel shelf. This may cause interference with signal reception.

## Program Loading

GI  
NAEL0429

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



\* Program loading progress is shown on the bar graph at the center of the screen.

Note: Load the program only after the engine has been started.

SEL612X

## Initialization


This procedure is for initializing the current location. Perform "Initialize Location" when the vehicle is transported a long distance by trailer, etc. NAEL0430

Map with grey background appears and the vehicle location cannot be adjusted by scrolling the display when the vehicle location in the memory is out of the area of the inserted map data.

Perform "Initialize Location" when this occurs.


### NOTE:

- Only initialize the system when the display & NAVI control unit is replaced. If the system is initialized in other cases, it may cause inaccurate positioning of the position marker for a while.
- Initialize the system outside for receiving the radio wave from the GPS satellite.




## HOW TO PERFORM


1. Switch the navigation system mode to self-diagnosis by pushing both "MAP" and "D/N" switches at the same time for more than 5 seconds. NAEL0430S01



2. Touch "Confirmation/ adjustment".




3. Touch "Initialize Location". Then the previous screen is displayed.



SEL584X

4. Push "Previous" switch.




SEL598X

5. Push the "MAP" switch.  
6. Touch "Setting".




SEL599X

7. Touch "System Setting".



SEL600X

8. Touch "GPS Information".



SEL146W

9. More than one GPS satellite icon turns green. (It may take 1 to 15 minutes.)

**NOTE:**


Drive the vehicle for a while\* in order to change the receiving condition of the radio wave from the GPS satellite if the GPS icon does not turn green.

\* The driving distance which is necessary depends on the receiving condition of the radio wave from the GPS satellite.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

## NAVIGATION SYSTEM

Initialization (Cont'd)



10. Push "MAP" switch and check the following.
  - Confirm that the GPS icon on the map turns green.
  - Then the position marker should show the current location.
  - Position marker rotates corresponding to the movement of the vehicle.
11. Initialization is completed.




# ELECTRICAL UNITS LOCATION

Engine Compartment

## Engine Compartment

NAEL0431

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX




MEL912N

# ELECTRICAL UNITS LOCATION


Passenger Compartment

## Passenger Compartment

NAEL0432




### A Instrument panel LH side




MEL9180

# ELECTRICAL UNITS LOCATION

Passenger Compartment (Cont'd)



**K** Behind the luggage room trim LH side



GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC

EL

MEL4170


IDX

# HARNESS LAYOUT

How to Read Harness Layout

## How to Read Harness Layout

NAEL0433



The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness

### TO USE THE GRID REFERENCE

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

NAEL0433S01

### CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.

NAEL0433S02


Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> <li>• Cavity: Less than 4</li> <li>• Relay connector</li> </ul>				
<ul style="list-style-type: none"> <li>• Cavity: From 5 to 8</li> </ul>				
<ul style="list-style-type: none"> <li>• Cavity: More than 9</li> </ul>	—	—		
<ul style="list-style-type: none"> <li>• Ground terminal etc.</li> </ul>	—			

# HARNESS LAYOUT

Outline

## Outline

NAEL0434



MEL072M


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HARNESS LAYOUT

Main Harness

## Main Harness

NAEL0435



MEL4180





# HARNESS LAYOUT

Main Harness (Cont'd)

B4★	M1	SMJ	: To	E1	M47	W/20	: To	Z1
B4★	M2	SMJ	: To	B1	M48	W/10	: Audio unit	
B4	M3	BR/24	: ASCD control unit	G3	M49	W/6	: Audio unit	
A3	M4	—	: Body ground	D1	M51	W/8	: Combination meter	
B4	M5	BR/16	: To	D3	M52	L/4	: Heated seat switch LH	
A3	M6	W/10	: To	D4	M53	W/4	: Heated seat switch RH	
A3	M7	B/2	: Diode	D4	M55	W/3	: Air mix door motor (With auto A/C)	
B2	M8	BR/2	: Tweeter LH	F4	M56	B/2	: Cigarette lighter socket	
C4	M9	W/16	: Data link connector	F4	M57	W/2	: Cigarette lighter illumination	
C3★	M10	SMJ	: Fuse block (J/B)	E1	M58	B/2	: Sunload sensor (With auto A/C)	
B4	M12	GY/3	: Diode	G2	M59	W/8	: Intake door motor (With auto A/C)	
C4	M14	L/2	: ASCD clutch switch (With M/T)	G2	M60	W/4	: Fan control amp. (With auto A/C)	
B3	M15	B/3	: Combination flasher unit	G1	M61	BR/4	: Fan resistor	
C4	M17	GY/6	: Memory seat cancel switch	F1	M62	W/6	: To	R1
C4	M19	W/3	: Illumination control switch	F1	M63	W/6	: To	R2
C3	M20	W/2	: Security indicator lamp	F1	M64	BR/2	: Tweeter RH	
B2	M23	L/4	: Power window relay	G2	M66	—	: Body ground	
C1★	M24	W/24	: Combination meter	F2	M67	BR/16	: To	D33
D1★	M25	BR/20	: Combination meter	G2	M68	W/6	: To	D34
D1★	M26	BR/24	: Combination meter	F3	M69	W/3	: Power antenna	
C3	M28	L/2	: Clutch interlock switch (With M/T)	F3★	M70	W/20	: To	B50
C3	M29	L/2	: ASCD brake switch	F3★	M71	W/24	: To	B51
E3	M30	W/2	: Glove box lamp	F3★	M72	W/16	: To	B52
C3	M31	B/2	: Stop lamp switch	G3	M73	W/2	: Blower motor	
D3★	M32	BR/24	: To	E1	M75	W/3	: Auto light sensor	
D3★	M33	GY/16	: To	C5	M77	—	: Body ground	
D3	M34	W/2	: In-vehicle sensor (With auto A/C)	C5	M78	GY/6	: Front wiper motor	
D2	M35	W/8	: Hazard switch	A3	M81	B/2	: Fuse block (J/B)	
D3	M36	W/6	: Rear window defogger switch	D1	M90	B/2	: Diode (With manual A/C)	
C3	M37	B/2	: Diode	B3★	M91	W/12	: Fuse block (J/B)	
D4	M38	W/3	: Mode door motor (With auto A/C)	D3	M92	B/2	: CD player	
D2	M40	W/4	: Clock	D3	M93	W/4	: CD player	
D4	M41	W/8	: Steering wheel receiver control switch					
E2	M42	W/4	: Recirculation switch					
F1	M43	W/6	: Fan switch					
F2	M44	W/3	: A/C switch (With manual A/C)					
E1	M45	W/3	: A/C switch illumination (With manual A/C)					

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes.

**Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC, AT and TF sections.**



MEL4190


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HARNESS LAYOUT

Engine Room Harness

## Engine Room Harness

NAEL0436



MEL917N




# HARNESS LAYOUT

Engine Control Harness

## Engine Control Harness

NAEL0437



★ : Be sure to connect and lock the connectors securely after repair work.  
Failure to do so may cause the ECM to have diagnostic trouble codes.

Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC, AT and TF sections.

MEL317N

# HARNES LAYOUT

Engine Control Harness (Cont'd)

C1★	(F1)	G/4	: Heated oxygen sensor 2 (BANK 1)	E2★	(F102)	GY/2	: Knock sensor
D1★	(F2)	SB/3	: Heated oxygen sensor 1 (BANK 1)	B3★	(F103)	GY/2	: Injector No. 1
E5★	(F3)	G/4	: Heated oxygen sensor 2 (BANK 2)	C4★	(F104)	GY/2	: Injector No. 2
F5★	(F4)	SB/3	: Heated oxygen sensor 1 (BANK 2)	B3★	(F105)	GY/2	: Injector No. 3
E5★	(F5)	L/8	: To (F100)	C4★	(F106)	GY/2	: Injector No. 4
E5★	(F6)	G/8	: To (F101)	E2★	(F107)	GY/2	: Injector No. 5
F3★	(F8)	BR/3	: Throttle position sensor	E1★	(F108)	GY/2	: Injector No. 6
G3★	(F9)	GY/3	: Throttle position switch	F1★	(F109)	L/6	: IACV-AAC valve
G5★	(F10)	GY/5	: Mass air flow sensor	D1★	(F112)	SB/3	: To (F28)
E5★	(F16)	GY/2	: To (F115)	F4★	(F113)	L/2	: EVAP canister purge volume control solenoid valve
E5★	(F19)	SB/2	: To (F116)	E1★	(F114)	GY/2	: Engine coolant temperature sensor
D5★	(F20)	—	: Engine ground	G5★	(F115)	GY/2	: To (F16)
G1★	(F22)	GY/16	: To (M33)	F5★	(F116)	SB/2	: To (F19)
G1★	(F23)	BR/24	: To (M32)	D2	(F117)	B/1	: Thermal transmitter
F2★	(F24)	SMJ	: ECM	C4★	(F118)	GY/3	: Ignition coil No.2
D5★	(F25)	—	: Engine ground	F1★	(F119)	GY/3	: Ignition coil No.4
G2★	(F27)	W/18	: To (M94)	G3★	(F120)	GY/3	: Ignition coil No.6
D1★	(F28)	SB/3	: To (F112)	D5	(F202)	B/1	: Compressor (Air conditioner)
C3★	(F29)	W/2	: Condenser				
B2★	(F30)	GY/3	: Ignition coil No.1				
C2★	(F31)	GY/3	: Ignition coil No.3				
C2★	(F32)	GY/3	: Ignition coil No.5				
C5★	(F36)	GY/2	: Camshaft position sensor (PHASE)				
C4★	(F37)	B/3	: Intake valve timing control position sensor LH				
B3★	(F38)	B/3	: Intake valve timing control position sensor RH				
G2★	(F39)	G/2	: Intake valve timing control solenoid valve LH				
B2★	(F40)	SB/2	: Intake valve timing control solenoid valve RH				
C4★	(F41)	G/2	: Swirl control valve control solenoid valve				
C3★	(F42)	BR/2	: VIAS control solenoid valve (With A/T)				
D4★	(F43)	—	: Engine ground				
D4★	(F44)	—	: Engine ground				
F4★	(F100)	L/8	: To (F5)				
G5★	(F101)	G/8	: To (F6)				

★ : Be sure to connect and lock the connectors securely after repair work.  
Failure to do so may cause the ECM to have diagnostic trouble codes.

★ : Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC, AT and TF sections.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC

EL

MEL7050


IDX

# HARNES LAYOUT

Body Harness LH

## Body Harness LH

NAEL0438




★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC, AT and TF sections.

- ★ (B1) SMJ : To (M2)
- (B3) : Parking brake switch
- (B4) W/2 : Power socket
- (B5) GY/3 : Front heated seat LH (Via sub-harness)
- (B6) W/3 : Seat belt buckle switch
- (B7) W/2 : Power seat LH
- (B8) BR/2 : Rear wheel sensor LH
- (B9) B/3 : Front door switch LH
- (B10) W/10 : To (D50)
- (B11) — : Body ground
- (B12) GY/4 : Fuel level sensor unit
- (B13) GY/2 : Fuel pump
- (B14) W/12 : Rear wiper amp.
- (B16) W/16 : Seat control unit LH (Via sub-harness)
- (B18) BR/1 : Rear door switch LH
- (B22) — : Body ground
- (B23) W/12 : To (D100)
- (B24) W/6 : To (D101)
- (B25) BR/6 : To (D102)
- (B26) W/6 : Rear combination lamp LH
- (B27) — : Diode
- (B28) — : Diode
- ★ (B43) GY/8 : To (B101)
- (B46) W/26 : Rear speaker amp. (With BOSE system)
- (B47) W/4 : Audio amp. relay (With BOSE system)
- ★ (B101) GY/8 : To (B43)
- ★ (B102) GY/3 : EVAP control system pressure sensor
- ★ (B103) B/2 : EVAP canister vent control valve
- ★ (B104) G/2 : Vacuum cut valve bypass valve
- (B106) Y/2 : Seat belt pre-tensioner LH
- (B107) Y/2 : Satellite sensor LH
- (B109) Y/2 : Side air bag module LH
- (B112) W/4 : Door mirror defogger relay
- (B115) W/6 : Aux box (With rear TV)
- ★ (B151) GY/2 : To (B152)
- ★ (B152) GY/2 : To (B151)
- (B153) Y/12 : Air bag diagnosis sensor unit

MEL4200

## Body Harness RH



- (B131) B/2 : Rear power socket
- (B300) GY/2 : To (B72)
- (B301) B/3 : Tire carrier switch

- (B50) W/20 : To (M70)
- (B51) W/24 : To (M71)
- (B52) W/16 : To (M72)
- (B55) - : Body ground
- (B56) GY/3 : Heated seat RH (Via sub-harness)
- (B57) W/2 : Power seat RH
- (B58) GY/5 : G sensor (For 4WD model with ABS)
- (B59) GY/8 : A/T device (With A/T) (Via sub-harness)
- (B61) B/6 : To (B200) (With M/T)
- (B62) B/4 : To (B201) (With A/T and part-time 4-wheel drive)
- (B64) BR/8 : Terminal cord assembly
- (B65) GY/8 : Park/neutral position switch (With A/T)
- (B66) GY/2 : Park/neutral position switch
- (B67) GY/3 : Rear revolution sensor
- (B68) B/3 : Front door switch RH
- (B69) GY/2 : Rear wheel sensor RH
- (B70) W/10 : To (D70)
- (B71) BR/1 : Rear door switch RH
- (B72) GY/2 : To (B300)
- (B74) W/6 : Rear combination lamp RH
- (B75) - : Body ground
- (B76) W/3 : Ashtray illumination
- (B77) W/12 : To (M99)
- (B78) GY/8 : To (B206)
- (B79) B/4 : To (B208)
- (B80) B/8 : To (B207)
- (B82) GY/6 : To (B251)
- (B83) Y/2 : Seat belt pre-tensioner RH
- (B87) BR/4 : Turbine revolution sensor (With A/T)
- (B88) GY/20 : To (M100)
- (B89) W/2 : Diode
- (B126) Y/2 : Side air bag module RH
- (B128) Y/2 : Satellite sensor RH
- (B129) Y/12 : Air bag diagnosis sensor unit

★ : Be sure to connect and lock the connectors securely after repair work.  
 Failure to do so may cause the ECM to have diagnostic trouble codes.  
 Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC, AT and TF sections.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HARNESS LAYOUT

Back Door Harness

## Back Door Harness

NAEL0440



- D100 W/12 : To B23
  - ★ D101 W/6 : To B24
  - D102 BR/6 : To B25
  - D103 W/3 : Luggage room lamp
  - ★ D105 W/16 : To D205
  - D106 W/4 : To D206
  - D107 W/4 : To D207
  - D108 W/2 : To D208
  - D109 W/1 : To D209
  - D201 W/2 : Diode
  - D202 W/6 : Back door key cylinder switch
  - BR/2 : License plate lamp (Without spare tire carrier)
  - D203 BR/2 : License plate lamp (With spare tire carrier)
  - D205 W/16 : To D105
  - ★ D206 W/4 : To D106
  - D207 W/4 : Back door lock actuator
  - D208 W/2 : Back door lock switch
  - D209 W/2 : Glass hatch switch
  - ★ D210 — : Body ground
  - D212 W/8 : Rear wiper motor
  - D300 W/2 : To D107
  - D301 W/1 : To D108
  - D302 W/3 : High-mounted stop lamp
  - D303 B/1 : Rear window defogger
  - D304 B/1 : Rear window defogger
  - D305 — : Body ground
  - Diode D109
- Luggage room lamp → Rear door switch LH  
Luggage room lamp → Rear door switch RH  
Luggage room lamp → Back door switch
- ★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC, AT and TF sections.


MEL241M

# HARNESS LAYOUT

Engine and Transmission Harness

## Engine and Transmission Harness

NAEL0441



MEL4790


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# HARNESS LAYOUT

Room Lamp Harness

## Room Lamp Harness

NAEL0442




MEL446P

# HARNESS LAYOUT

Air Bag Harness

## Air Bag Harness

NAEL0443



GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

**EL**

IDX

# HARNESS LAYOUT


Front Door Harness

## Front Door Harness

NAEL0444


### LH side

- D1** W/8 : Door mirror LH
- D3** BR/16 : To **M5**
- D4** W/10 : To **M6**
- D5** GY/6 : Front power window regulator LH
- D6** W/16 : Power window main switch
- D7** GY/4 : Front door lock actuator LH
- D9** BR/3 : Front door key cylinder switch LH
- D10** BR/2 : Front door speaker LH  
(Without BOSE system)
- D12** W/6 : Front door speaker LH  
(With BOSE system)
- D13** GY/12 : To **M112**
- D15** W/3 : Power window main switch
- D16** W/8 : Seat memory switch



### RH side

- D31** W/8 : Door mirror RH
- D33** BR/16 : To **M67**
- D34** W/6 : To **M68**
- D35** GY/6 : Front power window regulator RH
- D36** W/12 : Front power window switch RH
- D37** GY/4 : Front door lock actuator RH
- D40** BR/2 : Front door speaker RH (Without BOSE system)
- D41** BR/6 : To **M101** (With BOSE system)
- D42** W/6 : Front door speaker RH (With BOSE system)
- D43** W/8 : Front power window switch RH



MEL4820


# HARNESS LAYOUT

Rear Door Harness

## Rear Door Harness


NAEL0445

LH side



- (D50) W/10 : To (B10)
- (D51) B/2 : Rear power window regulator LH
- (D52) W/8 : Rear power window switch LH
- (D53) BR/2 : Rear door speaker LH
- (D54) GY/4 : Rear door lock actuator LH

RH side



- (D70) W/10 : To (B70)
- (D71) B/2 : Rear power window regulator RH
- (D72) W/8 : Rear power window switch RH
- (D73) BR/2 : Rear door speaker RH
- (D74) GY/4 : Rear door lock actuator RH

MEL261M

EL-475

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
TF  
PD  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

**BULB SPECIFICATIONS***Headlamp***Headlamp**

NAEL0446S01

Item	Wattage W
High/Low (Semi-sealed beam)	60/55 (HB2)

**Exterior Lamp**

NAEL0446S02

Item	Wattage W	
Front fog lamp	55	
Front turn signal lamp	21	
Parking lamp	5	
Rear combination lamp	Turn signal lamp	27
	Stop/Tail lamp	21/5
	Back-up lamp	18
License plate lamp	5	
High-mounted stop lamp	5	

**Interior Lamp**

NAEL0446S03

Item	Wattage W
Interior lamp	10
Spot lamp	8
Luggage room lamp	10

# WIRING DIAGRAM CODES (CELL CODES)

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
1STSIG	AT	A/T 1ST Signal
2NDSIG	AT	A/T 2ND Signal
3RDSIG	AT	A/T 3RD Signal
4THSIG	AT	A/T 4TH Signal
A/C, A	HA	Auto Air Conditioner
AAC/V	EC	IACV-AAC Valve
ABS	BR	Anti-lock Brake System
AP/SEN	EC	Absolute Pressure Sensor
ASCD	EL	Automatic Speed Control Device
AT/C	EC	A/T Control
ATDIAG	EC	A/T Diagnosis Communication Line
AUDIO	EL	Audio
AUT/DP	EL	Automatic Drive Positioner
BA/FTS	AT	A/T Fluid Temperature Sensor and TCM Power Supply
BACK/L	EL	Back-up Lamp
BYPS/V	EC	Vacuum Cut Valve Bypass Valve
CHARGE	SC	Charging System
CHIME	EL	Warning Chime
CIGAR	EL	Cigarette Lighter
CLOCK	EL	Clock
COMPAS	EL	Compass and Thermometer
D/LOCK	EL	Power Door Lock
DEF	EL	Rear Window Defogger
DTRL	EL	Headlamp — With Daytime Light System —
ECTS	EC	Engine Coolant Temperature Sensor
ENGSS	AT	Engine Speed Signal
F/FOG	EL	Front Fog Lamp
F/PUMP	EC	Fuel Pump Control
FICD	EC	IACV-FICD Solenoid Valve
FLS1	EC	Fuel Gauge
FLS2	EC	Fuel Gauge
FLS3	EC	Fuel Gauge

Code	Section	Wiring Diagram Name
FTS	AT	A/T Fluid Temperature Sensor
FUELLH	EC	Fuel Injection System Function (Left Bank)
FUELRH	EC	Fuel Injection System Function (Right Bank)
H/LAMP	EL	Headlamp
HORN	EL	Horn
HSEAT	EL	Heated Seat
IATS	EC	Intake Air Temperature Sensor
IGN/SG	EC	Ignition Signal
ILL	EL	Illumination
INJECT	EC	Injector
INT/L	EL	Interior, Spot, Vanity Mirror, and Luggage Room Lamps
IVC-L	EC	Intake Valve Timing Control Solenoid Valve LH
IVC-R	EC	Intake Valve Timing Control Solenoid Valve RH
IVCS-L	EC	Intake Valve Timing Control Position Sensor LH
IVCS-R	EC	Intake Valve Timing Control Position Sensor RH
KS	EC	Knock Sensor
LAN	AT	A/T Communication Line
LOAD	EC	Electrical Load Signal
LPSV	AT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
MAIN	AT	Main Power Supply and Ground Circuit
MAIN	EC	Main Power Supply and Ground Circuit
METER	EL	Speedometer, Tachometer, Temp., Oil, and Fuel Gauges
MIL/DL	EC	MIL and Data Link Connectors
MIRROR	EL	Door Mirror
KEYLES	EL	Remote Keyless Entry System
NATS	EL	NVIS (NISSAN Vehicle Immobilizer System)
NAVI	EL	Navigation System
NONDTC	AT	Non-detectable Items
O2H1B1	EC	Heated Oxygen Sensor 1 Heater (Bank 1)

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

## WIRING DIAGRAM CODES (CELL CODES)

Code	Section	Wiring Diagram Name
O2H1B2	EC	Heated Oxygen Sensor 1 Heater (Bank 2)
O2H2B1	EC	Heated Oxygen Sensor 2 Heater (Bank 1)
O2H2B2	EC	Heated Oxygen Sensor 2 Heater (Bank 2)
O2S1B1	EC	Heated Oxygen Sensor 1 (Bank 1)
O2S1B2	EC	Heated Oxygen Sensor 1 (Bank 2)
O2S2B1	EC	Heated Oxygen Sensor 2 (Bank 1)
O2S2B2	EC	Heated Oxygen Sensor 2 (Bank 2)
OVRCSV	AT	Overrun Clutch Solenoid Valve
P/ANT	EL	Power Antenna
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHASE	EC	Camshaft Position Sensor (PHASE)
PNP/SW	EC	Park/Neutral Position Switch
PNP/SW	AT	Park/Neutral Position Switch
POS	EC	Crankshaft Position Sensor (CKPS) (POS)
POWER	EL	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor
PST/SW	EC	Power Steering Oil Pressure Switch
REF	EC	Crankshaft Position Sensor (CKPS) (REF)
REMOTE	EL	Audio (Remote Control Switch)
RP/SEN	EC	Refrigerant Pressure
S/SIG	EC	Start Signal
S/VCSW	EC	Swirl Control Valve Control Vacuum Check Switch
SEAT	EL	Power Seat
SHIFT	AT	A/T Shift Lock System
SROOF	EL	Sunroof
SRS	RS	Supplemental Restraint System
SSV/A	AT	Shift Solenoid Valve A
SSV/B	AT	Shift Solenoid Valve B
START	SC	Starting System
STOP/L	EL	Stop lamp

Code	Section	Wiring Diagram Name
SWL/V	EC	Swirl Control Valve Control Solenoid Valve
TAIL/L	EL	Parking, License and Tail Lamps
TCCSIG	AT	A/T TCC Signal (Lock up)
TCV	AT	Torque Converter Clutch Solenoid Valve
T/F	TF	Transfer
FTTS	EC	Fuel Tank Temperature Sensor
TP/SW	EC	Throttle Position Switch
TPS	AT	Throttle Position Sensor
TPS	EC	Throttle Position Sensor
TRNSCV	EL	Homelink Universal Transceiver
TRSA/T	AT	Turbine Revolution Sensor
TURN	EL	Turn Signal and Hazard Warning Lamps
VEHSEC	EL	Vehicle Security System
VIAS/V	EC	Variable Induction Air Control System
VSS	EC	Vehicle Speed Sensor
VSSA/T	AT	Vehicle Speed Sensor A/T (Revolution Sensor)
VSSMTR	AT	Vehicle Speed Sensor MTR
WARN	EL	Warning Lamps
WINDOW	EL	Power Window
WIP/R	EL	Rear Wiper and Washer
WIPER	EL	Front Wiper and Washer