

LT  
**SECTION**  
**LIGHTING SYSTEM**

A  
B  
C  
D  
E

**CONTENTS**

<p><b>PRECAUTIONS</b> ..... 4</p> <p style="padding-left: 20px;">Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ..... 4</p> <p style="padding-left: 20px;">General precautions for service operations ..... 5</p> <p style="padding-left: 20px;">Wiring Diagrams and Trouble Diagnosis ..... 5</p> <p><b>HEADLAMP (FOR USA)</b> ..... 6</p> <p style="padding-left: 20px;">Component Parts and Harness Connector Location... 6</p> <p style="padding-left: 20px;">System Description ..... 6</p> <p style="padding-left: 40px;">OUTLINE ..... 6</p> <p style="padding-left: 40px;">BATTERY SAVER CONTROL ..... 7</p> <p style="padding-left: 40px;">AUTO LIGHT OPERATION ..... 7</p> <p style="padding-left: 40px;">VEHICLE SECURITY SYSTEM (PANIC ALARM)... 7</p> <p style="padding-left: 20px;">CAN Communication System Description ..... 7</p> <p style="padding-left: 20px;">Wiring Diagram — H/LAMP — ..... 8</p> <p style="padding-left: 20px;">Terminals and Reference Values for BCM ..... 10</p> <p style="padding-left: 20px;">Terminals and Reference Values for IPDM E/R ..... 11</p> <p style="padding-left: 20px;">How to Proceed With Trouble Diagnosis ..... 11</p> <p style="padding-left: 20px;">Preliminary Check ..... 12</p> <p style="padding-left: 40px;">CHECK POWER SUPPLY AND GROUND CIRCUIT ..... 12</p> <p style="padding-left: 20px;">CONSULT-II Function (BCM) ..... 14</p> <p style="padding-left: 40px;">CONSULT-II OPERATION ..... 14</p> <p style="padding-left: 40px;">WORK SUPPORT ..... 15</p> <p style="padding-left: 40px;">DATA MONITOR ..... 15</p> <p style="padding-left: 40px;">ACTIVE TEST ..... 16</p> <p style="padding-left: 40px;">SELF-DIAGNOSTIC RESULTS ..... 16</p> <p style="padding-left: 20px;">CONSULT-II Function (IPDM E/R) ..... 17</p> <p style="padding-left: 40px;">CONSULT-II OPERATION ..... 17</p> <p style="padding-left: 40px;">DATA MONITOR ..... 18</p> <p style="padding-left: 40px;">ACTIVE TEST ..... 18</p> <p style="padding-left: 20px;">Headlamp HI Does Not Illuminate (Both Sides) ... 19</p> <p style="padding-left: 20px;">Headlamp HI Does Not Illuminate (One Side) ..... 21</p> <p style="padding-left: 20px;">High-Beam Indicator Lamp Does Not Illuminate ... 22</p> <p style="padding-left: 20px;">Headlamp LO Does Not Illuminate (Both Sides) ... 22</p> <p style="padding-left: 20px;">Headlamp LO Does Not Illuminate (One Side) ..... 24</p> <p style="padding-left: 20px;">Headlamps Do Not Turn OFF ..... 25</p> <p style="padding-left: 20px;">Aiming Adjustment ..... 26</p> <p style="padding-left: 40px;">LOW BEAM AND HIGH BEAM ..... 26</p> <p style="padding-left: 20px;">Bulb Replacement ..... 27</p>	<p style="padding-left: 20px;">HEADLAMP (OUTER SIDE), FOR LOW BEAM.. 27</p> <p style="padding-left: 20px;">HEADLAMP (INNER SIDE), FOR HIGH BEAM.. 27</p> <p style="padding-left: 20px;">FRONT TURN SIGNAL/PARKING LAMP ..... 27</p> <p style="padding-left: 20px;">Removal and Installation ..... 27</p> <p style="padding-left: 40px;">REMOVAL ..... 27</p> <p style="padding-left: 40px;">INSTALLATION ..... 28</p> <p style="padding-left: 20px;">Disassembly and Assembly ..... 29</p> <p style="padding-left: 40px;">DISASSEMBLY ..... 29</p> <p><b>HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -</b> ..... <b>30</b></p> <p style="padding-left: 20px;">Component Parts and Harness Connector Location.. 30</p> <p style="padding-left: 20px;">System Description ..... 30</p> <p style="padding-left: 40px;">HEADLAMP OPERATION ..... 31</p> <p style="padding-left: 40px;">BATTERY SAVER CONTROL ..... 32</p> <p style="padding-left: 40px;">AUTO LIGHT OPERATION ..... 32</p> <p style="padding-left: 40px;">DAYTIME LIGHT OPERATION ..... 32</p> <p style="padding-left: 40px;">OPERATION ..... 33</p> <p style="padding-left: 20px;">CAN Communication System Description ..... 33</p> <p style="padding-left: 20px;">Schematic ..... 34</p> <p style="padding-left: 20px;">Wiring Diagram — DTRL — ..... 35</p> <p style="padding-left: 20px;">Trouble Diagnoses ..... 38</p> <p style="padding-left: 40px;">DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE ..... 38</p> <p style="padding-left: 20px;">Aiming Adjustment ..... 39</p> <p style="padding-left: 20px;">Bulb Replacement ..... 39</p> <p style="padding-left: 20px;">Removal and Installation For Headlamp ..... 39</p> <p style="padding-left: 20px;">Disassembly and Assembly For Headlamp ..... 39</p> <p style="padding-left: 20px;">Removal and Installation For Daytime Light Control Unit ..... 39</p> <p style="padding-left: 40px;">REMOVAL ..... 39</p> <p style="padding-left: 40px;">INSTALLATION ..... 39</p> <p style="padding-left: 20px;">Removal and Installation For Daytime Light Relay.. 39</p> <p style="padding-left: 40px;">REMOVAL ..... 39</p> <p style="padding-left: 40px;">INSTALLATION ..... 39</p> <p><b>AUTO LIGHT SYSTEM</b> ..... <b>40</b></p> <p style="padding-left: 20px;">Component Parts and Harness Connector Location.. 40</p> <p style="padding-left: 20px;">System Description ..... 40</p> <p style="padding-left: 40px;">OUTLINE ..... 40</p> <p style="padding-left: 40px;">COMBINATION SWITCH READING FUNCTION.. 40</p> <p style="padding-left: 40px;">EXTERIOR LAMP BATTERY SAVER CONTROL. 41</p>
--	---

F  
G  
H  
I  
J  
LT  
L  
M

DELAY TIMER FUNCTION .....	41	Schematic .....	72
CAN Communication System Description .....	41	Wiring Diagram — TURN — .....	73
Major Components and Functions .....	41	Terminals and Reference Values for BCM .....	76
Schematic .....	42	How to Proceed With Trouble Diagnosis .....	77
Wiring Diagram — AUTO/L — .....	43	Preliminary Check .....	78
Terminals and Reference Values for BCM .....	46	CHECK POWER SUPPLY AND GROUND CIR-	
Terminals and Reference Values for IPDM E/R .....	47	CUIT .....	78
How to Proceed With Trouble Diagnosis .....	48	CONSULT-II Function (BCM) .....	79
Preliminary Check .....	48	CONSULT-II OPERATION .....	79
SETTING CHANGE FUNCTIONS .....	48	DATA MONITOR .....	80
CHECK BCM CONFIGURATION .....	48	ACTIVE TEST .....	80
CHECK POWER SUPPLY AND GROUND CIR-		Turn Signal Lamp Does Not Operate .....	81
CUIT .....	48	Rear Turn Signal Lamp Does Not Operate .....	82
CONSULT-II Function (BCM) .....	50	Hazard Warning Lamp Does Not Operate But Turn	
CONSULT-II OPERATION .....	50	Signal Lamps Operate .....	83
WORK SUPPORT .....	51	Turn Signal Indicator Lamp Does Not Operate .....	84
DATA MONITOR .....	51	Bulb Replacement (Front Turn Signal Lamp) .....	85
ACTIVE TEST .....	52	Bulb Replacement (Rear Turn Signal Lamp) .....	85
CONSULT-II Function (IPDM E/R) .....	53	Removal and Installation of Front Turn Signal Lamp..	85
CONSULT-II OPERATION .....	53	Removal and Installation of Rear Turn Signal Lamp..	85
DATA MONITOR .....	54	<b>CORNERING LAMP .....</b>	<b>86</b>
ACTIVE TEST .....	54	Component Parts and Harness Connector Location..	86
Trouble Diagnosis Chart by Symptom .....	55	System Description .....	86
Lighting Switch Inspection .....	55	OUTLINE .....	86
Optical Sensor System Inspection .....	56	CORNERING LAMP OPERATION .....	86
Removal and Installation of Optical Sensor .....	57	COMBINATION SWITCH READING FUNCTION..	87
REMOVAL .....	57	CAN Communication System Description .....	87
INSTALLATION .....	57	Schematic .....	88
<b>FRONT FOG LAMP .....</b>	<b>58</b>	Wiring Diagram — CORNER — .....	89
Component Parts and Harness Connector Location..	58	Terminals and Reference Values for BCM .....	92
System Description .....	58	Terminals and Reference Values for IPDM E/R .....	93
OUTLINE .....	58	How to Proceed With Trouble Diagnosis .....	93
COMBINATION SWITCH READING FUNCTION..	59	Preliminary Check .....	94
EXTERIOR LAMP BATTERY SAVER CONTROL..	59	CHECK POWER SUPPLY AND GROUND CIR-	
CAN Communication System Description .....	59	CUIT .....	94
Wiring Diagram — F/FOG — .....	60	CONSULT-II Function .....	95
Terminals and Reference Values for BCM .....	62	Cornering Lamp Does Not Operate .....	95
Terminals and Reference Values for IPDM E/R .....	63	Bulb Replacement .....	96
How to Proceed With Trouble Diagnosis .....	63	<b>LIGHTING AND TURN SIGNAL SWITCH .....</b>	<b>97</b>
Preliminary Check .....	64	Removal and Installation .....	97
CHECK BCM CONFIGURATION .....	64	REMOVAL .....	97
CHECK POWER SUPPLY AND GROUND CIR-		INSTALLATION .....	97
CUIT .....	64	<b>HAZARD SWITCH .....</b>	<b>98</b>
CONSULT-II Functions .....	65	Removal and Installation .....	98
Front Fog Lamps Do Not Illuminate (Both Sides) ...	65	REMOVAL .....	98
Front Fog Lamp Does Not Illuminate (One Side) ...	66	INSTALLATION .....	98
Aiming Adjustment .....	67	<b>COMBINATION SWITCH .....</b>	<b>99</b>
Bulb Replacement .....	68	Wiring Diagram — COMBSW — .....	99
Removal and Installation .....	68	Combination Switch Reading Function .....	100
<b>TURN SIGNAL AND HAZARD WARNING LAMPS..</b>	<b>69</b>	CONSULT-II Function (BCM) .....	100
Component Parts and Harness Connector Location..	69	CONSULT-II OPERATION .....	100
System Description .....	69	DATA MONITOR .....	101
OUTLINE .....	69	Combination Switch Inspection .....	102
TURN SIGNAL OPERATION .....	69	Removal and Installation .....	104
HAZARD LAMP OPERATION .....	70	Switch Circuit Inspection .....	104
REMOTE KEYLESS ENTRY SYSTEM OPERA-		<b>STOP LAMP .....</b>	<b>105</b>
TION .....	71	System Description .....	105
COMBINATION SWITCH READING FUNCTION..	71	Wiring Diagram — STOP/L — .....	106
CAN Communication System Description .....	71	High-Mounted Stop Lamp .....	107

BULB REPLACEMENT, REMOVAL AND INSTALLATION .....	107	TABLE .....	127	
Stop Lamp .....	107	<b>INTERIOR ROOM LAMP</b> .....	<b>128</b>	A
BULB REPLACEMENT .....	107	Component Parts and Harness Connector Location .....	128	
REMOVAL AND INSTALLATION .....	107	System Description .....	129	B
<b>BACK-UP LAMP</b> .....	<b>108</b>	POWER SUPPLY AND GROUND .....	129	
Wiring Diagram — BACK/L — .....	108	SWITCH OPERATION .....	130	C
Bulb Replacement .....	109	ROOM LAMP TIMER OPERATION .....	131	
Removal and Installation .....	109	INTERIOR LAMP BATTERY SAVER CONTROL .....	131	
<b>PARKING, LICENSE PLATE AND TAIL LAMPS</b> ...	<b>110</b>	Schematic .....	132	D
Component Parts and Harness Connector Location .....	110	Wiring Diagram — INT/L — .....	134	
System Description .....	110	Terminals and Reference Values for BCM .....	141	E
OPERATION BY LIGHTING SWITCH .....	111	How to Proceed With Trouble Diagnosis .....	142	
COMBINATION SWITCH READING FUNCTION .....	111	Preliminary Check .....	142	F
EXTERIOR LAMP BATTERY SAVER CONTROL .....	111	SWITCH INSPECTION .....	142	
CAN Communication System Description .....	111	INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT .....	142	G
Schematic .....	112	CONSULT-II Function (BCM) .....	144	
Wiring Diagram — TAIL/L — .....	113	CONSULT-II OPERATION .....	144	H
Terminals and Reference Values for BCM .....	116	WORK SUPPORT .....	145	
Terminals and Reference Values for IPDM E/R ...	117	DATA MONITOR .....	145	I
How to Proceed With Trouble Diagnosis .....	117	ACTIVE TEST .....	146	
Preliminary Check .....	117	Room/Map Lamp Control Does Not Operate .....	146	J
CHECK POWER SUPPLY AND GROUND CIRCUIT .....	117	Personal Lamp Control Does Not Operate (Room/Map Lamps Operate) .....	149	
CONSULT-II Functions .....	118	Ignition Keyhole Illumination Control Does Not Operate .....	150	LT
Parking, License Plate and/or Tail Lamps Do Not Illuminate .....	119	All Step/Foot/Puddle Lamps Do Not Operate .....	151	
Parking, License Plate and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes) .....	122	All Interior Room Lamps Do Not Operate .....	152	
Front Parking Lamp .....	123	<b>ILLUMINATION</b> .....	<b>153</b>	
BULB REPLACEMENT .....	123	Component Parts and Harness Connector Location .....	153	
Tail Lamp .....	123	System Description .....	153	
BULB REPLACEMENT .....	123	ILLUMINATION OPERATION BY LIGHTING SWITCH .....	154	
<b>REAR COMBINATION LAMP</b> .....	<b>124</b>	EXTERIOR LAMP BATTERY SAVER CONTROL .....	155	
Bulb Replacement .....	124	CAN Communication System Description .....	155	
Removal and Installation .....	124	Schematic .....	156	
.....	124	Wiring Diagram — ILL — .....	158	
<b>TRAILER TOW</b> .....	<b>125</b>	Removal and Installation .....	167	L
Component Parts and Harness Connector Location .....	125	ILLUMINATION CONTROL SWITCH .....	167	
System Description .....	125	<b>BULB SPECIFICATIONS</b> .....	<b>168</b>	M
TRAILER TAIL LAMP OPERATION .....	125	Headlamp .....	168	
TRAILER STOP, TURN SIGNAL AND HAZARD LAMP OPERATION .....	125	Exterior Lamp .....	168	
Wiring Diagram — T/TOW — .....	126	Interior Lamp/Illumination .....	168	
Trouble Diagnoses .....	127			
TRAILER TOW CONTROL UNIT INSPECTION				

# PRECAUTIONS

---

## PRECAUTIONS

PF0:00011

### Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS005KV

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

# PRECAUTIONS

## General precautions for service operations

EKS005KW

- Never work with wet hands.
- Turn the lighting switch OFF before disconnecting and connecting the connector.
- When checking the headlamp on/off operation, check it on vehicle and with the power connected to the vehicle-side connector.
- Do not touch the headlamp bulb glass surface with bare hands or allow oil or grease to get on it. Do not touch the headlamp bulb just after the headlamp is turned off, because it is very hot.
- When the bulb has burned out, wrap it in a thick vinyl bag and discard. Do not break the bulb.
- Leaving the bulb removed from the headlamp housing for a long period of time can deteriorate the performance of the lens and reflector (dirt, clouding). Always prepare a new bulb and have it on hand when replacing the bulb.
- Do not use organic solvent (paint thinner or gasoline) to clean lamps and to remove old sealant.

## Wiring Diagrams and Trouble Diagnosis

EKS005KX

When you read wiring diagrams, refer to the following:

- Refer to [GI-12, "How to Read Wiring Diagrams"](#) in GI section.
- Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) for power distribution in PG section.

When you perform trouble diagnosis, refer to the following:

- Refer to [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#) in GI section.
- Refer to [GI-25, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) in GI section.

A

B

C

D

E

F

G

H

I

J

LT

L

M


# HEADLAMP (FOR USA)

## HEADLAMP (FOR USA)

PF2:26010

### Component Parts and Harness Connector Location

EKS0065X



WKIA1048E

## System Description

EKS0065Y

Control of the headlamp system operation is dependent upon the position of the combination switch (lighting switch). When the lighting switch is placed in the 2ND position, the BCM (body control module) receives input requesting the headlamps (and tail lamps) illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the headlamp high and headlamp low relay coils. When energized, these relays direct power to the respective headlamps, which then illuminate.

## OUTLINE

Power is supplied at all times

- to headlamp high relay, located in the IPDM E/R, and
- to headlamp low relay, located in the IPDM E/R, and
- through 50A fusible link (letter j, located in the fuse and fusible link box)
- to BCM terminal 55, and
- through 15A fuse [No. 3, located in the fuse block (J/B)]
- to BCM terminal 42.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 16, located in the fuse block (J/B)]
- to BCM terminal 38.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 4, located in the fuse block (J/B)]

# HEADLAMP (FOR USA)

- to BCM terminal 11.

Ground is supplied

- to BCM terminals 49 (early production) and 52
- through grounds M57, M61 and M79, and
- to IPDM E/R terminals 38 and 60
- through grounds E9, E15 and E24.

## Low Beam Operation

With the lighting switch in 2ND position, the BCM receives input requesting the headlamps to illuminate. This input is communicated to the IPDM E/R across the CAN communication lines. The CPU of the IPDM E/R controls the headlamp low relay coil. When energized, this relay directs power

- through 15A fuse (No. 36, located in the IPDM E/R)
- through IPDM E/R terminal 20
- to headlamp RH terminal 1, and
- through 15A fuse (No. 45, located in the IPDM E/R)
- through IPDM E/R terminal 30
- to headlamp LH terminal 1.

Ground is supplied

- to headlamp LH and RH terminal 2
- through grounds E9, E15 and E24.

With power and ground supplied, low beam headlamps illuminate.

## High Beam Operation/Flash-to-Pass Operation

With the lighting switch in 2ND position and placed in HIGH or PASS position, the BCM receives input requesting the headlamp high beams to illuminate. This input is communicated to the IPDM E/R across the CAN communication lines. The CPU of the combination meter controls the ON/OFF status of the HIGH BEAM indicator. The CPU of the IPDM E/R controls the headlamp high relay coil. When energized, this relay directs power

- through 10A fuse (No. 40, located in the IPDM E/R)
- through IPDM E/R terminal 27
- to headlamp RH terminal 1, and
- through 10A fuse (No. 38, located in the IPDM E/R)
- through IPDM E/R terminal 28
- to headlamp LH terminal 1.

Ground is supplied

- to headlamp LH and RH terminal 2
- through grounds E9, E15 and E24.

With power and ground supplied, the high beam headlamps illuminate.

## BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, unless the combination switch (lighting switch) position is changed. If the combination switch (lighting switch) position is changed, then the headlamps are turned off.

## AUTO LIGHT OPERATION

Refer to [LT-40, "System Description"](#) for auto light operation.

## VEHICLE SECURITY SYSTEM (PANIC ALARM)

The vehicle security system (panic alarm) will flash the high beams if the system is triggered. Refer to [BL-58, "Panic Alarm Operation"](#).

## CAN Communication System Description

Refer to [LAN-6, "CAN COMMUNICATION"](#).



EKS0065Z

# HEADLAMP (FOR USA)

EKS00660

## Wiring Diagram — H/LAMP —

LT-H/LAMP-01




REFER TO THE FOLLOWING.  
 (M4), (E30) - FUSE BLOCK-JUNCTION BOX (J/B)  
 (M18), (M19) - ELECTRICAL UNITS


WKWA1421E

# HEADLAMP (FOR USA)

LT-H/LAMP-02



PRECEDING PAGE







WKWA0540E

# HEADLAMP (FOR USA)

## Terminals and Reference Values for BCM

EKS00661

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
2	GR/R	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>
3	G/Y	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>
4	G/R	Combination switch input 3	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>
5	G/B	Combination switch input 2	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>
6	G/W	Combination switch input 1			
11	V	Ignition switch (ACC)	ACC	—	Battery voltage
32	R/G	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>
33	R/Y	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>
34	R	Combination switch output 3	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>

# HEADLAMP (FOR USA)

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
35	R/B	Combination switch output 2	ON	Lighting, turn, wiper OFF Wiper dial position 4	
36	R/W	Combination switch output 1			
38	G	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN-H	—	—	—
40	Y	CAN-L	—	—	—
42	Y/G	Battery power supply	OFF	—	Battery voltage
49*	B	Ground	ON	—	0V
52	B/W	Ground	ON	—	0V
55	W/B	Battery power supply (fusible link)	OFF	—	Battery voltage

\* Early production

## Terminals and Reference Values for IPDM E/R

EKS00662

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
20	R/Y	Headlamp low (RH)	ON	Lighting switch 2ND position OFF	0V
				ON	Battery voltage
27	L/W	Headlamp high (RH)	ON	Lighting switch HIGH or PASS position OFF	0V
				ON	Battery voltage
28	G	Headlamp high (LH)	ON	Lighting switch HIGH or PASS position OFF	0V
				ON	Battery voltage
30	L	Headlamp low (LH)	ON	Lighting switch 2ND position OFF	0V
				ON	Battery voltage
38	B	Ground	ON	—	0V
48	L	CAN-H	—	—	—
49	Y	CAN-L	—	—	—
60	B	Ground	ON	—	0V

## How to Proceed With Trouble Diagnosis

EKS00663

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-6, "System Description"](#) .
3. Perform the Preliminary Check. Refer to [LT-12, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the headlamp operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

# HEADLAMP (FOR USA)

EKS00664

## Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES OR FUSIBLE LINK

Check for blown fuses or fusible link.

Unit	Power source	Fuse No.
BCM	Battery	j
		3
	Ignition switch ON or START position	16
	Ignition switch ACC or ON position	4
IPDM E/R	Battery	36
		38
		40
		45
		45

Refer to [LT-8, "Wiring Diagram — H/LAMP —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of blown fuse before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

### 2. CHECK POWER SUPPLY CIRCUIT


1. Disconnect BCM connectors.
2. Check voltage between BCM harness connector and ground.

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M18	11 (V)	Ground	0V	Battery voltage	Battery voltage
	38 (G)		0V	0V	Battery voltage
M19	42 (Y/G)		Battery voltage	Battery voltage	Battery voltage
	55 (W/B)		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open between BCM and fuse.



# HEADLAMP (FOR USA)

## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Terminals		Continuity
Connector	Terminal (Wire color)	
M19	49* (B)	Ground
	52 (B/W)	
		Yes

\* Early production

### OK or NG

- OK >> Inspection End.
- NG >> Check ground circuit harness.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HEADLAMP (FOR USA)

EKS00665

## CONSULT-II Function (BCM)

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnostic test item	Diagnostic mode	Description
Inspection by part	WORK SUPPORT	Supports inspections and adjustments. Commands are transmitted to the BCM for setting the status suitable for required operation, input/output signals are received from the BCM and received data is displayed.
	DATA MONITOR	Displays BCM input/output data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
	SELF-DIAG RESULTS	Displays BCM self-diagnosis results.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
	ECU PART NUMBER	BCM part number can be read.
	CONFIGURATION	Performs BCM configuration read/write functions.

## CONSULT-II OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen.  
If "BCM" is not indicated, go to [GI-37, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .



# HEADLAMP (FOR USA)

4. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.



## WORK SUPPORT

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch item on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SETT".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

### Display Item List

Item	Description	CONSULT-II	Factory setting
BATTERY SAVER SET	Exterior lamp battery saver control mode can be changed in this mode. Selects exterior lamp battery saver control mode between ON/OFF.	ON	×
		OFF	—

## DATA MONITOR

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on the "SELECT MONITOR ITEM" screen.

All signals	Monitors all the signals.
Selection from menu	Selects and monitors individual signal.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
ACC ON SW "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1ST "ON/OFF"	Displays status (lighting switch 1st position: ON/Others: OFF) of lighting switch judged from lighting switch signal.

## HEADLAMP (FOR USA)

Monitor item	Contents
AUTO LIGHT SW      "ON/OFF"	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW          "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW            "ON/OFF"	Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
DOOR SW-DR          "ON/OFF"	Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-AS          "ON/OFF"	Displays status of the passenger door as judged from the passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-RR          "ON/OFF"	Displays status of the rear door as judged from the rear door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-RL          "ON/OFF"	Displays status of the rear door as judged from the rear door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW        "ON/OFF"	Displays status of the back door as judged from the back door switch signal. (Door is open: ON/Door is closed: OFF)
TURN SIGNAL R        "ON/OFF"	Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L        "ON/OFF"	Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
CARGO LAMP SW       "ON/OFF"	Displays status of cargo lamp switch.
OPTICAL SENSOR      [0 - 5V]	Displays "ambient light (close to 5V when dark/close to 0V when light)" judged from optical sensor signal.

### ACTIVE TEST

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested, and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

#### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay (HI, LO) to operate by switching ON-OFF.
FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF.
CARGO LAMP	Allows cargo lamp to operate by switching ON-OFF.
CORNERING LAMP	Allows cornering lamp relay (RH, LH) to operate by switching ON-OFF.

### SELF-DIAGNOSTIC RESULTS

#### Operation Procedure

1. Touch "BCM" on "SELECT TEST ITEM" screen.
2. Touch "SELF-DIAG RESULTS" on "SELECT DIAG MODE" screen.
3. Self-diagnostic results are displayed.

#### Display Item List

Monitored item	CONSULT-II display	Description
CAN communication	CAN communication [U1000]	Malfunction is detected in CAN communication.
CAN communication system	CAN communication system 1 to 6 [U1000]	Malfunction is detected in CAN system.

# HEADLAMP (FOR USA)

EKS00666

## CONSULT-II Function (IPDM E/R)

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


IPDM E/R diagnostic Mode	Description
SELF-DIAG RESULTS	Displays IPDM E/R self-diagnosis results.
DATA MONITOR	Displays IPDM E/R input/output data in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.

## CONSULT-II OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn the ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "IPDM E/R" on "SELECT SYSTEM" screen. If "IPDM E/R" is not displayed, go to [GI-37, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# HEADLAMP (FOR USA)

- Select the desired part to be diagnosed on the "SELECT DIAG MODE" screen.



## DATA MONITOR

### Operation Procedure

- Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
- Touch "ALL SIGNALS", "MAIN SIGNALS" or "SELECTION FROM MENU" on the "SELECT MONITOR ITEM" screen.

ALL SIGNALS	All items will be monitored.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Select any item for monitoring.

- Touch "START".
- Touch the required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
- Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

### All Items, Main Items, Select Item Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Position lights request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Cornering lamp	CRNRNG LMP REQ	ON/OFF	×	–	×	Signal status input from BCM
Front fog lights request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM

#### NOTE:

Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.

## ACTIVE TEST

### Operation Procedure

- Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
- Touch item to be tested and check operation.
- Touch "START".
- Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option.

# HEADLAMP (FOR USA)

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI, LO) at your option (Head lamp high beam repeats ON-OFF every 1 second).
Front fog lamp relay (FOG) output		Allows fog lamp relay (FOG) to operate by switching operation ON-OFF at your option.
Cornering lamp relay (RH, LH) output	CORNERING LAMP	Allows cornering lamp relay (RH, LH) to operate by switching operation ON-OFF at your option.

## Headlamp HI Does Not Illuminate (Both Sides)

EKS00610

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HI BEAM SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is in HIGH position : HI BEAM SW ON**

OK or NG

OK >> GO TO 2.

NG >> Check lighting switch. Refer to [LT-102, "Combination Switch Inspection"](#).

DATA MONITOR	
MONITOR	
HI BEAM SW	ON

SKIA4193E

### 2. HEADLAMP ACTIVE TEST

- Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
- Select "LAMPS" on "SELECT TEST ITEM" screen.
- Touch "HI" on "ACTIVE TEST" screen.
- Make sure headlamp high beam operates.

**Headlamp high beam should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.

ACTIVE TEST	
LAMPS	OFF
	HI
	FOG
	LO
MODE	BACK
LIGHT	COPY

SKIA5774E

### 3. CHECK IPDM E/R

- Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
- Make sure "HL LO REQ" and "HL HI REQ" turns ON when lighting switch is in HIGH position.

**When lighting switch is in HIGH position : HL LO REQ ON  
: HL HI REQ ON**

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).

NG >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).

DATA MONITOR	
MONITOR	
HL LO REQ	ON
HL HI REQ	ON
	Page Down
	RECORD
MODE	BACK
LIGHT	COPY

SKIA5775E

# HEADLAMP (FOR USA)


## 4. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect headlamp RH and LH connectors.
3. Turn ignition switch ON.
4. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
5. Select "LAMPS" on "SELECT TEST ITEM" screen.
6. Touch "HI" on "ACTIVE TEST" screen.
7. When headlamp high beam is operating, check voltage between headlamp RH and LH harness connector and ground.

Terminals			Voltage
(+)		(-)	
Connector	Terminal (Wire color)		
RH	E13	1 (L/W)	Ground
LH	E45	1 (G)	
			Battery voltage

OK or NG

- OK >> GO TO 6.  
 NG >> GO TO 5.



## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E122 terminal 27 (L/W) and headlamp RH harness connector E13 terminal 1 (L/W).


**27 (L/W) - 1 (L/W) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E122 terminal 28 (G) and headlamp LH harness connector E45 terminal 1 (G).

**28 (G) - 1 (G) : Continuity should exist.**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).  
 NG >> Repair harness or connector.



## 6. CHECK HEADLAMP GROUND

1. Check continuity between headlamp RH harness connector E13 terminal 2 (B) and ground.


**2 (B) - Ground : Continuity should exist.**

2. Check continuity between headlamp LH harness connector E45 terminal 2 (B) and ground.

**2 (B) - Ground : Continuity should exist.**

OK or NG

- OK >> Check headlamp connector for damage or poor connection. Repair as necessary.  
 NG >> Repair harness or connector.



# HEADLAMP (FOR USA)

EKS00677

## Headlamp HI Does Not Illuminate (One Side)

### 1. BULB INSPECTION

Inspect inoperative headlamp bulb.

OK or NG

OK >> GO TO 2.

NG >> Replace headlamp bulb. Refer to [LT-27, "HEADLAMP \(INNER SIDE\), FOR HIGH BEAM"](#) .

### 2. CHECK POWER TO HEADLAMP


1. Disconnect inoperative headlamp connector.
2. Turn the HI beam headlamps ON.
3. Check voltage between inoperative headlamp terminal and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
Connector	Terminal (Wire color)		
RH	E13	1 (L/W)	Ground
LH	E45	1 (G)	
			Battery voltage

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.



### 3. CHECK HEADLAMP GROUND


1. Turn the HI beam headlamps OFF.
2. Check continuity between inoperative headlamp connector and ground.

Terminals			Continuity
Connector	Terminal (Wire color)		
RH	E13	2 (B)	Ground
LH	E45		
			Yes

OK or NG

OK >> Check headlamp connector for damage or poor connection. Repair as necessary.

NG >> Repair open circuit in harness between inoperative headlamp and ground.



# HEADLAMP (FOR USA)

## 4. INSPECTION BETWEEN IPDM E/R AND HEADLAMPS


1. Disconnect IPDM E/R connector and inoperative headlamp connector.
2. Check continuity between harness connector terminals of IPDM E/R and harness connector terminals of inoperative headlamp.

Terminals					Continuity
IPDM E/R		Headlamp			
Connector	Terminal (wire color)	Connector	Terminal (wire color)		
E122	27 (L/W)	RH	E13	1 (L/W)	Yes
	28 (G)	LH	E45	1 (G)	

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#) .

NG >> Check for short circuits and open circuits in harness between IPDM E/R and headlamps. Repair as necessary.



## High-Beam Indicator Lamp Does Not Illuminate

EKS00678

### 1. BULB INSPECTION

Inspect CAN communication system. Refer to [LAN-6, "CAN COMMUNICATION"](#) .

OK or NG

OK >> Replace combination meter. Refer to [IP-12, "Combination Meter"](#) .

NG >> Repair as necessary.

## Headlamp LO Does Not Illuminate (Both Sides)

EKS00679

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL


Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is in 2ND position :**  
**HEAD LAMP SW 1 ON**  
**HEAD LAMP SW 2 ON**

OK or NG

OK >> GO TO 2.

NG >> Check lighting switch. Refer to [LT-102, "Combination Switch Inspection"](#) .



## 2. HEADLAMP ACTIVE TEST


1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "LO" on "ACTIVE TEST" screen.
4. Make sure headlamp low beam operates.

**Headlamp low beam should operate.**

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.



# HEADLAMP (FOR USA)


## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "HL LO REQ" turns ON when lighting switch is in 2ND position.

**When lighting switch is in 2ND position : HL LO REQ ON**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).
- NG >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).




## 4. CHECK HEADLAMP INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect headlamp RH and LH connector.
3. Turn ignition switch ON.
4. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
5. Select "LAMPS" on "SELECT TEST ITEM" screen.
6. Touch "LO" on "ACTIVE TEST" screen.
7. When headlamp low beam is operating, check voltage between headlamp RH and LH harness connector and ground.

Terminals			Voltage
(+)		(-)	
Connector	Terminal (Wire color)		
RH	E12	1 (R/Y)	Ground
LH	E44	1 (L)	
			Battery voltage

OK or NG

- OK >> GO TO 6.
- NG >> GO TO 5.



## 5. CHECK HEADLAMP CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector E122 terminal 20 (R/Y) and headlamp RH harness connector E12 terminal 1 (R/Y).


**20 (R/Y) - 1 (R/Y) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E122 terminal 30 (L) and headlamp LH harness connector E44 terminal 1 (L).

**30 (L) - 1 (L) : Continuity should exist.**

OK or NG

- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).
- NG >> Repair harness or connector.



# HEADLAMP (FOR USA)

## 6. CHECK HEADLAMP GROUND

1. Turn ignition switch OFF.
2. Check continuity between headlamp RH harness connector E12 terminal 2 (B) and ground.

**2 (B) - Ground : Continuity should exist.**


3. Check continuity between headlamp LH harness connector E44 terminal 2 (B) and ground.

**2 (B) - Ground : Continuity should exist.**

OK or NG

OK >> Check headlamp connector for damage or poor connection. Repair as necessary.

NG >> Repair harness or connector.



WKIA1050E

## Headlamp LO Does Not Illuminate (One Side)

EKS0067A

### 1. BULB INSPECTION

Inspect inoperative headlamp bulb.

OK or NG

OK >> GO TO 2.

NG >> Replace headlamp bulb. Refer to [LT-27, "HEADLAMP \(OUTER SIDE\), FOR LOW BEAM"](#).

### 2. CHECK POWER TO HEADLAMP


1. Disconnect inoperative headlamp connector.
2. Turn the low beam headlamps ON.
3. Check voltage between inoperative headlamp connector terminal and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
Connector	Terminal		
RH	E12	1 (R/Y)	Ground
LH	E44	1 (L)	
			Battery voltage

OK or NG

OK >> GO TO 3.

NG >> GO TO 4.



WKIA1252E

### 3. CHECK HEADLAMP GROUND


1. Turn the low beam headlamps OFF.
2. Check continuity between inoperative headlamp connector terminal and ground.

Terminals			Continuity
Connector	Terminal (Wire color)		
RH	E12	2 (B)	Ground
LH	E44		
			Yes

OK or NG

OK >> Check headlamp and IPDM E/R connector. Repair as necessary.

NG >> Repair open circuit in harness between inoperative headlamp and ground.



WKIA1050E

# HEADLAMP (FOR USA)

## 4. INSPECTION BETWEEN IPDM E/R AND HEADLAMPS


1. Disconnect IPDM E/R connector.
2. Check continuity between harness connector terminals of IPDM E/R harness connector terminals of inoperative headlamp.

Terminals					Continuity
IPDM E/R		Headlamp			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E122	20 (R/Y)	RH	E12	1 (R/Y)	Yes
	30 (L)	LH	E44	1 (L)	

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#) .

NG >> Check for short circuits and open circuits in harness between IPDM E/R and headlamps. Repair as necessary.



## Headlamps Do Not Turn OFF

EKS0066E

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "HEAD LAMP SW 1" and "HEAD LAMP SW 2" turns ON/OFF linked with operation of lighting switch.

**When lighting switch is in OFF position : HEAD LAMP SW 1 OFF**  
**: HEAD LAMP SW 2 OFF**

OK or NG

OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#) .

NG >> GO TO 2.

DATA MONITOR	
MONITOR	
HEAD LAMP SW 1	OFF
HEAD LAMP SW 2	OFF

SKIA5200E

### 2. CHECK LIGHTING SWITCH

Check lighting switch. Refer to [LT-102, "Combination Switch Inspection"](#) .

OK or NG

OK >> GO TO 3.

NG >> Replace lighting switch. Refer to [LT-104, "Removal and Installation"](#) .

### 3. CHECKING CAN COMMUNICATIONS BETWEEN BCM AND IPDM E/R

Select "BCM" on CONSULT-II and perform self-diagnosis for BCM.

Display of self-diagnosis results

NO DTC>> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#) .

CAN COMM CIRCUIT>> Refer to [BCS-13, "CAN Communication Inspection Using CONSULT-II \(Self-Diagnosis\)"](#) .


SELF-DIAG RESULTS			
DTC RESULTS		TIME	
CAN COMM CIRCUIT [U1000]		PAST	
ERASE		PRINT	
MODE	BACK	LIGHT	COPY

SKIA1039E

# HEADLAMP (FOR USA)

## Aiming Adjustment

EKS0066H



WKIA1052E

### **For details, refer to the regulations in your state.**

Before performing aiming adjustment, check the following.

1. Ensure all tires are inflated to correct pressure.
2. Place vehicle and screen on level surface.
3. Ensure there is no load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant and engine oil filled to correct level, and fuel tank full.
4. Confirm spare tire, jack and tools are properly stowed.


### **LOW BEAM AND HIGH BEAM**

#### **NOTE:**

Aim each headlamp individually and ensure other headlamp beam pattern is blocked from screen.

1. Turn headlamp low beam on.
2. Use adjusting screw to perform aiming adjustment.

# HEADLAMP (FOR USA)



If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- **Basic illuminating area for adjustment should be within the range shown on the aiming chart. Adjust headlamps accordingly.**

## Bulb Replacement HEADLAMP (OUTER SIDE), FOR LOW BEAM

EKS0066I

1. Turn headlamp switch OFF.
2. Disconnect the electrical connector.
3. Turn the bulb counterclockwise to remove it.
4. Install in reverse order of removal.

## HEADLAMP (INNER SIDE), FOR HIGH BEAM

1. Turn headlamp switch OFF.
2. Disconnect the electrical connector.
3. Turn the bulb counterclockwise to remove it.
4. Installation is reverse order of removal.

## FRONT TURN SIGNAL/PARKING LAMP

1. Turn the bulb socket counterclockwise to unlock it.
2. Pull the bulb to remove it from the socket.
3. Installation is reverse order of removal.

### CAUTION:

After installing the bulb, be sure to install the bulb socket securely to ensure watertightness.


## Removal and Installation REMOVAL

EKS0066J

1. Remove the front fascia. Refer to [EI-13, "Removal and Installation"](#).

## HEADLAMP (FOR USA)

2. Remove the headlamp mounting bolts.
3. Pull the headlamp toward the front of the vehicle, disconnect connectors, and remove from vehicle.



### INSTALLATION

Install in the reverse order of removal.

#### Headlamp-to-radiator support mounting bolts:

: 6.5 N·m (0.66 kg-m, 58 in-lb)


#### Headlamp-to-fender mounting bolt:

: 5.7 N·m (0.58 kg-m, 50 in-lb)

# HEADLAMP (FOR USA)

## Disassembly and Assembly DISASSEMBLY

EKS0066K



- |                               |   |                                  |
|-------------------------------|---|----------------------------------|
| 1. Headlamp bulb (High beam)  | 2. Headlamp assembly                    | 3. Cornering lamp bulb           |
| 4. Cornering lamp bulb socket | 5. Parking/turn signal lamp bulb socket | 6. Parking/turn signal lamp bulb |
| 7. Headlamp bulb (Low beam)   |   |                                  |

WKIA1055E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

PF2:26010

### Component Parts and Harness Connector Location

EKS0066L



WKIA1056E

## System Description

EKS0066M

The headlamp system for Canada vehicles is equipped with a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

Battery saver system is controlled by the BCM (body control module).

Power is supplied at all times

- to headlamp high relay located in the IPDM E/R (intelligent power distribution module engine room), and
- to headlamp low relay located in the IPDM E/R, and
- through 50A fusible link (letter j , located in the fuse and fusible link box)

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

- to BCM terminal 55, and
- through 15A fuse [No. 3, located in the fuse block (J/B)]
- to BCM terminal 42, and
- through 15A fuse (No. 29, located in the fuse and fusible link box).
- to daytime light control unit terminals 2 and 3

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 12, located in the fuse block (J/B)], and
- to daytime light control unit terminal 12, and
- through 10A fuse [No. 16, located in the fuse block (J/B)]
- to BCM terminal 38.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 4, located in the fuse block (J/B)]
- to BCM terminal 11.

With the ignition switch in the START position, power is supplied

- through 10A fuse [No. 9, located in the fuse block (J/B)]
- to daytime light control unit terminal 1.

Ground is supplied

- to daytime light control unit terminal 9
- through grounds E9, E15 and E24, and
- to BCM terminals 49 (early production) and 52
- through grounds M57, M61 and M79.

## HEADLAMP OPERATION

### Low Beam Operation

With the lighting switch in 2ND position, the BCM receives input requesting the headlamps to illuminate. This input is communicated to the IPDM E/R across the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the headlamp low relay coil. When energized, this relay directs power

- through 15A fuse (No. 45, located in the IPDM E/R)
- through IPDM E/R terminal 30
- to daylight control unit terminal 4 and
- to headlamp LH (low) terminal 1, and
- through 15A fuse (No. 36, located in the IPDM E/R)
- through IPDM E/R terminal 20
- to diode-3 terminal 3 and
- to headlamp RH (low) terminal 1.

Ground is supplied

- to headlamp LH (low) and RH (low) terminal 2
- through grounds E9, E15 and E24.

With power and ground supplied, low beam headlamps illuminate.

### High Beam Operation/Flash-to-Pass Operation

With the lighting switch in 2ND position and placed in HIGH or PASS position, the BCM receives input requesting the headlamp high beams to illuminate. This input is communicated to the IPDM E/R across the CAN communication lines. The CPU of the combination meter controls the ON/OFF status of the HIGH BEAM indicator. The CPU of the IPDM E/R controls the headlamp high relay coil. When energized, this relay directs power

- through 10A fuse (No. 40, located in the IPDM E/R)
- through IPDM E/R terminal 27
- to diode-3 terminal 1 and
- to daytime light relay terminal 1.

When energized, this relay directs power

- through daytime light relay terminal 3

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LT

L  
M

## HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

---

- to daytime light control unit terminal 8 and
- to terminal 1 of headlamp RH (high).

Also when the headlamp high relay is energized, it directs power

- to 10A fuse [No. 38, located in the IPDM E/R]
- through terminal 28 of the IPDM E/R
- to terminal 5 of the daytime light control unit
- through terminal 6 of the daytime light control unit
- to terminal 1 of headlamp LH (high).

Ground is supplied

- to daytime light relay terminal 2 and
- to headlamp RH (high) terminal 2
- through grounds E9, E15 and E24, and
- to headlamp LH (high) terminal 2 and
- to daytime light control unit terminal 7
- through daytime light control unit terminal 9
- through grounds E9, E15 and E24.

With power and ground supplied, the high beam headlamps illuminate.

### BATTERY SAVER CONTROL

With the combination switch (lighting switch) is in the 2ND position (ON), and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the headlamps remain illuminated for 5 minutes, unless the combination switch (lighting switch) position is changed. If the combination switch (lighting switch) position is changed, then the headlamps are turned off.

### AUTO LIGHT OPERATION

For auto light operation, refer to [LT-40, "System Description"](#) .

### DAYTIME LIGHT OPERATION

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

- through daytime light control unit terminal 6
- to headlamp LH (high) terminal 1
- through headlamp LH (high) terminal 2
- to daytime light control unit terminal 7
- through daytime light control unit terminal 8
- to headlamp RH (high) terminal 1.

Ground is supplied

- to headlamp RH (high) terminal 2
- through grounds E9, E15 and E24.

Because the high beam headlamps are now wired in series, they operate at half illumination.

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## OPERATION

After starting the engine with the lighting switch in the "OFF" or 1ST position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running								
Lighting switch		OFF			1ST			2ND			OFF			1ST			2ND		
		Hi	Lo	P	Hi	Lo	P	Hi	Lo	P	Hi	Lo	P	Hi	Lo	P	Hi	Lo	P
Headlamp	High beam	-	-	-	-	-	×	×	-	×	●*	●*	×	●*	●*	×	×	-	×
	Low beam	-	-	-	-	-	×	×	×	×	-	-	×	-	-	×	×	×	×
Tail lamp		-	-	-	×	×	×	×	×	×	-	-	-	×	×	×	×	×	×
License and instrument illumination lamp		-	-	-	×	×	×	×	×	×	-	-	-	×	×	×	×	×	×

- Hi: "HIGH BEAM" position
- Lo: "LOW BEAM" position
- P: "FLASH TO PASS" position
- ×: Lamp "ON"
- -: Lamp "OFF"
- ●: Lamp dims. (Added functions)
- \*: When starting the engine with the parking brake released, the daytime lights will operate.  
When starting the engine with the parking brake applied, the daytime lights will not operate.

## CAN Communication System Description

EKS0066N

Refer to [LAN-6, "CAN COMMUNICATION"](#).

A

B

C

D

E

F

G

H

I

J

LT


L

M

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## Schematic

EKS00660








WKWA2793E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

EKS0066P

## Wiring Diagram — DTRL —

LT-DTRL-01




REFER TO THE FOLLOWING.  
 M4, E30 - FUSE BLOCK-JUNCTION BOX (J/B)  
 M18, M19 - ELECTRICAL UNITS

WKWA1422E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-02





REFER TO "PG-POWER".

WKWA0543E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

LT-DTRL-03



WKWA1417E

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

EKS0069J

## Trouble Diagnoses DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE

Terminal No.	Wire color	Item	Condition	Voltage (Approx.)
1	BR/W	Ignition switch start signal	Ignition switch in START position	Battery voltage
			All other conditions	0
2	SB	Battery	Ignition switch in all positions	Battery voltage
3	SB	Battery	Ignition switch in all positions	Battery voltage
4	L	Lighting switch headlamp LH low beam output	Lighting switch in the headlamp ON (2ND) position and low beam (B) position	Battery voltage
			All other conditions	0
5	G	Lighting switch headlamp LH high beam output	Lighting switch in the flash-to-pass (C) position or headlamp ON (2ND) position and high beam (A) position	Battery voltage
			All other conditions	0
6	L/W	Headlamp LH high beam	Lighting switch in the flash-to-pass (C) position or headlamp ON (2ND) position and high beam (A) position	Battery voltage
			With parking brake released, engine running and lighting switch in OFF or parking and tail lamp ON (1ST) positions <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in P or N position.</b>	Battery voltage
			All other conditions	0
7	Y/G	Headlamp LH (high) control	Lighting switch in the flash-to-pass (C) position or headlamp ON (2ND) position and high beam (A) position and high beam position	0
			With parking brake released, engine running and lighting switch in OFF or parking and tail lamp ON (1ST) positions <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in P or N position.</b>	Battery voltage
			All other conditions	0
8	Y	Lighting switch headlamp RH high beam output	Lighting switch in the flash-to-pass (C) position or headlamp ON (2ND) position and high beam (A) position	Battery voltage
			With parking brake released, engine running and lighting switch in OFF or parking and tail lamp ON (1ST) positions <b>CAUTION:</b> <b>Block wheels and ensure selector lever is in P or N position.</b>	6
			All other conditions	0
9	B	Ground	—	—
10	Y/G	Parking brake switch	Parking brake released	Battery voltage
			Parking brake set	0
11	BR/Y	Generator (L terminal)	When engine is running	Battery voltage
			All other conditions	0
12	G	Ignition switch on signal	Ignition switch OFF, ACC positions	0
			Ignition switch ON, START positions	Battery voltage

# HEADLAMP (FOR CANADA) - DAYTIME LIGHT SYSTEM -

## Aiming Adjustment

EKS0066R

Refer to [LT-26, "Aiming Adjustment"](#) .

A

## Bulb Replacement

EKS0066S

Refer to [LT-27, "Bulb Replacement"](#) .

B

## Removal and Installation For Headlamp

EKS0066T

Refer to [LT-39, "Removal and Installation For Daytime Light Control Unit"](#) .

C

## Disassembly and Assembly For Headlamp

EKS0066U

Refer to [LT-29, "Disassembly and Assembly"](#) .


D

## Removal and Installation For Daytime Light Control Unit

EKS0069K

### REMOVAL

1. Remove the daytime light control unit mounting bolt.
2. Disconnect connectors and remove from vehicle.



E

F

G

H

### INSTALLATION

Install in the reverse order of removal.

## Removal and Installation For Daytime Light Relay


EKS0069M

### REMOVAL

#### NOTE:

The daytime light relay is taped to the main wiring harness near the lower dash side finisher RH.

1. Remove the glove box assembly. Refer to [IP-10, "INSTRUMENT PANEL ASSEMBLY"](#) .
2. Carefully remove the tape holding the daytime light relay to the main harness.
3. Disconnect the connector.



I

J

LT

L

M

### INSTALLATION

Install in the reverse order of removal.


# AUTO LIGHT SYSTEM

## AUTO LIGHT SYSTEM

PF2:28491

### Component Parts and Harness Connector Location

EKS005M1



WKIA1058E

## System Description

EKS005M2

Automatically turns on/off the parking lamps and the headlamps in accordance with ambient light. Timing for when the lamps turn on/off can be selected using four modes.

### OUTLINE

The auto light control system uses an optical sensor that detects outside brightness. When the lighting switch is in "AUTO" position, it automatically turns on/off the parking lamps and the headlamps in accordance with the ambient light. Sensitivity can be adjusted in four steps. For the details of the setting, refer to [LT-48. "SETTING CHANGE FUNCTIONS"](#).

Optical sensor ground is supplied

- through BCM (body control module) terminal 18
- to optical sensor terminal 3.

When ignition switch is turned to "ON" position and when outside brightness is darker than prescribed level, input is supplied

- to BCM terminal 43
- through optical sensor terminal 4.

The headlamps will then illuminate. For a description of headlamp operation, Refer to [LT-6. "System Description"](#).

### COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3. "COMBINATION SWITCH READING FUNCTION"](#).

# AUTO LIGHT SYSTEM

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the AUTO position, and the ignition switch is turned from ON or ACC to OFF, and one of the front doors is opened, the battery saver control feature is activated. Under this condition, the headlamps remain illuminated for 5 minutes, then the headlamp are turned off. Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## DELAY TIMER FUNCTION

When the ignition switch is ON and ACC is OFF while auto light switch is ON, the BCM turns on/off the headlamps. In delay timer function, auto timer sensor power source is OFF and BCM is not turned on/off by auto sensor signal. On condition that:

- when the state is ignition switch ON or ACC is ON and output judgment by auto light function is headlamp ON turn to ignition switch ON or ACC are OFF and front door switch (driver side), front door switch (passenger side) is ON, output judgment by auto light function should be headlamp ON for 5 minutes by timer. After time out, output judgment by auto light function should be headlamp OFF.
- when the state is front door switch (driver side), front door switch (passenger side), rear door switch LH, rear door switch RH is turned to ON from OFF 45 seconds or 5 minutes while timer is counting, timer stops, and re-starts counting for 5 minutes, then auto light function judges output as headlamp ON. After time out, auto light function judges output as headlamp OFF.
- when the state is front door switch (driver side), front door switch (passenger side), rear door switch LH, rear door switch RH or back door switch is ON turns to front door switch (driver side), front door switch (passenger side), rear door switch LH, rear door switch RH or back door switch are OFF 45 seconds or 5 minute while is counting, timer stops, and re-starts counting for 45 seconds, then auto light function judges output as headlamp ON. After timer out, auto light function judges output as headlamp OFF.
- when the state is ignition switch ON or ACC is ON or auto light switch OFF while timer is counting, timer stops counting and BCM turns on/off lamps according to headlamp function, front fog lamp function, auto light function and headlamp battery save function.

Delay timer control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

EKS005M3

Refer to [LAN-6, "CAN COMMUNICATION"](#) .

## Major Components and Functions


EKS005M4

Components	Functions
BCM	• Turns on/off circuits of tail light and headlamp according to signals from light sensor, lighting switch (AUTO), driver door switch, passenger door switch, rear door switch, and ignition switch (ON, OFF).
Optical sensor	• Converts ambient light (lux) to voltage, and sends it to BCM. (Detects lightness of 50 to 1,300 lux)

# AUTO LIGHT SYSTEM

## Schematic

EKS005M5



EP : EARLY PRODUCTION

\* THIS RELAY IS BUILT INTO THE IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM).

WKWA1663E


# AUTO LIGHT SYSTEM

EKS005M6

## Wiring Diagram — AUTO/L —

LT-AUTO/L-01


EP : EARLY PRODUCTION



REFER TO "PG-POWER".

BCM (BODY CONTROL MODULE)  
M18, M19

REFER TO THE FOLLOWING.  
M4, E30 - FUSE BLOCK-JUNCTION BOX (J/B)  
M18, M19 - ELECTRICAL UNITS





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# AUTO LIGHT SYSTEM

LT-AUTO/L-02

- : DATA LINE  
WC : WITH BACK DOOR AUTO CLOSURE SYSTEM  
XC : WITHOUT BACK DOOR AUTO CLOSURE SYSTEM  
 \*1 WC : 4    \*2 WC : 4    \*3 WC : 14    \*4 WC : 7    \*5 WC : 8  
XC : 1    \*2 XC : 1    \*3 XC : 6    \*4 XC : 1    \*5 XC : 3





REFER TO THE FOLLOWING.  
M18, M20 - ELECTRICAL UNITS

WKWA0547E

# AUTO LIGHT SYSTEM

LT-AUTO/L-03









WKWA0548E



# AUTO LIGHT SYSTEM

## Terminals and Reference Values for BCM

EKS005M7

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)	
			Ignition switch	Operation or condition		
2	GR/R	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>	
3	G/Y	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>	
4	G/R	Combination switch input 3	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>	
5	G/B	Combination switch input 2	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>	
6	G/W	Combination switch input 1				
11	V	Ignition switch (ACC)	ACC	—	Battery voltage	
12	GR/L	Front door switch RH signal	OFF	Front door switch RH	ON (open)	0V
					OFF (closed)	Battery voltage
13	O/B	Sliding door switch RH signal	OFF	Sliding door switch RH	ON (open)	0V
					OFF (closed)	Battery voltage
18	P	Sensor ground	ON	—	0V	
32	R/G	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>	
33	R/Y	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>	

# AUTO LIGHT SYSTEM

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)	
			Ignition switch	Operation or condition		
34	R	Combination switch output 3	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E	
35	R/B	Combination switch output 2	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E	
36	R/W	Combination switch output 1				
38	G	Ignition switch (ON)	ON	—	Battery voltage	
39	L	CAN-H	—	—	—	
40	Y	CAN-L	—	—	—	
42	Y/G	Battery power supply	OFF	—	Battery voltage	
43	W/R	Optical sensor signal	ON	When optical sensor is illuminated	3.1 V or more <sup>Note</sup>	
				When optical sensor is not illuminated	0.6 V or less	
49*	B	Ground	ON	—	0V	
52	B/W	Ground	ON	—	0V	
55	W/B	Battery power supply	OFF	—	Battery voltage	
58	O	Back door switch signal	OFF	Back door switch	ON (open)	0V
				OFF (closed)	Battery voltage	
62	GR/R	Front door switch LH signal	OFF	Front door switch LH	ON (open)	0V
					OFF (closed)	Battery voltage
63	W/G	Sliding door switch LH signal	OFF	Sliding door switch LH	ON (open)	0V
					OFF (closed)	Battery voltage

\* Early production

**NOTE:**

Optical sensor must be completely subjected to work lamp light. If the optical sensor is insufficiently illuminated, the measured value may not satisfy standard.

## Terminals and Reference Values for IPDM E/R

EKS005M8

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)	
			Ignition switch	Operation or condition		
20	R/Y	Headlamp low (RH)	ON	Lighting switch 2ND position	OFF	0V
				ON	Battery voltage	
22	R/L	Parking, license, and tail lamp	ON	Lighting switch 1ST position	OFF	0V
					ON	Battery voltage
27	L/W	Headlamp high (RH)	ON	Lighting switch HIGH or PASS position	OFF	0V
					ON	Battery voltage

# AUTO LIGHT SYSTEM

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
28	G	Headlamp high (LH)	ON	Lighting switch HIGH or PASS position	OFF 0V
					ON Battery voltage
30	L	Headlamp low (LH)	ON	Lighting switch 2ND position	OFF 0V
					ON Battery voltage
38	B	Ground	ON	—	0V
48	L	CAN-H	—	—	—
49	Y	CAN-L	—	—	—
60	B	Ground	ON	—	0V

## How to Proceed With Trouble Diagnosis

EKS005M9

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-40, "System Description"](#).
3. Carry out the Preliminary Check. Refer to [LT-48, "Preliminary Check"](#).
4. Check symptom and repair or replace the cause of malfunction. Refer to [LT-55, "Trouble Diagnosis Chart by Symptom"](#).
5. Does the auto light system operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

## Preliminary Check SETTING CHANGE FUNCTIONS

EKS005MA

- Sensitivity of auto light system can be adjusted using CONSULT-II. Refer to [LT-51, "WORK SUPPORT"](#).

## CHECK BCM CONFIGURATION

### 1. CHECK BCM CONFIGURATION

- Confirm BCM configuration for "AUTO LIGHT" is set to "WITH". Refer to [BCS-14, "READ CONFIGURATION PROCEDURE"](#).

#### OK or NG

- OK >> Continue preliminary check. Refer to [LT-48, "CHECK POWER SUPPLY AND GROUND CIRCUIT"](#).
- NG >> Change BCM configuration for "AUTO LIGHT" to "WITH". Refer to [BCS-16, "WRITE CONFIGURATION PROCEDURE"](#).

## CHECK POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES OR FUSIBLE LINK

Check for blown fuses or fusible link.

Unit	Power source	Fuse No.
BCM	Battery	j
		3
	Ignition switch ON or START position	16
	Ignition switch ACC or ON position	4
IPDM E/R	Battery	34
		36
		38
		40
		41
		45

# AUTO LIGHT SYSTEM

Refer to [LT-43, "Wiring Diagram — AUTO/L —"](#) .

**OK or NG**

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of blown fuse before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

## 2. CHECK POWER SUPPLY CIRCUIT


1. Disconnect BCM connectors.
2. Check voltage between BCM harness connector and ground.

Terminals		(-)	Ignition switch position		
(+)	Connector		Terminal (Wire color)	OFF	ACC
M18	11 (V)	Ground	0V	Battery voltage	Battery voltage
	38 (G)		0V	0V	Battery voltage
M19	42 (Y/G)		Battery voltage	Battery voltage	Battery voltage
	55 (W/B)		Battery voltage	Battery voltage	Battery voltage

**OK or NG**

OK >> GO TO 3.

NG >> Check harness for open between BCM and fuse.



## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.


Terminals		Continuity
Connector	Terminal (Wire color)	
M19	49* (B)	Ground
	52 (B/W)	
		Yes

\* Early production

**OK or NG**

OK >> Inspection End.

NG >> Check ground circuit harness.



# AUTO LIGHT SYSTEM

EKS005MB

## CONSULT-II Function (BCM)

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnostic test item	Diagnostic mode	Description
Inspection by part	WORK SUPPORT	Supports inspections and adjustments. Commands are transmitted to the BCM for setting the status suitable for required operation, input/output signals are received from the BCM and received data is displayed.
	DATA MONITOR	Displays BCM input/output data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
	SELF-DIAG RESULTS	Displays BCM self-diagnosis results.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
	ECU PART NUMBER	BCM part number can be read.
	CONFIGURATION	Performs BCM configuration read/write functions.

## CONSULT-II OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen.  
If "BCM" is not indicated, go to [GI-37, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .



# AUTO LIGHT SYSTEM

4. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.



## WORK SUPPORT

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "CUSTOM A/LIGHT SETTING" or "ILL DELAY SET" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "MODE 1-4" of setting to be changed (CUSTOM A/LIGHT SETTING). Touch "MODE1-8" of setting to be changed (ILL DELAY SET).
6. Touch "CHANGE SETT".
7. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
8. Touch "END".

### Work Support Setting Item

- Sensitivity of auto light can be selected and set from four modes.

Work item	Description
CUSTOM A/LIGHT SETTING	Auto light sensitivity can be changed in this mode. Sensitivity can be adjusted in four modes. ● MODE 1 (Normal)/ MODE 2 (Sensitive)/MODE 3 (Desensitized)/MODE4 (Insensitive)
ILL DELAY SET	Auto light delay off timer period can be changed in this mode. Selects auto light delay off timer period among eight modes. ● MODE 1 (45 sec.)/MODE 2 (OFF)/MODE 3 (30 sec.)/MODE 4 (60 sec.)/MODE 5 (90 sec.)/MODE 6 (120 sec.)/MODE 7 (150 sec.)/MODE 8 (180 sec.)

## DATA MONITOR

### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on the "SELECT MONITOR ITEM" screen.

All signals	Monitors all the signals.
Selection from menu	Selects and monitors individual signal.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch individual items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
IGN ON SW      "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
ACC ON SW      "ON/OFF"	Displays "ACC (ON)/OFF, Ignition OFF (OFF)" status judged from ignition switch signal.
HI BEAM SW      "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.

## AUTO LIGHT SYSTEM

Monitor item	Contents
HEAD LAMP SW 1    "ON/OFF"	Displays status (headlamp switch 1: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
HEAD LAMP SW 2    "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1ST        "ON/OFF"	Displays status (lighting switch 1st position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
AUTO LIGHT SW       "ON/OFF"	Displays status of the lighting switch as judged from the lighting switch signal. (AUTO position: ON/Other than AUTO position: OFF)
PASSING SW          "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
FR FOG SW            "ON/OFF"	Displays status (front fog lamp switch: ON/Others: OFF) of front fog lamp switch judged from lighting switch signal.
DOOR SW-DR          "ON/OFF"	Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-AS          "ON/OFF"	Displays status of the passenger door as judged from the passenger door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-RR          "ON/OFF"	Displays status of the sliding door as judged from the sliding door switch (RH) signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-RL          "ON/OFF"	Displays status of the sliding door as judged from the sliding door switch (LH) signal. (Door is open: ON/Door is closed: OFF)
BACK DOOR SW        "ON/OFF"	Displays status of the back door as judged from the back door switch signal. (Door is open: ON/Door is closed: OFF)
TURN SIGNAL R        "ON/OFF"	Displays status (Turn right: ON/Others: OFF) as judged from lighting switch signal.
TURN SIGNAL L        "ON/OFF"	Displays status (Turn left: ON/Others: OFF) as judged from lighting switch signal.
CARGO LAMP SW       "ON/OFF"	Displays status of cargo lamp.
OPTICAL SENSOR      [0 - 5V]	Displays "ambient light (close to 5V when dark/close to 0V when light)" judged from optical sensor signal.

### ACTIVE TEST

#### Operation Procedure

1. Touch "HEAD LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

#### Display Item List

Test item	Description
TAIL LAMP	Allows tail lamp relay to operate by switching ON-OFF.
HEAD LAMP	Allows headlamp relay (HI, LO) to operate by switching ON-OFF.
FR FOG LAMP	Allows fog lamp relay to operate by switching ON-OFF.
CARGO LAMP	Allows cargo lamp to operate by switching ON-OFF.
CORNERING LAMP	Allows cornering lamp relay (RH, LH) to operate by switching ON-OFF.

# AUTO LIGHT SYSTEM

## CONSULT-II Function (IPDM E/R)

EKS005MC

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


IPDM E/R diagnostic Mode	Description
SELF-DIAG RESULTS	Displays IPDM E/R self-diagnosis results.
DATA MONITOR	Displays IPDM E/R input/output data in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.

## CONSULT-II OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn the ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "IPDM E/R" on "SELECT SYSTEM" screen. If "IPDM E/R" is not displayed, go to [GI-37, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# AUTO LIGHT SYSTEM

- Select the desired part to be diagnosed on the "SELECT DIAG MODE" screen.



## DATA MONITOR

### Operation Procedure

- Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
- Touch "ALL SIGNALS", "MAIN SIGNALS" or "SELECTION FROM MENU" on the "SELECT MONITOR ITEM" screen.

ALL SIGNALS	All items will be monitored.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Select any item for monitoring.

- Touch "START".
- Touch the required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
- Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

### All Items, Main Items, Select Item Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Position lights request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp low beam request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
Headlamp high beam request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Front fog lights request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM
Cornering lamp	CRNRNG LMP REQ	ON/OFF	×	-	×	Signal status input from BCM

#### NOTE:

Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.

## ACTIVE TEST

### Operation Procedure

- Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
- Touch item to be tested, and check operation.
- Touch "START".
- Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Tail lamp relay output	TAIL LAMP	Allows tail lamp relay to operate by switching operation ON-OFF at your option.

# AUTO LIGHT SYSTEM

Test item	CONSULT-II screen display	Description
Headlamp relay (HI, LO) output	LAMPS	Allows headlamp relay (HI, LO) to operate by switching operation (OFF, HI, LO) at your option (Headlamp high beam repeats ON-OFF every 1 second).
Front fog lamp relay output		Allows fog lamp relay to operate by switching operation ON-OFF at your option.
Cornering lamp relay (RH, LH) output	CORNERING LAMP	Allows cornering lamp relay (RH, LH) to operate by switching operation ON-OFF at your option.

## Trouble Diagnosis Chart by Symptom

EKS005MD

Trouble phenomenon	Malfunction system and reference
<ul style="list-style-type: none"> <li>● Parking lamps and headlamps will not illuminate when outside of the vehicle becomes dark. (Lighting switch 1st position and 2nd position operate normally.)</li> <li>● Parking lamps and headlamp will not go out when outside of the vehicle becomes light. (Lighting switch 1st position and 2nd position operate normally.)</li> <li>● Headlamps go out when outside of the vehicle becomes light, but parking lamps stay on.</li> </ul>	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-51, "WORK SUPPORT"</a> .</li> <li>● Refer to <a href="#">LT-55, "Lighting Switch Inspection"</a> .</li> <li>● Refer to <a href="#">LT-56, "Optical Sensor System Inspection"</a> .</li> </ul> <p>If above systems are normal, replace BCM. Refer to <a href="#">BCS-19, "Removal and Installation of BCM"</a> .</p>
Parking lamps illuminate when outside of the vehicle becomes dark, but headlamps stay off. (Lighting switch 1st position and 2nd position operate normally.)	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-51, "WORK SUPPORT"</a> .</li> <li>● Refer to <a href="#">LT-56, "Optical Sensor System Inspection"</a> .</li> </ul> <p>If above systems are normal, replace BCM. Refer to <a href="#">BCS-19, "Removal and Installation of BCM"</a> .</p>
Auto light adjustment system will not operate. (Lighting switch AUTO, 1st position and 2nd position operate normally.)	<ul style="list-style-type: none"> <li>● Refer to <a href="#">LT-56, "Optical Sensor System Inspection"</a> .</li> </ul> <p>If above system is normal, replace BCM. Refer to <a href="#">BCS-19, "Removal and Installation of BCM"</a> .</p>
Auto light adjustment system will not operate.	<ul style="list-style-type: none"> <li>● CAN communication line to BCM inspection. Refer to <a href="#">BCS-13, "CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)"</a> .</li> </ul>
Shut off delay feature will not operate.	<ul style="list-style-type: none"> <li>● CAN communication line inspection between BCM and combination meter. Refer to <a href="#">BCS-13, "CAN Communication Inspection Using CONSULT-II (Self-Diagnosis)"</a> .</li> <li>● Refer to <a href="#">BL-40, "Door Switch Check (Without Automatic Back Door System)"</a> .</li> </ul> <p>If above system is normal, replace BCM. Refer to <a href="#">BCS-19, "Removal and Installation of BCM"</a> .</p>

## Lighting Switch Inspection

EKS005ME

### 1. CHECK LIGHTING SWITCH INPUT SIGNAL

Ⓔ With CONSULT-II

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "AUTO LIGHT SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is in AUTO position : AUTO LIGHT SW ON**

ⓧ Without CONSULT-II

Refer to [LT-102, "Combination Switch Inspection"](#) .

OK or NG

OK >> Inspection End.

NG >> Check lighting switch. Refer to [LT-102, "Combination Switch Inspection"](#) .

DATA MONITOR	
MONITOR	
AUTO LIGHT SW	ON

SKIA4196E

# AUTO LIGHT SYSTEM

EKS005MF

## Optical Sensor System Inspection

### 1. CHECK OPTICAL SENSOR INPUT SIGNAL

④ With CONSULT-II

Select "BCM" on CONSULT-II. With "OPTICAL SENSOR" data monitor, check difference in the voltage when the optical sensor is illuminated and not illuminated.

**Illuminated**

**OPTICAL SENSOR : 3.0V or less**

**Not illuminated**

**OPTICAL SENSOR : 3.1V or more**

#### CAUTION:

Optical sensor must be completely subjected to work lamp light. If the optical sensor is insufficiently illuminated, the measured value may not satisfy the standard.


⊗ Without CONSULT-II

GO TO 2.

OK or NG

OK >> Inspection End.

NG >> GO TO 2.




### 2. CHECK OPTICAL SENSOR SIGNAL GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and optical sensor connector.
3. Check continuity (open circuit) between BCM harness connector M18 terminal 18 (P) and optical sensor harness connector M402 terminal 3 (P).

**18 (P) - 3 (P) : Continuity should exist.**

4. Check continuity (short circuit) between BCM harness connector M18 terminal 18 (P) and ground.

**18 (P) - Ground : Continuity should not exist.**



OK or NG

OK >> GO TO 3.

NG >> Repair harness or connector.

### 3. CHECK OPTICAL SENSOR SIGNAL CIRCUIT

1. Check continuity (open circuit) between BCM harness connector M19 terminal 43 (W/R) and optical sensor harness connector M402 terminal 4 (W/R).

**43 (W/R) - 4 (W/R) : Continuity should exist.**


2. Check continuity (short circuit) between BCM harness connector M19 terminal 43 (W/R) and ground.

**43 (W/R) - Ground : Continuity should not exist.**

OK or NG

OK >> Replace optical sensor. Refer to [LT-57, "Removal and Installation of Optical Sensor"](#) . Recheck sensor output with CONSULT-II. If NG, replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .

NG >> Repair harness or connector.




# AUTO LIGHT SYSTEM

## Removal and Installation of Optical Sensor

EKS005MG

### REMOVAL

1. Remove defrost grille. Refer to [IP-10, "Removal and Installation"](#).
2. Disconnect the connector.
3. Turn the optical sensor counterclockwise to remove it from defroster grille.



### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M


# FRONT FOG LAMP

PFP:26150

## FRONT FOG LAMP

### Component Parts and Harness Connector Location

EKS005MH



WKIA1062E

## System Description

EKS005MI

Control of the fog lamps is dependent upon the position of the combination switch (lighting switch). The lighting switch must be in the 2ND position or AUTO position (LOW beam is ON) for front fog lamp operation. When the lighting switch is placed in the fog lamp position, the BCM (body control module) receives input signal requesting the fog lamps to illuminate. When the headlamps are illuminated, this input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the front fog lamp relay coil. When activated, this relay directs power to the front fog lamps.

## OUTLINE

Power is supplied at all times

- through 15A fuse (No. 43, located in the IPDM E/R)
- to front fog lamp relay, located in the IPDM E/R, and
- through 15A fuse (No. 34, located in the IPDM E/R)
- to CPU of the IPDM E/R, and
- through 50A fusible link (letter j, located in the fuse and fusible link box)
- to BCM terminal 55, and
- through 15A fuse [No. 3, located in the fuse block (J/B)]
- to BCM terminal 42.

When the ignition switch is in ON or START position, power is supplied

- to ignition relay, located in the IPDM E/R, and
- through 10A fuse [No. 16, located in the fuse block (J/B)]
- to BCM terminal 38.

When the ignition switch is in ACC or ON position, power is supplied

- through 10A fuse [No. 4, located in the fuse block (J/B)]

# FRONT FOG LAMP

- to BCM terminal 11.

Ground is supplied

- to BCM terminals 49 (early production) and 52
- through grounds M57, M61 and M79, and
- to IPDM E/R terminals 38 and 60
- through grounds E9, E15 and E24.

## FOG LAMP OPERATION

The fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position or AUTO position (LOW beam is ON) and the fog lamp switch must be ON for fog lamp operation.

With the fog lamp switch in the ON position, the CPU of the IPDM E/R grounds the coil side of the fog lamp relay. The fog lamp relay then directs power

- through IPDM E/R terminal 37
- to front fog lamp LH terminal +, and
- through IPDM E/R terminal 36
- to front fog lamp RH terminal +.

Ground is supplied

- to front fog lamp LH and RH terminal –
- through grounds E9, E15 and E24.

With power and grounds supplied, the front fog lamps illuminate.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#).

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 2ND position (ON), the fog lamp switch is ON, and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the fog lamps (and headlamps) remain illuminated for 5 minutes, then the fog lamps (and headlamps) are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

EKS005MJ

Refer to [LAN-6, "CAN COMMUNICATION"](#).

A

B

C

D

E

F

G

H

I

J

LT

L



M

# FRONT FOG LAMP

EKS005MK

## Wiring Diagram — F/FOG —

LT-F/FOG-01





REFER TO THE FOLLOWING.  
 (M4), (E30) - FUSE BLOCK-JUNCTION BOX (J/B)  
 (M18), (M19) - ELECTRICAL UNITS

WKWA1424E

# FRONT FOG LAMP

LT-F/FOG-02









WKWA0550E

# FRONT FOG LAMP

## Terminals and Reference Values for BCM

EKS005ML

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
2	GR/R	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>
3	G/Y	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>
4	G/R	Combination switch input 3	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>
5	G/B	Combination switch input 2	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>
6	G/W	Combination switch input 1			
11	V	Ignition switch (ACC)	ACC	—	Battery voltage
32	R/G	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>
33	R/Y	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>
34	R	Combination switch output 3	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>

# FRONT FOG LAMP

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
35	R/B	Combination switch output 2	ON	Lighting, turn, wiper OFF Wiper dial position 4	
36	R/W	Combination switch output 1			
38	G	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN-H	—	—	—
40	Y	CAN-L	—	—	—
42	Y/G	Battery power supply	OFF	—	Battery voltage
49*	B	Ground	ON	—	0V
52	B/W	Ground	ON	—	0V
55	W/B	Battery power supply (fusible link)	OFF	—	Battery voltage

\* Early production

## Terminals and Reference Values for IPDM E/R

EKS005MM

Terminal No.	Wire color	Signal name	Measuring condition			Reference value (Approx.)
			Ignition switch	Operation or condition		
36	W/G	Front fog lamp (RH)	ON	Lighting switch must be in the 2ND position or AUTO position (LOW beam is ON) and the front fog lamp switch must be ON	OFF	0V
					ON	Battery voltage
37	W/R	Front fog lamp (LH)	ON	Lighting switch must be in the 2ND position or AUTO position (LOW beam is ON) and the front fog lamp switch must be ON	OFF	0V
					ON	Battery voltage
38	B	Ground	ON	—	0V	
48	L	CAN-H	—	—	—	
49	Y	CAN-L	—	—	—	
60	B	Ground	ON	—	0V	

## How to Proceed With Trouble Diagnosis

EKS005MN

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-58, "System Description"](#) .
3. Perform the Preliminary Check. Refer to [LT-64, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the front fog lamp operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

# FRONT FOG LAMP

EKS005MO

## Preliminary Check CHECK BCM CONFIGURATION

### 1. CHECK BCM CONFIGURATION

- Confirm BCM configuration for "FR FOG LAMP" is set to "WITH". Refer to [BCS-14, "READ CONFIGURATION PROCEDURE"](#).

OK or NG

- OK >> Continue preliminary check. Refer to [LT-64, "CHECK POWER SUPPLY AND GROUND CIRCUIT"](#).
- NG >> Change BCM configuration for "FR FOG LAMP" to "WITH". Refer to [BCS-16, "WRITE CONFIGURATION PROCEDURE"](#).

## CHECK POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES OR FUSIBLE LINK

Check for blown fuses or fusible link.

Unit	Power source	Fuse No.
BCM	Battery	j
		3
	Ignition switch ON or START position	16
IPDM E/R	Battery	4
		34
		43

Refer to [LT-60, "Wiring Diagram — F/FOG —"](#).

OK or NG

- OK >> GO TO 2.
- NG >> If fuse is blown, be sure to eliminate cause of blown fuse before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#).


### 2. CHECK POWER SUPPLY CIRCUIT

- Disconnect BCM connectors.
- Check voltage between BCM harness connector and ground.

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)				
M18	11 (V)	Ground	0V	Battery voltage	Battery voltage
	38 (G)		0V	0V	Battery voltage
M19	42 (Y/G)		Battery voltage	Battery voltage	Battery voltage
	55 (W/B)		Battery voltage	Battery voltage	Battery voltage

OK or NG

- OK >> GO TO 3.
- NG >> Check harness for open between BCM and fuse.



# FRONT FOG LAMP

## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Connector	Terminals		Continuity
	Terminal (Wire color)		
M19	49* (B)	Ground	Yes
	52 (B/W)		

\* Early production

OK or NG

- OK >> Inspection End.
- NG >> Check ground circuit harness.



## CONSULT-II Functions

Refer to [LT-14, "CONSULT-II Function \(BCM\)"](#) in HEADLAMP (FOR USA).  
 Refer to [LT-17, "CONSULT-II Function \(IPDM E/R\)"](#) in HEADLAMP (FOR USA).

## Front Fog Lamps Do Not Illuminate (Both Sides)


### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

Select "BCM" on CONSULT-II. With "HEAD LAMP" data monitor, make sure "FR FOG SW" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is in FOG position : FR FOG SW ON**

OK or NG

- OK >> GO TO 2.
- NG >> Check lighting switch. Refer to [LT-102, "Combination Switch Inspection"](#).




### 2. FOG LAMP ACTIVE TEST

1. Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Select "LAMPS" on "SELECT TEST ITEM" screen.
3. Touch "FOG" on "ACTIVE TEST" screen.
4. Make sure fog lamps operate.

**Fog lamps should operate.**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 4.



# FRONT FOG LAMP


## 3. CHECK IPDM E/R

1. Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.
2. Make sure "FR FOG REQ" turns ON when lighting switch is in FOG position.

**When lighting switch is in FOG position : FR FOG REQ ON**

OK or NG


- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).
- NG >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).



## 4. IPDM E/R INSPECTION

Start auto active test. Refer to [PG-21, "Auto Active Test"](#). When front fog lamp relay is operating, check voltage between left/right front fog lamp connector terminals and ground.

Terminals			Voltage (Approx.)
Front fog lamp (+)		(-)	
Connector	Terminal (wire color)		
RH	E101	+ (W/G)	Ground
LH	E102	+ (W/R)	
			Battery voltage



OK or NG

- OK >> Check front fog lamp bulbs and replace as necessary.
- NG >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).

## Front Fog Lamp Does Not Illuminate (One Side)

EKS0066W

### 1. BULB INSPECTION

Inspect bulbs of lamps which do not illuminate.


OK or NG

- OK >> GO TO 2.
- NG >> Replace lamp bulb. Refer to [LT-68, "Bulb Replacement"](#).

### 2. INSPECTION BETWEEN IPDM E/R AND FRONT FOG LAMPS

1. Disconnect IPDM E/R connector and inoperative front fog lamp connector.
2. Check continuity between harness connector terminals of IPDM E/R and harness connector terminal of front fog lamps.

Terminals				Continuity
IPDM E/R		Front fog lamp		
Connector	Terminal (wire color)	Connector	Terminal (wire color)	
E124	36 (W/G)	RH	E101	+ (W/G)
	37 (W/R)	LH	E102	+ (W/R)
				Yes



OK or NG

- OK >> Check ground circuit. If OK, replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#). If NG, repair harness or connector.
- NG >> Check for short circuits and open circuits in harness between IPDM E/R and front fog lamps.

# FRONT FOG LAMP


EKS0066X

## Aiming Adjustment


The fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb. Before performing aiming adjustment, make sure of the following.

- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver seat.


Adjust aiming in the vertical direction by turning the adjusting screw.



1. Set the distance between the screen and the center of the fog lamp lens as shown.
2. Turn front fog lamps ON.



3. Adjust front fog lamps using adjusting screw so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown.
- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# FRONT FOG LAMP


## Bulb Replacement

EKS005MT

1. Position the front fender protector aside.
2. Disconnect electrical connector.
3. Turn the bulb counterclockwise to remove it.

### CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily matters away from it. Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.
- Do not leave bulb out of fog lamp reflector for a long time because dust, moisture, smoke, etc. May affect the performance of fog lamp. When replacing bulb, be sure to replace it with new one.



## Removal and Installation

EKS0066Y


The fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb.

### CAUTION:

- Do not leave fog lamp assembly without bulb for a long period of time. Dust, moisture, smoke, etc. entering the fog lamp body may affect the performance. Remove the bulb from the headlamp assembly just before replacement bulb is installed.
- Grasp only the plastic base when handling the bulb. Never touch the glass envelope. Touching the glass could significantly affect the bulb life and/or fog lamp performance.

1. Position the fender protector aside.
2. Disconnect electrical connector.
3. Remove bolt and pull fog lamp out of front fascia.

Install in the reverse order of removal.




# TURN SIGNAL AND HAZARD WARNING LAMPS

PF26120

EKS005MV

## TURN SIGNAL AND HAZARD WARNING LAMPS

### Component Parts and Harness Connector Location



WKIA1068E

### System Description OUTLINE

EKS005MV

Power is supplied at all times

- through 50A fusible link (letter j, located in the fuse and fusible link box)
- to BCM (body control module) terminal 55, and
- through 15A fuse [No. 3, located in the fuse block (J/B)]
- to BCM terminal 42, and
- through 15A fuse [No. 19, located in the fuse block (J/B)]
- to combination meter terminal 31.

### TURN SIGNAL OPERATION

When the ignition switch is in the ON or START position, power is supplied

- through 10A fuse [No. 16, located in the fuse block (J/B)]
- to BCM terminal 38, and
- through 10A fuse [No. 14, located in the fuse block (J/B)]
- to combination meter terminal 30.

Ground is supplied

- to BCM terminals 49 (early production) and 52 and
- to combination meter terminal 32
- through grounds M57, M61 and M79.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LT

L  
M

# TURN SIGNAL AND HAZARD WARNING LAMPS

---

## LH Turn

When the turn signal switch is moved to the left position, BCM outputs turn signal from BCM terminal 45, interpreting it as turn signal is ON.

The BCM supplies power

- through BCM terminal 45
- to front combination lamp LH terminal 2
- through front combination lamp LH terminal 1
- to grounds E9, E15 and E24, and
- to rear combination lamp LH terminal 3
- through rear combination lamp LH terminal 5
- to grounds B7 and B19.

BCM sends signal to combination meter through CAN communication lines, and turns on turn signal indicator lamp within combination meter.

## RH Turn

When the turn signal switch is moved to the right position, BCM outputs turn signal from BCM terminal 46, interpreting it as turn signal is ON.

The BCM supplies power

- through BCM terminal 46
- to front combination lamp RH terminal 2
- through front combination lamp RH terminal 1
- to grounds E9, E15 and E24, and
- to rear combination lamp RH terminal 3
- through rear combination lamp terminal 5
- to grounds B117 and B132.

BCM sends signal to combination meter through CAN communication lines, and turns on turn signal indicator lamp within combination meter.

## HAZARD LAMP OPERATION

Power is supplied at all times

- through 50A fusible link (letter j , located in the fuse and fusible link box)
- to BCM terminal 55, and
- through 15A fuse [No. 19, located in the fuse block (J/B)]
- to combination meter terminal 31.

Ground is supplied

- through BCM terminals 49 (early production) and 52
- through combination meter terminal 32
- to grounds M57, M61 and M79.

When the hazard switch is depressed, ground is supplied

- through BCM terminal 29
- to hazard switch terminal 2
- through hazard switch terminal 1
- to grounds M57, M61 and M79.

When the hazard switch is depressed, BCM outputs turn signal from BCM terminals 45 and 46, interpreting it as turn signal is ON.

The BCM supplies power

- through BCM terminals 45 and 46
- to front combination lamp LH and RH terminal 2
- through front combination lamp LH and RH terminal 1
- to grounds E9, E15 and E24, and
- to rear combination lamp LH terminal 3
- through rear combination lamp LH terminal 5

# TURN SIGNAL AND HAZARD WARNING LAMPS

- to grounds B7 and B19, and
- to rear combination lamp RH terminal 3
- through rear combination lamp terminal 5
- to grounds B117 and B132.

BCM sends signal to combination meter through CAN communication lines, and turns on turn signal indicator lamps within combination meter.

## REMOTE KEYLESS ENTRY SYSTEM OPERATION

Power is supplied at all times

- through 50A fusible link (letter j , located in the fuse and fusible link box)
- to BCM terminal 55, and
- through 10A fuse [No. 3, located in the fuse block (J/B)]
- to BCM terminal 42, and
- through 15A fuse [No. 19, located in the fuse block (J/B)]
- to combination meter terminal 31.

Ground is supplied

- to BCM terminals 49 (early production) and 52 and
- to combination meter terminal 32
- through grounds M57, M61 and M79.

When the remote keyless entry system is triggered by input from the keyfob, BCM output turn signal from BCM terminals 45 and 46, interpreting it as turn signal is ON.

The BCM supplies power

- through BCM terminals 45 and 46
- to front combination lamp LH and RH terminal 2
- through front combination lamp LH and RH terminal 1
- to grounds E9, E15 and E24, and
- to rear combination lamp LH terminal 3
- through rear combination lamp LH terminal 5
- to grounds B7 and B19, and
- to rear combination lamp RH terminal 3
- through rear combination lamp terminal 5
- to grounds B117 and B132.

BCM sends signal to combination meter through CAN communication lines, and turns on turn signal indicator lamps within combination meter.

With power and input supplied, the BCM controls the flashing of the hazard warning lamps when keyfob is used to activate the remote keyless entry system.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## CAN Communication System Description

Refer to [LAN-6, "CAN COMMUNICATION"](#) .


EKS005MX

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# TURN SIGNAL AND HAZARD WARNING LAMPS

## Schematic

EKS005MY



WKWA1677E



# TURN SIGNAL AND HAZARD WARNING LAMPS

## Wiring Diagram — TURN —

EKS005MZ

### LT-TURN-01

EP : EARLY PRODUCTION





REFER TO THE FOLLOWING.  
 M4, E30 - FUSE BLOCK-JUNCTION BOX (J/B)  
 M18, M19 - ELECTRICAL UNITS

WKWA1419E

# TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-02





REFER TO THE FOLLOWING.  
(M18), (M19) - ELECTRICAL UNITS

WKWA1803E

# TURN SIGNAL AND HAZARD WARNING LAMPS

LT-TURN-03



REFER TO THE FOLLOWING.





(M4) - FUSE BLOCK - JUNCTION BOX (J/B)

WKWA0554E




# TURN SIGNAL AND HAZARD WARNING LAMPS

EKS005N0

## Terminals and Reference Values for BCM

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)	
			Ignition switch	Operation or condition		
2	GR/R	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5291E</p>	
3	G/Y	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5292E</p>	
4	G/R	Combination switch input 3	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5291E</p>	
5	G/B	Combination switch input 2	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5292E</p>	
6	G/W	Combination switch input 1				
11	V	Ignition switch (ACC)	ACC	—	Battery voltage	
29	Y/R	Hazard switch signal	OFF	Hazard switch	ON	0V
					OFF	5V
32	R/G	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5291E</p>	
33	R/Y	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5292E</p>	

# TURN SIGNAL AND HAZARD WARNING LAMPS

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)	
			Ignition switch	Operation or condition		
34	R	Combination switch output 3	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E	
35	R/B	Combination switch output 2	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E	
36	R/W	Combination switch output 1				
38	G	Ignition switch (ON)	ON	—	Battery voltage	
39	L	CAN-H	—	—	—	
40	Y	CAN-L	—	—	—	
42	Y/G	Battery power supply	OFF	—	Battery voltage	
45	GR/L	Turn signal (left)	ON	Combination switch	Turn left ON	 SKIA3009J
46	G/R	Turn signal (right)	ON	Combination switch	Turn right ON	 SKIA3009J
49*	B	Ground	ON	—	0V	
52	B/W	Ground	ON	—	0V	
55	W/B	Battery power supply	OFF	—	Battery voltage	

\* Early production

## How to Proceed With Trouble Diagnosis

EKS005N1

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-69, "System Description"](#).
3. Perform preliminary check. Refer to [LT-78, "Preliminary Check"](#).
4. Check symptom and repair or replace the cause of malfunction.
5. Do turn signal and hazard warning lamps operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

# TURN SIGNAL AND HAZARD WARNING LAMPS

EKS005N2

## Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES OR FUSIBLE LINK

Check for blown fuses or fusible link.

Unit	Power source	Fuse No.
BCM	Battery	j
	Battery	3
	Ignition switch ON or START position	16
	Ignition switch ACC or ON position	4

Refer to [LT-73, "Wiring Diagram — TURN —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of blown fuse before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

### 2. CHECK POWER SUPPLY CIRCUIT


1. Disconnect BCM connectors.
2. Check voltage between BCM harness connector and ground.

Terminals		Ignition switch position			
Connector	(+)	(-)	OFF	ACC	ON
	M18	11 (V)	Ground	0V	Battery voltage
38 (G)		0V		0V	Battery voltage
M19	42 (Y/G)	Battery voltage		Battery voltage	Battery voltage
	55 (W/B)	Battery voltage		Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open between BCM and fuse.



### 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.


Terminals		Continuity
Connector	Terminal (Wire color)	
M19	49* (B)	Ground
	52 (B/W)	

\* Early production

OK or NG

OK >> Inspection End.

NG >> Check ground circuit harness.



# TURN SIGNAL AND HAZARD WARNING LAMPS

## CONSULT-II Function (BCM)

EKS005N3

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnostic test item	Diagnostic mode	Description
Inspection by part	WORK SUPPORT	Supports inspections and adjustments. Commands are transmitted to the BCM for setting the status suitable for required operation, input/output signals are received from the BCM and received data is displayed.
	DATA MONITOR	Displays BCM input/output data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
	SELF-DIAG RESULTS	Displays BCM self-diagnosis results.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
	ECU PART NUMBER	BCM part number can be read.
	CONFIGURATION	Performs BCM configuration read/write functions.

## CONSULT-II OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen. If "BCM" is not indicated, go to [GI-37, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# TURN SIGNAL AND HAZARD WARNING LAMPS

4. Touch "FLASHER" on "SELECT TEST ITEM" screen.



## DATA MONITOR

### Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on the "SELECT MONITOR ITEM" screen.

All signals	Monitors all the signals.
Selection from menu	Selects and monitors the individual signal.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
HAZARD SW "ON/OFF"	Displays "Hazard ON (ON)/Hazard OFF (OFF)" status, determined from hazard switch signal.
TURN SIGNAL R "ON/OFF"	Displays "Turn right (ON)/Other (OFF)" status, determined from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays "Turn left (ON)/Other (OFF)" status, determined from lighting switch signal.
BRAKE SW "OFF"	Displays status of parking brake switch.

## ACTIVE TEST

### Operation Procedure

1. Touch "FLASHER" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

### Display Item List

Test item	Description
FLASHER (RH)	Turn signal lamp (RH) can be operated by any ON-OFF operations.
FLASHER (LH)	Turn signal lamp (LH) can be operated by any ON-OFF operations.

# TURN SIGNAL AND HAZARD WARNING LAMPS

EKS005N4

## Turn Signal Lamp Does Not Operate

### 1. CHECK COMBINATION SWITCH INPUT SIGNAL

Ⓜ With CONSULT-II

Select "BCM" on CONSULT-II. With "FLASHER" data monitor, make sure "TURN SIGNAL R" and "TURN SIGNAL L" turns ON-OFF linked with operation of lighting switch.

**When lighting switch is in : TURN SIGNAL R ON  
TURN RH position**

**When lighting switch is in : TURN SIGNAL L ON  
TURN LH position**

ⓧ Without CONSULT-II

Refer to [LT-102, "Combination Switch Inspection"](#).

OK or NG

OK >> GO TO 2.

NG >> Check lighting switch. Refer to [LT-102, "Combination Switch Inspection"](#).

DATA MONITOR	
MONITOR	
TURN SIGNAL R	ON
TURN SIGNAL L	ON

SKIA4499E

### 2. ACTIVE TEST

Ⓜ With CONSULT-II

1. Select "FLASHER" during active test. Refer to [LT-80, "ACTIVE TEST"](#).

2. Make sure "FLASHER RH" and "FLASHER LH" operate.

ⓧ Without CONSULT-II

GO TO 3.

OK or NG

OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).

NG >> GO TO 3.

ACTIVE TEST	
FLASHER	
RH	LH
MODE	BACK
LIGHT	COPY

SKIA6190E

### 3. CHECK TURN SIGNAL LAMPS CIRCUIT

1. Turn ignition switch OFF.

2. Disconnect BCM connector and front combination lamp LH and RH connectors.

3. Check continuity between BCM harness connector M19 terminal 45 (GR/L) and front combination lamp LH harness connector E11 terminal 2 (GR/L).

**45 (GR/L) - 2 (GR/L) : Continuity should exist.**


4. Check continuity between BCM harness connector M19 terminal 46 (G/R) and front combination lamp RH harness connector E107 terminal 2 (G/R).

**46 (G/R) - 2 (G/R) : Continuity should exist.**

OK or NG

OK >> GO TO 4.

NG >> Repair harness or connector.



# TURN SIGNAL AND HAZARD WARNING LAMPS

## 4. CHECK GROUND

1. Check continuity between front combination lamp LH harness connector E11 terminal 1 (B) and ground.


**1 (B) - Ground : Continuity should exist.**

2. Check continuity between front combination lamp RH harness connector E107 terminal 1 (B) and ground.

**1 (B) - Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 5.  
NG >> Repair harness or connector.



## 5. CHECK BULB

Check bulb standard of each turn signal lamp is correct.

OK or NG

- OK >> Replace BCM if turn signal lamps do not work after setting the connector again. Refer to [BCS-19, "Removal and Installation of BCM"](#).  
NG >> Replace turn signal lamp bulb. Refer to [LT-27, "FRONT TURN SIGNAL/PARKING LAMP"](#).

## Rear Turn Signal Lamp Does Not Operate

EKS005N5

### 1. CHECK TAIL LAMPS AND STOP LAMPS

Check bulb standard of each turn signal lamp is correct.

OK or NG

- OK >> GO TO 2.  
NG >> Replace turn signal lamp bulb. Refer to [LT-124, "Bulb Replacement"](#).

### 2. CHECK TURN SIGNAL LAMPS CIRCUIT

1. Disconnect BCM connector and rear combination lamp connector.

2. Check continuity between BCM harness connector M19 terminal 46 (G/R) and rear combination lamp RH harness connector B130 terminal 3 (G/R).


**46 (G/Y) - 3 (G/R) : Continuity should exist.**

3. Check continuity between BCM harness connector M19 terminal 45 (GR/L) and rear combination lamp LH harness connector B35 terminal 3 (GR/L).

**45 (GR/L) - 3 (GR/L) : Continuity should exist.**

OK or NG

- OK >> GO TO 3.  
NG >> Repair harness or connector.



# TURN SIGNAL AND HAZARD WARNING LAMPS


## 3. CHECK GROUND CIRCUIT

Check continuity between rear combination lamp harness connector B35 LH and B130 RH terminal 5 (B) and ground.

**5 (B) - Ground : Continuity should exist.**

OK or NG

- OK >> Check rear combination lamp connector for proper connection. Repair as necessary.
- NG >> Repair harness or connector.



## Hazard Warning Lamp Does Not Operate But Turn Signal Lamps Operate

EKS005N6

### 1. CHECK BULB

Make sure bulb standard of each turn signal lamp is correct.

OK or NG


- OK >> GO TO 2.
- NG >> Replace turn signal lamp bulb. Refer to [LT-27, "FRONT TURN SIGNAL/PARKING LAMP"](#) for front turn signal bulb. Refer to [LT-124, "Bulb Replacement"](#) for rear turn signal bulb.

### 2. CHECK HAZARD SWITCH INPUT SIGNAL

Ⓜ With CONSULT-II

Select "BCM" on CONSULT-II. With "FLASHER" data monitor, make sure "HAZARD SW" turns ON-OFF linked with operation of hazard switch.

**When hazard switch is in ON position : HAZARD SW ON**




⊗ Without CONSULT-II

Check voltage between BCM harness connector M18 terminal 29 (Y/R) and ground.

Terminals			Condition	Voltage (Approx.)
(+)		(-)		
Connector	Terminal (Wire color)			
M18	29 (Y/R)	Ground	Hazard switch is ON	0V
			Hazard switch is OFF	5V

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.



# TURN SIGNAL AND HAZARD WARNING LAMPS


## 3. CHECK HAZARD SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and hazard switch connector.
3. Check continuity between BCM harness connector M18 terminal 29 (Y/R) and hazard switch harness connector M55 terminal 2 (Y/R).

**29 (Y/R) - 2 (Y/R) : Continuity should exist.**

OK or NG

- OK >> GO TO 4.  
 NG >> Repair harness or connector.




## 4. CHECK GROUND

Check continuity between hazard switch harness connector M55 terminal 1 (B) and ground.

**1 (B) - Ground : Continuity should exist.**

OK or NG

- OK >> GO TO 5.  
 NG >> Repair harness or connector.




## 5. CHECK HAZARD SWITCH

1. Disconnect hazard switch connector.
2. Check continuity of hazard switch.

Terminal		Condition	Continuity
Hazard switch			
1	2	Hazard switch is ON	Yes
		Hazard switch is OFF	No

OK or NG

- OK >> Replace BCM if turn signal lamps does not work after setting the connector again. Refer to [BCS-19, "Removal and Installation of BCM"](#) .  
 NG >> Replace hazard switch. Refer to [LT-98, "Removal and Installation"](#) .



## Turn Signal Indicator Lamp Does Not Operate

EKS005N7

### 1. CHECK CAN COMMUNICATION SYSTEM

Check CAN communication. Refer to [LAN-6, "CAN COMMUNICATION"](#) .

OK or NG

- OK >> Replace combination meter. Refer to [IP-12, "Combination Meter"](#) .  
 NG >> Repair as necessary.

# TURN SIGNAL AND HAZARD WARNING LAMPS

---

## Bulb Replacement (Front Turn Signal Lamp)

EKS005N8

Refer to [LT-27, "FRONT TURN SIGNAL/PARKING LAMP"](#) .

A

## Bulb Replacement (Rear Turn Signal Lamp)

EKS005N9

Refer to [LT-124, "Bulb Replacement"](#) in REAR COMBINATION LAMP.

B

## Removal and Installation of Front Turn Signal Lamp

EKS005NA

Refer to [LT-27, "Removal and Installation"](#) .

C

## Removal and Installation of Rear Turn Signal Lamp

EKS005NB

Refer to [LT-124, "Removal and Installation"](#) in REAR COMBINATION LAMP.

D

E

F

G

H

I

J

LT

L

M


# CORNERING LAMP

PF2:26100

## CORNERING LAMP

### Component Parts and Harness Connector Location

EKS005NC



WKIA1072E

## System Description

### OUTLINE

EKS005ND

Power is supplied at all times

- through 50A fusible link (letter j, located in the fuse and fusible link box)
- to BCM (body control module) terminal 55, and
- through 15A fuse [No. 3, located in the fuse block (J/B)]
- to BCM terminal 42, and
- through 15A fuse [No. 34, located in the IPDM E/R (intelligent power distribution module engine room)]
- to CPU (central processing unit) of the IPDM E/R, and
- through 15A fuse (No. 41, located in the IPDM E/R)
- to cornering lamp relay LH and RH.

### CORNERING LAMP OPERATION

When the ignition switch is in the ON or START position, power is supplied

- to ignition relay, located in the IPDM E/R
- through 15A fuse [No. 16, located in the fuse block (J/B)]
- to BCM terminal 38.

Ground is supplied

- to BCM terminals 49 (early production) and 52
- through grounds M57, M61 and M79, and
- to IPDM E/R terminals 38 and 60

# CORNERING LAMP

- through grounds E9, E15 and E24.

## LH Turn

When the lighting switch is in the 2nd position or in the AUTO position (headlamp ON) and turn signal switch is moved to the left position, BCM sends signal through CAN communication lines to IPDM E/R. IPDM E/R then operates cornering lamp relay LH. It sends power from IPDM E/R terminal 34 to cornering lamp LH terminal +. Cornering lamp turns on

- through cornering lamp terminal –
- to grounds E9, E15 and E24.

## RH Turn

When the lighting switch is in the 2nd position or in the AUTO position (headlamp ON) and turn signal switch is moved to the right position, BCM sends signal through CAN communication lines to IPDM E/R. IPDM E/R then operates cornering lamp relay RH. It sends power from IPDM E/R terminal 23 to cornering lamp RH terminal +.

Cornering lamp turns on

- through cornering lamp terminal –
- to grounds E9, E15 and E24.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## CAN Communication System Description

Refer to [LAN-6, "CAN COMMUNICATION"](#) .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


EKS005NE

LT

# CORNERING LAMP

## Schematic

EKS005NF



EP : EARLY PRODUCTION  
 \* : THIS RELAY IS BUILT INTO THE IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)



WKWA2794E

# CORNERING LAMP

## Wiring Diagram — CORNER —

EKS005NG

### LT-CORNER-01




REFER TO THE FOLLOWING.  
 (M4), (E30) - FUSE BLOCK-JUNCTION BOX (J/B)  
 (M18), (M19) - ELECTRICAL UNITS

WKWA1425E

# CORNERING LAMP

LT-CORNER-02




1	2	3	4	5	6	7	8	9	10	11	(M90)		
12	13	14	15	16	17	18	19	20	21	22	23	24	W

45	46	47	48	49	50	51	52	(E121)	17	18	19	20	21	22	23	(E122)	33	34	35	36	37	(E124)				
53	54	55	56	57	58	59	60	W	24	25	26	27	28	29	30	31	32	GR	38	39	40	41	42	43	44	W


WKWA0556E

# CORNERING LAMP

LT-CORNER-03



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M









WKWA0557E

# CORNERING LAMP

## Terminals and Reference Values for BCM

EKS005NH

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
2	GR/R	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5291E</p>
3	G/Y	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5292E</p>
4	G/R	Combination switch input 3	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5291E</p>
5	G/B	Combination switch input 2	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5292E</p>
6	G/W	Combination switch input 1			
11	V	Ignition switch (ACC)	ACC	—	Battery voltage
32	R/G	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5291E</p>
33	R/Y	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5292E</p>
34	R	Combination switch output 3	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right; font-size: small;">SKIA5291E</p>

# CORNERING LAMP

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
35	R/B	Combination switch output 2	ON	Lighting, turn, wiper OFF Wiper dial position 4	
36	R/W	Combination switch output 1			
38	G	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN-H	—	—	—
40	Y	CAN-L	—	—	—
42	Y/G	Battery power supply	OFF	—	Battery voltage
49*	B	Ground	ON	—	0V
52	B/W	Ground	ON	—	0V
55	W/B	Battery power supply (fusible link)	OFF	—	Battery voltage

\* Early production

## Terminals and Reference Values for IPDM E/R

EKS005NI

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
23	W/L	Cornering lamp RH	ON	Lighting switch in RH position	OFF 0V
					ON Battery voltage
34	W/G	Cornering lamp LH	ON	Lighting switch in LH position	OFF 0V
					ON Battery voltage
38	B	Ground	ON	—	0V
48	L	CAN-H	—	—	—
49	Y	CAN-L	—	—	—
60	B	Ground	ON	—	0V

## How to Proceed With Trouble Diagnosis

EKS005NJ

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-86, "System Description"](#).
3. Perform preliminary check. Refer to [LT-94, "Preliminary Check"](#).
4. Check symptom and repair or replace the cause of malfunction.
5. Do turn signal and hazard warning lamps operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

# CORNERING LAMP

EKS005NK

## Preliminary Check CHECK POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES OR FUSIBLE LINK

Check for blown fuses or fusible link.

Unit	Power source	Fuse No.
BCM	Battery	j
	Battery	3
	Ignition switch ON or START position	16
	Ignition switch ACC or ON position	4
IPDM E/R	Battery	41

Refer to [LT-89, "Wiring Diagram — CORNER —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of blown fuse before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

### 2. CHECK POWER SUPPLY CIRCUIT


1. Disconnect BCM connectors.
2. Check voltage between BCM harness connector and ground.

Terminals		(-)	Ignition switch position		
(+)			OFF	ACC	ON
M18	11 (V)	Ground	0V	Battery voltage	Battery voltage
	38 (G)		0V	0V	Battery voltage
M19	42 (Y/G)		Battery voltage	Battery voltage	Battery voltage
	55 (W/B)		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open between BCM and fuse.



# CORNERING LAMP

## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Connector	Terminals		Continuity
	Terminal (Wire color)		
M19	49* (B)	Ground	Yes
	52 (B/W)		

\* Early production

**OK or NG**

- OK >> Inspection End.
- NG >> Check ground circuit harness.



## CONSULT-II Function

Refer to [LT-79, "CONSULT-II Function \(BCM\)"](#) in TURN SIGNAL AND HAZARD WARNING LAMPS.  
Refer to [LT-17, "CONSULT-II Function \(IPDM E/R\)"](#) in HEADLAMP (FOR USA).

## Cornering Lamp Does Not Operate

### 1. ACTIVE TEST

Ⓜ With CONSULT-II


- Select "IPDM E/R" on CONSULT-II, and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
- Select "CORNERING LAMP" on "SELECT TEST ITEM" screen.
- Select "LH", then "RH" during active test.
- Make sure cornering lamp LH and cornering lamp RH operate.

ⓧ Without CONSULT-II

GO TO 3.

**OK or NG**

- OK >> GO TO 2.
- NG >> GO TO 3.



### 2. CHECK COMBINATION SWITCH INPUT SIGNAL

Select "IPDM E/R" on CONSULT-II, and select "DATA MONITOR" on "SELECT DIAG MODE" screen.

Make sure "CRNRNG LMP REQ" turns ON-OFF linked with operation of lighting switch.

**NOTE:**


Lighting switch must not be in OFF position.

**When lighting switch is in : CRNRNG LMP REQ R  
TURN RH position**

**When lighting switch is in : CRNRNG LMP REQ L  
TURN LH position**

**OK or NG**

- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).
- NG >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).



# CORNERING LAMP

## 3. CHECK BULB

Check bulb standard of each cornering lamp is correct.

OK or NG

OK >> GO TO 4.

NG >> Replace cornering lamp bulb. Refer to [LT-96. "Bulb Replacement"](#).

## 4. CHECK CORNERING LAMPS CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connectors and cornering lamp LH and RH connectors.
3. Check continuity between IPDM E/R harness connector E122 terminal 23 (W/L) and cornering lamp RH harness connector E137 terminal + (W/L).

**23 (W/L) - + (W/L) : Continuity should exist.**

4. Check continuity between IPDM E/R harness connector E124 terminal 34 (W/G) and front cornering lamp LH harness connector E43 terminal + (W/G).

**34 (W/G) - + (W/G) : Continuity should exist.**

OK or NG

OK >> GO TO 5.

NG >> Repair harness or connector.

## 5. CHECK GROUND

1. Check continuity between cornering lamp LH harness connector E43 terminal – (B) and ground.

**– (B) - Ground : Continuity should exist.**

2. Check continuity between cornering lamp RH harness connector E137 terminal – (B) and ground.

**– (B) - Ground : Continuity should exist.**



OK or NG

OK >> Replace IPDM E/R. Refer to [PG-27. "Removal and Installation of IPDM E/R"](#).

NG >> Repair harness or connector.

## Bulb Replacement

1. Turn the bulb socket counterclockwise to unlock it.
2. Pull the bulb to remove it from the socket.
3. Installation is reverse order of removal.



EKS005NN

# LIGHTING AND TURN SIGNAL SWITCH

## LIGHTING AND TURN SIGNAL SWITCH


PF2:25540

### Removal and Installation

EKS005NO

#### REMOVAL

1. Remove steering column cover.
2. While pressing tabs, pull lighting and turn signal switch toward driver door and disconnect from the base.



#### INSTALLATION

Installation in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# HAZARD SWITCH

## HAZARD SWITCH


PF2P:25290

### Removal and Installation

EKS005NP

#### REMOVAL

1. Remove AV switch. Refer to [AV-69, "Removal and Installation for AV Switch"](#).
2. While pressing the tabs, push out the hazard switch.



#### INSTALLATION

Install in the reverse order of removal.

# COMBINATION SWITCH



PF:25567

EKS005NQ

## COMBINATION SWITCH

### Wiring Diagram — COMBSW —

### LT-COMBSW-01



REFER TO THE FOLLOWING.  
 (M4), (E30) - FUSE BLOCK-JUNCTION BOX (J/B)  
 (M18), (M19) - ELECTRICAL UNITS

WKWA1426E

# COMBINATION SWITCH

## Combination Switch Reading Function

EKS005NR

For details, refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#).

## CONSULT-II Function (BCM)

EKS005NS

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnostic test item	Diagnostic mode	Description
Inspection by part	WORK SUPPORT	Supports inspections and adjustments. Commands are transmitted to the BCM for setting the status suitable for required operation, input/output signals are received from the BCM and received data is displayed.
	DATA MONITOR	Displays BCM input/output data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
	SELF-DIAG RESULTS	Displays BCM self-diagnosis results.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
	ECU PART NUMBER	BCM part number can be read.
	CONFIGURATION	Performs BCM configuration read/write functions.

## CONSULT-II OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen.  
If "BCM" is not indicated, go to [GI-37, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



# COMBINATION SWITCH

4. Touch "COMB SW".



## DATA MONITOR

### Operation Procedure

1. Touch "COMB SW" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

ALL SIGNALS	Monitors all the signals.
SELECTION FROM MENU	Selects and monitors individual signal.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the signals will be monitored.
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

### Display Item List

Monitor item name "OPERATION OR UNIT"	Contents
TURN SIGNAL R "ON/OFF"	Displays "Turn Right (ON)/Other (OFF)" status, determined from lighting switch signal.
TURN SIGNAL L "ON/OFF"	Displays "Turn Left (ON)/Other (OFF)" status, determined from lighting switch signal.
HI BEAM SW "ON/OFF"	Displays status (high beam switch: ON/Others: OFF) of high beam switch judged from lighting switch signal.
HEAD LAMP SW 1 "ON/OFF"	Displays "Headlamp switch 1 (ON)/Other (OFF)" status, determined from lighting switch signal.
HEAD LAMP SW 2 "ON/OFF"	Displays status (headlamp switch 2: ON/Others: OFF) of headlamp switch 2 judged from lighting switch signal.
LIGHT SW 1ST "ON/OFF"	Displays status (lighting switch 1st position: ON/Others: OFF) of lighting switch judged from lighting switch signal.
PASSING SW "ON/OFF"	Displays status (flash-to-pass switch: ON/Others: OFF) of flash-to-pass switch judged from lighting switch signal.
AUTO LIGHT SW "ON/OFF"	Displays "Auto light switch (ON)/Other (OFF)" status, determined from lighting switch signal.
FR FOG SW "ON/OFF"	Displays "Front fog lamp switch (ON)/Other (OFF)" status, determined from lighting switch signal.
FR WIPER HI "ON/OFF"	Displays "Front Wiper HI (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WIPER LOW "ON/OFF"	Displays "Front Wiper LOW (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WIPER INT "ON/OFF"	Displays "Front Wiper INT (ON)/Other (OFF)" status, determined from wiper switch signal.
FR WASHER SW "ON/OFF"	Displays "Front Washer Switch (ON)/Other (OFF)" status, determined from wiper switch signal.
INT VOLUME [1 - 7]	Displays intermittent operation knob setting (1 - 7), determined from wiper switch signal.
RR WIPER ON "ON/OFF"	Displays "Rear Wiper (ON)/(OFF)" status, determined from wiper switch signal.
RR WIPER INT "ON/OFF"	Displays "Rear Wiper INT (ON)/(OFF)" status, determined from wiper switch signal.
RR WASHER SW "ON/OFF"	Displays "Rear Washer (ON)/(OFF)" status, determined from wiper switch signal.

# COMBINATION SWITCH

EKS005NT

## Combination Switch Inspection

### 1. SYSTEM CHECK

1. Referring to table below, check to which system malfunctioning switch belongs.

System 1	System 2	System 3	System 4	System 5
—	FR WASHER	FR WIPER LO	TURN LH	TURN RH
FR WIPER HI	—	FR WIPER INT	PASSING	HEAD LAMP1
INT VOLUME 1	RR WASHER	—	HEAD LAMP2	HI BEAM
RR WIPER INT	INT VOLUME 3	AUTO LIGHT	—	TAIL LAMP
INT VOLUME 2	RR WIPER ON	—	FR FOG	—

>> GO TO 2.

### 2. SYSTEM CHECK

 With CONSULT-II

#### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.

1. Connect CONSULT-II, and select "COMB SW" on "SELECT TEST ITEM" screen.
2. Select "DATA MONITOR".
3. Select "START", and confirm that other switches in malfunctioning system operate normally.

Example: When auto light switch is malfunctioning, confirm that "FRONT WIPER LOW" and "FRONT WIPER INT" in System 3, to which the auto light switch belongs, turn ON-OFF normally.

DATA MONITOR	
MONITOR	
TURN SIGNAL R	OFF
TURN SIGNAL L	OFF
HIBEAM SW	OFF
HEAD LAMP SW1	OFF
HEAD LAMP SW2	OFF
LIGHT SW 1ST	OFF
PASSING SW	OFF
AUTO LIGHT SW	OFF
FR FOG SW	OFF
	Page Down
	RECORD
MODE	BACK
LIGHT	COPY

SKIA7075E

 Without CONSULT-II

Operate combination switch, and confirm that other switches in malfunctioning system operate normally.

Example: When auto light switch is malfunctioning, confirm that "FRONT WIPER LOW" and "FRONT WIPER INT" in System 3, to which the auto light switch belongs, operate normally.

#### Check results

Other switches in malfunctioning system operate normally.>>Replace lighting switch or wiper switch.


Other switches in malfunctioning system do not operate normally.>>GO TO 3.

# COMBINATION SWITCH

## 3. HARNESS INSPECTION

1. Disconnect BCM and combination switch connectors.
2. Check for continuity between BCM harness connector of the suspect system and the corresponding combination switch connector terminals.

Suspect system	Terminals				Continuity	
	BCM		Combination switch			
	Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
1	M18	Input 1	6 (G/W)	M28	6 (G/W)	Yes
		Output 1	36 (R/W)		1 (R/W)	
2		Input 2	5 (G/B)		7 (G/B)	
		Output 2	35 (R/B)		2 (R/B)	
3		Input 3	4 (G/R)		10 (G/R)	
		Output 3	34 (R)		3 (R)	
4		Input 4	3 (G/Y)		9 (G/Y)	
		Output 4	33 (R/Y)		4 (R/Y)	
5		Input 5	2 (GR/R)		8 (GR/R)	
		Output 5	32 (R/G)		5 (R/G)	



3. Check for continuity between each terminal of BCM harness connector in suspect malfunctioning system and ground.

Suspect system	Terminals			Continuity	
	BCM				
	Connector	Terminal (Wire color)			
1	M18	Input 1	6 (G/W)	Ground	No
		Output 1	36 (R/W)		
2		Input 2	5 (G/B)		
		Output 2	35 (R/B)		
3		Input 3	4 (G/R)		
		Output 3	34 (R)		
4		Input 4	3 (G/Y)		
		Output 4	33 (R/Y)		
5		Input 5	2 (GR/R)		
		Output 5	32 (R/G)		

**OK or NG**

OK >> GO TO 4.

NG >> Check harness between BCM and combination switch for open or short circuit.

# COMBINATION SWITCH

## 4. BCM OUTPUT TERMINAL INSPECTION


1. Turn lighting switch and wiper switch to OFF.
2. Set wiper dial to position 4.
3. Connect BCM and combination switch connectors, and check BCM output terminal voltage waveform of suspect malfunctioning system.

Suspect system	Terminals	
	Combination switch (+)	
	Connector	Terminal (Wire color)
1	M28	Output 1 1 (R/W)
2		Output 2 2 (R/B)
3		Output 3 3 (R)
4		Output 4 4 (R/Y)
5		Output 5 5 (R/G)

OK or NG

OK >> Open circuit in combination switch, GO TO 5.

NG >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .



## 5. COMBINATION SWITCH INSPECTION

Referring to table below, perform combination switch inspection.

Procedure									
1	2		3	4		5	6		7
Replace lighting switch.	Confirm check results.	OK	INSPECTION END	Confirm check results.	OK	INSPECTION END	Confirm check results.	OK	INSPECTION END
		NG	Replace wiper switch.		NG	Replace switch base.		NG	Confirm symptom again.

>> Inspection End.

### Removal and Installation

For details, refer to [LT-97, "Removal and Installation"](#) .

### Switch Circuit Inspection

For details, refer to [LT-102, "Combination Switch Inspection"](#) .

EKS005NU

EKS005NV

# STOP LAMP

## STOP LAMP

PFP:26550

### System Description

EKS005NW

Power is supplied at all times

- through 10A fuse [No. 20, located in fuse block (J/B)]
- to stop lamp switch terminal 1.

When the brake pedal is pressed, the stop lamp switch is closed and power is supplied

- through stop lamp switch terminal 2
- to rear combination lamp LH and RH terminal 1 and
- to high-mounted stop lamp terminal +.

Ground is supplied

- to rear combination lamp LH terminal 5
- through grounds B7 and B19, and
- to rear combination lamp RH terminal 5
- through grounds B117 and B132, and
- to high-mounted stop lamp terminal –
- through grounds D403 and D404.

With power and ground supplied, the stop lamps illuminate.

A

B

C

D

E

F

G

H

I

J

LT

L


M

# STOP LAMP


## Wiring Diagram — STOP/L —

EKS005NX

### LT-STOP/L-01



- WC : WITH BACK DOOR AUTO CLOSURE SYSTEM
- XC : WITHOUT BACK DOOR AUTO CLOSURE SYSTEM
- \*1 WC : 19  
XC : 2
- \*2 WC : 19  
XC : 2
- \*3 WC : 14  
XC : 6



REFER TO THE FOLLOWING.  
 (E30) - FUSE BLOCK - JUNCTION BOX (J/B)

WKWA0558E


# STOP LAMP

## High-Mounted Stop Lamp

EKS005NY

### BULB REPLACEMENT, REMOVAL AND INSTALLATION

1. Remove back door upper finisher. Refer to [EI-34, "BACK DOOR UPPER FINISHER"](#) .
2. Remove rear washer nozzle.
3. Disconnect connector.
4. Remove 2 nuts and remove high-mounted stop lamp.
5. Turn bulb socket counterclockwise to remove it from the high-mounted stop lamp housing.
6. Pull bulb from socket.
7. Install in the reverse order of removal.



## Stop Lamp

### BULB REPLACEMENT

EKS005NZ

Refer to [LT-124, "Bulb Replacement"](#) in REAR COMBINATION LAMP.

### REMOVAL AND INSTALLATION

Refer to [LT-124, "Removal and Installation"](#) in REAR COMBINATION LAMP.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

LT

# BACK-UP LAMP


PF:26550

EKS00500


## BACK-UP LAMP

### Wiring Diagram — BACK/L —

### LT-BACK/L-01



- ⬡A4 : WITH 4-SPEED A/T
- ⬡A5 : WITH 5-SPEED A/T
- \*1 ⬡A4 : 3
- ⬡A5 : 2
- \*2 ⬡A4 : 8
- ⬡A5 : 4



REFER TO THE FOLLOWING.

⬡M4 - FUSE BLOCK - JUNCTION BOX (J/B)

WKWA0559E

# BACK-UP LAMP

---

## Bulb Replacement

EKS00501

Refer to [LT-124, "Bulb Replacement"](#) in REAR COMBINATION LAMP.

A

## Removal and Installation

EKS00502

Refer to [LT-124, "Removal and Installation"](#) in REAR COMBINATION LAMP.

B

C

D

E

F

G

H

I

J

LT

L

M


# PARKING, LICENSE PLATE AND TAIL LAMPS

## PARKING, LICENSE PLATE AND TAIL LAMPS

PF2:26550

### Component Parts and Harness Connector Location

EKS00503



## System Description

EKS00504

Control of the parking, license plate, and tail lamp operation is dependent upon the position of the lighting switch (combination switch). When the lighting switch is placed in the 1ST position, the BCM (body control module) receives input signal requesting the parking, license plate, side marker and tail lamps to illuminate. This input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the tail lamp relay coil. This relay, when energized, directs power to the parking, license plate and tail lamps, which then illuminate.

Power is supplied at all times

- through 15A fuse (No. 41, located in the IPDM E/R)
- to tail lamp relay, located in the IPDM E/R, and
- through 15A fuse (No. 34, located in the IPDM E/R)
- to CPU of the IPDM E/R, and
- to ignition relay, located in the IPDM E/R, and
- through 50A fusible link (letter j, located in the fuse and fusible link box)
- to BCM terminal 55, and
- through 15A fuse [No. 3, located in the fuse block (J/B)]
- to BCM terminal 42.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 16, located in the fuse block (J/B)]
- to BCM terminal 38, and

# PARKING, LICENSE PLATE AND TAIL LAMPS

- to ignition relay, located in the IPDM E/R.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 4, located in the fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 49 (early production) and 52
- through grounds M57, M61 and M79, and
- to IPDM E/R terminals 38 and 60
- through grounds E9, E15 and E24.

## OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1ST or 2ND position (or if the auto light system is activated), the BCM receives input signal requesting the parking, license plate, side marker and tail lamps to illuminate. This input signal is communicated to the IPDM E/R across the CAN communication lines. The CPU in the IPDM E/R controls the tail lamp relay coil, which when energized, directs power

- through IPDM E/R terminal 22
- to front combination lamp LH and RH terminal 3, and
- to license plate lamp LH and RH terminal +, and
- to rear combination lamp LH and RH terminal 2.

Ground is supplied

- to front combination lamp LH and RH terminal 1
- through grounds E9, E15 and E24, and
- to license plate lamp LH and RH terminal –
- through grounds D403 and D404, and
- to rear combination lamp LH terminal 5
- through grounds B7 and B19, and
- to rear combination lamp RH terminal 5
- through grounds B117 and B132.

With power and ground supplied, the parking, license plate and tail lamps illuminate.

## COMBINATION SWITCH READING FUNCTION

Refer to [BCS-3, "COMBINATION SWITCH READING FUNCTION"](#) .

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 1ST (or 2ND) position, and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated.

Under this condition, the parking, license and tail lamps remain illuminated for 5 minutes, then the parking, license plate and tail lamps are turned off.

Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description

Refer to [LAN-6, "CAN COMMUNICATION"](#) .

EKS00505

A  
B  
C  
D  
E  
F  
G  
H  
I  
J


LT

L  
M

# PARKING, LICENSE PLATE AND TAIL LAMPS

## Schematic

EKS00506





WKWA2795E

# PARKING, LICENSE PLATE AND TAIL LAMPS

EKS00507

## Wiring Diagram — TAIL/L —

### LT-TAIL/L-01



REFER TO THE FOLLOWING.  
 (M4), (E30) - FUSE BLOCK-JUNCTION BOX (J/B)  
 (M18), (M19) - ELECTRICAL UNITS

WKWA1427E











# PARKING, LICENSE PLATE AND TAIL LAMPS

## Terminals and Reference Values for BCM

EKS00508

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
2	GR/R	Combination switch input 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>
3	G/Y	Combination switch input 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>
4	G/R	Combination switch input 3	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>
5	G/B	Combination switch input 2	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>
6	G/W	Combination switch input 1			
11	V	Ignition switch (ACC)	ACC	—	Battery voltage
32	R/G	Combination switch output 5	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>
33	R/Y	Combination switch output 4	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5292E</p>
34	R	Combination switch output 3	ON	Lighting, turn, wiper OFF Wiper dial position 4	 <p style="text-align: right;">SKIA5291E</p>

# PARKING, LICENSE PLATE AND TAIL LAMPS

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)
			Ignition switch	Operation or condition	
35	R/B	Combination switch output 2	ON	Lighting, turn, wiper OFF Wiper dial position 4	
36	R/W	Combination switch output 1			
38	G	Ignition switch (ON)	ON	—	Battery voltage
39	L	CAN-H	—	—	—
40	Y	CAN-L	—	—	—
42	Y/G	Battery power supply	OFF	—	Battery voltage
49*	B	Ground	ON	—	0V
52	B/W	Ground	ON	—	0V
55	W/B	Battery power supply (fusible link)	OFF	—	Battery voltage

\* Early production

## Terminals and Reference Values for IPDM E/R

EKS00509

Terminal No.	Wire color	Signal name	Measuring condition		Reference value (Approx.)	
			Ignition switch	Operation or condition		
22	R/L	Parking, license, and tail lamp	ON	Lighting switch 1ST position	OFF	0V
					ON	Battery voltage
38	B	Ground	ON	—	0V	
48	L	CAN-H	—	—	—	
49	Y	CAN-L	—	—	—	
60	B	Ground	ON	—	0V	

## How to Proceed With Trouble Diagnosis

EKS0050A

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-110, "System Description"](#).
3. Carry out the Preliminary Check. Refer to [LT-117, "Preliminary Check"](#).
4. Check symptom and repair or replace the cause of malfunction.
5. Do the parking, license and tail lamps operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

## Preliminary Check

EKS0050B

### CHECK POWER SUPPLY AND GROUND CIRCUIT

#### 1. CHECK FUSES OR FUSIBLE LINK

Check for blown fuses or fusible link.

Unit	Power source	Fuse No.
BCM	Battery	j
		3
	Ignition switch ON or START position	16
	Ignition switch ACC or ON position	4
IPDM E/R	Battery	34
		41

# PARKING, LICENSE PLATE AND TAIL LAMPS

Refer to [LT-113, "Wiring Diagram — TAIL/L —"](#) .

OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of blown fuse before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

## 2. CHECK POWER SUPPLY CIRCUIT


1. Disconnect BCM connectors.
2. Check voltage between BCM harness connector and ground.

Terminals		Ignition switch position			
(+)		(-)	OFF	ACC	ON
Connector	Terminal (Wire color)		OFF	ACC	ON
M18	11 (V)	Ground	0V	Battery voltage	Battery voltage
	38 (G)		0V	0V	Battery voltage
M19	42 (Y/G)		Battery voltage	Battery voltage	Battery voltage
	55 (W/B)		Battery voltage	Battery voltage	Battery voltage

OK or NG

OK >> GO TO 3.

NG >> Check harness for open between BCM and fuse.



## 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.


Terminals		Continuity
Connector	Terminal (Wire color)	
M19	49* (B)	Ground
	52 (B/W)	
		Yes

\* Early production

OK or NG

OK >> Inspection End.

NG >> Check ground circuit harness.



## CONSULT-II Functions

Refer to [LT-14, "CONSULT-II Function \(BCM\)"](#) in HEADLAMP (FOR USA).

Refer to [LT-17, "CONSULT-II Function \(IPDM E/R\)"](#) in HEADLAMP (FOR USA).

EKS0050C



# PARKING, LICENSE PLATE AND TAIL LAMPS

## 4. CHECK INPUT SIGNAL


Ⓟ With CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect front combination lamp, license plate lamp and rear combination lamp connectors.
3. Turn ignition switch ON.
4. Select "IPDM E/R" on CONSULT-II. and select "ACTIVE TEST" on "SELECT DIAG MODE" screen.
5. Select "TAIL LAMP" on "SELECT TEST ITEM" screen.
6. Touch "ON" on "ACTIVE TEST" screen.
7. When tail lamp is operating, check voltage between front combination lamp, license plate lamp, rear combination lamp harness connector and ground.


ⓧ Without CONSULT-II

1. Turn ignition switch OFF.
2. Start auto active test. Refer to [PG-21, "Auto Active Test"](#).
3. When tail lamp is operating, check voltage between front combination lamp, license plate lamp, rear combination lamp harness connector and ground.


Terminals				Voltage
Front combination lamp (+)		(-)		
Connector	Terminal (Wire color)			
RH	E107	3 (R/L)	Ground	Battery voltage
LH	E11			



Terminals				Voltage
License plate lamp (+)		(-)		
Connector	Terminal (Wire color)			
RH	D508	+ (R/L)	Ground	Battery voltage
LH	D509			



Terminals				Voltage
Rear combination lamp (+)		(-)		
Connector	Terminal (Wire color)			
RH	B130	2 (R/L)	Ground	Battery voltage
LH	B35			



OK or NG


- OK >> GO TO 6.  
 NG >> GO TO 5.

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 5. CHECK PARKING, LICENSE PLATE AND TAIL LAMP CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

Terminals					Continuity
IPDM E/R		Front combination lamp			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E122	22 (R/L)	RH	E107	3 (R/L)	Yes
		LH	E11		




4. Check continuity between IPDM E/R harness connector and license plate lamp harness connector.

Terminals					Continuity
IPDM E/R		License plate lamp			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E122	22 (R/L)	RH	D508	+ (R/L)	Yes
		LH	D509		



5. Check continuity between IPDM E/R harness connector and rear combination lamp harness connector.

Terminals					Continuity
IPDM E/R		Rear combination lamp			
Connector	Terminal (Wire color)	Connector	Terminal (Wire color)		
E122	22 (R/L)	RH	B130	2 (R/L)	Yes
		LH	B35		



OK or NG


- OK >> Replace IPDM E/R. Refer to [PG-27, "Removal and Installation of IPDM E/R"](#).
- NG >> Repair harness or connector.

# PARKING, LICENSE PLATE AND TAIL LAMPS

## 6. CHECK GROUND


1. Check continuity between front combination lamp harness connector and ground.

Terminals				Continuity
Front combination lamp		Terminal (Wire color)	Ground	
Connector				
RH	E107	1 (B)	Ground	Yes
LH	E11			




2. Check continuity between license lamp plate harness connector and ground.

Terminals				Continuity
License plate lamp		Terminal (Wire color)	Ground	
Connector				
RH	D508	- (B)	Ground	Yes
LH	D509			



3. Check continuity between rear combination lamp harness connector and ground.

Terminals				Continuity
Rear combination lamp		Terminal (Wire color)	Ground	
Connector				
RH	B130	5 (B)	Ground	Yes
LH	B35			



**OK or NG**

- OK >> Check bulbs.
- NG >> Repair harness or connector.

## Parking, License Plate and Tail Lamps Do Not Turn OFF (After Approx. 10 Minutes)

EKS0050E

### 1. CHECK IPDM E/R

1. Turn ignition switch ON. Turn the combination switch (lighting switch) to the OFF position. Turn ignition switch OFF.
2. Verify that the parking, license plate, and tail lamps turn on and off after approximately 10 minutes.

**OK or NG**

- OK >> Ignition relay malfunction. Refer to [PG-16, "Function of Detecting Ignition Relay Malfunction"](#).
- NG >> Inspection End.

# PARKING, LICENSE PLATE AND TAIL LAMPS

---

## Front Parking Lamp BULB REPLACEMENT

EKS0050F

For bulb replacement, refer to [LT-27, "FRONT TURN SIGNAL/PARKING LAMP"](#) .

## Tail Lamp BULB REPLACEMENT

EKS0050G

For bulb replacement, refer to [LT-124, "Bulb Replacement"](#) .

A

B

C

D

E

F

G

H

I

J

LT

L

M

# REAR COMBINATION LAMP


## REAR COMBINATION LAMP

PFP:26554

### Bulb Replacement

EKS0050I

1. Remove rear combination lamp mounting bolts.
2. Pull rear combination lamp to remove from the vehicle.
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb.
5. Install in the reverse order of removal.




### Removal and Installation


EKS0050J

1. Remove rear lower finisher assembly. Refer to [EI-34, "REAR LOWER FINISHER ASSEMBLY"](#).
2. Disconnect rear combination lamp connector.
3. Remove rear combination lamp mounting bolts.
4. Pull rear combination lamp to remove from the vehicle.

**Rear combination lamp mounting bolts : 2.6 N-m (0.27 kg-m, 23 in-lb)**



5. Install in the reverse order of removal noting the following.
  - Install rear combination lamp harness and grommet so that paint mark on grommet is at top and harness points down.




# TRAILER TOW

PFP:93020

## TRAILER TOW

### Component Parts and Harness Connector Location

EKS006HZ



### System Description

EKS006HW

Power is supplied at all times

- through 20A fuse (No. 24, located in the fuse and fusible link box)
- to trailer tow control unit terminal 7.

Ground is supplied

- to trailer tow control unit terminal 5 and
- to trailer harness connector terminal 5
- through ground B304.

### TRAILER TAIL LAMP OPERATION

The trailer tail lamps are controlled by the trailer tow control unit.

With the lighting switch in the parking and tail lamp ON (1ST) position, AUTO position (and the auto light system is activated) or headlamp ON (2ND) position, power is supplied

- to trailer tow control unit terminal 3
- through rear combination lamp LH.

### TRAILER STOP, TURN SIGNAL AND HAZARD LAMP OPERATION

The trailer stop, turn signal and hazard lamps are all controlled by the trailer tow control unit. The trailer tow control unit regulates the amount of voltage supplied to the trailer lamps. If either turn signal or the hazard lamps are turned on and the trailer tow control unit gets a brake lamp input, the trailer tow control unit supplies more voltage to the trailer lamps to make them illuminate brighter.

Stop lamp input is supplied

- to trailer tow control unit terminal 8
- through rear combination lamp LH.

Left turn signal and hazard lamp input is supplied

- to trailer tow control unit terminal 4
- through rear combination lamp LH.

Right turn signal and hazard lamp input is supplied

- to trailer tow control unit terminal 9
- through rear combination lamp RH.

Based on the stop lamp, turn signal lamp and hazard lamp inputs to the trailer tow control unit, power is supplied to trailer stop/turn lamp LH

- through trailer tow control unit terminal 2
- to trailer harness connector terminal 2.

Power is also supplied to trailer stop/turn lamp RH

- through trailer tow control unit terminal 6
- to trailer harness connector terminal 6.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# TRAILER TOW

## Wiring Diagram — T/TOW —

EKS006HX

LT-T/TOW-01



\* : THIS CONNECTOR IS NOT SHOWN IN HARNESS LAYOUT OF PG SECTION.

WKWA0564E

# TRAILER TOW

## Trouble Diagnoses TRAILER TOW CONTROL UNIT INSPECTION TABLE

EKS006HY

Terminal No.	Wire color	Item	Condition	Voltage (Approx.)
1	BR	Tail lamps signal output	When tail lamps operate	Battery voltage
			All other conditions	0
2	Y	Stop/LH turn lamp (output)	When brake pedal is depressed	Battery voltage
			When LH turn lamps or hazard lamps operate	Battery voltage (intermittently)
			All other conditions	0
3	R/L	Tail lamps signal input	When tail lamps operate	Battery voltage
			All other conditions	0
4	G/B	LH turn lamps input	When LH turn lamps or hazard lamps operate	Battery voltage (intermittently)
			All other conditions	0
5	W	Ground	—	—
6	G	Stop/RH turn lamp (output)	When brake pedal is depressed	Battery voltage
			When RH turn lamps or hazard lamps operate	Battery voltage (intermittently)
			All other conditions	0
7	R	Power supply	—	Battery voltage
8	R/G	Stop lamps signal input	When brake pedal is depressed	Battery voltage
			When brake pedal is released	0
9	G/Y	RH turn lamps input	When RH turn lamps or hazard lamps operate	Battery voltage (intermittently)
			All other conditions	0

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
  
LT  
  
L  
M

LT


# INTERIOR ROOM LAMP

PFP:26410

## INTERIOR ROOM LAMP

### Component Parts and Harness Connector Location

EKS0050K



WKIA1082E

# INTERIOR ROOM LAMP

EKS0050L

## System Description

When lamps on demand switch is in DOOR position, room lamp and personal lamp ON/OFF is controlled by timer according to signals from switches including key switch, front door switch driver side, unlock signal from keyfob, door lock and unlock switch, key cylinder lock and unlock switch, ignition switch.

When room lamp and personal lamp turns ON, there is a gradual brightening over 1 second. When room lamp and personal lamp turns OFF, there is a gradual dimming over 1 second.

The room lamp and personal lamp timer is controlled by the BCM (body control module).

Room lamp and personal lamp timer control settings can be changed with CONSULT-II.

Ignition keyhole illumination turns ON when driver door is opened (door switch ON) or key is removed from key cylinder. Illumination turns OFF when driver door is closed (door switch OFF).

Step and foot lamp turns ON when driver door, passenger or rear doors are opened (door switch ON). Lamp turns OFF when driver, passenger and rear doors are closed (all door switches OFF).

## POWER SUPPLY AND GROUND

Power is supplied at all times

- through 15A fuse [No. 19, located in the fuse block (J/B)]
- to key switch terminal 1
- through 15A fuse [No. 3, located in the fuse block (J/B)]
- to BCM terminal 42
- through 50A fusible link (letter j , located in the fuse and fusible link box)
- to BCM terminal 55.

When the key is inserted in key switch, power is supplied

- through the key switch terminal 2
- to BCM terminal 37.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 16, located in the fuse block (J/B)]
- to BCM terminal 38.

Ground is supplied

- to BCM terminals 49 (early production) and 52
- through grounds terminals M57, M61 and M79.

When the driver side door is opened, ground is supplied

- through case ground of front door switch LH
- to BCM terminal 62.

When the passenger side door is opened, ground is supplied

- through case ground of front door switch RH
- to BCM terminal 12.

When the sliding door LH is opened, ground is supplied

- through case ground of sliding door switch LH
- to BCM terminal 63.

When the sliding door RH is opened, ground is supplied

- through case ground of sliding door switch RH
- to BCM terminal 13.

When the liftgate is opened, ground is supplied

- to BCM terminal 58.
- through back door switch terminal 3 (without back door auto closure system) or terminal 8 (with back door auto closure system)
- to grounds terminals D403 and D404.

When the driver or passenger side door is unlocked by the door lock and unlock switch, BCM receives serial data

- through grounds terminals M57, M61 and M79
- to main power window and door lock/unlock switch terminal 14 (with rear power vent windows) or terminal 12 (without rear power vent windows) and power window and door lock/unlock switch RH terminal 16

A

B

C

D

E

F

G

H

I

J

LT

L

M

## INTERIOR ROOM LAMP

---

- to BCM terminal 22.

When the driver side door is unlocked by the key, the BCM receives serial data

- through grounds M57, M61 and M79
- to front door key cylinder switch LH terminal 5
- from front door key cylinder switch LH terminal 1
- to main power window and door lock/unlock switch terminal 4 (with rear power vent windows) or terminal 6 (without rear power vent windows)
- from main power window and door lock/unlock switch terminal 14 (with rear power vent windows) or terminal 12 (without rear power vent windows)
- to BCM terminal 22.

When a signal, or combination of signals is received by BCM, ground is supplied

- through BCM terminal 48
- to lamps on demand switch terminal 3
- through lamps on demand switch terminal 4
- to interior room/map lamps terminal 2 and
- to personal lamps terminal 2 (without rear roof console assembly) or terminal 3 (with rear roof console assembly).

With power and ground supplied, the lamps illuminate.

### SWITCH OPERATION

When driver door switch is ON (door is opened), ground is supplied

- through BCM terminal 1
- to ignition keyhole illumination terminal –.

And power is supplied

- through BCM terminal 41
- to ignition keyhole illumination terminal +.

When any door switch is ON (door is opened), ground is supplied

- through BCM terminal 47
- to front step lamp LH and RH and foot lamp LH and RH terminal –.

And power is supplied

- through BCM terminal 41
- to front step lamp LH and RH terminal +, puddle lamp LH and RH terminal 1, running board lamps terminal 2 and foot lamp LH and RH terminal +.

When map lamp switch is ON, ground is supplied

- through grounds M57, M61 and M79
- to map lamp terminal 3.

And power is supplied

- through BCM terminal 41
- to map lamp terminal 1.

When vanity mirror lamp (driver side and passenger side) is ON, ground is supplied

- through grounds M57, M61 and M79
- to vanity mirror lamp (driver side and passenger side) terminal –.

And power is supplied

- through BCM terminal 41
- to vanity mirror lamp (driver side and passenger side) terminal +.

When cargo lamp is ON, ground is supplied

- through grounds M57, M61 and M79
- to cargo lamp terminal 1.

And power is supplied

- through BCM terminal 41

# INTERIOR ROOM LAMP

- to cargo lamp terminal 2.

## ROOM LAMP TIMER OPERATION

When lamps on demand switch is in DOOR position, and when all conditions below are met, BCM performs timer control (maximum 30 seconds) for interior room lamp and map lamp ON/OFF.

Power is supplied

- through 15A fuse [No. 19, located in the fuse block (J/B)]
- to key switch terminal 1.

Key is removed from ignition key cylinder (key switch OFF), power will not be supplied to BCM terminal 37.

Serial data is supplied

- to BCM terminal 22
- through main power window and door lock/unlock switch terminal 14 (with rear power vent windows) or 12 (without rear power vent windows).

At the time that driver door is opened, BCM detects that driver door is unlocked. It determines that interior room lamp and map lamp timer operation conditions are met, and turns the interior room lamp and map lamp ON for 30 seconds.

Key is in ignition key cylinder (key switch ON), power is supplied

- through key switch terminal 2
- to BCM terminal 37.

When key is removed from key switch (key switch OFF), power supply to BCM terminal 37 is terminated. BCM detects that key has been removed, determines that interior room lamp and map lamp timer conditions are met, and turns the interior room lamp and map lamp ON for 30 seconds.

When driver door opens → closes, and the key is not inserted in the key switch (key switch OFF), BCM terminal 62 changes between 0V (door open) → 12V (door closed). The BCM determines that conditions for interior room lamp and map lamp operation are met and turns the interior room lamp ON for 30 seconds.

Timer control is canceled under the following conditions.

- Driver door is locked (when locked with keyfob, main power window and door lock/unlock switch or door key cylinder switch)
- Driver door is opened (driver door switch turns ON)
- Ignition switch ON.

## INTERIOR LAMP BATTERY SAVER CONTROL

If interior lamp is left "ON", it will not be turned out even when door is closed.

BCM turns off interior lamp automatically to save battery 30 minutes after ignition switch is turned off.

BCM controls interior lamps listed below:

- Vanity lamp
- Room/map lamp
- Cargo lamp
- Personal lamp
- Step lamps
- Puddle lamps
- Foot lamps

After lamps turn OFF by the battery saver system, the lamps illuminate again when

- signal from keyfob, or main power window and door lock/unlock switch or key cylinder is locked or unlocked,
- door is opened or closed,
- key is removed from ignition key cylinder or inserted in ignition key cylinder.


Interior lamp battery saver control period can be changed by the function setting of CONSULT-II.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LT



# INTERIOR ROOM LAMP



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

(FC) : WITH FULL OVERHEAD CONSOLE  
(XF) : WITHOUT FULL OVERHEAD CONSOLE




WKWA0631E

# INTERIOR ROOM LAMP

## Wiring Diagram — INT/L —

EKS0050N

### LT-INT/L-01





REFER TO THE FOLLOWING.  
M4, M30 - FUSE BLOCK - JUNCTION BOX (J/B)  
M18, M19 - ELECTRICAL UNITS

WKWA1428E

# INTERIOR ROOM LAMP

LT-INT/L-02

WC : WITH BACK DOOR AUTO CLOSURE SYSTEM  
XC : WITHOUT BACK DOOR AUTO CLOSURE SYSTEM  
 \*1 WC : 4    \*2 WC : 4    \*3 WC : 14    \*4 WC : 7    \*5 WC : 8  
XC : 1    XC : 1    XC : 6    XC : 1    XC : 3






REFER TO THE FOLLOWING.  
M18, M20 - ELECTRICAL UNITS

WKWA2796E

# INTERIOR ROOM LAMP

LT-INT/L-03





REFER TO THE FOLLOWING.  
(M18) - ELECTRICAL UNITS

WKWA2797E

# INTERIOR ROOM LAMP

LT-INT/L-04



WP : WITH PUDDLE LAMPS



WKWA1415E

# INTERIOR ROOM LAMP

LT-INT/L-05





WKWA1416E

# INTERIOR ROOM LAMP

LT-INT/L-06

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M





WKWA0571E

# INTERIOR ROOM LAMP

LT-INT/L-07

WD : WITH DVD ENTERTAINMENT SYSTEM  
 XD : WITHOUT DVD ENTERTAINMENT SYSTEM



WKWA0572E

# INTERIOR ROOM LAMP

## Terminals and Reference Values for BCM

EKS00500

Terminal No.	Wire color	Signal name	Measuring condition			Reference value (Approx.)	
			Ignition switch	Operation or condition			
1	BR/W	Ignition keyhole illumination signal	OFF	Door is locked. (SW OFF)		Battery voltage	
				Door is unlocked. (SW ON)		0V	
12	GR/L	Front door switch RH signal	OFF	Front door switch RH	ON (open)	0V	
					OFF (closed)	Battery voltage	
13	O/B	Sliding door switch RH signal	OFF	Sliding door switch RH	ON (open)	0V	
					OFF (closed)	Battery voltage	
22	Y/B	Power window switch serial link	—	—			
37	B/R	Key-in detection switch signal	OFF	Vehicle key is removed.		0V	
				Vehicle key is inserted.		Battery voltage	
38	G	Ignition power supply	ON	—		Battery voltage	
39	L	CAN-H	—	—		—	
40	Y	CAN-L	—	—		—	
41	R/G	Battery saver output signal	OFF	30 minutes after ignition switch is turned to OFF		0V	
			ON	—		Battery voltage	
42	Y/G	Battery power supply	OFF	—		Battery voltage	
47	R/W	Step lamp signal	OFF	Any door is open (ON)		0V	
				All doors are closed (OFF)		Battery voltage	
48	P	Interior room/map lamp signal	OFF	Lamps on demand switch: DOOR position	Any door switch	ON (open)	0V
						OFF (closed)	Battery voltage
49*	B	Ground	ON	—		0V	
52	B/W	Ground	ON	—		0V	
55	W/B	Battery power supply	OFF	—		Battery voltage	
58	O	Back door switch signal	OFF	Back door switch	ON (open)	0V	
					OFF (closed)	Battery voltage	
62	GR/R	Front door switch LH signal	OFF	Front door switch LH	ON (open)	0V	
					OFF (closed)	Battery voltage	
63	W/G	Sliding door switch LH signal	OFF	Sliding door switch LH	ON (open)	0V	
					OFF (closed)	Battery voltage	
64	W/V	Cargo lamp signal	OFF	Cargo lamp switch: DOOR position	ON (open)	0V	
					OFF (closed)	Battery voltage	

\* Early production

# INTERIOR ROOM LAMP

EKS0050P

## How to Proceed With Trouble Diagnosis

1. Confirm the symptom or customer complaint.
2. Understand operation description and function description. Refer to [LT-129, "System Description"](#) .
3. Carry out the Preliminary Check. Refer to [LT-142, "Preliminary Check"](#) .
4. Check symptom and repair or replace the cause of malfunction.
5. Does the interior room lamp operate normally? If YES: GO TO 6. If NO: GO TO 4.
6. Inspection End.

## Preliminary Check SWITCH INSPECTION

EKS0050Q

- Ensure lamps on demand switch is in the DOOR or ON position.

## INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT

### 1. CHECK FUSES OR FUSIBLE LINK

Check for blown BCM fuses or fusible link.

Unit	Power source	Fuse or fusible link No.
BCM	Battery	j
		3
	Ignition switch ON or START position	16

Refer to [LT-134, "Wiring Diagram — INT/L —"](#) .

#### OK or NG

OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of blown fuse before installing new fuse. Refer to [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#) .

### 2. CHECK POWER SUPPLY CIRCUIT


1. Disconnect BCM connectors.
2. Check voltage between BCM connector and ground.

Terminals		(-)	Ignition switch position	
(+)			OFF	ON
Connector	Terminal (Wire color)	Ground	Battery voltage	Battery voltage
	M19		42 (Y/G)	Battery voltage
	55 (W/B)		Battery voltage	Battery voltage
M18	38 (G)	0V	Battery voltage	

#### OK or NG

OK >> GO TO 3.

NG >> Check harness for open between BCM and fuse.



# INTERIOR ROOM LAMP

## 3. CHECK GROUND CIRCUIT


Check continuity between BCM harness connector and ground.

Terminals		Continuity
Connector	Terminal (Wire color)	
M19	49* (B)	Ground
	52 (B/W)	
		Yes

\* Early production

### OK or NG

- OK >> Inspection End.
- NG >> Check harness ground circuit.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# INTERIOR ROOM LAMP

## CONSULT-II Function (BCM)

EKS0050R

CONSULT-II can display each diagnostic item using the diagnostic test modes shown following.


BCM diagnostic test item	Diagnostic mode	Description
Inspection by part	WORK SUPPORT	Supports inspections and adjustments. Commands are transmitted to the BCM for setting the status suitable for required operation, input/output signals are received from the BCM and received data is displayed.
	DATA MONITOR	Displays BCM input/output data in real time.
	ACTIVE TEST	Operation of electrical loads can be checked by sending drive signal to them.
	SELF-DIAG RESULTS	Displays BCM self-diagnosis results.
	CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
	ECU PART NUMBER	BCM part number can be read.
	CONFIGURATION	Performs BCM configuration read/write functions.

## CONSULT-II OPERATION


### CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carries out CAN communication.


1. With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "BCM" on "SELECT SYSTEM" screen. If "BCM" is not indicated, go to [GI-37, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#) .



# INTERIOR ROOM LAMP

4. Touch "INT LAMP" on "SELECT SYSTEM" screen.



## WORK SUPPORT

### Operation Procedure

1. Touch "INT LAMP" on "SELECT SYSTEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "SET I/L D-UNLCK INTCON" on "SELECT WORK ITEM" screen.
4. Touch "START".
5. Touch "CHANGE SETT".
6. The setting will be changed and "CUSTOMIZING COMPLETED" will be displayed.
7. Touch "END".

### Display Item List

Item	Description	CONSULT-II
SET I/L D-UNLCK INTCON	The 30 seconds operating function of the interior room lamps and the ignition keyhole illumination can be selected when driver door is released (unlocked).	ON/OFF
ROOM LAMP ON TIME SET	The time in order to escalate illumination can be adjusted when the interior room lamps and the ignition keyhole illumination is turned on.	MODE 1 - 7
ROOM LAMP OFF TIME SET	The time in order to diminish illumination can be adjusted when the interior room lamps and the ignition keyhole illumination is turned off.	MODE 1 - 7

Reference between "MODE" and "TIME" for "TURN ON/OFF".

MODE	1	2	3	4	5	6	7
Time (sec.)	0.5	1	2	3	4	5	0

## DATA MONITOR

### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "DATA MONITOR" on "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on "SELECT MONITOR ITEM" screen.

All signals	Monitors all the signals.
Selection from menu	Selects and monitors the individual signal.

4. Touch "START".
5. When "SELECTION FROM MENU" is selected, touch items to be monitored. When "ALL SIGNALS" is selected, all the items will be monitored.
6. Touch "RECORD" while monitoring, then the status of the monitored item can be recorded. To stop recording, touch "STOP".

# INTERIOR ROOM LAMP

## Display Item List

Monitor item	Contents
IGN ON SW "ON/OFF"	Displays "IGN position (ON)/OFF, ACC position (OFF)" judged from the ignition switch signal.
KEY ON SW "ON/OFF"	Displays "Key inserted (ON)/key removed (OFF)" status judged from the key switch signal.
DOOR SW-DR "ON/OFF"	Displays status of the driver door as judged from the driver door switch signal. (Door is open: ON/Door is closed: OFF)
DOOR SW-AS "ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from passenger door switch signal.
DOOR SW-RR "ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from sliding door switch RH signal.
DOOR SW-RL "ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from sliding door switch LH signal.
BACK DOOR SW "ON/OFF"	Displays "Door open (ON)/Door closed (OFF)" status, determined from back door switch signal.
KEY CYL LK-SW "ON/OFF"	Displays "Door locked (ON)" status, determined from key cylinder lock switch in driver door.
KEY CYL UN-SW "ON/OFF"	Displays "Door unlocked (OFF)" status, determined from key cylinder lock switch in driver door.
CDL LOCK SW "ON/OFF"	Displays "Door locked (ON)/Door unlocked (OFF)" status, determined from locking detection switch in driver door.
CDL UNLOCK SW "ON/OFF"	Displays "Door unlocked (OFF)" status, determined from locking detection switch in passenger door.
KEYLESS LOCK "ON/OFF"	Displays "Locked (ON)/Other (OFF)" status, determined from lock signal.
KEYLESS UNLOCK "ON/OFF"	Displays "Unlocked (ON)/Other (OFF)" status, determined from unlock signal.

## ACTIVE TEST

### Operation Procedure

1. Touch "INT LAMP" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch item to be tested and check operation of the selected item.
4. During the operation check, touching "BACK" deactivates the operation.

## Display Item List

Test item	Description
INT LAMP	Interior room lamp can be operated by any ON-OFF operations.
IGN ILLUM	Ignition keyhole illumination can be operated by ON-OFF operation.

## Room/Map Lamp Control Does Not Operate

EKS0050S

### 1. CHECK EACH SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor, make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-146, "Display Item List"](#) for switches and their functions.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

SKIA5930E


# INTERIOR ROOM LAMP

## 2. ACTIVE TEST

1. Select "BCM" on CONSULT-II. Select "INT LAMP" active test.
2. When lamps on demand switch is in "DOOR" position, use active test to make sure interior room lamp operates.

OK or NG

- OK >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> GO TO 3.




## 3. CHECK INTERIOR ROOM LAMP INPUT

1. Turn ignition switch OFF.
2. Check voltage between room/map lamp harness connector R9 terminal 1 (R/G) and ground.

**Battery voltage should exist.**

OK or NG

- OK >> GO TO 4.
- NG >> GO TO 6.




## 4. CHECK LAMPS ON DEMAND SWITCH

1. Disconnect lamps on demand switch connector.
2. Check continuity between lamps on demand switch terminals.

Terminal		Condition	Continuity
Lamps on demand switch			
3	4	Lamps on demand switch position: DOOR	Yes
		Lamps on demand switch position: OFF	No

OK or NG

- OK >> GO TO 5.
- NG >> Replace lamps on demand switch.



# INTERIOR ROOM LAMP

## 5. CHECK INTERIOR ROOM LAMP CIRCUIT


1. Connect lamps on demand switch connector.
2. Turn lamps on demand switch to DOOR position.
3. Disconnect BCM connector.
4. Check continuity between BCM harness connector M19 terminal 48 (P) and lamps on demand switch harness connector M108 terminal 3 (P).

**Continuity should exist.**

OK or NG

OK >> Replace BCM if interior lamp does not work after setting the connector again. Refer to [BCS-19. "Removal and Installation of BCM"](#).

NG >> Repair harness or connector.



## 6. CHECK INTERIOR ROOM LAMP CIRCUIT


1. Disconnect BCM connector and interior room lamp connector.
2. Check continuity between BCM harness connector M19 terminal 41 (R/G) and interior room/map lamps harness connector R9 terminal 1 (R/G).

**Continuity should exist.**

OK or NG

OK >> Replace BCM if interior lamp does not work after setting the connector again. Refer to [BCS-19. "Removal and Installation of BCM"](#).

NG >> Repair harness or connector between BCM and room/map lamp or between room/map lamp and lamps on demand switch.



# INTERIOR ROOM LAMP

## Personal Lamp Control Does Not Operate (Room/Map Lamps Operate)

EKS0050U

### 1. CHECK EACH DOOR SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor, make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-130, "SWITCH OPERATION"](#) for switches and their function.

OK or NG

- OK >> GO TO 2.
- NG >> Inspect malfunctioning door switch.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

SKIA5930E


### 2. CHECK PERSONAL LAMP OUTPUT

1. Turn ignition switch OFF.
2. Confirm lamps on demand switch is in the "DOOR" position.
3. Disconnect personal lamp connector.
4. Open any door.
5. Check voltage between personal lamp harness connector terminal 1 (R/G) and ground.

**Battery voltage should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> Repair harness or connector.




### 3. CHECK PERSONAL LAMP CONTROL CIRCUIT

1. Disconnect lamps on demand switch connector.
2. Check continuity between lamps on demand switch harness connector M108 terminal 4 (LG) and personal lamp harness connector terminal 2 (LG) (without rear roof console assembly) or terminal 3 (LG) (with rear roof console assembly).

**Continuity should exist.**

OK or NG

- OK >> Replace personal lamp.
- NG >> Repair harness or connector.





# INTERIOR ROOM LAMP


## 5. CHECK IGNITION KEYHOLE ILLUMINATION CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector M18 terminal 1 (BR/W) and ignition keyhole illumination harness connector M25 terminal – (BR/W).

**Continuity should exist.**

OK or NG

- OK >> Replace BCM if ignition keyhole illumination does not work after setting the connector again. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.




## 6. CHECK IGNITION KEYHOLE ILLUMINATION CIRCUIT

1. Disconnect BCM connector and ignition keyhole illumination connector.
2. Check continuity between BCM harness connector M19 terminal 41 (R/G) and ignition keyhole illumination harness connector M25 terminal + (R/G).

**Continuity should exist.**

OK or NG

- OK >> Replace BCM if ignition keyhole illumination does not work after setting the connector again. Refer to [BCS-19, "Removal and Installation of BCM"](#).
- NG >> Repair harness or connector.



## All Step/Foot/Puddle Lamps Do Not Operate

EKS0050W

### 1. CHECK EACH DOOR SWITCH

Select "BCM" on CONSULT-II. With "INT LAMP" data monitor, make sure switches listed in display item list turn ON-OFF linked with switch operation. Refer to [LT-146, "Display Item List"](#) for switches and their functions.

OK or NG

- OK >> GO TO 2.
- NG >> Inspect malfunctioning switch system.

DATA MONITOR	
MONITOR	
IGN ON SW	ON
KEY ON SW	ON
DOOR SW-DR	ON
DOOR SW-AS	ON
DOOR SW-RR	OFF
DOOR SW-RL	OFF
BACK DOOR SW	OFF
KEY CYL LK-SW	OFF
KEY CYL UN-SW	OFF

SKIA5930E


### 2. CHECK STEP LAMP POWER SUPPLY

1. Turn ignition switch OFF.
2. Check voltage between front step lamp LH harness connector D11 terminal + (R/G) and ground.

**Battery voltage should exist.**

OK or NG

- OK >> GO TO 3.
- NG >> GO TO 4.



LKIA0306E

# INTERIOR ROOM LAMP


## 3. CHECK STEP LAMP CONTROL CIRCUIT

1. Disconnect BCM connector and front step lamp LH connector.
2. Check continuity between BCM harness connector M19 terminal 47 (R/W) and front step lamp LH harness connector D11 terminal – (R/W).

**Continuity should exist.**

OK or NG

- OK >> Replace BCM if step lamp does not work after setting the connector again. Refer to [BCS-19, "Removal and Installation of BCM"](#) .
- NG >> Repair harness or connector.




## 4. CHECK STEP LAMP CIRCUIT

1. Disconnect BCM connector and step lamp LH connector.
2. Check continuity between BCM harness connector M19 terminal 41 (R/G) and front step lamp LH harness connector D11 terminal + (R/G).

**Continuity should exist.**

OK or NG

- OK >> Replace BCM if step lamp does not work after setting the connector again. Refer to [BCS-19, "Removal and Installation of BCM"](#) .
- NG >> Repair harness or connector.



## All Interior Room Lamps Do Not Operate

EKS0050Y


### 1. CHECK POWER SUPPLY CIRCUIT

1. All interior room lamps switch are OFF.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector M19 terminal 41 (R/G) and ground.

**Battery voltage should exist.**


OK or NG

- OK >> Repair harness or connector. In a case of making a short circuit, be sure to disconnect battery negative cable after repairing harness, and then reconnect.
- NG >> Replace BCM. Refer to [BCS-19, "Removal and Installation of BCM"](#) .



## ILLUMINATION

### Component Parts and Harness Connector Location



WKIA1091E

EKS005P0

### System Description

Control of the illumination lamps operation is dependent upon the position of the lighting switch (combination switch). When the lighting switch is placed in the 1ST or 2ND position (or if the auto light system is activated) the BCM (body control module) receives input signal requesting the illumination lamps to illuminate. This input signal is communicated to the IPDM E/R (intelligent power distribution module engine room) across the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the tail lamp relay coil. This relay, when energized, directs power to the illumination lamps, which then illuminate. Power is supplied at all times

- through 15A fuse (No. 41, located in the IPDM E/R)
- to tail lamp relay, located in the IPDM E/R, and
- through 50A fusible link (letter j, located in the fuse and fusible link box)
- to BCM terminal 55, and
- through 15A fuse [No. 3 located in fuse block (J/B)]
- to BCM terminal 42, and
- through 15A fuse [No. 34 located in the IPDM E/R]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# ILLUMINATION

---

- to CPU of the IPDM E/R, and
- through 10A fuse [No.19 located in fuse block (J/B)]
- to combination meter terminal 31, and
- to ignition relay, located in the IPDM E/R, and
- through BCM terminal 54
- to power window and door lock/unlock switch RH terminal 10, and
- through BCM terminal 53
- to main power window and door lock/unlock switch terminal 10.

With the ignition switch in the ON or START position, power is supplied

- through 10A fuse [No. 16, located in the fuse block (J/B)]
- to BCM terminal 38, and
- to ignition relay, located in the IPDM E/R, and
- through 10A fuse [No. 14 located in the fuse block (J/B)]
- to combination meter terminal 30.

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 4, located in the fuse block (J/B)]
- to BCM terminal 11.

Ground is supplied

- to BCM terminal 49 (early production) and 52 and
- to combination meter terminal 32
- through grounds M57, M61 and M79, and
- to IPDM E/R terminals 38 and 60
- through grounds E9, E15 and E24.

## ILLUMINATION OPERATION BY LIGHTING SWITCH

With the lighting switch in the 1ST or 2ND position (or if the auto light system is activated), the BCM receives input signal requesting the illumination lamps to illuminate. This input signal is communicated to the IPDM E/R across the CAN communication lines. The CPU of the IPDM E/R controls the tail lamp relay coil, which, when energized, directs power

- through IPDM E/R terminal 22
- to illumination control switch terminal 1
- to glove box lamp terminal +
- to A/T device (illumination) terminal 3
- to TCS OFF switch (illumination) terminal 3 (without VDC)
- to VDC OFF switch (illumination) terminal 3 (with VDC)
- to hazard switch (illumination) terminal 3
- to AV switch (illumination) terminal 3
- to audio unit terminal 8
- to rear sonar system OFF switch terminal 5 (with rear sonar system)
- to lamps on demand switch terminal 5
- to display unit terminal 4 (without NAVI)
- to display control unit terminal 14 (with NAVI)
- to front air control terminal 23
- to NAVI control unit terminal 25 (with NAVI)
- to DVD player terminal 12 (with DVD entertainment system)
- to automatic door main switch terminal 5 (with power sliding door)
- to rear audio remote control unit terminal 6 (with rear audio remote control unit) and
- to rear air control terminal 1.

Illumination is controlled

- through illumination control switch terminal 2

# ILLUMINATION

- to A/T device terminal 4
- to TCS OFF switch terminal 4 (without VDC)
- to VDC OFF switch terminal 4 (with VDC)
- to audio unit terminal 7
- to hazard switch terminal 4
- to AV switch terminal 4
- to rear sonar system OFF switch terminal 4 (with rear sonar system)
- to lamps on demand switch terminal 6
- to front air control terminal 24 and
- to DVD player terminal 10 (with DVD entertainment system)
- to automatic door main switch terminal 7 (with power sliding door)
- to combination meter terminal 10.

Ground is supplied

- to illumination control switch terminal 3
- to glove box lamp terminal –
- to display unit terminal 6 (without NAVI)
- to display control unit terminal 3 (with NAVI)
- to main power window and door lock/unlock switch terminal 17 (with rear power vent windows) or terminal 15 (without rear power vent windows) and
- to power window and door lock/unlock switch RH terminal 11
- through grounds M57, M61 and M79, and
- to rear audio remote control unit terminal 15 (with rear audio remote control unit)
- through grounds B7 and B19, and
- to NAVI control unit terminal 30 (with NAVI) and
- to rear air control terminal 3
- through grounds B117 and B132.

With power and ground supplied, illumination lamps illuminate.

## EXTERIOR LAMP BATTERY SAVER CONTROL

When the combination switch (lighting switch) is in the 1ST or 2ND position (or if auto light system is activated), and the ignition switch is turned from ON or ACC to OFF, the battery saver control function is activated. Under this condition, the illumination lamps remain illuminated for 5 minutes, then the illumination lamps are turned off.

When the lighting switch is turned from OFF to 1ST or 2ND position (or if auto light system is activated) after illumination lamps are turned off by the battery saver control, the illumination lamps illuminate again. Exterior lamp battery saver control mode can be changed by the function setting of CONSULT-II.

## CAN Communication System Description


Refer to [LAN-6, "CAN COMMUNICATION"](#) .

EKS005P1

# ILLUMINATION

## Schematic

EKS005P2




EP : EARLY PRODUCTION  
 \* : THIS RELAY IS BUILT INTO THE IPDM E/R  
 (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM).

▶ A  
 ▶ B  
 NEXT PAGE

WKWA1701E

# ILLUMINATION



- (WS) : WITH POWER SLIDING DOOR
- (RF) : WITH REAR AUDIO REMOTE CONTROL UNIT
- (WD) : WITH DVD ENTERTAINMENT SYSTEM
- (EN) : WITHOUT NAVI
- (NV) : WITH NAVI
- (SO) : WITH REAR SONAR SYSTEM

\* : THIS RELAY IS BUILT INTO THE IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM).



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M

# ILLUMINATION

EKS005P3

## Wiring Diagram — ILL —

LT-ILL-01





REFER TO THE FOLLOWING.  
 (M4), (E30) - FUSE BLOCK-JUNCTION BOX (J/B)  
 (M18), (M19) - ELECTRICAL UNITS

WKWA1429E



# ILLUMINATION

LT-ILL-03




WKWA0576E


# ILLUMINATION

LT-ILL-04

SO : WITH REAR SONAR SYSTEM



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M




WKWA0577E

# ILLUMINATION

LT-ILL-05

NV : WITH NAVI  
EN : WITHOUT NAVI



1	2	3	4	5	6	7	8	9	10	11	12	13	<span style="border: 1px solid black; border-radius: 50%; padding: 2px;">M49</span>
14	15	16	17	18	19	20	21	22	23	24	25	26	B



24	22	20	18	16	14	12	10	8	6	4	2	<span style="border: 1px solid black; border-radius: 50%; padding: 2px;">M93</span> , <span style="border: 1px solid black; border-radius: 50%; padding: 2px;">M94</span>
23	21	19	17	15	13	11	9	7	5	3	1	W W

WKWA0578E

# ILLUMINATION

LT-ILL-06

: WITH NAVI  
 : WITH DVD ENTERTAINMENT SYSTEM



REFER TO THE FOLLOWING.  
 - SUPER MULTIPLE JUNCTION (SMJ)



\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" IN PG SECTION.

WKWA0579E

# ILLUMINATION

LT-ILL-07


WS : WITH POWER SLIDING DOOR  
 RR : WITH REAR AUDIO REMOTE CONTROL UNIT




WKWA0580E

# ILLUMINATION

LT-ILL-08



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LT  
L  
M





WKWA0581E

# ILLUMINATION

LT-ILL-09

- : DATA LINE
- ◻PV : WITH REAR POWER VENTWINDOWS
- ◻OP : WITHOUT REAR POWER VENT WINDOWS
- \*1 ◻PV : 14      \*2 ◻PV : 17
- ◻OP : 12      ◻OP : 15



REFER TO THE FOLLOWING.  
 (M18), (M19) - ELECTRICAL UNITS

WKWA0582E


# ILLUMINATION

## Removal and Installation

### ILLUMINATION CONTROL SWITCH

EKS005P4

1. Remove lower driver instrument panel. Refer to [IP-12, "Instrument Lower Panel LH"](#) .
2. Carefully lift tabs and pull illumination control switch out of lower driver instrument panel.
3. Installation is the reverse order of removal.



A

B

C

D

E

F

G

H

I

J

LT

L

M

# BULB SPECIFICATIONS

## BULB SPECIFICATIONS

PFP:26297

### Headlamp

EKS00670

Item	Wattage (W)*
Low	51 (HB4)
High	60 (HB3)

\*: Always check with the Parts Department for the latest parts information.

### Exterior Lamp

EKS00671

Item	Wattage (W)*	
Front combination lamp	Turn signal lamp/parking lamp	29/8
	Cornering lamp	27
Rear combination lamp	Stop/Tail lamp	27/7
	Turn signal lamp	27
	Back-up lamp	18
Fog lamp	55 (H11)	
License plate lamp	5	
High-mounted stop lamp	13	

\*: Always check with the Parts Department for the latest parts information.

### Interior Lamp/Illumination

EKS00672

Item	Wattage (W)*
Glove box lamp	3.4
Ignition keyhole illumination lamp	0.74
Room/Map lamp	8
A/T device lamp	3
Foot lamp	3.4
Step lamp	3.8
Cargo lamp	7
Vanity mirror lamp	1.32
Personal lamp (with rear roof console assembly)	8
Personal lamp (without rear roof console assembly)	8
Puddle lamp	8
Running board lamp	3.4

\*: Always check with the Parts Department for the latest parts information.