

SECTION AV

AUDIO, VISUAL & NAVIGATION SYSTEM

CONTENTS

BASE AUDIO	Reference Value	18	F
	Wiring Diagram - BASE AUDIO -	20	
BASIC INSPECTION	SYMPTOM DIAGNOSIS	25	G
4	AUDIO SYSTEM	25	
DIAGNOSIS AND REPAIR WORKFLOW	Symptom Table	25	H
4	NORMAL OPERATING CONDITION	26	
Work Flow	Description	26	I
4	PRECAUTION	27	
FUNCTION DIAGNOSIS	PRECAUTIONS	27	J
6	FOR USA AND CANADA	27	
AUDIO SYSTEM	FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	27	K
6	FOR MEXICO	27	
System Diagram	FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	27	L
6	PREPARATION	28	
System Description	PREPARATION	28	M
6	Commercial Service Tools	28	AV
Component Parts Location	ON-VEHICLE REPAIR	29	
6	AUDIO UNIT	29	O
Component Description	Exploded View	29	
7	Removal and Installation	29	P
DIAGNOSIS SYSTEM (AUDIO UNIT)	TWEETER	30	
8	Exploded View	30	
Diagnosis Description	Removal and Installation	30	
8	FRONT SPEAKER	31	
COMPONENT DIAGNOSIS	Exploded View	31	
11	Removal and Installation	31	
POWER SUPPLY AND GROUND CIRCUIT			
11			
AUDIO UNIT			
11			
AUDIO UNIT : Diagnosis Procedure			
11			
STEERING SWITCH SIGNAL A CIRCUIT			
12			
Description			
12			
Diagnosis Procedure			
12			
Component Inspection			
12			
STEERING SWITCH SIGNAL B CIRCUIT			
14			
Description			
14			
Diagnosis Procedure			
14			
Component Inspection			
14			
STEERING SWITCH SIGNAL GND CIRCUIT			
16			
Description			
16			
Diagnosis Procedure			
16			
Component Inspection			
16			
ECU DIAGNOSIS			
18			
AUDIO UNIT			
18			

REAR SPEAKER	32	Component Inspection	52
Exploded View	32		
Removal and Installation	32		
STEERING SWITCH	33	STEERING SWITCH SIGNAL B CIRCUIT	
Exploded View	33	(STEERING SWITCH TO TEL ADAPTER	
Removal and Installation	33	UNIT)	54
		Description	54
		Diagnosis Procedure	54
		Component Inspection	54
RADIO ANTENNA	34	STEERING SWITCH SIGNAL GND CIRCUIT	
Exploded View	34	(STEERING SWITCH TO TEL ADAPTER	
Removal and Installation	34	UNIT)	56
		Description	56
		Diagnosis Procedure	56
		Component Inspection	56
ANTENNA FEEDER	35		
Location of Antenna	35		
BOSE AUDIO			
BASIC INSPECTION	36	STEERING SWITCH SIGNAL A CIRCUIT	
		(TEL ADAPTER UNIT TO AUDIO UNIT)	58
DIAGNOSIS AND REPAIR WORKFLOW	36	Description	58
Work Flow	36	Diagnosis Procedure	58
FUNCTION DIAGNOSIS	38	STEERING SWITCH SIGNAL B CIRCUIT	
AUDIO SYSTEM	38	(TEL ADAPTER UNIT TO AUDIO UNIT)	59
System Diagram	38	Description	59
System Description	38	Diagnosis Procedure	59
Component Parts Location	39	STEERING SWITCH SIGNAL GND CIRCUIT	
Component Description	39	(TEL ADAPTER UNIT TO AUDIO UNIT)	60
HANDS-FREE PHONE SYSTEM	41	Description	60
System Diagram	41	Diagnosis Procedure	60
System Description	41	COMMUNICATION SIGNAL CIRCUIT	61
Component Parts Location	42	Description	61
Component Description	42	Diagnosis Procedure	61
DIAGNOSIS SYSTEM (AUDIO UNIT)	44	REQUEST SIGNAL CIRCUIT (SAT TO AU-	
Diagnosis Description	44	DIO)	63
DIAGNOSIS SYSTEM (TEL ADAPTER UNIT) ..	47	Description	63
Diagnosis Description	47	Diagnosis Procedure	63
COMPONENT DIAGNOSIS	49	AMP. ON SIGNAL CIRCUIT	64
POWER SUPPLY AND GROUND CIRCUIT	49	Description	64
		Diagnosis Procedure	64
AUDIO UNIT	49	WOOFER AMP. ON SIGNAL CIRCUIT	65
AUDIO UNIT : Diagnosis Procedure	49	Description	65
		Diagnosis Procedure	65
BOSE AMP.	49	MICROPHONE SIGNAL CIRCUIT	66
BOSE AMP. : Diagnosis Procedure	49	Description	66
		Diagnosis Procedure	66
SATELLITE RADIO TUNER	50	TELEPHONE ON SIGNAL CIRCUIT	67
SATELLITE RADIO TUNER : Diagnosis Proce-		Description	67
dure	50	Diagnosis Procedure	67
TEL ADAPTER UNIT	50	ECU DIAGNOSIS	68
TEL ADAPTER UNIT : Diagnosis Procedure	50		
STEERING SWITCH SIGNAL A CIRCUIT		AUDIO UNIT	68
(STEERING SWITCH TO TEL ADAPTER		Reference Value	68
UNIT)	52	Wiring Diagram - BOSE AUDIO -	72
Description	52		
Diagnosis Procedure	52		

BOSE AMP.	83	Removal and Installation	131	
Reference Value	83			A
Wiring Diagram - BOSE AUDIO -	86			
SATELLITE RADIO TUNER	97	TWEETER	132	
Reference Value	97	Exploded View	132	B
Wiring Diagram - BOSE AUDIO -	99	Removal and Installation	132	
TEL ADAPTER UNIT	110	CENTER SPEAKER	133	
Reference Value	110	Exploded View	133	C
Wiring Diagram - BOSE AUDIO -	113	Removal and Installation	133	
SYMPTOM DIAGNOSIS	124	FRONT SPEAKER	134	
AUDIO SYSTEM SYMPTOMS	124	Exploded View	134	D
Symptom Table	124	Removal and Installation	134	
HANS-FREE PHONE SYMPTOMS	125	REAR SPEAKER	135	
Symptom Table	125	Exploded View	135	E
NORMAL OPERATING CONDITION	127	Removal and Installation	135	
Description	127	WOOFER	136	
PRECAUTION	128	Exploded View	136	F
PRECAUTIONS	128	Removal and Installation	136	
FOR USA AND CANADA	128	SATELLITE RADIO TUNER	137	
FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	128	Exploded View	137	G
FOR MEXICO	128	Removal and Installation	137	
FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	128	RADIO & SATELLITE RADIO ANTENNA	138	
PREPARATION	129	Exploded View	138	H
PREPARATION	129	Removal and Installation	138	
Commercial Service Tools	129	STEERING SWITCH	139	
ON-VEHICLE REPAIR	130	Exploded View	139	I
AUDIO UNIT	130	Removal and Installation	139	J
Exploded View	130	MICROPHONE	140	
Removal and Installation	130	Exploded View	140	K
BOSE AMP.	131	Removal and Installation	140	
Exploded View	131	TEL ADAPTER UNIT	141	
		Exploded View	141	L
		Removal and Installation	141	
		TEL ANTENNA	142	
		Exploded View	142	M
		Removal and Installation	142	
		ANTENNA FEEDER	143	
		Location of Antenna	143	AV


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000001737431

OVERALL SEQUENCE



Reference 1 ... Refer to [AV-25. "Symptom Table"](#).

DETAILED FLOW

1. CHECK SYMPTOM

Check the malfunction symptoms by performing the following items.

- Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred).
- Check the symptom.

>> GO TO 2.

2. PERFORM DIAGNOSIS BY SYMPTOM

Perform the relevant diagnosis referring to the diagnosis chart by symptom. Refer to [AV-25. "Symptom Table"](#).

>> GO TO 3.

3. REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace the malfunctioning parts.

>> GO TO 4.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[BASE AUDIO]

4.FINAL CHECK

Perform the operation to check that the malfunction symptom is solved or any other symptoms are present.

Is there any symptom?

YES >> GO TO 2.

NO >> INSPECTION END

A

B

C

D

E

F

G

H

I

J

K

L

M

AV


O

P

FUNCTION DIAGNOSIS

AUDIO SYSTEM

System Diagram



System Description

INFOID:000000001713529

AUDIO SYSTEM

Audio functions

AM/FM radio

CD


- Radio signal are received by radio antenna, next it is amplified by antenna amp., and finally it is input to audio unit. (Antenna amp. is built into radio antenna.)
- Audio unit outputs the audio signal to each speaker.

SPEED SENSITIVE VOLUME

- Volume level of this system gone up and down automatically in proportion to the vehicle speed.
- The control level can be selected by the customer.

Component Parts Location

INFOID:000000001700240



- | | | |
|---------------------|--------------------|---------------------|
| 1. Tweeter RH | 2. Tweeter LH | 3. Front speaker LH |
| 4. Rear speaker LH | 5. Radio antenna | 6. Rear speaker RH |
| 7. Front speaker RH | 8. Steering switch | 9. Audio unit |

AUDIO SYSTEM

< FUNCTION DIAGNOSIS >

[BASE AUDIO]

Component Description

INFOID:000000001713530

Part name	Description
Audio unit	Controls audio system functions.
Front speaker	<ul style="list-style-type: none">• Outputs sound signal from audio unit.• Outputs high, mid and low range sounds.
Tweeter	<ul style="list-style-type: none">• Outputs sound signal from audio unit.• Outputs high range sounds.
Rear speaker	<ul style="list-style-type: none">• Outputs sound signal from audio unit.• Outputs high, mid and low range sounds.
Radio antenna (Built-in antenna amp.)	<ul style="list-style-type: none">• Radio signal received by radio antenna is amplified and sent to audio unit.• Power (antenna amp. ON signal) is supplied from audio unit.
Steering switch	<ul style="list-style-type: none">• Each audio operation can be operated.• Steering switch signal (operation signal) is output to audio unit.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

DIAGNOSIS SYSTEM (AUDIO UNIT)

Diagnosis Description


INFOID:000000001713613

Self-diagnosis mode can check the following items.


- Audio unit hardware/software versions
- Continuity of each speaker channel
- Continuity of each audio unit switch

OPERATION PROCEDURE

1. Turn ignition switch to the ON position.
2. Turn the audio unit off.
3. While pressing the “AUDIO” button, turn the volume control dial clockwise or counterclockwise 30 clicks or more. When the self-diagnosis mode is started, a short beep will be heard.




4. Initially, all display segments will be illuminated.



Version Check

1. Press the “AUDIO” switch to enter version diagnostics. “Software” (audio software version) is displayed.



DIAGNOSIS SYSTEM (AUDIO UNIT)

< FUNCTION DIAGNOSIS >

[BASE AUDIO]

2. Press the "AUDIO" switch again to display the "Hardware" (audio hardware version).



A
B
C
D

3. Press the "AUDIO" switch again to display the "CD Mech" (CD mechanism version).



E
F
G
H

4. Press the "AUDIO" switch again to display the "SDARS" (satellite radio version).



I
J
K
L

Channel Check Diagnostics

When all segments are illuminated, press the "TUNE" up switch to enter channel check diagnostics. The self-diagnostic function will then send a tone to each channel (FL, RL, RR, FR) for 1 second.



M
AV
O
P


Button Check Diagnostics

DIAGNOSIS SYSTEM (AUDIO UNIT)

< FUNCTION DIAGNOSIS >

[BASE AUDIO]

When all segments are illuminated, press the "TUNE" down switch to enter button check diagnostics. When each audio unit switch is pressed, a tone will sound and the switch name will be displayed.



POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[BASE AUDIO]

COMPONENT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT AUDIO UNIT

AUDIO UNIT : Diagnosis Procedure

INFOID:000000001713614

1.CHECK FUSE

Check that the following fuses of the audio unit are not blown.

Power source	Fuse No.
Battery	35
Ignition switch ACC or ON	20

Is inspection result OK?

YES >> GO TO 2.

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK AUDIO UNIT POWER SUPPLY CIRCUIT

Check voltage between the audio unit and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Reference value
Battery power supply	M46	19	OFF	Battery voltage
ACC power supply	M46	7	ACC	Battery voltage

Is inspection result OK?

YES >> INSPECTION END

NO >> Check harness between audio unit and fuse.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

STEERING SWITCH SIGNAL A CIRCUIT

< COMPONENT DIAGNOSIS >

[BASE AUDIO]

STEERING SWITCH SIGNAL A CIRCUIT

Description

INFOID:000000001700251

Transmits the steering switch signal to audio unit.

Diagnosis Procedure

INFOID:000000001700252

1. CHECK STEERING SWITCH SIGNAL A CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio unit connector and spiral cable connector.
3. Check continuity between audio unit harness connector terminal 6 and spiral cable harness connector terminal 24.

6 – 24 : Continuity should exist.

4. Check continuity between audio unit harness connector terminal 6 and ground.

6 – Ground : Continuity should not exist.

Is inspection result OK?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK SPIRAL CABLE

Check spiral cable.

Is inspection result OK?

- YES >> GO TO 3.
NO >> Replace spiral cable.

3. CHECK AUDIO UNIT VOLTAGE

1. Connect audio unit connector and spiral cable connector.
2. Turn ignition switch ON.
3. Check voltage between audio unit harness connector terminals 6 and 15.

6 – 15 : Approx. 3.3 V

Is inspection result OK?

- YES >> GO TO 4.
NO >> Replace audio unit.

4. CHECK STEERING SWITCH

1. Turn ignition switch ON.
2. Check steering switch. Refer to [AV-12, "Component Inspection"](#).

Is inspection result OK?

- YES >> INSPECTION END
NO >> Replace steering switch.

Component Inspection

INFOID:000000001715928

Measure the resistance between the steering switch connector terminals 20 to 17 and 16 to 17.

STEERING SWITCH SIGNAL A CIRCUIT

< COMPONENT DIAGNOSIS >


[BASE AUDIO]

Between terminals 20 and 17

- VOL UP switch ON : 645 – 659 Ω**
- SEEK UP switch ON : 163 – 167 Ω**
- SOURCE switch ON : 0 Ω**

Between terminals 16 and 17

- VOL DOWN switch ON : 645 – 659 Ω**
- SEEK DOWN switch ON : 163 – 167 Ω**
- POWER switch ON : 0 Ω**



A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

STEERING SWITCH SIGNAL B CIRCUIT

< COMPONENT DIAGNOSIS >

[BASE AUDIO]

STEERING SWITCH SIGNAL B CIRCUIT

Description

INFOID:000000001715918

Transmits the steering switch signal to audio unit.

Diagnosis Procedure

INFOID:000000001715919

1. CHECK STEERING SWITCH SIGNAL B CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio unit connector and spiral cable connector.
3. Check continuity between audio unit harness connector terminal 16 and spiral cable harness connector terminal 32.

16 – 32 : Continuity should exist.

4. Check continuity between audio unit harness connector terminal 16 and ground.

16 – Ground : Continuity should not exist.

Is inspection result OK?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK SPIRAL CABLE

Check spiral cable.

Is inspection result OK?

- YES >> GO TO 3.
NO >> Replace spiral cable.

3. CHECK AUDIO UNIT VOLTAGE

1. Connect audio unit connector and spiral cable connector.
2. Turn ignition switch ON.
3. Check voltage between audio unit harness connector terminals 16 and 15.

16 – 15 : Approx. 3.3 V

Is inspection result OK?

- YES >> GO TO 4.
NO >> Replace audio unit.

4. CHECK STEERING SWITCH

1. Turn ignition switch ON.
2. Check steering switch. Refer to [AV-14, "Component Inspection"](#).

Is inspection result OK?

- YES >> INSPECTION END
NO >> Replace steering switch.

Component Inspection

INFOID:000000001716705

Measure the resistance between the steering switch connector terminals 20 to 17 and 16 to 17.

STEERING SWITCH SIGNAL B CIRCUIT

< COMPONENT DIAGNOSIS >


[BASE AUDIO]

Between terminals 20 and 17

- VOL UP switch ON : 645 – 659 Ω**
- SEEK UP switch ON : 163 – 167 Ω**
- SOURCE switch ON : 0 Ω**

Between terminals 16 and 17

- VOL DOWN switch ON : 645 – 659 Ω**
- SEEK DOWN switch ON : 163 – 167 Ω**
- POWER switch ON : 0 Ω**



A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

STEERING SWITCH SIGNAL GND CIRCUIT

< COMPONENT DIAGNOSIS >

[BASE AUDIO]

STEERING SWITCH SIGNAL GND CIRCUIT

Description

INFOID:000000001716706

Transmits the steering switch signal to audio unit.

Diagnosis Procedure

INFOID:000000001716707

1. CHECK STEERING SWITCH SIGNAL GND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio unit connector and spiral cable connector.
3. Check continuity between audio unit harness connector terminal 15 and spiral cable harness connector terminal 31.

15 – 31 : Continuity should exist.

Is inspection result OK?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK SPIRAL CABLE

Check spiral cable.

Is inspection result OK?

- YES >> GO TO 3.
NO >> Replace spiral cable.

3. CHECK GROUND CIRCUIT

1. Connect audio unit connector.
2. Check continuity between audio unit harness connector terminals 15 and ground.

15 – Ground : Continuity should exist.

Is inspection result OK?

- YES >> GO TO 4.
NO >> Replace audio unit.

4. CHECK STEERING SWITCH

1. Turn ignition switch ON.
2. Check steering switch. Refer to [AV-16, "Component Inspection"](#).

Is inspection result OK?

- YES >> INSPECT IN ON END
NO >> Replace steering switch.


Component Inspection

INFOID:000000001716708

Measure the resistance between the steering switch connector terminals 20 to 17 and 16 to 17.

Between terminals 20 and 17
VOL UP switch ON : 645 – 659 Ω
SEEK UP switch ON : 163 – 167 Ω
SOURCE switch ON : 0 Ω

Between terminals 16 and 17
VOL DOWN switch ON : 645 – 659 Ω



STEERING SWITCH SIGNAL GND CIRCUIT

< COMPONENT DIAGNOSIS >

[BASE AUDIO]

SEEK DOWN switch ON : 163 – 167 Ω
POWER switch ON : 0 Ω

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

AUDIO UNIT

< ECU DIAGNOSIS >

[BASE AUDIO]


ECU DIAGNOSIS

AUDIO UNIT

Reference Value

INFOID:000000001714520

TERMINAL LAYOUT





PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
2 (R)	3 (G)	Sound signal front LH	Output	Ignition switch ON	Voice output	<p style="text-align: right;">SKIB3609E</p>
4 (V)	5 (LG)	Sound signal rear LH	Output	Ignition switch ON	Voice output	<p style="text-align: right;">SKIB3609E</p>
6 (W)	15 (GR)	Steering switch signal A	Input	Ignition switch ON	Keep pressing SOURCE switch	0 V
					Keep pressing SEEK UP switch	1.1 V
					Keep pressing VOL UP switch	2.2 V
					Except for above	3.3 V
7 (SB)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
11 (O)	12 (W)	Sound signal front RH	Output	Ignition switch ON	Voice output	<p style="text-align: right;">SKIB3609E</p>

AUDIO UNIT

< ECU DIAGNOSIS >

[BASE AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
13 (L)	14 (P)	Sound signal rear RH	Output	Ignition switch ON	Voice output	
15 (GR)	Ground	Steering switch signal ground	—	Ignition switch ON	—	0 V
16 (O)	15 (GR)	Steering switch signal B	Input	Ignition switch ON	Keep pressing POWER switch	0 V
					Keep pressing SEEK DOWN switch	1.1 V
					Keep pressing VOL DOWN switch	2.2 V
					Except for above	3.3 V
18 (L)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	When vehicle speed is ap- prox. 40 km/h (25MPH)	<p>NOTE: The maximum voltage varies de- pending on the specification (destination unit).</p> 
19 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
51	—	Antenna signal	Input	—	—	—
52	Ground	Antenna amp. ON signal	Output	Ignition switch ON	—	12 V

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P


AUDIO UNIT

< ECU DIAGNOSIS >

[BASE AUDIO]

Wiring Diagram - BASE AUDIO -

INFOID:000000001714521



AUDIO UNIT

< ECU DIAGNOSIS >

[BASE AUDIO]

BASE AUDIO

Connector No.	B1	Connector No.	B3B	Connector No.	B4	Connector No.	B8B
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	TH80WF-CS (F-TM4)	Connector Type	NS12MF-CS	Connector Type	NS16MF-CS	Connector Type	NS12MF-CS

Terminal No.	91	Terminal No.	3	Terminal No.	1	Terminal No.	3
Color of Wire	GR	Terminal No.	8	Color of Wire	R	Terminal No.	8
	Y	Color of Wire	L	Terminal No.	6	Color of Wire	GR
		Color of Wire	R	Signal Name [Specification]		Color of Wire	Y
		Signal Name [Specification]					

Terminal No.	7	Terminal No.	4	Terminal No.	3	Terminal No.	1
	6	Terminal No.	10	Color of Wire	L	Terminal No.	8
	5	Color of Wire	GR	Terminal No.	6	Color of Wire	R
	4	Color of Wire	Y	Signal Name [Specification]		Color of Wire	GR
	3	Color of Wire	R				
	2	Color of Wire	L				
	1	Color of Wire	R				
		Signal Name [Specification]					

Terminal No.	7	Terminal No.	4	Terminal No.	3	Terminal No.	1
	6	Terminal No.	10	Color of Wire	L	Terminal No.	8
	5	Color of Wire	GR	Terminal No.	6	Color of Wire	R
	4	Color of Wire	Y	Signal Name [Specification]		Color of Wire	GR
	3	Color of Wire	R				
	2	Color of Wire	L				
	1	Color of Wire	R				
		Signal Name [Specification]					

Terminal No.	7	Terminal No.	4	Terminal No.	3	Terminal No.	1
	6	Terminal No.	10	Color of Wire	L	Terminal No.	8
	5	Color of Wire	GR	Terminal No.	6	Color of Wire	R
	4	Color of Wire	Y	Signal Name [Specification]		Color of Wire	GR
	3	Color of Wire	R				
	2	Color of Wire	L				
	1	Color of Wire	R				
		Signal Name [Specification]					




Connector No.	D2	Connector No.	D42	Connector No.	D4	Connector No.	D44
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE	Connector Name	FRONT SPEAKER LH	Connector Name	FRONT SPEAKER RH
Connector Type	NS16FW-CS	Connector Type	NS10FW-CS	Connector Type	NS02FW-CS	Connector Type	NS02FW-CS

Terminal No.	3	Terminal No.	4	Terminal No.	1	Terminal No.	1
Color of Wire	B	Terminal No.	10	Color of Wire	L	Terminal No.	2
	P	Color of Wire	GR	Terminal No.	6	Color of Wire	G
		Color of Wire	R	Signal Name [Specification]		Color of Wire	R
		Signal Name [Specification]					

Terminal No.	3	Terminal No.	4	Terminal No.	1	Terminal No.	1
Color of Wire	B	Terminal No.	10	Color of Wire	L	Terminal No.	2
	P	Color of Wire	GR	Terminal No.	6	Color of Wire	G
		Color of Wire	R	Signal Name [Specification]		Color of Wire	R
		Signal Name [Specification]					

Terminal No.	3	Terminal No.	4	Terminal No.	1	Terminal No.	1
Color of Wire	B	Terminal No.	10	Color of Wire	L	Terminal No.	2
	P	Color of Wire	GR	Terminal No.	6	Color of Wire	G
		Color of Wire	R	Signal Name [Specification]		Color of Wire	R
		Signal Name [Specification]					



JCNWM0548G1

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AUDIO UNIT

< ECU DIAGNOSIS >

[BASE AUDIO]

BASE AUDIO

<table border="1"> <tr><td>Connector No.</td><td>D01</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>NS12FW-CS</td></tr> </table>   <table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>3</td><td>L</td><td></td></tr> <tr><td>8</td><td>R</td><td></td></tr> </table>	Connector No.	D01	Connector Name	WIRE TO WIRE	Connector Type	NS12FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	3	L		8	R		<table border="1"> <tr><td>Connector No.</td><td>D05</td></tr> <tr><td>Connector Name</td><td>REAR SPEAKER LH</td></tr> <tr><td>Connector Type</td><td>NS02FW-CS</td></tr> </table>   <table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>L</td><td></td></tr> <tr><td>2</td><td>R</td><td></td></tr> </table>	Connector No.	D05	Connector Name	REAR SPEAKER LH	Connector Type	NS02FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	1	L		2	R		<table border="1"> <tr><td>Connector No.</td><td>D101</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>NS12FW-CS</td></tr> </table>   <table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>3</td><td>GR</td><td></td></tr> <tr><td>8</td><td>Y</td><td></td></tr> </table>	Connector No.	D101	Connector Name	WIRE TO WIRE	Connector Type	NS12FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	3	GR		8	Y		<table border="1"> <tr><td>Connector No.</td><td>D106</td></tr> <tr><td>Connector Name</td><td>REAR SPEAKER RH</td></tr> <tr><td>Connector Type</td><td>NS02FW-CS</td></tr> </table>   <table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>GR</td><td></td></tr> <tr><td>2</td><td>Y</td><td></td></tr> </table>	Connector No.	D106	Connector Name	REAR SPEAKER RH	Connector Type	NS02FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	1	GR		2	Y	
Connector No.	D01																																																														
Connector Name	WIRE TO WIRE																																																														
Connector Type	NS12FW-CS																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																													
3	L																																																														
8	R																																																														
Connector No.	D05																																																														
Connector Name	REAR SPEAKER LH																																																														
Connector Type	NS02FW-CS																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																													
1	L																																																														
2	R																																																														
Connector No.	D101																																																														
Connector Name	WIRE TO WIRE																																																														
Connector Type	NS12FW-CS																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																													
3	GR																																																														
8	Y																																																														
Connector No.	D106																																																														
Connector Name	REAR SPEAKER RH																																																														
Connector Type	NS02FW-CS																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																													
1	GR																																																														
2	Y																																																														
<table border="1"> <tr><td>Connector No.</td><td>E105</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH80FW-CS16-TM4</td></tr> </table>   <table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>100</td><td>L</td><td></td></tr> </table>	Connector No.	E105	Connector Name	WIRE TO WIRE	Connector Type	TH80FW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]	100	L		<table border="1"> <tr><td>Connector No.</td><td>M11</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH80FW-CS16-TM4</td></tr> </table>   <table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>91</td><td>L</td><td></td></tr> <tr><td>96</td><td>P</td><td></td></tr> </table>	Connector No.	M11	Connector Name	WIRE TO WIRE	Connector Type	TH80FW-CS16-TM4	Terminal No.	Color of Wire	Signal Name [Specification]	91	L		96	P		<table border="1"> <tr><td>Connector No.</td><td>M14</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>NS18FW-CS</td></tr> </table>   <table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>1</td><td>LG</td><td></td></tr> <tr><td>8</td><td>V</td><td></td></tr> </table>	Connector No.	M14	Connector Name	WIRE TO WIRE	Connector Type	NS18FW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	1	LG		8	V		<table border="1"> <tr><td>Connector No.</td><td>M19</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>NS18MW-CS</td></tr> </table>   <table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name [Specification]</td></tr> <tr><td>3</td><td>R</td><td></td></tr> <tr><td>10</td><td>G</td><td></td></tr> </table>	Connector No.	M19	Connector Name	WIRE TO WIRE	Connector Type	NS18MW-CS	Terminal No.	Color of Wire	Signal Name [Specification]	3	R		10	G				
Connector No.	E105																																																														
Connector Name	WIRE TO WIRE																																																														
Connector Type	TH80FW-CS16-TM4																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																													
100	L																																																														
Connector No.	M11																																																														
Connector Name	WIRE TO WIRE																																																														
Connector Type	TH80FW-CS16-TM4																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																													
91	L																																																														
96	P																																																														
Connector No.	M14																																																														
Connector Name	WIRE TO WIRE																																																														
Connector Type	NS18FW-CS																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																													
1	LG																																																														
8	V																																																														
Connector No.	M19																																																														
Connector Name	WIRE TO WIRE																																																														
Connector Type	NS18MW-CS																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																													
3	R																																																														
10	G																																																														

JCNWM0549GI

AUDIO UNIT

< ECU DIAGNOSIS >

[BASE AUDIO]

BASE AUDIO

Connector No.	M22
Connector Name	TWEETER RH
Connector Type	TK02FBR



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	Y	-

Connector No.	M33
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK08FGY-1V



Terminal No.	Color of Wire	Signal Name [Specification]
24	BR	-
31	GR	-
32	O	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SAB4QFW



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L
31	L	VEHICLE SPEED (8-PULSE)


Connector No.	M46
Connector Name	AUDIO UNIT
Connector Type	TH18FW-CS2



Terminal No.	Color of Wire	Signal Name [Specification]
2	R	SOUND SIGNAL FRONT LH (+)
3	G	SOUND SIGNAL FRONT LH (-)
4	V	SOUND SIGNAL REAR LH (+)
5	LG	SOUND SIGNAL REAR LH (-)
6	W	STEERING SW SIGNAL A
7	SB	ACC
11	O	SOUND SIGNAL FRONT RH (+)
12	W	SOUND SIGNAL FRONT RH (-)
13	L	SOUND SIGNAL REAR RH (+)
14	P	SOUND SIGNAL REAR RH (-)
15	GR	STEERING SW SIGNAL GND

Terminal No.	16	O	STEERING SW SIGNAL B
Terminal No.	18	L	VEHICLE SPEED SIGNAL (8-PULSE)
Terminal No.	19	Y	BAT

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40JFW



Terminal No.	Color of Wire	Signal Name [Specification]
39	L	CAN-H
40	P	CAN-L

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80MY-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
100	Y	-

JCNWM0550GI

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

AUDIO UNIT

< ECU DIAGNOSIS >

[BASE AUDIO]

BASE AUDIO

Connector No.	M80	Connector No.	M401
Connector Name	TWEETER LH	Connector Name	AUDIO UNIT
Connector Type	TK22FBR	Connector Type	GT13SH-2/1S-HU




Terminal No.	Color of Wire	Signal Name [Specification]
1	B	- [Without BOSE system]
2	GR	- [With BOSE system]

Terminal No.	Color of Wire	Signal Name [Specification]
51	-	ANTENNA SIGNAL
52	-	ANTENNA AMP. ON SIGNAL

Connector No.	M352
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK6BEGY



Terminal No.	Color of Wire	Signal Name [Specification]
16	-	-
17	-	-
20	-	-

Connector No.	M82
Connector Name	WIRE TO WIRE
Connector Type	NS10MH-CS



Terminal No.	Color of Wire	Signal Name [Specification]
2	O	-
6	W	-

Connector No.	M402
Connector Name	WIRE TO WIRE
Connector Type	GT13SC-1/1S-HU



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	- [Without BOSE system]
2	GR	- [With BOSE system]

Connector No.	M404
Connector Name	RADIO ANTENNA
Connector Type	GT13SSN-1/1PP-HU



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	M403
Connector Name	WIRE TO WIRE
Connector Type	GT13SCN-1/1PP-HU



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	M402
Connector Name	WIRE TO WIRE
Connector Type	GT13SC-1/1S-HU



Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

JCNWM0551G1

SYMPTOM DIAGNOSIS

AUDIO SYSTEM

Symptom Table

INFOID:000000001714543

AUDIO SYSTEM

Symptoms	Check items	Possible malfunction location / Action to take
Audio sound is not heard.	No sound from all speakers.	Audio unit power supply and ground circuit. Refer to AV-11. "AUDIO UNIT : Diagnosis Procedure" .
	Sound is not heard only from the specific places.	Sound signal circuit of malfunctioning system.

RELATED TO STEERING SWITCH

Symptoms	Possible malfunction location / Action to take
All steering switches are not operated.	Steering switch signal ground circuit. Refer to AV-16. "Diagnosis Procedure" .
Only specified switch cannot be operated.	Replace steering switch.
"SEEK UP", "VOL UP" and "SOURCE" switches are not operated.	Steering switch signal A circuit. Refer to AV-12. "Diagnosis Procedure" .
"SEEK DOWN" "VOL DOWN" and "POWER" switches are not operated.	Steering switch signal B circuit. Refer to AV-14. "Diagnosis Procedure" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BASE AUDIO]

NORMAL OPERATING CONDITION

Description

INFOID:000000003032449

RELATED TO AUDIO

- The majority of the audio malfunctions are the result of outside causes (bad CD, electromagnetic interference, etc.). Check the symptoms below to diagnose the malfunction.
- The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check that noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment. Then determine the cause.

NOTE:

- CD-R is not guaranteed to play because they can contain compressed audio (MP3, WMA) or could be incorrectly mastered by the customer on a computer. (6CD models)
- Check that the CDs carry the Compact Disc Logo. If not, the disc is not mastered to the red book Compact Disc Standard and may not play.

Symptoms	Cause and Counter measure
Cannot play	Check that the CD was inserted correctly.
	Check that the CD is scratched or dirty.
	Check that there is condensation inside the player, and if there is, wait until the condensation is gone (about 1 hour) before using the player.
	The player will play correctly after it returns to the normal temperature if there is a temperature increase error.
	Only the music CD files (CD-DA data) will be played if there is a mixture of music CD files (CD-DA data) and MP3/WMA files on a CD. (6CD models)
	Files with extensions other than “.MP3”, “.WMA”, “.mp3”, or “.wma” cannot be played. (6CD models)
	Check that the finalization process, such as session close and disc close, is done for the disc.
	Check that the CD is protected by copyright.
Poor sound quality	Check that the CD is scratched or dirty.
It takes a relatively long time before the music starts playing.	If there are many folder or file levels on the MP3/WMA CD, or if it is a multi session disc, some time may be required before the music starts playing. (6CD models)
The songs do not play back in the desired order.	The playback order is the order in which the files were written by the software, so the files might not play in the desired order.

Noise resulting from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources, is not a malfunction.

NOTE:

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from a time difference between the broadcast waves directly from the station arriving at the antenna and the waves reflected by mountains or buildings.

PRECAUTION

PRECAUTIONS
FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003248447

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003248446

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P



PREPARATION

< PREPARATION >


[BASE AUDIO]

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000001700266


Tool name	Description
<p data-bbox="162 520 272 541">Power tool</p>  <p data-bbox="850 632 915 646">PBIC0191E</p>	<p data-bbox="1010 520 1260 541">Loosening bolts and nuts</p>

ON-VEHICLE REPAIR

AUDIO UNIT

Exploded View

INFOID:000000001724851



- 1. Audio unit

Removal and Installation

INFOID:000000001724852

REMOVAL

- 1. Remove cluster lid C and cluster lid D. Refer to [IP-12, "Exploded View"](#).
- 2. Remove audio unit with bracket.
- 3. Remove bracket screws, and then remove audio unit.

INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M


AV

O
P

TWEETER

Exploded View

INFOID:000000001724853



1. Tweeter

Removal and Installation

INFOID:000000001724854

REMOVAL

1. Remove instrument panel. Refer to [IP-13, "Removal and Installation"](#).
2. Remove tweeter from instrument panel.

INSTALLATION

Installation is the reverse order of removal.

FRONT SPEAKER


< ON-VEHICLE REPAIR >

[BASE AUDIO]

FRONT SPEAKER

Exploded View

INFOID:000000001724855



1. Front speaker
2. Bracket

Removal and Installation

INFOID:000000001724856

REMOVAL

1. Remove front door finisher. Refer to [INT-11, "FRONT DOOR FINISHER : Removal and Installation"](#).
2. Remove front door speaker from bracket.

INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

REAR SPEAKER


< ON-VEHICLE REPAIR >

[BASE AUDIO]

REAR SPEAKER

Exploded View

INFOID:000000001724857



1. Rear speaker

Removal and Installation

INFOID:000000001724858

REMOVAL

1. Remove rear door finisher. Refer to [INT-14. "REAR DOOR FINISHER : Removal and Installation"](#).
2. Remove rear speaker.

INSTALLATION

Installation is the reverse order of removal.

STEERING SWITCH

< ON-VEHICLE REPAIR >

[BASE AUDIO]

STEERING SWITCH

Exploded View

INFOID:000000001724859

Refer to [SR-5, "Exploded View"](#).

Removal and Installation

INFOID:000000001724860

REMOVAL

Refer to [SR-5, "Removal and Installation"](#).

INSTALLATION

Installation is the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV


O

P

RADIO ANTENNA

Exploded View

INFOID:000000001724861



1. Antenna rod
2. Antenna base

Removal and Installation

INFOID:000000001724862

REMOVAL

1. Remove headlining assembly. Refer to [INT-24, "NORMAL ROOF : Removal and Installation"](#) (normal roof models) or [INT-27, "SUNROOF : Removal and Installation"](#) (sunroof models).
2. Remove nuts, and then remove radio antenna.

INSTALLATION

Installation is the reverse order of removal.

CAUTION:

Be careful about tightening torque. Antenna sensitivity becomes poor, and when it is excessive, roof panel may be deformed, when roof antenna mounting nut tightening torque is loose.

ANTENNA FEEDER

< ON-VEHICLE REPAIR >


[BASE AUDIO]

ANTENNA FEEDER


Location of Antenna

INFOID:000000001724863

SEC. 280



Instrument panel driver side



Rear view of vehicle

JSNIA0726GB

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000001700275

OVERALL SEQUENCE



Reference 1 ... Refer to [AV-124, "Symptom Table"](#).

DETAILED FLOW

1. CHECK SYMPTOM

Check the malfunction symptoms by performing the following items.

- Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred).
- Check the symptom.

>> GO TO 2.

2. PERFORM DIAGNOSIS BY SYMPTOM

Perform the relevant diagnosis referring to the diagnosis chart by symptom. Refer to [AV-124, "Symptom Table"](#).

>> GO TO 3.

3. REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace the malfunctioning parts.

>> GO TO 4.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[BOSE AUDIO]

4. FINAL CHECK

Perform the operation to check that the malfunction symptom is solved or any other symptoms are present.

Is there any symptom?

YES >> GO TO 2.

NO >> INSPECTION END


A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

FUNCTION DIAGNOSIS

AUDIO SYSTEM

System Diagram



System Description

INFOID:000000001700277

AUDIO SYSTEM

Audio functions

AM/FM radio
CD

- Radio signals are received by the radio antenna, then amplified by the antenna amp., and finally input to the audio unit. (The antenna amp. is built into the radio antenna.)
- The audio unit outputs a sound signal to the BOSE amp., and the BOSE amp. outputs to each speaker.

SATELLITE RADIO SYSTEM

- Radio signals are supplied to the satellite radio tuner from the satellite antenna.
- The satellite radio tuner then sends a sound signal to the audio unit.
- The audio unit outputs a sound signal to the BOSE amp., and the BOSE amp. outputs to each speaker.

SPEED SENSITIVE VOLUME

- The volume level of this system goes up and down automatically in proportion to the vehicle speed.
- The control level can be selected by the customer.


AUDIO SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO]

Component Parts Location

INFOID:000000001700278



- | | | |
|-------------------------------------|--------------------------|----------------------|
| 1. Center speaker | 2. Tweeter LH | 3. Front speaker LH |
| 4. Rear speaker LH | 5. Satellite radio tuner | 6. Woofer |
| 7. TEL adapter unit | 8. TEL antenna | 9. BOSE amp. |
| 10. Radio & satellite radio antenna | 11. Rear speaker RH | 12. Front speaker RH |
| 13. Tweeter RH | 14. Audio unit | 15. Microphone |
| 16. Steering switch | | |
| A. Luggage side LH | B. Luggage side RH | C. Luggage side RH |

Component Description

INFOID:000000001700279

Part name	Description
Audio unit	Controls audio system and satellite radio system functions.
BOSE amp.	<ul style="list-style-type: none"> Receives power (amp. ON) and sound signals from audio unit, and outputs sound signals to each speaker. Woofer amp. ON signal is output to woofer.
Steering switch	<ul style="list-style-type: none"> Each audio operation can be operated. Steering switch signal (operation signal) is output to audio unit. (without hands-free phone system) Steering switch signal (operation signal) is output to audio unit through TEL adapter unit. (with hands-free phone system)
Front speaker	<ul style="list-style-type: none"> Outputs sound signal from BOSE amp. Outputs high, mid and low range sounds.
Tweeter	<ul style="list-style-type: none"> Outputs sound signal from BOSE amp. Outputs high range sounds.
Center speaker	<ul style="list-style-type: none"> Outputs sound signal from BOSE amp. Outputs mid and high range sounds.

AUDIO SYSTEM


< FUNCTION DIAGNOSIS >

[BOSE AUDIO]

Part name	Description
Rear speaker	<ul style="list-style-type: none">• Outputs sound signal from BOSE amp.• Outputs high, mid and low range sounds.
Woofers	<ul style="list-style-type: none">• Woofer amp. ON signal is input from BOSE amp.• Outputs sound signal from BOSE amp.• Outputs low range sounds.
Radio & satellite radio antenna	<p>Radio antenna</p> <ul style="list-style-type: none">• Radio signal received by radio antenna is amplified and sent to audio unit.• Power (antenna amp. ON signal) is supplied from audio unit. <p>Satellite radio antenna</p> <ul style="list-style-type: none">• Sound signal (satellite radio) is received and output to audio unit.
Satellite radio tuner	<ul style="list-style-type: none">• Receives radio signals from satellite antenna.• Sends sound signals to audio unit.

HANDS-FREE PHONE SYSTEM

System Diagram



System Description

INFOID:000000001705369

- The connection between portable telephone and TEL adapter unit is performed with Bluetooth® communication.
- The voice guidance signal is input from the TEL adapter unit to the audio unit and output via BOSE amp. to the front speaker when operating the telephone.
- TEL adapter unit has the on board self-diagnosis function. Refer to [AV-47. "Diagnosis Description"](#).

When receiving a call

Telephone voice signal received with the portable telephone is input from TEL antenna via TEL adapter unit to audio unit with Bluetooth communication and output via BOSE amp. to the front speaker. The operation is performed with the steering switch or voice recognition function.

When a call is originated

Speech sound (telephone voice signal) is input from the microphone to the TEL adapter unit. It is input from the TEL antenna via Bluetooth communication to the portable telephone. It is transmitted to the phone on the other side. The operation is performed with the steering switch or voice recognition function.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P


HANDS-FREE PHONE SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO]

Component Parts Location

INFOID:000000001747957



- | | | |
|-------------------------------------|--------------------------|----------------------|
| 1. Center speaker | 2. Tweeter LH | 3. Front speaker LH |
| 4. Rear speaker LH | 5. Satellite radio tuner | 6. Woofer |
| 7. TEL adapter unit | 8. TEL antenna | 9. BOSE amp. |
| 10. Radio & satellite radio antenna | 11. Rear speaker RH | 12. Front speaker RH |
| 13. Tweeter RH | 14. Audio unit | 15. Microphone |
| 16. Steering switch | | |
| A. Luggage side LH | B. Luggage side RH | C. Luggage side RH |

Component Description

INFOID:000000001700283

Part name	Description
Audio unit	<ul style="list-style-type: none"> Receives telephone voice signal from TEL adapter unit. Sends telephone voice and voice guidance signals to BOSE amp. Audio unit and TEL adapter unit exchange data by AV communication, and control audio unit display.
BOSE amp.	Inputs power (amp. ON) and sound signal from audio unit, and outputs sound signal to each speaker.
Front door speaker	Receives telephone voice and voice guidance signals from BOSE amp.
Tweeter	
Center speaker	
Steering switch	<ul style="list-style-type: none"> The hands free phone system can be operated. Steering switch signal (operation signal) is output to audio unit through TEL adapter unit.
Microphone	<ul style="list-style-type: none"> Uses when operating the hands-free phone. Outputs microphone signal (telephone voice signal) to the TEL adapter unit. The power (microphone power supply) is supplied from the TEL adapter unit.

HANDS-FREE PHONE SYSTEM

< FUNCTION DIAGNOSIS >

[BOSE AUDIO]

Part name	Description
TEL adapter unit	<ul style="list-style-type: none">• Receives the steering switch signal (operation signal) from the steering switch.• Inputs the telephone voice signal from TEL antenna during reception and outputs into the audio unit.• Inputs the telephone voice signal from microphone during speech recognition and outputs it to the TEL antenna.
TEL antenna	Connects with the portable telephone via Bluetooth® communication and communicates the telephone voice signal.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

DIAGNOSIS SYSTEM (AUDIO UNIT)

Diagnosis Description


INFOID:000000001700284

Self-diagnosis mode can check the following items.


- Audio unit hardware/software versions
- Continuity of each speaker channel
- Continuity of each audio unit switch

OPERATION PROCEDURE

1. Turn ignition switch to the ON position.
2. Turn the audio unit off.
3. While pressing the “AUDIO” button, turn the volume control dial clockwise or counterclockwise 30 clicks or more. When the self-diagnosis mode is started, a short beep will be heard.




4. Initially, all display segments will be illuminated.



Version Check

1. Press the “AUDIO” switch to enter version diagnostics. “Software” (audio software version) is displayed.




DIAGNOSIS SYSTEM (AUDIO UNIT)

< FUNCTION DIAGNOSIS >

[BOSE AUDIO]

2. Press the "AUDIO" switch again to display the "Hardware" (audio hardware version).



A
B
C
D

3. Press the "AUDIO" switch again to display the "CD Mech" (CD mechanism version).



E
F
G
H

4. Press the "AUDIO" switch again to display the "SDARS" (satellite radio version).



I
J
K
L

Channel Check Diagnostics

When all segments are illuminated, press the "TUNE" up switch to enter channel check diagnostics. The self-diagnostic function will then send a tone to each channel (FL, RL, RR, FR) for 1 second.



M
AV
O
P


Button Check Diagnostics

DIAGNOSIS SYSTEM (AUDIO UNIT)

< FUNCTION DIAGNOSIS >

[BOSE AUDIO]

When all segments are illuminated, press the "TUNE" down switch to enter button check diagnostics. When each audio unit switch is pressed, a tone will sound and the switch name will be displayed.



DIAGNOSIS SYSTEM (TEL ADAPTER UNIT)

< FUNCTION DIAGNOSIS >

[BOSE AUDIO]

DIAGNOSIS SYSTEM (TEL ADAPTER UNIT)

Diagnosis Description

INFOID:000000001705395

HANDS FREE PHONE SYSTEM ON BOARD DIAGNOSIS

During on board diagnosis the diagnosis function of TEL adapter unit starts with the operation of the steering switch and performs the diagnosis when ignition switch ACC.

On board diagnosis item

The on board diagnosis has 3 modes: the self-diagnosis mode that performs the trouble diagnosis, the speaker adaptation data deleting mode and the hands free phone system initialization mode.

CAUTION:

- Perform the diagnosis with the vehicle stopped.
- Perform STEP2 if necessary.

STEP	MODE	Description
STEP 1	Self-diagnosis	The self-diagnosis mode performs the microphone test and the diagnosis of TEL adapter unit, TEL antenna and steering unit, and then reads out the results with the sound and indicates them on the audio screen.
STEP 2	Hands free phone system initialization	Hands free phone system initialization mode can perform the initialization of hands free phone system.
	Speaker adaptation data deleting	The speaker adaptation data deleting mode can delete the speaker adaptation data.

Self-diagnosis results

Self-diagnosis mode reads out the self-diagnosis results and indicates DTC on the audio screen.

NOTE:

- Error count is read out simultaneously when reading out the DTC name.
- The errors are read out continuously when some errors occur at the same time. The DTC displays are combined and displayed. For example, DTC 01100 is displayed when DTC 01000 and DTC 00100 are indicated at the same time.

Self-diagnosis results

DTC (Audio screen)	Failure message	Possible causes
DTC 10000	Internal failure	TEL adapter unit
DTC 01000	Bluetooth antenna open	TEL antenna
DTC 00100	Bluetooth antenna shorted	
DTC 00010	Button ladder A is stuck	Steering switch
DTC 00001	Button ladder B is stuck	
DTC 00000	There are no failure records to report	—

The details of error count


The error count guides "0" when the error occurs. The next time it counts up "1" if it is normal with the ignition switch ON. It continues the count up unless the initialization of hands free phone system is performed.

DIAGNOSIS SYSTEM (TEL ADAPTER UNIT)

< FUNCTION DIAGNOSIS >

[BOSE AUDIO]

FLOW CHART OF TROUBLE DIAGNOSIS



POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

COMPONENT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT AUDIO UNIT

AUDIO UNIT : Diagnosis Procedure

INFOID:000000001700287

1.CHECK FUSE

Check that the following fuses of the audio unit are not blown.

Power source	Fuse No.
Battery	35
Ignition switch ACC or ON	20

Is inspection result OK?

YES >> GO TO 2.

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK AUDIO UNIT POWER SUPPLY CIRCUIT

Check voltage between the audio unit and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Reference value
Battery power supply	M46	19	OFF	Battery voltage
ACC power supply	M46	7	ACC	Battery voltage

Is inspection result OK?

YES >> INSPECTION END

NO >> Check harness between audio unit and fuse.

BOSE AMP.

BOSE AMP. : Diagnosis Procedure

INFOID:000000001700288

1.CHECK FUSE

Check that the following fuses of the BOSE amp. are not blown.

Power source	Fuse No.
Battery	13

Is inspection result OK?

YES >> GO TO 2.

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT

Check voltage between BOSE speaker amp harness connector and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Reference value
Battery power supply	B64	11	OFF	Battery voltage

Is inspection result OK?

YES >> GO TO 3.

NO >> Check harness between BOSE amp. and fuse.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BOSE amp. connector.
3. Check continuity between BOSE amp. harness connector and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

Signal name	Connector No.	Terminal No.	Ignition switch position	Continuity
Ground	B64	12	OFF	Continuity should exist.

Is inspection result OK?

YES >> INSPECTION END

NO >> Repair harness or connector.

SATELLITE RADIO TUNER

SATELLITE RADIO TUNER : Diagnosis Procedure

INFOID:000000001700289

1.CHECK FUSES

Check that the following fuses of the satellite radio tuner are not blown.

Power source	Fuse No.
Battery	35
Ignition switch ACC or ON	20

Is inspection result OK?

YES >> GO TO 2.

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT

Check voltage between the satellite radio tuner and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Reference value
Battery power supply	B19	12	OFF	Battery voltage
ACC power supply	B19	16	ACC	Battery voltage

Is inspection result OK?

YES >> INSPECTION END

NO >> Check harness between satellite radio tuner and fuse.

TEL ADAPTER UNIT

TEL ADAPTER UNIT : Diagnosis Procedure

INFOID:000000001700290

1.CHECK FUSES

Check that the following fuses of the TEL adapter unit are not blown.

Power source	Fuse No.
Battery	35
Ignition switch ACC or ON	20
Ignition switch ON or START	1

Is inspection result OK?

YES >> GO TO 2.

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT

Check voltage between TEL adapter unit harness connector and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Reference value
Battery power supply	B6	1	OFF	Battery voltage
ACC power supply	B6	2	ACC	Battery voltage
Ignition signal	B6	3	ON	Battery voltage

Is inspection result OK?

POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

- YES >> GO TO 3.
NO >> Check harness between TEL adapter unit and fuse.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TEL adapter unit connector.
3. Check continuity between TEL adapter unit harness connector and ground.

Signal name	Connector No.	Terminal No.	Ignition switch position	Continuity
Ground	B6	4	OFF	Continuity should exist.
		21	OFF	Continuity should exist.
		22	OFF	Continuity should exist.
		23	OFF	Continuity should exist.
		24	OFF	Continuity should exist.

Is inspection result OK?

- YES >> INSPECTION END
NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

STEERING SWITCH SIGNAL A CIRCUIT (STEERING SWITCH TO TEL ADAPTER UNIT)

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

STEERING SWITCH SIGNAL A CIRCUIT (STEERING SWITCH TO TEL ADAPTER UNIT)

Description

INFOID:000000001716720

- Transmits the steering switch signal to TEL adapter unit.
- Transmits the steering switch signal to audio unit through TEL adapter unit.

Diagnosis Procedure

INFOID:000000001716721

1. CHECK STEERING SWITCH SIGNAL A CIRCUIT (STEERING SWITCH TO TEL ADAPTER UNIT)

1. Turn ignition switch OFF.
2. Disconnect TEL adapter unit connector and spiral cable connector.
3. Check continuity between TEL adapter unit harness connector terminal 12 and spiral cable harness connector terminal 24.

12 – 24 : Continuity should exist.

4. Check continuity between audio unit harness connector terminal 12 and ground.

12 – Ground : Continuity should not exist.

Is inspection result OK?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK SPIRAL CABLE

Check spiral cable.

Is inspection result OK?

- YES >> GO TO 3.
NO >> Replace spiral cable.

3. CHECK TEL ADAPTER UNIT VOLTAGE

1. Connect TEL adapter unit connector and spiral cable connector.
2. Turn ignition switch ON.
3. Check voltage between TEL adapter unit harness connector terminals 12 and 14.

12 – 14 : Approx. 5 V

Is inspection result OK?

- YES >> GO TO 4.
NO >> Replace TEL adapter unit.

4. CHECK STEERING SWITCH

1. Turn ignition switch OFF.
2. Check steering switch. Refer to [AV-52, "Component Inspection"](#).

Is inspection result OK?

- YES >> INSPECTION END
NO >> Replace steering switch.

Component Inspection

INFOID:000000001716722

Measure the resistance between the steering switch connector terminals 20 to 17 and 16 to 17.

STEERING SWITCH SIGNAL A CIRCUIT (STEERING SWITCH TO TEL ADAPTER UNIT)

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

Between terminals 20 and 17

SEEK DOWN switch ON : 327 – 333 Ω

SEEK UP switch ON : 109 – 111 Ω

SEEK switch OFF : 0 Ω


Between terminals 16 and 17

SOURCE switch ON : 1000 – 1020 Ω

VOL UP switch ON : 327 – 333 Ω

VOL DOWN switch ON : 109 – 111 Ω

VOL switch OFF : 0 Ω



A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

STEERING SWITCH SIGNAL B CIRCUIT (STEERING SWITCH TO TEL ADAPTER UNIT)

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

STEERING SWITCH SIGNAL B CIRCUIT (STEERING SWITCH TO TEL ADAPTER UNIT)

Description

INFOID:000000001720223

- Transmits the steering switch signal to TEL adapter unit.
- Transmits the steering switch signal to audio unit through TEL adapter unit.

Diagnosis Procedure

INFOID:000000001720224

1. CHECK STEERING SWITCH SIGNAL B CIRCUIT (STEERING SWITCH TO TEL ADAPTER UNIT)

1. Turn ignition switch OFF.
2. Disconnect TEL adapter unit connector and spiral cable connector.
3. Check continuity between TEL adapter unit harness connector terminal 13 and spiral cable harness connector terminal 32.

13 – 32 : Continuity should exist.

4. Check continuity between audio unit harness connector terminal 13 and ground.

13 – Ground : Continuity should not exist.

Is inspection result OK?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK SPIRAL CABLE

Check spiral cable.

Is inspection result OK?

- YES >> GO TO 3.
NO >> Replace spiral cable.

3. CHECK TEL ADAPTER UNIT VOLTAGE

1. Connect TEL adapter unit connector and spiral cable connector.
2. Turn ignition switch ON.
3. Check voltage between TEL adapter unit harness connector terminals 13 and 14.

13 – 14 : Approx. 5 V

Is inspection result OK?

- YES >> GO TO 4.
NO >> Replace TEL adapter unit.

4. CHECK STEERING SWITCH

1. Turn ignition switch OFF.
2. Check steering switch. Refer to [AV-54, "Component Inspection"](#).

Is inspection result OK?

- YES >> INSPECTION END
NO >> Replace steering switch.

Component Inspection

INFOID:000000001720225

Measure the resistance between the steering switch connector terminals 20 to 17 and 16 to 17.

STEERING SWITCH SIGNAL B CIRCUIT (STEERING SWITCH TO TEL ADAPTER UNIT)

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

Between terminals 20 and 17

SEEK DOWN switch ON : 327 – 333 Ω

SEEK UP switch ON : 109 – 111 Ω

SEEK switch OFF : 0 Ω


Between terminals 16 and 17

SOURCE switch ON : 1000 – 1020 Ω

VOL UP switch ON : 327 – 333 Ω

VOL DOWN switch ON : 109 – 111 Ω

VOL switch OFF : 0 Ω



A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

STEERING SWITCH SIGNAL GND CIRCUIT (STEERING SWITCH TO TEL ADAPTER UNIT)

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

STEERING SWITCH SIGNAL GND CIRCUIT (STEERING SWITCH TO TEL ADAPTER UNIT)

Description

INFOID:000000001720649

- Transmits the steering switch signal to TEL adapter unit.
- Transmits the steering switch signal to audio unit through TEL adapter unit.

Diagnosis Procedure

INFOID:000000001720650

1. CHECK STEERING SWITCH SIGNAL GND CIRCUIT (STEERING SWITCH TO TEL ADAPTER UNIT)

1. Turn ignition switch OFF.
2. Disconnect TEL adapter unit connector and spiral cable connector.
3. Check continuity between TEL adapter unit harness connector terminal 14 and spiral cable harness connector terminal 31.

14 – 31 : Continuity should exist.

Is inspection result OK?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK SPIRAL CABLE

Check spiral cable.

Is inspection result OK?

- YES >> GO TO 3.
NO >> Replace spiral cable.

3. CHECK GROUND CIRCUIT

1. Connect TEL adapter unit connector.
2. Check continuity between TEL adapter unit harness connector terminal 14 and ground.

14 – Ground : Continuity should exist.

Is inspection result OK?

- YES >> GO TO 4.
NO >> Replace TEL adapter unit.

4. CHECK STEERING SWITCH

1. Turn ignition switch OFF.
2. Check steering switch. Refer to [AV-56, "Component Inspection"](#).

Is inspection result OK?

- YES >> INSPECTION END
NO >> Replace steering switch.

Component Inspection

INFOID:000000001720651

Measure the resistance between the steering switch connector terminals 20 to 17 and 16 to 17.

STEERING SWITCH SIGNAL GND CIRCUIT (STEERING SWITCH TO TEL ADAPTER UNIT)

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

Between terminals 20 and 17

SEEK DOWN switch ON : 327 – 333 Ω

SEEK UP switch ON : 109 – 111 Ω

SEEK switch OFF : 0 Ω


Between terminals 16 and 17

SOURCE switch ON : 1000 – 1020 Ω

VOL DOWN switch ON : 327 – 333 Ω

VOL UP switch ON : 109 – 111 Ω

VOL switch OFF : 0 Ω



A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

STEERING SWITCH SIGNAL A CIRCUIT (TEL ADAPTER UNIT TO AUDIO UNIT)

Description

INFOID:000000001721220

- Transmits the steering switch signal to TEL adapter unit.
- Transmits the steering switch signal to audio unit through TEL adapter unit.

Diagnosis Procedure

INFOID:000000001721144

1. CHECK STEERING SWITCH SIGNAL A (TEL ADAPTER UNIT TO AUDIO UNIT) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio unit connector and TEL adapter unit connector.
3. Check continuity between audio unit harness connector terminal 6 and TEL adapter unit harness connector terminal 17.

6 – 17 : Continuity should exist.

4. Check continuity between audio unit harness connector terminal 6 and ground.

6 – Ground : Continuity should not exist.

Is inspection result OK?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK AUDIO UNIT VOLTAGE

1. Connect audio unit connector and TEL adapter unit connector.
2. Turn ignition switch ON.
3. Check voltage between audio unit harness connector terminals 6 and 15.

6 – 15 : Approx. 3.3 V

Is inspection result OK?

- YES >> Replace TEL adapter unit.
NO >> Replace audio unit.

STEERING SWITCH SIGNAL B CIRCUIT (TEL ADAPTER UNIT TO AUDIO UNIT)

Description

INFOID:000000001721228

- Transmits the steering switch signal to TEL adapter unit.
- Transmits the steering switch signal to audio unit through TEL adapter unit.

Diagnosis Procedure

INFOID:000000001721758

1. CHECK STEERING SWITCH SIGNAL B (TEL ADAPTER UNIT TO AUDIO UNIT) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio unit connector and TEL adapter unit connector.
3. Check continuity between audio unit harness connector terminal 16 and TEL adapter unit harness connector terminal 18.

16 – 18 : Continuity should exist.

4. Check continuity between audio unit harness connector terminal 16 and ground.

16 – Ground : Continuity should not exist.

Is inspection result OK?

- YES >> GO TO 2.
- NO >> Repair harness or connector.

2. CHECK AUDIO UNIT VOLTAGE

1. Connect audio unit connector and TEL adapter unit connector.
2. Turn ignition switch ON.
3. Check voltage between audio unit harness connector terminals 16 and 15.

16 – 15 : Approx. 3.3 V

Is inspection result OK?

- YES >> Replace TEL adapter unit.
- NO >> Replace audio unit.

A
B
C
D
E
F
G
H
I
J
K
L
M



O
P

STEERING SWITCH SIGNAL GND CIRCUIT (TEL ADAPTER UNIT TO AUDIO UNIT)

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

STEERING SWITCH SIGNAL GND CIRCUIT (TEL ADAPTER UNIT TO AUDIO UNIT)

Description

INFOID:000000001721273

- Transmits the steering switch signal to TEL adapter unit.
- Transmits the steering switch signal to audio unit through TEL adapter unit.

Diagnosis Procedure

INFOID:000000001721150

1. CHECK STEERING SWITCH SIGNAL GND (TEL ADAPTER UNIT TO AUDIO UNIT) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio unit connector and TEL adapter unit connector.
3. Check continuity between audio unit harness connector terminal 15 and TEL adapter unit harness connector terminal 19.

15 – 19 : Continuity should exist.

Is inspection result OK?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK GROUND CIRCUIT

1. Connect audio unit connector.
2. Check continuity between audio unit harness connector terminal 15 and ground.

15 – Ground : Continuity should exist.

Is inspection result OK?

- YES >> Replace TEL adapter unit.
NO >> Replace audio unit.

COMMUNICATION SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

COMMUNICATION SIGNAL CIRCUIT

Description

INFOID:000000001700307

Satellite radio tuner and audio unit are connected with a serial communication. They transmit the operation signal from audio unit to satellite radio tuner.

Diagnosis Procedure

INFOID:000000001700308

1. CHECK CONTINUITY COMMUNICATION SIGNAL (AUDIO-SAT) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner connector and audio unit connector.
3. Check continuity between satellite radio tuner harness connector terminals 9, 10 and audio unit harness connector terminals 39, 40.

9 – 39 : Continuity should exist.

10 – 40 : Continuity should exist.

4. Check continuity between satellite radio tuner harness connector terminals 9, 10 and ground.

9, 10 – Ground : Continuity should not exist.

Is inspection result OK?

YES >> GO TO 2.

NO >> Repair harness or connector.

2. CHECK AUDIO UNIT

1. Connect audio unit connector.
2. Turn ignition switch ON.
3. Check voltage between audio unit harness connector terminal 39 and ground.

39 – Ground : Approx. 4 V

Is inspection result OK?

YES >> GO TO 3.

NO >> Replace audio unit.

3. CHECK SATELLITE RADIO TUNER

1. Turn ignition switch OFF.
2. Disconnect audio unit connector, and connect satellite radio tuner connector.
3. Turn ignition switch ON.
4. Check voltage between satellite radio tuner harness connector terminal 10 and ground.

10 – Ground : Approx. 7.5 V

Is inspection result OK?

YES >> GO TO 4.

NO >> Replace satellite radio tuner.

4. CHECK COMMUNICATION SIGNAL (SAT-AUDIO)

1. Turn ignition switch OFF.
2. Connect audio unit connector.
3. Turn ignition switch ON.
4. Check signal between satellite radio tuner harness connector terminal 9 and ground.


A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

COMMUNICATION SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]


9 – Ground	When satellite radio mode is selected.	 <p style="text-align: right; font-size: small;">PKIB5039J</p>
------------	--	--

Is inspection result OK?

- YES >> GO TO 5.
- NO >> Replace satellite radio tuner.

5. CHECK COMMUNICATION SIGNAL (AUDIO-SAT)

Check signal between audio unit harness connector terminal 40 and ground.

40 – Ground	When satellite radio mode is selected.	 <p style="text-align: right; font-size: small;">SKIA9301J</p>
-------------	--	--

Is inspection result OK?

- YES >> INSPECTION END
- NO >> Replace audio unit.

REQUEST SIGNAL CIRCUIT (SAT TO AUDIO)

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

REQUEST SIGNAL CIRCUIT (SAT TO AUDIO)

Description

INFOID:000000001722582

Request signal transmits the signal to recognize the connection of satellite radio tuner from satellite radio tuner to audio unit.

Diagnosis Procedure

INFOID:000000001722583

1. CHECK CONTINUITY REQUEST SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner connector and audio unit connector.
3. Check continuity between satellite radio tuner unit harness connector terminal 8 and audio unit harness connector terminal 38.

8 – 38 : Continuity should exist.

4. Check continuity between satellite radio tuner harness connector terminal 8 and ground.

8 – Ground : Continuity should not exist.

Is inspection result OK?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK AUDIO UNIT

1. Connect audio unit connector.
2. Turn ignition switch ON.
3. Check voltage between audio unit harness connector terminal 38 and ground.


38 – Ground : Approx. 4 V

Is inspection result OK?

- YES >> GO TO 3.
NO >> Replace audio unit.

3. CHECK CONTINUITY REQUEST SIGNAL

1. Turn ignition switch OFF.
2. Connect satellite radio tuner connector.
3. Turn ignition switch ON.
4. Check signal between satellite radio tuner harness connector terminal 8 and ground.



Is inspection result OK?

- YES >> INSPECTION END
NO >> Replace satellite radio tuner.

AMP. ON SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

AMP. ON SIGNAL CIRCUIT

Description

INFOID:000000001700302

When the audio system is turned on, a voltage signal is supplied from the audio unit to the BOSE amp. When this signal is received, the BOSE amp. will turn on.

Diagnosis Procedure

INFOID:000000001700303

1. CHECK CONTINUITY AMP. ON SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect audio unit connector and BOSE amp. connector.
3. Check continuity between audio unit harness connector terminal 1 and BOSE amp. harness connector terminal 31.

1 – 31 : Continuity should exist.

4. Check continuity between audio unit harness connector terminal 1 and ground.

1 – Ground : continuity should not exist.

Is inspection result OK?

YES >> GO TO 2.

NO >> Repair harness or connector.

2. CHECK VOLTAGE AMP. ON SIGNAL

1. Connect audio unit connector.
2. Turn ignition switch ON.
3. Check voltage between audio unit harness connector terminal 1 and ground.

1 – Ground : Approx. 12 V

Is inspection result OK?

YES >> Replace BOSE amp.

NO >> Replace audio unit.

WOOFER AMP. ON SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

WOOFER AMP. ON SIGNAL CIRCUIT

Description

INFOID:000000001871933

When the audio system is turned on, a voltage signal is supplied from the BOSE amp. to the woofer. When this signal is received, the woofer will turn on.

Diagnosis Procedure

INFOID:000000001871946

1. CHECK CONTINUITY WOOFER AMP. ON SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BOSE amp. connector and woofer connector.
3. Check continuity between BOSE amp. harness connector terminal 25 and woofer harness connector terminal 4.

25 – 4 : Continuity should exist.

4. Check continuity between BOSE amp. harness connector terminal 25 and ground.

25 – Ground : continuity should not exist.

Is inspection result OK?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK VOLTAGE AMP. ON SIGNAL

1. Connect BOSE amp. connector
2. Turn ignition switch ON.
3. Check voltage between BOSE amp. harness connector terminal 25 and ground.

25 – Ground : Approx. 12 V

Is inspection result OK?

- YES >> Replace woofer.
NO >> Replace BOSE amp.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

MICROPHONE SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

MICROPHONE SIGNAL CIRCUIT

Description

INFOID:000000001700311

Supply power from TEL adapter unit to microphone. The microphone transmits the sound voice to the TEL adapter unit.

Diagnosis Procedure

INFOID:000000001722804

1. CHECK CONTINUITY BETWEEN TEL ADAPTER UNIT AND MICROPHONE CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TEL adapter unit connector and microphone connector.
3. Check continuity between TEL adapter unit harness connector terminals 7, 8, 29 and microphone harness connector terminals 1, 2, 4.

7 – 1 : Continuity should exist.

8 – 2 : Continuity should exist.

29 – 4 : Continuity should exist.

4. Check continuity between TEL adapter unit harness connector terminals 7, 29 and ground.

7, 29 – Ground : Continuity should not exist.

Is inspection result OK?

YES >> GO TO 2.

NO >> Repair harness or connector.

2. CHECK MICROPHONE POWER SUPPLY

1. Connect TEL adapter unit connector.
2. Turn ignition switch ON.
3. Check voltage between TEL adapter unit harness connector terminals 29 and ground.

29 – Ground : Approx. 5 V


Is inspection result OK?

YES >> GO TO 3.

NO >> Replace TEL adapter unit.

3. CHECK MICROPHONE SIGNAL

1. Turn ignition switch OFF.
2. Connect microphone connector.
3. Turn ignition switch ON.
4. Check signal between TEL adapter unit harness connector terminals 7 and 8.

7 – 8	Give a voice	 <p>SKIB3609E</p>
-------	--------------	--

Is inspection result OK?

YES >> INSPECTION END

NO >> Replace microphone.

TELEPHONE ON SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

[BOSE AUDIO]

TELEPHONE ON SIGNAL CIRCUIT

Description

INFOID:000000001722666

When telephone is being used. TEL adapter unit transmits telephone ON signal to audio unit.

Diagnosis Procedure

INFOID:000000001722667

1. CHECK CONTINUITY TELEPHONE ON SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect TEL adapter unit connector and audio unit connector.
3. Check continuity between TEL adapter unit harness connector terminal 11 and audio unit harness connector terminal 28.

11 – 28 : Continuity should exist.

4. Check continuity between TEL adapter unit harness connector terminal 11 and ground.

11 – Ground : Continuity should not exist.

Is inspection result OK?

- YES >> GO TO 2.
NO >> Repair harness or connector.

2. CHECK TELEPHONE ON SIGNAL

1. Connect audio unit connector.
2. Turn ignition switch ON.
3. Check voltage between audio unit harness connector terminal 28 and ground.

28 – Ground

While using hands-free phone system : 0 V

While not using hands-free phone system : 5 V

Is inspection result OK?

- YES >> INSPECTION END
NO >> Replace audio unit.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]


ECU DIAGNOSIS

AUDIO UNIT

Reference Value



INFOID:000000001700313

TERMINAL LAYOUT



JSNIA0759ZZ




PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
1 (BR)	Ground	Amp. ON signal	Output	Ignition switch ON	—	12 V
2 (R)	3 (G)	Sound signal front LH	Output	Ignition switch ON	Voice output	 SKIB3609E
4 (V)	5 (LG)	Sound signal rear LH	Output	Ignition switch ON	Voice output	 SKIB3609E
6 (W)	15 (GR)	Steering switch signal A	Input	Ignition switch ON	Keep pressing SOURCE switch	0 V
					Keep pressing SEEK UP switch	1.1 V
					Keep pressing VOL UP switch	2.2 V
					Except for above	3.3 V
7 (SB)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
10	—	Shield	—	—	—	—

AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
11 (O)	12 (W)	Sound signal front RH	Output	Ignition switch ON	Voice output	
13 (L)	14 (P)	Sound signal rear RH	Output	Ignition switch ON	Voice output	
15 (GR)	Ground	Steering switch signal ground	—	Ignition switch ON	—	0 V
16 (O)	15 (GR)	Steering switch signal B	Input	Ignition switch ON	Keep pressing POWER switch*	0 V
					Keep pressing SEEK DOWN switch	1.1 V
					Keep pressing VOL DOWN switch	2.2 V
					Except for above	3.3 V
18 (L)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	When vehicle speed is ap- prox. 40 km/h (25MPH)	<p>NOTE: The maximum voltage varies de- pending on the specification (destination unit).</p> 
19 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
20	—	shield	—	—	—	—
21 (L)	—	AV communication signal (H)	—	Input/ Output	—	—
22 (P)	—	AV communication signal (L)	—	Input/ Output	—	—
23	—	Shield	—	—	—	—
25	—	Shield	—	—	—	—

A
B
C
D
E
F
G
H
I
J
K
L
M







AV

O
P

AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
26 (BR)	27 (Y)	Sound signal (Telephone voice, tele- phone guidance)	Input	Ignition switch ON	Give a voice	 SKIB3609E
28 (V)	Ground	Telephone ON signal	Input	Ignition switch ON	While using hands-free phone system	0 V
					While not using hands-free phone system	5 V
32 (L)	31 (R)	Satellite radio sound signal LH	Input	Ignition switch ON	When satellite radio mode is selected	 SKIB3609E
34 (W)	33 (G)	Satellite radio sound signal RH	Input	Ignition switch ON	When satellite radio mode is selected	 SKIB3609E
35	—	Shield	—	—	—	—
36	—	Shield	—	—	—	—
38 (Y)	Ground	Request signal (SAT TO AUDIO)	Input	Ignition switch ON	When satellite radio mode is selected	 JSNIA0675ZZ
39 (B)	Ground	Communication signal (SAT-AUDIO)	Input	Ignition switch ON	When satellite radio mode is selected	 PKIB5039J
40 (L)	Ground	Communication signal (AUDIO-SAT)	Output	Ignition switch ON	When satellite radio mode is selected	 SKIA9301J

AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
51	—	Antenna signal	Input	—	—	—
52	Ground	Antenna amp. ON signal	Output	Ignition switch ON	—	12 V

* : Without telephone system

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV


AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

Wiring Diagram - BOSE AUDIO -

INFOID:000000001700314



*: This connector is not shown in "Harness Layout".


2007/07/13

JCNWM0552GI

AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]



*: This connector is not shown in "Harness Layout".

JCNWM0554G1

AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]


BOSE AUDIO

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80WV-CS (F-TM4)



Terminal No.	Color of Wire	Signal Name [Specification]
35	SHIELD	-
36	R	-
37	LG	-
38	SHIELD	-
39	O	-
40	G	-
41	R	-
45	L	-
46	W	-
47	SHIELD	-
48	V	-

Connector No.	B8
Connector Name	TEL ADAPTER UNIT
Connector Type	TH2FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	BAT
2	SB	ACC
3	W	IGN
4	B	GND
6	SHIELD	SHIELD
7	B	MICROPHONE SIGNAL (+)
8	R	MICROPHONE SIGNAL (-)
9	BR	SOUND SIGNAL (+)
10	Y	SOUND SIGNAL (-)
11	O	TELEPHONE ON SIGNAL
12	W	STEERING SW SIGNAL A

49	W	-
50	SHIELD	-
52	L	-
53	G	-
54	O	-
55	Y	-
56	SHIELD	-
57	L	-
58	W	-
59	B	-
60	SB	-
61	BR	-
62	GR	-
63	W	-
65	SHIELD	-
66	BR	-
67	P	-
68	SHIELD	-
69	R	-
70	W	-
71	W	-
72	Y	-
82	GR	-

13	Y	STEERING SW SIGNAL B
14	GR	STEERING SW SIGNAL GND
17	W	STEERING SW SIGNAL A
18	L	STEERING SW SIGNAL B
19	GR	STEERING SW SIGNAL GND
21	B	GND
22	B	GND
23	B	GND
24	B	GND
28	G	VEHICLE SPEED SIGNAL (P-PULSE)
29	W	MICROPHONE POWER

Connector No.	B2
Connector Name	WIRE TO WIRE
Connector Type	TH24WV-NH



Terminal No.	Color of Wire	Signal Name [Specification]
7	SHIELD	-
8	G	-
9	SHIELD	-
10	G	-
11	B	-
12	SB	-
20	L	-
21	Y	-
22	W	-
23	L	-
24	BR	-

Connector No.	B7
Connector Name	TEL ADAPTER UNIT
Connector Type	TH8BFW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
35	L	AV COMMUNICATION SIGNAL (H)
36	P	AV COMMUNICATION SIGNAL (L)
37	SHIELD	SHIELD

Connector No.	B19
Connector Name	SATELLITE RADIO TUNER
Connector Type	A18FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	SOUND SIGNAL LH (-)
2	L	SOUND SIGNAL LH (+)
3	G	SOUND SIGNAL RH (-)
4	W	SOUND SIGNAL RH (+)
5	SHIELD	SHIELD
6	SHIELD	SHIELD
8	Y	REQUEST SIGNAL (SAT TO AUDIO)
9	G	COMMUNICATION SIGNAL (SAT-AUDIO)
10	L	COMMUNICATION SIGNAL (AUDIO-SAT)
12	BR	BAT
16	SB	ACC

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No.	B55
Connector Name	WIRE TO WIRE
Connector Type	NSJ2FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	R	-
5	L	-

Connector No.	B54
Connector Name	WIRE TO WIRE
Connector Type	NSJ2MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	R	-
5	L	-

Connector No.	B52
Connector Name	WIRE TO WIRE
Connector Type	NSQMMH-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	R	-


Connector No.	B51
Connector Name	WIRE TO WIRE
Connector Type	NS4MY-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	R	-

Terminal No.	Color of Wire	Signal Name [Specification]
12	B	GND
13	R	SOUND SIGNAL FRONT SPEAKER RH (-)
14	BR	SOUND SIGNAL WOOFER (-)

Connector No.	B64
Connector Name	BOSE AMP.
Connector Type	SGA2FRF-SJA2

Connector No.	B63
Connector Name	WOOFER
Connector Type	RS0FGY-PR




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	SOUND SIGNAL REAR SPEAKER LH (+)
2	GR	SOUND SIGNAL REAR SPEAKER RH (+)
3	Y	SOUND SIGNAL REAR SPEAKER LH (-)
4	B	SOUND SIGNAL FRONT SPEAKER LH (+)
5	P	SOUND SIGNAL FRONT SPEAKER LH (-)
6	BR	SOUND SIGNAL TWEETER LH (+)
7	GR	SOUND SIGNAL TWEETER LH (-)
8	G	SOUND SIGNAL FRONT SPEAKER RH (+)
9	Y	SOUND SIGNAL WOOFER (+)
10	R	SOUND SIGNAL REAR SPEAKER LH (-)
11	W	BAT

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	SOUND SIGNAL WOOFER (-)
2	Y	SOUND SIGNAL WOOFER (+)
3	SHIELD	SHIELD
4	G	WOOFER AMP_ON SIGNAL
5	B	GND
6	SB	BAT

JCNWM0556G1


AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No.	B65
Connector Name	BOSE AMP.
Connector Type	SCA1PBR-SCA4



Terminal No.	Color of Wire	Signal Name [Specification]
15	V	SOUND SIGNAL CENTER SPEAKER (+)
16	R	SOUND SIGNAL FRONT LH (+)
18	O	SOUND SIGNAL FRONT RH (+)
20	W	SOUND SIGNAL FRONT RH (-)
21	V	SOUND SIGNAL REAR LH (+)
22	LG	SOUND SIGNAL REAR LH (-)
23	W	SOUND SIGNAL REAR RH (+)
25	G	WOOFER AMP. ON SIGNAL
27	W	SOUND SIGNAL TWEETER RH (+)
28	O	SOUND SIGNAL CENTER SPEAKER (-)
31	L	AMP. ON SIGNAL

Connector No.	B76
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	P	-
3	B	-
4	R	-
5	G	-
6	SB	-
7	O	-
8	V	-
9	GR	-
10	BR	-
11	W	-

32	G	SOUND SIGNAL FRONT LH (-)
33	R	SOUND SIGNAL REAR RH (-)
37	O	SOUND SIGNAL TWEETER RH (+)



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
3	R	-

Connector No.	B86
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	L	-
8	R	-

Connector No.	B67
Connector Name	WIRE TO WIRE
Connector Type	NS08MP-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
3	R	-

Connector No.	B88
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	GR	-
8	Y	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No. B351	SATELLITE RADIO TUNER	FAKRA JACK			Terminal No. 31	Color of Wire -	Signal Name [Specification] -
Connector No. B352	SATELLITE RADIO ANTENNA	GT16C-1PP-RU			Terminal No. 1	Color of Wire -	Signal Name [Specification] -
Connector No. B451	TEL ADAPTER UNIT	GT16C-IS-RU			Terminal No. 33 34	Color of Wire - -	Signal Name [Specification] TEL ANTENNA SIGNAL SHIELD
Connector No. D2	WIRE TO WIRE	NS16FW-CS			Terminal No. 3 10	Color of Wire B P	Signal Name [Specification] -
Connector No. D4	FRONT SPEAKER LH	NS02FW-CS			Terminal No. 1 2	Color of Wire B P	Signal Name [Specification] -
Connector No. D42	WIRE TO WIRE	NS10FW-CS			Terminal No. 2 6	Color of Wire G R	Signal Name [Specification] -
Connector No. D44	FRONT SPEAKER RH	NS02FW-CS			Terminal No. 1 2	Color of Wire G R	Signal Name [Specification] -
Connector No. D81	WIRE TO WIRE	NS12FW-CS			Terminal No. 3 8	Color of Wire L R	Signal Name [Specification] -

JCNWM05586I

AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]


BOSE AUDIO

Connector No.	D084
Connector Name	REAR SPEAKER LH
Connector Type	NS2ZFBF-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	R	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Type	NS1ZFW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
3	GR	-
8	Y	-

Connector No.	D104
Connector Name	REAR SPEAKER RH
Connector Type	NS2ZFBF-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	Y	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
99	SB	-
100	L	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
35	SHIELD	-
36	P	-
37	LG	-
38	SHIELD	-
39	O	-
40	G	-
41	R	-
45	BR	-
46	L	-
47	SHIELD	-
48	Y	-

49	W	-
50	SHIELD	-
52	O	-
53	G	-
54	V	-
55	Y	-
56	SHIELD	-
57	L	-
58	W	-
59	B	-
60	SB	-
61	BR	-
62	GR	-
63	W	-
65	SHIELD	-
66	BR	-
67	P	-
68	SHIELD	-
69	R	-
70	LG	-
71	BR	-
72	O	-
82	GR	-

Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
7	SHIELD	-
8	B	-
9	SHIELD	-
10	G	-
11	R	-
12	SB	-
20	L	-
21	Y	-
22	W	-
23	L	-
24	BR	-

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	R	-
10	G	-

JCNWM0559G1

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]


BOSE AUDIO

Connector No.	M22
Connector Name	TWEETER RH
Connector Type	TK22FR




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	Y	-

Connector No.	M23
Connector Name	WIRE TO WIRE
Connector Type	TH12FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
2	SHIELD	-
3	W	-
8	R	-
9	B	-

Connector No.	M33
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK33BGY-IV




Terminal No.	Color of Wire	Signal Name [Specification]
24	BR	-
31	GR	-
32	O	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SA34GEW



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L
30	Y	VEHICLE SPEED (2-PULSE)
31	L	VEHICLE SPEED (8-PULSE)

Connector No.	M46
Connector Name	AUDIO UNIT
Connector Type	TH18FW-CSZ



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	AMP. ON SIGNAL
2	R	SOUND SIGNAL FRONT LH (+)
3	G	SOUND SIGNAL FRONT LH (-)
4	V	SOUND SIGNAL REAR LH (+)
5	LG	SOUND SIGNAL REAR LH (-)
6	W	STEERING SW SIGNAL A
7	SB	ACC
10	SHIELD	SHIELD
11	O	SOUND SIGNAL FRONT RH (+)
12	W	SOUND SIGNAL FRONT RH (-)
13	L	SOUND SIGNAL REAR RH (+)

14	P	SOUND SIGNAL REAR RH (+)
15	GR	STEERING SW SIGNAL GND
16	O	STEERING SW SIGNAL B
18	L	VEHICLE SPEED SIGNAL (8-PULSE)
19	Y	BAT.
20	SHIELD	SHIELD

Connector No.	M47
Connector Name	AUDIO UNIT
Connector Type	TH38FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	AV COMMUNICATION SIGNAL (H)
22	P	AV COMMUNICATION SIGNAL (L)
23	SHIELD	SHIELD
25	SHIELD	SHIELD
26	BR	SOUND SIGNAL (+)
27	Y	SOUND SIGNAL (-)
28	V	TELEPHONE ON SIGNAL

Connector No.	M48
Connector Name	AUDIO UNIT
Connector Type	A12FW



Terminal No.	Color of Wire	Signal Name [Specification]
31	R	SOUND SIGNAL LH (-)
32	L	SOUND SIGNAL LH (+)
33	G	SOUND SIGNAL LH (-)
34	W	SOUND SIGNAL LH (+)
35	SHIELD	SHIELD
36	Y	REQUEST SIGNAL (SAT TO AUDIO)
39	B	COMMUNICATION SIGNAL (SAT-AUDIO)
40	L	COMMUNICATION SIGNAL (AUDIO-SAT)


JCNWM0560G1

AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

<p>Connector No. M65 Connector Name BCM BODY CONTROL MODULE) Connector Type TH407W</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>39</td> <td>L</td> <td>CAN-H</td> </tr> <tr> <td>40</td> <td>P</td> <td>CAN-L</td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	39	L	CAN-H	40	P	CAN-L	<p>Connector No. M77 Connector Name WIRE TO WIRE Connector Type TH80MH-CS (6-TM4)</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>99</td> <td>SB</td> <td></td> </tr> <tr> <td>100</td> <td>Y</td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	99	SB		100	Y		<p>Connector No. M79 Connector Name WIRE TO WIRE Connector Type NS12FW-CS</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>LG</td> <td></td> </tr> <tr> <td>2</td> <td>G</td> <td></td> </tr> <tr> <td>3</td> <td>R</td> <td></td> </tr> <tr> <td>4</td> <td>W</td> <td></td> </tr> <tr> <td>5</td> <td>O</td> <td></td> </tr> <tr> <td>8</td> <td>SB</td> <td></td> </tr> <tr> <td>7</td> <td>P</td> <td></td> </tr> <tr> <td>8</td> <td>V</td> <td></td> </tr> <tr> <td>9</td> <td>GR</td> <td></td> </tr> <tr> <td>10</td> <td>BR</td> <td></td> </tr> <tr> <td>11</td> <td>Y</td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	1	LG		2	G		3	R		4	W		5	O		8	SB		7	P		8	V		9	GR		10	BR		11	Y		<p>Connector No. M80 Connector Name TWEETER LH Connector Type TK02FBR</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>BR</td> <td></td> </tr> <tr> <td>2</td> <td>P</td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	1	BR		2	P		<p>Connector No. M82 Connector Name WIRE TO WIRE Connector Type NS10MW-CS</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>2</td> <td>O</td> <td></td> </tr> <tr> <td>6</td> <td>W</td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	2	O		6	W		<p>Connector No. M85 Connector Name CENTER SPEAKER Connector Type TK02FBR</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>V</td> <td></td> </tr> <tr> <td>2</td> <td>P</td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	1	V		2	P		<p>Connector No. M86 Connector Name WIRE TO WIRE Connector Type NS10MW-CS</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>14</td> <td>B</td> <td></td> </tr> <tr> <td>15</td> <td>Y</td> <td></td> </tr> <tr> <td>16</td> <td>W</td> <td></td> </tr> <tr> <td>17</td> <td>W</td> <td></td> </tr> <tr> <td>18</td> <td>W</td> <td></td> </tr> <tr> <td>19</td> <td>W</td> <td></td> </tr> <tr> <td>20</td> <td>W</td> <td></td> </tr> <tr> <td>21</td> <td>W</td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	14	B		15	Y		16	W		17	W		18	W		19	W		20	W		21	W		<p>Connector No. M87 Connector Name COMBINATION SWITCH (SPIRAL CABLE) Connector Type TK08FGY</p>  <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>16</td> <td></td> <td></td> </tr> <tr> <td>17</td> <td></td> <td></td> </tr> <tr> <td>20</td> <td></td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	16			17			20		
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																													
39	L	CAN-H																																																																																																																													
40	P	CAN-L																																																																																																																													
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																													
99	SB																																																																																																																														
100	Y																																																																																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																													
1	LG																																																																																																																														
2	G																																																																																																																														
3	R																																																																																																																														
4	W																																																																																																																														
5	O																																																																																																																														
8	SB																																																																																																																														
7	P																																																																																																																														
8	V																																																																																																																														
9	GR																																																																																																																														
10	BR																																																																																																																														
11	Y																																																																																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																													
1	BR																																																																																																																														
2	P																																																																																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																													
2	O																																																																																																																														
6	W																																																																																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																													
1	V																																																																																																																														
2	P																																																																																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																													
14	B																																																																																																																														
15	Y																																																																																																																														
16	W																																																																																																																														
17	W																																																																																																																														
18	W																																																																																																																														
19	W																																																																																																																														
20	W																																																																																																																														
21	W																																																																																																																														
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																																													
16																																																																																																																															
17																																																																																																																															
20																																																																																																																															

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AUDIO UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No.	M401	Connector No.	M402	Connector No.	M403	Connector No.	M404
Connector Name	AUDIO UNIT	WIRE TO WIRE	WIRE TO WIRE	WIRE TO WIRE	WIRE TO WIRE	RADIO ANTENNA	RADIO ANTENNA
Connector Type	GT13SH-2/1S-HU	GT13SC-1/1S-HU	GT13SC-1/1S-HU	GT13SCN-1/1PP-HU	GT13SCN-1/1PP-HU	GT13SSN-1/1PP-HU	GT13SSN-1/1PP-HU

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
51	-	ANTENNA SIGNAL	1	-	-
52	-	ANTENNA AMP. ON SIGNAL	2	-	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	R1	Connector No.	R3
Connector Name	WIRE TO WIRE	CONNECTOR NAME	MICROPHONE
Connector Type	TH12MW-NH	Connector Type	TRQ4FW

Terminal No.	Color of Wire	Signal Name [Specification]
2	SHIELD	-
3	W	-
8	R	-
9	B	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	MICROPHONE SIGNAL (+)
2	R	MICROPHONE SIGNAL (-)
4	W	MICROPHONE POWER

JCNWM0562GI

BOSE AMP.

< ECU DIAGNOSIS >


[BOSE AUDIO]

BOSE AMP.

Reference Value

INFOID:000000001700315

TERMINAL LAYOUT



PHYSICAL VALUES







Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
1 (L)	10 (R)	Sound signal rear speaker LH	Output	Ignition switch ON	Voice output	<p>SKIB3609E</p>
2 (GR)	3 (Y)	Sound signal rear speaker RH	Output	Ignition switch ON	Voice output	<p>SKIB3609E</p>
4 (B)	5 (P)	Sound signal front speaker LH	Output	Ignition switch ON	Voice output	<p>SKIB3609E</p>
6 (BR)	7 (GR)	Sound signal tweeter LH	Output	Ignition switch ON	Voice output	<p>SKIB3609E</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

BOSE AMP.

< ECU DIAGNOSIS >



[BOSE AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
8 (G)	13 (R)	Sound signal front speaker RH	Output	Ignition switch ON	Voice output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
9 (Y)	14 (BR)	Sound signal woofer	Output	Ignition switch ON	Voice output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
11 (W)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
12 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
15 (V)	28 (O)	Sound signal center speak- er	Output	Ignition switch ON	Voice output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
18 (R)	32 (G)	Sound signal front LH	Input	Ignition switch ON	Voice output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
19 (O)	20 (W)	Sound signal front RH	Input	Ignition switch ON	Voice output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
21 (V)	22 (LG)	Sound signal rear LH	Input	Ignition switch ON	Voice output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>

BOSE AMP.

< ECU DIAGNOSIS >

[BOSE AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
23 (W)	33 (R)	Sound signal rear RH	Input	Ignition switch ON	Voice output	
25 (G)	Ground	Woofer Amp. ON signal	Output	Ignition switch ACC	—	12 V
31 (L)	Ground	Amp. ON signal	Input	Ignition switch ACC	—	12 V
37 (O)	27 (W)	Sound signal tweeter RH	Output	Ignition switch ON	Voice output	

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P


BOSE AMP.

< ECU DIAGNOSIS >

[BOSE AUDIO]

Wiring Diagram - BOSE AUDIO -

INFOID:000000001711578



*: This connector is not shown in "Harness Layout".


2007/07/13

JCNWM0552GI

BOSE AMP.

< ECU DIAGNOSIS >

[BOSE AUDIO]



*: This connector is not shown in "Harness Layout".

JCNWM0554G1

BOSE AMP.

< ECU DIAGNOSIS >

[BOSE AUDIO]


BOSE AUDIO

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80WV-CS (F-TM4)



Terminal No.	Color of Wire	Signal Name [Specification]
35	SHIELD	-
36	R	-
37	LG	-
38	SHIELD	-
39	O	-
40	G	-
41	R	-
45	L	-
46	W	-
47	SHIELD	-
48	V	-

Connector No.	B8
Connector Name	TEL ADAPTER UNIT
Connector Type	TH2FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	BAT
2	SB	ACC
3	W	IGN
4	B	GND
6	SHIELD	SHIELD
7	B	MICROPHONE SIGNAL (+)
8	R	MICROPHONE SIGNAL (-)
9	BR	SOUND SIGNAL (+)
10	Y	SOUND SIGNAL (-)
11	O	TELEPHONE ON SIGNAL
12	W	STEERING SW SIGNAL A

49	W	-
50	SHIELD	-
52	L	-
53	G	-
54	O	-
55	Y	-
56	SHIELD	-
57	L	-
58	W	-
59	B	-
60	SB	-
61	BR	-
62	GR	-
63	W	-
65	SHIELD	-
66	BR	-
67	P	-
68	SHIELD	-
69	R	-
70	W	-
71	W	-
72	Y	-
82	GR	-

13	Y	STEERING SW SIGNAL B
14	GR	STEERING SW SIGNAL GND
17	W	STEERING SW SIGNAL A
18	L	STEERING SW SIGNAL B
19	GR	STEERING SW SIGNAL GND
21	B	GND
22	B	GND
23	B	GND
24	B	GND
28	G	VEHICLE SPEED SIGNAL (PULSE)
29	W	MICROPHONE POWER

Connector No.	B2
Connector Name	WIRE TO WIRE
Connector Type	TH24WV-NH



Terminal No.	Color of Wire	Signal Name [Specification]
7	SHIELD	-
8	G	-
9	SHIELD	-
10	G	-
11	B	-
12	SB	-
20	L	-
21	Y	-
22	W	-
23	L	-
24	BR	-

Connector No.	B7
Connector Name	TEL ADAPTER UNIT
Connector Type	TH8BFW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
35	L	AV COMMUNICATION SIGNAL (H)
36	P	AV COMMUNICATION SIGNAL (L)
37	SHIELD	SHIELD

Connector No.	B19
Connector Name	SATELLITE RADIO TUNER
Connector Type	A18FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	SOUND SIGNAL LH (-)
2	L	SOUND SIGNAL LH (+)
3	G	SOUND SIGNAL RH (-)
4	W	SOUND SIGNAL RH (+)
5	SHIELD	SHIELD
6	SHIELD	SHIELD
8	Y	REQUEST SIGNAL (SAT TO AUDIO)
9	G	COMMUNICATION SIGNAL (SAT-AUDIO)
10	L	COMMUNICATION SIGNAL (AUDIO-SAT)
12	BR	BAT
16	SB	ACC

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV


BOSE AMP.

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No.	B65
Connector Name	BOSE AMP.
Connector Type	SCA1PBR-SCA4



Terminal No.	Color of Wire	Signal Name [Specification]
15	V	SOUND SIGNAL CENTER SPEAKER (+)
16	R	SOUND SIGNAL FRONT LH (+)
18	O	SOUND SIGNAL FRONT RH (+)
20	W	SOUND SIGNAL FRONT RH (-)
21	V	SOUND SIGNAL REAR LH (+)
22	LG	SOUND SIGNAL REAR LH (-)
23	W	SOUND SIGNAL REAR RH (+)
25	G	WOOFER AMP-ON SIGNAL
27	W	SOUND SIGNAL TWEETER RH (+)
28	O	SOUND SIGNAL CENTER SPEAKER (-)
31	L	AMP-ON SIGNAL

Connector No.	B76
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	P	-
3	B	-
4	R	-
5	G	-
6	SB	-
7	O	-
8	V	-
9	GR	-
10	BR	-
11	W	-

32	G	SOUND SIGNAL FRONT LH (-)
33	R	SOUND SIGNAL REAR RH (-)
37	O	SOUND SIGNAL TWEETER RH (+)

Connector No.	B66
Connector Name	WIRE TO WIRE
Connector Type	NSB6FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
3	R	-

Connector No.	B88
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	L	-
8	R	-

Connector No.	B67
Connector Name	WIRE TO WIRE
Connector Type	NSB6FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
3	R	-

Connector No.	B88
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	GR	-
8	Y	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

JCNWM0557GI

BOSE AMP.

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No. B351	SATELLITE RADIO TUNER	FAKRA JACK			Terminal No. 31	Color of Wire -	Signal Name [Specification] -
Connector No. B352	SATELLITE RADIO ANTENNA	GT16C-1PP-RU			Terminal No. 1	Color of Wire -	Signal Name [Specification] -
Connector No. B451	TEL ADAPTER UNIT	GT16C-IS-RU			Terminal No. 33	Color of Wire -	Signal Name [Specification] TEL ANTENNA SIGNAL
Connector No. D2	WIRE TO WIRE	NS16FW-CS			Terminal No. 3	Color of Wire B	Signal Name [Specification] -
Connector No. D4	FRONT SPEAKER LH	NS02FW-CS			Terminal No. 1	Color of Wire B	Signal Name [Specification] -
Connector No. D42	WIRE TO WIRE	NS10FW-CS			Terminal No. 2	Color of Wire G	Signal Name [Specification] -
Connector No. D44	FRONT SPEAKER RH	NS02FW-CS			Terminal No. 1	Color of Wire G	Signal Name [Specification] -
Connector No. D81	WIRE TO WIRE	NS12FW-CS			Terminal No. 3	Color of Wire L	Signal Name [Specification] -

JCNWM05586I

BOSE AUDIO

Connector No.	D084
Connector Name	REAR SPEAKER LH
Connector Type	NS2ZFBF-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	R	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Type	NS1ZFW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
3	GR	-
8	Y	-

Connector No.	D104
Connector Name	REAR SPEAKER RH
Connector Type	NS2ZFBF-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	Y	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
99	SB	-
100	L	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
35	SHIELD	-
36	P	-
37	LG	-
38	SHIELD	-
39	O	-
40	G	-
41	R	-
45	BR	-
46	L	-
47	SHIELD	-
48	Y	-

49	W	-
50	SHIELD	-
52	O	-
53	G	-
54	V	-
55	Y	-
56	SHIELD	-
57	L	-
58	W	-
59	B	-
60	SB	-
61	BR	-
62	GR	-
63	W	-
65	SHIELD	-
66	BR	-
67	P	-
68	SHIELD	-
69	R	-
70	LG	-
71	BR	-
72	O	-
82	GR	-

Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
7	SHIELD	-
8	B	-
9	SHIELD	-
10	G	-
11	R	-
12	SB	-
20	L	-
21	Y	-
22	W	-
23	L	-
24	BR	-

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	R	-
10	G	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

JCNWM0559G1


BOSE AUDIO

Connector No.	M22
Connector Name	TWEETER RH
Connector Type	TK22FR




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	Y	-

Connector No.	M23
Connector Name	WIRE TO WIRE
Connector Type	TH12FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
2	SHIELD	-
3	W	-
8	R	-
9	B	-

Connector No.	M33
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK33BGY-IV




Terminal No.	Color of Wire	Signal Name [Specification]
24	BR	-
31	GR	-
32	O	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SA340FW



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L
30	Y	VEHICLE SPEED (2-PULSE)
31	L	VEHICLE SPEED (8-PULSE)

Connector No.	M46
Connector Name	AUDIO UNIT
Connector Type	TH18FW-CSZ



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	AMP ON SIGNAL
2	R	SOUND SIGNAL FRONT LH (+)
3	G	SOUND SIGNAL FRONT LH (-)
4	V	SOUND SIGNAL REAR LH (+)
5	LG	SOUND SIGNAL REAR LH (-)
6	W	STEERING SW SIGNAL A
7	SB	ACC
10	SHIELD	SHIELD
11	O	SOUND SIGNAL FRONT RH (+)
12	W	SOUND SIGNAL FRONT RH (-)
13	L	SOUND SIGNAL REAR RH (+)

14	P	SOUND SIGNAL REAR RH (+)
15	GR	STEERING SW SIGNAL GND
16	O	STEERING SW SIGNAL B
18	L	VEHICLE SPEED SIGNAL (8-PULSE)
19	Y	BAT
20	SHIELD	SHIELD

Connector No.	M47
Connector Name	AUDIO UNIT
Connector Type	TH30FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	AV COMMUNICATION SIGNAL (H)
22	P	AV COMMUNICATION SIGNAL (L)
23	SHIELD	SHIELD
25	SHIELD	SHIELD
26	BR	SOUND SIGNAL (+)
27	Y	SOUND SIGNAL (-)
28	V	TELEPHONE ON SIGNAL

Connector No.	M48
Connector Name	AUDIO UNIT
Connector Type	A12FW




Terminal No.	Color of Wire	Signal Name [Specification]
31	R	SOUND SIGNAL LH (-)
32	L	SOUND SIGNAL LH (+)
33	G	SOUND SIGNAL LH (-)
34	W	SOUND SIGNAL LH (+)
35	SHIELD	SHIELD
36	Y	REQUEST SIGNAL (SAT TO AUDIO)
39	B	COMMUNICATION SIGNAL (SAT-AUDIO)
40	L	COMMUNICATION SIGNAL (AUDIO-SAT)

BOSE AMP.

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

<p>Connector No. M65 Connector Name BCM BODY CONTROL MODULE) Connector Type TH407W</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>39</td> <td>L</td> <td>CAN-H</td> </tr> <tr> <td>40</td> <td>P</td> <td>CAN-L</td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	39	L	CAN-H	40	P	CAN-L	<p>Connector No. M77 Connector Name WIRE TO WIRE Connector Type TH80MH-CS(B-TM4)</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>99</td> <td>SB</td> <td></td> </tr> <tr> <td>100</td> <td>Y</td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	99	SB		100	Y		<p>Connector No. M79 Connector Name WIRE TO WIRE Connector Type NS12FW-CS</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>LG</td> <td></td> </tr> <tr> <td>2</td> <td>G</td> <td></td> </tr> <tr> <td>3</td> <td>R</td> <td></td> </tr> <tr> <td>4</td> <td>W</td> <td></td> </tr> <tr> <td>5</td> <td>O</td> <td></td> </tr> <tr> <td>8</td> <td>SB</td> <td></td> </tr> <tr> <td>7</td> <td>P</td> <td></td> </tr> <tr> <td>8</td> <td>V</td> <td></td> </tr> <tr> <td>9</td> <td>GR</td> <td></td> </tr> <tr> <td>10</td> <td>BR</td> <td></td> </tr> <tr> <td>11</td> <td>Y</td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	1	LG		2	G		3	R		4	W		5	O		8	SB		7	P		8	V		9	GR		10	BR		11	Y		<p>Connector No. M80 Connector Name TWEETER LH Connector Type TK02FBR</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>BR</td> <td></td> </tr> <tr> <td>2</td> <td>P</td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	1	BR		2	P		<p>Connector No. M82 Connector Name WIRE TO WIRE Connector Type NS10MW-CS</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>2</td> <td>O</td> <td></td> </tr> <tr> <td>6</td> <td>W</td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	2	O		6	W		<p>Connector No. M95 Connector Name CENTER SPEAKER Connector Type TK02FBR</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>V</td> <td></td> </tr> <tr> <td>2</td> <td>P</td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	1	V		2	P		<p>Connector No. M92 Connector Name WIRE TO WIRE Connector Type NS10MW-CS</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>2</td> <td>O</td> <td></td> </tr> <tr> <td>6</td> <td>W</td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	2	O		6	W		<p>Connector No. M52 Connector Name COMBINATION SWITCH (SPIRAL CABLE) Connector Type TK08FGY</p>   <table border="1"> <thead> <tr> <th>Terminal No.</th> <th>Color of Wire</th> <th>Signal Name [Specification]</th> </tr> </thead> <tbody> <tr> <td>16</td> <td></td> <td></td> </tr> <tr> <td>17</td> <td></td> <td></td> </tr> <tr> <td>20</td> <td></td> <td></td> </tr> </tbody> </table>	Terminal No.	Color of Wire	Signal Name [Specification]	16			17			20		
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																											
39	L	CAN-H																																																																																																											
40	P	CAN-L																																																																																																											
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																											
99	SB																																																																																																												
100	Y																																																																																																												
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																											
1	LG																																																																																																												
2	G																																																																																																												
3	R																																																																																																												
4	W																																																																																																												
5	O																																																																																																												
8	SB																																																																																																												
7	P																																																																																																												
8	V																																																																																																												
9	GR																																																																																																												
10	BR																																																																																																												
11	Y																																																																																																												
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																											
1	BR																																																																																																												
2	P																																																																																																												
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																											
2	O																																																																																																												
6	W																																																																																																												
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																											
1	V																																																																																																												
2	P																																																																																																												
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																											
2	O																																																																																																												
6	W																																																																																																												
Terminal No.	Color of Wire	Signal Name [Specification]																																																																																																											
16																																																																																																													
17																																																																																																													
20																																																																																																													

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

BOSE AUDIO

Connector No.	M401	Connector No.	M402	Connector No.	M403	Connector No.	M404
Connector Name	AUDIO UNIT	WIRE TO WIRE	WIRE TO WIRE	WIRE TO WIRE	RADIO ANTENNA		
Connector Type	GT13SH-2/1S-HU	GT13SC-1/1S-HU	GT13SC-1/1S-HU	GT13SCN-1/1PP-HU	GT13SSN-1/1PP-HU		

Terminal No.	Color of Wire	Signal Name [Specification]	Terminal No.	Color of Wire	Signal Name [Specification]
51	-	ANTENNA SIGNAL	1	-	-
52	-	ANTENNA AMP. ON SIGNAL	2	-	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	-	-
2	-	-

BOSE AMP.

Connector No.	R1	Connector No.	R3
Connector Name	WIRE TO WIRE	MICROPHONE	
Connector Type	TH12MW-NH	TRQ4FW	

Terminal No.	Color of Wire	Signal Name [Specification]
2	SHIELD	-
3	W	-
8	R	-
9	B	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	B	MICROPHONE SIGNAL (+)
2	R	MICROPHONE SIGNAL (-)
4	W	MICROPHONE POWER

SATELLITE RADIO TUNER

< ECU DIAGNOSIS >


[BOSE AUDIO]

SATELLITE RADIO TUNER

Reference Value

INFOID:000000001711579

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/Output			
2 (L)	1 (R)	Satellite radio sound signal LH	Output	Ignition switch ON	When satellite radio mode is selected	<p>SKIB3609E</p>
4 (W)	3 (G)	Satellite radio sound signal RH	Output	Ignition switch ON	When satellite radio mode is selected	<p>SKIB3609E</p>
5	—	Shield	—	—	—	—
6	—	Shield	—	—	—	—
8 (Y)	Ground	Request signal (SAT TO AUDIO)	Output	Ignition switch ON	When satellite radio mode is selected	<p>SKIA9299J</p>
9 (G)	Ground	Communication signal (SAT-AUDIO)	Output	Ignition switch ON	When satellite radio mode is selected	<p>PKIB5039J</p>


A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

SATELLITE RADIO TUNER

< ECU DIAGNOSIS >

[BOSE AUDIO]

Terminal		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
10 (L)	Ground	Communication signal (AUDIO→SAT)	Input	Ignition switch ON	When satellite radio mode is selected	 <p>(V) 10 0 -10 → 1ms</p> <p>SKIA9301J</p>
12 (BR)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
16 (SB)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
31	—	Satellite antenna	Input	—	—	—


SATELLITE RADIO TUNER

< ECU DIAGNOSIS >

[BOSE AUDIO]

Wiring Diagram - BOSE AUDIO -

INFOID:000000001711702



*: This connector is not shown in "Harness Layout".

2007/07/13

JCNWM0552GI


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

SATELLITE RADIO TUNER

< ECU DIAGNOSIS >

[BOSE AUDIO]




*: This connector is not shown in "Harness Layout".

JCNWM0553GI

SATELLITE RADIO TUNER

< ECU DIAGNOSIS >

[BOSE AUDIO]



JCNWM0554GI

*: This connector is not shown in "Harness Layout".

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV


SATELLITE RADIO TUNER

< ECU DIAGNOSIS >

[BOSE AUDIO]


BOSE AUDIO

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
35	SHIELD	-
36	R	-
37	LG	-
38	SHIELD	-
39	D	-
40	G	-
41	R	-
45	L	-
46	W	-
47	SHIELD	-
48	V	-

Connector No.	B8
Connector Name	TEL ADAPTER UNIT
Connector Type	TH82FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	BAT
2	SB	ACC
3	W	IGN
4	B	GND
6	SHIELD	SHIELD
7	B	MICROPHONE SIGNAL (+)
8	R	MICROPHONE SIGNAL (-)
9	BR	SOUND SIGNAL (+)
10	Y	SOUND SIGNAL (-)
11	O	TELEPHONE ON SIGNAL
12	W	STEERING SW SIGNAL A

49	W	-
50	SHIELD	-
52	L	-
53	G	-
54	O	-
55	Y	-
56	SHIELD	-
57	L	-
58	W	-
59	B	-
60	SB	-
61	BR	-
62	GR	-
63	W	-
65	SHIELD	-
66	BR	-
67	P	-
68	SHIELD	-
69	R	-
70	W	-
71	W	-
72	Y	-
82	GR	-

13	Y	STEERING SW SIGNAL B
14	GR	STEERING SW SIGNAL GND
17	W	STEERING SW SIGNAL A
18	L	STEERING SW SIGNAL B
19	GR	STEERING SW SIGNAL GND
21	B	GND
22	B	GND
23	B	GND
24	B	GND
26	G	VEHICLE SPEED SIGNAL (2-PULSE)
29	W	MICROPHONE POWER

Connector No.	B2
Connector Name	WIRE TO WIRE
Connector Type	TH24MW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
7	SHIELD	-
8	G	-
9	SHIELD	-
10	G	-
11	R	-
12	SB	-
20	L	-
21	Y	-
22	W	-
23	L	-
24	BR	-

Connector No.	B7
Connector Name	TEL ADAPTER UNIT
Connector Type	TH80FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
35	L	AV COMMUNICATION SIGNAL (H)
36	P	AV COMMUNICATION SIGNAL (L)
37	SHIELD	SHIELD

Connector No.	B19
Connector Name	SATELLITE RADIO TUNER
Connector Type	A18FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	SOUND SIGNAL LH (-)
2	L	SOUND SIGNAL LH (+)
3	G	SOUND SIGNAL RH (-)
4	W	SOUND SIGNAL RH (+)
5	SHIELD	SHIELD
6	SHIELD	SHIELD
8	Y	REQUEST SIGNAL (SAT TO AUDIO)
9	G	COMMUNICATION SIGNAL (SAT-AUDIO)
10	L	COMMUNICATION SIGNAL (AUDIO-SAT)
12	BR	BAT
16	SB	ACC

SATELLITE RADIO TUNER

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No.	B65
Connector Name	BOSE AMP.
Connector Type	SCA19BR-SGA4



Terminal No.	Color of Wire	Signal Name [Specification]
15	V	SOUND SIGNAL CENTER SPEAKER (+)
18	R	SOUND SIGNAL FRONT LH (+)
19	O	SOUND SIGNAL FRONT RH (+)
20	W	SOUND SIGNAL FRONT LH (-)
21	V	SOUND SIGNAL FRONT RH (-)
22	LG	SOUND SIGNAL REAR LH (+)
23	W	SOUND SIGNAL REAR RH (+)
25	G	WOOFER AMP. ON SIGNAL
27	W	SOUND SIGNAL TWEETER RH (+)
28	O	SOUND SIGNAL CENTER SPEAKER (-)
31	L	AMP. ON SIGNAL



Connector No.	B76
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS

32	G	SOUND SIGNAL FRONT LH (-)
33	R	SOUND SIGNAL REAR RH (-)
37	O	SOUND SIGNAL TWEETER RH (+)

Connector No.	B66
Connector Name	WIRE TO WIRE
Connector Type	NS6BFW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	
3	R	


12	O	
----	---	--

Connector No.	B68
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	
2	P	
3	B	
4	R	
5	G	
6	SB	
7	O	
8	V	
9	GR	
10	BR	
11	W	

Connector No.	B67
Connector Name	WIRE TO WIRE
Connector Type	NS6BMW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	
3	R	

Connector No.	B68
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	GR	
8	Y	

SATELLITE RADIO TUNER

< ECU DIAGNOSIS >


[BOSE AUDIO]

BOSE AUDIO

Connector No.	B351	Connector No.	B451	Connector No.	B352	Connector No.	D2
Connector Name	SATELLITE RADIO TUNER	Connector Name	TEL ADAPTER UNIT	Connector Name	SATELLITE RADIO ANTENNA	Connector Name	WIRE TO WIRE
Connector Type	FAKRA JACK	Connector Type	GT16C-1SP-RU	Connector Type	GT16C-1PP-RU	Connector Type	NS12FW-CS

Terminal No.	31	Terminal No.	33	Terminal No.	1	Terminal No.	3
Color of Wire	-	Color of Wire	-	Color of Wire	-	Color of Wire	B
Signal Name [Specification]	-	Signal Name [Specification]	TEL ANTENNA SIGNAL SHIELD	Signal Name [Specification]	-	Signal Name [Specification]	P


Terminal No.	2	Terminal No.	1	Terminal No.	2	Terminal No.	3
Color of Wire	B	Color of Wire	G	Color of Wire	R	Color of Wire	L
Signal Name [Specification]	-						



Connector No.	D4	Connector No.	D44	Connector No.	D42	Connector No.	D81
Connector Name	FRONT SPEAKER LH	Connector Name	FRONT SPEAKER RH	Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS	Connector Type	NS12FW-CS	Connector Type	NS10FW-CS	Connector Type	NS12FW-CS

Terminal No.	1	Terminal No.	2	Terminal No.	1	Terminal No.	3
Color of Wire	B	Color of Wire	G	Color of Wire	R	Color of Wire	L
Signal Name [Specification]	-						

Terminal No.	2	Terminal No.	1	Terminal No.	2	Terminal No.	3
Color of Wire	P	Color of Wire	G	Color of Wire	R	Color of Wire	L
Signal Name [Specification]	-						



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

SATELLITE RADIO TUNER

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No.	D04
Connector Name	REAR SPEAKER LH
Connector Type	NS2ZFR-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	R	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Type	NS1ZFW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
3	GR	-
8	Y	-

Connector No.	D104
Connector Name	REAR SPEAKER RH
Connector Type	NS2ZFR-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	Y	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
99	SB	-
100	L	-


Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
35	SHIELD	-
36	P	-
37	LG	-
38	SHIELD	-
39	O	-
40	G	-
41	R	-
45	BR	-
46	L	-
47	SHIELD	-
48	Y	-

49	W	-
50	SHIELD	-
52	O	-
53	G	-
54	V	-
55	Y	-
56	SHIELD	-
57	L	-
58	W	-
59	B	-
60	SB	-
61	BR	-
62	GR	-
63	W	-
65	SHIELD	-
66	BR	-
67	P	-
68	SHIELD	-
69	R	-
70	LG	-
71	BR	-
72	O	-
82	GR	-

Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
7	SHIELD	-
8	B	-
9	SHIELD	-
10	G	-
11	R	-
12	SB	-
20	L	-
21	Y	-
22	W	-
23	L	-
24	BR	-

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	R	-
10	G	-

JCNWM0559G1

SATELLITE RADIO TUNER

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No.	M401	Connector No.	M402	Connector No.	M403	Connector No.	M404
Connector Name	AUDIO UNIT	WIRE TO WIRE	WIRE TO WIRE	WIRE TO WIRE	WIRE TO WIRE	RADIO ANTENNA	RADIO ANTENNA
Connector Type	GT13SH-2/1S-HU	GT13SC-1/1S-HU	GT13SC-1/1S-HU	GT13SCN-1/1PP-HU	GT13SCN-1/1PP-HU	GT13SSN-1/1PP-HU	GT13SSN-1/1PP-HU

Terminal No.	51	Terminal No.	1	Terminal No.	1	Terminal No.	1
Color of Wire	-	Color of Wire	-	Color of Wire	-	Color of Wire	-
Signal Name [Specification]	ANTENNA SIGNAL	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-
	ANTENNA AMP. ON SIGNAL		-		-		-

Terminal No.	2	Terminal No.	1	Terminal No.	1	Terminal No.	1
Color of Wire	-						
Signal Name [Specification]	-						

Terminal No.	3	Terminal No.	2	Terminal No.	2	Terminal No.	2
Color of Wire	-						
Signal Name [Specification]	-						

Connector No.	R1	Connector No.	R3
Connector Name	WIRE TO WIRE	Connector Name	MICROPHONE
Connector Type	TH12MW-NH	Connector Type	TR04FW

Terminal No.	1	Terminal No.	1	Terminal No.	1	Terminal No.	1
Color of Wire	SHIELD	Color of Wire	B	Color of Wire	B	Color of Wire	B
Signal Name [Specification]	-	Signal Name [Specification]	MICROPHONE SIGNAL (+)	Signal Name [Specification]	MICROPHONE SIGNAL (-)	Signal Name [Specification]	MICROPHONE POWER
	3		2		2		4
	8		R		R		W
	9		R		W		W
	B		B		W		W

JCNWM0562GI

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

TEL ADAPTER UNIT

< ECU DIAGNOSIS >


[BOSE AUDIO]

TEL ADAPTER UNIT

Reference Value

INFOID:000000001711706

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
1 (BR)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
2 (SB)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
3 (W)	Ground	Ignition signal	Input	Ignition switch ON	—	Battery voltage
4 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
6	—	Shield	—	—	—	—
7 (B)	8 (R)	Microphone signal	Input	Ignition switch ON	Give a voice	<p>SKIB3609E</p>
9 (BR)	10 (Y)	Sound signal (Telephone voice, tele- phone guidance)	Output	Ignition switch ON	During voice guide output with the switch pressed	<p>SKIB3609E</p>
11 (O)	Ground	Telephone ON signal	Output	Ignition switch ON	While using hands-free phone system	0 V
					While not using hands-free phone system	5 V

TEL ADAPTER UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

Terminal (Wire color)		Description		Condition	Reference value (Approx.)	
+	-	Signal name	Input/ Output			
12 (W)	14 (GR)	Steering switch signal A	Input	Ignition switch ON	Keep pressing  switch	0 V
					Keep pressing SEEK UP switch	1.25 V
					Keep pressing SEEK DOWN switch	2.5 V
					Except for above	5 V
13 (Y)	14 (GR)	Steering switch signal B	Input	Ignition switch ON	Keep pressing VOL DOWN switch	0 V
					Keep pressing VOL UP switch	1.25 V
					Keep pressing  switch	2.5 V
					Keep pressing SOURCE switch	3.7 V
					Except for above.	5 V
14 (GR)	Ground	Steering switch signal ground	—	Ignition switch ON	—	0 V
17 (W)	19 (GR)	Steering switch signal A	Output	Ignition switch ON	Keep pressing SOURCE switch	0 V
					Keep pressing SEEK UP switch	1.1 V
					Keep pressing VOL UP switch	2.2 V
					Except for above	3.3 V
18 (L)	19 (GR)	Steering switch signal B	Output	Ignition switch ON	Keep pressing SEEK DOWN switch	1.1 V
					Keep pressing VOL DOWN switch	2.2 V
					Except for above	3.3 V
19 (GR)	Ground	Steering switch signal ground	—	Ignition switch ON	—	0 V
21 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
22 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
23 (B)	Ground	Ground	—	Ignition switch ON	—	0 V
24 (B)	Ground	Ground	—	Ignition switch ON	—	0 V


A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

TEL ADAPTER UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
28 (G)	Ground	Vehicle speed signal (2-pulse)	Input	Ignition switch ON	When vehicle speed is ap- prox. 40 km/h (25MPH)	<p>NOTE: The maximum voltage varies de- pending on the specification (destination unit).</p>  <p style="text-align: right; font-size: small;">JSNIA0015GB</p>
29 (W)	Ground	Microphone power supply	Output	Ignition switch ON	—	5 V
33	—	TEL antenna signal	Input	—	Not connected to TEL an- tenna connector	—
34	—	Shield	—	—	—	—
35 (L)	—	AV communication signal (H)	Input/ Output	—	—	—
36 (P)	—	AV communication signal (L)	Input/ Output	—	—	—
37	—	Shield	—	—	—	—


TEL ADAPTER UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

Wiring Diagram - BOSE AUDIO -

INFOID:000000001711784



*: This connector is not shown in "Harness Layout".

2007/07/13

JCNWM0552GI


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

TEL ADAPTER UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]



JCNWM0554GI

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV


TEL ADAPTER UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
35	SHIELD	-
36	R	-
37	LG	-
38	SHIELD	-
39	D	-
40	G	-
41	R	-
45	L	-
46	W	-
47	SHIELD	-
48	V	-

Connector No.	B8
Connector Name	TEL ADAPTER UNIT
Connector Type	TH82FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	BAT
2	SB	ACC
3	W	IGN
4	B	GND
6	SHIELD	SHIELD
7	B	MICROPHONE SIGNAL (+)
8	R	MICROPHONE SIGNAL (-)
9	BR	SOUND SIGNAL (+)
10	Y	SOUND SIGNAL (-)
11	O	TELEPHONE ON SIGNAL
12	W	STEERING SW SIGNAL A

49	W	-
50	SHIELD	-
52	L	-
53	G	-
54	O	-
55	Y	-
56	SHIELD	-
57	L	-
58	W	-
59	B	-
60	SB	-
61	BR	-
62	GR	-
63	W	-
65	SHIELD	-
66	BR	-
67	P	-
68	SHIELD	-
69	R	-
70	W	-
71	W	-
72	Y	-
82	GR	-

13	Y	STEERING SW SIGNAL B
14	GR	STEERING SW SIGNAL GND
17	W	STEERING SW SIGNAL A
18	L	STEERING SW SIGNAL B
19	GR	STEERING SW SIGNAL GND
21	B	GND
22	B	GND
23	B	GND
24	B	GND
26	G	VEHICLE SPEED SIGNAL (2-PULSE)
29	W	MICROPHONE POWER

Connector No.	B2
Connector Name	WIRE TO WIRE
Connector Type	TH24MW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
7	SHIELD	-
8	G	-
9	SHIELD	-
10	G	-
11	R	-
12	SB	-
20	L	-
21	Y	-
22	W	-
23	L	-
24	BR	-

Connector No.	B7
Connector Name	TEL ADAPTER UNIT
Connector Type	TH80FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
35	L	AV COMMUNICATION SIGNAL (R)
36	P	AV COMMUNICATION SIGNAL (L)
37	SHIELD	SHIELD

Connector No.	B19
Connector Name	SATELLITE RADIO TUNER
Connector Type	A18FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	SOUND SIGNAL LH (-)
2	L	SOUND SIGNAL LH (+)
3	G	SOUND SIGNAL RH (-)
4	W	SOUND SIGNAL RH (+)
5	SHIELD	SHIELD
6	SHIELD	SHIELD
8	Y	REQUEST SIGNAL (SAT TO AUDIO)
9	G	COMMUNICATION SIGNAL (SAT-AUDIO)
10	L	COMMUNICATION SIGNAL (AUDIO-SAT)
12	BR	BAT
16	SB	ACC

TEL ADAPTER UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No.	B55
Connector Name	WIRE TO WIRE
Connector Type	NSJ2FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	R	
5	L	

Connector No.	B54
Connector Name	WIRE TO WIRE
Connector Type	NSJ2MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
4	R	
5	L	

Connector No.	B52
Connector Name	WIRE TO WIRE
Connector Type	NSG0MH-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	
2	R	


Connector No.	B51
Connector Name	WIRE TO WIRE
Connector Type	NS04FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	
2	R	

Terminal No.	Color of Wire	Signal Name [Specification]
12	B	GND
13	R	SOUND SIGNAL FRONT SPEAKER RH (-)
14	BR	SOUND SIGNAL WOOFER (-)

Connector No.	B64
Connector Name	BOSE AMP.
Connector Type	SGA12FR-SJA2

Connector No.	B63
Connector Name	WOOFER
Connector Type	RS06FGY-PR




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	SOUND SIGNAL REAR SPEAKER LH (+)
2	GR	SOUND SIGNAL REAR SPEAKER RH (+)
3	Y	SOUND SIGNAL REAR SPEAKER RH (-)
4	B	SOUND SIGNAL FRONT SPEAKER LH (+)
5	P	SOUND SIGNAL FRONT SPEAKER LH (-)
6	BR	SOUND SIGNAL TWEETER LH (+)
7	GR	SOUND SIGNAL TWEETER LH (-)
8	G	SOUND SIGNAL FRONT SPEAKER RH (+)
9	Y	SOUND SIGNAL WOOFER (+)
10	R	SOUND SIGNAL REAR SPEAKER LH (-)
11	W	BAT

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	SOUND SIGNAL WOOFER (-)
2	Y	SOUND SIGNAL WOOFER (+)
3	SHIELD	SHIELD
4	G	WOOFER AMP_ON SIGNAL
5	B	GND
6	SB	BAT

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

JCNWM0556G1


TEL ADAPTER UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No.	B65
Connector Name	BOSE AMP.
Connector Type	SCA19BR-SGA4



Terminal No.	Color of Wire	Signal Name [Specification]
15	V	SOUND SIGNAL CENTER SPEAKER (+)
18	R	SOUND SIGNAL FRONT LH (+)
19	O	SOUND SIGNAL FRONT RH (+)
20	W	SOUND SIGNAL FRONT LH (-)
21	V	SOUND SIGNAL FRONT RH (-)
22	LG	SOUND SIGNAL REAR LH (+)
23	W	SOUND SIGNAL REAR RH (+)
25	G	WOOFER AMP. ON SIGNAL
27	W	SOUND SIGNAL TWEETER RH (+)
28	O	SOUND SIGNAL CENTER SPEAKER (-)
31	L	AMP. ON SIGNAL

Connector No.	B76
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	P	-
3	B	-
4	R	-
5	G	-
6	SB	-
7	O	-
8	V	-
9	GR	-
10	BR	-
11	W	-

32	G	SOUND SIGNAL FRONT LH (-)
33	R	SOUND SIGNAL REAR RH (-)
37	O	SOUND SIGNAL TWEETER RH (+)

Connector No.	B66
Connector Name	WIRE TO WIRE
Connector Type	NS6BFW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
3	R	-

12	O	-
----	---	---

Connector No.	B68
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	L	-
8	R	-

Connector No.	B67
Connector Name	WIRE TO WIRE
Connector Type	NS68MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
3	R	-

Connector No.	B68
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	GR	-
8	Y	-

TEL ADAPTER UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]

BOSE AUDIO

Connector No.	B351	Connector No.	B451	Connector No.	B352	Connector No.	D2
Connector Name	SATELLITE RADIO TUNER	Connector Name	TEL ADAPTER UNIT	Connector Name	SATELLITE RADIO ANTENNA	Connector Name	WIRE TO WIRE
Connector Type	FAKRA JACK	Connector Type	GT16C-1S-7U	Connector Type	GT16C-1FP-7U	Connector Type	NS12FW-CS

Terminal No.	31	Terminal No.	33	Terminal No.	1	Terminal No.	3
Color of Wire	-	Color of Wire	-	Color of Wire	-	Color of Wire	B
Signal Name [Specification]	-	Signal Name [Specification]	TEL ANTENNA SIGNAL SHIELD	Signal Name [Specification]	-	Signal Name [Specification]	P

Terminal No.	2	Terminal No.	1	Terminal No.	2	Terminal No.	3
Color of Wire	B	Color of Wire	1	Color of Wire	2	Color of Wire	L
Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	R

Connector No.	D4	Connector No.	D44	Connector No.	D42	Connector No.	D81
Connector Name	FRONT SPEAKER LH	Connector Name	FRONT SPEAKER RH	Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS	Connector Type	NS12FW-CS	Connector Type	NS10FW-CS	Connector Type	NS12FW-CS

Terminal No.	1	Terminal No.	2	Terminal No.	4	Terminal No.	5
Color of Wire	B	Color of Wire	G	Color of Wire	3	Color of Wire	4
Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	10	Signal Name [Specification]	11

Terminal No.	2	Terminal No.	1	Terminal No.	2	Terminal No.	3
Color of Wire	P	Color of Wire	G	Color of Wire	2	Color of Wire	L
Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	-	Signal Name [Specification]	R

JCNWM0558GI

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

TEL ADAPTER UNIT

BOSE AUDIO

Connector No.	D04
Connector Name	REAR SPEAKER LH
Connector Type	NS2ZFR-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	R	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Type	NS1ZFW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
3	GR	-
8	Y	-

Connector No.	D104
Connector Name	REAR SPEAKER RH
Connector Type	NS2ZFR-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	Y	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
99	SB	-
100	L	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
35	SHIELD	-
36	P	-
37	LG	-
38	SHIELD	-
39	O	-
40	G	-
41	R	-
45	BR	-
46	L	-
47	SHIELD	-
48	Y	-

49	W	-
50	SHIELD	-
52	O	-
53	G	-
54	V	-
55	Y	-
56	SHIELD	-
57	L	-
58	W	-
59	B	-
60	SB	-
61	BR	-
62	GR	-
63	W	-
65	SHIELD	-
66	BR	-
67	P	-
68	SHIELD	-
69	R	-
70	LG	-
71	BR	-
72	O	-
82	GR	-

Connector No.	M12
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
7	SHIELD	-
8	B	-
9	SHIELD	-
10	G	-
11	R	-
12	SB	-
20	L	-
21	Y	-
22	W	-
23	L	-
24	BR	-

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
3	R	-
10	G	-

TEL ADAPTER UNIT

< ECU DIAGNOSIS >

[BOSE AUDIO]


BOSE AUDIO

Connector No.	M22
Connector Name	TWEETER RH
Connector Type	TK22FBR



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	Y	-

Connector No.	M23
Connector Name	WIRE TO WIRE
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
2	SHIELD	-
3	W	-
8	R	-
9	B	-

Connector No.	M33
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK33FGY-IV



Terminal No.	Color of Wire	Signal Name [Specification]
24	BR	-
31	GR	-
32	O	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SB43GFW



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L
30	Y	VEHICLE SPEED (2-PULSE)
31	L	VEHICLE SPEED (8-PULSE)

Connector No.	M46
Connector Name	AUDIO UNIT
Connector Type	TH18FW-CS2



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	AMP ON SIGNAL
2	R	SOUND SIGNAL FRONT LH (+)
3	G	SOUND SIGNAL FRONT LH (-)
4	V	SOUND SIGNAL REAR LH (+)
5	LG	SOUND SIGNAL REAR LH (-)
6	W	STEERING SW SIGNAL A
7	SB	ACC
10	SHIELD	SHIELD
11	O	SOUND SIGNAL FRONT RH (+)
12	W	SOUND SIGNAL FRONT RH (-)
13	L	SOUND SIGNAL REAR RH (+)

14	P	SOUND SIGNAL REAR RH (+)
15	GR	STEERING SW SIGNAL GND
16	O	STEERING SW SIGNAL B
18	L	VEHICLE SPEED SIGNAL (8-PULSE)
19	Y	BAT
20	SHIELD	SHIELD

Connector No.	M47
Connector Name	AUDIO UNIT
Connector Type	TH33FGY-NH



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	AV COMMUNICATION SIGNAL (H)
22	P	AV COMMUNICATION SIGNAL (L)
23	SHIELD	SHIELD
25	SHIELD	SHIELD
26	BR	SOUND SIGNAL (+)
27	Y	SOUND SIGNAL (-)
28	V	TELEPHONE ON SIGNAL

Connector No.	M48
Connector Name	AUDIO UNIT
Connector Type	A12FW



Terminal No.	Color of Wire	Signal Name [Specification]
31	R	SOUND SIGNAL LH (-)
32	L	SOUND SIGNAL LH (+)
33	G	SOUND SIGNAL LH (-)
34	W	SOUND SIGNAL LH (+)
35	SHIELD	SHIELD
36	Y	REQUEST SIGNAL (SAT TO AUDIO)
39	B	COMMUNICATION SIGNAL (SAT-AUDIO)
40	L	COMMUNICATION SIGNAL (AUDIO-SAT)

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

JCNWM0560GI

AUDIO SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO]

SYMPTOM DIAGNOSIS

AUDIO SYSTEM SYMPTOMS

Symptom Table

INFOID:000000001700318

AUDIO SYSTEM

Symptoms	Check items	Possible malfunction location / Action to take
Audio sound is not heard.	No sound from all speakers.	<ul style="list-style-type: none"> Audio unit power supply and ground circuit. Refer to AV-49, "AUDIO UNIT : Diagnosis Procedure". BOSE amp. power supply and ground circuit. Refer to AV-49, "BOSE AMP. : Diagnosis Procedure". Amp. ON signal circuit. Refer to AV-64, "Diagnosis Procedure".
	Sound is not heard from woofer.	<ul style="list-style-type: none"> Sound signal woofer circuit Woofer amp. ON signal circuit. Refer to AV-65, "Diagnosis Procedure".
	Sound is not heard only from the specific places.	Sound signal circuit of malfunctioning system.
Satellite radio is not received.	When "RADIO" switch is pressed, it change to satellite radio mode.	<ul style="list-style-type: none"> Satellite radio sound signal circuit Satellite radio antenna
	When "RADIO" switch is pressed, it does not change to satellite radio mode.	<ul style="list-style-type: none"> Satellite radio tuner power supply and ground circuit. Refer to AV-50, "SATELLITE RADIO TUNER : Diagnosis Procedure". Request signal circuit. Refer to AV-63, "Diagnosis Procedure". Communication circuit between audio unit and satellite radio tuner. Refer to AV-61, "Diagnosis Procedure".

RELATED TO STEERING SWITCH

Symptoms	Possible malfunction location / Action to take
All steering switches are not operated.	Steering switch signal ground circuit. Refer to AV-56, "Diagnosis Procedure" .
Only specified switch cannot be operated.	Steering switch
"SEEK UP", "SEEK DOWN" and "  " switches are not operated.	Steering switch signal A circuit (steering switch to TEL adapter unit). Refer to AV-52, "Diagnosis Procedure" .
"  ", "VOL UP", "VOL DOWN", "SOURCE" switches are not operated.	Steering switch signal B circuit (steering switch to TEL adapter unit). Refer to AV-54, "Diagnosis Procedure" .
"VOL UP", "SEEK UP" and "SOURCE" switches are not operated.	Steering switch signal A circuit (TEL adapter unit to audio unit). Refer to AV-58, "Diagnosis Procedure" .
"VOL DOWN" and "SEEK DOWN" switches are not operated.	Steering switch signal B circuit (TEL adapter unit to audio unit). Refer to AV-59, "Diagnosis Procedure" .

HANS-FREE PHONE SYMPTOMS

Symptom Table

INFOID:000000001713378

RELATED TO HANDS-FREE PHONE

- Check that the cellular phone is corresponding type (Bluetooth® enabled) when the hands-free related malfunction vehicle is in service before performing a diagnosis.
- There is a case that malfunction occurs due to the version change of the phone type, etc. even though it is a corresponding type. Therefore, confirm it by changing the cellular phone to another corresponding type phone, and check that it operates normally. It is necessary to distinguish whether the cause is the vehicle or cellular phone. Check to ensure the customer's phone is supported by checking the phone compatibility for the hands-free system.

Simple check for Bluetooth® communication


If cellular phone and TEL adapter unit cannot be connected with Bluetooth® communication, following procedure allows the technician to judge which device has malfunction.

1. Turn on a cellular phone, not connecting Bluetooth® communication.
2. Start CONSULT-III, then start Windows®.
3. Set CONSULT-III near a cellular phone.
4. When operated Bluetooth® registration by cellular phone, check if CONSULT-III* would be displayed on the device name.
(If other Bluetooth® device is located near cellular phone, a name of the device would be displayed also.)

NOTE:

*:Displayed device name is "NISSAN-*****".

- If no device name is displayed, cellular phone is malfunction. Repair the cellular phone first, then perform diagnosis.
- If CONSULT-III is displayed on device name, cellular phone is normal. Perform diagnosis as per the following table.



Trouble diagnosis chart by symptom

Symptoms	Check items	Possible malfunction location/Action to take
Does not recognize cellular phone connection.	Repeat the registration of cellular phone.	TEL adapter unit
Hands-free phone cannot be established.	<ul style="list-style-type: none"> • Both the reception and the speech cannot be performed. • Audio cannot be operated by steering switch. 	TEL adapter unit power supply and ground circuit. Refer to AV-50, "TEL ADAPTER UNIT : Diagnosis Procedure" .
	<ul style="list-style-type: none"> • Both the reception and the speech cannot be performed. • Audio can be operated by steering switch. 	Telephone ON signal circuit. Refer to AV-67, "Diagnosis Procedure" .
The other party's voice cannot be heard by hands-free phone.	Audio system sound is normal.	Sound signal (telephone voice, telephone guidance) circuit
	Audio system sound does not sound.	Refer to AV-124, "Symptom Table" .
Originating sound is not heard by the other party with hands-free phone communication.	Sound operation function is normal.	TEL adapter unit
	Sound operation function does not work.	Microphone signal circuit. Refer to AV-66, "Diagnosis Procedure" .
When hands-free phone is in use, the information (connection time etc.) is not displayed on the audio screen.	—	AV communication signal (H, L)

RELATED TO STEERING SWITCH

HANS-FREE PHONE SYMPTOMS

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO]

Symptoms	Possible malfunction location / Action to take
Only specified switch cannot be operated.	Steering switch
“SEEK UP”, “SEEK DOWN” and “  ” switches are not operated.	Steering switch signal A (steering switch to TEL adapter unit) circuit. Refer to AV-52, "Diagnosis Procedure" .
“  ”, “VOL UP”, “VOL DOWN” “SOURCE” switches are not operated.	Steering switch signal B (steering switch to TEL adapter unit) circuit. Refer to AV-54, "Component Inspection" .

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO]

NORMAL OPERATING CONDITION

Description

INFOID:000000001700319

RELATED TO AUDIO

- The majority of the audio malfunctions are the result of outside causes (bad CD, electromagnetic interference, etc.). Check the symptoms below to diagnose the malfunction.
- The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check that noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment. Then determine the cause.

NOTE:

- CD-R is not guaranteed to play because they can contain compressed audio (MP3, WMA) or could be incorrectly mastered by the customer on a computer.
- Check that the CDs carry the Compact Disc Logo. If not, the disc is not mastered to the red book Compact Disc Standard and may not play.

Symptoms	Cause and Counter measure
Cannot play	Check that the CD was inserted correctly.
	Check that the CD is scratched or dirty.
	Check that there is condensation inside the player, and if there is, wait until the condensation is gone (about 1 hour) before using the player.
	The player will play correctly after it returns to the normal temperature if there is a temperature increase error.
	Only the music CD files (CD-DA data) will be played if there is a mixture of music CD files (CD-DA data) and MP3/WMA files on a CD.
	Files with extensions other than “.MP3”, “.WMA”, “.mp3”, or “.wma” cannot be played.
	Check that the finalization process, such as session close and disc close, is done for the disc.
	Check that the CD is protected by copyright.
Poor sound quality	Check that the CD is scratched or dirty.
It takes a relatively long time before the music starts playing.	If there are many folder or file levels on the MP3/WMA CD, or if it is a multi session disc, some time may be required before the music starts playing.
The songs do not play back in the desired order.	The playback order is the order in which the files were written by the software, so the files might not play in the desired order.

Noise resulting from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources, is not a malfunction.

NOTE:

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from a time difference between the broadcast waves directly from the station arriving at the antenna and the waves reflected by mountains or buildings.

RELATED TO TELEPHONE

Symptom	Possible cause	Possible solution
The voice on the other side is difficult to be heard. The voice is difficult to reach the other side of the connection.	The interior of the vehicle is too noisy.	Close the windows or have other occupants be quiet.
	The volume of the voice is too low.	Speak louder.
	Pronunciation is unclear.	Speak clearly.

PRECAUTION

PRECAUTIONS

FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003248448

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted.

Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003248449

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PREPARATION

< PREPARATION >


[BOSE AUDIO]

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000001700321

Tool name	Description
<p>Power tool</p>  <p>PBIC0191E</p>	<p>Loosening bolts and nuts</p>

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O


P

ON-VEHICLE REPAIR

AUDIO UNIT

Exploded View

INFOID:000000001724729



1. Audio unit

Removal and Installation

INFOID:000000001700322

REMOVAL

1. Remove cluster lid C and cluster lid D. Refer to [JP-12, "Exploded View"](#).
2. Remove audio unit with bracket.
3. Remove bracket screws, and then remove audio unit.


INSTALLATION

Install in the reverse order of removal.

BOSE AMP.

Exploded View

INFOID:000000001724730



←: Vehicle front

1. BOSE amp.

Removal and Installation

INFOID:000000001700323

REMOVAL

1. Remove luggage floor spacer assembly (FR, RH). Refer to [INT-32. "Removal and Installation"](#).
2. Remove BOSE amp.

INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

TWEETER


< ON-VEHICLE REPAIR >

[BOSE AUDIO]

TWEETER

Exploded View

INFOID:000000001724731



1. Tweeter

Removal and Installation

INFOID:000000001700325

REMOVAL

1. Remove instrument panel. Refer to [IP-13, "Removal and Installation"](#).
2. Remove tweeter from instrument panel.

INSTALLATION

Installation is the reverse order of removal.

CENTER SPEAKER


< ON-VEHICLE REPAIR >

[BOSE AUDIO]

CENTER SPEAKER

Exploded View

INFOID:000000001724732



1. Center speaker

Removal and Installation

INFOID:000000001700326

REMOVAL

1. Remove center speaker grille. Refer to [IP-12, "Exploded View"](#).
2. Remove center speaker.

INSTALLATION

Installation is the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

FRONT SPEAKER


< ON-VEHICLE REPAIR >

[BOSE AUDIO]

FRONT SPEAKER

Exploded View

INFOID:000000001724733



1. Front speaker
2. Bracket

Removal and Installation

INFOID:000000001700327

REMOVAL

1. Remove front door finisher. Refer to [INT-11, "FRONT DOOR FINISHER : Removal and Installation"](#).
2. Remove front door speaker from bracket.

INSTALLATION

Install in the reverse order of removal.

REAR SPEAKER


< ON-VEHICLE REPAIR >

[BOSE AUDIO]

REAR SPEAKER

Exploded View

INFOID:000000001724734



1. Rear speaker

Removal and Installation

INFOID:000000001700329

REMOVAL

1. Remove rear door finisher. Refer to [INT-14. "REAR DOOR FINISHER : Removal and Installation"](#).
2. Remove rear speaker.

INSTALLATION

Installation is the reverse order of removal.


A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

WOOFER

Exploded View

INFOID:000000001724735



- ⇐ Vehicle front
1. Clamp
 2. Woofer

Removal and Installation

INFOID:000000001700331

REMOVAL

1. Remove luggage floor center box. Refer to [INT-32, "Removal and Installation"](#).
2. Remove clamp, and then remove woofer.

INSTALLATION

Install in the reverse order of removal.

SATELLITE RADIO TUNER


< ON-VEHICLE REPAIR >

[BOSE AUDIO]

SATELLITE RADIO TUNER

Exploded View

INFOID:0000000001724736



1. Satellite radio tuner

Removal and Installation

INFOID:0000000001700332

REMOVAL

1. Remove luggage side lower finisher (LH). Refer to [INT-32. "Removal and Installation"](#).
2. Remove satellite radio tuner.

INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

RADIO & SATELLITE RADIO ANTENNA


< ON-VEHICLE REPAIR >

[BOSE AUDIO]

RADIO & SATELLITE RADIO ANTENNA

Exploded View

INFOID:000000001724737



1. Antenna rod

2. Antenna base & satellite radio antenna

Removal and Installation

INFOID:000000001700333

REMOVAL

1. Remove headlining assembly. Refer to [INT-24, "NORMAL ROOF : Removal and Installation"](#) (normal roof models) or [INT-27, "SUNROOF : Removal and Installation"](#) (sunroof models).
2. Remove nuts, and then remove radio & satellite radio antenna.

INSTALLATION

Installation is the reverse order of removal.

CAUTION:

Be careful about tightening torque. Antenna sensitivity becomes poor, and when it is excessive, roof panel may be deformed, when roof antenna mounting nut tightening torque is loose.

STEERING SWITCH

< ON-VEHICLE REPAIR >

[BOSE AUDIO]

STEERING SWITCH

Exploded View

INFOID:000000001724841

Refer to [SR-5, "Exploded View"](#).

Removal and Installation

INFOID:000000001724842

REMOVAL

Refer to [SR-5, "Removal and Installation"](#).

INSTALLATION

Installation is the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O


P

< ON-VEHICLE REPAIR >

MICROPHONE

Exploded View

INFOID:000000001724739



1. Microphone

Removal and Installation

INFOID:000000001700339

REMOVAL

1. Remove map lamp. Refer to [JNL-65. "Removal and Installation"](#).
2. Remove microphone from map lamp.


INSTALLATION

Installation is the reverse order of removal.

TEL ADAPTER UNIT

Exploded View

INFOID:000000001724741



1. TEL adapter unit

Removal and Installation

INFOID:000000001700341

REMOVAL

1. Remove luggage side lower finisher (RH). Refer to [JNT-32, "Removal and Installation"](#).
2. Remove TEL adapter unit.

INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

TEL ANTENNA


< ON-VEHICLE REPAIR >

[BOSE AUDIO]

TEL ANTENNA

Exploded View

INFOID:000000001724740



1. TEL antenna
2. TEL adapter unit

Removal and Installation

INFOID:000000001700340

REMOVAL

1. Remove luggage side upper finisher (RH). Refer to [INT-32. "Removal and Installation"](#).
2. Remove TEL antenna.

