

# SECTION **EXL**

## EXTERIOR LIGHTING SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

### CONTENTS

<b>XENON TYPE</b>	<b>DIAGNOSIS SYSTEM (BCM) .....</b>	<b>18</b>
<b>BASIC INSPECTION .....</b>	<b>COMMON ITEM .....</b>	<b>18</b>
<b>DIAGNOSIS AND REPAIR WORKFLOW .....</b>	COMMON ITEM : CONSULT-III Function (BCM -	
Work Flow .....	COMMON ITEM) .....	18
<b>FUNCTION DIAGNOSIS .....</b>	<b>HEADLAMP .....</b>	<b>18</b>
<b>HEADLAMP SYSTEM .....</b>	HEADLAMP : CONSULT-III Function (BCM -	
System Diagram .....	HEAD LAMP) .....	19
System Description .....	<b>FLASHER .....</b>	<b>20</b>
Component Parts Location .....	FLASHER : CONSULT-III Function (BCM -	
Component Description .....	FLASHER) .....	20
<b>FRONT FOG LAMP SYSTEM .....</b>	<b>DIAGNOSIS SYSTEM (IPDM E/R) .....</b>	<b>22</b>
System Diagram .....	Diagnosis Description .....	22
System Description .....	CONSULT-III Function (IPDM E/R) .....	24
Component Parts Location .....	<b>COMPONENT DIAGNOSIS .....</b>	<b>27</b>
Component Description .....	<b>POWER SUPPLY AND GROUND CIRCUIT ....</b>	<b>27</b>
<b>TURN SIGNAL AND HAZARD WARNING</b>	<b>BCM (BODY CONTROL MODULE) .....</b>	<b>27</b>
<b>LAMP SYSTEM .....</b>	BCM (BODY CONTROL MODULE) : Diagnosis	
System Diagram .....	Procedure .....	27
System Description .....	<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION</b>	
Component Parts Location .....	<b>MODULE ENGINE ROOM) .....</b>	<b>27</b>
Component Description .....	IPDM E/R (INTELLIGENT POWER DISTRIBUTION	
<b>PARKING, LICENSE PLATE AND TAIL</b>	MODULE ENGINE ROOM) : Diagnosis Pro-	
<b>LAMPS SYSTEM .....</b>	cedure .....	27
System Diagram .....	<b>EXTERIOR LAMP FUSE .....</b>	<b>29</b>
System Description .....	Description .....	29
Component Parts Location .....	Diagnosis Procedure .....	29
Component Description .....	<b>HEADLAMP (HI) CIRCUIT .....</b>	<b>30</b>
<b>EXTERIOR LAMP BATTERY SAVER SYS-</b>	Component Function Check .....	30
<b>TEM .....</b>	Diagnosis Procedure .....	30
System Diagram .....	<b>HEADLAMP (LO) CIRCUIT .....</b>	<b>32</b>
System Description .....	Description .....	32
Component Parts Location .....	Component Function Check .....	32
Component Description .....		

EXL

Diagnosis Procedure .....	32	<b>BCM (BODY CONTROL MODULE) .....</b>	<b>73</b>
<b>XENON HEADLAMP .....</b>	<b>34</b>	Reference Value .....	73
Description .....	34	Wiring Diagram - BCM - .....	88
Diagnosis Procedure .....	34	Fail Safe .....	92
<b>FRONT FOG LAMP CIRCUIT .....</b>	<b>36</b>	DTC Inspection Priority Chart .....	93
Component Function Check .....	36	DTC Index .....	93
Diagnosis Procedure .....	36	<b>IPDM E/R (INTELLIGENT POWER DISTRI- BUTION MODULE ENGINE ROOM) .....</b>	<b>95</b>
<b>PARKING LAMP CIRCUIT .....</b>	<b>38</b>	Reference Value .....	95
Component Function Check .....	38	Wiring Diagram - IPDM E/R - .....	100
Diagnosis Procedure .....	38	Fail Safe .....	103
<b>TURN SIGNAL LAMP CIRCUIT .....</b>	<b>40</b>	DTC Index .....	105
Description .....	40	<b>SYMPTOM DIAGNOSIS .....</b>	<b>106</b>
Component Function Check .....	40	<b>EXTERIOR LIGHTING SYSTEM SYMPTOMS .....</b>	<b>106</b>
Diagnosis Procedure .....	40	Symptom Table .....	106
<b>HAZARD SWITCH .....</b>	<b>42</b>	<b>NORMAL OPERATING CONDITION .....</b>	<b>108</b>
Component Function Check .....	42	Description .....	108
Diagnosis Procedure .....	42	<b>BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON .....</b>	<b>109</b>
<b>TAIL LAMP CIRCUIT .....</b>	<b>44</b>	Description .....	109
Component Function Check .....	44	Diagnosis Procedure .....	109
Diagnosis Procedure .....	44	<b>BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON .....</b>	<b>110</b>
<b>LICENSE PLATE LAMP CIRCUIT .....</b>	<b>46</b>	Description .....	110
Component Function Check .....	46	Diagnosis Procedure .....	110
Diagnosis Procedure .....	46	<b>PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON .....</b>	<b>111</b>
<b>HEADLAMP SYSTEM .....</b>	<b>47</b>	Description .....	111
Wiring Diagram - HEADLAMP - .....	47	Diagnosis Procedure .....	111
<b>HEADLAMP AIMING CONTROL SYSTEM (MANUAL) .....</b>	<b>50</b>	<b>BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON .....</b>	<b>112</b>
Description .....	50	Description .....	112
Wiring Diagram - HEADLAMP AIMING CON- TROL SYSTEM (MANUAL) - .....	50	Diagnosis Procedure .....	112
Component Inspection .....	51	<b>PRECAUTION .....</b>	<b>113</b>
<b>FRONT FOG LAMP SYSTEM .....</b>	<b>53</b>	<b>PRECAUTIONS .....</b>	<b>113</b>
Wiring Diagram - FRONT FOG LAMP - .....	53	<b>FOR USA AND CANADA .....</b>	<b>113</b>
<b>TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM .....</b>	<b>56</b>	FOR USA AND CANADA : Precaution for Supple- mental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	113
Wiring Diagram - TURN AND HAZARD WARN- ING LAMPS - .....	56	FOR USA AND CANADA : Precautions For Xenon Headlamp Service .....	113
<b>PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM .....</b>	<b>60</b>	<b>FOR MEXICO .....</b>	<b>113</b>
Wiring Diagram - PARKING, LICENSE PLATE AND TAIL LAMPS - .....	60	FOR MEXICO : Precaution for Supplemental Re- straint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	113
<b>STOP LAMP .....</b>	<b>67</b>	FOR MEXICO : Precautions For Xenon Headlamp Service .....	114
Wiring Diagram - STOP LAMP - .....	67	<b>ON-VEHICLE MAINTENANCE .....</b>	<b>115</b>
<b>BACK-UP LAMP .....</b>	<b>70</b>		
Wiring Diagram - BUCK-UP LAMP - .....	70		
<b>ECU DIAGNOSIS .....</b>	<b>73</b>		

<b>HEADLAMP AIMING ADJUSTMENT</b> .....	115	<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	134	
Description .....	115	Work Flow .....	134	A
Aiming Adjustment Procedure .....	116	<b>FUNCTION DIAGNOSIS</b> .....	136	
<b>FRONT FOG LAMP AIMING ADJUSTMENT</b> ..	118	<b>HEADLAMP SYSTEM</b> .....	136	B
Description .....	118	System Diagram .....	136	
Aiming Adjustment Procedure .....	118	System Description .....	136	
<b>ON-VEHICLE REPAIR</b> .....	120	Component Parts Location .....	137	C
<b>FRONT COMBINATION LAMP</b> .....	120	Component Description .....	137	
Exploded View .....	120	<b>DAYTIME RUNNING LIGHT SYSTEM</b> .....	138	D
Removal and Installation .....	121	System Diagram .....	138	
Replacement .....	121	System Description .....	138	
Disassembly and Assembly .....	121	Component Parts Location .....	139	E
<b>FRONT FOG LAMP</b> .....	123	Component Description .....	139	
Exploded View .....	123	<b>FRONT FOG LAMP SYSTEM</b> .....	141	F
Removal and Installation .....	123	System Diagram .....	141	
Replacement .....	123	System Description .....	141	
<b>LIGHTING &amp; TURN SIGNAL SWITCH</b> .....	124	Component Parts Location .....	142	G
Exploded View .....	124	Component Description .....	142	
Removal and Installation .....	124	<b>TURN SIGNAL AND HAZARD WARNING</b>		
<b>HAZARD SWITCH</b> .....	125	<b>LAMP SYSTEM</b> .....	143	H
Exploded View .....	125	System Diagram .....	143	
Removal and Installation .....	125	System Description .....	143	
<b>HEADLAMP AIMING SWITCH</b> .....	126	Component Parts Location .....	144	I
Exploded View .....	126	Component Description .....	144	
Removal and Installation .....	126	<b>PARKING, LICENSE PLATE AND TAIL</b>		
<b>REAR COMBINATION LAMP</b> .....	127	<b>LAMPS SYSTEM</b> .....	145	J
Exploded View .....	127	System Diagram .....	145	
Removal and Installation .....	127	System Description .....	145	
Replacement .....	128	Component Parts Location .....	146	K
<b>HIGH-MOUNTED STOP LAMP</b> .....	129	Component Description .....	146	
Exploded View .....	129	<b>EXTERIOR LAMP BATTERY SAVER SYS-</b>		
Removal and Installation .....	129	<b>TEM</b> .....	147	EXL
<b>BACK-UP LAMP</b> .....	130	System Diagram .....	147	
Exploded View .....	130	System Description .....	147	
Removal and Installation .....	130	Component Parts Location .....	148	M
Replacement .....	130	Component Description .....	148	
<b>LICENSE PLATE LAMP</b> .....	131	<b>DIAGNOSIS SYSTEM (BCM)</b> .....	149	N
Exploded View .....	131	<b>COMMON ITEM</b> .....	149	
Removal and Installation .....	131	COMMON ITEM : CONSULT-III Function (BCM -		
Replacement .....	131	COMMON ITEM) .....	149	O
<b>SERVICE DATA AND SPECIFICATIONS</b>		<b>HEADLAMP</b> .....	149	
<b>(SDS)</b> .....	133	HEADLAMP : CONSULT-III Function (BCM -		
<b>SERVICE DATA AND SPECIFICATIONS</b>		HEAD LAMP) .....	150	P
<b>(SDS)</b> .....	133	<b>FLASHER</b> .....	151	
Bulb Specifications .....	133	FLASHER : CONSULT-III Function (BCM -		
<b>HALOGEN TYPE</b>		FLASHER) .....	151	
<b>BASIC INSPECTION</b> .....	134	<b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....	153	
		Diagnosis Description .....	153	
		CONSULT-III Function (IPDM E/R) .....	155	

<b>COMPONENT DIAGNOSIS</b> .....	158	Wiring Diagram - DAYTIME RUNNING LIGHT SYSTEM - .....	183
<b>POWER SUPPLY AND GROUND CIRCUIT</b> ..	158	<b>FRONT FOG LAMP SYSTEM</b> .....	190
<b>BCM (BODY CONTROL MODULE)</b> .....	158	Wiring Diagram - FRONT FOG LAMP - .....	190
BCM (BODY CONTROL MODULE) : Diagnosis Procedure .....	158	<b>TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM</b> .....	193
<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</b> .....	158	Wiring Diagram - TURN AND HAZARD WARNING LAMPS - .....	193
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure .....	158	<b>PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM</b> .....	197
<b>EXTERIOR LAMP FUSE</b> .....	160	Wiring Diagram - PARKING, LICENSE PLATE AND TAIL LAMPS - .....	197
Description .....	160	<b>STOP LAMP</b> .....	204
Diagnosis Procedure .....	160	Wiring Diagram - STOP LAMP - .....	204
<b>HEADLAMP (HI) CIRCUIT</b> .....	161	<b>BACK-UP LAMP</b> .....	207
Component Function Check .....	161	Wiring Diagram - BUCK-UP LAMP - .....	207
Diagnosis Procedure .....	161	<b>ECU DIAGNOSIS</b> .....	210
<b>HEADLAMP (LO) CIRCUIT</b> .....	164	<b>BCM (BODY CONTROL MODULE)</b> .....	210
Component Function Check .....	164	Reference Value .....	210
Diagnosis Procedure .....	164	Wiring Diagram - BCM - .....	225
<b>FRONT FOG LAMP CIRCUIT</b> .....	166	Fail Safe .....	229
Component Function Check .....	166	DTC Inspection Priority Chart .....	230
Diagnosis Procedure .....	166	DTC Index .....	230
<b>DAYTIME RUNNING LIGHT RELAY CIRCUIT</b> ..	168	<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</b> .....	232
Component Function Check .....	168	Reference Value .....	232
Diagnosis Procedure .....	168	Wiring Diagram - IPDM E/R - .....	237
Component Inspection .....	169	Fail Safe .....	240
<b>PARKING LAMP CIRCUIT</b> .....	171	DTC Index .....	242
Component Function Check .....	171	<b>SYMPTOM DIAGNOSIS</b> .....	243
Diagnosis Procedure .....	171	<b>EXTERIOR LIGHTING SYSTEM SYMPTOMS</b> .....	243
<b>TURN SIGNAL LAMP CIRCUIT</b> .....	173	Symptom Table .....	243
Description .....	173	<b>BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON</b> .....	245
Component Function Check .....	173	Description .....	245
Diagnosis Procedure .....	173	Diagnosis Procedure .....	245
<b>HAZARD SWITCH</b> .....	175	<b>BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON</b> .....	246
Component Function Check .....	175	Description .....	246
Diagnosis Procedure .....	175	Diagnosis Procedure .....	246
<b>TAIL LAMP CIRCUIT</b> .....	177	<b>PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON</b> .....	247
Component Function Check .....	177	Description .....	247
Diagnosis Procedure .....	177	Diagnosis Procedure .....	247
<b>LICENSE PLATE LAMP CIRCUIT</b> .....	179	<b>BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON</b> .....	248
Component Function Check .....	179	Description .....	248
Diagnosis Procedure .....	179		
<b>HEADLAMP SYSTEM</b> .....	180		
Wiring Diagram - HEADLAMP - .....	180		
<b>DAYTIME RUNNING LIGHT SYSTEM</b> .....	183		

Diagnosis Procedure .....	248	Replacement .....	257	
<b>PRECAUTION .....</b>	<b>249</b>	<b>LIGHTING &amp; TURN SIGNAL SWITCH .....</b>	<b>258</b>	A
<b>PRECAUTIONS .....</b>	<b>249</b>	Exploded View .....	258	
<b>FOR USA AND CANADA .....</b>	<b>249</b>	Removal and Installation .....	258	B
FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	249	<b>HAZARD SWITCH .....</b>	<b>259</b>	
<b>FOR MEXICO .....</b>	<b>249</b>	Exploded View .....	259	C
FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	249	Removal and Installation .....	259	
<b>ON-VEHICLE MAINTENANCE .....</b>	<b>250</b>	<b>REAR COMBINATION LAMP .....</b>	<b>260</b>	D
<b>HEADLAMP AIMING ADJUSTMENT .....</b>	<b>250</b>	Exploded View .....	260	
Description .....	250	Removal and Installation .....	260	D
Aiming Adjustment Procedure .....	251	Replacement .....	261	
<b>FRONT FOG LAMP AIMING ADJUSTMENT ..</b>	<b>253</b>	<b>HIGH-MOUNTED STOP LAMP .....</b>	<b>262</b>	E
Description .....	253	Exploded View .....	262	
Aiming Adjustment Procedure .....	253	Removal and Installation .....	262	
<b>ON-VEHICLE REPAIR .....</b>	<b>255</b>	<b>BACK-UP LAMP .....</b>	<b>263</b>	F
<b>FRONT COMBINATION LAMP .....</b>	<b>255</b>	Exploded View .....	263	
Exploded View .....	255	Removal and Installation .....	263	G
Removal and Installation .....	255	Replacement .....	263	
Replacement .....	256	<b>LICENSE PLATE LAMP .....</b>	<b>264</b>	
Disassembly and Assembly .....	256	Exploded View .....	264	H
<b>FRONT FOG LAMP .....</b>	<b>257</b>	Removal and Installation .....	264	
Exploded View .....	257	Replacement .....	264	
Removal and Installation .....	257	<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	<b>266</b>	I
		<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	<b>266</b>	J
		Bulb Specifications .....	266	

**EXL**


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000001716312

#### OVERALL SEQUENCE



JPLIA0313GB

#### DETAILED FLOW

##### 1. INTERVIEW FOR MALFUNCTION

Interview the symptom to the customer.

# DIAGNOSIS AND REPAIR WORKFLOW

[XENON TYPE]

< BASIC INSPECTION >

>> GO TO 2.

## 2. SYMPTOM CHECK

Check the symptom from the customer's information.

>> GO TO 3.

## 3. BASIC INSPECTION

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4.

## 4. SELF-DIAGNOSIS WITH CONSULT-III

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

## 5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

## 6. FAIL-SAFE ACTIVATION CHECK

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

## 7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

## 8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

## 9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10.

## 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 11.

## 11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N


O

P

## FUNCTION DIAGNOSIS

### HEADLAMP SYSTEM

#### System Diagram



#### System Description

INFOID:000000001720619

##### OUTLINE

Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

##### HEADLAMP (LO) OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R with CAN communication according to the headlamp (LO) ON condition.

Headlamp (LO) ON condition

- Lighting switch 2ND
- IPDM E/R turns the integrated headlamp low relay ON, and turns the headlamp ON according to the low beam request signal.

##### HEADLAMP (HI) OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter with CAN communication according to the headlamp (HI) ON condition.

Headlamp (HI) ON condition

- Lighting switch HI with the lighting switch 2ND
- Lighting switch PASS
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the integrated headlamp high relay ON, and turns the headlamp ON according to the high beam request signal.


# HEADLAMP SYSTEM

< FUNCTION DIAGNOSIS >

[XENON TYPE]

## Component Parts Location

INFOID:000000001720620



- |                       |                             |                             |
|-----------------------|-----------------------------|-----------------------------|
| 1. Headlamp           | 2. Combination switch       | 3. BCM                      |
| 4. IPDM E/R           | 5. High beam indicator lamp |                             |
| A. Over the glove box | B. Engine room (LH)         | C. On the combination meter |

## Component Description

INFOID:000000001720621

EXL

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges that the headlamp is turned ON according to the vehicle condition.</li> <li>- Requests the headlamp relay (HI/LO) ON to IPDM E/R (with CAN communication).</li> <li>- Requests the high beam indicator lamp ON to the combination meter (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay, and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .
Combination meter (High beam indicator lamp)	Turns the high beam indicator lamp ON according to the request from BCM (with CAN communication).
Front combination lamp assembly	<ul style="list-style-type: none"> <li>• HID control unit</li> <li>• Xenon bulb</li> </ul> Refer to <a href="#">EXL-34, "Description"</a> .

M

N


O

P

## FRONT FOG LAMP SYSTEM

### System Diagram

INFOID:000000001716335



### System Description

INFOID:000000001716336

#### OUTLINE

Front fog lamp is controlled by combination switch reading function and front fog lamp control function of BCM, and relay control function of IPDM E/R.

#### FRONT FOG LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front fog light request signal to IPDM E/R with CAN communication according to the front fog lamp ON condition.

Front fog lamp ON condition

- Front fog lamp switch ON with headlamp ON (except for the high beam ON)
- IPDM E/R turns the integrated front fog lamp relay ON, and turns the front fog lamp ON according to the front fog light request signal.


# FRONT FOG LAMP SYSTEM

< FUNCTION DIAGNOSIS >

[XENON TYPE]

## Component Parts Location

INFOID:000000001716337



1. Front fog lamp

4. IPDM E/R

A. Over the glove box

2. Combination switch

B. Engine room (LH)

3. BCM

## Component Description

INFOID:000000001716338

EXL

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges the front fog lamp ON/OFF status according to the vehicle condition.</li> <li>- Requests the front fog lamp relay ON to IPDM E/R (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .

M

N

O

P

A

B

C

D

E

F

G

H

I

J

K


# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< FUNCTION DIAGNOSIS >

[XENON TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

### System Diagram



### System Description

INFOID:000000001716340

#### OUTLINE

Turn signal lamp and the hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

#### TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the ignition switch is turned ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

#### HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuit when the hazard switch is turned ON. BCM blinks the hazard warning lamp.

#### TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL SOUND OPERATION

- BCM transmits the turn indicator signal to the combination meter with CAN communication while the turn signal lamp and the hazard warning lamp are operating.
- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn indicator signal.

#### HIGH FLASHER OPERATION (FAIL-SAFE)

- BCM detects the turn signal lamp circuit status by the terminal current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while operating the hazard warning lamp.


# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< FUNCTION DIAGNOSIS >

[XENON TYPE]

## Component Parts Location

INFOID:000000001716341



- |                          |                             |                               |
|--------------------------|-----------------------------|-------------------------------|
| 1. Hazard switch         | 2. Front turn signal lamp   | 3. Combination switch         |
| 4. Rear turn signal lamp | 5. BCM                      | 6. Turn signal indicator lamp |
| A. Over the glove box    | B. On the combination meter |                               |

## Component Description

INFOID:000000001716342

EXL

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges the blinks of the turn signal lamp and the hazard warning lamp from each switch status. The applicable turn signal lamp blinks.</li> <li>• Requests the turn signal indicator lamp blink to the combination meter (with CAN communication).</li> </ul>
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .
Hazard switch	Inputs the hazard switch ON/OFF signal to BCM.
Combination meter (Turn signal indicator lamp & buzzer)	Blinks the turn signal indicator lamp and outputs the turn signal operating sound with integrated buzzer according to the request from BCM (with CAN communication).


# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< FUNCTION DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

### System Diagram



### System Description

INFOID:000000001722046

#### OUTLINE

Parking\*, license plate and tail\* lamps are controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

\*: Illuminated as side maker lamps too.

#### PARKING, LICENSE PLATE AND TAIL LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter with CAN communication according to the ON/OFF condition of the parking, license plate and tail lamps.

Parking, license plate and tail lamps ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- IPDM E/R turns the integrated tail lamp relay ON and turns the parking lamp, the license plate and tail lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.


# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< FUNCTION DIAGNOSIS >

[XENON TYPE]

## Component Parts Location

INFOID:000000001722047



- |                                    |                       |                                 |
|------------------------------------|-----------------------|---------------------------------|
| 1. Parking lamp (Side marker lamp) | 2. Combination switch | 3. Tail lamp (Side marker lamp) |
| 4. License plate lamp              | 5. BCM                | 6. IPDM E/R                     |
| 7. Tail lamp indicator lamp        |                       |                                 |
| A. Over the glove box              | B. Engine room (LH)   | C. On the combination meter     |

## Component Description

INFOID:000000001722048

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges the ON/OFF status of the parking, license plate and tail lamps according to the vehicle condition.</li> <li>- Requests the tail lamp relay ON to IPDM E/R (with CAN communication).</li> <li>- Requests the tail lamp indicator lamp ON to the combination meter (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .
Combination meter (Tail lamp indicator lamp)	Turns the tail lamp indicator lamp ON according to the request from BCM (with CAN communication).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P


# EXTERIOR LAMP BATTERY SAVER SYSTEM

< FUNCTION DIAGNOSIS >

[XENON TYPE]

## EXTERIOR LAMP BATTERY SAVER SYSTEM

### System Diagram



### System Description

INFOID:000000001722577

#### OUTLINE

- Exterior lamp battery saver system is controlled by each function of BCM and IPDM E/R.

#### Control by BCM

- Combination switch reading function
- Headlamp control function
- Exterior lamp battery saver function

#### Control by IPDM E/R

- Relay control function
  - BCM turns the exterior lamp\* OFF after a period of time to prevent the battery from over-discharge when the ignition switch is turned OFF with the exterior lamp ON.
- \*: Headlamp (LO/HI), parking lamp, tail lamp, license plate lamp and front fog lamp

#### EXTERIOR LAMP BATTERY SAVER ACTIVATION

BCM activates the timer and turns the exterior lamp OFF 5 minutes after the ignition switch is turned from ON → OFF with the exterior lamps ON.

#### NOTE:

- Headlamp control function turns the exterior lamps ON normally when the ignition switch is turned ACC or the engine started (both before and after the exterior lamp battery saver is turned OFF).
- The timer starts at the time that the lighting switch is turned from OFF → 1ST or 2ND with the exterior lamp OFF.


# EXTERIOR LAMP BATTERY SAVER SYSTEM

< FUNCTION DIAGNOSIS >

[XENON TYPE]

## Component Parts Location

INFOID:000000001722570



1. Combination switch

A. Over the glove box

2. BCM

B. Engine room (LH)

3. IPDM E/R

## Component Description

INFOID:000000001722571

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Activates the battery saver to turn the exterior lamps OFF according to the vehicle condition.</li> <li>- Requests each relay OFF to IPDM E/R (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[XENON TYPE]

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000003049960

#### APPLICATION ITEM

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

Diagnosis mode	Function description
ECU Identification	BCM part number is displayed.
Self-Diagnostic Result	Displays the diagnosis results judged by BCM. Refer to <a href="#">EXL-93, "DTC Index"</a> .
Data Monitor	BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Work Support	Changes the setting for each system function.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.

#### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	CONSULT-III sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp control	INT LAMP	×	×	×
Remote keyless entry system	MULTI REMOTE ENT	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER		×	×
Air conditioner	AIR CONDITONER		×	
Intelligent Key system	INTELLIGENT KEY		×	
Combination switch	COMB SW		×	
—	BCM	×		
Immobilizer	IMMU		×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Back door open	TRUNK		×	×
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR	×	×	×
Signal buffer system	SIGNAL BUFFER		×	×
—	FUEL LID*			
TPMS	TPMS (AIR PRESSURE MONITOR)	×	×	×
Panic alarm system	PANIC ALARM			×

\*: This item is displayed, but is not function.

### HEADLAMP

# DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[XENON TYPE]

## HEADLAMP : CONSULT-III Function (BCM - HEAD LAMP)

INFOID:000000001716356

### WORK SUPPORT

Service item	Setting item	Setting
BATTERY SAVER SET	On*	With the exterior lamp battery saver function
	Off	Without the exterior lamp battery saver function
ILL DELAY SET	MODE 1	<b>NOTE:</b> The item is indicated, but not operate
	MODE 2	
	MODE 3	
	MODE 4	
	MODE 5	
	MODE 6	
	MODE 7	
	MODE 8	

\*: Initial setting

### DATA MONITOR

Monitor item [Unit]	Description
IGN ON SW [On/Off]	Ignition switch (ON) status judged from IGN signal (ignition power supply)
ACC SW [On/Off]	Ignition switch (ACC) status judged from ACC signal (ACC power supply)
HI BEAM SW [On/Off]	Each switch status that BCM judges from the combination switch reading function
HEAD LAMP SW1 [On/Off]	
HEAD LAMP SW2 [On/Off]	
LIGHT SW 1ST [On/Off]	
PASSING SW [On/Off]	
FR FOG SW [On/Off]	
AUTO LIGHT SW [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored
RR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch RH
DOOR SW- RL [On/Off]	The switch status input from rear door switch LH
BACK DOOR SW [On/Off]	The switch status input from back door switch

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[XENON TYPE]

Monitor item [Unit]	Description
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
ENGINE RUNNING [On/Off]	The engine status received from ECM with CAN communication
PKB SW [On/Off]	The parking brake switch status received from combination meter with CAN communication
CARGO LAMP SW [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored
OPTICAL SENSOR [V]	

## ACTIVE TEST

Test item	Operation	Description
TAIL LAMP	On	Transmits the position light request signal to IPDM E/R with CAN communication to turn the tail lamp ON.
	Off	Stops the tail lamp request signal transmission.
HEAD LAMP	Hi	Transmits the high beam request signal with CAN communication to turn the headlamp (HI).
	Lo	Transmits the low beam request signal with CAN communication to turn the headlamp (LO).
	Off	Stops the high & low beam request signal transmission.
FR FOG LAMP	On	Transmits the front fog lights request signal to IPDM E/R with CAN communication to turn the front fog lamp ON.
	Off	Stops the front fog lights request signal transmission.
DAYTIME RUNNING LIGHT	On	<b>NOTE:</b> The item indicated, but not operate
	Off	

## FLASHER

### FLASHER : CONSULT-III Function (BCM - FLASHER)

INFOID:000000001716357

## DATA MONITOR

Monitor item [Unit]	Description
IGN ON SW [On/Off]	Ignition switch (ON) status judged from IGN signal (ignition power supply)
HAZARD SW [On/Off]	The switch status input from the hazard switch
TURN SIGNAL R [On/Off]	Each switch condition that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
BRAKE SW [On/Off]	The switch status input from the stop lamp switch

## ACTIVE TEST

# DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[XENON TYPE]

Test item	Operation	Description
FLASHER	RH	Outputs the voltage to turn the right side turn signal lamps ON.
	LH	Outputs the voltage to turn the left side turn signal lamps ON.
	Off	Stops the voltage to turn the turn signal lamps OFF.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

## DIAGNOSIS SYSTEM (IPDM E/R)

### Diagnosis Description

INFOID:000000003049963

#### Auto active test

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp
- Rear window defogger
- Front wiper (LO, HI)
- Parking lamps
- License plate lamps
- Tail lamps
- Front fog lamps
- Headlamps (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan (LO, MID, HI)

##### Operation procedure

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)

**NOTE:**

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.

**CAUTION:**

**Close passenger door.**

4. Turn the ignition switch ON within 10 seconds. Then the horn sounds once and the auto active test starts.

**NOTE:**

Only a vehicle with the vehicle security system, the horn sounds.

5. The oil pressure warning lamp starts blinking when the auto active test starts.
6. After a series of the following operations is repeated 3 times, auto active test is completed.

**NOTE:**


When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.

**CAUTION:**

- **If auto active test mode cannot be actuated, check door switch system.**
- **Never start the engine.**

##### Inspection in auto active test mode

When auto active test mode is actuated, the following 6 steps are repeated 3 times.



# DIAGNOSIS SYSTEM (IPDM E/R)

< FUNCTION DIAGNOSIS >


[XENON TYPE]

Operation sequence	Inspection location	Operation
A	Oil pressure warning lamp	Blinks continuously during operation of auto active test.
1	Rear window defogger	10 seconds
2	Front wiper	LO for 5 seconds → HI for 5 seconds
3	<ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• License plate lamps</li> <li>• Tail lamps</li> <li>• Front fog lamps</li> <li>• Headlamps HI (daytime running light operation)*</li> </ul>	10 seconds
4	Headlamps	LO ↔ HI 5 times
5	A/C compressor (magnet clutch)	ON ↔ OFF 5 times
6	Cooling fan	LO for 5 seconds → MID for 3 seconds → HI for 2 seconds

**NOTE:**

\*: With daytime running light system

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents		Possible cause
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES	BCM signal input circuit
		NO	<ul style="list-style-type: none"> <li>• Rear window defogger</li> <li>• Rear window defogger ground circuit</li> <li>• Harness or connector between IPDM E/R and rear window defogger</li> <li>• IPDM E/R</li> </ul>
Any of the following components do not operate <ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• License plate lamps</li> <li>• Tail lamps</li> <li>• Front fog lamps</li> <li>• Headlamps (HI, LO)</li> <li>• Front wiper (HI, LO)</li> </ul>	Perform auto active test. Does the applicable system operate?	YES	BCM signal input circuit
		NO	<ul style="list-style-type: none"> <li>• Lamp or motor</li> <li>• Lamp or motor ground circuit</li> <li>• Harness or connector between IPDM E/R and applicable system</li> <li>• IPDM E/R</li> </ul>

# DIAGNOSIS SYSTEM (IPDM E/R)

< FUNCTION DIAGNOSIS >

[XENON TYPE]

Symptom	Inspection contents	Possible cause
Headlamps HI (daytime running light operation) do not operate	Perform auto active test. Do headlamps HI (daytime running light operation) operate?	YES <ul style="list-style-type: none"> <li>• CAN communication signal between ECM and BCM</li> <li>• CAN communication signal between combination meter and BCM</li> <li>• BCM signal input circuit</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Daytime running light relay power supply circuit</li> <li>• Harness or connector between IPDM E/R and daytime running light relay</li> <li>• Daytime running light relay</li> </ul>
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES <ul style="list-style-type: none"> <li>• BCM signal input circuit</li> <li>• CAN communication signal between BCM and ECM</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Magnet clutch</li> <li>• Harness or connector between IPDM E/R and magnet clutch</li> <li>• IPDM E/R</li> </ul>
Oil pressure warning lamp does not operate	Perform auto active test. Does the oil pressure warning lamp blink?	YES <ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and oil pressure switch</li> <li>• Oil pressure switch</li> <li>• IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• CAN communication signal between IPDM E/R and BCM</li> <li>• CAN communication signal between BCM and combination meter</li> <li>• Combination meter</li> </ul>
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES <ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>• Cooling fan motor-2 power supply circuit</li> <li>• Cooling fan motor-1 ground circuit</li> <li>• Cooling fan relay-4 or cooling fan relay-5 power supply circuit</li> <li>• Cooling fan relay-5 ground circuit</li> <li>• Harness or connector between IPDM E/R and cooling fan motor</li> <li>• Harness or connector between IPDM E/R, and cooling fan relay-4 or cooling fan relay-5</li> <li>• Harness or connector between cooling fan motor-2, and cooling fan relay-4 or cooling fan relay-5</li> <li>• Cooling fan relay-4 or cooling fan relay-5</li> <li>• Cooling fan motor</li> <li>• IPDM E/R</li> </ul>

## CONSULT-III Function (IPDM E/R)

INFOID:000000003049964

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.

# DIAGNOSIS SYSTEM (IPDM E/R)

[XENON TYPE]

< FUNCTION DIAGNOSIS >

Diagnosis mode	Description
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

## SELF DIAGNOSTIC

Refer to [EXL-105. "DTC Index"](#).

## DATA MONITOR

Monitor item

Monitor Item [Unit]	MAIN SIGNALS	Description
MOTOR FAN REQ [1 - 4]	×	Displays the value of the cooling fan speed signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication. <b>NOTE:</b> This item is monitored only the vehicle with front fog lamp system.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper auto stop signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
ST RLY REQ [Off/On]		Displays the status of the starter request signal.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
RR DEF REQ [Off/On]	×	Displays the status of the rear defogger request signal received from BCM via CAN communication.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
DTRL REQ [Off/On]		Displays the status of the daytime running light request signal received from BCM via CAN communication. <b>NOTE:</b> This item is monitored only the vehicle with daytime running light system.
HOOD SW [Off/On]		Displays the status of the hood switch judged by IPDM E/R. <b>NOTE:</b> This item is monitored only the vehicle for Mexico.
THFT HRN REQ [Off/On]		Displays the status of the horn request signal by vehicle security system or panic alarm system received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn request signal by key fob LOCK operation received from BCM via CAN communication.

## ACTIVE TEST

Test item

## DIAGNOSIS SYSTEM (IPDM E/R)

< FUNCTION DIAGNOSIS >

[XENON TYPE]

Test item	Operation	Description
REAR DEFOGGER	Off	OFF
	On	Operates the rear window defogger relay.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.
MOTOR FAN	1	OFF
	2	Operates the cooling fan relay (LO operation).
	3	Operates the cooling fan relay (MID operation).
	4	Operates the cooling fan relay (HI operation).
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay and the daytime running light relay. <b>NOTE:</b> Daytime running light relay is with daytime running light system only.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 4 seconds intervals.
	Fog	Operates the front fog lamp relay. <b>NOTE:</b> This item can test only the vehicle with front fog lamp system.
HORN	On	Operates horn relay for 20 ms.

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## COMPONENT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT

#### BCM (BODY CONTROL MODULE)

#### BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000003049967

#### 1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not fusing.

Signal name	Fuses and fusible link No.
Battery power supply	10
	J
ACC power supply	20
Ignition power supply	1

#### Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

#### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		(-)	Ignition switch position		
(+)	BCM		OFF	ACC	ON
Connector	Terminal	Ground			
M67	70		Battery voltage	Battery voltage	Battery voltage
	57				
M65	11		Approx. 0 V	Battery voltage	Battery voltage
	38	Approx. 0 V	Approx. 0 V	Battery voltage	

#### Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

#### 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M67	67		Existed

#### Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

#### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

#### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Di-

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[XENON TYPE]

INFOID:000000003049968

## agnosis Procedure

### 1.CHECK FUSIBLE LINK

Check that the following IPDM E/R fusible link is not blown.

Signal name	Fusible link No.
Battery power supply	C
	E
	K

Is the fusible link fusing?

- YES >> Replace the blown fusible link after repairing the affected circuit if a fusible link is blown.  
NO >> GO TO 2.

### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connectors.
3. Check voltage between IPDM E/R harness connectors and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
IPDM E/R		Battery voltage
Connector	Terminal	
E9	1	
	2	
E10	6	

Is the measurement value normal?

- YES >> GO TO 3.  
NO >> Repair harness or connector.

### 3.CHECK GROUND CIRCUIT

Check continuity between IPDM E/R harness connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E11	11		Exist
E13	25		

Does continuity exist?

- YES >> INSPECTION END  
NO >> Repair harness or connector.

# EXTERIOR LAMP FUSE

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## EXTERIOR LAMP FUSE

### Description

INFOID:000000001716387

#### Fuse list

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	#44	10 A
Headlamp HI (RH)	IPDM E/R	#43	10 A
Headlamp LO (LH)	IPDM E/R	#49	15 A
Headlamp LO (RH)	IPDM E/R	#50	15 A
Front fog lamp	IPDM E/R	#65	15 A
Parking lamp	IPDM E/R	#46	10 A
<ul style="list-style-type: none"><li>Tail lamp</li><li>License plate lamp</li><li>Each illumination</li></ul>	IPDM E/R	#45	10 A
Stop lamp	FUSE BLOCK (J/B)	#11	10 A
Back-up lamp	IPDM E/R	#60	10 A

### Diagnosis Procedure

INFOID:000000001716388

#### 1. CHECK FUSE

Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	#44	10 A
Headlamp HI (RH)	IPDM E/R	#43	10 A
Headlamp LO (LH)	IPDM E/R	#49	15 A
Headlamp LO (RH)	IPDM E/R	#50	15 A
Front fog lamp	IPDM E/R	#65	15 A
Parking lamp	IPDM E/R	#46	10 A
<ul style="list-style-type: none"><li>Tail lamp</li><li>License plate lamp</li><li>Each illumination</li></ul>	IPDM E/R	#45	10 A
Stop lamp	FUSE BLOCK (J/B)	#11	10 A
Back-up lamp	IPDM E/R	#60	10 A

#### Is the fuse fusing?

- YES >> Repair the applicable circuit. And then replace the fuse.  
NO >> The fuse is normal.

# HEADLAMP (HI) CIRCUIT

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## HEADLAMP (HI) CIRCUIT

### Component Function Check

INFOID:000000001720622

#### 1. CHECK HEADLAMP (HI) OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the headlamp switches to the high beam.

##### Ⓟ CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp (HI) is turned ON.

**Hi** : Headlamp (HI) ON

**Off** : Headlamp (HI) OFF

##### NOTE:

ON/OFF is repeated 1 second each.

##### Is the headlamp (HI) turned ON?

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-30, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001720623

#### 1. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

##### Ⓟ CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the headlamp high connector.
3. Turn the ignition switch ON.
4. Select "EXTERNAL LAMP" of IPDM E/R active test item.
5. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals			Condition	Voltage (Approx.)
(+)		(-)		
IPDM E/R			External lamp	Battery voltage
Connector	Terminal			
RH	E12	22	Hi	0 V
LH		21	Off	

##### Is the measurement value normal?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK HEADLAMP (HI) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the headlamp high harness connector.

IPDM E/R			Headlamp high		Continuity
Connector	Terminal		Connector	Terminal	
RH	E12	22	E75	1	Existed
LH		21	E72	1	

##### Does continuity exist?

YES >> GO TO 5.

# HEADLAMP (HI) CIRCUIT

[XENON TYPE]

## < COMPONENT DIAGNOSIS >

NO >> Repair the harnesses or connectors.

### 3.CHECK HEADLAMP (HI) FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	#44	10 A
Headlamp HI (RH)	IPDM E/R	#43	10 A

#### Is the fuse fusing?

YES >> GO TO 4.

NO >> Replace IPDM E/R.

### 4.CHECK HEAD LAMP HIGH SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between the IPDM E/R harness connector terminal and the ground.

IPDM E/R			Ground	Continuity
Connector	Terminal			
RH	E12	22		Not existed
LH		21		

#### Does continuity exist?

YES >> Repair the harnesses or connectors. And then replace the fuse.

NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

### 5.CHECK HEAD LAMP (HI) GROUND OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the headlamp high connector.
3. Check continuity between the headlamp high harness connector and the ground.

Headlamp high			Ground	Continuity
Connector	Terminal			
RH	E75	2		Existed
LH	E72	2		

#### Does continuity exist?

YES >> Replace the headlamp (HI) bulb. (Bulb socket is abnormally.)

NO >> Repair the harnesses or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HEADLAMP (LO) CIRCUIT

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## HEADLAMP (LO) CIRCUIT

### Description

INFOID:000000001720624

Headlamp (LO) circuit is connected to HID control unit integrated in the headlamp. Headlamp (LO) circuit turns xenon headlamp ON.

For the details of HID control unit and the xenon headlamp, refer to [EXL-34, "Description"](#).

### Component Function Check

INFOID:000000001720625

#### 1. CHECK HEADLAMP (LO) OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the headlamp is turned ON.

##### Ⓟ CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp (LO) is turned ON.

**Lo** : Headlamp (LO) ON

**Off** : Headlamp (LO) OFF

Is the headlamp (LO) turned ON?

YES >> Headlamp (LO) is normal.

NO >> Refer to [EXL-32, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001720626

#### 1. CHECK HEADLAMP (LO) OUTPUT VOLTAGE

##### Ⓟ CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the headlamp low connector.
3. Turn the ignition switch ON.
4. Select "EXTERNAL LAMP" of IPDM E/R active test item.
5. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals			Test item	Voltage (Approx.)
(+)	(-)			
IPDM E/R			EXTERNAL LAMP	Battery voltage
Connector	Terminal			
RH	E12	20	Lo	0 V
LH		18	Off	

Is the measurement value normal?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK HEADLAMP (LO) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the headlamp low harness connector.

IPDM E/R		Headlamp low		Continuity
Connector	Terminal	Connector	Terminal	

# HEADLAMP (LO) CIRCUIT

[XENON TYPE]

## < COMPONENT DIAGNOSIS >

RH	E12	20	E74	1	Existed
LH		18	E71	1	

### Does continuity exist?

YES >> GO TO 5.

NO >> Repair the harnesses or connectors.

### 3.CHECK HEADLAMP (LO) FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp LO (LH)	IPDM E/R	#49	15 A
Headlamp LO (RH)	IPDM E/R	#50	15 A

### Is the fuse fusing?

YES >> GO TO 4.

NO >> Replace IPDM E/R.

### 4.CHECK HEADLAMP (LO) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E12	20	Not existed
LH		18	

### Does continuity exist?

YES >> Repair the harnesses or connectors. And then replace the fuse.

NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

### 5.CHECK HEADLAMP (LO) GROUND OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the headlamp low connector.
3. Check continuity between the headlamp low harness connector and the ground.

Headlamp low			Ground	Continuity
Connector		Terminal		
RH	E74	2	Existed	
LH	E71	2		

### Does continuity exist?

YES >> Perform the xenon headlamp diagnosis. Refer to [EXL-34, "Description"](#).

NO >> Repair the harnesses or connectors.

## XENON HEADLAMP

### Description

INFOID:000000001838119

#### OUTLINE


- The lamp light source is by the arch discharge by applying high voltage into the xenon gas-filled bulb instead of the halogen bulb filament.
- Sight becomes more natural and brighter because the amount of light are gained adequately and the color of light is sunshine-like white.
- The xenon bulb drops the amount of light, repeats blinking, and illuminates in red if the bulb reaches the service life.

#### ILLUMINATION PRINCIPLE

1. Discharging starts in high voltage pulse between bulb electrodes.
2. Xenon gas is activated by current between electrodes. Pale light is emitted.
3. The luminous tube (bulb) temperature elevates. Evaporated halide is activated by discharge. The color of light changes into white.

#### NOTE:

- Brightness and the color of light may change slightly immediately after the headlamp turned ON until the xenon bulb becomes stable. This is not malfunction.
- Illumination time lag may occur between right and left. This is not malfunction.



#### PRECAUTIONS FOR TROUBLE DIAGNOSIS

Representative malfunction examples are; "Light does not turn ON", "Light blinks", and "Brightness is inadequate." The cause often be the xenon bulb. Such malfunctions, however, are occurred occasionally by HID control unit malfunction or lamp case malfunction. Specify the malfunctioning part with diagnosis procedure.

#### WARNING:

- **Never touch the harness, HID control unit, the inside and metal part of lamp when turning the headlamp ON or operating the lighting switch.**
- **Never work with wet hands.**

#### CAUTION:

- **Never perform HID control unit circuit diagnosis with a circuit tester or an equivalent.**
- **Temporarily install the headlamps on the vehicle. Connect the battery to the connector (vehicle side) when checking ON/OFF status.**
- **Disconnect the battery negative terminal before disconnecting the lamp socket connector or the harness connector.**
- **Check for fusing of the fusible link(s), open around connector, short, disconnection if the symptom is caused by electric error.**

#### NOTE:

- Turn the switch OFF once before turning ON, if the ON/OFF is inoperative.
- The xenon bulb drops the amount of light, repeats blinking, and illuminates in red if the bulb reaches the service life.

### Diagnosis Procedure

INFOID:000000001838120

#### 1. CHECK XENON BULB

Install the normal bulb to the applicable headlamp. Check that the lighting switch is turned ON.

Is the headlamp turned ON?

- YES >> Replace the xenon bulb.
- NO >> GO TO 2.

#### 2. CHECK HID CONTROL UNIT

Install the normal HID control unit to the applicable headlamp. Check that the lighting switch is turned ON.

Is the headlamp turned ON?

# XENON HEADLAMP

< COMPONENT DIAGNOSIS >

[XENON TYPE]

YES >> Replace HID control unit.

NO >> Xenon headlamp is normal. Check the headlamp control system.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# FRONT FOG LAMP CIRCUIT

[XENON TYPE]

< COMPONENT DIAGNOSIS >

## FRONT FOG LAMP CIRCUIT

### Component Function Check

INFOID:000000001716402

#### 1. CHECK FRONT FOG LAMP OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the front fog lamp is turned ON.

##### Ⓟ CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the test items, check that the front fog lamp is turned ON.

**Fog** : Front fog lamp ON  
**Off** : Front fog lamp OFF

##### Is the front fog lamp turned ON?

- YES >> Front fog lamp circuit is normal.  
NO >> Refer to [EXL-36, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001716403

#### 1. CHECK FRONT FOG LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuse is not fusing.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#65	15 A

##### Is the fuse fusing?

- YES >> GO TO 2.  
NO >> GO TO 3.

#### 2. CHECK FRONT FOG LAMP SHORT CIRCUIT

1. Disconnect IPDM E/R connector and the front fog connector.
2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R			Ground	Continuity
Connector	Terminal			
RH	E12	17	Not existed	
LH		16		

##### Does continuity exist?

- YES >> Repair the harnesses or connectors. And then replace the fuse.  
NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

#### 3. CHECK FRONT FOG LAMP BULB

Check the applicable lamp bulb.

##### Is the bulb normal?

- YES >> GO TO 4.  
NO >> Replace the bulb.

#### 4. CHECK FRONT FOG LAMP OUTPUT VOLTAGE

##### Ⓟ CONSULT-III ACTIVE TEST

1. Disconnect the front fog lamp connector.
2. Turn the ignition switch ON.
3. Select "EXTERNAL LAMP" of IPDM E/R active test item.

# FRONT FOG LAMP CIRCUIT

[XENON TYPE]

## < COMPONENT DIAGNOSIS >

4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals			Test item	Voltage (Approx.)
(+)		(-)		
IPDM E/R			EXTERNAL LAMP	Battery voltage
Connector	Terminal			
RH	E12	17	Fog	0 V
LH		16	Ground	

Is the measurement value normal?

YES >> GO TO 5.

NO >> Replace IPDM E/R.

## 5.CHECK FRONT FOG LAMP OPEN CIRCUIT

- Turn the ignition switch OFF.
- Disconnect IPDM E/R connector.
- Check continuity between the IPDM E/R harness connector and the front fog lamp harness connector.

IPDM E/R			Front fog lamp		Continuity
Connector	Terminal		Connector	Terminal	
RH	E12	17	E48	2	Existed
LH		16	E30	2	

Does continuity exist?

YES >> GO TO 6.

NO >> Repair the harnesses or connectors.

## 6.CHECK FRONT FOG LAMP GROUND CIRCUIT OPEN CIRCUIT

Check continuity between the front fog lamp harness connector and the ground.

Front fog lamp			Ground	Continuity
Connector	Terminal			
RH	E48	1	Ground	Existed
LH	E30	1		

Does continuity exist?

YES >> Replace the front fog lamp.

NO >> Repair the harnesses or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# PARKING LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## PARKING LAMP CIRCUIT

### Component Function Check

INFOID:000000001716407

#### 1. CHECK PARKING LAMP OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the parking lamp is turned ON.

##### Ⓟ CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the test items, check that the parking lamp is turned ON.

**TAIL : Parking lamp ON**  
**Off : Parking lamp OFF**

##### Is the parking lamp turned ON?

- YES >> Parking lamp circuit is normal.  
NO >> Refer to [EXL-38, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001716408

#### 1. CHECK PARKING LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Parking lamp	IPDM E/R	#46	10 A

##### Is the fuse fusing?

- YES >> GO TO 2.  
NO >> GO TO 3.

#### 2. CHECK PARKING LAMP SHORT CIRCUIT

1. Disconnect IPDM E/R connector and the parking lamp connector.
2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R			Ground	Continuity
Connector	Terminal			
RH	E14	39	Not existed	
LH		38		

##### Does continuity exist?

- YES >> Repair the harnesses or connectors. And then replace the fuse.  
NO >> Replace the fuse. (Replace IPDM E/R if fusing is found again.)

#### 3. CHECK PARKING LAMP BULB

Check the applicable lamp bulb.

##### Is the bulb normal?

- YES >> GO TO 4.  
NO >> Replace the bulb.

#### 4. CHECK PARKING LAMP OUTPUT VOLTAGE

##### Ⓟ CONSULT-III ACTIVE TEST

1. Disconnect the parking lamp connector.
2. Turn the ignition switch ON.
3. Select "EXTERNAL LAMP" of IPDM E/R active test item.

# PARKING LAMP CIRCUIT

**[XENON TYPE]**

**< COMPONENT DIAGNOSIS >**

4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals			Test item	Voltage (Approx.)
(+)		(-)		
IPDM E/R			EXTERNAL LAMP	Battery voltage
Connector	Terminal			
RH	E14	39	TAIL	0 V
LH		38	Off	

Is the measurement value normal?

- YES >> GO TO 5.  
 NO >> Replace IPDM E/R.

## 5. CHECK PARKING LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the parking lamp harness connector.

IPDM E/R			Parking lamp		Continuity
Connector	Terminal		Connector	Terminal	
RH	E14	39	E46	1	Existed
LH		38	E27	1	

Does continuity exist?

- YES >> GO TO 6.  
 NO >> Repair the harnesses or connectors.

## 6. CHECK PARKING LAMP GROUND OPEN CIRCUIT

Check continuity between the parking lamp harness connector and the ground.

Parking lamp			Ground	Continuity
Connector	Terminal			
RH	E46	2	Ground	Existed
LH	E27	2		

Does continuity exist?

- YES >> Replace the front combination lamp.  
 NO >> Repair the harnesses or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

EXL

# TURN SIGNAL LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## TURN SIGNAL LAMP CIRCUIT

### Description

INFOID:000000001716411

BCM performs the high flasher operation (fail-safe) if any bulb or harness of the turn signal lamp circuit is open.

**NOTE:**

The turn signal lamp blinks at normal speed when using the hazard warning lamp.

### Component Function Check

INFOID:000000001716412

#### 1. CHECK TURN SIGNAL LAMP

ⓐ CONSULT-III ACTIVE TEST

1. Select "FLASHER" of BCM (FLASHER) active test item.
2. With operating the test items, check that the turn signal lamp is turned ON.

- LH** : Turn signal lamps (LH) ON
- RH** : Turn signal lamps (RH) ON
- Off** : Turn signal lamps OFF

Is the turn signal lamp turned ON?

- YES >> Turn signal lamp circuit is normal.
- NO >> Refer to [EXL-40, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001716413

#### 1. CHECK TURN SIGNAL LAMP BULB


Check the applicable lamp bulb.

Is the bulb normal?

- YES >> GO TO 2.
- NO >> Replace the bulb.

#### 2. CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the front turn signal lamp connector or the rear combination lamp connector.
3. Turn the ignition switch ON.
4. With operating the turn signal switch, check the voltage between the BCM harness connector and the ground.

Terminals			Condition	Voltage (Approx.)
(+)	(-)			
BCM			Turn signal switch	
Connector	Terminal			
RH	M67	61	LH or RH	PKID0926E
LH		60		
Ground			OFF	0 V

Is the measurement value normal?

- YES >> GO TO 3.
- NO >> Replace BCM. Refer to [BCS-67, "Exploded View"](#).

# TURN SIGNAL LAMP CIRCUIT

[XENON TYPE]

< COMPONENT DIAGNOSIS >

## 3. CHECK TURN SIGNAL LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between the BCM harness connector and the front turn signal lamp, or the rear combination lamp harness connector.

Front turn signal lamp

BCM		Front turn signal lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M67	61	E46	Existed
LH		60	E27	

Rear turn signal lamp

BCM		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M67	61	B59	Existed
LH		60	B80	

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

## 4. CHECK TURN SIGNAL LAMP SHORT CIRCUIT

Check continuity between the BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
RH	M67	61	Not existed
LH		60	

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 5.

## 5. CHECK TURN SIGNAL LAMP GROUND OPEN CIRCUIT

Check continuity between the front turn signal lamp, or the rear combination lamp and the ground.

Front turn signal lamp

Front turn signal lamp		Ground	Continuity
Connector	Terminal		
RH	E46	2	Existed
LH	E27		

Rear turn signal lamp

Rear combination lamp		Ground	Continuity
Connector	Terminal		
RH	B59	4	Existed
LH	B80		

Does continuity exist?

YES >> Replace the front combination lamp or the rear combination lamp.

NO >> Repair the harnesses or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# HAZARD SWITCH

[XENON TYPE]

< COMPONENT DIAGNOSIS >

## HAZARD SWITCH

### Component Function Check

INFOID:000000001716417

#### 1. CHECK HAZARD SWITCH SIGNAL BY CONSULT-III

##### CONSULT-III DATA MONITOR

1. Turn the ignition switch ON.
2. Select "HAZARD SW" of BCM (FLASHER) data monitor item.
3. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the item status normal?


- YES >> Hazard switch circuit is normal.  
 NO >> Refer to [EXL-42, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001716418

#### 1. CHECK HAZARD SWITCH SIGNAL INPUT

With operating the hazard switch, check the voltage between the BCM harness connector and the ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
BCM		Hazard switch	0 V
Connector	Terminal		
M65	29	ON	
		OFF	
	Ground		

JPMIA0154GB

Is the measurement value normal?

- YES >> Replace BCM. Refer to [BCS-67, "Exploded View"](#).  
 NO >> GO TO 2.

#### 2. CHECK HAZARD SWITCH SIGNAL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the hazard switch connector and BCM connector.
3. Check continuity between the hazard switch harness connector and the BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M45	2	M65	29	Existed

Does continuity exist?

- YES >> GO TO 3.  
 NO >> Repair the harnesses or connectors.

#### 3. CHECK HAZARD SWITCH SIGNAL SHORT CIRCUIT

Check continuity between the hazard switch harness connector and the ground.

# HAZARD SWITCH

< COMPONENT DIAGNOSIS >

[XENON TYPE]

Hazard switch		Ground	Continuity
Connector	Terminal		
M45	2		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 4.

## 4.CHECK HAZARD SWITCH GROUND OPEN CIRCUIT

Check continuity between the hazard switch harness connector and the ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M45	1		Existed

Does continuity exist?

YES >> Replace the hazard switch.

NO >> Repair the harnesses or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# TAIL LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## TAIL LAMP CIRCUIT

### Component Function Check

INFOID:000000001716419

#### NOTE:

Check the license plate lamp circuit if the tail lamp and the license plate lamp are not turned ON. Refer to [EXL-46, "Component Function Check"](#).

#### 1. CHECK TAIL LAMP OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the tail lamp is turned ON.

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the test items, check that the tail lamp is turned ON.

**TAIL : Tail Lamp ON**

**Off : Tail lamp OFF**

Is the tail lamp turned ON?

- YES >> Tail lamp circuit is normal.  
NO >> Refer to [EXL-44, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001716420

#### 1. CHECK TAIL LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Tail lamp	IPDM E/R	#45	10 A

Is the fuse fusing?

- YES >> Repair the malfunctioning part before replacing the fuse.  
NO >> GO TO 2.

#### 2. CHECK TAIL LAMP OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Disconnect the rear combination lamp connector.
2. Turn the ignition switch ON.
3. Select "EXTERNAL LAMP" of IPDM E/R active test item.
4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		EXTERNAL LAMP	Battery voltage
Connector	Terminal		
E14	37	TAIL	0 V
		Off	0 V

Is the measurement value normal?

- YES >> GO TO 3.  
NO >> Replace IPDM E/R.

#### 3. CHECK TAIL LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.

# TAIL LAMP CIRCUIT

**[XENON TYPE]**

**< COMPONENT DIAGNOSIS >**

2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the rear combination lamp harness connector.

IPDM E/R		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E14	37	B59	1
LH			B80	1

Does continuity exist?

- YES >> GO TO 4.  
 NO >> Repair the harnesses or connectors.

**4. CHECK TAIL LAMP GROUND OPEN CIRCUIT**

Check continuity between the rear combination lamp harness connector and the ground.

Rear combination lamp			Ground	Continuity
Connector	Terminal			
RH	B59	4		Existed
LH	B80	4		

Does continuity exist?

- YES >> Replace the rear combination lamp.  
 NO >> Repair the harnesses or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# LICENSE PLATE LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## LICENSE PLATE LAMP CIRCUIT

### Component Function Check

INFOID:000000001716423

#### 1.CHECK LICENSE PLATE LAMP OPERATION

##### ⊗IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the license plate lamp is turned ON.

##### ⓅCONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the lighting switch, check that the license plate lamp is turned ON.

**TAIL : License plate lamp ON**

**Off : License plate lamp OFF**

Is the license plate lamp turned ON?

- YES >> License plate lamp circuit is normal.  
NO >> Refer to [EXL-46, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001716424

#### 1.CHECK LICENSE PLATE LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

- YES >> GO TO 2.  
NO >> Replace the bulb.

#### 2.CHECK LICENSE PLATE LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector and the license plate lamp connector.
3. Check continuity between the IPDM E/R harness connector and the license plate lamp harness connector.

IPDM E/R		License plate lamp		Continuity	
Connector	Terminal	Connector	Terminal		
RH	E14	37	D196	1	Existed
LH			D195	1	

Does continuity exist?

- YES >> GO TO 3.  
NO >> Repair the harnesses or connectors.

#### 3.CHECK LICENSE PLATE LAMP GROUND OPEN CIRCUIT

Check continuity between the license plate lamp harness connector and the ground.

License plate lamp			Ground	Continuity
Connector	Terminal			
RH	D196	2	Ground	Existed
LH	D195	2		

Does continuity exist?

- YES >> Replace the license plate lamp.  
NO >> Repair the harnesses or connectors.

# HEADLAMP SYSTEM


< COMPONENT DIAGNOSIS >

[XENON TYPE]

## HEADLAMP SYSTEM

### Wiring Diagram - HEADLAMP -

INFOID:000000001719617



2007/07/13

JCLWM0868GE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HEADLAMP SYSTEM

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## HEADLAMP (WITH XENON HEADLAMP)

Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	M08FB-1C



Terminal No.	Color of Wire	Signal Name [Specification]
11	B	-

Connector No.	E12
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS02FBR-CS



Terminal No.	Color of Wire	Signal Name [Specification]
18	L	-
20	SB	-
21	G	-
22	LG	-

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH1Z7W-RH



Terminal No.	Color of Wire	Signal Name [Specification]
25	B	-
26	P	-
27	L	-

Connector No.	E71
Connector Name	HEADLAMP LOW LH
Connector Type	EQ2FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	B	-

Connector No.	E72
Connector Name	HEADLAMP HIGH LH
Connector Type	U02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	B	-

Connector No.	E74
Connector Name	HEADLAMP LOW RH
Connector Type	EQ2FGY-RS



Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	B	-

Connector No.	E75
Connector Name	HEADLAMP HIGH RH
Connector Type	U02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	B	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH8DFW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-
12	P	-
22	L	-

# HEADLAMP SYSTEM

< COMPONENT DIAGNOSIS >

[XENON TYPE]


## HEADLAMP (WITH XENON HEADLAMP)

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-
14	P	-

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TK16FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	INPUT 1
2	B	INPUT 2
3	L	INPUT 3
4	GR	INPUT 4
5	BR	INPUT 5
6	P	OUTPUT 1
7	R	OUTPUT 2
8	G	OUTPUT 3
9	Y	OUTPUT 4
10	W	OUTPUT 3

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	G	INPUT 5
3	Y	INPUT 4
4	W	INPUT 3
5	R	INPUT 2
6	P	INPUT 1
11	SB	ACC
32	BR	OUTPUT 5
33	GR	OUTPUT 4
34	L	OUTPUT 3
35	B	OUTPUT 2
36	V	OUTPUT 1

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	S4F40FW




Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA



Terminal No.	Color of Wire	Signal Name [Specification]
57	G	BAT FUSE
67	B	GND
70	Y	BAT FL

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80MY-CG16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-
12	P	-
22	L	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HEADLAMP AIMING CONTROL SYSTEM (MANUAL)

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## HEADLAMP AIMING CONTROL SYSTEM (MANUAL)


### Description

INFOID:000000001720226

The headlamp levelizer adjusts the headlamp light axis upward and downward with the aiming motor integrated in the front combination lamp.

### Wiring Diagram - HEADLAMP AIMING CONTROL SYSTEM (MANUAL) -

INFOID:000000001720229



2007/07/13

JCLWM0881GE

# HEADLAMP AIMING CONTROL SYSTEM (MANUAL)

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## HEADLAMP AIMING CONTROL

Connector No.	E28
Connector Name	HEADLAMP AIMING MOTOR LH
Connector Type	RH03FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	V	-
3	R	-

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
79	V	-
89	G	-

Connector No.	E47
Connector Name	HEADLAMP AIMING MOTOR RH
Connector Type	RH03FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	V	-
3	R	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
79	V	-
89	R	-

Connector No.	M6
Connector Name	HEADLAMP AIMING SWITCH
Connector Type	AG4FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	B	-
3	R	-
4	Y	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## Component Inspection

### 1. CHECK HEADLAMP AIMING SWITCH

1. Remove the headlamp aiming switch.

JCLWM0882GE

INFOID:000000001720228


# HEADLAMP AIMING CONTROL SYSTEM (MANUAL)

[XENON TYPE]

## < COMPONENT DIAGNOSIS >

2. Check the resistance among each headlamp aiming switch terminal.

Headlamp aiming switch		Condition	Resistance (Approx.)
Terminal		Switch position	
1	2	0	A: 160 Ω
		1	B: 249 Ω
		2	C: 464 Ω
		3	D: 887 Ω
	3	—	E: 412 Ω



Is the measurement value normal?

- YES >> Headlamp aiming switch is normal.
- NO >> Replace the headlamp aiming switch.

# FRONT FOG LAMP SYSTEM


< COMPONENT DIAGNOSIS >

[XENON TYPE]

## FRONT FOG LAMP SYSTEM

### Wiring Diagram - FRONT FOG LAMP -

INFOID:000000001720202



2007/07/13

JCLWM0883GE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT FOG LAMP SYSTEM

< COMPONENT DIAGNOSIS >

[XENON TYPE]


## FRONT FOG LAMP

Connector No.	E30
Connector Name	FRONT FOG LAMP LH
Connector Type	FHZ02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	
2	Y	

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH12FW-RH



Terminal No.	Color of Wire	Signal Name [Specification]
25	B	
26	P	
27	L	

Connector No.	E12
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS02FBR-CS



Terminal No.	Color of Wire	Signal Name [Specification]
16	Y	
17	W	

Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	M08FB-LC




Terminal No.	Color of Wire	Signal Name [Specification]
11	B	

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TK16FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	INPUT 1
2	B	INPUT 2
3	L	INPUT 3
4	GR	INPUT 4
5	BR	INPUT 5
6	P	OUTPUT 1
7	R	OUTPUT 2
8	G	OUTPUT 5
9	Y	OUTPUT 4
10	W	OUTPUT 3

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
6	L	
14	P	

Connector No.	E05
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	
12	P	
22	L	

Connector No.	E48
Connector Name	FRONT FOG LAMP RH
Connector Type	FHZ02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	
2	W	

JCLWM0884GE


# FRONT FOG LAMP SYSTEM

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## FRONT FOG LAMP


Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH407W



Terminal No.	Color of Wire	Signal Name [Specification]
2	G	INPUT 5
3	Y	INPUT 4
4	W	INPUT 3
5	R	INPUT 2
6	D	INPUT 1
11	SB	ACC
32	BR	OUTPUT 5
33	GR	OUTPUT 4
34	L	OUTPUT 3
35	B	OUTPUT 2
36	V	OUTPUT 1


38	G	IGN
39	L	CAN-H
40	P	CAN-L

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FRAG-SA



Terminal No.	Color of Wire	Signal Name [Specification]
57	G	BAT FUSE
67	B	GND
70	Y	BAT FL

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80MP-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	
12	P	
22	L	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >


[XENON TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

Wiring Diagram - TURN AND HAZARD WARNING LAMPS -

INFOID:000000001720203

### TURN SIGNAL AND HAZARD WARNING LAMPS



2007/07/13

JCLWM0886GE

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMPS

Connector No. B1	WIRE TO WIRE THB0WF-CS (F-TM4)		Terminal No. 93	Color of Wire W	Signal Name [Specification]	Terminal No. 3	Color of Wire BR	Signal Name [Specification]
Connector No. B4	WIRE TO WIRE NS16MF-CS		Terminal No. 15	Color of Wire BR	Signal Name [Specification]	Terminal No. 3	Color of Wire W	Signal Name [Specification]
Connector No. B59	REAR COMBINATION LAMP RH NSGAMF-CS		Terminal No. 3	Color of Wire W	Signal Name [Specification]	Terminal No. 3	Color of Wire BR	Signal Name [Specification]
Connector No. B60	REAR COMBINATION LAMP LH NSGAMF-CS		Terminal No. 4	Color of Wire B	Signal Name [Specification]	Terminal No. 4	Color of Wire B	Signal Name [Specification]
Connector No. E27	FRONT COMBINATION LAMP LH Z03FGY		Terminal No. 2	Color of Wire B	Signal Name [Specification]	Terminal No. 6	Color of Wire L	Signal Name [Specification]
Connector No. E46	FRONT COMBINATION LAMP RH Z03FGY		Terminal No. 3	Color of Wire GR	Signal Name [Specification]	Terminal No. 14	Color of Wire P	Signal Name [Specification]
Connector No. E105	WIRE TO WIRE THB0FW-CS16-TM4		Terminal No. 5	Color of Wire Y	Signal Name [Specification]	Terminal No. 6	Color of Wire L	Signal Name [Specification]
Connector No. M4	DATA LINK CONNECTOR BD16FW		Terminal No. 8	Color of Wire GR	Signal Name [Specification]	Terminal No. 14	Color of Wire P	Signal Name [Specification]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

JCLWM0887GE

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMPS

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TK18FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	INPUT 1
2	B	INPUT 2
3	L	INPUT 3
4	GR	INPUT 4
5	BR	INPUT 5
6	P	OUTPUT 1
7	R	OUTPUT 2
8	G	OUTPUT 5
9	Y	OUTPUT 4
10	W	OUTPUT 3

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Type	NS18FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
15	BR	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
93	GR	-

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA



Terminal No.	Color of Wire	Signal Name [Specification]
57	G	BAT FUSE
60	BR	FLASHER OUT PUT (LEFT)
61	GR	FLASHER OUT PUT (RIGHT)
67	B	GND
70	Y	BAT FL

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA



Terminal No.	Color of Wire	Signal Name [Specification]
38	G	IGN
39	L	CAN-H
40	P	CAN-L

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	G	INPUT 5
3	Y	INPUT 4
4	W	INPUT 3
5	R	INPUT 2
6	P	INPUT 1
29	W	HAZARD SW
32	BR	OUTPUT 5
33	GR	OUTPUT 4
34	L	OUTPUT 3
35	B	OUTPUT 2
36	V	OUTPUT 1

Connector No.	M45
Connector Name	HAZARD SWITCH
Connector Type	TK04FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	W	-

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA



Terminal No.	Color of Wire	Signal Name [Specification]
57	G	BAT FUSE
60	BR	FLASHER OUT PUT (LEFT)
61	GR	FLASHER OUT PUT (RIGHT)
67	B	GND
70	Y	BAT FL

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA



Terminal No.	Color of Wire	Signal Name [Specification]
38	G	IGN
39	L	CAN-H
40	P	CAN-L

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW



Terminal No.	Color of Wire	Signal Name [Specification]
2	G	INPUT 5
3	Y	INPUT 4
4	W	INPUT 3
5	R	INPUT 2
6	P	INPUT 1
29	W	HAZARD SW
32	BR	OUTPUT 5
33	GR	OUTPUT 4
34	L	OUTPUT 3
35	B	OUTPUT 2
36	V	OUTPUT 1

Connector No.	M45
Connector Name	HAZARD SWITCH
Connector Type	TK04FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	W	-

JCLW00888GE

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM


< COMPONENT DIAGNOSIS >

[XENON TYPE]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## TURN SIGNAL AND HAZARD WARNING LAMPS

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	THEBMW-CS (F-TM4)



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-
8	GR	-
9	BR	-

JCLWM0889GE

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< COMPONENT DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

Wiring Diagram - PARKING, LICENSE PLATE AND TAIL LAMPS -

INFOID:000000001720204




2007/07/13

JCLWM0896GE

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

[XENON TYPE]



JCLWM0897GE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS


Connector No.	B3
Connector Name	WIRE TO WIRE
Connector Type	TH2ZMW-NH



Terminal No.	15	P	Signal Name [Specification]	-
--------------	----	---	-----------------------------	---


Connector No.	B34
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	A03FW



Terminal No.	2	P	Signal Name [Specification]	-
--------------	---	---	-----------------------------	---

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	TH8DMW-CS(6-TM4



Terminal No.	8	R	Signal Name [Specification]	-
--------------	---	---	-----------------------------	---


  

Connector No.	B54
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	6	R	Signal Name [Specification]	-
--------------	---	---	-----------------------------	---

Connector No.	B55
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS



Terminal No.	6	R	Signal Name [Specification]	-
--------------	---	---	-----------------------------	---

Connector No.	B77
Connector Name	WIRE TO WIRE
Connector Type	NS10MW-CS



Terminal No.	6	R	Signal Name [Specification]	-
--------------	---	---	-----------------------------	---

Connector No.	B59
Connector Name	REAR COMBINATION LAMP RH
Connector Type	NS8AMW-CS



Terminal No.	1	R	Signal Name [Specification]	-
Terminal No.	2	Y	Signal Name [Specification]	-
Terminal No.	4	B	Signal Name [Specification]	-

Connector No.	B79
Connector Name	WIRE TO WIRE
Connector Type	MM4MW-LC



Terminal No.	3	B	Signal Name [Specification]	-
--------------	---	---	-----------------------------	---


JCLWM0898GE

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No. B80	Connector Name REAR COMBINATION LAMP LH	Connector Type NS04MW-CS	Connector No. D151	Connector Name WIRE TO WIRE	Connector Type NS00FBR-CS	Terminal No. 1 2 4	Color of Wire R Y B	Signal Name [Specification]	Terminal No. 6	Color of Wire R	Signal Name [Specification]
 			 			 			 		
Connector No. D159	Connector Name WIRE TO WIRE	Connector Type MG4FW-LC	Connector No. D181	Connector Name WIRE TO WIRE	Connector Type NS00MBR-CS	Terminal No. 2	Color of Wire R	Signal Name [Specification]	Connector No. D195	Connector Name LICENSE PLATE LAMP LH	Connector Type TK02FBR
 			 			 			 		
Terminal No. 3	Color of Wire B	Signal Name [Specification]	Terminal No. 2	Color of Wire R	Signal Name [Specification]	Terminal No. 2	Color of Wire B	Signal Name [Specification]	Terminal No. 1	Color of Wire R	Signal Name [Specification]
 			 			 			 		

JCLLWM0899GE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	E14
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS12FBR-CS



39	38	37	36	35
46	45	44	43	42
41	40	39	38	37

Terminal No.	Color of Wire	Signal Name [Specification]
37	R	
38	R	
39	GR	

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH12FW-RH



28	27	26	25	24	23
34	33	32	31	30	29

Terminal No.	Color of Wire	Signal Name [Specification]
25	B	
26	P	
27	L	

Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	M06FB-LC



11	10	9
14	13	12

Terminal No.	Color of Wire	Signal Name [Specification]
11	B	

Connector No.	D196
Connector Name	LICENSE PLATE LAMP RH
Connector Type	TK02FBR



2	1
---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	R	
2	B	

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH8DFW-CS16-TM4



18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
----	----	----	----	----	----	----	----	----	---	---	---	---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	
12	P	
22	L	

Connector No.	E101
Connector Name	WIRE TO WIRE
Connector Type	TH8DFW-CS16-TM4



18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
----	----	----	----	----	----	----	----	----	---	---	---	---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
8	R	

Connector No.	E46
Connector Name	FRONT COMBINATION LAMP RH
Connector Type	Z03FGY



3	2	1
---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	
2	B	

Connector No.	E27
Connector Name	FRONT COMBINATION LAMP LH
Connector Type	Z03FGY



3	2	1
---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	R	
2	B	

JCLWM0900GE

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	M64
Connector Name	COMBINATION METER
Connector Type	SAB6FW



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TK18FW



12	13	10	9	8	7	14	11	1	2	3	4	5	6
----	----	----	---	---	---	----	----	---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	V	INPUT 1
2	B	INPUT 2
3	L	INPUT 3
4	GR	INPUT 4
5	BR	INPUT 5
8	P	OUTPUT 1
7	R	OUTPUT 2
9	G	OUTPUT 3
10	W	OUTPUT 3

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA



56	57	58	59	60	61	62	63	64	65	66	67	68	69	70
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
57	G	BAT FUSE
67	B	GND
70	Y	BAT FL

Connector No.	M13
Connector Name	WIRE TO WIRE
Connector Type	TH32FW-NH



16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17
----	----	----	----	----	----	----	---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
15	W	-

38	G	IGN
39	L	CAN-H
40	P	CAN-L

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD18FW



9	10	11	12	13	14	15	16	1	2	3	4	5	6	7	8
---	----	----	----	----	----	----	----	---	---	---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-
14	P	-

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
2	G	INPUT 5
3	Y	INPUT 4
4	W	INPUT 3
5	R	INPUT 2
6	P	INPUT 1
11	SB	ACC
32	BR	OUTPUT 5
33	GR	OUTPUT 4
34	L	OUTPUT 3
35	B	OUTPUT 2
36	V	OUTPUT 1

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	W77
Connector Name	WIRE TO WIRE
Connector Type	THB0WV-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-
12	P	-
22	L	-

JCLWM0902GE

# STOP LAMP

< COMPONENT DIAGNOSIS >


[XENON TYPE]

## STOP LAMP

### Wiring Diagram - STOP LAMP -

INFOID:000000001720205

STOP LAMP



2007/07/13

JCLWM0890GE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# STOP LAMP

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## STOP LAMP


Connector No. B11	WIRE TO WIRE TH80MW-CS16-TM4	 	Terminal No. 9	Color of Wire Y	Signal Name [Specification] -
Connector No. B54	WIRE TO WIRE NS17MW-CS	 	Terminal No. 6	Color of Wire Y R	Signal Name [Specification] -
Connector No. B55	WIRE TO WIRE NS12FW-CS	 	Terminal No. 6	Color of Wire Y R	Signal Name [Specification] -
Connector No. B59	REAR COMBINATION LAMP RH NS30MM-CS	 	Terminal No. 1 2 4	Color of Wire R Y B	Signal Name [Specification] -
Connector No. B60	REAR COMBINATION LAMP LH NS30MM-CS	 	Terminal No. 1 2 4	Color of Wire R Y B	Signal Name [Specification] -
Connector No. B77	WIRE TO WIRE NS10MW-CS	 	Terminal No. 1 2	Color of Wire B Y	Signal Name [Specification] -
Connector No. D154	HIGH-MOUNTED STOP LAMP TK02FW	 	Terminal No. 1 2	Color of Wire Y B	Signal Name [Specification] -
Connector No. D157	WIRE TO WIRE NS10FW-CS	 	Terminal No. 1 2	Color of Wire B Y	Signal Name [Specification] -

JCLWM0891GE


# STOP LAMP

< COMPONENT DIAGNOSIS >

[XENON TYPE]

STOP LAMP		
Connector No.	E101	
Connector Name	WIRE TO WIRE	
Connector Type	TH80PW-CS16-TM4	
 		
Terminal No.	9	Y
Color of Wire	Y	
Signal Name [Specification]		


  

Connector No.	E105	
Connector Name	WIRE TO WIRE	
Connector Type	TH80PW-CS16-TM4	
 		
Terminal No.	4	V
Color of Wire	V	
Signal Name [Specification]		

Connector No.	E115	
Connector Name	STOP LAMP SWITCH	
Connector Type	MM0FY-LC	
 		
Terminal No.	1	V
Color of Wire	V	
Signal Name [Specification]		
Terminal No.	2	Y
Color of Wire	Y	
Signal Name [Specification]		
Terminal No.	3	G
Color of Wire	G	
Signal Name [Specification]		
Terminal No.	4	L
Color of Wire	L	
Signal Name [Specification]		

Connector No.	M77	
Connector Name	WIRE TO WIRE	
Connector Type	TH80MP-CS16-TM4	
 		
Terminal No.	4	Y
Color of Wire	Y	
Signal Name [Specification]		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BACK-UP LAMP

< COMPONENT DIAGNOSIS >


[XENON TYPE]

## BACK-UP LAMP

Wiring Diagram - BUCK-UP LAMP -

INFOID:000000001720206

BACK-UP LAMP



2007/07/13

JCLWM0893GE

# BACK-UP LAMP

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## BACK-UP LAMP

Connector No.	B79	WIRE TO WIRE	MM4MF-LC
Connector Name			
Connector Type			
Terminal No.	3	Color of Wire	B
Signal Name [Specification]	1 2 3 4		

Connector No.	B77	WIRE TO WIRE	NS10MF-CS
Connector Name			
Connector Type			
Terminal No.	5	Color of Wire	G
Signal Name [Specification]	1 2 3 4 5 6 7 8 9 10		

Connector No.	D151	WIRE TO WIRE	NS30FBR-CS
Connector Name			
Connector Type			
Terminal No.	8	Color of Wire	G
Signal Name [Specification]	3 2 1 8 7 6 5 4		

Connector No.	D152	WIRE TO WIRE	MD2FW-GY-LC
Connector Name			
Connector Type			
Terminal No.	2	Color of Wire	B
Signal Name [Specification]	1 2		

Connector No.	D156	BACK-UP LAMP LH	NS02FW-CS
Connector Name			
Connector Type			
Terminal No.	1	Color of Wire	Y
Signal Name [Specification]	1 2		

Connector No.	D157	WIRE TO WIRE	NS10FW-CS
Connector Name			
Connector Type			
Terminal No.	5	Color of Wire	G
Signal Name [Specification]	4 3 2 1 10 9 8 7 6 5		

Connector No.	D159	WIRE TO WIRE	MM4FW-LC
Connector Name			
Connector Type			
Terminal No.	3	Color of Wire	B
Signal Name [Specification]	2 1 4 3		

JCLWM0894GE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BACK-UP LAMP

< COMPONENT DIAGNOSIS >

[XENON TYPE]

## BACK-UP LAMP

Connector No.	D181
Connector Name	WIRE TO WIRE
Connector Type	NS38MR-CS



Terminal No.	8	Color of Wire	G	Signal Name [Specification]	-
--------------	---	---------------	---	-----------------------------	---

Connector No.	D182
Connector Name	WIRE TO WIRE
Connector Type	M02MM-GY-LC



Terminal No.	2	Color of Wire	B	Signal Name [Specification]	-
--------------	---	---------------	---	-----------------------------	---

Connector No.	D184
Connector Name	BACK-UP LAMP RH
Connector Type	NS02FW-CS



Terminal No.	1	Color of Wire	G	Signal Name [Specification]	-
2	B	-	-	-	-

Connector No.	E6
Connector Name	WIRE TO WIRE
Connector Type	TK2AMF-IV




Terminal No.	2	Color of Wire	SB	Signal Name [Specification]	-
3	G	-	-	-	-

Connector No.	E15
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS16FW-CS



Terminal No.	60	Color of Wire	SB	Signal Name [Specification]	-
--------------	----	---------------	----	-----------------------------	---

Connector No.	E101
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	1	Color of Wire	G	Signal Name [Specification]	-
--------------	---	---------------	---	-----------------------------	---

Connector No.	F21
Connector Name	PARK / NEUTRAL POSITION SWITCH
Connector Type	RK08FG



Terminal No.	3	Color of Wire	SB	Signal Name [Specification]	-
5	G	-	-	-	-

Connector No.	F23
Connector Name	WIRE TO WIRE
Connector Type	TK24FW-IV



Terminal No.	2	Color of Wire	SB	Signal Name [Specification]	-
3	G	-	-	-	-

JCLWM0895GE

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]

## ECU DIAGNOSIS

### BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000003049971

#### VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
IGN ON SW	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
KEY ON SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted to key cylinder	On
CDL LOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the lock side	On
CDL UNLOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the unlock side	On
DOOR SW-DR	Driver's door closed	Off
	Driver's door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
BACK DOOR SW	Back door closed	Off
	Back door opened	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEYLESS LOCK	"LOCK" button of key fob is not pressed	Off
	"LOCK" button of key fob is pressed	On
KEYLESS UNLOCK	"UNLOCK" button of key fob is not pressed	Off
	"UNLOCK" button of key fob is pressed	On
I-KEY LOCK	"LOCK" button of Intelligent Key or door request switch are not pressed	Off
	"LOCK" button of Intelligent Key or door request switch are pressed	On
I-KEY UNLOCK	"UNLOCK" button of Intelligent Key or door request switch are not pressed	Off
	"UNLOCK" button of Intelligent Key or door request switch are pressed	On
ACC ON SW	Ignition switch OFF	Off
	Ignition switch ACC or ON	On
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
LIGHT SW 1ST	Lighting switch OFF	Off
	Lighting switch 1ST	On

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]

Monitor Item	Condition	Value/Status
BUCKLE SW	The seat belt (driver side) is unfastened. [Seat belt switch (driver side) OFF]	Off
	The seat belt (driver side) is fastened. [Seat belt switch (driver side) ON]	On
KEYLESS PANIC	PANIC button of key fob is not pressed	Off
	PANIC button of key fob is pressed	On
KEYLESS TRUNK	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TRNK OPN MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off
RKE LCK-UNLCK	LOCK/UNLOCK button of key fob is not pressed and held simultaneously	Off
	LOCK/UNLOCK button of key fob is pressed and held simultaneously	On
RKE KEEP UNLK	UNLOCK button of key fob is not pressed	Off
	UNLOCK button of key fob is pressed and held	On
HI BEAM SW	Lighting switch OFF	Off
	Lighting switch HI	On
HEAD LAMP SW 1	Lighting switch OFF	Off
	Lighting switch 2ND	On
HEAD LAMP SW 2	Lighting switch OFF	Off
	Lighting switch 2ND	On
AUTO LIGHT SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
TURN SIGNAL R	Turn signal switch OFF	Off
	Turn signal switch RH	On
TURN SIGNAL L	Turn signal switch OFF	Off
	Turn signal switch LH	On
ENGINE RUN	Engine stopped	Off
	Engine running	On
PKB SW	Parking brake switch is OFF	Off
	Parking brake switch is ON	On
CARGO LAMP SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
OPTICAL SENSOR	<b>NOTE:</b> The item is indicated, but not monitored.	0 V
IGN SW CAN	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
FR WIPER HI	Front wiper switch OFF	Off
	Front wiper switch HI	On
FR WIPER LOW	Front wiper switch OFF	Off
	Front wiper switch LO	On

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]

Monitor Item	Condition	Value/Status	
FR WIPER INT	Front wiper switch OFF	Off	A
	Front wiper switch INT	On	
FR WASHER SW	Front washer switch OFF	Off	B
	Front washer switch ON	On	
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7	
FR WIPER STOP	Any position other than front wiper stop position	Off	C
	Front wiper stop position	On	
VEHICLE SPEED	While driving	Equivalent to speedometer reading	D
RR WIPER ON	Rear wiper switch OFF	Off	
	Rear wiper switch ON	On	
RR WIPER INT	Rear wiper switch OFF	Off	E
	Rear wiper switch INT	On	
RR WASHER SW	Rear washer switch OFF	Off	F
	Rear washer switch ON	On	
RR WIPER STOP	Rear wiper stop position	Off	G
	Other than rear wiper stop position	On	
RR WIPER STP2	<b>NOTE:</b> The item is indicated, but not monitored.	Off	H
H/L WASH SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
HAZARD SW	Hazard switch OFF	Off	I
	Hazard switch ON	On	
BRAKE SW	Brake pedal is not depressed	Off	J
	Brake pedal is depressed	On	
FAN ON SIG	Blower fan motor switch OFF	Off	
	Blower fan motor switch ON (other than OFF)	On	
AIR COND SW	Compressor ON is not requested from auto amp. (A/C indicator OFF, blower fan motor switch OFF or etc.)	Off	K
	Compressor ON is requested from auto amp. (A/C indicator ON and blower fan motor switch ON).	On	EXL
I-KEY TRUNK	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
I-KEY PW DWN	UNLOCK button of Intelligent Key is not pressed	Off	M
	UNLOCK button of Intelligent Key is pressed and held	On	
I-KEY PANIC	PANIC button of Intelligent Key is not pressed	Off	N
	PANIC button of Intelligent Key is pressed	On	
PUSH SW	Return to ignition switch to "LOCK" position	Off	O
	Press ignition switch	On	
TRNK OPNR SW	When back door opener switch is not pressed	Off	P
	When back door opener switch is pressed	On	
TRUNK CYL SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
HOOD SW	Close the hood	Off	
	<b>NOTE:</b> Vehicles of except for Mexico are OFF-fixed Open the hood	On	

## BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]


Monitor Item	Condition	Value/Status
OIL PRESS SW	<ul style="list-style-type: none"> <li>• Ignition switch OFF or ACC</li> <li>• Engine running</li> </ul>	Off
	Ignition switch ON	On
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]

## TERMINAL LAYOUT



### PHYSICAL VALUES

**CAUTION:**






- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF is not to be fluctuated by being overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-III. Refer to [BCS-26. "COMB SW : CONSULT-III Function \(BCM - COMB SW\)".](#)
- BCM reads the status of the combination switch at 10 ms internal normally. Refer to [BCS-9. "System Diagram".](#)

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output	Ignition key hole illumination	OFF	Battery voltage
1 (V)	Ground	Ignition key hole illumination control	Output		ON	

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >






[XENON TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
2 (G)	Ground	Combination switch INPUT 5	Input	All switch OFF	0 V
				Turn signal switch RH	
				Lighting switch HI	
				Lighting switch 1ST	
					1.0 V
					
					2.0 V
3 (Y)	Ground	Combination switch INPUT 4	Input	All switch OFF	0 V
				Turn signal switch LH	
				Lighting switch PASS	
				Lighting switch 2ND	
					1.0 V
					
					0.8 V
4 (W)	Ground	Combination switch INPUT 3	Input	All switch OFF	0 V
				Front wiper switch LO	
				Front wiper switch MIST	
				Front wiper switch INT	
					1.0 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]





Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
5 (R)	Ground	Combination switch INPUT 2	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front washer switch (Wiper intermittent dial 4) Rear washer ON (Wiper intermittent dial 4) Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>	 <p style="text-align: right; font-size: small;">PKIB4959J</p>
						1.0 V
					Rear wiper switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4955J</p>
						0.8 V
6 (P)	Ground	Combination switch INPUT 1	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4) Rear wiper switch INT (Wiper intermittent dial 4) Wiper intermittent dial 3 (All switch OFF)	 <p style="text-align: right; font-size: small;">PKIB4959J</p>
						1.0 V
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> </ul>	 <p style="text-align: right; font-size: small;">PKIB4952J</p>
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>	 <p style="text-align: right; font-size: small;">PKIB4955J</p>
						0.8 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >




[XENON TYPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
7 (L)	Ground	Door key cylinder switch UNLOCK signal	Input	Door key cylinder switch	NEUTRAL position	 <small>JPMIA0587GB</small> 8.0 - 8.5 V
					UNLOCK position	0 V
8 (R)	Ground	Door key cylinder switch LOCK signal	Input	Door key cylinder switch	NEUTRAL position	 <small>JPMIA0587GB</small> 8.0 - 8.5 V
					LOCK position	0 V
9 (R)	Ground	Stop lamp switch	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is de- pressed)	Battery voltage
10 (SB)	Ground	Rear window defog- ger switch	Input	Rear window defogger switch	Not pressed	Battery voltage
					Pressed	0 V
11 (SB)	Ground	Ignition switch ACC	Input	Ignition switch OFF		0 V
				Ignition switch ACC or ON		Battery voltage
12 (P)	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closed)	 <small>JPMIA0586GB</small> 7.5 - 8.0 V
					ON (When passenger door opened)	0 V
13 (LG)	Ground	Rear door switch RH	Input	Rear door switch RH	OFF (When rear door RH closed)	 <small>JPMIA0587GB</small> 8.0 - 8.5 V
					ON (When rear door RH opened)	0 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]




Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
15*1 (O)	Ground	TPMS mode trigger switch	Input	Ignition switch OFF		 <p style="text-align: right; font-size: small;">JPMIA0588GB</p> <p style="text-align: center;">1.5 V</p>
18*1 (O)	Ground	Remote keyless entry receiver ground	Input	Ignition switch ON		0 V
19*1 (V)	Ground	Remote keyless entry receiver power supply	Input	Without Intelligent Key system	At any condition	5 V
				With Intelligent Key system	• Ignition switch OFF • For 3 seconds after ignition switch OFF to ON	0 V
					3 seconds or later after ignition switch OFF to ON	5 V
20*1 (GR)	Ground	Remote keyless entry receiver signal	Input	Without Intelligent Key system	At any condition	 <p style="text-align: right; font-size: small;">JPMIA0589GB</p> <p><b>NOTE:</b> The wave form changes according to signal-receiving condition.</p>
				With Intelligent Key system	• Ignition switch OFF • For 3 seconds after ignition switch OFF to ON	0 V
					3 seconds or later after ignition switch OFF to ON	 <p style="text-align: right; font-size: small;">JPMIA0589GB</p> <p><b>NOTE:</b> The wave form changes according to signal-receiving condition.</p>
21 (G)	Ground	Immobilizer antenna signal (Clock)	Input/ Output	Ignition switch OFF		Battery voltage

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





[XENON TYPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
23 (B)	Ground	Security indicator signal	Input	Security indica- tor	ON	0 V
					Blinking (Ignition switch OFF)	 <p style="text-align: center;">12.0 V</p> <p style="text-align: right; font-size: small;">JPMIA0590GB</p>
25 (BR)	Ground	Immobilizer anten- na signal (Rx, Tx)	Input/ Output	Ignition switch OFF		Battery voltage
27 (Y)	Ground	A/C switch	Input	Ignition switch ON	A/C switch OFF	 <p style="text-align: center;">1.6 V</p> <p style="text-align: right; font-size: small;">JPMIA0591GB</p>
					A/C switch ON	0 V
28 (LG)	Ground	Blower fan switch	Input	Ignition switch ON	Blower fan switch OFF	 <p style="text-align: center;">7.0 - 7.5 V</p> <p style="text-align: right; font-size: small;">JPMIA0592GB</p>
					Blower fan switch ON	0 V
29 (W)	Ground	Hazard switch	Input	Hazard switch	OFF	Battery voltage
					ON	0 V
30 (G)	Ground	Back door opener switch	Input	Back door opener switch	Not pressed	Battery voltage
					Pressed	0 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
32 (BR)	Ground	Combination switch OUTPUT 5	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.2 V</p>
					Front fog lamp switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4956J</p> <p style="text-align: center;">1.0 V</p>
					Rear wiper switch ON (Wiper intermittent dial 4)	
					Any of the condition below with all switch OFF	
33 (GR)	Ground	Combination switch OUTPUT 4	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.2 V</p>
					Lighting switch 1ST (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Rear wiper switch INT (Wiper intermittent dial 4)	
					Any of the condition below with all switch OFF	







A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >




[XENON TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
34 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.2 V</p>
					Lighting switch 2ND (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Lighting switch HI (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 3</li> </ul>						
35 (B)	Ground	Combination switch OUTPUT 2	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.2 V</p>
					Lighting switch 2ND	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Lighting switch PASS	
					Front wiper switch INT	
Front wiper switch HI						
36 (V)	Ground	Combination switch OUTPUT 1	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.2 V</p>
					Turn signal switch RH	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Turn signal switch LH	
					Front wiper switch LO (Front wiper switch MIST)	
Front washer switch ON						

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]



Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
37 (LG)	Ground	Key switch	Input	Insert mechanical key into ignition key cylinder	Battery voltage
				Remove mechanical key from ignition key cylinder	0 V
38 (G)	Ground	Ignition switch ON	Input	Ignition switch OFF or ACC	0 V
				Ignition switch ON or START	Battery voltage
39 (L)	Ground	CAN-H	Input/ Output	—	—
40 (P)	Ground	CAN-L	Input/ Output	—	—
43 (V)	Ground	Back door switch	Input	Back door switch OFF (When back door closed)	
				Back door switch ON (When back door opened)	0 V
44 (B)	Ground	Rear wiper auto stop	Input	Ignition switch ON Rear wiper stop position	0 V
				Any position other than rear wiper stop position	Battery voltage
45 (P)	Ground	Door lock and unlock switch LOCK signal	Input	Door lock and unlock switch NEUTRAL position	
				Door lock and unlock switch LOCK position	0 V
46 (BR)	Ground	Door lock and unlock switch UNLOCK signal	Input	Door lock and unlock switch NEUTRAL position	
				Door lock and unlock switch UNLOCK position	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
47 (W)	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closed)	 8.0 - 8.5 V
					ON (When driver door opened)	0 V
48 (GR)	Ground	Rear door switch LH	Input	Rear door switch LH	OFF (When rear door LH closed)	 8.5 - 9.0 V
					ON (When rear door LH opened)	0 V
49 (L)	Ground	Back door lamp control	Output	Back door lamp switch DOOR position	Back door is closed (Back door lamp turns OFF)	Battery voltage
					Back door is opened (Back door lamp turns ON)	0 V
53 (V)	Ground	Back door open	Output	Back door opener switch	Not pressed (Back door actuator is activated)	0 V
					Pressed (Back door actuator is activated)	Battery voltage
55 (SB)	Ground	Rear wiper motor	Output	Ignition switch ON	Rear wiper switch OFF	0 V
					Rear wiper switch ON	Battery voltage
56 (Y)	Ground	Interior room lamp power supply	Output	After passing the interior room lamp battery saver operation time		0 V
				Any other time after passing the interior room lamp battery saver operation time		Battery voltage
57 (G)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
59 (L)	Ground	Driver door UN-LOCK	Output	Driver door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
60 (BR)	Ground	Turn signal LH	Output	Ignition switch OFF	0 V
				Ignition switch ON	Turn signal switch LH
61 (GR)	Ground	Turn signal RH	Output	Ignition switch OFF	0 V
				Ignition switch ON	Turn signal switch RH
63 (R)	Ground	Interior room lamp timer control	Output	Interior room lamp OFF	Battery voltage
				Interior room lamp ON	0 V
65 (V)	Ground	All doors LOCK	Output	All doors LOCK (Actuator is activated)	Battery voltage
				All doors Other then LOCK (Actuator is not activated)	0 V
66 (G)	Ground	Passenger door and rear door UNLOCK	Output	Passenger door and rear door UNLOCK (Actuator is activated)	Battery voltage
				Passenger door and rear door Other then UNLOCK (Actuator is not activated)	0 V
67 (B)	Ground	Ground	Output	Ignition switch ON	0 V
68 (L)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	Battery voltage
69 (R) <sup>*2</sup> (P) <sup>*3</sup>	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	Battery voltage
70 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage

**NOTE:**

- \*1: Except for Mexico
- \*2: Without anti-pinch system
- \*3: With anti-pinch system

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]

## Wiring Diagram - BCM -

INFOID:00000003049972



2007/07/13

JCMWM1029G




# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]

- ◊XM◊ : Except for Mexico
- ◊SR◊ : With sunroof
- ◊PS◊ : With power seat
- ◊AN◊ : With anti-pinch system
- ◊VM◊ : With vanity mirror lamp




\*: This connector is not shown in "Harness Layout".

JCMWM1031G

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]



JCMWM1032GI

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- EXL
- M
- N
- O
- P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]

## BCM (BODY CONTROL MODULE)

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TK16FW



12	13	14	11	1	2	3	4	5	6		
10	9	8	7	14	11	1	2	3	4	5	6

Terminal No.	Color of Wire	Signal Name [Specification]
1	V	INPUT 1
2	B	INPUT 2
3	L	INPUT 3
4	GR	INPUT 4
5	BR	INPUT 5
6	P	OUTPUT 1
7	R	OUTPUT 2
8	G	OUTPUT 5
9	Y	OUTPUT 4
10	W	OUTPUT 3

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA08FB-FHA6-SA



56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			

Terminal No.	Color of Wire	Signal Name [Specification]
56	Y	BATTERYSAVEROUTPUT
57	G	BAT FUSE
59	L	D/L UNLOCK DR
60	BR	FLASHER OUT PUT (LEFT)
61	GR	FLASHER OUT PUT (RIGHT)
63	R	ROOMLAMPOUTPUT
65	V	D/L LOCK ALL
66	G	D/L UNLOCK OTHER
67	B	GND
68	L	POWER WDM OUTPUT(RAP)
68	R	POWER WDM OUTPUT(BAT)(Without electrical system)
68	P	POWER WDM OUTPUT(BAT)(With electrical system)
70	Y	BAT FL

Terminal No.	Color of Wire	Signal Name [Specification]
12	P	DR SW AS
13	LG	DR SW RR
15	O	TPMS MODE TRIGGER SW
18	O	KEYLESS TUNER SEUS GND
18	V	KEYLESS TUNER POWER
20	GR	KEYLESS TUNER SIGNAL
21	G	IMMOBI ANT(CLOCK)
23	B	SECURITY IND OUTPUT
23	BR	IMMOBI ANT(RX, TX)
27	Y	AIRCORN SW
28	LG	BLOWER FAN SW
28	W	HAZARD SW
29	G	BACK DOOR OPEN SW
32	BR	OUTPUT 5
33	GR	OUTPUT 4
34	L	OUTPUT 3
35	B	OUTPUT 2
36	V	OUTPUT 1
37	LG	KEY SW
38	G	IGN
38	L	KEY CYC UNLOCK
38	R	KEY CYC LOCK SW
9	R	BRAKE SW
10	SB	RR DEF SW
11	SB	ACC

Connector No.	M66
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA08FW-FHA6-SA



41	42	43	44	45	46	47	48	49
50	51	52	53	54	55			

Terminal No.	Color of Wire	Signal Name [Specification]
43	V	BACK DOOR SW
44	B	RR WIP AUTO STOP
45	P	CDL LOCK SW
46	BR	CDL UNLOCK SW
47	W	DR SW DR
48	GR	DR SW RL
49	L	LUGGAGE LAMP OUTPUT
53	V	BACK DOOR PEPPER OUTPUT
55	SB	RR WIP MTR OUT

## Fail Safe

### REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper auto stop signal.

When the rear wiper auto stop signal does not change more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

JCMWM1033G

INFOID:000000003049973

# BCM (BODY CONTROL MODULE)

[XENON TYPE]

## < ECU DIAGNOSIS >

1. Pass more than 1 minute after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

### HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.  
 BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

**NOTE:**

The blinking speed is normal while activating the hazard warning lamp.

### DTC Inspection Priority Chart

INFOID:000000003049974

Priority	DTC
1	U1000: CAN COMM CIRCUIT
2	C1735: IGN CIRCUIT OPEN
3	<ul style="list-style-type: none"> <li>• C1704: LOW PRESSURE FL</li> <li>• C1705: LOW PRESSURE FR</li> <li>• C1706: LOW PRESSURE RR</li> <li>• C1707: LOW PRESSURE RL</li> <li>• C1708: [NO DATA] FL</li> <li>• C1709: [NO DATA] FR</li> <li>• C1710: [NO DATA] RR</li> <li>• C1711: [NO DATA] RL</li> <li>• C1712: [CHECKSUM ERR] FL</li> <li>• C1713: [CHECKSUM ERR] FR</li> <li>• C1714: [CHECKSUM ERR] RR</li> <li>• C1715: [CHECKSUM ERR] RL</li> <li>• C1716: [PRESS DATA ERR] FL</li> <li>• C1717: [PRESS DATA ERR] FR</li> <li>• C1718: [PRESS DATA ERR] RR</li> <li>• C1719: [PRESS DATA ERR] RL</li> <li>• C1720: [CODE ERR] FL</li> <li>• C1721: [CODE ERR] FR</li> <li>• C1722: [CODE ERR] RR</li> <li>• C1723: [CODE ERR] RL</li> <li>• C1724: [BATT VOLT LOW] FL</li> <li>• C1725: [BATT VOLT LOW] FR</li> <li>• C1726: [BATT VOLT LOW] RR</li> <li>• C1727: [BATT VOLT LOW] RL</li> <li>• C1729: VHCL SPEED SIG ERR</li> </ul>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL

### DTC Index

INFOID:000000003049975

**NOTE:**

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
  - 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

DTC	Tire pressure monitor warning lamp ON	Reference
U1000: CAN COMM CIRCUIT	—	<a href="#">BCS-35</a>
C1704: LOW PRESSURE FL	×	<a href="#">WT-14</a>
C1705: LOW PRESSURE FR	×	
C1706: LOW PRESSURE RR	×	
C1707: LOW PRESSURE RL	×	

M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[XENON TYPE]

DTC	Tire pressure monitor warning lamp ON	Reference
C1708: [NO DATA] FL	×	<a href="#">WT-16</a>
C1709: [NO DATA] FR	×	
C1710: [NO DATA] RR	×	
C1711: [NO DATA] RL	×	
C1712: [CHECKSUM ERR] FL	×	<a href="#">WT-19</a>
C1713: [CHECKSUM ERR] FR	×	
C1714: [CHECKSUM ERR] RR	×	
C1715: [CHECKSUM ERR] RL	×	
C1716: [PRESS DATA ERR] FL	×	<a href="#">WT-22</a>
C1717: [PRESS DATA ERR] FR	×	
C1718: [PRESS DATA ERR] RR	×	
C1719: [PRESS DATA ERR] RL	×	
C1720: [CODE ERR] FL	×	<a href="#">WT-24</a>
C1721: [CODE ERR] FR	×	
C1722: [CODE ERR] RR	×	
C1723: [CODE ERR] RL	×	
C1724: [BATT VOLT LOW] FL	—	<a href="#">WT-27</a>
C1725: [BATT VOLT LOW] FR	—	
C1726: [BATT VOLT LOW] RR	—	
C1727: [BATT VOLT LOW] RL	—	
C1729: VHCL SPEED SIG ERR	×	<a href="#">WT-30</a>
C1735: IGN CIRCUIT OPEN	—	<a href="#">BCS-36</a>

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[XENON TYPE]

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:000000003049977

### VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
MOTOR FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	1 - 4
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST or 2ND		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND		On
HL HI REQ	Lighting switch OFF		Off
	Lighting switch HI (Light is illuminated)		On
FR FOG REQ <b>NOTE:</b> This item is monitored only on the vehicle with front fog lamp.	Lighting switch 2ND	Front fog lamp switch OFF	Off
		Front fog lamp switch ON	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
ST RLY REQ <b>NOTE:</b> Vehicle without Intelligent Key system indicates only "ON", and it does not change.	When Intelligent Key is outside the vehicle, and the push switch is pushed		Off
	When Intelligent Key is inside the vehicle, and the push switch is pushed		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
RR DEF REQ	Ignition switch ON	Rear window defogger switch OFF	Off
		Rear window defogger switch ON (Rear window defogger is operating)	On
OIL P SW	Ignition switch OFF, ACC or engine running		Open
	Ignition switch ON		Close
DTRL REQ <b>NOTE:</b> This item is monitored only on the vehicle with the daytime running light system.	Daytime running light system is not operated.		Off
	Daytime running light system is operated.		On

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[XENON TYPE]

Monitor Item	Condition	Value/Status
HOOD SW <b>NOTE:</b> This item is monitored only the vehicle for Mexico.	Close the hood	Off
	Open the hood	On
THFT HRN REQ	Not operation	Off
	Horn is activated with vehicle security system or panic alarm system.	On
HORN CHIRP	Not operation	Off
	Horn is activated with key fob LOCK operation.	On

## TERMINAL LAYOUT



## PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (G)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[XENON TYPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
3 (O)	Ground	Starter relay power supply	Output	When engine is clanking		Battery voltage
				When engine is not clanking		0 V
4 (W)	Ground	Cooling fan relay-1 power supply	Output	Cooling fan operation	OFF	0 V
					MID or HI	Battery voltage
5 (R)	Ground	Ignition switch START	Input	Ignition switch OFF, ACC or ON		0 V
				Ignition switch START		Battery voltage
6 (BR)	Ground	Battery power supply (Cooling fan relay)	Input	Ignition switch OFF		Battery voltage
7 (P)	Ground	Cooling fan motor-2 (HI) ground	—	Cooling fan operation	OFF	Battery voltage
					HI	0 V
8 (G)	Ground	Cooling fan relay-2 power supply	Output	Cooling fan operation	OFF	0 V
					HI	Battery voltage
11 (B)	Ground	Ground	—	Ignition switch ON		0 V
12 (O)	Ground	Rear window defogger relay power supply	Output	Ignition switch ON	Rear window defogger switch OFF	0 V
					Rear window defogger switch ON	Battery voltage
15*1 (SB)	Ground	Daytime running light relay control	Output	Daytime running light system	Not operated	Battery voltage
					Operated	0 V
16*2 (Y)	Ground	Front fog lamp (LH)	Output	Lighting switch 2ND	Front fog lamp switch OFF	0 V
					Front fog lamp switch ON	Battery voltage
17*2 (W)	Ground	Front fog lamp (RH)	Output	Lighting switch 2ND	Front fog lamp switch OFF	0 V
					Front fog lamp switch ON	Battery voltage
18 (L)	Ground	Headlamp LO (LH)	Output	Lighting switch OFF		0 V
				Lighting switch 2ND		Battery voltage
20 (SB)	Ground	Headlamp LO (RH)	Output	Lighting switch OFF		0 V
				Lighting switch 2ND		Battery voltage
21 (G)	Ground	Headlamp HI (LH)	Output	Lighting switch OFF		0 V
				<ul style="list-style-type: none"> <li>• Lighting switch 2ND and HI</li> <li>• Lighting switch PASS</li> </ul>		Battery voltage
22 (LG)	Ground	Headlamp HI (RH)	Output	Lighting switch OFF		0 V
				<ul style="list-style-type: none"> <li>• Lighting switch 2ND and HI</li> <li>• Lighting switch PASS</li> </ul>		Battery voltage
23 (W)	Ground	Oil pressure switch	Input	Ignition switch ON	Engine stopped	0 V
					Engine running	Battery voltage
24 (Y)	Ground	Front wiper auto stop	Input	Ignition switch ON	Front wiper stop position	0 V
					Any position other than front wiper stop position	Battery voltage
25 (B)	Ground	Ground	—	Ignition switch ON		0 V
26 (P)	—	CAN-L	Input/Output	—		—
27 (L)	—	CAN-H	Input/Output	—		—

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[XENON TYPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
31 (LG)	Ground	Cooling fan relay-4 control	Output	Cooling fan operation	OFF	Battery voltage
					LO	0 - 1.0 V
32 (V)	Ground	ETC relay control	Input	After passing approximately 2 seconds or more after turning the ignition switch from ON to OFF		Battery voltage
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• For approximately 2 seconds after turning ignition switch from ON to OFF</li> </ul>		0 - 1.0 V
33 (GR)	Ground	Fuel pump relay control	Input	Ignition switch OFF		0 V
				Ignition switch ON	Engine stopped	Battery voltage
					Engine running	0.8 V
34*3 (W)	Ground	Hood switch	Input	Close the hood		Battery voltage
				Open the hood		0 V
37 (R)	Ground	Tail, license plate lamps and illuminations	Output	Lighting switch OFF		0 V
				Lighting switch 1ST		Battery voltage
38 (R)	Ground	Parking lamp (LH)	Output	Lighting switch OFF		0 V
				Lighting switch 1ST		Battery voltage
39 (GR)	Ground	Parking lamp (RH)	Output	Lighting switch OFF		0 V
				Lighting switch 1ST		Battery voltage
40 (BR)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC		0 V
				Ignition switch ON		Battery voltage
41 (O)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC		0 V
				Ignition switch ON		Battery voltage
42 (L)	Ground	Front wiper HI	Output	Ignition switch ON	Front wiper switch OFF	0 V
					Front wiper switch HI	Battery voltage
43 (G)	Ground	Front wiper LO	Output	Ignition switch ON	Front wiper switch OFF	0 V
					Front wiper switch LO	Battery voltage
45 (Y)	Ground	Starter relay power supply	Input	Ignition switch ON	Selector lever "P" or "N"	Battery voltage
					Selector lever in any position other than "P" or "N"	0 V
46 (W)	Ground	Fuel pump relay power supply	Output	<ul style="list-style-type: none"> <li>• Ignition switch OFF or ACC</li> <li>• After passing approximately 1 second or more after turning the ignition switch ON</li> </ul>		0 V
				<ul style="list-style-type: none"> <li>• For approximately 1 second after turning the ignition switch ON</li> <li>• Engine running</li> </ul>		Battery voltage
47 (BR)	Ground	ECM relay power supply	Output	After passing approximately 4 seconds or more after turning the ignition switch from ON to OFF		0 V
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• For approximately 4 seconds after turning ignition switch from ON to OFF</li> </ul>		Battery voltage
48 (R)	Ground	ECM relay power supply	Output	After passing approximately 4 seconds or more after turning the ignition switch from ON to OFF		0 V
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• For approximately 4 seconds after turning ignition switch from ON to OFF</li> </ul>		Battery voltage
50 (G)	Ground	Cooling fan relay-5 control	Output	Cooling fan operation	OFF	Battery voltage
					MID or HI	0 - 1.0 V

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[XENON TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
51 (L)	Ground	ECM relay control	Output	After passing approximately 4 seconds or more after turning the ignition switch from ON to OFF	Battery voltage	
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• For approximately 4 seconds after turning ignition switch from ON to OFF</li> </ul>	0 - 1.0 V	
52 (P)	Ground	ETC relay power supply	Output	After passing approximately 2 seconds or more after turning the ignition switch from ON to OFF	0 V	
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• For approximately 2 seconds after turning ignition switch from ON to OFF</li> </ul>	Battery voltage	
55 (O)	Ground	A/C relay power supply	Output	Engine stopped	0 V	
				Engine running	A/C switch OFF	0 V
					A/C switch ON (A/C compressor is operating)	Battery voltage
56 (L)	Ground	Ignition switch ON	Input	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	Battery voltage	
57 (V)	Ground	Horn relay control	Output	The horn is not activated	Battery voltage	
				The horn is activated	0 V	
58 (LG)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	Battery voltage	
59 (BR)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	Battery voltage	
60 (SB)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	Battery voltage	
61 (R)	Ground	ECM power supply	Output	Ignition switch OFF	Battery voltage	

\*1: With daytime running light system

\*2: With front fog lamp system

\*3: For Mexico

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[XENON TYPE]

## Wiring Diagram - IPDM E/R -

INFOID:00000003049978




2007/07/13

JCMWM1037G

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[XENON TYPE]



JCMWM1038GI


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[XENON TYPE]



JCMWM1039G

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[XENON TYPE]

**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**

Connector No.	E9
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	LOPE-MC




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	G	-

Connector No.	E10
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	MOBFW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
3	O	-
4	W	-
5	R	-
6	BR	-
7	P	-
8	G	-


Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	MOBFW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
11	B	-
12	O	-

Connector No.	E12
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS30FBR-CS

Terminal No.	Color of Wire	Signal Name [Specification]
15	SB	-
16	Y	-
17	W	-
18	L	-
20	SB	-
21	G	-
22	LG	-

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH12FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
23	W	-
24	Y	-
25	B	-
26	P	-
27	L	-
31	LG	-
32	V	-
33	GR	-
34	W	-


Connector No.	E14
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS12FBR-CS




Terminal No.	Color of Wire	Signal Name [Specification]
37	R	-
38	R	-
39	GR	-
40	BR	-
41	O	-
42	L	-
43	G	-
45	Y	-
46	W	-

Connector No.	E15
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS18FW-CS

Terminal No.	Color of Wire	Signal Name [Specification]
47	BR	-
48	R	-
50	G	-
51	L	-
52	P	-
55	O	-
56	SB	- [For North America]
57	V	- [Except for North America]
58	LG	-
59	BR	-
60	SB	-
61	R	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

## Fail Safe

### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If no CAN communication is available with ECM

JCMWM1040G1

INFOID:000000003049979

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[XENON TYPE]

Control part	Fail-safe in operation
Cooling fan	<ul style="list-style-type: none"> <li>The cooling fan relay-1, the cooling fan relay-2, the cooling fan relay-3 and the cooling fan relay-5 turn ON when the ignition switch is turned ON</li> <li>The cooling fan relay-1, the cooling fan relay-2, the cooling fan relay-3 and the cooling fan relay-5 turn OFF when the ignition switch is turned OFF</li> <li>Cooling fan relay-4 OFF</li> </ul>
A/C compressor	A/C relay OFF

If no CAN communication is available with BCM

Control part	Fail-safe in operation
Headlamp	<ul style="list-style-type: none"> <li>The headlamp low relay turns ON when the ignition switch is turned ON</li> <li>The headlamp low relay turns OFF when the ignition switch is turned OFF</li> <li>Headlamp high relay OFF</li> </ul>
<ul style="list-style-type: none"> <li>Parking lamps</li> <li>License plate lamps</li> <li>Tail lamps</li> <li>Illuminations</li> </ul>	<ul style="list-style-type: none"> <li>The tail lamp relay and the daytime running light relay* turn ON when the ignition switch is turned ON</li> <li>The tail lamp relay and the daytime running light relay* turn OFF when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>The front wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.</li> </ul>
Front fog lamps	Front fog lamp relay OFF
Starter motor	Starter relay OFF
Rear window defogger	Rear window defogger relay OFF
Horn	Horn relay OFF

**NOTE:**

\*: With daytime running light system

## IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors status of ignition relay by the voltage at ignition relay contact circuit inside it.
- IPDM E/R judges that the ignition relay is error, if status of the ignition relay and ignition switch ON signal (CAN).
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay and daytime running light relay\* for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Detection		IPDM E/R judgment	Operation
Ignition switch ON signal	Ignition relay		
ON	ON	Ignition relay normal	—
OFF	OFF	Ignition relay normal	—
OFF	ON	Ignition relay ON stuck	Turn on the tail lamp relay and daytime running light relay* for 10 minutes
ON	OFF	Ignition relay OFF stuck	Detect DTC "B2099: IGN RELAY OFF"

**NOTE:**

\*: With daytime running light system

## FRONT WIPER CONTROL

IPDM E/R detects the front wiper stop position with the front wiper auto stop signal.

When the front wiper auto stop signal is in the conditions listed below, IPDM E/R repeats a front wiper 10 seconds operation and 20 seconds stop five times.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[XENON TYPE]

Ignition switch	Front wiper switch	Front wiper auto stop signal
ON	OFF	The front wiper auto stop signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper auto stop signal does not change for 10 seconds.

**NOTE:**

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

## DTC Index

INFOID:000000003049980

CONSULT display	Fail-safe	Timing <sup>NOTE</sup>		Reference page
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	×	CRNT	PAST	<a href="#">PCS-13</a>
B2099: IGN RELAY OFF	—	CRNT	PAST	<a href="#">PCS-14</a>

**NOTE:**

The details of time display are as follows.

- CRNT: The malfunctions that are detected now.
- PAST: The number is indicated when it is normal at present and a malfunction was detected in the past.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## SYMPTOM DIAGNOSIS

### EXTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000001722042

**CAUTION:**

Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp (HI) is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Halogen bulb (HI)</li> <li>• Harness between IPDM E/R and the headlamp high</li> <li>• IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-30</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to <a href="#">EXL-109</a> .	
Headlamp (HI) is not turned OFF.	When ignition switch is turned ON.		
	When ignition switch is turned OFF.	IPDM E/R	—
High beam indicator lamp is not turned ON. [The headlamp (HI) is turned ON.]		Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Data monitor "HI-BEAM IND"</li> <li>• BCM (HEAD LAMP)</li> <li>• Active test "HEADLAMP"</li> </ul>
Headlamp (LO) is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Xenon bulb (LO)</li> <li>• Harness between IPDM E/R and the headlamp low</li> <li>• IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-32</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-110</a> .	
Headlamp (LO) is not turned OFF.	When ignition switch is turned ON.		
	When ignition switch is turned OFF.	IPDM E/R	—
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Front fog lamp bulb</li> <li>• Harness between IPDM E/R and the front fog lamp</li> <li>• Front fog lamp</li> <li>• IPDM E/R</li> </ul>	Front fog lamp circuit Refer to <a href="#">EXL-36</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-112</a> .	
Front fog lamp is not turned ON.			
Parking lamp is not turned ON.		<ul style="list-style-type: none"> <li>• Parking lamp bulb</li> <li>• Harness between IPDM E/R and the front combination lamp</li> <li>• Front combination lamp</li> <li>• IPDM E/R</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-38</a> .
Tail lamp is not turned ON.		<ul style="list-style-type: none"> <li>• Tail lamp bulb</li> <li>• Harness between IPDM E/R and the rear combination lamp</li> <li>• Rear combination lamp</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-44</a> .
License plate lamp is not turned ON.		<ul style="list-style-type: none"> <li>• License plate lamp bulb</li> <li>• Harness between IPDM E/R and the license plate lamp</li> <li>• License plate lamp</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-46</a> .

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom	Possible cause	Inspection item	
Tail lamp and the license plate lamp are not turned ON.	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Harness between IPDM E/R and the rear combination lamp</li> <li>• IPDM E/R</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-46</a> .	
<ul style="list-style-type: none"> <li>• Parking lamp, the tail lamp and the license plate lamp are not turned ON.</li> <li>• Parking lamp, the tail lamp and the license plate lamp are not turned OFF.</li> </ul> (Each illumination is turned ON/OFF.)	<b>Symptom diagnosis</b> "PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-111</a> .		
Tail lamp indicator is not turned ON. (Parking, tail lamps are turned ON.)	Combination meter	<ul style="list-style-type: none"> <li>• Combination meter Data monitor "LIGHT IND"</li> <li>• BCM (HEAD LAMP) Active test "TAIL LAMP"</li> </ul>	
Turn signal lamp does not blink.	Indicator lamp is normal. (Applicable side performs the high flasher activation.)	<ul style="list-style-type: none"> <li>• Harness between BCM and each turn signal lamp</li> <li>• Turn signal lamp bulb</li> </ul> Turn signal circuit Refer to <a href="#">EXL-40</a> .	
	Indicator lamp is included.	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between the combination switch and BCM</li> <li>• BCM</li> </ul> Combination switch Refer to <a href="#">BCS-42</a> .	
Turn signal indicator lamp does not blink. (Turn signal indicator lamp is normal.)	One side	Combination meter  —	
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn signal indicator lamp signal</li> <li>- BCM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Combination meter Data monitor "TURN IND"</li> <li>• BCM (FLASHER) Active test "FLASHER"</li> </ul>
	Both sides (Only when activating hazard warning lamp with the ignition switch OFF)	<ul style="list-style-type: none"> <li>• Combination meter power supply and the ground circuit</li> <li>• Combination meter</li> </ul>	Combination meter Power supply and the ground circuit Refer to <a href="#">MWI-41</a> .
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate.</li> <li>• Hazard warning lamp continues activating.</li> </ul> (Turn signal is normal.)	<ul style="list-style-type: none"> <li>• Hazard switch</li> <li>• Harness between the hazard switch and BCM</li> <li>• BCM</li> </ul>	Hazard switch Refer to <a href="#">EXL-42</a> .	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

---

### NORMAL OPERATING CONDITION

#### Description

*INFOID:000000001720630*

#### XENON HEADLAMP

- Brightness and the color of light may change slightly immediately after turning the headlamp ON until the xenon bulb becomes stable. This is normal.
- Illumination time lag may occur between right and left. This is normal.

# BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

### Description

INFOID:000000001720631

Both side headlamps (HI) are not turned ON when setting to the lighting switch HI or PASS.

### Diagnosis Procedure

INFOID:000000001720632

#### 1.COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-66. "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

 CONSULT-III DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R data monitor item.

2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2ND)	HI or PASS	On
		LO	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-67. "Exploded View"](#).

#### 3.HEADLAMP (HI) CIRCUIT INSPECTION

Check the headlamp (HI) circuit. Refer to [EXL-30. "Component Function Check"](#).

Is the headlamp (HI) circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

### Description

INFOID:000000001720633

Both side headlamps (LO) are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000001720634

#### 1. CHECK COMBINATION SWITCH

Check the combination switch. Refer to [BCS-66, "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2. CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

##### ⓑCONSULT-III DATA MONITOR

1. Select "HL LO REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
HL LO REQ	Lighting switch	2ND	On
		OFF	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-67, "Exploded View"](#).

#### 3. HEADLAMP (LO) CIRCUIT INSPECTION

Check the headlamp (LO) circuit. Refer to [EXL-32, "Component Function Check"](#).

Is the headlamp (LO) circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

# PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

### Description

INFOID:000000001722049

The parking, license plate, tail lamps and each illumination are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000001722050

#### 1.CHECK FUSE

Check that the following fuse is fusing.

Unit	Location	Fuse No.	Capacity
Parking lamp	IPDM E/R	#46	10 A
<ul style="list-style-type: none"><li>• Tail lamp</li><li>• License plate lamp</li></ul>		#45	10 A

#### Is the fuse fusing?

- YES >> Repair the applicable circuit. And then replace the fuse.  
NO >> GO TO 2.

#### 2.COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-66. "Symptom Table"](#).

#### Is the combination switch normal?

- YES >> GO TO 3.  
NO >> Repair or replace the malfunctioning part.

#### 3.CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

##### CONSULT-III DATA MONITOR

1. Select "TAIL & CLR REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
TAIL & CLR REQ	Lighting switch	1ST	On
		OFF	Off

#### Is the item status normal?

- YES >> GO TO 4.  
NO >> Replace BCM. Refer to [BCS-67. "Exploded View"](#).

#### 4.TAIL LAMP CIRCUIT INSPECTION

Check the tail lamp circuit. Refer to [EXL-44. "Component Function Check"](#).

#### Is the tail lamp circuit normal?

- YES >> Replace IPDM E/R.  
NO >> Repair or replace the malfunctioning part.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

## BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

### Description

INFOID:000000001716469

The front fog lamps are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000001716470

#### 1.CHECK FUSE

Check that the following fuse is fusing.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#65	15 A

##### Is the fuse fusing?

- YES >> Repair the applicable circuit. And then replace the fuse.
- NO >> GO TO 2.

#### 2.COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-66, "Symptom Table"](#).

##### Is the combination switch normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning part.

#### 3.CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

##### ⓑCONSULT-III DATA MONITOR

1. Select "FR FOG REQ" of IPDM E/R data monitor item.
2. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition	Monitor status
FR FOG REQ	Front fog lamp switch (With lighting switch 1ST)	ON On
		OFF Off

##### Is the item status normal?

- YES >> GO TO 4.
- NO >> Replace BCM. Refer to [BCS-67, "Exploded View"](#).

#### 4.FRONT FOG LAMP CIRCUIT INSPECTION

Check the front fog lamp circuit. Refer to [EXL-36, "Component Function Check"](#).

##### Is the front fog lamp circuit normal?

- YES >> Replace IPDM E/R.
- NO >> Repair or replace the malfunctioning part.

PRECAUTION

PRECAUTIONS  
FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003248992

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

FOR USA AND CANADA : Precautions For Xenon Headlamp Service

INFOID:000000001716471

**WARNING:**

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector. (Turning it ON outside the lamp case may cause fire or visual impairments.)
- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

**CAUTION:**

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003248993

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# PRECAUTIONS

< PRECAUTION >

[XENON TYPE]

- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the “SRS AIRBAG”.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

FOR MEXICO : Precautions For Xenon Headlamp Service

INFOID:000000003248994

## **WARNING:**

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector. (Turning it ON outside the lamp case may cause fire or visual impairments.)
- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

## **CAUTION:**

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

# HEADLAMP AIMING ADJUSTMENT

< ON-VEHICLE MAINTENANCE >

[XENON TYPE]

## ON-VEHICLE MAINTENANCE

### HEADLAMP AIMING ADJUSTMENT

#### Description

INFOID:000000001716472

#### PREPARATION BEFORE ADJUSTING

##### NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the luggage room.)

##### NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.


- Wipe out dirt on the headlamp.

##### CAUTION:

**Never use organic solvent (thinner, gasoline etc.)**

- Ride alone on the driver seat.
- Headlamp aiming switch sets to "0".

#### AIMING ADJUSTMENT SCREW



A. Headlamp RH (UP/DOWN) adjustment screw

B. Headlamp LH (UP/DOWN) adjustment screw

↔: Vehicle center

# HEADLAMP AIMING ADJUSTMENT

< ON-VEHICLE MAINTENANCE >

[XENON TYPE]

Adjustment screw		Screw driver rotation	Facing direction
A	Headlamp RH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP
B	Headlamp LH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP

## Aiming Adjustment Procedure

INFOID:000000001888445

1. Place the screen.

**NOTE:**

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the headlamp bulb center and the screen.

3. Start the engine. Turn the headlamp (LO) ON.

**NOTE:**

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.

**CAUTION:**

**Never cover the lens surface with a tape etc. The lens is made of resin.**

4. Measure the distance (X) between the horizontal center line of headlamp (H) and the cutoff line (A) within the light axis measurement range (R) from the vertical center line ahead of headlamp (V).

**Light axis measurement range (R) : 350 ± 175 mm (13.78 ± 6.89 in)**

Low beam distribution on the screen

5. Adjust the cutoff line height (X) with the aiming adjustment screw so as to enter in the adjustment range (M–N) according to the horizontal center line of headlamp (H).

unit: mm (in)

Side view

# HEADLAMP AIMING ADJUSTMENT

< ON-VEHICLE MAINTENANCE >

[XENON TYPE]

Distance between the headlamp center and the screen (L) : 10 m (32.8 ft)

A

B

C

D

E

F

G

H

I

J

K

**EXL**

M

N

O

P

# FRONT FOG LAMP AIMING ADJUSTMENT

< ON-VEHICLE MAINTENANCE >

[XENON TYPE]

## FRONT FOG LAMP AIMING ADJUSTMENT

### Description

INFOID:000000001716475

### PREPARATION BEFORE ADJUSTING

#### NOTE:

- For details, refer to the regulations in your own country.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the luggage room.)

#### NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.

- Wipe out dirt on the headlamp.

#### CAUTION:

**Never use organic solvent (thinner, gasoline etc.)**

- Ride alone on the driver seat.

### AIMING ADJUSTMENT SCREW

- Turn the aiming adjusting screw for adjustment.


A: UP

B: DOWN

- For the position and direction of the adjusting screw, refer to the figure.

#### NOTE:

A screwdriver or hexagonal wrench [6 mm (0.24 in)] can be used for adjustment.



### Aiming Adjustment Procedure

INFOID:000000001716476

1. Place the screen.

#### NOTE:

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the front fog lamp center and the screen.

3. Start the engine. Illuminate the front fog lamp.

#### CAUTION:


**Never cover the lens surface with a tape etc. The lens is made of resin.**

#### NOTE:

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.

4. Adjust the cutoff line height (A) with the aiming adjustment screw so that the distance (X) between the horizontal center line of front fog lamp (H) and (A) becomes 130 mm (5.12 in).

Front fog lamp light distribution on the screen



# FRONT FOG LAMP AIMING ADJUSTMENT

< ON-VEHICLE MAINTENANCE >

[XENON TYPE]

- A : Cutoff line
- B : High illuminance area
- H : Horizontal center line of front fog lamp
- V : Vertical center line of front fog lamp
- X : Cutoff line height

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# FRONT COMBINATION LAMP

< ON-VEHICLE REPAIR >

[XENON TYPE]


## ON-VEHICLE REPAIR

### FRONT COMBINATION LAMP

Exploded View

INFOID:000000001716479

#### REMOVAL



1. Front combination lamp

#### DISASSEMBLY



- |  |   |                               |
|--|---|-------------------------------|
| 1. Front turn signal/parking (side marker) lamp bulb | 2. Front turn signal/parking (side marker) lamp bulb socket | 3. Resin cap                  |
| 4. Seal packing                                      | 5. Xenon bulb socket (Starter)                              | 6. Xenon bulb (LO)            |
| 7. Retaining spring                                  | 8. Headlamp aiming motor                                    | 9. Seal packing               |
| 10. HID control unit (Inverter)                      | 11. Halogen bulb (HI)                                       | 12. Headlamp housing assembly |

Refer to [GI-4, "Components"](#) for symbols in the figure.

# FRONT COMBINATION LAMP

< ON-VEHICLE REPAIR >

[XENON TYPE]

## Removal and Installation

INFOID:000000001716480

### REMOVAL

#### CAUTION:

Disconnect the battery negative terminal or the fuse.

1. Remove front bumper fascia. Refer to [EXT-13, "Exploded View"](#).
2. Remove the headlamp mounting bolts and nuts.
3. Remove the mounting stud of the headlamp outside from front fender.
4. Pull out the headlamp assembly forward the vehicle.
5. Disconnect the connector before removing the headlamp assembly.

### INSTALLATION

Install in the reverse order of removal.

#### NOTE:

After installation, perform aiming adjustment. Refer to [EXL-115, "Description"](#).

### Replacement

INFOID:000000001716481

#### CAUTION:


- Disconnect the battery negative terminal or the fuse.
- After installing the bulb, install the resin cap and the bulb socket securely for watertightness.

### HEADLAMP BULB (LO)

1. Remove the air duct\*. Keep a service area.  
\*When replace a left.
2. Rotate the resin cap counterclockwise and unlock it.
3. Rotate the bulb socket counterclockwise and unlock it.
4. Unlock the retaining spring. And remove the bulb from the headlamp housing assembly.

#### CAUTION:

Never break the xenon bulb ceramic tube when replacing the bulb.



### HEADLAMP BULB (HI)

1. Rotate the bulb socket counterclockwise and unlock it.
2. Disconnect the connector. And remove the bulb.

### FRONT TURN SIGNAL/PARKING (SIDE MARKER) LAMP BULB

1. Rotate the bulb socket counterclockwise and unlock it.
2. Remove the bulb from the bulb socket.

### Disassembly and Assembly

INFOID:000000001716482

### DISASSEMBLY

1. Rotate the resin cap counterclockwise and unlock it.
2. Rotate the xenon bulb socket counterclockwise and unlock it.
3. Unlock the retaining spring. And remove the xenon bulb (LO).
4. Remove the HID control unit installation screw.
5. Remove the screw. Disconnect the connector from HID control unit.
6. Remove the xenon bulb socket from headlamp housing assembly.
7. Rotate the halogen bulb (HI) counterclockwise and unlock it.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL

## FRONT COMBINATION LAMP

[XENON TYPE]

< ON-VEHICLE REPAIR >

---

8. Remove the halogen bulb from headlamp housing assembly.
9. Rotate the front turn signal/parking (side marker) lamp bulb socket counterclockwise and unlock it.
10. Remove the bulb from the front turn signal/parking (side marker) lamp bulb socket.

### ASSEMBLY

Assemble in the reverse order of disassembly.

#### **CAUTION:**

- **Install HID control unit securely.**
- **After installing the bulb, install the resin cap and the bulb socket securely for watertightness.**

# FRONT FOG LAMP


< ON-VEHICLE REPAIR >

[XENON TYPE]

## FRONT FOG LAMP

### Exploded View

INFOID:000000001716483



1. Front fog lamp bracket
2. Front fog lamp

### Removal and Installation

INFOID:000000001716484

**CAUTION:**  
Disconnect the battery negative terminal or the fuse.

#### REMOVAL

1. Remove the front fender protector. Keep a service area. Refer to [EXT-22, "Exploded View"](#).
2. Remove the front fog lamp connector.
3. Remove the screw. And remove the front fog lamp.
4. Remove the screw. And remove the front fog lamp bracket.

#### INSTALLATION

Installation is the reverse order of removal.

**NOTE:**  
After installation, perform aiming adjustment. Refer to [EXL-118, "Description"](#)


### Replacement

INFOID:000000001716485

**CAUTION:**  
Disconnect the battery negative terminal or the fuse.

#### FRONT FOG LAMP BULB

1. Remove the front fender protector. Keep the service area. Refer to [EXT-22, "Exploded View"](#).
2. Remove the front fog lamp bulb connector (1).
3. Rotate the bulb (2) counterclockwise and unlock it.



# LIGHTING & TURN SIGNAL SWITCH


< ON-VEHICLE REPAIR >

[XENON TYPE]

## LIGHTING & TURN SIGNAL SWITCH

### Exploded View

INFOID:000000001716491



- 1. Lighting & turn signal switch
- A. Pawl

### Removal and Installation

INFOID:000000001716492

#### REMOVAL

1. Remove steering column cover. Refer to [IP-12. "Exploded View"](#).
2. While pressing pawls, pull the lighting & turn signal switch. And disconnect from the switch base.

#### INSTALLATION

Installation is the reverse order of removal.

# HAZARD SWITCH


< ON-VEHICLE REPAIR >

[XENON TYPE]

## HAZARD SWITCH

### Exploded View

INFOID:000000001716496



- 1. Hazard switch
- A. Pawls

### Removal and Installation

INFOID:000000001716497

#### REMOVAL

1. Remove the cluster lid C. Refer to [IP-12, "Exploded View"](#).
2. Push the pawl. And remove the hazard switch.

#### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HEADLAMP AIMING SWITCH


< ON-VEHICLE REPAIR >

[XENON TYPE]

## HEADLAMP AIMING SWITCH

Exploded View

INFOID:000000001716709



1. Headlamp aiming switch
- A. Pawls

## Removal and Installation

INFOID:000000001716710

### REMOVAL

1. Remove the switch panel. Refer to [IP-12, "Exploded View"](#).
2. Widen the pawl. And remove the headlamp aiming switch.

### INSTALLATION

Install in the reverse order of removal.

# REAR COMBINATION LAMP

< ON-VEHICLE REPAIR >


[XENON TYPE]

## REAR COMBINATION LAMP

### Exploded View

INFOID:000000001716502


### REMOVAL



1. Seal packing
2. Rear combination lamp

Refer to [GI-4, "Components"](#) for symbols in the figure.

### DISASSEMBLY



1. Rear turn signal lamp bulb socket
2. Rear turn signal lamp bulb
3. Stop/tail (side marker lamp) bulb
4. Stop/tail (side marker lamp) bulb socket

### Removal and Installation

INFOID:000000001716503

**CAUTION:**  
Disconnect the battery negative terminal or the fuse.

### REMOVAL


1. Remove the luggage side lower finisher. Refer to [INT-31, "Exploded View"](#).
2. Disconnect rear combination lamp connector.

## REAR COMBINATION LAMP

[XENON TYPE]

### < ON-VEHICLE REPAIR >

3. Remove rear combination lamp mounting bolts (A).
4. Turn up the back door weather strip, insert an appropriate tool between rear combination lamp and vehicles and remove a clip (B).
5. Pull the rear combination lamp toward rear of the vehicle. Remove the rear combination lamp.



### INSTALLATION

Install in the reverse order of removal.

### Replacement

INFOID:000000001716504

#### **CAUTION:**

**Disconnect the battery negative terminal or the fuse.**

### STOP/TAIL (SIDE MARKER) LAMP BULB

1. Remove rear combination lamp. Refer to [EXL-127, "Exploded View"](#).
2. Rotate the stop/tail (side marker lamp) bulb socket counterclockwise, and unlock it.
3. Remove bulb from the bulb socket.

### REAR TURN SIGNAL LAMP BULB

1. Remove rear combination lamp. Refer to [EXL-127, "Exploded View"](#).
2. Rotate the rear turn signal lamp bulb socket counterclockwise, and unlock it.
3. Remove bulb from the bulb socket.

# HIGH-MOUNTED STOP LAMP


< ON-VEHICLE REPAIR >

[XENON TYPE]

## HIGH-MOUNTED STOP LAMP

### Exploded View

INFOID:000000001716505



1. High-mounted stop lamp
2. Clip
3. Seal packing

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000001716506

#### **CAUTION:**


**Disconnect battery negative terminal or remove the fuse.**

#### REMOVAL

1. Remove the back door trim finisher upper. Refer to [INT-34, "Exploded View"](#).
2. Remove the mounting nuts and clips.
3. Cut the seal packing by the thin plate (A).

1. Back door panel
2. High-mounted stop lamp

4. Pull the high-mounted stop lamp toward rear of the vehicle. Remove the high-mounted stop lamp.
5. Disconnect the high-mounted stop lamp connector.



#### INSTALLATION

Install in the reverse order of removal.

#### **CAUTION:**

**Seal packing cannot be reused.**

# BACK-UP LAMP


< ON-VEHICLE REPAIR >

[XENON TYPE]

## BACK-UP LAMP

### Exploded View

INFOID:000000001716507



1. Seal packing
2. Back-up lamp

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000001716508

#### **CAUTION:**

**Disconnect the battery negative terminal or the fuse.**

#### REMOVAL

1. Remove the back door mask. Refer to [INT-34, "Exploded View"](#).
2. Remove back-up lamp mounting nuts.
3. Disconnect back-up lamp connector. And remove the back-up lamp.

#### INSTALLATION

Install in the reverse order of removal.

#### **CAUTION:**

**Seal packing cannot be reused.**

### Replacement


INFOID:000000001716509

#### **CAUTION:**

**Disconnect the battery negative terminal or the fuse.**

#### BACK-UP LAMP BULB

1. Remove the back-up lamp. Refer to [EXL-130, "Exploded View"](#).
2. Disconnect the connector, rotate the bulb socket (1) counter-clockwise and unlock it.
3. Remove the bulb (2) from the socket.



# LICENSE PLATE LAMP


< ON-VEHICLE REPAIR >

[XENON TYPE]

## LICENSE PLATE LAMP

### Exploded View

INFOID:000000001716510



1. License plate lamp


### Removal and Installation

INFOID:000000001716511

**CAUTION:**  
Disconnect the battery negative terminal or the fuse.

#### REMOVAL

1. Remove back door trim finisher lower. Refer to [INT-34, "Exploded View"](#).
2. Remove back door finisher. Refer to [INT-34, "Exploded View"](#).
3. Remove the license plate lamp in numerical order shown in the figure.
4. Disconnect the license plate lamp connector.



#### INSTALLATION

1. Connect the license plate lamp connector.
2. Fix the pawl-side behind the license plate lamp housing first, then push the resin clip-side.

### Replacement

INFOID:000000001716512

**CAUTION:**  
Disconnect the battery negative terminal or the fuse.

#### LICENSE PLATE LAMP BULB

1. Remove back door trim finisher lower. Refer to [INT-34, "Exploded View"](#).


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## LICENSE PLATE LAMP

[XENON TYPE]

### < ON-VEHICLE REPAIR >

2. Turn the bulb socket (1) counterclockwise and unlock it.
3. Remove the bulb (2) from the socket.



# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[XENON TYPE]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Bulb Specifications

INFOID:000000001716516

Item	Type	Wattage (W)
Front combination lamp	Headlamp (HI)	HB3 60
	Headlamp (LO)	D2S (XENON) 35
	Front turn signal/parking (side marker) lamp	S25 (Amber) 27/8
Front fog lamp	H11	55
Rear combination lamp	Stop/tail (side marker) lamp	W21/5W 21/5
	Rear turn signal lamp	W21W 21
	Back-up lamp	W16W 16
License plate lamp	W5W	5
High-mounted stop lamp	LED	—

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

EXL


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000001716543

#### OVERALL SEQUENCE



JPLIA0313GB

#### DETAILED FLOW

##### 1. INTERVIEW FOR MALFUNCTION

Interview the symptom to the customer.

# DIAGNOSIS AND REPAIR WORKFLOW

[HALOGEN TYPE]

< BASIC INSPECTION >

>> GO TO 2.

## 2. SYMPTOM CHECK

Check the symptom from the customer's information.

>> GO TO 3.

## 3. BASIC INSPECTION

Check the operation of each part. Check that any symptom occurs other than the interviewed symptom.

>> GO TO 4.

## 4. SELF-DIAGNOSIS WITH CONSULT-III

Perform the self-diagnosis with CONSULT-III. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

## 5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

## 6. FAIL-SAFE ACTIVATION CHECK

Check that the symptom is applied to the fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

## 7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system that the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

## 8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9.

## 9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10.

## 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT-III)

Perform the self-diagnosis with CONSULT-III. Check that any DTC is not detected. Erase DTC if DTC is detected before the repair. Check that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 11.

## 11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> INSPECTION END

NO >> GO TO 3.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N


O

P

## FUNCTION DIAGNOSIS

### HEADLAMP SYSTEM

#### System Diagram



#### System Description

INFOID:000000001720636

##### OUTLINE

Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

##### HEADLAMP (LO) OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R with CAN communication according to the headlamp (LO) ON condition.

Headlamp (LO) ON condition

- Lighting switch 2ND
- IPDM E/R turns the integrated headlamp low relay ON, and turns the headlamp ON according to the low beam request signal.

##### HEADLAMP (HI) OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter with CAN communication according to the headlamp (HI) ON condition.

Headlamp (HI) ON condition

- Lighting switch HI with the lighting switch 2ND
- Lighting switch PASS
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the integrated headlamp high relay ON, and turns the headlamp ON according to the high beam request signal.


# HEADLAMP SYSTEM

[HALOGEN TYPE]

< FUNCTION DIAGNOSIS >

## Component Parts Location

INFOID:000000001720637



- |                       |                             |                             |
|-----------------------|-----------------------------|-----------------------------|
| 1. Headlamp           | 2. Combination switch       | 3. BCM                      |
| 4. IPDM E/R           | 5. High beam indicator lamp |                             |
| A. Over the glove box | B. Engine room (LH)         | C. On the combination meter |

## Component Description

INFOID:000000001720638

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges that the headlamp is turned ON according to the vehicle condition.</li> <li>- Requests the headlamp relay (HI/LO) ON to IPDM E/R (with CAN communication).</li> <li>- Requests the high beam indicator lamp ON to the combination meter (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay, and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .
Combination meter (High beam indicator lamp)	Turns the high beam indicator lamp ON according to the request from BCM (with CAN communication).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL


# DAYTIME RUNNING LIGHT SYSTEM

< FUNCTION DIAGNOSIS >

[HALOGEN TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

### System Diagram



### System Description

INFOID:000000001716324

#### OUTLINE

- Turns the headlamp high ON (high beam at approximately half illumination) as the daytime running light.
- Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and relay control function of IPDM E/R.

#### DAYTIME RUNNING LIGHT OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects the engine condition by the engine status signal received from ECM with CAN communication.
- BCM detects the parking brake condition by the parking brake switch signal received from combination meter with CAN communication.
- BCM transmits the daytime running light request signal to IPDM E/R with CAN communication according to the daytime running light ON condition.

#### Daytime running light ON condition

- Engine running
- Lighting switch OFF or 1ST
- Parking brake OFF
- Ignition switch ON
- IPDM E/R controls the daytime running light relay (ground-side) to turn ON according to the daytime running light request signal.
- Power is supplied from the daytime running light relay through headlamp high (RH) and IPDM E/R to headlamp high (LH). And high beam headlamps are illuminated (approximately half illumination) as the daytime running light.


# DAYTIME RUNNING LIGHT SYSTEM

< FUNCTION DIAGNOSIS >

[HALOGEN TYPE]

## Component Parts Location

INFOID:000000001716325



- |                                |                      |                              |
|--------------------------------|----------------------|------------------------------|
| 1. Headlamp (HI)               | 2. Combination meter | 3. Combination switch        |
| 4. Parking brake               | 5. BCM               | 6. ECM                       |
| 7. Daytime running light relay | 8. IPDM E/R          |                              |
| A. Over the glove box          | B. Engine room (LH)  | C. Fuse and fusible link box |
| D. Engine room (LH)            |                      |                              |

## Component Description

INFOID:000000001716326

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition with the combination switch reading function.</li> <li>• Judges each lamps ON/OFF condition according to the vehicle condition. Requests the each relay ON to IPDM E/R (with CAN communication).</li> </ul>
IPDM E/R	Controls the relay and supplies voltage to the load according to the request from BCM (with CAN communication).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DAYTIME RUNNING LIGHT SYSTEM


[HALOGEN TYPE]

< FUNCTION DIAGNOSIS >

Part	Description
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .
ECM	Transmits the engine status signal to BCM with CAN communication.
Combination meter	Transmits the parking brake switch signal to BCM with CAN communication.

## FRONT FOG LAMP SYSTEM

### System Diagram



### System Description

INFOID:000000003049935

#### OUTLINE

Front fog lamp is controlled by combination switch reading function and front fog lamp control function of BCM, and relay control function of IPDM E/R.

#### FRONT FOG LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front fog light request signal to IPDM E/R with CAN communication according to the front fog lamp ON condition.

Front fog lamp ON condition

- Front fog lamp switch ON with headlamp ON (except for the high beam ON)
- IPDM E/R turns the integrated front fog lamp relay ON, and turns the front fog lamp ON according to the front fog light request signal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P


# FRONT FOG LAMP SYSTEM

[HALOGEN TYPE]

< FUNCTION DIAGNOSIS >

## Component Parts Location

INFOID:000000003049936



1. Front fog lamp

4. IPDM E/R

A. Over the glove box

2. Combination switch

B. Engine room (LH)

3. BCM

## Component Description

INFOID:000000003049937

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges the front fog lamp ON/OFF status according to the vehicle condition.</li> <li>- Requests the front fog lamp relay ON to IPDM E/R (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .


# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< FUNCTION DIAGNOSIS >

[HALOGEN TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

### System Diagram



### System Description

INFOID:000000003049941

#### OUTLINE

Turn signal lamp and the hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

#### TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the ignition switch is turned ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

#### HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuit when the hazard switch is turned ON. BCM blinks the hazard warning lamp.

#### TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL SOUND OPERATION

- BCM transmits the turn indicator signal to the combination meter with CAN communication while the turn signal lamp and the hazard warning lamp are operating.
- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn indicator signal.

#### HIGH FLASHER OPERATION (FAIL-SAFE)

- BCM detects the turn signal lamp circuit status by the terminal current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while operating the hazard warning lamp.


# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< FUNCTION DIAGNOSIS >

[HALOGEN TYPE]

## Component Parts Location

INFOID:000000003049942



- |                          |                             |                               |
|--------------------------|-----------------------------|-------------------------------|
| 1. Hazard switch         | 2. Front turn signal lamp   | 3. Combination switch         |
| 4. Rear turn signal lamp | 5. BCM                      | 6. Turn signal indicator lamp |
| A. Over the glove box    | B. On the combination meter |                               |

## Component Description

INFOID:000000003049943

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges the blinks of the turn signal lamp and the hazard warning lamp from each switch status. The applicable turn signal lamp blinks.</li> <li>• Requests the turn signal indicator lamp blink to the combination meter (with CAN communication).</li> </ul>
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .
Hazard switch	Inputs the hazard switch ON/OFF signal to BCM.
Combination meter (Turn signal indicator lamp & buzzer)	Blinks the turn signal indicator lamp and outputs the turn signal operating sound with integrated buzzer according to the request from BCM (with CAN communication).


# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< FUNCTION DIAGNOSIS >

[HALOGEN TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

### System Diagram



### System Description

INFOID:000000003049947

#### OUTLINE

Parking\*, license plate and tail\* lamps are controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

\*: Illuminated as side maker lamps too.

#### PARKING, LICENSE PLATE AND TAIL LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter with CAN communication according to the ON/OFF condition of the parking, license plate and tail lamps.

Parking, license plate and tail lamps ON condition

- Lighting switch 1ST
- Lighting switch 2ND

- IPDM E/R turns the integrated tail lamp relay ON and turns the parking lamp, the license plate and tail lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.


# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< FUNCTION DIAGNOSIS >

[HALOGEN TYPE]

## Component Parts Location

INFOID:000000003049948



- |                                    |                       |                                 |
|------------------------------------|-----------------------|---------------------------------|
| 1. Parking lamp (Side marker lamp) | 2. Combination switch | 3. Tail lamp (Side marker lamp) |
| 4. License plate lamp              | 5. BCM                | 6. IPDM E/R                     |
| 7. Tail lamp indicator lamp        |                       |                                 |
| A. Over the glove box              | B. Engine room (LH)   | C. On the combination meter     |

## Component Description

INFOID:000000003049949

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Judges the ON/OFF status of the parking, license plate and tail lamps according to the vehicle condition.</li> <li>- Requests the tail lamp relay ON to IPDM E/R (with CAN communication).</li> <li>- Requests the tail lamp indicator lamp ON to the combination meter (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay and supplies voltage to the load according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-9, "System Diagram"</a> .
Combination meter (Tail lamp indicator lamp)	Turns the tail lamp indicator lamp ON according to the request from BCM (with CAN communication).


# EXTERIOR LAMP BATTERY SAVER SYSTEM

< FUNCTION DIAGNOSIS >

[HALOGEN TYPE]

## EXTERIOR LAMP BATTERY SAVER SYSTEM

### System Diagram



### System Description

INFOID:000000003049951

#### OUTLINE

- Exterior lamp battery saver system is controlled by each function of BCM and IPDM E/R.

##### Control by BCM

- Combination switch reading function
- Headlamp control function
- Exterior lamp battery saver function

##### Control by IPDM E/R

- Relay control function
  - BCM turns the exterior lamp\* OFF after a period of time to prevent the battery from over-discharge when the ignition switch is turned OFF with the exterior lamp ON.
- \*: Headlamp (LO/HI), parking lamp, tail lamp, license plate lamp and front fog lamp

#### EXTERIOR LAMP BATTERY SAVER ACTIVATION

BCM activates the timer and turns the exterior lamp OFF 5 minutes after the ignition switch is turned from ON → OFF with the exterior lamps ON.

#### NOTE:

- Headlamp control function turns the exterior lamps ON normally when the ignition switch is turned ACC or the engine started (both before and after the exterior lamp battery saver is turned OFF).
- The timer starts at the time that the lighting switch is turned from OFF → 1ST or 2ND with the exterior lamp OFF.


# EXTERIOR LAMP BATTERY SAVER SYSTEM

< FUNCTION DIAGNOSIS >

[HALOGEN TYPE]

## Component Parts Location

INFOID:000000003049953



1. Combination switch

A. Over the glove box

2. BCM

B. Engine room (LH)

3. IPDM E/R

## Component Description

INFOID:000000003049954

Part	Description
BCM	<ul style="list-style-type: none"> <li>• Detects each switch condition by the combination switch reading function.</li> <li>• Activates the battery saver to turn the exterior lamps OFF according to the vehicle condition.</li> <li>- Requests each relay OFF to IPDM E/R (with CAN communication).</li> </ul>
IPDM E/R	Controls the integrated relay according to the request from BCM (with CAN communication).
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-9. "System Diagram"</a> .

# DIAGNOSIS SYSTEM (BCM)

[HALOGEN TYPE]

< FUNCTION DIAGNOSIS >

## DIAGNOSIS SYSTEM (BCM) COMMON ITEM

### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000003049962

#### APPLICATION ITEM

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

Diagnosis mode	Function description
ECU Identification	BCM part number is displayed.
Self-Diagnostic Result	Displays the diagnosis results judged by BCM. Refer to <a href="#">EXL-93, "DTC Index"</a> .
Data Monitor	BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Work Support	Changes the setting for each system function.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.

#### SYSTEM APPLICATION

BCM can perform the following functions for each system.

##### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	CONSULT-III sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp control	INT LAMP	x	x	x
Remote keyless entry system	MULTI REMOTE ENT	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER		x	x
Air conditioner	AIR CONDITONER		x	
Intelligent Key system	INTELLIGENT KEY		x	
Combination switch	COMB SW		x	
—	BCM	x		
Immobilizer	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door open	TRUNK		x	x
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR	x	x	x
Signal buffer system	SIGNAL BUFFER		x	x
—	FUEL LID*			
TPMS	TPMS (AIR PRESSURE MONITOR)	x	x	x
Panic alarm system	PANIC ALARM			x

\*: This item is displayed, but is not function.

## HEADLAMP

# DIAGNOSIS SYSTEM (BCM)

[HALOGEN TYPE]

< FUNCTION DIAGNOSIS >

## HEADLAMP : CONSULT-III Function (BCM - HEAD LAMP)

INFOID:00000002993009

### WORK SUPPORT

Service item	Setting item	Setting
BATTERY SAVER SET	On*	With the exterior lamp battery saver function
	Off	Without the exterior lamp battery saver function
ILL DELAY SET	MODE 1	<b>NOTE:</b> The item is indicated, but not operate
	MODE 2	
	MODE 3	
	MODE 4	
	MODE 5	
	MODE 6	
	MODE 7	
	MODE 8	

\*: Initial setting

### DATA MONITOR

Monitor item [Unit]	Description
IGN ON SW [On/Off]	Ignition switch (ON) status judged from IGN signal (ignition power supply)
HI BEAM SW [On/Off]	Each switch status that BCM judges from the combination switch reading function
HEAD LAMP SW1 [On/Off]	
HEAD LAMP SW2 [On/Off]	
LIGHT SW 1ST [On/Off]	
PASSING SW [On/Off]	
FR FOG SW [On/Off]	
AUTO LIGHT SW [On/Off]	
RR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch RH
DOOR SW- RL [On/Off]	The switch status input from rear door switch LH
BACK DOOR SW [On/Off]	The switch status input from back door switch

# DIAGNOSIS SYSTEM (BCM)

[HALOGEN TYPE]

## < FUNCTION DIAGNOSIS >

Monitor item [Unit]	Description
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
ENGINE RUNNING [On/Off]	The engine status received from ECM with CAN communication
PKB SW [On/Off]	The parking brake switch status received from combination meter with CAN communication
CARGO LAMP SW [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored
OPTICAL SENSOR [V]	

## ACTIVE TEST

Test item	Operation	Description
TAIL LAMP	On	Transmits the position light request signal to IPDM E/R with CAN communication to turn the tail lamp ON.
	Off	Stops the tail lamp request signal transmission.
HEAD LAMP	Hi	Transmits the high beam request signal with CAN communication to turn the headlamp (HI).
	Lo	Transmits the low beam request signal with CAN communication to turn the headlamp (LO).
	Off	Stops the high & low beam request signal transmission.
FR FOG LAMP	On	Transmits the front fog lights request signal to IPDM E/R with CAN communication to turn the front fog lamp ON.
	Off	Stops the front fog lights request signal transmission.
DAYTIME RUNNING LIGHT	On	Transmits the daytime running light request signal to IPDM E/R with CAN communication to turn the daytime running lights ON.
	Off	Stops the daytime running light request signal transmission.

## FLASHER

### FLASHER : CONSULT-III Function (BCM - FLASHER)

INFOID:000000003049961

## DATA MONITOR

Monitor item [Unit]	Description
IGN ON SW [On/Off]	Ignition switch (ON) status judged from IGN signal (ignition power supply)
HAZARD SW [On/Off]	The switch status input from the hazard switch
TURN SIGNAL R [On/Off]	Each switch condition that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
BRAKE SW [On/Off]	The switch status input from the stop lamp switch

## ACTIVE TEST

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P

# DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

[HALOGEN TYPE]

Test item	Operation	Description
FLASHER	RH	Outputs the voltage to turn the right side turn signal lamps ON.
	LH	Outputs the voltage to turn the left side turn signal lamps ON.
	Off	Stops the voltage to turn the turn signal lamps OFF.

## DIAGNOSIS SYSTEM (IPDM E/R)

### Diagnosis Description

INFOID:000000003049965

#### Auto active test

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp
- Rear window defogger
- Front wiper (LO, HI)
- Parking lamps
- License plate lamps
- Tail lamps
- Front fog lamps
- Headlamps (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan (LO, MID, HI)

##### Operation procedure

1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)  
**NOTE:**  
 When auto active test is performed with hood opened, sprinkle water on windshield beforehand.
2. Turn ignition switch OFF.
3. Turn the ignition switch ON, and within 20 seconds, press the driver door switch 10 times. Then turn the ignition switch OFF.

**CAUTION:**

**Close passenger door.**

4. Turn the ignition switch ON within 10 seconds. Then the horn sounds once and the auto active test starts.  
**NOTE:**  
 Only a vehicle with the vehicle security system, the horn sounds.
5. The oil pressure warning lamp starts blinking when the auto active test starts.
6. After a series of the following operations is repeated 3 times, auto active test is completed.

**NOTE:**


When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.

**CAUTION:**

- If auto active test mode cannot be actuated, check door switch system.
- Never start the engine.

##### Inspection in auto active test mode

When auto active test mode is actuated, the following 6 steps are repeated 3 times.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# DIAGNOSIS SYSTEM (IPDM E/R)

< FUNCTION DIAGNOSIS >


[HALOGEN TYPE]

Operation sequence	Inspection location	Operation
A	Oil pressure warning lamp	Blinks continuously during operation of auto active test.
1	Rear window defogger	10 seconds
2	Front wiper	LO for 5 seconds → HI for 5 seconds
3	<ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• License plate lamps</li> <li>• Tail lamps</li> <li>• Front fog lamps</li> <li>• Headlamps HI (daytime running light operation)*</li> </ul>	10 seconds
4	Headlamps	LO ↔ HI 5 times
5	A/C compressor (magnet clutch)	ON ↔ OFF 5 times
6	Cooling fan	LO for 5 seconds → MID for 3 seconds → HI for 2 seconds

**NOTE:**

\*: With daytime running light system

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents		Possible cause
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES	BCM signal input circuit
		NO	<ul style="list-style-type: none"> <li>• Rear window defogger</li> <li>• Rear window defogger ground circuit</li> <li>• Harness or connector between IPDM E/R and rear window defogger</li> <li>• IPDM E/R</li> </ul>
Any of the following components do not operate <ul style="list-style-type: none"> <li>• Parking lamps</li> <li>• License plate lamps</li> <li>• Tail lamps</li> <li>• Front fog lamps</li> <li>• Headlamps (HI, LO)</li> <li>• Front wiper (HI, LO)</li> </ul>	Perform auto active test. Does the applicable system operate?	YES	BCM signal input circuit
		NO	<ul style="list-style-type: none"> <li>• Lamp or motor</li> <li>• Lamp or motor ground circuit</li> <li>• Harness or connector between IPDM E/R and applicable system</li> <li>• IPDM E/R</li> </ul>

# DIAGNOSIS SYSTEM (IPDM E/R)

[HALOGEN TYPE]

< FUNCTION DIAGNOSIS >

Symptom	Inspection contents	Possible cause		
Headlamps HI (daytime running light operation) do not operate	Perform auto active test. Do headlamps HI (daytime running light operation) operate?	YES	<ul style="list-style-type: none"> <li>• CAN communication signal between ECM and BCM</li> <li>• CAN communication signal between combination meter and BCM</li> <li>• BCM signal input circuit</li> </ul>	A
		NO	<ul style="list-style-type: none"> <li>• Daytime running light relay power supply circuit</li> <li>• Harness or connector between IPDM E/R and daytime running light relay</li> <li>• Daytime running light relay</li> </ul>	B C
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES	<ul style="list-style-type: none"> <li>• BCM signal input circuit</li> <li>• CAN communication signal between BCM and ECM</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>	D E
		NO	<ul style="list-style-type: none"> <li>• Magnet clutch</li> <li>• Harness or connector between IPDM E/R and magnet clutch</li> <li>• IPDM E/R</li> </ul>	F
Oil pressure warning lamp does not operate	Perform auto active test. Does the oil pressure warning lamp blink?	YES	<ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and oil pressure switch</li> <li>• Oil pressure switch</li> <li>• IPDM E/R</li> </ul>	G
		NO	<ul style="list-style-type: none"> <li>• CAN communication signal between IPDM E/R and BCM</li> <li>• CAN communication signal between BCM and combination meter</li> <li>• Combination meter</li> </ul>	H I
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES	<ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>	J
		NO	<ul style="list-style-type: none"> <li>• Cooling fan motor-2 power supply circuit</li> <li>• Cooling fan motor-1 ground circuit</li> <li>• Cooling fan relay-4 or cooling fan relay-5 power supply circuit</li> <li>• Cooling fan relay-5 ground circuit</li> <li>• Harness or connector between IPDM E/R and cooling fan motor</li> <li>• Harness or connector between IPDM E/R, and cooling fan relay-4 or cooling fan relay-5</li> <li>• Harness or connector between cooling fan motor-2, and cooling fan relay-4 or cooling fan relay-5</li> <li>• Cooling fan relay-4 or cooling fan relay-5</li> <li>• Cooling fan motor</li> <li>• IPDM E/R</li> </ul>	K <b>EXL</b> M N

## CONSULT-III Function (IPDM E/R)

INFOID:000000003049966

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.

# DIAGNOSIS SYSTEM (IPDM E/R)

[HALOGEN TYPE]

< FUNCTION DIAGNOSIS >

Diagnosis mode	Description
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

## SELF DIAGNOSTIC

Refer to [EXL-105. "DTC Index"](#).

## DATA MONITOR

Monitor item

Monitor Item [Unit]	MAIN SIGNALS	Description
MOTOR FAN REQ [1 - 4]	×	Displays the value of the cooling fan speed signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication. <b>NOTE:</b> This item is monitored only the vehicle with front fog lamp system.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper auto stop signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
ST RLY REQ [Off/On]		Displays the status of the starter request signal.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
RR DEF REQ [Off/On]	×	Displays the status of the rear defogger request signal received from BCM via CAN communication.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
DTRL REQ [Off/On]		Displays the status of the daytime running light request signal received from BCM via CAN communication. <b>NOTE:</b> This item is monitored only the vehicle with daytime running light system.
HOOD SW [Off/On]		Displays the status of the hood switch judged by IPDM E/R. <b>NOTE:</b> This item is monitored only the vehicle for Mexico.
THFT HRN REQ [Off/On]		Displays the status of the horn request signal by vehicle security system or panic alarm system received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn request signal by key fob LOCK operation received from BCM via CAN communication.

## ACTIVE TEST

Test item

# DIAGNOSIS SYSTEM (IPDM E/R)

< FUNCTION DIAGNOSIS >

[HALOGEN TYPE]

Test item	Operation	Description
REAR DEFOGGER	Off	OFF
	On	Operates the rear window defogger relay.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.
MOTOR FAN	1	OFF
	2	Operates the cooling fan relay (LO operation).
	3	Operates the cooling fan relay (MID operation).
	4	Operates the cooling fan relay (HI operation).
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay and the daytime running light relay. <b>NOTE:</b> Daytime running light relay is with daytime running light system only.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 4 seconds intervals.
	Fog	Operates the front fog lamp relay. <b>NOTE:</b> This item can test only the vehicle with front fog lamp system.
HORN	On	Operates horn relay for 20 ms.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## COMPONENT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT

#### BCM (BODY CONTROL MODULE)

#### BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000003049994

### 1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not fusing.

Signal name	Fuses and fusible link No.
Battery power supply	10
	J
ACC power supply	20
Ignition power supply	1

#### Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

### 2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

Terminals		(-)	Ignition switch position		
BCM			OFF	ACC	ON
Connector	Terminal				
M67	70	Ground	Battery voltage	Battery voltage	Battery voltage
	57		Battery voltage	Battery voltage	Battery voltage
M65	11		Approx. 0 V	Battery voltage	Battery voltage
	38		Approx. 0 V	Approx. 0 V	Battery voltage

#### Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

### 3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M67	67		Existed

#### Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Di-

# POWER SUPPLY AND GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## agnosis Procedure

INFOID:000000003049997

### 1.CHECK FUSIBLE LINK

Check that the following IPDM E/R fusible link is not blown.

Signal name	Fusible link No.
Battery power supply	C
	E
	K

Is the fusible link fusing?

- YES >> Replace the blown fusible link after repairing the affected circuit if a fusible link is blown.
- NO >> GO TO 2.

### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connectors.
3. Check voltage between IPDM E/R harness connectors and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
IPDM E/R		Battery voltage
Connector	Terminal	
E9	1	
	2	
E10	6	

Is the measurement value normal?

- YES >> GO TO 3.
- NO >> Repair harness or connector.

### 3.CHECK GROUND CIRCUIT

Check continuity between IPDM E/R harness connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E11	11		Exist
E13	25		

Does continuity exist?

- YES >> INSPECTION END
- NO >> Repair harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# EXTERIOR LAMP FUSE

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## EXTERIOR LAMP FUSE

### Description

INFOID:000000001716583

#### Fuse list

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	#44	10 A
Headlamp HI (RH)	IPDM E/R	#43	10 A
Headlamp LO (LH)	IPDM E/R	#49	15 A
Headlamp LO (RH)	IPDM E/R	#50	15 A
Daytime running light	FUSE AND FUSIBLE LINK BLOCK	#33	10 A
Front fog lamp	IPDM E/R	#65	15 A
Parking lamp	IPDM E/R	#46	10 A
<ul style="list-style-type: none"><li>Tail lamp</li><li>License plate lamp</li><li>Each illumination</li></ul>	IPDM E/R	#45	10 A
Stop lamp	FUSE BLOCK (J/B)	#11	10 A
Back-up lamp	IPDM E/R	#60	10 A

### Diagnosis Procedure

INFOID:000000001716584

#### 1. CHECK FUSE

Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	#44	10 A
Headlamp HI (RH)	IPDM E/R	#43	10 A
Headlamp LO (LH)	IPDM E/R	#49	15 A
Headlamp LO (RH)	IPDM E/R	#50	15 A
Daytime running light	FUSE AND FUSIBLE LINK BLOCK	#33	10 A
Front fog lamp	IPDM E/R	#65	15 A
Parking lamp	IPDM E/R	#46	10 A
<ul style="list-style-type: none"><li>Tail lamp</li><li>License plate lamp</li><li>Each illumination</li></ul>	IPDM E/R	#45	10 A
Stop lamp	FUSE BLOCK (J/B)	#11	10 A
Back-up lamp	IPDM E/R	#60	10 A

#### Is the fuse fusing?

- YES >> Repair the applicable circuit. And then replace the fuse.  
NO >> The fuse is normal.

# HEADLAMP (HI) CIRCUIT

[HALOGEN TYPE]

< COMPONENT DIAGNOSIS >

## HEADLAMP (HI) CIRCUIT

### Component Function Check

INFOID:000000001720639

#### 1. CHECK HEADLAMP (HI) OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the headlamp switches to the high beam.

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp (HI) is turned ON.

**Hi** : Headlamp (HI) ON

**Off** : Headlamp (HI) OFF

##### NOTE:

ON/OFF is repeated 1 second each.

Is the headlamp (HI) turned ON?

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-161, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001720640

#### 1. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the headlamp high connector.
3. Turn the ignition switch ON.
4. Select "EXTERNAL LAMP" of IPDM E/R active test item.
5. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals			Condition	Voltage (Approx.)	
(+)		(-)			
IPDM E/R			Ground	External lamp	
Connector	Terminal				
RH	E12	22		Hi	Battery voltage
LH		21		Off	0 V

Is the measurement value normal?

YES >> GO TO 2.

NO >> GO TO 3.

#### 2. CHECK HEADLAMP (HI) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the headlamp high harness connector.

IPDM E/R			Headlamp high		Continuity
Connector	Terminal	Connector	Terminal		
RH	E12	22	E43	1	Existed
LH		21	E24	1	

Does continuity exist?

YES >> • GO TO 5. (Without daytime running light system)

# HEADLAMP (HI) CIRCUIT

[HALOGEN TYPE]

## < COMPONENT DIAGNOSIS >

- GO TO 6. (With daytime running light system)

NO >> Repair the harnesses or connectors.

### 3.CHECK HEADLAMP (HI) FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	#44	10 A
Headlamp HI (RH)	IPDM E/R	#43	10 A

#### Is the fuse fusing?

YES >> GO TO 4.

NO >> Replace IPDM E/R.

### 4.CHECK HEADLAMP HIGH (HI) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between the IPDM E/R harness connector terminal and the ground.

IPDM E/R			Ground	Continuity
Connector	Terminal			
RH	E12	22		Not existed
LH		21		

#### Does continuity exist?

YES >> Repair the harnesses or connectors. And then replace the fuse.

NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

### 5.CHECK HEADLAMP (HI) GROUND OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the headlamp high connector.
3. Check continuity between the headlamp high harness connector and ground.

Headlamp high			Ground	Continuity
Connector	Terminal			
RH	E43	2		Existed
LH	E24	2		

#### Does continuity exist?

YES >> Replace the headlamp (HI) bulb. (Bulb socket is abnormally.)

NO >> Repair the harnesses or connectors.

### 6.CHECK HEADLAMP (HI) GROUND OPEN CIRCUIT (LH SIDE)

1. Turn the ignition switch OFF.
2. Disconnect the headlamp high connector.
3. Check continuity between the headlamp high harness connector and ground.

Headlamp high			Ground	Continuity
Connector	Terminal			
LH	E24	2		Existed

#### Does continuity exist?

YES >> GO TO 7.

NO >> Repair the harnesses or connectors.

### 7.CHECK CONTINUITY BETWEEN HEADLAMP HIGH (RH) AND DAYTIME RUNNING LIGHT RELAY

1. Remove daytime running light relay.

# HEADLAMP (HI) CIRCUIT

[HALOGEN TYPE]

## < COMPONENT DIAGNOSIS >

2. Check continuity between headlamp high RH harness connector and daytime running light relay harness connector.

Headlamp high		Daytime running light relay		Continuity
Connector	Terminal	Connector	Terminal	Existed
RH	E43	E65	3	

Does continuity exist?

YES >> GO TO 8.

NO >> Repair the harness or connector.

## 8. CHECK THE DAYTIME RUNNING LIGHT RELAY GROUND OPEN CIRCUIT

Check continuity between daytime running light relay harness connector and ground.

Daytime running light relay		Ground	Continuity
Connector	Terminal		Existed
E65	4		

Does continuity exist?

YES >> GO TO 9.

NO >> Repair the harness or connector.

## 9. CHECK THE DAYTIME RUNNING LIGHT RELAY

Check daytime running light relay. Refer to [EXL-169, "Component Inspection"](#).

Is the daytime running light relay normal?

YES >> Replace the headlamp (HI) bulb. (Bulb socket is abnormally.)

NO >> Replace the daytime running light relay.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# HEADLAMP (LO) CIRCUIT

[HALOGEN TYPE]

< COMPONENT DIAGNOSIS >

## HEADLAMP (LO) CIRCUIT

### Component Function Check

INFOID:000000001720641

#### 1. CHECK HEADLAMP (LO) OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the headlamp is turned ON.

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the test items, check that the headlamp (LO) is turned ON.

**Lo** : Headlamp (LO) ON  
**Off** : Headlamp (LO) OFF

##### Is the headlamp (LO) turned ON?

- YES >> Headlamp (LO) is normal.  
NO >> Refer to [EXL-164, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001720642

#### 1. CHECK HEADLAMP (LO) OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the headlamp low connector.
3. Turn the ignition switch ON.
4. Select "EXTERNAL LAMP" of IPDM E/R active test item.
5. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals			Test item	Voltage (Approx.)
(+)	(-)			
IPDM E/R			External lamp	Battery voltage
Connector	Terminal			
RH	E12	20	LO	0 V
LH		18	OFF	

##### Is the measurement value normal?

- YES >> GO TO 2.  
NO >> GO TO 3.

#### 2. CHECK HEADLAMP (LO) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the headlamp low harness connector.

IPDM E/R			Headlamp low		Continuity
Connector	Terminal		Connector	Terminal	
RH	E12	20	E45	1	Existed
LH		18	E26	1	

##### Does continuity exist?

- YES >> GO TO 5.  
NO >> Repair the harnesses or connectors.

# HEADLAMP (LO) CIRCUIT

[HALOGEN TYPE]

< COMPONENT DIAGNOSIS >

## 3. CHECK HEADLAMP (LO) FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp LO (LH)	IPDM E/R	#49	15 A
Headlamp LO (RH)	IPDM E/R	#50	15 A

Is the fuse fusing?

- YES >> GO TO 4.  
NO >> Replace IPDM E/R.

## 4. CHECK HEADLAMP (LO) SHORT CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E12	20	Not existed
LH		18	

Does continuity exist?

- YES >> Repair the harnesses or connectors. And then replace the fuse.  
NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

## 5. CHECK HEADLAMP (LO) GROUND OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the headlamp low connector.
3. Check continuity between the headlamp low harness connector and ground.

Headlamp low		Ground	Continuity
Connector	Terminal		
RH	E45	2	Existed
LH	E26	2	

Does continuity exist?

- YES >> Replace the headlamp (LO) bulb. (Bulb socket is abnormally.)  
NO >> Repair the harnesses or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT FOG LAMP CIRCUIT

[HALOGEN TYPE]

< COMPONENT DIAGNOSIS >

## FRONT FOG LAMP CIRCUIT

### Component Function Check

INFOID:000000003050001

#### 1. CHECK FRONT FOG LAMP OPERATION

##### ⊗ IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the front fog lamp is turned ON.

##### Ⓟ CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the test items, check that the front fog lamp is turned ON.

**Fog** : Front fog lamp ON  
**Off** : Front fog lamp OFF

##### Is the front fog lamp turned ON?

- YES >> Front fog lamp circuit is normal.  
NO >> Refer to [EXL-166, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000003050002

#### 1. CHECK FRONT FOG LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuse is not fusing.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#65	15 A

##### Is the fuse fusing?

- YES >> GO TO 2.  
NO >> GO TO 3.

#### 2. CHECK FRONT FOG LAMP SHORT CIRCUIT

1. Disconnect IPDM E/R connector and the front fog connector.
2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E12	17	Not existed
LH		16	

##### Does continuity exist?

- YES >> Repair the harnesses or connectors. And then replace the fuse.  
NO >> Replace the fuse. (Replace IPDM E/R if the fuse is fusing again.)

#### 3. CHECK FRONT FOG LAMP BULB

Check the applicable lamp bulb.

##### Is the bulb normal?

- YES >> GO TO 4.  
NO >> Replace the bulb.

#### 4. CHECK FRONT FOG LAMP OUTPUT VOLTAGE

##### Ⓟ CONSULT-III ACTIVE TEST

1. Disconnect the front fog lamp connector.
2. Turn the ignition switch ON.
3. Select "EXTERNAL LAMP" of IPDM E/R active test item.

# FRONT FOG LAMP CIRCUIT

**[HALOGEN TYPE]**

## < COMPONENT DIAGNOSIS >

4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals			Test item	Voltage (Approx.)
(+)		(-)		
IPDM E/R			EXTERNAL LAMP	Battery voltage
Connector	Terminal			
RH	E12	17	Fog	0 V
LH		16		
			Ground	

Is the measurement value normal?

YES >> GO TO 5.

NO >> Replace IPDM E/R.

## 5. CHECK FRONT FOG LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the front fog lamp harness connector.

IPDM E/R			Front fog lamp		Continuity
Connector	Terminal		Connector	Terminal	
RH	E12	17	E48	2	Existed
LH		16	E30	2	

Does continuity exist?

YES >> GO TO 6.

NO >> Repair the harnesses or connectors.

## 6. CHECK FRONT FOG LAMP GROUND CIRCUIT OPEN CIRCUIT

Check continuity between the front fog lamp harness connector and the ground.

Front fog lamp			Ground	Continuity
Connector	Terminal			
RH	E48	1		Existed
LH	E30	1		

Does continuity exist?

YES >> Replace the front fog lamp.

NO >> Repair the harnesses or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DAYTIME RUNNING LIGHT RELAY CIRCUIT

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## DAYTIME RUNNING LIGHT RELAY CIRCUIT

### Component Function Check

INFOID:000000001716404

#### 1. CHECK DAYTIME RUNNING LIGHT OPERATION

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the test item, check that daytime running light operation.

**TAIL : Daytime running light ON**

**Off : Daytime running light OFF**

##### Is the daytime running light turned ON?

- YES >> Daytime running light relay circuit is normal.  
 NO >> Refer to [EXL-168, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000001716405

#### 1. CHECK DAYTIME RUNNING LIGHT RELAY FUSE

Check that the following fuse is not fusing.

Unit	Location	Fuse No.	Capacity
Daytime running light relay	Fuse and fusible link block	#33	10A

##### Is the fuse fusing?

- YES >> Replace the fuse after repairing the applicable circuit.  
 NO >> GO TO 2.

#### 2. CHECK DAYTIME RUNNING LIGHT RELAY POWER SUPPLY

1. Remove daytime running light relay.
2. Check voltage between daytime running light relay harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Daytime running light relay		Ground
Connector	Terminal	
E65	1	
	5	
		Battery voltage

##### Is the measurement value normal?

- YES >> GO TO 3.  
 NO >> Repair harnesses or connectors.

#### 3. CHECK DAYTIME RUNNING LIGHT RELAY

Check daytime running light relay. Refer to [EXL-169, "Component Inspection"](#).

##### Is the daytime running light relay normal?

- YES >> GO TO 4.  
 NO >> Replace daytime running light relay.

#### 4. CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL OUTPUT

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Install daytime running light relay.
3. Turn the ignition switch ON.
4. Select "DAYTIME RUNNING LIGHT" of BCM (HEAD LAMP) active test item.
5. With operating the test item, check voltage between IPDM E/R harness connector and ground.

# DAYTIME RUNNING LIGHT RELAY CIRCUIT

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		DAYTIME RUNNING LIGHT	0 V
Connector	Terminal		
E12	15	On	0 V
		Off	Battery voltage

Is the measurement value normal?

YES >> Check daytime running light relay circuit. Refer to [EXL-168, "Diagnosis Procedure"](#).

Fixed at 0 V >> GO TO 5.

Fixed at battery voltage >> Replace IPDM E/R.

## 5. CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL OPEN CIRCUIT

1. Remove daytime running light relay.
2. Disconnect IPDM E/R harness connector.
3. Check continuity between IPDM E/R harness connector and daytime running light relay harness connector.

IPDM E/R		Daytime running light relay		Continuity
Connector	Terminal	Connector	Terminal	
E12	15	E65	2	Existed

Does continuity exist?

YES >> GO TO 6.

NO >> Repair the harnesses or connectors.

## 6. CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL SHORT CIRCUIT

Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E12	15		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> Replace IPDM E/R.

## Component Inspection

INFOID:000000001716406

### 1. CHECK DAYTIME RUNNING LIGHT RELAY

1. Turn the ignition switch OFF.
2. Remove daytime running light relay.
3. Apply battery voltage to daytime running light relay between terminals 1 and 2.
4. Check continuity of daytime running light relay.

Daytime running light relay		Condition	Continuity
Terminal		Voltage	
5	3	Apply	Existed
		Not Apply	Not existed
4		Apply	Not existed
		Not Apply	Existed

Does continuity exist?

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

## DAYTIME RUNNING LIGHT RELAY CIRCUIT

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

---

- YES >> Daytime running light relay is normal.
- NO >> Replace daytime running light relay.

# PARKING LAMP CIRCUIT

[HALOGEN TYPE]

< COMPONENT DIAGNOSIS >

## PARKING LAMP CIRCUIT

### Component Function Check

INFOID:000000003050006

#### 1. CHECK PARKING LAMP OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the parking lamp is turned ON.

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the test items, check that the parking lamp is turned ON.

**TAIL : Parking lamp ON**  
**Off : Parking lamp OFF**

Is the parking lamp turned ON?

- YES >> Parking lamp circuit is normal.  
NO >> Refer to [EXL-171, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000003050007

#### 1. CHECK PARKING LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Parking lamp	IPDM E/R	#46	10 A

Is the fuse fusing?

- YES >> GO TO 2.  
NO >> GO TO 3.

#### 2. CHECK PARKING LAMP SHORT CIRCUIT

1. Disconnect IPDM E/R connector and the parking lamp connector.
2. Check continuity between the IPDM E/R harness connector and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E14	39	Not existed
LH		38	

Does continuity exist?

- YES >> Repair the harnesses or connectors. And then replace the fuse.  
NO >> Replace the fuse. (Replace IPDM E/R if fusing is found again.)

#### 3. CHECK PARKING LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

- YES >> GO TO 4.  
NO >> Replace the bulb.

#### 4. CHECK PARKING LAMP OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Disconnect the parking lamp connector.
2. Turn the ignition switch ON.
3. Select "EXTERNAL LAMP" of IPDM E/R active test item.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# PARKING LAMP CIRCUIT

**[HALOGEN TYPE]**

**< COMPONENT DIAGNOSIS >**

4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals			Test item	Voltage (Approx.)
(+)		(-)		
IPDM E/R			EXTERNAL LAMP	Battery voltage
Connector	Terminal			
RH	E14	39	TAIL	0 V
LH		38	Off	

Is the measurement value normal?

- YES >> GO TO 5.  
 NO >> Replace IPDM E/R.

## 5. CHECK PARKING LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the parking lamp harness connector.

IPDM E/R			Parking lamp		Continuity
Connector	Terminal		Connector	Terminal	
RH	E14	39	E46	1	Existed
LH		38	E27	1	

Does continuity exist?

- YES >> GO TO 6.  
 NO >> Repair the harnesses or connectors.

## 6. CHECK PARKING LAMP GROUND OPEN CIRCUIT

Check continuity between the parking lamp harness connector and the ground.

Parking lamp			Ground	Continuity
Connector	Terminal			
RH	E46	2	Ground	Existed
LH	E27	2		

Does continuity exist?

- YES >> Replace the front combination lamp.  
 NO >> Repair the harnesses or connectors.

# TURN SIGNAL LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## TURN SIGNAL LAMP CIRCUIT

### Description

INFOID:000000003050010

BCM performs the high flasher operation (fail-safe) if any bulb or harness of the turn signal lamp circuit is open.

**NOTE:**

The turn signal lamp blinks at normal speed when using the hazard warning lamp.

### Component Function Check

INFOID:000000003050011

#### 1. CHECK TURN SIGNAL LAMP

**ⓐ CONSULT-III ACTIVE TEST**

1. Select "FLASHER" of BCM (FLASHER) active test item.
2. With operating the test items, check that the turn signal lamp is turned ON.

- LH** : Turn signal lamps (LH) ON
- RH** : Turn signal lamps (RH) ON
- Off** : Turn signal lamps OFF

Is the turn signal lamp turned ON?

- YES >> Turn signal lamp circuit is normal.
- NO >> Refer to [EXL-173. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000003050012

#### 1. CHECK TURN SIGNAL LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

- YES >> GO TO 2.
- NO >> Replace the bulb.

#### 2. CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the front turn signal lamp connector or the rear combination lamp connector.
3. Turn the ignition switch ON.
4. With operating the turn signal switch, check the voltage between the BCM harness connector and the ground.

EXL

Terminals			Condition	Voltage (Approx.)
(+)	(-)			
BCM			Turn signal switch	
Connector	Terminal			
RH	61			
LH	M67	60		
			Ground	LH or RH
			OFF	0 V

Is the measurement value normal?

- YES >> GO TO 3.
- NO >> Replace BCM. Refer to [BCS-67. "Exploded View"](#).

# TURN SIGNAL LAMP CIRCUIT

[HALOGEN TYPE]

< COMPONENT DIAGNOSIS >

## 3. CHECK TURN SIGNAL LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between the BCM harness connector and the front turn signal lamp, or the rear combination lamp harness connector.

Front turn signal lamp

BCM		Front turn signal lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M67	61	E46	Existed
LH		60	E27	

Rear turn signal lamp

BCM		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	M67	61	B59	Existed
LH		60	B80	

Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

## 4. CHECK TURN SIGNAL LAMP SHORT CIRCUIT

Check continuity between the BCM harness connector and the ground.

BCM		Ground	Continuity
Connector	Terminal		
RH	M67	61	Not existed
LH		60	

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 5.

## 5. CHECK TURN SIGNAL LAMP GROUND OPEN CIRCUIT

Check continuity between the front turn signal lamp, or the rear combination lamp and the ground.

Front turn signal lamp

Front turn signal lamp		Ground	Continuity
Connector	Terminal		
RH	E46	2	Existed
LH	E27		

Rear turn signal lamp

Rear combination lamp		Ground	Continuity
Connector	Terminal		
RH	B59	4	Existed
LH	B80		

Does continuity exist?

YES >> Replace the front combination lamp or the rear combination lamp.

NO >> Repair the harnesses or connectors.

# HAZARD SWITCH

[HALOGEN TYPE]

< COMPONENT DIAGNOSIS >

## HAZARD SWITCH

### Component Function Check

INFOID:000000003050013

#### 1.CHECK HAZARD SWITCH SIGNAL BY CONSULT-III

##### CONSULT-III DATA MONITOR

1. Turn the ignition switch ON.
2. Select "HAZARD SW" of BCM (FLASHER) data monitor item.
3. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the item status normal?


- YES >> Hazard switch circuit is normal.  
 NO >> Refer to [EXL-175, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000003050014

#### 1.CHECK HAZARD SWITCH SIGNAL INPUT

With operating the hazard switch, check the voltage between the BCM harness connector and the ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
BCM		Hazard switch	0 V
Connector	Terminal		
M65	29	ON	
		OFF	
		Ground	

JPMA0154GB

Is the measurement value normal?

- YES >> Replace BCM. Refer to [BCS-67, "Exploded View"](#).  
 NO >> GO TO 2.

#### 2.CHECK HAZARD SWITCH SIGNAL OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the hazard switch connector and BCM connector.
3. Check continuity between the hazard switch harness connector and the BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M45	2	M65	29	Existed

Does continuity exist?

- YES >> GO TO 3.  
 NO >> Repair the harnesses or connectors.

#### 3.CHECK HAZARD SWITCH SIGNAL SHORT CIRCUIT

Check continuity between the hazard switch harness connector and the ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HAZARD SWITCH

[HALOGEN TYPE]

< COMPONENT DIAGNOSIS >

Hazard switch		Ground	Continuity
Connector	Terminal		
M45	2		Not existed

Does continuity exist?

YES >> Repair the harnesses or connectors.

NO >> GO TO 4.

## 4.CHECK HAZARD SWITCH GROUND OPEN CIRCUIT

Check continuity between the hazard switch harness connector and the ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M45	1		Existed

Does continuity exist?

YES >> Replace the hazard switch.

NO >> Repair the harnesses or connectors.

# TAIL LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## TAIL LAMP CIRCUIT

### Component Function Check

INFOID:000000003050015

#### NOTE:

Check the license plate lamp circuit if the tail lamp and the license plate lamp are not turned ON. Refer to [EXL-179, "Component Function Check"](#).

### 1. CHECK TAIL LAMP OPERATION

#### IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the tail lamp is turned ON.

#### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the test items, check that the tail lamp is turned ON.

**TAIL : Tail Lamp ON**

**Off : Tail lamp OFF**

Is the tail lamp turned ON?

YES >> Tail lamp circuit is normal.

NO >> Refer to [EXL-177, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000003050016

### 1. CHECK TAIL LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Tail lamp	IPDM E/R	#45	10 A

Is the fuse fusing?

YES >> Repair the malfunctioning part before replacing the fuse.

NO >> GO TO 2.

### 2. CHECK TAIL LAMP OUTPUT VOLTAGE

#### CONSULT-III ACTIVE TEST

1. Disconnect the rear combination lamp connector.
2. Turn the ignition switch ON.
3. Select "EXTERNAL LAMP" of IPDM E/R active test item.
4. With operating the test items, check the voltage between the IPDM E/R harness connector and the ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		EXTERNAL LAMP	Battery voltage
Connector	Terminal		
E14	37	TAIL	Battery voltage
		Off	0 V

Is the measurement value normal?

YES >> GO TO 3.

NO >> Replace IPDM E/R.

### 3. CHECK TAIL LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# TAIL LAMP CIRCUIT

[HALOGEN TYPE]

## < COMPONENT DIAGNOSIS >

2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector and the rear combination lamp harness connector.

IPDM E/R		Rear combination lamp		Continuity	
Connector	Terminal	Connector	Terminal		
RH	E14	37	B59	1	Existed
LH			B80		

### Does continuity exist?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

## 4. CHECK TAIL LAMP GROUND OPEN CIRCUIT

Check continuity between the rear combination lamp harness connector and the ground.

Rear combination lamp			Ground	Continuity
Connector	Terminal			
RH	B59	4		Existed
LH	B80	4		

### Does continuity exist?

YES >> Replace the rear combination lamp.

NO >> Repair the harnesses or connectors.

# LICENSE PLATE LAMP CIRCUIT

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## LICENSE PLATE LAMP CIRCUIT

### Component Function Check

INFOID:000000003050019

#### 1.CHECK LICENSE PLATE LAMP OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the license plate lamp is turned ON.

##### CONSULT-III ACTIVE TEST

1. Select "EXTERNAL LAMP" of IPDM E/R active test item.
2. With operating the lighting switch, check that the license plate lamp is turned ON.

**TAIL : License plate lamp ON**

**Off : License plate lamp OFF**

Is the license plate lamp turned ON?

YES >> License plate lamp circuit is normal.

NO >> Refer to [EXL-179, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000003050020

#### 1.CHECK LICENSE PLATE LAMP BULB

Check the applicable lamp bulb.

Is the bulb normal?

YES >> GO TO 2.

NO >> Replace the bulb.

#### 2.CHECK LICENSE PLATE LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector and the license plate lamp connector.
3. Check continuity between the IPDM E/R harness connector and the license plate lamp harness connector.

IPDM E/R		License plate lamp		Continuity	
Connector	Terminal	Connector	Terminal		
RH	E14	37	D196	1	Existed
LH			D195		

Does continuity exist?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

#### 3.CHECK LICENSE PLATE LAMP GROUND OPEN CIRCUIT

Check continuity between the license plate lamp harness connector and the ground.

License plate lamp			Ground	Continuity
Connector	Terminal			
RH	D196	2	Ground	Existed
LH	D195	2		

Does continuity exist?

YES >> Replace the license plate lamp.

NO >> Repair the harnesses or connectors.

# HEADLAMP SYSTEM


[HALOGEN TYPE]

< COMPONENT DIAGNOSIS >

## HEADLAMP SYSTEM

### Wiring Diagram - HEADLAMP -

INFOID:000000001722065



2007/07/13

JCLWM0871GE

# HEADLAMP SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## HEADLAMP (WITH HALOGEN HEADLAMP)

Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	MOBEP-LC



Connector No.	E12
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NSGFBR-CS



Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH1ZFW-NH



Connector No.	E24
Connector Name	HEADLAMP HIGH LH
Connector Type	UO2FB



Terminal No.	11	Color of Wire	B	Signal Name [Specification]	-
--------------	----	---------------	---	-----------------------------	---

Terminal No.	18	Color of Wire	L	Signal Name [Specification]	-
Terminal No.	20	Color of Wire	SB	Signal Name [Specification]	-
Terminal No.	21	Color of Wire	G	Signal Name [Specification]	-
Terminal No.	22	Color of Wire	LG	Signal Name [Specification]	-

Terminal No.	25	Color of Wire	B	Signal Name [Specification]	-
Terminal No.	26	Color of Wire	P	Signal Name [Specification]	-
Terminal No.	27	Color of Wire	L	Signal Name [Specification]	-

Terminal No.	1	Color of Wire	G	Signal Name [Specification]	-
Terminal No.	2	Color of Wire	B	Signal Name [Specification]	-

Connector No.	E26
Connector Name	HEADLAMP LOW LH
Connector Type	FH20ZFB




Connector No.	E43
Connector Name	HEADLAMP HIGH RH
Connector Type	UO2FB



Connector No.	E45
Connector Name	HEADLAMP LOW RH
Connector Type	FH20ZFB



Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH8DFW-CS16-TM4



Terminal No.	1	Color of Wire	L	Signal Name [Specification]	-
Terminal No.	2	Color of Wire	B	Signal Name [Specification]	-

Terminal No.	1	Color of Wire	LG	Signal Name [Specification]	-
Terminal No.	2	Color of Wire	B	Signal Name [Specification]	- [Without daytime running light system]

Terminal No.	1	Color of Wire	SB	Signal Name [Specification]	-
Terminal No.	2	Color of Wire	B	Signal Name [Specification]	-

Terminal No.	5	Color of Wire	Y	Signal Name [Specification]	-
Terminal No.	12	Color of Wire	P	Signal Name [Specification]	-
Terminal No.	22	Color of Wire	L	Signal Name [Specification]	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# HEADLAMP SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]


## HEADLAMP (WITH HALOGEN HEADLAMP)

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-
14	P	-

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TK16FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	INPUT 1
2	B	INPUT 2
3	L	INPUT 3
4	GR	INPUT 4
5	BR	INPUT 5
6	P	OUTPUT 1
7	R	OUTPUT 2
8	G	OUTPUT 3
9	Y	OUTPUT 4
10	W	OUTPUT 3

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SAB40FW




Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW




Terminal No.	Color of Wire	Signal Name [Specification]
2	G	INPUT 5
3	Y	INPUT 4
4	W	INPUT 3
5	R	INPUT 2
6	P	INPUT 1
11	SB	ACC
32	BR	OUTPUT 5
33	GR	OUTPUT 4
34	L	OUTPUT 3
35	B	OUTPUT 2
36	Y	OUTPUT 1

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA



Terminal No.	Color of Wire	Signal Name [Specification]
57	G	BAT FUSE
67	B	GND
70	Y	BAT FL

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80MY-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-
12	P	-
22	L	-

JCLWM0873GE

# DAYTIME RUNNING LIGHT SYSTEM


< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

### Wiring Diagram - DAYTIME RUNNING LIGHT SYSTEM -

INFOID:000000001720201



2007/07/13


JCLWM0874GE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DAYTIME RUNNING LIGHT SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]



JCLWM0875GE



# DAYTIME RUNNING LIGHT SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D152</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>M02FW-GY-LC</td></tr> </table>	Connector No.	D152	Connector Name	WIRE TO WIRE	Connector Type	M02FW-GY-LC	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>2</td></tr> <tr><td>Color of Wire</td><td>B</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	2	Color of Wire	B	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D157</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>NS10FW-CS</td></tr> </table>	Connector No.	D157	Connector Name	WIRE TO WIRE	Connector Type	NS10FW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>6</td></tr> <tr><td>Color of Wire</td><td>R</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	6	Color of Wire	R	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D159</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>M04FW-LC</td></tr> </table>	Connector No.	D159	Connector Name	WIRE TO WIRE	Connector Type	M04FW-LC	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>3</td></tr> <tr><td>Color of Wire</td><td>B</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	3	Color of Wire	B	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D181</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>NS30MER-CS</td></tr> </table>	Connector No.	D181	Connector Name	WIRE TO WIRE	Connector Type	NS30MER-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>2</td></tr> <tr><td>Color of Wire</td><td>R</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	2	Color of Wire	R	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D182</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>M02MW-GY-LC</td></tr> </table>	Connector No.	D182	Connector Name	WIRE TO WIRE	Connector Type	M02MW-GY-LC	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>2</td></tr> <tr><td>Color of Wire</td><td>B</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	2	Color of Wire	B	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>E11</td></tr> <tr><td>Connector Name</td><td>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</td></tr> <tr><td>Connector Type</td><td>M06FB-LC</td></tr> </table>	Connector No.	E11	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Type	M06FB-LC	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>11</td></tr> <tr><td>Color of Wire</td><td>B</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	11	Color of Wire	B	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D195</td></tr> <tr><td>Connector Name</td><td>LICENSE PLATE LAMP LH</td></tr> <tr><td>Connector Type</td><td>TK02FBR</td></tr> </table>	Connector No.	D195	Connector Name	LICENSE PLATE LAMP LH	Connector Type	TK02FBR	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>1</td></tr> <tr><td>Color of Wire</td><td>R</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> <tr><td>Terminal No.</td><td>2</td></tr> <tr><td>Color of Wire</td><td>B</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	1	Color of Wire	R	Signal Name [Specification]	-	Terminal No.	2	Color of Wire	B	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>D196</td></tr> <tr><td>Connector Name</td><td>LICENSE PLATE LAMP RH</td></tr> <tr><td>Connector Type</td><td>TK02FBR</td></tr> </table>	Connector No.	D196	Connector Name	LICENSE PLATE LAMP RH	Connector Type	TK02FBR	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>1</td></tr> <tr><td>Color of Wire</td><td>R</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> <tr><td>Terminal No.</td><td>2</td></tr> <tr><td>Color of Wire</td><td>B</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	1	Color of Wire	R	Signal Name [Specification]	-	Terminal No.	2	Color of Wire	B	Signal Name [Specification]	-
Connector No.	D152																																																																																																																										
Connector Name	WIRE TO WIRE																																																																																																																										
Connector Type	M02FW-GY-LC																																																																																																																										
Terminal No.	2																																																																																																																										
Color of Wire	B																																																																																																																										
Signal Name [Specification]	-																																																																																																																										
Connector No.	D157																																																																																																																										
Connector Name	WIRE TO WIRE																																																																																																																										
Connector Type	NS10FW-CS																																																																																																																										
Terminal No.	6																																																																																																																										
Color of Wire	R																																																																																																																										
Signal Name [Specification]	-																																																																																																																										
Connector No.	D159																																																																																																																										
Connector Name	WIRE TO WIRE																																																																																																																										
Connector Type	M04FW-LC																																																																																																																										
Terminal No.	3																																																																																																																										
Color of Wire	B																																																																																																																										
Signal Name [Specification]	-																																																																																																																										
Connector No.	D181																																																																																																																										
Connector Name	WIRE TO WIRE																																																																																																																										
Connector Type	NS30MER-CS																																																																																																																										
Terminal No.	2																																																																																																																										
Color of Wire	R																																																																																																																										
Signal Name [Specification]	-																																																																																																																										
Connector No.	D182																																																																																																																										
Connector Name	WIRE TO WIRE																																																																																																																										
Connector Type	M02MW-GY-LC																																																																																																																										
Terminal No.	2																																																																																																																										
Color of Wire	B																																																																																																																										
Signal Name [Specification]	-																																																																																																																										
Connector No.	E11																																																																																																																										
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)																																																																																																																										
Connector Type	M06FB-LC																																																																																																																										
Terminal No.	11																																																																																																																										
Color of Wire	B																																																																																																																										
Signal Name [Specification]	-																																																																																																																										
Connector No.	D195																																																																																																																										
Connector Name	LICENSE PLATE LAMP LH																																																																																																																										
Connector Type	TK02FBR																																																																																																																										
Terminal No.	1																																																																																																																										
Color of Wire	R																																																																																																																										
Signal Name [Specification]	-																																																																																																																										
Terminal No.	2																																																																																																																										
Color of Wire	B																																																																																																																										
Signal Name [Specification]	-																																																																																																																										
Connector No.	D196																																																																																																																										
Connector Name	LICENSE PLATE LAMP RH																																																																																																																										
Connector Type	TK02FBR																																																																																																																										
Terminal No.	1																																																																																																																										
Color of Wire	R																																																																																																																										
Signal Name [Specification]	-																																																																																																																										
Terminal No.	2																																																																																																																										
Color of Wire	B																																																																																																																										
Signal Name [Specification]	-																																																																																																																										

JCLWM0877GE

# DAYTIME RUNNING LIGHT SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

Connector No.	E12
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS38FBR-CS




Terminal No.	Color of Wire	Signal Name [Specification]
15	SB	-
16	L	-
20	SB	-
21	G	-
22	LG	-

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH12FTR-HH




Terminal No.	Color of Wire	Signal Name [Specification]
25	B	-
26	P	-
27	L	-

Connector No.	E14
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS12FBR-CS



Terminal No.	Color of Wire	Signal Name [Specification]
37	R	-
38	R	-
39	GR	-

Connector No.	E16
Connector Name	ECM
Connector Type	MAA24FB-MEA3-RH



Terminal No.	Color of Wire	Signal Name [Specification]
97	P	VEHCAN-L
98	L	VEHCAN-H

Connector No.	E24
Connector Name	HEADLAMP HIGH LH
Connector Type	U02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	B	-

Connector No.	E26
Connector Name	HEADLAMP LOW LH
Connector Type	FHZ02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	B	-

Connector No.	E27
Connector Name	FRONT COMBINATION LAMP LH
Connector Type	Z03FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	E43
Connector Name	HEADLAMP HIGH RH
Connector Type	U02FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	R	- [With daytime running light system]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DAYTIME RUNNING LIGHT SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

Connector No.	E43
Connector Name	HEADLAMP LOW RH
Connector Type	FH20FB

Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-
2	B	-

Connector No.	E46
Connector Name	FRONT COMBINATION LAMP RH
Connector Type	Z03GY

Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	B	-

Connector No.	E55
Connector Name	DAYTIME RUNNING LIGHT RELAY
Connector Type	MS03FB-M2

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	SB	-
3	R	-
4	B	-
5	Y	-

Connector No.	E101
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4

Terminal No.	Color of Wire	Signal Name [Specification]
8	R	-

Connector No.	E103
Connector Name	PARKING BRAKE SWITCH
Connector Type	P01FE-A

Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4

Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-
12	P	-
15	V	-
20	P	-
22	L	-
30	L	-

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW

Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-
14	P	-

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TK16FW

Terminal No.	Color of Wire	Signal Name [Specification]
1	V	INPUT 1
2	B	INPUT 2
3	L	INPUT 3
4	GR	INPUT 4
5	BR	INPUT 5
7	R	OUTPUT 1
8	G	OUTPUT 2
9	Y	OUTPUT 3
10	W	OUTPUT 4

JCLWM0879GE


# DAYTIME RUNNING LIGHT SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## DAYTIME RUNNING LIGHT SYSTEM

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SAB4DFW



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L
26	V	PARKING BRAKE SW

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CST16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-
12	P	-
15	V	-
20	P	-
22	L	-
30	L	-

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH4QFW



Terminal No.	Color of Wire	Signal Name [Specification]
2	G	INPUT 5
3	Y	INPUT 4
4	W	INPUT 3
5	R	INPUT 2
6	P	INPUT 1
11	SB	ACC
32	BR	OUTPUT 5
33	GR	OUTPUT 4
34	L	OUTPUT 3
35	B	OUTPUT 2
36	V	OUTPUT 1

38	G	IGN
39	L	CAN-H
40	P	CAN-L

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA



Terminal No.	Color of Wire	Signal Name [Specification]
57	G	BAT FUSE
67	B	GND
70	Y	BAT FL

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT FOG LAMP SYSTEM


< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## FRONT FOG LAMP SYSTEM

### Wiring Diagram - FRONT FOG LAMP -

INFOID:000000001720232



2007/07/13

JCLWM0883GE

# FRONT FOG LAMP SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]


## FRONT FOG LAMP

Connector No.	E40
Connector Name	FRONT FOG LAMP LH
Connector Type	FH2ZF8



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	
2	Y	

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH1ZFW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
25	B	
26	P	
27	L	

Connector No.	E12
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NSGFBR-CS



Terminal No.	Color of Wire	Signal Name [Specification]
16	Y	
17	W	

Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	MD8EP-LC




Terminal No.	Color of Wire	Signal Name [Specification]
11	B	

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TK16FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	INPUT 1
2	B	INPUT 2
3	L	INPUT 3
4	GR	INPUT 4
5	BR	INPUT 5
6	P	OUTPUT 1
7	R	OUTPUT 2
8	G	OUTPUT 5
9	Y	OUTPUT 4
10	W	OUTPUT 3

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
6	L	
14	P	

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	
12	P	
22	L	

Connector No.	E48
Connector Name	FRONT FOG LAMP RH
Connector Type	FH2ZF8



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	
2	W	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

JCLWM0884GE


# FRONT FOG LAMP SYSTEM

[HALOGEN TYPE]

## < COMPONENT DIAGNOSIS >

### FRONT FOG LAMP

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH407W



Terminal No.	Color of Wire	Signal Name [Specification]
2	G	INPUT 5
3	Y	INPUT 4
4	W	INPUT 3
5	R	INPUT 2
6	P	INPUT 1
11	SB	ACC
32	BR	OUTPUT 5
33	GR	OUTPUT 4
34	L	OUTPUT 3
35	B	OUTPUT 2
36	V	OUTPUT 1


38	G	IGN
39	L	CAN-H
40	P	CAN-L

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FE/08FB-FHAG-SA



Terminal No.	Color of Wire	Signal Name [Specification]
57	G	BAT FUSE
67	B	GND
70	Y	BAT FL

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	FR80MM-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-
12	P	-
22	L	-

JCLWM0885GE

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >


[HALOGEN TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

Wiring Diagram - TURN AND HAZARD WARNING LAMPS -

INFOID:000000001720233

### TURN SIGNAL AND HAZARD WARNING LAMPS



2007/07/13

JCLWM0886GE





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMPS

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B1</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH80FW-CS16-TM4</td></tr> </table>  <p style="text-align: center;"><b>H.S.</b></p>	Connector No.	B1	Connector Name	WIRE TO WIRE	Connector Type	TH80FW-CS16-TM4	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>93</td></tr> <tr><td>Color of Wire</td><td>W</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	93	Color of Wire	W	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>15</td></tr> <tr><td>Color of Wire</td><td>BR</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	15	Color of Wire	BR	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B4</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>NS16MW-CS</td></tr> </table>  <p style="text-align: center;"><b>H.S.</b></p>	Connector No.	B4	Connector Name	WIRE TO WIRE	Connector Type	NS16MW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>15</td></tr> <tr><td>Color of Wire</td><td>BR</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	15	Color of Wire	BR	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>5</td></tr> <tr><td>Color of Wire</td><td>Y</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	5	Color of Wire	Y	Signal Name [Specification]	-
Connector No.	B1																																								
Connector Name	WIRE TO WIRE																																								
Connector Type	TH80FW-CS16-TM4																																								
Terminal No.	93																																								
Color of Wire	W																																								
Signal Name [Specification]	-																																								
Terminal No.	15																																								
Color of Wire	BR																																								
Signal Name [Specification]	-																																								
Connector No.	B4																																								
Connector Name	WIRE TO WIRE																																								
Connector Type	NS16MW-CS																																								
Terminal No.	15																																								
Color of Wire	BR																																								
Signal Name [Specification]	-																																								
Terminal No.	5																																								
Color of Wire	Y																																								
Signal Name [Specification]	-																																								
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B59</td></tr> <tr><td>Connector Name</td><td>REAR COMBINATION LAMP RH</td></tr> <tr><td>Connector Type</td><td>NS30MW-CS</td></tr> </table>  <p style="text-align: center;"><b>H.S.</b></p>	Connector No.	B59	Connector Name	REAR COMBINATION LAMP RH	Connector Type	NS30MW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>3</td></tr> <tr><td>Color of Wire</td><td>W</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	3	Color of Wire	W	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>4</td></tr> <tr><td>Color of Wire</td><td>B</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	4	Color of Wire	B	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>E105</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Type</td><td>TH80FW-CS16-TM4</td></tr> </table>  <p style="text-align: center;"><b>H.S.</b></p>	Connector No.	E105	Connector Name	WIRE TO WIRE	Connector Type	TH80FW-CS16-TM4	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>5</td></tr> <tr><td>Color of Wire</td><td>Y</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	5	Color of Wire	Y	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>8</td></tr> <tr><td>Color of Wire</td><td>GR</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	8	Color of Wire	GR	Signal Name [Specification]	-
Connector No.	B59																																								
Connector Name	REAR COMBINATION LAMP RH																																								
Connector Type	NS30MW-CS																																								
Terminal No.	3																																								
Color of Wire	W																																								
Signal Name [Specification]	-																																								
Terminal No.	4																																								
Color of Wire	B																																								
Signal Name [Specification]	-																																								
Connector No.	E105																																								
Connector Name	WIRE TO WIRE																																								
Connector Type	TH80FW-CS16-TM4																																								
Terminal No.	5																																								
Color of Wire	Y																																								
Signal Name [Specification]	-																																								
Terminal No.	8																																								
Color of Wire	GR																																								
Signal Name [Specification]	-																																								
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>B80</td></tr> <tr><td>Connector Name</td><td>REAR COMBINATION LAMP LH</td></tr> <tr><td>Connector Type</td><td>NS30MW-CS</td></tr> </table>  <p style="text-align: center;"><b>H.S.</b></p>	Connector No.	B80	Connector Name	REAR COMBINATION LAMP LH	Connector Type	NS30MW-CS	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>3</td></tr> <tr><td>Color of Wire</td><td>BR</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	3	Color of Wire	BR	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>4</td></tr> <tr><td>Color of Wire</td><td>B</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	4	Color of Wire	B	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M4</td></tr> <tr><td>Connector Name</td><td>DATA LINK CONNECTOR</td></tr> <tr><td>Connector Type</td><td>BD16FW</td></tr> </table>  <p style="text-align: center;"><b>H.S.</b></p>	Connector No.	M4	Connector Name	DATA LINK CONNECTOR	Connector Type	BD16FW	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>6</td></tr> <tr><td>Color of Wire</td><td>L</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	6	Color of Wire	L	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>14</td></tr> <tr><td>Color of Wire</td><td>P</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	14	Color of Wire	P	Signal Name [Specification]	-
Connector No.	B80																																								
Connector Name	REAR COMBINATION LAMP LH																																								
Connector Type	NS30MW-CS																																								
Terminal No.	3																																								
Color of Wire	BR																																								
Signal Name [Specification]	-																																								
Terminal No.	4																																								
Color of Wire	B																																								
Signal Name [Specification]	-																																								
Connector No.	M4																																								
Connector Name	DATA LINK CONNECTOR																																								
Connector Type	BD16FW																																								
Terminal No.	6																																								
Color of Wire	L																																								
Signal Name [Specification]	-																																								
Terminal No.	14																																								
Color of Wire	P																																								
Signal Name [Specification]	-																																								
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>E27</td></tr> <tr><td>Connector Name</td><td>FRONT COMBINATION LAMP LH</td></tr> <tr><td>Connector Type</td><td>Z03FGY</td></tr> </table>  <p style="text-align: center;"><b>H.S.</b></p>	Connector No.	E27	Connector Name	FRONT COMBINATION LAMP LH	Connector Type	Z03FGY	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>2</td></tr> <tr><td>Color of Wire</td><td>B</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	2	Color of Wire	B	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>3</td></tr> <tr><td>Color of Wire</td><td>BR</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	3	Color of Wire	BR	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>E46</td></tr> <tr><td>Connector Name</td><td>FRONT COMBINATION LAMP RH</td></tr> <tr><td>Connector Type</td><td>Z03FGY</td></tr> </table>  <p style="text-align: center;"><b>H.S.</b></p>	Connector No.	E46	Connector Name	FRONT COMBINATION LAMP RH	Connector Type	Z03FGY	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>2</td></tr> <tr><td>Color of Wire</td><td>B</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	2	Color of Wire	B	Signal Name [Specification]	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>3</td></tr> <tr><td>Color of Wire</td><td>GR</td></tr> <tr><td>Signal Name [Specification]</td><td>-</td></tr> </table>	Terminal No.	3	Color of Wire	GR	Signal Name [Specification]	-
Connector No.	E27																																								
Connector Name	FRONT COMBINATION LAMP LH																																								
Connector Type	Z03FGY																																								
Terminal No.	2																																								
Color of Wire	B																																								
Signal Name [Specification]	-																																								
Terminal No.	3																																								
Color of Wire	BR																																								
Signal Name [Specification]	-																																								
Connector No.	E46																																								
Connector Name	FRONT COMBINATION LAMP RH																																								
Connector Type	Z03FGY																																								
Terminal No.	2																																								
Color of Wire	B																																								
Signal Name [Specification]	-																																								
Terminal No.	3																																								
Color of Wire	GR																																								
Signal Name [Specification]	-																																								

JCLWM0887GE


# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]


## TURN SIGNAL AND HAZARD WARNING LAMPS

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH8DFW-CS16-TM4




Terminal No.	93	GR	Signal Name [Specification]	-
--------------	----	----	-----------------------------	---

Connector No.	M14
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS




Terminal No.	15	BR	Signal Name [Specification]	-
--------------	----	----	-----------------------------	---

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TK16FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	INPUT 1
2	B	INPUT 2
3	L	INPUT 3
4	GR	INPUT 4
5	BR	INPUT 5
8	P	OUTPUT 1
7	R	OUTPUT 2
6	G	OUTPUT 5
9	Y	OUTPUT 4
10	W	OUTPUT 3

Connector No.	M64
Connector Name	COMBINATION METER
Connector Type	SB46FW




Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L

Connector No.	M45
Connector Name	HAZARD SWITCH
Connector Type	TK04FW




Connector No.	M85
Connector Name	BSM (BODY CONTROL MODULE)
Connector Type	TH40FW



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	-
2	W	-

Terminal No.	Color of Wire	Signal Name [Specification]
2	G	INPUT 5
3	Y	INPUT 4
4	W	INPUT 3
5	R	INPUT 2
6	P	INPUT 1
29	W	HAZARD SW
32	BR	OUTPUT 5
33	GR	OUTPUT 4
34	L	OUTPUT 3
35	B	OUTPUT 2
36	V	OUTPUT 1

Connector No.	M67
Connector Name	BSM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA



Terminal No.	Color of Wire	Signal Name [Specification]
57	G	BAT FUSE
60	BR	FLASHER OUT PUT (LEFT)
61	GR	FLASHER OUT PUT (RIGHT)
67	B	GND
70	Y	BAT FL

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## TURN SIGNAL AND HAZARD WARNING LAMPS

Connector No.	W77
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name (Specification)
5	Y	
8	GR	
9	BR	

JCLWM0889GE

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

### Wiring Diagram - PARKING, LICENSE PLATE AND TAIL LAMPS -

INFOID:000000001720234



2007/07/13


JCLWM0896GE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]



JCLWM0897GE

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	B53	Connector No.	B34	Connector No.	B11	Connector No.	B54
Connector Name	WIRE TO WIRE	Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)	Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE
Connector Type	TH22MW-NH	Connector Type	A03FW	Connector Type	TH80MW-CS (6-TM4)	Connector Type	NS12MW-CS



							
---	---	---	---	---	---	---	---

Terminal No.	15	Terminal No.	2	Terminal No.	8	Terminal No.	1
Color of Wire	P	Color of Wire	P	Color of Wire	R	Color of Wire	Y
Signal Name [Specification]		Signal Name [Specification]		Signal Name [Specification]		Signal Name [Specification]	

Connector No.	B55	Connector No.	B77	Connector No.	B59	Connector No.	B79
Connector Name	WIRE TO WIRE	Connector Name	WIRE TO WIRE	Connector Name	REAR COMBINATION LAMP RH	Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS	Connector Type	NS10MW-CS	Connector Type	NS04MW-CS	Connector Type	MM4MW-LC

							
---	---	---	---	---	---	---	---

Terminal No.	6	Terminal No.	6	Terminal No.	1	Terminal No.	3
Color of Wire	R	Color of Wire	R	Color of Wire	R	Color of Wire	B
Signal Name [Specification]		Signal Name [Specification]		Signal Name [Specification]		Signal Name [Specification]	

JCLWM0898GE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	B80
Connector Name	REAR COMBINATION LAMP LH
Connector Type	NS24MW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	Y	-
4	B	-

Connector No.	D151
Connector Name	WIRE TO WIRE
Connector Type	NS00FBR-CS




Terminal No.	Color of Wire	Signal Name [Specification]
2	R	-

Connector No.	D152
Connector Name	WIRE TO WIRE
Connector Type	M02FW-GY-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-

Connector No.	D157
Connector Name	WIRE TO WIRE
Connector Type	NS10FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
6	R	-

Connector No.	D159
Connector Name	WIRE TO WIRE
Connector Type	M04FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
3	B	-

Connector No.	D181
Connector Name	WIRE TO WIRE
Connector Type	NS00M8R-CS



Terminal No.	Color of Wire	Signal Name [Specification]
2	R	-

Connector No.	D182
Connector Name	WIRE TO WIRE
Connector Type	M02MW-GY-LC



Terminal No.	Color of Wire	Signal Name [Specification]
2	B	-

Connector No.	D195
Connector Name	LICENSE PLATE LAMP LH
Connector Type	TK02FBR



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-

JCLWM0899GE

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	D196
Connector Name	LICENSE PLATE LAMP RH
Connector Type	TK02FBR



Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	E11
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	M06FB-LC



Terminal No.	Color of Wire	Signal Name [Specification]
11	B	-

Connector No.	E13
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH12FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
25	B	-
26	P	-
27	L	-

Connector No.	E14
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS12FBR-CS



Terminal No.	Color of Wire	Signal Name [Specification]
37	R	-
38	R	-
39	GR	-

Connector No.	E27
Connector Name	FRONT COMBINATION LAMP LH
Connector Type	Z03FGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	E46
Connector Name	FRONT COMBINATION LAMP RH
Connector Type	Z03FGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	-
2	B	-

Connector No.	E101
Connector Name	WIRE TO WIRE
Connector Type	TH8DFW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
8	R	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH8DFW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-
12	P	-
22	L	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS

Connector No.	M24
Connector Name	COMBINATION METER
Connector Type	SA840FW



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TK18FW



12	13	10	9	8	7	14	11	1	2	3	4	5	6
----	----	----	---	---	---	----	----	---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	V	INPUT 1
2	B	INPUT 2
3	L	INPUT 3
4	GR	INPUT 4
5	BR	INPUT 5
6	P	OUTPUT 1
7	R	OUTPUT 2
8	G	OUTPUT 5
9	Y	OUTPUT 4
10	W	OUTPUT 3

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA



56	57	58	59	60	61	62	63	64	65	66	67	68	69	70
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
57	G	BAT FUSE
67	B	GND
70	Y	BAT FL

Connector No.	M13
Connector Name	WIRE TO WIRE
Connector Type	TH42FW-NH



16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17
----	----	----	----	----	----	----	---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
15	W	-

38	G	IGN
39	L	CAN-H
40	P	CAN-L

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



9	10	11	12	13	14	15	16	1	2	3	4	5	6	7	8
---	----	----	----	----	----	----	----	---	---	---	---	---	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
6	L	-
14	P	-

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
2	G	INPUT 5
3	Y	INPUT 4
4	W	INPUT 3
5	R	INPUT 2
6	P	INPUT 1
11	SB	ACC
32	BR	OUTPUT 5
33	GR	OUTPUT 4
34	L	OUTPUT 3
35	B	OUTPUT 2
36	V	OUTPUT 1

JCLWM0901GE

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

**PARKING, LICENSE PLATE AND TAIL LAMPS**

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	THEBMW-CS (F-TM4)



Terminal No.	Color of Wire	Signal Name [Specification]
5	Y	-
12	P	-
22	L	-

JCLWM0902GE

# STOP LAMP

< COMPONENT DIAGNOSIS >


[HALOGEN TYPE]

## STOP LAMP

Wiring Diagram - STOP LAMP -

INFOID:000000001720235

STOP LAMP



2007/07/13

JCLWM0890GE

# STOP LAMP

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## STOP LAMP

Connector No.	B59
Connector Name	REAR COMBINATION LAMP RH
Connector Type	NS30AMP-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	
2	Y	
4	B	

Connector No.	B55
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	
6	R	

Connector No.	B54
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	
6	R	

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	TH30MW-CS (F-TM4)




Terminal No.	Color of Wire	Signal Name [Specification]
9	Y	

Connector No.	D157
Connector Name	WIRE TO WIRE
Connector Type	NS10FW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	B	
2	Y	

Connector No.	D154
Connector Name	HIGH-MOUNTED STOP LAMP
Connector Type	TK02FW




Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	
2	B	

Connector No.	B80
Connector Name	REAR COMBINATION LAMP LH
Connector Type	NS30MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	R	
2	Y	
4	B	

Connector No.	B77
Connector Name	WIRE TO WIRE
Connector Type	NS10MW-CS




Terminal No.	Color of Wire	Signal Name [Specification]
1	B	
2	Y	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# STOP LAMP

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]


## STOP LAMP

Connector No.	E101
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4





Terminal No.	Color of Wire	Signal Name [Specification]
9	Y	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4





Terminal No.	Color of Wire	Signal Name [Specification]
4	V	-

Connector No.	E115
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC




Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	Y	-
3	G	-
4	L	-

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80MM-CS16-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
4	Y	-

JCLWM0892GE

# BACK-UP LAMP

< COMPONENT DIAGNOSIS >


[HALOGEN TYPE]

## BACK-UP LAMP

Wiring Diagram - BUCK-UP LAMP -

INFOID:000000001720236

BACK-UP LAMP



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

2007/07/13

JCLWM0893GE


# BACK-UP LAMP

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## BACK-UP LAMP

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4

Terminal No.	1	Color of Wire	G	Signal Name [Specification]	-
--------------	---	---------------	---	-----------------------------	---

Connector No.	B77
Connector Name	WIRE TO WIRE
Connector Type	NS10MWF-CS




Terminal No.	5	Color of Wire	G	Signal Name [Specification]	-
--------------	---	---------------	---	-----------------------------	---

Connector No.	B79
Connector Name	WIRE TO WIRE
Connector Type	M04MW-LC




Terminal No.	3	Color of Wire	B	Signal Name [Specification]	-
--------------	---	---------------	---	-----------------------------	---

Connector No.	D151
Connector Name	WIRE TO WIRE
Connector Type	NS30FBR-CS




Terminal No.	8	Color of Wire	G	Signal Name [Specification]	-
--------------	---	---------------	---	-----------------------------	---

Connector No.	D152
Connector Name	WIRE TO WIRE
Connector Type	M02FW-GY-LC




Terminal No.	2	Color of Wire	B	Signal Name [Specification]	-
--------------	---	---------------	---	-----------------------------	---

Connector No.	D156
Connector Name	BACK-UP LAMP LH
Connector Type	NS02FW-CS




Terminal No.	1	Color of Wire	Y	Signal Name [Specification]	-
Terminal No.	2	Color of Wire	B	Signal Name [Specification]	-

Connector No.	D157
Connector Name	WIRE TO WIRE
Connector Type	NS10FW-CS




Terminal No.	5	Color of Wire	G	Signal Name [Specification]	-
--------------	---	---------------	---	-----------------------------	---

Connector No.	D159
Connector Name	WIRE TO WIRE
Connector Type	M04FW-LC




Terminal No.	3	Color of Wire	B	Signal Name [Specification]	-
--------------	---	---------------	---	-----------------------------	---

JCLWM0894GE

# BACK-UP LAMP

< COMPONENT DIAGNOSIS >

[HALOGEN TYPE]

## BACK-UP LAMP

<p>Connector No. D181</p> <p>Connector Name WIRE TO WIRE</p> <p>Connector Type NS38MR-CS</p>	<p>Connector No. E6</p> <p>Connector Name WIRE TO WIRE</p> <p>Connector Type TK24MF-TV</p>	<p>Terminal No. 8</p> <p>Color of Wire G</p> <p>Signal Name [Specification]</p>	<p>Terminal No. 2</p> <p>Color of Wire SB</p> <p>Signal Name [Specification]</p>
<p>Connector No. D182</p> <p>Connector Name WIRE TO WIRE</p> <p>Connector Type M02MH-GY-LC</p>	<p>Connector No. D194</p> <p>Connector Name BACK-UP LAMP RH</p> <p>Connector Type NS02FW-CS</p>	<p>Terminal No. 2</p> <p>Color of Wire B</p> <p>Signal Name [Specification]</p>	<p>Terminal No. 2</p> <p>Color of Wire SB</p> <p>Signal Name [Specification]</p>
<p>Connector No. E15</p> <p>Connector Name IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</p> <p>Connector Type NS16FW-CS</p>	<p>Connector No. F21</p> <p>Connector Name PARK / NEUTRAL POSITION SWITCH</p> <p>Connector Type RK08FG</p>	<p>Terminal No. 1</p> <p>Color of Wire G</p> <p>Signal Name [Specification]</p>	<p>Terminal No. 2</p> <p>Color of Wire SB</p> <p>Signal Name [Specification]</p>
<p>Connector No. E101</p> <p>Connector Name WIRE TO WIRE</p> <p>Connector Type TH80FW-CS16-TM4</p>	<p>Connector No. F23</p> <p>Connector Name WIRE TO WIRE</p> <p>Connector Type TK24FW-TV</p>	<p>Terminal No. 1</p> <p>Color of Wire G</p> <p>Signal Name [Specification]</p>	<p>Terminal No. 2</p> <p>Color of Wire SB</p> <p>Signal Name [Specification]</p>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

## ECU DIAGNOSIS

### BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000003050024

#### VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
IGN ON SW	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
KEY ON SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted to key cylinder	On
CDL LOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the lock side	On
CDL UNLOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the unlock side	On
DOOR SW-DR	Driver's door closed	Off
	Driver's door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
BACK DOOR SW	Back door closed	Off
	Back door opened	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEYLESS LOCK	"LOCK" button of key fob is not pressed	Off
	"LOCK" button of key fob is pressed	On
KEYLESS UNLOCK	"UNLOCK" button of key fob is not pressed	Off
	"UNLOCK" button of key fob is pressed	On
I-KEY LOCK	"LOCK" button of Intelligent Key or door request switch are not pressed	Off
	"LOCK" button of Intelligent Key or door request switch are pressed	On
I-KEY UNLOCK	"UNLOCK" button of Intelligent Key or door request switch are not pressed	Off
	"UNLOCK" button of Intelligent Key or door request switch are pressed	On
ACC ON SW	Ignition switch OFF	Off
	Ignition switch ACC or ON	On
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
LIGHT SW 1ST	Lighting switch OFF	Off
	Lighting switch 1ST	On

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Monitor Item	Condition	Value/Status	
BUCKLE SW	The seat belt (driver side) is unfastened. [Seat belt switch (driver side) OFF]	Off	A
	The seat belt (driver side) is fastened. [Seat belt switch (driver side) ON]	On	B
KEYLESS PANIC	PANIC button of key fob is not pressed	Off	C
	PANIC button of key fob is pressed	On	
KEYLESS TRUNK	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
TRNK OPN MNTR	<b>NOTE:</b> The item is indicated, but not monitored.	Off	D
RKE LCK-UNLCK	LOCK/UNLOCK button of key fob is not pressed and held simultaneously	Off	E
	LOCK/UNLOCK button of key fob is pressed and held simultaneously	On	
RKE KEEP UNLK	UNLOCK button of key fob is not pressed	Off	F
	UNLOCK button of key fob is pressed and held	On	
HI BEAM SW	Lighting switch OFF	Off	G
	Lighting switch HI	On	
HEAD LAMP SW 1	Lighting switch OFF	Off	H
	Lighting switch 2ND	On	
HEAD LAMP SW 2	Lighting switch OFF	Off	I
	Lighting switch 2ND	On	
AUTO LIGHT SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
PASSING SW	Other than lighting switch PASS	Off	J
	Lighting switch PASS	On	
FR FOG SW	Front fog lamp switch OFF	Off	K
	Front fog lamp switch ON	On	
RR FOG SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
TURN SIGNAL R	Turn signal switch OFF	Off	EXL
	Turn signal switch RH	On	
TURN SIGNAL L	Turn signal switch OFF	Off	M
	Turn signal switch LH	On	
ENGINE RUN	Engine stopped	Off	N
	Engine running	On	
PKB SW	Parking brake switch is OFF	Off	O
	Parking brake switch is ON	On	
CARGO LAMP SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off	
OPTICAL SENSOR	<b>NOTE:</b> The item is indicated, but not monitored.	0 V	P
IGN SW CAN	Ignition switch OFF or ACC	Off	
	Ignition switch ON	On	
FR WIPER HI	Front wiper switch OFF	Off	
	Front wiper switch HI	On	
FR WIPER LOW	Front wiper switch OFF	Off	
	Front wiper switch LO	On	

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Monitor Item	Condition	Value/Status
FR WIPER INT	Front wiper switch OFF	Off
	Front wiper switch INT	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7
FR WIPER STOP	Any position other than front wiper stop position	Off
	Front wiper stop position	On
VEHICLE SPEED	While driving	Equivalent to speedometer reading
RR WIPER ON	Rear wiper switch OFF	Off
	Rear wiper switch ON	On
RR WIPER INT	Rear wiper switch OFF	Off
	Rear wiper switch INT	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER STOP	Rear wiper stop position	Off
	Other than rear wiper stop position	On
RR WIPER STP2	<b>NOTE:</b> The item is indicated, but not monitored.	Off
H/L WASH SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch OFF	Off
	Hazard switch ON	On
BRAKE SW	Brake pedal is not depressed	Off
	Brake pedal is depressed	On
FAN ON SIG	Blower fan motor switch OFF	Off
	Blower fan motor switch ON (other than OFF)	On
AIR COND SW	Compressor ON is not requested from auto amp. (A/C indicator OFF, blower fan motor switch OFF or etc.)	Off
	Compressor ON is requested from auto amp. (A/C indicator ON and blower fan motor switch ON).	On
I-KEY TRUNK	<b>NOTE:</b> The item is indicated, but not monitored.	Off
I-KEY PW DWN	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed and held	On
I-KEY PANIC	PANIC button of Intelligent Key is not pressed	Off
	PANIC button of Intelligent Key is pressed	On
PUSH SW	Return to ignition switch to "LOCK" position	Off
	Press ignition switch	On
TRNK OPNR SW	When back door opener switch is not pressed	Off
	When back door opener switch is pressed	On
TRUNK CYL SW	<b>NOTE:</b> The item is indicated, but not monitored.	Off
HOOD SW	Close the hood <b>NOTE:</b> Vehicles of except for Mexico are OFF-fixed	Off
	Open the hood	On

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Monitor Item	Condition	Value/Status
OIL PRESS SW	<ul style="list-style-type: none"> <li>• Ignition switch OFF or ACC</li> <li>• Engine running</li> </ul>	Off
	Ignition switch ON	On
AIR PRESS FL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front LH tire
AIR PRESS FR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of front RH tire
AIR PRESS RR	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear RH tire
AIR PRESS RL	Ignition switch ON (Only when the signal from the transmitter is received)	Air pressure of rear LH tire
ID REGST FL1	ID of front LH tire transmitter is registered	Done
	ID of front LH tire transmitter is not registered	Yet
ID REGST FR1	ID of front RH tire transmitter is registered	Done
	ID of front RH tire transmitter is not registered	Yet
ID REGST RR1	ID of rear RH tire transmitter is registered	Done
	ID of rear RH tire transmitter is not registered	Yet
ID REGST RL1	ID of rear LH tire transmitter is registered	Done
	ID of rear LH tire transmitter is not registered	Yet
WARNING LAMP	Tire pressure indicator OFF	Off
	Tire pressure indicator ON	On
BUZZER	Tire pressure warning alarm is not sounding	Off
	Tire pressure warning alarm is sounding	On

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

## TERMINAL LAYOUT



### PHYSICAL VALUES

**CAUTION:**





- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF is not to be fluctuated by being overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT-III. Refer to [BCS-26. "COMB SW : CONSULT-III Function \(BCM - COMB SW\)"](#).
- BCM reads the status of the combination switch at 10 ms internal normally. Refer to [BCS-9. "System Diagram"](#).

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output	Ignition key hole illumination	OFF ON	
1 (V)	Ground	Ignition key hole illumination control	Output	Ignition key hole illumination	OFF ON	Battery voltage 0 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
2 (G)	Ground	Combination switch INPUT 5	Input	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Turn signal switch RH	
					Lighting switch HI	
					Lighting switch 1ST	
					Lighting switch 2ND	
3 (Y)	Ground	Combination switch INPUT 4	Input	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Turn signal switch LH	
					Lighting switch PASS	
					Lighting switch 2ND	
				Front fog lamp switch ON		
4 (W)	Ground	Combination switch INPUT 3	Input	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	0 V
					Front wiper switch LO	
					Front wiper switch MIST	
					Front wiper switch INT	






A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >





[HALOGEN TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
5 (R)	Ground	Combination switch INPUT 2	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front washer switch (Wiper intermittent dial 4) Rear washer ON (Wiper intermittent dial 4) Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>	 <p style="text-align: right; font-size: small;">PKIB4955J</p>
					Rear wiper switch ON (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4955J</p>
						1.0 V
6 (P)	Ground	Combination switch INPUT 1	Input	Combination switch	All switch OFF (Wiper intermittent dial 4)	0 V
					Front wiper switch HI (Wiper intermittent dial 4) Rear wiper switch INT (Wiper intermittent dial 4) Wiper intermittent dial 3 (All switch OFF)	 <p style="text-align: right; font-size: small;">PKIB4959J</p>
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> </ul>	 <p style="text-align: right; font-size: small;">PKIB4952J</p>
					Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>	 <p style="text-align: right; font-size: small;">PKIB4955J</p>
						1.0 V
						1.7 V
						0.8 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
7 (L)	Ground	Door key cylinder switch UNLOCK signal	Input	Door key cylinder switch	NEUTRAL position	 <small>JPMIA0587GB</small> 8.0 - 8.5 V
				Door key cylinder switch	UNLOCK position	0 V
8 (R)	Ground	Door key cylinder switch LOCK signal	Input	Door key cylinder switch	NEUTRAL position	 <small>JPMIA0587GB</small> 8.0 - 8.5 V
				Door key cylinder switch	LOCK position	0 V
9 (R)	Ground	Stop lamp switch	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
				Stop lamp switch	ON (Brake pedal is de- pressed)	Battery voltage
10 (SB)	Ground	Rear window defog- ger switch	Input	Rear window defogger switch	Not pressed	Battery voltage
				Rear window defogger switch	Pressed	0 V
11 (SB)	Ground	Ignition switch ACC	Input	Ignition switch OFF		0 V
				Ignition switch ACC or ON		Battery voltage
12 (P)	Ground	Passenger door switch	Input	Passenger door switch	OFF (When passenger door closed)	 <small>JPMIA0586GB</small> 7.5 - 8.0 V
				Passenger door switch	ON (When passenger door opened)	0 V
13 (LG)	Ground	Rear door switch RH	Input	Rear door switch RH	OFF (When rear door RH closed)	 <small>JPMIA0587GB</small> 8.0 - 8.5 V
				Rear door switch RH	ON (When rear door RH opened)	0 V




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >




[HALOGEN TYPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
15*1 (O)	Ground	TPMS mode trigger switch	Input	Ignition switch OFF		 <p style="text-align: right; font-size: small;">JPMIA0588GB</p> <p style="text-align: center;">1.5 V</p>
18*1 (O)	Ground	Remote keyless entry receiver ground	Input	Ignition switch ON		0 V
19*1 (V)	Ground	Remote keyless entry receiver power supply	Input	Without Intelligent Key system	At any condition	5 V
				With Intelligent Key system	<ul style="list-style-type: none"> <li>• Ignition switch OFF</li> <li>• For 3 seconds after ignition switch OFF to ON</li> </ul>	0 V
						3 seconds or later after ignition switch OFF to ON
20*1 (GR)	Ground	Remote keyless entry receiver signal	Input	Without Intelligent Key system	At any condition	 <p style="text-align: right; font-size: small;">JPMIA0589GB</p> <p><b>NOTE:</b> The wave form changes according to signal-receiving condition.</p>
						With Intelligent Key system
				3 seconds or later after ignition switch OFF to ON	 <p style="text-align: right; font-size: small;">JPMIA0589GB</p> <p><b>NOTE:</b> The wave form changes according to signal-receiving condition.</p>	
					21 (G)	Ground

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]





Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
23 (B)	Ground	Security indicator signal	Input	Security indica- tor	ON	0 V
				Blinking (Ignition switch OFF)		
25 (BR)	Ground	Immobilizer anten- na signal (Rx, Tx)	Input/ Output	Ignition switch OFF	Battery voltage	
27 (Y)	Ground	A/C switch	Input	Ignition switch ON	A/C switch OFF	
				A/C switch ON	0 V	
28 (LG)	Ground	Blower fan switch	Input	Ignition switch ON	Blower fan switch OFF	
				Blower fan switch ON	0 V	
29 (W)	Ground	Hazard switch	Input	Hazard switch	OFF	Battery voltage
				Hazard switch	ON	0 V
30 (G)	Ground	Back door opener switch	Input	Back door opener switch	Not pressed	Battery voltage
				Back door opener switch	Pressed	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >







[HALOGEN TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)		
+	-	Signal name	Input/ Output				
32 (BR)	Ground	Combination switch OUTPUT 5	Output	Combination switch	All switch OFF (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="text-align: right; margin-right: 50px;">7.2 V</p> </div>		
				Front fog lamp switch ON (Wiper intermittent dial 4)	Rear wiper switch ON (Wiper intermittent dial 4)	Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 2</li> <li>• Wiper intermittent dial 6</li> <li>• Wiper intermittent dial 7</li> </ul>	<div style="text-align: right;">  <p style="text-align: right; margin-right: 50px;">1.0 V</p> </div>
						Combination switch OUTPUT 4	Output
33 (GR)	Ground	Combination switch OUTPUT 4	Output	Lighting switch 1ST (Wiper intermittent dial 4)	Lighting switch 1ST (Wiper intermittent dial 4) <div style="text-align: right;">  <p style="text-align: right; margin-right: 50px;">1.2 V</p> </div>		
				Rear wiper switch INT (Wiper intermittent dial 4)	Rear wiper switch INT (Wiper intermittent dial 4)	Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>• Wiper intermittent dial 1</li> <li>• Wiper intermittent dial 5</li> <li>• Wiper intermittent dial 6</li> </ul>	<div style="text-align: right;">  <p style="text-align: right; margin-right: 50px;">1.2 V</p> </div>
						Combination switch OUTPUT 5	Output

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
34 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch	All switch OFF (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.2 V</p>
					Lighting switch 2ND (Wiper intermittent dial 4)	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Lighting switch HI (Wiper intermittent dial 4)	
					Rear washer switch ON (Wiper intermittent dial 4)	
Any of the condition below with all switch OFF <ul style="list-style-type: none"> <li>Wiper intermittent dial 1</li> <li>Wiper intermittent dial 2</li> <li>Wiper intermittent dial 3</li> </ul>						
35 (B)	Ground	Combination switch OUTPUT 2	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.2 V</p>
					Lighting switch 2ND	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Lighting switch PASS	
					Front wiper switch INT	
Front wiper switch HI						
36 (V)	Ground	Combination switch OUTPUT 1	Output	Combination switch (Wiper intermit- tent dial 4)	All switch OFF	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.2 V</p>
					Turn signal switch RH	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
					Turn signal switch LH	
					Front wiper switch LO (Front wiper switch MIST)	
Front washer switch ON						




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >



[HALOGEN TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
37 (LG)	Ground	Key switch	Input	Insert mechanical key into ignition key cylinder	Battery voltage
				Remove mechanical key from ignition key cylinder	0 V
38 (G)	Ground	Ignition switch ON	Input	Ignition switch OFF or ACC	0 V
				Ignition switch ON or START	Battery voltage
39 (L)	Ground	CAN-H	Input/ Output	—	—
40 (P)	Ground	CAN-L	Input/ Output	—	—
43 (V)	Ground	Back door switch	Input	Back door switch OFF (When back door closed)	
				Back door switch ON (When back door opened)	0 V
44 (B)	Ground	Rear wiper auto stop	Input	Ignition switch ON Rear wiper stop position	0 V
				Any position other than rear wiper stop position	Battery voltage
45 (P)	Ground	Door lock and unlock switch LOCK signal	Input	Door lock and unlock switch NEUTRAL position	
				Door lock and unlock switch LOCK position	0 V
46 (BR)	Ground	Door lock and unlock switch UNLOCK signal	Input	Door lock and unlock switch NEUTRAL position	
				Door lock and unlock switch UNLOCK position	0 V

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]



Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
47 (W)	Ground	Driver door switch	Input	Driver door switch	OFF (When driver door closed)	 <p style="text-align: center;">8.0 - 8.5 V</p>
				ON (When driver door opened)	0 V	
48 (GR)	Ground	Rear door switch LH	Input	Rear door switch LH	OFF (When rear door LH closed)	 <p style="text-align: center;">8.5 - 9.0 V</p>
				ON (When rear door LH opened)	0 V	
49 (L)	Ground	Back door lamp control	Output	Back door lamp switch DOOR position	Back door is closed (Back door lamp turns OFF)	Battery voltage
				Back door is opened (Back door lamp turns ON)	0 V	
53 (V)	Ground	Back door open	Output	Back door opener switch	Not pressed (Back door actuator is activated)	0 V
					Pressed (Back door actuator is activated)	Battery voltage
55 (SB)	Ground	Rear wiper motor	Output	Ignition switch ON	Rear wiper switch OFF	0 V
					Rear wiper switch ON	Battery voltage
56 (Y)	Ground	Interior room lamp power supply	Output	After passing the interior room lamp battery saver operation time		0 V
				Any other time after passing the interior room lamp battery saver operation time		Battery voltage
57 (G)	Ground	Battery power supply	Input	Ignition switch OFF		Battery voltage
59 (L)	Ground	Driver door UN-LOCK	Output	Driver door	UNLOCK (Actuator is activated)	Battery voltage
					Other than UNLOCK (Actuator is not activated)	0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
60 (BR)	Ground	Turn signal LH	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch LH	
61 (GR)	Ground	Turn signal RH	Output	Ignition switch ON	Turn signal switch OFF 0 V
				Turn signal switch RH	
63 (R)	Ground	Interior room lamp timer control	Output	Interior room lamp	OFF Battery voltage
				ON	0 V
65 (V)	Ground	All doors LOCK	Output	All doors	LOCK (Actuator is activat- ed) Battery voltage
				Other then LOCK (Actua- tor is not activated)	0 V
66 (G)	Ground	Passenger door and rear door UNLOCK	Output	Passenger door and rear door	UNLOCK (Actuator is activat- ed) Battery voltage
				Other then UNLOCK (Ac- tuator is not activated)	0 V
67 (B)	Ground	Ground	Output	Ignition switch ON	0 V
68 (L)	Ground	P/W power supply (RAP)	Output	Ignition switch ON	Battery voltage
69 (R)*2 (P)*3	Ground	P/W power supply (BAT)	Output	Ignition switch OFF	Battery voltage
70 (Y)	Ground	Battery power sup- ply	Input	Ignition switch OFF	Battery voltage

**NOTE:**

- \*1: Except for Mexico
- \*2: Without anti-pinch system
- \*3: With anti-pinch system


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

## Wiring Diagram - BCM -

INFOID:000000003050025



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

◊IK◊ : With Intelligent Key  
 ◊OI◊ : Without Intelligent Key




# BCM (BODY CONTROL MODULE)

[HALOGEN TYPE]

< ECU DIAGNOSIS >

- ◊XM◊ : Except for Mexico
- ◊SR◊ : With sunroof
- ◊PS◊ : With power seat
- ◊AN◊ : With anti-pinch system
- ◊VM◊ : With vanity mirror lamp



\* : This connector is not shown in "Harness Layout".


JCMWM1031G

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]



JCMWM1032G

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

## BCM (BODY CONTROL MODULE)

Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TK16FW



12	13	10	9	8	7		
14	11	1	2	3	4	5	6

Terminal No.	Color of Wire	Signal Name [Specification]
1	V	INPUT 1
2	B	INPUT 2
3	L	INPUT 3
4	GR	INPUT 4
5	BR	INPUT 5
6	P	OUTPUT 1
7	R	OUTPUT 2
8	G	OUTPUT 5
9	Y	OUTPUT 4
10	W	OUTPUT 3

Connector No.	M67
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHA6-SA



56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			

Terminal No.	Color of Wire	Signal Name [Specification]
56	Y	BATTERYSAVEROUTPUT
57	G	BAT FUSE
58	L	D/L UNLOCK DR
60	BR	FLASHER OUT PUT (LEFT)
61	GR	FLASHER OUT PUT (RIGHT)
63	R	ROOMLAMPOUTPUT
65	V	D/L LOCK ALL
66	G	D/L UNLOCK OTHER
67	B	GND
68	L	POWER WDW OUTPUT(16AP)
69	R	POWER WDW OUTPUT(16B&C, anti-theft system)
70	P	POWER WDW OUTPUT(16A anti-theft system)
	Y	BAT FL

Connector No.	M65
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH4QFW



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
1	V	KEY RING OUTPUT
2	G	INPUT 5
3	Y	INPUT 4
4	W	INPUT 3
5	R	INPUT 2
6	P	INPUT 1
7	L	KEY CYL UNLOCK
8	R	KEY CYL LOCK SW
9	R	BRAKE SW
10	SB	RR DEF SW
11	SB	ACC

Terminal No.	Color of Wire	Signal Name [Specification]
12	P	DR SW AS
13	LG	DR SW RR
15	O	TRMS MODE TRIGGER SW
18	O	KEYLESS TUNER SECS GND
19	V	KEYLESS TUNER POWER
20	GR	KEYLESS TUNER SIGNAL
21	G	IMMOBIL ANT(GLOCK)
23	B	SECURITY IND OUT PUT
25	BR	IMMOBIL ANT(RX.TX)
27	Y	AIRGON SW
28	LG	BLOWER FAN SW
29	W	HAZARD SW
30	G	BACK DOOR OPEN SW
32	BR	OUTPUT 5
33	GR	OUTPUT 4
34	L	OUTPUT 3
35	B	OUTPUT 2
36	V	OUTPUT 1
37	LG	KEY SW
38	G	IGN
39	L	CAN-H
40	P	CAN-L

Connector No.	M66
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FHA6-SA



41	42	43	44	45	46	47	48	49
50	51	52	53	54	55			

Terminal No.	Color of Wire	Signal Name [Specification]
43	V	BACK DOOR SW
44	B	RR WIP AUTO STOP
45	P	GDL LOCKSW
46	BR	GDL UNLOCKSW
47	W	DR SW DR
48	GR	DR SW RL
49	L	LUGGAGE LAMP OUTPUT
53	V	BACKDOORPENEROUTPUT
55	SB	RR WIP MTR OUT

## Fail Safe

### REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper auto stop signal. When the rear wiper auto stop signal does not change more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

JCMWM1033GI

INFOID:0000000003050026

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BCM (BODY CONTROL MODULE)

[HALOGEN TYPE]

## < ECU DIAGNOSIS >

1. Pass more than 1 minute after the rear wiper stop.
2. Turn rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

### HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

#### NOTE:

The blinking speed is normal while activating the hazard warning lamp.

### DTC Inspection Priority Chart

INFOID:000000003050027

Priority	DTC
1	U1000: CAN COMM CIRCUIT
2	C1735: IGN CIRCUIT OPEN
3	<ul style="list-style-type: none"> <li>• C1704: LOW PRESSURE FL</li> <li>• C1705: LOW PRESSURE FR</li> <li>• C1706: LOW PRESSURE RR</li> <li>• C1707: LOW PRESSURE RL</li> <li>• C1708: [NO DATA] FL</li> <li>• C1709: [NO DATA] FR</li> <li>• C1710: [NO DATA] RR</li> <li>• C1711: [NO DATA] RL</li> <li>• C1712: [CHECKSUM ERR] FL</li> <li>• C1713: [CHECKSUM ERR] FR</li> <li>• C1714: [CHECKSUM ERR] RR</li> <li>• C1715: [CHECKSUM ERR] RL</li> <li>• C1716: [PRESS DATA ERR] FL</li> <li>• C1717: [PRESS DATA ERR] FR</li> <li>• C1718: [PRESS DATA ERR] RR</li> <li>• C1719: [PRESS DATA ERR] RL</li> <li>• C1720: [CODE ERR] FL</li> <li>• C1721: [CODE ERR] FR</li> <li>• C1722: [CODE ERR] RR</li> <li>• C1723: [CODE ERR] RL</li> <li>• C1724: [BATT VOLT LOW] FL</li> <li>• C1725: [BATT VOLT LOW] FR</li> <li>• C1726: [BATT VOLT LOW] RR</li> <li>• C1727: [BATT VOLT LOW] RL</li> <li>• C1729: VHCL SPEED SIG ERR</li> </ul>

### DTC Index

INFOID:000000003050028

#### NOTE:

Details of time display

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

DTC	Tire pressure monitor warning lamp ON	Reference
U1000: CAN COMM CIRCUIT	—	<a href="#">BCS-35</a>
C1704: LOW PRESSURE FL	×	<a href="#">WT-14</a>
C1705: LOW PRESSURE FR	×	
C1706: LOW PRESSURE RR	×	
C1707: LOW PRESSURE RL	×	

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

DTC	Tire pressure monitor warning lamp ON	Reference	
C1708: [NO DATA] FL	×	<a href="#">WT-16</a>	A
C1709: [NO DATA] FR	×		B
C1710: [NO DATA] RR	×		C
C1711: [NO DATA] RL	×	<a href="#">WT-19</a>	D
C1712: [CHECKSUM ERR] FL	×		E
C1713: [CHECKSUM ERR] FR	×		F
C1714: [CHECKSUM ERR] RR	×	<a href="#">WT-22</a>	G
C1715: [CHECKSUM ERR] RL	×		H
C1716: [PRESS DATA ERR] FL	×		I
C1717: [PRESS DATA ERR] FR	×	<a href="#">WT-24</a>	J
C1718: [PRESS DATA ERR] RR	×		K
C1719: [PRESS DATA ERR] RL	×		L
C1720: [CODE ERR] FL	×	<a href="#">WT-27</a>	M
C1721: [CODE ERR] FR	×		N
C1722: [CODE ERR] RR	×		O
C1723: [CODE ERR] RL	×	<a href="#">WT-30</a>	P
C1724: [BATT VOLT LOW] FL	—		Q
C1725: [BATT VOLT LOW] FR	—		R
C1726: [BATT VOLT LOW] RR	—	<a href="#">WT-30</a>	S
C1727: [BATT VOLT LOW] RL	—		T
C1729: VHCL SPEED SIG ERR	×	<a href="#">WT-30</a>	U
C1735: IGN CIRCUIT OPEN	—	<a href="#">BCS-36</a>	V

EXL

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:000000003050035

### VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition		Value/Status
MOTOR FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	1 - 4
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (Compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	Lighting switch 1ST or 2ND		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND		On
HL HI REQ	Lighting switch OFF		Off
	Lighting switch HI (Light is illuminated)		On
FR FOG REQ <b>NOTE:</b> This item is monitored only on the vehicle with front fog lamp.	Lighting switch 2ND	Front fog lamp switch OFF	Off
		Front fog lamp switch ON	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch INT	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
ST RLY REQ <b>NOTE:</b> Vehicle without Intelligent Key system indicates only "ON", and it does not change.	When Intelligent Key is outside the vehicle, and the push switch is pushed		Off
	When Intelligent Key is inside the vehicle, and the push switch is pushed		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
RR DEF REQ	Ignition switch ON	Rear window defogger switch OFF	Off
		Rear window defogger switch ON (Rear window defogger is operating)	On
OIL P SW	Ignition switch OFF, ACC or engine running		Open
	Ignition switch ON		Close
DTRL REQ <b>NOTE:</b> This item is monitored only on the vehicle with the daytime running light system.	Daytime running light system is not operated.		Off
	Daytime running light system is operated.		On


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Monitor Item	Condition	Value/Status
HOOD SW <b>NOTE:</b> This item is monitored only the vehicle for Mexico.	Close the hood	Off
	Open the hood	On
THFT HRN REQ	Not operation	Off
	Horn is activated with vehicle security system or panic alarm system.	On
HORN CHIRP	Not operation	Off
	Horn is activated with key fob LOCK operation.	On

## TERMINAL LAYOUT



## PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/Output		
1 (R)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (G)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
3 (O)	Ground	Starter relay power supply	Output	When engine is clanking		Battery voltage
				When engine is not clanking		0 V
4 (W)	Ground	Cooling fan relay-1 power supply	Output	Cooling fan operation	OFF	0 V
					MID or HI	Battery voltage
5 (R)	Ground	Ignition switch START	Input	Ignition switch OFF, ACC or ON		0 V
				Ignition switch START		Battery voltage
6 (BR)	Ground	Battery power supply (Cooling fan relay)	Input	Ignition switch OFF		Battery voltage
7 (P)	Ground	Cooling fan motor-2 (HI) ground	—	Cooling fan operation	OFF	Battery voltage
					HI	0 V
8 (G)	Ground	Cooling fan relay-2 power supply	Output	Cooling fan operation	OFF	0 V
					HI	Battery voltage
11 (B)	Ground	Ground	—	Ignition switch ON		0 V
12 (O)	Ground	Rear window defogger relay power supply	Output	Ignition switch ON	Rear window defogger switch OFF	0 V
					Rear window defogger switch ON	Battery voltage
15*1 (SB)	Ground	Daytime running light relay control	Output	Daytime running light system	Not operated	Battery voltage
					Operated	0 V
16*2 (Y)	Ground	Front fog lamp (LH)	Output	Lighting switch 2ND	Front fog lamp switch OFF	0 V
					Front fog lamp switch ON	Battery voltage
17*2 (W)	Ground	Front fog lamp (RH)	Output	Lighting switch 2ND	Front fog lamp switch OFF	0 V
					Front fog lamp switch ON	Battery voltage
18 (L)	Ground	Headlamp LO (LH)	Output	Lighting switch OFF		0 V
				Lighting switch 2ND		Battery voltage
20 (SB)	Ground	Headlamp LO (RH)	Output	Lighting switch OFF		0 V
				Lighting switch 2ND		Battery voltage
21 (G)	Ground	Headlamp HI (LH)	Output	Lighting switch OFF		0 V
				<ul style="list-style-type: none"> <li>• Lighting switch 2ND and HI</li> <li>• Lighting switch PASS</li> </ul>		Battery voltage
22 (LG)	Ground	Headlamp HI (RH)	Output	Lighting switch OFF		0 V
				<ul style="list-style-type: none"> <li>• Lighting switch 2ND and HI</li> <li>• Lighting switch PASS</li> </ul>		Battery voltage
23 (W)	Ground	Oil pressure switch	Input	Ignition switch ON	Engine stopped	0 V
					Engine running	Battery voltage
24 (Y)	Ground	Front wiper auto stop	Input	Ignition switch ON	Front wiper stop position	0 V
					Any position other than front wiper stop position	Battery voltage
25 (B)	Ground	Ground	—	Ignition switch ON		0 V
26 (P)	—	CAN-L	Input/ Output	—		—
27 (L)	—	CAN-H	Input/ Output	—		—

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
31 (LG)	Ground	Cooling fan relay-4 control	Output	Cooling fan operation	OFF	Battery voltage
					LO	0 - 1.0 V
32 (V)	Ground	ETC relay control	Input	After passing approximately 2 seconds or more after turning the ignition switch from ON to OFF		Battery voltage
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>For approximately 2 seconds after turning ignition switch from ON to OFF</li> </ul>		0 - 1.0 V
33 (GR)	Ground	Fuel pump relay control	Input	Ignition switch OFF		0 V
				Ignition switch ON	Engine stopped	Battery voltage
					Engine running	0.8 V
34*3 (W)	Ground	Hood switch	Input	Close the hood		Battery voltage
				Open the hood		0 V
37 (R)	Ground	Tail, license plate lamps and illuminations	Output	Lighting switch OFF		0 V
				Lighting switch 1ST		Battery voltage
38 (R)	Ground	Parking lamp (LH)	Output	Lighting switch OFF		0 V
				Lighting switch 1ST		Battery voltage
39 (GR)	Ground	Parking lamp (RH)	Output	Lighting switch OFF		0 V
				Lighting switch 1ST		Battery voltage
40 (BR)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC		0 V
				Ignition switch ON		Battery voltage
41 (O)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC		0 V
				Ignition switch ON		Battery voltage
42 (L)	Ground	Front wiper HI	Output	Ignition switch ON	Front wiper switch OFF	0 V
					Front wiper switch HI	Battery voltage
43 (G)	Ground	Front wiper LO	Output	Ignition switch ON	Front wiper switch OFF	0 V
					Front wiper switch LO	Battery voltage
45 (Y)	Ground	Starter relay power supply	Input	Ignition switch ON	Selector lever "P" or "N"	Battery voltage
					Selector lever in any position other than "P" or "N"	0 V
46 (W)	Ground	Fuel pump relay power supply	Output	<ul style="list-style-type: none"> <li>Ignition switch OFF or ACC</li> <li>After passing approximately 1 second or more after turning the ignition switch ON</li> </ul>		0 V
				<ul style="list-style-type: none"> <li>For approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>		Battery voltage
47 (BR)	Ground	ECM relay power supply	Output	After passing approximately 4 seconds or more after turning the ignition switch from ON to OFF		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>For approximately 4 seconds after turning ignition switch from ON to OFF</li> </ul>		Battery voltage
48 (R)	Ground	ECM relay power supply	Output	After passing approximately 4 seconds or more after turning the ignition switch from ON to OFF		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>For approximately 4 seconds after turning ignition switch from ON to OFF</li> </ul>		Battery voltage
50 (G)	Ground	Cooling fan relay-5 control	Output	Cooling fan operation	OFF	Battery voltage
					MID or HI	0 - 1.0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
51 (L)	Ground	ECM relay control	Output	After passing approximately 4 seconds or more after turning the ignition switch from ON to OFF	Battery voltage	
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• For approximately 4 seconds after turning ignition switch from ON to OFF</li> </ul>	0 - 1.0 V	
52 (P)	Ground	ETC relay power supply	Output	After passing approximately 2 seconds or more after turning the ignition switch from ON to OFF	0 V	
				<ul style="list-style-type: none"> <li>• Ignition switch ON</li> <li>• For approximately 2 seconds after turning ignition switch from ON to OFF</li> </ul>	Battery voltage	
55 (O)	Ground	A/C relay power supply	Output	Engine stopped	0 V	
				Engine running	A/C switch OFF	0 V
					A/C switch ON (A/C compressor is operating)	Battery voltage
56 (L)	Ground	Ignition switch ON	Input	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	Battery voltage	
57 (V)	Ground	Horn relay control	Output	The horn is not activated	Battery voltage	
				The horn is activated	0 V	
58 (LG)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	Battery voltage	
59 (BR)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	Battery voltage	
60 (SB)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	Battery voltage	
61 (R)	Ground	ECM power supply	Output	Ignition switch OFF	Battery voltage	

\*1: With daytime running light system

\*2: With front fog lamp system

\*3: For Mexico


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

## Wiring Diagram - IPDM E/R -

INFOID:000000003050036



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

2007/07/13


JCMWM1037G1



# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) [HALOGEN TYPE]

< ECU DIAGNOSIS >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P





# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Control part	Fail-safe in operation
Cooling fan	<ul style="list-style-type: none"> <li>The cooling fan relay-1, the cooling fan relay-2, the cooling fan relay-3 and the cooling fan relay-5 turn ON when the ignition switch is turned ON</li> <li>The cooling fan relay-1, the cooling fan relay-2, the cooling fan relay-3 and the cooling fan relay-5 turn OFF when the ignition switch is turned OFF</li> <li>Cooling fan relay-4 OFF</li> </ul>
A/C compressor	A/C relay OFF

If no CAN communication is available with BCM

Control part	Fail-safe in operation
Headlamp	<ul style="list-style-type: none"> <li>The headlamp low relay turns ON when the ignition switch is turned ON</li> <li>The headlamp low relay turns OFF when the ignition switch is turned OFF</li> <li>Headlamp high relay OFF</li> </ul>
<ul style="list-style-type: none"> <li>Parking lamps</li> <li>License plate lamps</li> <li>Tail lamps</li> <li>Illuminations</li> </ul>	<ul style="list-style-type: none"> <li>The tail lamp relay and the daytime running light relay* turn ON when the ignition switch is turned ON</li> <li>The tail lamp relay and the daytime running light relay* turn OFF when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>The front wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.</li> </ul>
Front fog lamps	Front fog lamp relay OFF
Starter motor	Starter relay OFF
Rear window defogger	Rear window defogger relay OFF
Horn	Horn relay OFF

**NOTE:**

\*: With daytime running light system

## IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors status of ignition relay by the voltage at ignition relay contact circuit inside it.
- IPDM E/R judges that the ignition relay is error, if status of the ignition relay and ignition switch ON signal (CAN).
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay and daytime running light relay\* for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Detection		IPDM E/R judgment	Operation
Ignition switch ON signal	Ignition relay		
ON	ON	Ignition relay normal	—
OFF	OFF	Ignition relay normal	—
OFF	ON	Ignition relay ON stuck	Turn on the tail lamp relay and daytime running light relay* for 10 minutes
ON	OFF	Ignition relay OFF stuck	Detect DTC "B2099: IGN RELAY OFF"

**NOTE:**

\*: With daytime running light system

## FRONT WIPER CONTROL

IPDM E/R detects the front wiper stop position with the front wiper auto stop signal.

When the front wiper auto stop signal is in the conditions listed below, IPDM E/R repeats a front wiper 10 seconds operation and 20 seconds stop five times.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

[HALOGEN TYPE]

Ignition switch	Front wiper switch	Front wiper auto stop signal
ON	OFF	The front wiper auto stop signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper auto stop signal does not change for 10 seconds.

**NOTE:**

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

## DTC Index

INFOID:000000003050038

CONSULT display	Fail-safe	Timing <sup>NOTE</sup>		Reference page
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	×	CRNT	PAST	<a href="#">PCS-13</a>
B2099: IGN RELAY OFF	—	CRNT	PAST	<a href="#">PCS-14</a>

**NOTE:**

The details of time display are as follows.

- CRNT: The malfunctions that are detected now.
- PAST: The number is indicated when it is normal at present and a malfunction was detected in the past.

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## SYMPTOM DIAGNOSIS

### EXTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000001722044

**CAUTION:**

Perform the self-diagnosis with CONSULT-III before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp (HI) is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Halogen bulb (HI)</li> <li>• Harness between IPDM E/R and the headlamp high</li> <li>• Daytime running light relay (with daytime running light system)</li> <li>• IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-161</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to <a href="#">EXL-245</a> .	
Headlamp (HI) is not turned OFF.	When ignition switch is turned ON.		
	When ignition switch is turned OFF.	IPDM E/R	—
High beam indicator lamp is not turned ON. [The headlamp (HI) is turned ON.]		Combination meter	<ul style="list-style-type: none"> <li>• Combination meter Data monitor "HI-BEAM IND"</li> <li>• BCM (HEAD LAMP) Active test "HEADLAMP"</li> </ul>
Headlamp (LO) is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Halogen bulb (LO)</li> <li>• Harness between IPDM E/R and the headlamp low</li> <li>• IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-164</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-246</a> .	
Headlamp (LO) is not turned OFF.	When ignition switch is turned ON.		
	When ignition switch is turned OFF.	IPDM E/R	—
Daytime running light is not turned ON.		<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Halogen bulb (HI)</li> <li>• Harness between IPDM E/R and the daytime running light relay</li> <li>• Daytime running light relay</li> <li>• IPDM E/R</li> <li>• BCM</li> <li>• ECM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Daytime running light relay circuit Refer to <a href="#">EXL-168</a>.</li> <li>• BCM (HEAD LAMP) Data monitor "ENGINE RUNNING" and "PKB SW"</li> <li>• BCM (HEAD LAMP) Active test "DAYTIME RUNNING LIGHT"</li> </ul>
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Front fog lamp bulb</li> <li>• Harness between IPDM E/R and the front fog lamp</li> <li>• Front fog lamp</li> <li>• IPDM E/R</li> </ul>	Front fog lamp circuit Refer to <a href="#">EXL-166</a> .
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-248</a> .	
Front fog lamp is not turned ON.			

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

Symptom	Possible cause	Inspection item	
Parking lamp is not turned ON.	<ul style="list-style-type: none"> <li>• Parking lamp bulb</li> <li>• Harness between IPDM E/R and the front combination lamp</li> <li>• Front combination lamp</li> <li>• IPDM E/R</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-171</a> .	
Tail lamp is not turned ON.	<ul style="list-style-type: none"> <li>• Tail lamp bulb</li> <li>• Harness between IPDM E/R and the rear combination lamp</li> <li>• Rear combination lamp</li> </ul>	Tail lamp circuit Refer to <a href="#">EXL-177</a> .	
License plate lamp is not turned ON.	<ul style="list-style-type: none"> <li>• License plate lamp bulb</li> <li>• Harness between IPDM E/R and the license plate lamp</li> <li>• License plate lamp</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-179</a> .	
Tail lamp and the license plate lamp are not turned ON.	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Harness between IPDM E/R and the rear combination lamp</li> <li>• IPDM E/R</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-179</a> .	
<ul style="list-style-type: none"> <li>• Parking lamp, the tail lamp and the license plate lamp are not turned ON.</li> <li>• Parking lamp, the tail lamp and the license plate lamp are not turned OFF. (Each illumination is turned ON/OFF.)</li> </ul>	<p><b>Symptom diagnosis</b>                      "PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON"                      Refer to <a href="#">EXL-247</a>.</p>		
Tail lamp indicator is not turned ON. (Parking, tail lamps are turned ON.)	Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Data monitor "LIGHT IND"</li> <li>• BCM (HEAD LAMP)</li> <li>• Active test "TAIL LAMP"</li> </ul>	
Turn signal lamp does not blink.	Indicator lamp is normal. (Applicable side performs the high flasher activation.)	<ul style="list-style-type: none"> <li>• Harness between BCM and each turn signal lamp</li> <li>• Turn signal lamp bulb</li> </ul>	Turn signal circuit Refer to <a href="#">EXL-173</a> .
	Indicator lamp is included.	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between the combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-42</a> .
Turn signal indicator lamp does not blink. (Turn signal indicator lamp is normal.)	One side	Combination meter	—
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn signal indicator lamp signal</li> <li>- BCM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Data monitor "TURN IND"</li> <li>• BCM (FLASHER)</li> <li>• Active test "FLASHER"</li> </ul>
	Both sides (Only when activating hazard warning lamp with the ignition switch OFF)	<ul style="list-style-type: none"> <li>• Combination meter power supply and the ground circuit</li> <li>• Combination meter</li> </ul>	Combination meter Power supply and the ground circuit Refer to <a href="#">MWI-41</a> .
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate.</li> <li>• Hazard warning lamp continues activating. (Turn signal is normal.)</li> </ul>	<ul style="list-style-type: none"> <li>• Hazard switch</li> <li>• Harness between the hazard switch and BCM</li> <li>• BCM</li> </ul>	Hazard switch Refer to <a href="#">EXL-175</a> .	

# BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

### Description

INFOID:000000001720645

Both side headlamps (HI) are not turned ON when setting to the lighting switch HI or PASS.

### Diagnosis Procedure

INFOID:000000001720646

#### 1.COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-66. "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

 CONSULT-III DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R data monitor item.

2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2ND)	HI or PASS	On
		LO	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-67. "Exploded View"](#).

#### 3.HEADLAMP (HI) CIRCUIT INSPECTION

Check the headlamp (HI) circuit. Refer to [EXL-161. "Component Function Check"](#).

Is the headlamp (HI) circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

### Description

INFOID:000000001720647

Both side headlamps (LO) are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000001720648

#### 1. CHECK COMBINATION SWITCH

Check the combination switch. Refer to [BCS-66, "Symptom Table"](#).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2. CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

##### Ⓟ CONSULT-III DATA MONITOR

1. Select "HL LO REQ" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
HL LO REQ	Lighting switch	2ND	On
		OFF	Off

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-67, "Exploded View"](#).

#### 3. HEADLAMP (LO) CIRCUIT INSPECTION

Check the headlamp (LO) circuit. Refer to [EXL-164, "Component Function Check"](#).

Is the headlamp (LO) circuit normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace the malfunctioning part.

# PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

### Description

INFOID:000000003050050

The parking, license plate, tail lamps and each illumination are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000003050051

#### 1. CHECK FUSE

Check that the following fuse is fusing.

Unit	Location	Fuse No.	Capacity
Parking lamp	IPDM E/R	#46	10 A
<ul style="list-style-type: none"><li>Tail lamp</li><li>License plate lamp</li></ul>		#45	10 A

#### Is the fuse fusing?

- YES >> Repair the applicable circuit. And then replace the fuse.  
NO >> GO TO 2.

#### 2. COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-66. "Symptom Table"](#).

#### Is the combination switch normal?

- YES >> GO TO 3.  
NO >> Repair or replace the malfunctioning part.

#### 3. CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

##### CONSULT-III DATA MONITOR

- Select "TAIL & CLR REQ" of IPDM E/R data monitor item.
- With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
TAIL & CLR REQ	Lighting switch	1ST	On
		OFF	Off

#### Is the item status normal?

- YES >> GO TO 4.  
NO >> Replace BCM. Refer to [BCS-67. "Exploded View"](#).

#### 4. TAIL LAMP CIRCUIT INSPECTION

Check the tail lamp circuit. Refer to [EXL-177. "Component Function Check"](#).

#### Is the tail lamp circuit normal?

- YES >> Replace IPDM E/R.  
NO >> Repair or replace the malfunctioning part.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN TYPE]

## BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

### Description

INFOID:000000003050052

The front fog lamps are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000003050053

#### 1. CHECK FUSE

Check that the following fuse is fusing.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#65	15 A

##### Is the fuse fusing?

- YES >> Repair the applicable circuit. And then replace the fuse.
- NO >> GO TO 2.

#### 2. COMBINATION SWITCH INSPECTION

Check the combination switch. Refer to [BCS-66, "Symptom Table"](#).

##### Is the combination switch normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning part.

#### 3. CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

##### ⓅCONSULT-III DATA MONITOR

1. Select "FR FOG REQ" of IPDM E/R data monitor item.
2. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition	Monitor status
FR FOG REQ	Front fog lamp switch (With lighting switch 1ST)	ON On
		OFF Off

##### Is the item status normal?

- YES >> GO TO 4.
- NO >> Replace BCM. Refer to [BCS-67, "Exploded View"](#).

#### 4. FRONT FOG LAMP CIRCUIT INSPECTION

Check the front fog lamp circuit. Refer to [EXL-166, "Component Function Check"](#).

##### Is the front fog lamp circuit normal?

- YES >> Replace IPDM E/R.
- NO >> Repair or replace the malfunctioning part.

PRECAUTION

PRECAUTIONS  
FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003249001

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003249003

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIRBAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIRBAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HEADLAMP AIMING ADJUSTMENT

< ON-VEHICLE MAINTENANCE >

[HALOGEN TYPE]

## ON-VEHICLE MAINTENANCE

### HEADLAMP AIMING ADJUSTMENT

#### Description

INFOID:000000001716660

#### PREPARATION BEFORE ADJUSTING

##### NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the luggage room.)

##### NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.


- Wipe out dirt on the headlamp.

##### CAUTION:

**Never use organic solvent (thinner, gasoline etc.)**

- Ride alone on the driver seat.

#### AIMING ADJUSTMENT SCREW



A. Headlamp RH (UP/DOWN) adjustment screw

B. Headlamp LH (UP/DOWN) adjustment screw

↔: Vehicle center

# HEADLAMP AIMING ADJUSTMENT

< ON-VEHICLE MAINTENANCE >

[HALOGEN TYPE]

	Adjustment screw	Screw driver rotation	Facing direction
A	Headlamp RH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP
B	Headlamp LH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP


## Aiming Adjustment Procedure

INFOID:000000002996045

1. Place the screen.
  - NOTE:**
  - Stop the vehicle facing the wall.
  - Place the board on a plain road vertically.
2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the headlamp bulb center and the screen.
3. Start the engine. Turn the headlamp (LO) ON.
  - NOTE:**
  - Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.
  - CAUTION:**
  - Never cover the lens surface with a tape etc. The lens is made of resin.**
4. Measure the distance (X) between the horizontal center line of headlamp (H) and the cutoff line (A) within the light axis measurement range (R) from the vertical center line ahead of headlamp (V).

**Light axis measurement range (R) : 350 ± 175 mm (13.78 ± 6.89 in)**

Low beam distribution on the screen




5. Adjust the cutoff line height (X) with the aiming adjustment screw so as to enter in the adjustment range (M–N) according to the horizontal center line of headlamp (H).

unit: mm (in)

Horizontal center line of headlamp (H)	Highest cutoff line height (M)	Lowest cutoff line height (N)
700 (27.56) or less	4 (0.16)	30 (1.18)
701(27.60) – 800 (31.50)	4 (0.16)	30 (1.18)
801 (31.54) or more	17 (0.67)	44 (1.73)

Side view



# HEADLAMP AIMING ADJUSTMENT

< ON-VEHICLE MAINTENANCE >

[HALOGEN TYPE]

---

Distance between the headlamp center and the screen (L) : 10 m (32.8 ft)

# FRONT FOG LAMP AIMING ADJUSTMENT

< ON-VEHICLE MAINTENANCE >

[HALOGEN TYPE]

## FRONT FOG LAMP AIMING ADJUSTMENT

### Description

INFOID:000000003050055

### PREPARATION BEFORE ADJUSTING

#### NOTE:

- For details, refer to the regulations in your own country.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the luggage room.)

#### NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.

- Wipe out dirt on the headlamp.

#### CAUTION:

**Never use organic solvent (thinner, gasoline etc.)**

- Ride alone on the driver seat.

### AIMING ADJUSTMENT SCREW

- Turn the aiming adjusting screw for adjustment.


A: UP

B: DOWN

- For the position and direction of the adjusting screw, refer to the figure.

#### NOTE:

A screwdriver or hexagonal wrench [6 mm (0.24 in)] can be used for adjustment.



### Aiming Adjustment Procedure

INFOID:000000003050056

1. Place the screen.

#### NOTE:

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the front fog lamp center and the screen.

3. Start the engine. Illuminate the front fog lamp.

#### CAUTION:


**Never cover the lens surface with a tape etc. The lens is made of resin.**

#### NOTE:

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.

4. Adjust the cutoff line height (A) with the aiming adjustment screw so that the distance (X) between the horizontal center line of front fog lamp (H) and (A) becomes 130 mm (5.12 in).

Front fog lamp light distribution on the screen



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT FOG LAMP AIMING ADJUSTMENT

< ON-VEHICLE MAINTENANCE >

[HALOGEN TYPE]

---

- A : Cutoff line
- B : High illuminance area
- H : Horizontal center line of front fog lamp
- V : Vertical center line of front fog lamp
- X : Cutoff line height

# FRONT COMBINATION LAMP

< ON-VEHICLE REPAIR >

[HALOGEN TYPE]


## ON-VEHICLE REPAIR

### FRONT COMBINATION LAMP

Exploded View


INFOID:000000001716667

#### REMOVAL



1. Front combination lamp

#### DISASSEMBLY



1. Front turn signal/parking (side marker) lamp bulb
2. Front turn signal/parking (side marker) lamp bulb socket
3. Halogen bulb (LO)
4. Halogen bulb (HI)
5. Headlamp housing assembly

#### Removal and Installation

INFOID:000000001716668

#### REMOVAL

##### **CAUTION:**

**Disconnect the battery negative terminal or the fuse.**

1. Remove front bumper fascia. Refer to [EXT-13, "Exploded View"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT COMBINATION LAMP

[HALOGEN TYPE]

< ON-VEHICLE REPAIR >

2. Remove the headlamp mounting bolts and nuts.
3. Remove the mounting stud of the headlamp outside from front fender.
4. Pull out the headlamp assembly forward the vehicle.
5. Disconnect the connector before removing the headlamp assembly.

## INSTALLATION

Install in the reverse order of removal.

### NOTE:

After installation, perform aiming adjustment. Refer to [EXL-250. "Description"](#).

## Replacement

INFOID:000000001716669

### CAUTION:

- **Disconnect the battery negative terminal or the fuse.**
- **After installing the bulb, install the resin cap and the bulb socket securely for watertightness.**

## HEADLAMP BULB (LO)

1. Remove the air duct\*. Keep a service area.  
\*When replace a left.
2. Rotate the bulb counterclockwise and unlock it.
3. Disconnect the headlamp bulb connector.
4. Remove the bulb from the headlamp housing assembly.

## HEADLAMP BULB (HI)

1. Remove the air duct\*. Keep a service area.  
\*When replace a left.
2. Rotate the bulb counterclockwise and unlock it.
3. Disconnect the headlamp bulb connector.
4. Remove the bulb from the headlamp housing assembly.

## FRONT TURN SIGNAL/PARKING (SIDE MARKER) LAMP BULB

1. Rotate the bulb socket counterclockwise and unlock it.
2. Remove the bulb from the bulb socket.

## Disassembly and Assembly

INFOID:000000001716670

### DISASSEMBLY

1. Rotate the headlamp bulb (LO) counterclockwise and unlock it
2. Disconnect the headlamp bulb (LO) connector. And remove the bulb from the headlamp housing assembly.
3. Rotate the headlamp bulb (HI) counterclockwise and unlock it
4. Disconnect the headlamp bulb (HI) connector. And remove the bulb from the headlamp housing assembly.
5. Rotate the front turn signal/parking (side marker) lamp bulb socket counterclockwise and unlock it.
6. Remove the bulb from the front turn signal/parking (side marker) lamp bulb socket.

### ASSEMBLY

Assemble in the reverse order of disassembly.

# FRONT FOG LAMP


< ON-VEHICLE REPAIR >

[HALOGEN TYPE]

## FRONT FOG LAMP

### Exploded View

INFOID:000000003050057



1. Front fog lamp bracket
2. Front fog lamp

### Removal and Installation

INFOID:000000003050058

**CAUTION:**  
Disconnect the battery negative terminal or the fuse.

#### REMOVAL

1. Remove the front fender protector. Keep a service area. Refer to [EXT-22, "Exploded View"](#).
2. Remove the front fog lamp connector.
3. Remove the screw. And remove the front fog lamp.
4. Remove the screw. And remove the front fog lamp bracket.

#### INSTALLATION

Installation is the reverse order of removal.

**NOTE:**  
After installation, perform aiming adjustment. Refer to [EXL-253, "Description"](#)


### Replacement

INFOID:000000003050059

**CAUTION:**  
Disconnect the battery negative terminal or the fuse.

#### FRONT FOG LAMP BULB

1. Remove the front fender protector. Keep the service area. Refer to [EXT-22, "Exploded View"](#).
2. Remove the front fog lamp bulb connector (1).
3. Rotate the bulb (2) counterclockwise and unlock it.



# LIGHTING & TURN SIGNAL SWITCH


< ON-VEHICLE REPAIR >

[HALOGEN TYPE]

## LIGHTING & TURN SIGNAL SWITCH

Exploded View

INFOID:000000003050060



- 1. Lighting & turn signal switch
- A. Pawl

## Removal and Installation

INFOID:000000003050061

### REMOVAL

1. Remove steering column cover. Refer to [IP-12. "Exploded View"](#).
2. While pressing pawls, pull the lighting & turn signal switch. And disconnect from the switch base.

### INSTALLATION

Installation is the reverse order of removal.

# HAZARD SWITCH


< ON-VEHICLE REPAIR >

[HALOGEN TYPE]

## HAZARD SWITCH

### Exploded View

INFOID:000000003050062



- 1. Hazard switch
- A. Pawls

### Removal and Installation

INFOID:000000003050063

#### REMOVAL

1. Remove the cluster lid C. Refer to [IP-12, "Exploded View"](#).
2. Push the pawl. And remove the hazard switch.

#### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P




# REAR COMBINATION LAMP

[HALOGEN TYPE]

## < ON-VEHICLE REPAIR >

3. Remove rear combination lamp mounting bolts (A).
4. Turn up the back door weather strip, insert an appropriate tool between rear combination lamp and vehicles and remove a clip (B).
5. Pull the rear combination lamp toward rear of the vehicle. Remove the rear combination lamp.



## INSTALLATION

Install in the reverse order of removal.

## Replacement

INFOID:000000003050066

### **CAUTION:**

**Disconnect the battery negative terminal or the fuse.**

## STOP/TAIL (SIDE MARKER) LAMP BULB

1. Remove rear combination lamp. Refer to [EXL-127, "Exploded View"](#).
2. Rotate the stop/tail (side marker lamp) bulb socket counterclockwise, and unlock it.
3. Remove bulb from the bulb socket.

## REAR TURN SIGNAL LAMP BULB

1. Remove rear combination lamp. Refer to [EXL-127, "Exploded View"](#).
2. Rotate the rear turn signal lamp bulb socket counterclockwise, and unlock it.
3. Remove bulb from the bulb socket.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HIGH-MOUNTED STOP LAMP


< ON-VEHICLE REPAIR >

[HALOGEN TYPE]

## HIGH-MOUNTED STOP LAMP

### Exploded View

INFOID:000000003050067



1. High-mounted stop lamp                      2. Clip                      3. Seal packing

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000003050068

#### **CAUTION:**


**Disconnect battery negative terminal or remove the fuse.**

#### REMOVAL

1. Remove the back door trim finisher upper. Refer to [INT-34, "Exploded View"](#).
2. Remove the mounting nuts and clips.
3. Cut the seal packing by the thin plate (A).

1. Back door panel
2. High-mounted stop lamp

4. Pull the high-mounted stop lamp toward rear of the vehicle. Remove the high-mounted stop lamp.
5. Disconnect the high-mounted stop lamp connector.



#### INSTALLATION

Install in the reverse order of removal.

#### **CAUTION:**

**Seal packing cannot be reused.**

# BACK-UP LAMP


< ON-VEHICLE REPAIR >

[HALOGEN TYPE]

## BACK-UP LAMP

### Exploded View

INFOID:000000003050069



1. Seal packing
2. Back-up lamp

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000003050070

**CAUTION:**  
Disconnect the battery negative terminal or the fuse.

#### REMOVAL

1. Remove the back door mask. Refer to [INT-34, "Exploded View"](#).
2. Remove back-up lamp mounting nuts.
3. Disconnect back-up lamp connector. And remove the back-up lamp.

#### INSTALLATION

Install in the reverse order of removal.

**CAUTION:**  
Seal packing cannot be reused.


### Replacement

INFOID:000000003050071

**CAUTION:**  
Disconnect the battery negative terminal or the fuse.

#### BACK-UP LAMP BULB

1. Remove the back-up lamp. Refer to [EXL-130, "Exploded View"](#).
2. Disconnect the connector, rotate the bulb socket (1) counter-clockwise and unlock it.
3. Remove the bulb (2) from the socket.



# LICENSE PLATE LAMP


< ON-VEHICLE REPAIR >

[HALOGEN TYPE]

## LICENSE PLATE LAMP

### Exploded View

INFOID:000000003050072



1. License plate lamp

### Removal and Installation


INFOID:000000003050073

#### **CAUTION:**

**Disconnect the battery negative terminal or the fuse.**

#### REMOVAL

1. Remove back door trim finisher lower. Refer to [INT-34, "Exploded View"](#).
2. Remove back door finisher. Refer to [INT-34, "Exploded View"](#).
3. Remove the license plate lamp in numerical order shown in the figure.
4. Disconnect the license plate lamp connector.



#### INSTALLATION

1. Connect the license plate lamp connector.
2. Fix the pawl-side behind the license plate lamp housing first, then push the resin clip-side.

### Replacement

INFOID:000000003050074

#### **CAUTION:**

**Disconnect the battery negative terminal or the fuse.**

#### LICENSE PLATE LAMP BULB


1. Remove back door trim finisher lower. Refer to [INT-34, "Exploded View"](#).

# LICENSE PLATE LAMP

[HALOGEN TYPE]

## < ON-VEHICLE REPAIR >

2. Turn the bulb socket (1) counterclockwise and unlock it.
3. Remove the bulb (2) from the socket.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[HALOGEN TYPE]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Bulb Specifications

INFOID:000000001722773

Item		Type	Wattage (W)
Front combination lamp	Headlamp (HI)	HB3	60
	Headlamp (LO)	H11	55
	Front turn signal/parking (side marker) lamp	S25 (Amber)	27/8
Front fog lamp		H11	55
Rear combination lamp	Stop/tail (side marker) lamp	W21/5W	21/5
	Rear turn signal lamp	W21W	21
	Back-up lamp	W16W	16
License plate lamp		W5W	5
High-mounted stop lamp		LED	—