

A
LU

SECTION LU

ENGINE LUBRICATION SYSTEM

C

CONTENTS

QG18DE	QR25DE
PRECAUTIONS 2	PRECAUTIONS 12
Liquid Gasket Application Procedure 2	Precautions for Liquid Gasket 12
PREPARATION 3	REMOVAL OF LIQUID GASKET SEALING 12
Special Service Tools 3	LIQUID GASKET APPLICATION PROCEDURE.. 12
LUBRICATION SYSTEM 4	PREPARATION 13
Lubrication Circuit 4	Special Service Tools 13
ENGINE OIL 5	LUBRICATION SYSTEM 14
Inspection 5	Lubrication Circuit 14
OIL LEVEL AND MUDDINESS 5	System Drawing 15
OIL LEAKAGE 5	ENGINE OIL 16
OIL PRESSURE CHECK 5	Inspection 16
Changing Engine Oil 6	OIL LEVEL AND MUDINESS 16
OIL FILTER 7	OIL LEAKAGE 16
Removal and Installation 7	OIL PRESSURE CHECK 16
REMOVAL 7	Changing Engine Oil 17
INSTALLATION 7	OIL FILTER 18
OIL PUMP 8	Removal and Installation 18
Removal and Installation 8	REMOVAL 18
Disassembly and Assembly 8	INSTALLATION 18
Inspection 8	OIL PUMP 19
Regulator Valve Inspection 10	Removal and Installation 19
SERVICE DATA AND SPECIFICATIONS (SDS) 11	Disassembly and Assembly 19
Oil Pressure Check 11	DISASSEMBLY 19
Oil Pump Inspection 11	INSPECTION AFTER DISASSEMBLY 19
Regulator Valve Inspection 11	ASSEMBLY 21
	SERVICE DATA AND SPECIFICATIONS (SDS) 22
	Oil Pressure 22
	Oil Pump 22
	Regulator Valve 22
	Oil Capacity 22

PRECAUTIONS

Liquid Gasket Application Procedure

EBS006AZ

1. Use a scraper to remove all traces of old sealant from mating surfaces and grooves. Also, completely clean any oil from these areas.


2. Apply a continuous bead of Genuine RTV Silicone Sealant or equivalent. Refer to [GI-44, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#) .

- For oil pan, be sure RTV Silicone Sealant diameter is to specification.


Oil pan sealant diameter : 3.5 - 4.5 mm (0.138 - 0.177 in)

- For areas except oil pan, be sure RTV Silicone Sealant diameter is to specification.

Sealant diameter : 2.0 - 3.0 mm (0.079 - 0.118 in) except oil pan



3. Apply RTV Silicone Sealant around the inner side of bolt holes (unless otherwise specified).



4. Assembly should be done within 5 minutes after coating.

5. Wait at least 30 minutes before refilling the engine with oil and coolant.

PREPARATION

[QG18DE]




PFP:00002

EBS006B0

PREPARATION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J34301-C) Oil pressure gauge set 1 (J34301-1) Oil pressure gauge 2 (J34301-2) Hoses 3 (J34298) Adapter 4 (J34282-1) Adapter 5 (790-301-1230-A) 60° adapter 6 (J34301-15) Square socket	 <p>AAT896</p> <p>Measuring oil pressure Maximum measuring range: 1,373 kPa (14 kg/cm² , 199 psi)</p>
KV10115800 (J-37140-A) Oil filter wrench	 <p>14 faces Inner span 64.3 mm (2.531 in) (Face to opposite face)</p> <p>S-NT772</p> <p>Removing oil filter</p>
WS39930000 (—) Tube presser	 <p>S-NT052</p> <p>Pressing the tube of liquid gasket</p>

A
 LU
 C
 D
 E
 F
 G
 H
 I
 J
 K
 L
 M

LUBRICATION SYSTEM


[QG18DE]

LUBRICATION SYSTEM


PF15010

Lubrication Circuit

EBS006B1



WLC010




WLC011

ENGINE OIL

Inspection

OIL LEVEL AND MUDDINESS

- Before starting the engine, check the oil level. If the engine is already started, stop it and allow 10 minutes before checking.
- Check that the oil level is within the range shown in the figure.
- If it is out of range, adjust it.
- Check the oil for white turbidity or remarkable contamination.
- If the oil becomes turbid and white, it is highly probable that it is contaminated with coolant.



OIL LEAKAGE

Check for oil leakage around the following area.


- Oil pan
- Oil pan drain plug
- Oil pressure switch
- Oil filter
- Front cover
- Mating surface between cylinder block and cylinder head
- Mating surface between cylinder head and rocker cover
- Crankshaft oil seal.

OIL PRESSURE CHECK

WARNING:

- **Be careful not to burn yourself, as the engine oil may be hot.**
- **For M/T models, put gearshift lever in Neutral "N" position. For A/T models, put the selector lever in Park "P" position.**

1. Check the oil level.
2. Remove the oil pressure switch.
3. Connect the oil pressure gauge using the Tool.
4. After warming up the engine to the normal operating temperature, check that oil pressure corresponding to the engine speed is produced.



Engine oil pressure [Oil temperature is 80°C (176°F)]

Engine speed (rpm)	Idle speed	2,000	6,000
Engine pressure kPa (bar.kg/cm ² , psi)	Approx. 98 (0.98, 1.0, 14) or more	Approx. 294 (2.9, 3.0, 43) or more	Approx. 392 (3.9, 4.0, 57) or more

5. After checking, install the oil pressure switch as follows.
 - a. Remove old sealant adhering to the switch and engine.
 - b. Apply thread sealant. Tighten switch to specification.
Use Genuine High Performance Thread Sealant or equivalent. Refer to [GI-44, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#).

Oil pressure switch : 12 - 17 N·m (1.22 - 1.73 kg·m, 8.8 - 12.5 ft·lb)

Changing Engine Oil

WARNING:

- Be careful not to burn yourself, as the engine oil may be hot.
 - Prolonged and repeated contact with used engine oil may cause skin cancer: try to avoid direct skin contact with used oil. if skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.
1. Warm up engine, and check for oil leakage from engine components.
 2. Stop engine and wait for 10 minutes.
 3. Remove drain plug and oil filler cap to drain the oil.
 4. Remove the oil filter and install a new filter.
 5. Install the oil pan drain plug with a new washer.

CAUTION:

- Be sure to clean the drain plug and install with new washer.
 Oil pan drain plug : 29 - 39 N-m (3.0 - 4.0 kg-m, 22 - 29 ft-lb)
 - The refill capacity depends on the oil temperature and drain time. Use these specifications for reference only.
 Always use the dipstick to determine that the proper amount of oil is in the engine.
6. Fill the engine with oil.

Oil specification and viscosity

- Refer to [MA-13, "Fluids and Lubricants"](#) .

Oil capacity (Approximate):

Drain and refill	With oil filter change	2.7 ℓ (2-7/8 qt.)
	Without oil filter change	2.5 ℓ (2-5/8 qt.)
Dry engine (engine overhaul)		3.1 ℓ (3-1/4 qt.)

7. Warm up the engine and check the area around the drain plug and oil filter for oil leakage.
8. Stop the engine and wait for 10 minutes.
9. Check the oil level.

OIL FILTER

Removal and Installation

REMOVAL


1. Remove the RH engine under cover.
2. Using an oil filter wrench, remove the oil filter.

CAUTION:


- Be careful not to get burned when the engine and engine oil are hot.
- When removing, prepare a shop cloth to absorb any oil leakage or spillage.
- Do not allow engine oil to adhere to the drive belts.
- Completely wipe off any oil that adheres to the engine and the vehicle.

INSTALLATION


1. Remove foreign materials adhering to the oil filter installation surface.
2. Apply engine oil to the oil seal circumference of the new oil filter.



3. Screw the oil filter manually until it touches the installation surface, then tighten it by 2/3 turn.



4. After warming up the engine, check for engine oil leakage.
5. Check oil level with the dipstick and add engine oil as necessary. Refer to [LU-5, "ENGINE OIL"](#).
6. Install the RH engine under cover.




OIL PUMP

Removal and Installation

- When installing the oil pump, apply clean engine oil to the rotor.
 - Make sure that O-ring seal is fitted properly.
 - Use a scraper to remove the old RTV Silicone Sealant from the mating surface of the front cover.
 - Also remove all traces of the old RTV Silicone Sealant from the mating surface of the engine block.
1. Remove the drive belts.
 2. Remove the oil pan. Refer to [EM-19, "Removal"](#).
 3. Remove the oil strainer.
 4. Remove the front cover. Refer to [EM-25, "Removal"](#).
 5. Install the front cover, applying a continuous bead of Genuine RTV Silicone Sealant or equivalent to mating surface of front cover assembly. Refer to [GI-44, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#).
 6. Installation is in the reverse order of removal.


Disassembly and Assembly



- | | | |
|--------------------|----------------|-----------------|
| 1. Oil pump cover | 2. Inner rotor | 3. Outer rotor |
| 4. Front cover | 5. Gasket | 6. Oil strainer |
| 7. Regulator valve | 8. Spring | 9. Washer |
| 10. Plug | | |

Inspection


- Install the oil pump rotors with the punch marks on the oil pump cover side, as shown.



OIL PUMP

[QG18DE]


- Using a feeler gauge, check the following clearances.




Standard clearance:

Unit: mm (in)

Body to outer rotor radial clearance 1	0.114 - 0.200 (0.0045 - 0.0079)
Inner rotor to outer rotor tip clearance 2	Below 0.18 (0.0071)
Body to inner rotor clearance 3	0.030 - 0.070 (0.0012 - 0.0028)
Body to outer rotor axial clearance 4	0.030 - 0.090 (0.0012 - 0.0035)
Inner rotor to brazed portion of housing clearance 5	0.045 - 0.091 (0.0018 - 0.0036)




- If the tip clearance (2) exceeds the limit, replace the rotor set.
- If the body to rotor clearances (1, 3, 4, 5) exceed the limit, replace the front cover assembly.



Regulator Valve Inspection


1. Visually inspect components for wear and damage.
2. Check oil pressure regulator valve sliding surface and valve spring.
3. Coat regulator valve with engine oil.
 - Check that the regulator valve falls smoothly into the valve hole by its own weight and gravity.
 - If damaged, replace the regulator valve set or front cover assembly.



4. Check regulator valve to front cover clearance.

Clearance : 0.040 - 0.097 mm (0.0016 - 0.0038 in)

- If the valve exceeds the specification, replace the front cover assembly.



SERVICE DATA AND SPECIFICATIONS (SDS)

[QG18DE]

SERVICE DATA AND SPECIFICATIONS (SDS)

PF0:00030

Oil Pressure Check

EBS006B9

Engine speed rpm	Approximate discharge pressure kPa (kg/cm ² , psi)
600	More than 98 (1.0, 14)
2,000	More than 294 (3.0, 43)
6,000	More than 392 (4.0, 57)

Oil Pump Inspection

EBS006BA

Unit: mm (in)

Body to outer rotor radial clearance	0.114 - 0.200 (0.0045 - 0.0079)
Inner rotor to outer rotor tip clearance	Below 0.18 (0.0071)
Body to inner rotor clearance	0.030 - 0.070 (0.0012 - 0.0028)
Body to outer rotor axial clearance	0.030 - 0.090 (0.0012 - 0.0035)
Inner rotor to brazed portion of housing clearance	0.045 - 0.091 (0.0018 - 0.0036)

Regulator Valve Inspection

EBS006BB

Unit: mm (in)

Regulator valve to oil pump cover clearance	0.040 - 0.097 (0.0016 - 0.0038)
---	---------------------------------

PRECAUTIONS

Precautions for Liquid Gasket

REMOVAL OF LIQUID GASKET SEALING

- After removing the mounting bolts and nuts, disconnect and remove the RTV Silicone Sealant using a seal cutter.


CAUTION:

Be careful not to damage the mating surfaces.

- In areas where the cutter is difficult to use, use a plastic hammer to lightly tap the areas where the RTV Silicone Sealant is applied.

CAUTION:


If for some unavoidable reason a tool such as a flat-bladed screwdriver is used, be careful not to damage the mating surfaces.




LIQUID GASKET APPLICATION PROCEDURE

1. Using a scraper, remove the old RTV Silicone Sealant adhering to the gasket application surface and the mating surface.
 - Remove the old RTV Silicone Sealant completely from the groove of the gasket application surface, mounting bolts, and bolt holes.
2. Clean the mating surface to remove dirt, moisture, grease, and foreign material.
3. Attach the RTV Silicone Sealant to the tube presser.

Use Genuine RTV Silicone Sealant or equivalent. Refer to [GI-44, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#).




4. Apply the RTV Silicone Sealant without breaks to the specified location with the specified dimensions.
 - If there is a groove for the RTV Silicone Sealant application, apply the Sealant to the groove.
 - As for the bolt holes, normally apply the RTV Silicone Sealant inside the holes. Occasionally, it should be applied outside the holes.



- Within five minutes of gasket application, install the mating component.
- If the RTV Silicone Sealant protrudes, wipe it off immediately.
- Do not retighten after the installation.
- After 30 minutes or more have passed after installation, fill the engine with oil and coolant.

CAUTION:

If there are specific instructions in the service manual, observe them.



PREPARATION

[QR25DE]

PF0:00002


EBS006BD

PREPARATION


Special Service Tools

The actual shape of Kent-Moore tools may differ from those of special service tools illustrated here.


Tool number Tool name	Description
ST25051001 (J34301-1) Oil pressure gauge	Measuring oil pressure Maximum measuring range: 2,452 kPa (25 kg/cm², 356 psi)
ST25052000 (J34301-2) Hose	Adapting oil pressure gauge to cylinder block
KV10115801 (J37140-A) Oil filter wrench	Removing oil filter
WS39930000 (-) Tube presser	Pressing the tube of RTV Silicone Sealant




S-NT050



S-NT559



S-NT772



S-NT052

A

LU

C

D

E

F

G

H

I

J


K

L

M

LUBRICATION SYSTEM

Lubrication Circuit




PBIC0247E

LUBRICATION SYSTEM

[QR25DE]

System Drawing

EBS006BF




PBIC0248E

A
LU
C
D
E
F
G
H
I
J
K
L
M

ENGINE OIL

Inspection OIL LEVEL AND MUDINESS

- Before starting the engine, check the oil level. If the engine is already started, stop it and allow 10 minutes before checking.
- Check that the oil level is within the range shown in the figure.
- If it is out of range, add oil as necessary. Refer to [MA-13, "RECOMMENDED FLUIDS AND LUBRICANTS"](#) .
- Check the oil for white turbidity or remarkable contamination.
- If the oil becomes turbid and white, it is highly probable that it is contaminated with coolant. Diagnose the problem and correct as necessary.



OIL LEAKAGE


Check for oil leakage around the following areas.

- Oil pan
- Oil pan drain plug
- Oil pressure switch
- Oil filter
- IVTC (intake valve timing control) cover
- Front cover
- Mating surface between cylinder block and cylinder head
- Mating surface between cylinder head and rocker cover
- Crankshaft oil seal

OIL PRESSURE CHECK

WARNING:

- **Be careful not to burn yourself, as the engine oil may be hot.**
 - **For M/T models, put gearshift lever in Neutral position "N" position. For A/T models, put selector lever in Park "P" position.**
1. Check the oil level.
 2. Remove the under cover.
 3. Remove the oil pressure switch to connect the oil pressure gauge.
 4. After warming up the engine, check that oil pressure corresponding to the engine speed is produced.



Engine oil pressure [Oil temperature is 80 °C (176 °F)]

Engine speed (rpm)	Idle speed	2,000	6,000
Engine pressure kPa (bar.kg/cm ² , psi)	Approx. 98 (0.98,1.0, 14) or more	Approx. 294 (2.9, 3.0, 43) or more	Approx. 392 (3.9, 4.0, 57) or more


5. After checking, install the oil pressure switch as follows:
 - a. Remove the old thread sealant adhering to the switch and engine.
 - b. Apply thread sealant. Tighten the switch to specification.
Use Genuine High Performance Thread Sealant or equivalent. Refer to [GI-44, "RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS"](#) .

Oil pressure switch : 12.3 - 17.2 N·m (1.25 - 1.75 kg·m, 10 - 12 ft·lb)

Changing Engine Oil

WARNING:

- Be careful not to burn yourself, as the engine oil is hot.
 - Prolonged and repeated contact with used engine oil may cause skin cancer: try to avoid direct skin contact with used oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.
1. Warm up engine, and check for oil leakage from engine components.
 2. Stop the engine and wait for 10 minutes.
 3. Remove the oil drain plug and oil filler cap to drain the oil.
 4. Remove the oil filter and replace it with a new oil filter.
 5. Install the oil drain plug using a new washer.



Oil pan drain plug : 29 - 39 N·m (3.0 - 4.0 kg·m, 22 - 29 ft·lb)

CAUTION:

- Clean the oil drain plug and install with a new washer.
6. Fill the engine with the specified oil.
 - Refer to [MA-13, "RECOMMENDED FLUIDS AND LUBRICANTS"](#) .
- Oil capacity (Approximate):

Drain and refill	With oil filter change	4.2 ℓ (4 1/2 qt.)
	Without oil filter change	4.0 ℓ (4 1/4 qt.)
Dry engine (engine overhaul)		4.6 ℓ (4 7/8 qt.)

- The refill capacity depends on the oil temperature and drain time. Use these specifications for reference only.
 - Always use the dipstick to determine when the proper amount of oil is in the engine.
7. Warm up the engine and check the area around the oil drain plug and oil filter for oil leakage.
 8. Stop the engine and wait for 10 minutes.
 9. Check the oil level using the dipstick.

OIL FILTER


Removal and Installation

REMOVAL

1. Open the oil filter installation/removal access cover on the RH engine under cover.
2. Using an oil filter wrench, remove the oil filter.


CAUTION:

- Be careful not to get burned when the engine and engine oil are hot.
- When removing, prepare a shop cloth to absorb any oil leakage or spillage.
- Do not allow engine oil to adhere to the drive belts.
- Completely wipe off any oil that adheres to the engine and the vehicle.




INSTALLATION

1. Remove foreign material adhering to the oil filter installation surface.
2. Apply a thin coating of engine oil to the oil seal surface of the new oil filter.




3. Screw the oil filter manually until it touches the installation surface and then tighten it by 2/3 turn. Or tighten the oil filter to the correct specification.

Oil filter :14.7 - 20.5 N-m (1.5 - 2.1 kg-m, 11 - 15 ft-lb)



4. After warming up the engine, check for engine oil leakage.
5. Check the oil level and adjust the engine oil level as necessary. Refer to [LU-16, "ENGINE OIL"](#).




OIL PUMP

Removal and Installation

1. To remove the oil pump, remove the front cover.
2. Installation is in the reverse order of removal.

Disassembly and Assembly



- | | | |
|-------------------|--------------------|---------------------------|
| 1. Front cover | 2. Outer rotor | 3. Inner rotor |
| 4. Oil pump cover | 5. Regulator valve | 6. Regulator valve spring |
| 7. Regulator plug | | |

CAUTION:

Before installation, apply new engine oil to the parts as instructed in the figure.

DISASSEMBLY

1. Remove the oil pump cover.
2. Remove the inner rotor and the outer rotor from the front cover.
3. After removing the regulator plug, remove the regulator valve spring and the regulator valve.

INSPECTION AFTER DISASSEMBLY

1. Measuring the internal clearance of the oil pump components.
 - Measure the clearance with a feeler gauge.
 - Clearance between outer rotor and oil pump body (position 1):

Standard clearance : 0.114 - 0.179 mm (0.0045 - 0.0070 in)
 - Tip clearance between inner rotor and outer rotor (position 2):

Standard clearance : Less than 0.220 mm (0.0087 in)

OIL PUMP

[QR25DE]



- Measure clearance with feeler gauge and straightedge. Side clearance between inner rotor and oil pump body (position 3):

Standard clearance : 0.030 - 0.070 mm
(0.0012 - 0.0028 in)

Side clearance between outer rotor and oil pump body (position 4):

Standard clearance : 0.060 - 0.110 mm
(0.0024 - 0.0043 in)


- Calculate the clearance between inner rotor and oil pump body as follows.



2. Measure the outer diameter of protruded portion of inner rotor (Position 5).

3. Measure the inner diameter of oil pump body with an inside micrometer (Position 6).
(Clearance) = (Inner diameter of oil pump body) – (Outer diameter of inner rotor):

Standard clearance : 0.035 - 0.070 mm
(0.0014 - 0.0028 in)



4. Measure the regulator valve clearance.


- (Clearance) = D1 (Valve hole diameter) – D2 (Outer diameter of valve):

Standard clearance : 0.040 - 0.097 mm
(0.0016 - 0.0038 in)

CAUTION:

Coat the regulator valve with engine oil.

Check that it falls smoothly into the valve hole by its own weight.




OIL PUMP

[QR25DE]

ASSEMBLY

- Assembly is in the reverse order of disassembly.
- Install the inner rotor and outer rotor with the punched marks on the oil pump cover side.



A

LU

C

D

E

F

G

H

I

J

K

L

M

SERVICE DATA AND SPECIFICATIONS (SDS)

[QR25DE]

SERVICE DATA AND SPECIFICATIONS (SDS)

PF0:00030

Oil Pressure

EBS006BL

Engine speed rpm	Approximate discharge pressure kPa (bar, kg/cm ² , psi)
Idle speed	More than 98 (0.98, 1.0, 14)
2,000	294 (2.9, 3.0, 43)
6,000	392 (3.9, 4.0, 57)

Oil Pump

EBS006BM

Unit: mm (in)

Body to outer rotor radial clearance	0.114 - 0.179 (0.0045-0.0070)
Inner rotor to outer rotor tip clearance	Less than 0.220 (0.0087)
Body to inner rotor axial clearance	0.030 - 0.070 (0.0012 - 0.0028)
Body to outer rotor axial clearance	0.060 - 0.110 (0.0024 - 0.0043)
Inner rotor to brazed portion of housing clearance	0.035 - 0.070 (0.0014 - 0.0028)

Regulator Valve

EBS006BN

Unit: mm (in)

Regulator valve to oil pump cover clearance	0.040 - 0.097 (0.0016 - 0.0038)
---	---------------------------------

Oil Capacity

EBS006BO

Unit: ℓ (qt.)

With oil filter change	Approximately 4.2 ℓ (4 1/2 qt.)
Without oil filter change	Approximately 4.0 ℓ (4 1/4 qt.)
Dry engine (engine overhaul)	Approximately 4.6 ℓ (4 7/8 qt.)